



HITACHI

Inspire the Next

ENGLISH

SPLIT TYPE AIR CONDITIONER


INDOOR UNIT/OUTDOOR UNIT



MODEL


RAS-10SH1/RAC-10SH1
RAS-14SH1/RAC-14SH1

OUTDOOR UNIT



RAC-10SH1
RAC-14SH1

INDOOR UNIT



RAS-10SH1
RAS-14SH1



Instruction manual

Page 1~26

To obtain the best performance and ensure years of trouble free use, please read this instruction manual completely.

Инструкция по эксплуатации

Страницы 27~51
Для достижения наивысшей производительности и обеспечения долгой безаварийной эксплуатации полностью прочтите данную инструкцию по эксплуатации.





SAFETY PRECAUTION

ENGLISH

- Please read the "Safety Precaution" carefully before operating the unit to ensure correct usage of the unit.
- Pay special attention to signs of "▲ Warning" and "▲ Caution". The "Warning" section contains matters which, if not observed strictly, may cause death or serious injury. The "Caution" section contains matters which may result in serious consequences if not observed properly. Please observe all instructions strictly to ensure safety.
- The signs indicate the following meanings. (The following are examples of signs.)

This sign in the figure indicates prohibition.	Indicates the instructions that must be followed.
--	---

- Please keep this manual after reading.

PRECAUTIONS DURING INSTALLATION

	<ul style="list-style-type: none">• Do not reconstruct the unit. Water leakage, fault, short circuit or fire may occur if you reconstruct the unit by yourself.	PROHIBITION
	<ul style="list-style-type: none">• Please ask your sales agent or qualified technician for the installation of your unit. Water leakage, short circuit or fire may occur if you install the unit by yourself.	
	<ul style="list-style-type: none">• Please use earth line. Do not place the earth line near water or gas pipes, lightning-conductor, or the earth line of telephone. Improper installation of earth line may cause electric shock.	CONNECT EARTH LINE
	<ul style="list-style-type: none">• Be sure to use the specified piping set for R410A. Otherwise, this may result in broken copper pipes or faults.	
	<ul style="list-style-type: none">• A circuit breaker should be installed depending on the mounting site of the unit. Without a circuit breaker, the danger of electric shock exists.	
	<ul style="list-style-type: none">• Do not install the unit near a location where there is flammable gas. The outdoor unit may catch fire if flammable gas leaks around it. Piping shall be suitable supported with a maximum spacing of 1m between the supports.	PROHIBITION
	<ul style="list-style-type: none">• Please ensure smooth flow of water when installing the drain hose. If any failure is found in the drain path, water drops from the indoor and outdoor units, causing wet household effects.	
	<ul style="list-style-type: none">• Make sure that a single phase 230V power source is used. The use of other power sources may cause electrical components to overheat and lead to fire.	PROHIBITION

PRECAUTIONS DURING SHIFTING OR MAINTENANCE

	<ul style="list-style-type: none">• Should abnormal situation arise (like burning smell), please stop operating the unit and remove plug from the socket or turn off the circuit breaker. Contact your agent. Fault, short circuit or fire may occur if you continue to operate the unit under abnormal situation.	"OFF"
	<ul style="list-style-type: none">• Please contact your agent for maintenance. Improper self maintenance may cause electric shock and fire.	
	<ul style="list-style-type: none">• Please contact your agent if you need to remove and reinstall the unit. Electric shock or fire may occur if you remove and reinstall the unit yourself improperly.	
	<ul style="list-style-type: none">• Avoid an extended period of direct air flow for your health.	PROHIBITION
	<ul style="list-style-type: none">• Do not connect the power cable with an extension cable or do not plug too many leads of the other electric appliance into the socket where this cable is plugged. In addition, wire the cable with some allowances to prevent the cable from stretching. Not doing so will cause an electrical shock, heat generation or fire.	PROHIBITION
	<ul style="list-style-type: none">• Do not bundle the power cable, pull it, put something on it, heat it, process it, or put it between things. Breakage of the power cable may result. Use of a damaged cable may cause an electrical shock or a fire.	PROHIBITION
	<ul style="list-style-type: none">• Do not put objects like thin rods into the panel of blower and suction side because the high-speed fan inside may cause danger.	PROHIBITION



PRECAUTIONS DURING OPERATION

WARNING

- Do not use any conductor as fuse wire, this could cause fatal accident.



- During thunder storm, disconnect the plug top or turn off the circuit breaker.

- Spray cans and other combustibles should not be located within a meter of the air outlets of both indoor and outdoor units.
As a spray can's internal pressure can be increased by hot air, a rupture may result.



- The product shall be operated under the manufacturer specification and not for any other intended use.



- Do not attempt to operate the unit with wet hands, this could cause fatal accident.

- When operating the unit with burning equipments, regularly ventilate the room to avoid oxygen insufficiency.



- Do not direct the cool air coming out from the air-conditioner panel to face household heating apparatus as this may affect the working of apparatus such as the electric kettle, oven etc.

- Please ensure that outdoor mounting frame is always stable, firm and without defect. If not, the outdoor unit may collapse and cause danger.



- Do not wash the unit with water or place a water container such as a vase on the indoor unit.
Electrical leakage could be present and cause electric shock.

- Do not place plants or animals directly under the air flow as it is bad for the plants or animals.



- Do not climb on the outdoor unit or put objects on it.

CAUTION

- When operating the unit with the door and windows opened, (the room humidity is always above 80%) and with the air deflector facing down or moving automatically for a long period of time, water will condense on the air deflector and drips down occasionally. This will wet your furniture. Therefore, do not operate under such condition for a long time.



- If the amount of heat in the room is above the cooling or heating capability of the unit (for example: more people entering the room, using heating equipments and etc.), the preset room temperature cannot be achieved.

- This appliance especially indoor unit cleaning must be performed by authorized personnel only. Consult your sales agent.

Using a commercially available detergent or similar can damage the plastic parts or clog the drain pipe, causing water to drip with potential electric shock hazard.



- Do not touch the air outlet, bottom surface and aluminum fin of the outdoor unit.

You may get hurt.

- Do not touch the refrigerant pipe and connecting valve.
Burns may result.



- This appliance is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsible person to ensure that they can use this appliance safely.


- Young children should be supervised to ensure that they do not play with the appliance.




NAMES AND FUNCTIONS OF EACH PART

ENGLISH

INDOOR UNIT



OUTDOOR UNIT




MODEL NAME AND DIMENSIONS

MODEL	WIDTH (mm)	HEIGHT (mm)	DEPTH (mm)
RAS-10SH1, RAS-14SH1	795	295	198
RAC-10SH1, RAC-14SH1	750	548	288



INDOOR UNIT INDICATORS



FILTER LAMP

When the device is operated for a total of about 200 hours, the FILTER lamp lights to indicate that it is time to clean the filter.

OPERATION LAMP

This lamp lights during operation.

The OPERATION LAMP flashes in the following cases during heating.

(1) During preheating

For about 2–3 minutes after starting up.

(2) During defrosting

Defrosting will be performed about once every one hour when frost forms on the heat exchanger of the outdoor unit, for 5–10 minutes each time.


SIGNAL RECEIVING PORT

TIMER LAMP

This lamp lights when the timer is working.

OPERATION INDICATOR

1. Opening up the front panel



- Do not hold the moveable panel when the front panel is in either opened/closed position.

TEMPORARY SWITCH

Use this switch to start and stop when the remote controller does not work.

- By pressing the temporary switch, the operation is done in previously set operation mode.
- When the operation is done using the temporary switch after the power source is turned off and turn on again, the operation is done in automatic mode.


CAUTION

- Never try to force open/close the moveable panel manually.
Manually opening or closing the moveable panel may cause breakdowns. (The moveable panel will automatically close or open when the power supply is switched on or switched off and whenever the unit is in operations or has stopped operating.)




ENGLISH

2. Closing the Front Panel



- Pull toward the down direction.



- Initially press the left and the right sides of the front panel and finally press the central portion until you hear a clicking sound.

▲ CAUTION

- When front panel is shaky, there is a possibility panel coming off and falling down.
- Do not apply extra force on the front panel when it is opened up in the upright position.
Also frequent removal of the front panel from the front cover may cause damage.



Note

- Avoid to use the room air conditioner for cooling operation when the outside temperature is below -10°C (14°F).
The recommended maximum and minimum operating temperatures of the hot and cold sides should be as below:



		Cooling		Heating	
		Minimum	Maximum	Minimum	Maximum
Indoor	Dry bulb °C	21	32	20	27
	Wet bulb °C	15	23	12	19
Outdoor	Dry bulb °C	21	43	2	21
	Wet bulb °C	15	26	1	15



NAMES AND FUNCTIONS OF EACH PART

REMOTE CONTROLLER

- This controls the operation of the indoor unit.
The range of control is about 7 meters. If indoor lighting is controlled electronically, the range of control may be shorter, in some cases, the control signal may not be received.
This unit can be fixed on a wall using the fixture provided. Before fixing it, make sure the indoor unit can be controlled from the remote controller.
- Handle the remote controller with care.
Dropping it or getting it wet may compromise its signal transmission capability.
- After new batteries are inserted into the remote controller, the unit will initially require approximately 10 seconds to respond to commands and operate.



(A)	AUTO
(S)	HEAT
(D)	DEHUMIDIFY
(C)	COOL
(F)	FAN
	FANSPEED SILENT LOW MED HI
(S)	SLEEPING
(O)	STOP (CANCEL)
	START (RESERVE)
(I)	START/STOP
(T)	TIME
(T)	TIMER SET
(T)	TIMER SELECTOR ON TIMER OFF TIMER
(A)	AUTO SWING
(E)	EXTENDED AIRFLOW
	AIR PURIFIER

● Signal emitting window/transmission sign

Point this window toward the indoor unit when controlling it.
The transmission sign blinks when a signal is sent.

● Display

This indicates the room temperature selected, current time, timer status, function and intensity of circulation selected.

● START/STOP button

Press this button to start operation. Press it again to stop operation.

● AIR PURIFIER button

Use this button to start air purifying function.

● FAN SPEED selector

This determines the fan speed. Every time you press this button, the intensity of circulation will change from (A) (AUTO) to (HI) to (MED) to (LOW) to (SILENT). (This button allows selecting the optimal or preferred fan speed for each operation mode.)

● SLEEP button

Use this button to set the sleep timer.

● TEMPERATURE buttons

Use these buttons to raise or lower the temperature setting. (Keep pressed, and the value will change more quickly.)

● TIME button

Use this button to set and check the time and date.

● RESET button

Press this button after the batteries are replaced or when some irregular operation is found.

● FUNCTION selector

Use this button to select the operating mode. Every time you press it, the mode will change from (A) (AUTO) to (S) (HEAT) to (D) (DEHUMIDIFY) to (C) (COOL) and to (F) (FAN) cyclically.

● FAN SPEED selector

● AUTO SWING button

● EXTENDED AIRFLOW button

Pushes air out further for an extended airflow

● TIMER control

Use these buttons to set the timer.

● OFF-TIMER button

Select the turn OFF time.

● ON-TIMER button

Select the turn ON time.

● RESERVE button

Time setting reservation.

● CANCEL button

Cancel time reservation.

Precautions for Use

- Do not put the remote controller in the following places.
 - In direct sunlight
 - In the vicinity of a heater.
- Handle the remote controller carefully. Do not drop it on the floor, and protect it from water.
- Once the outdoor unit stops, it will not restart for about 3 minutes (unless you turn the power switch off and on or unplug the power cord and plug it in again).
This is to protect the device and does not indicate a failure.
- If you press the FUNCTION selector button during operation, the device may stop for about 3 minutes for protection.



VARIOUS FUNCTIONS


ENGLISH

■ Auto Restart Control

- If there is a power failure, operation will be automatically restarted when the power is resumed with previous operation mode and airflow direction.
(As the operation is not stopped by remote controller.)
 - If you intend not to continue the operation when the power is resumed, switch off the power supply. When you switch on the circuit breaker, the operation will be automatically restarted with previous operation mode and airflow direction.
- Note: 1. If you do not require Auto Restart Control, please consult your sales agent.
2. Auto Restart Control is not available when Timer or Sleep Timer mode is set.

AUTOMATIC OPERATION

The device will automatically determine the mode of operation, HEAT or COOL depending on the initial room temperature. The selected mode of operation will change when the room temperature varies.



1

Press the FUNCTION selector so that the display indicates the \textcircled{A} (AUTO) mode of operation.

- When AUTO has been selected, the device will automatically determine the mode of operation, HEAT or COOL depending on the current room temperature.
- When AUTO is first selected, the device will determine the current room temperature and select the proper operation mode accordingly.
- When the air conditioner has adjusted the room's temperature to the near preset temperature, it will begin to monitor operation. If the room temperature subsequently changes, the air conditioner will once again select the appropriate operation (heating or cooling) to adjust the temperature to the preset temperature. The monitoring operation range is $\pm 3^{\circ}\text{C}$ relative to the preset temperature.
- If the mode automatically selected by the unit is not satisfactory, manually change the mode setting (heat, dehumidify, cool or fan).


**START
STOP**

Press the \textcircled{I} (START/STOP) button.


Operation starts with a beep.

Press the button again to stop operation.

- As the settings are stored in memory in the remote controller, you only have to press the \textcircled{I} (START/STOP) button next time.



You can raise or lower the temperature setting as necessary by maximum of 3°C .



Press the temperature button and the temperature setting will change by 1°C each time.


- The preset temperature and the actual room temperature may vary somewhat depending on conditions.

Press the \textcircled{F} (FAN SPEED) button, AUTO and LOW is available.



HEATING OPERATION

- Use the device for heating when the outdoor temperature is under 21°C.
When it is too warm (over 21°C), the heating function may not work in order to protect the device.
- In order to keep reliability of the device, please use this device above -15°C of the outdoor temperature.




1

Press the FUNCTION selector so that the display indicates ☀ (HEAT).

2

Set the desired FAN SPEED with the ⚡ (FAN SPEED) button (the display indicates the setting).

- Ⓐ (AUTO) : The fan speed changes automatically according to the temperature of the air which blows out.
- ━ (HI) : Economical as the room will become warm quickly.
But you may feel a chill at the beginning.
- ━ (MED) : Quiet.
- ━ (LOW) : More quiet.
- ━ (SILENT) : Ultra quiet.



3

Set the desired room temperature with the TEMPERATURE buttons (the display indicates the setting).

The temperature setting and the actual room temperature may vary somewhat depending on conditions.

**START
STOP**

Press the ① (START/STOP) button. Heating operation starts with a beep. Press the button again to stop operation.

- As the settings are stored in memory in the remote controller, you only have to press the ① (START/STOP) button next time.

■ Defrosting

Defrosting will be performed about once an hour when frost forms on the heat exchange of the outdoor unit, for 5~10 minutes each time.

During defrosting operation, the operation lamp blinks in cycle of 3 seconds on and 0.5 second off.

The maximum time for defrosting is 20 minutes.


(If the piping length used is longer than usual, frost will likely to form.)



DEHUMIDIFYING OPERATION

ENGLISH

Use the device for dehumidifying when the room temperature is over 16°C.
When it is under 15°C, the dehumidifying function will not work.



1

Press the FUNCTION selector so that the display indicates
○ (DEHUMIDIFY).
The FAN SPEED is set at LOW or SILENT.


2

Set the desired room temperature with the TEMPERATURE button (the display indicates the setting).

The range of 20-26°C is recommended as the room temperature for dehumidifying.

**START
STOP**

Press the ① (START/STOP) button. Dehumidifying operation starts with a beep. Press the button again to stop operation.



■ As the settings are stored in memory in the remote controller, you only have to press the ① (START/STOP) button next time.


■ Dehumidifying Function

- When the room temperature is higher than the temperature setting: The device will dehumidify the room, reducing the room temperature to the preset level.
When the room temperature is lower than the temperature setting: Dehumidifying will be performed at the temperature setting slightly lower than the current room temperature, regardless of the temperature setting. The function will stop (the indoor unit will stop emitting air) as soon as the room temperature becomes lower than the setting temperature.
- The preset room temperature may not be reached depending on the number of people present in the room or other room conditions.



COOLING OPERATION

Use the device for cooling when the outdoor temperature is -10 to 42°C.
If humidity is very high (over 80%) indoors, some dew may form on the air outlet grille of the indoor unit.




1

Press the FUNCTION selector so that the display indicates
*(COOL).

2

Set the desired FAN SPEED with the (FAN SPEED) button (the display indicates the setting).

- (AUTO) : The FAN SPEED is HI at first and varies to MED automatically when the preset temperature has been reached.
 (HI) : Economical as the room will become cool quickly.
 (MED) : Quiet.
 (LOW) : More quiet.
 (SILENT) : Ultra quiet.



3

Set the desired room temperature with the TEMPERATURE buttons (the display indicates the setting).

The temperature setting and the actual room temperature may vary somewhat depending on conditions.

START
STOP

Press the (START/STOP) button. Cooling operation starts with a beep. Press the button again to stop operation. The cooling function does not start if the temperature setting is higher than the current room temperature (even though the (OPERATION) lamp lights).

The cooling function will start as soon as you set the temperature below the current room temperature.


- As the settings are stored in memory in the remote controller, you only have to press the (START/STOP) button next time.



FAN OPERATION

ENGLISH

You can use the device simply as an air circulator. Use this function to dry the interior of the indoor unit at the end of summer.




FAN SPEED (AUTO)

..... When the AUTO fan speed mode is set in the cooling/heating operation:

For the heating operation	<ul style="list-style-type: none">The fan speed will automatically change according to the temperature of discharged air.When the difference of room temperature and setting temperature is large, fan starts to run at HI speed.When the room temperature reaches setting temperature, fan speed changes to LOW automatically.
For the cooling operation	<ul style="list-style-type: none">When the difference of room temperature and setting temperature is large, fan starts to run at HI speed.After room temperature reaches the preset temperature, the cooling operation, which changes the fan speed and room temperature to obtain optimum conditions for natural healthful cooling will be performed.

EXTENDED AIRFLOW


- During operations, press the button to select the various operating modes that will set the preferred air flow direction and will also adjust the air flow speed to reach the furthest distance within its range. (During the cooling operating mode, the air flow direction and air flow speed will return to their original settings after 3 hours of operations).
 - If the (EXTENDED AIRFLOW) button is pressed while the AUTO SWING mode is set, the AUTO SWING mode is cancelled and the EXTENDED AIRFLOW mode is set.
 - If the (AUTO SWING) button is pressed while the EXTENDED AIRFLOW mode is set, the EXTENDED AIRFLOW mode is cancelled and the AUTO SWING mode is set.
 - If the (EXTENDED AIRFLOW) button is pressed when the horizontal air deflector stops at your preferred angle, the deflector will change to EXTENDED AIRFLOW.
 - As the angle of the horizontal air deflector changes, the air may blow directly onto the body.
- During stop operation, press the button will activate dry function for several minutes to protect the heat-exchange of indoor unit from mold and bad odour.





AIR PURIFYING OPERATION

Use this function for clean and comfortable air.



- 1 Press the button.
 - Operation start with the display indicates at any mode of operation.
 - The indoor unit will generate a negatively-charged ion to capture the finest and microscopic dust.
- 2 Press the button again to cancell the air purifying operation.

ADJUSTING THE AIR DEFLECTORS

1

Adjustment of the conditioned air in the upward and downward directions.

The horizontal air deflector is automatically set to the proper angle suitable for each operation. The deflector can be swung up and down continuously and also set to the desired angle using the (AUTO SWING) button.

- If the “ (AUTO SWING)” button is pressed once, the horizontal air deflector swings up and down. If the button is pressed again, the deflector stops in its current position. Several seconds (about 6 seconds) may be required before the deflector starts to move.
- Use the horizontal air deflector within the adjusting range shown in the right.
- When the operation is stopped, the horizontal air deflector moves and stops at the position where the air outlet closes.



CAUTION

- In “Cooling” operation, do not keep the horizontal air deflector swinging for a long time. Some dew may form on the horizontal air deflector and dew may drop.

2


Adjustment of the conditioned air to the left and right.

Hold the vertical air deflector as shown in the figure and adjust the conditioned air to the left and right.




When cooling, dehumidifying

Vertical



When heating

Vertical






HOW TO SET THE SLEEP TIMER

ENGLISH


Set the current time at first if it is not set before (see the pages for setting the current time). Press the (SLEEP) button, and the display changes as shown below.



Mode	Indication
Sleep timer	→ 1 hour → 2 hours → 3 hours → 7 hours Sleep timer off ←

Sleep Timer: The device will continue working for the designated number of hours and then turn off.
Point the signal window of the remote controller toward the indoor unit, and press the SLEEP button.
The timer information will be displayed on the remote controller. The TIMER lamp lights with a beep from the indoor unit. When the sleep timer has been set, the display indicates the turn-off time.

Example: If you set 3 hours sleep time at 11:38 p.m., the turn-off time is 2:38 a.m.



The device will be turned off by the sleep timer and turned on by on-timer.

1 Set the ON-timer.

2 Press the (SLEEP) button and set the sleep timer.

For heating:

In this case, the device will turn off in 2 hours (at 1:38 a.m.) and it will be turned on 6:00 next morning.


How to Cancel Reservation

Point the signal window of the remote controller toward the indoor unit, and press the (CANCEL) button.

The (RESERVED) sign goes out with a beep and the (TIMER) lamp turns off on the indoor unit.




HOW TO SET THE TIMER




Time

After you change the batteries;

- 1 Set the \odot (TIME) button.




OFF-Timer




You can set the device to turn off at the present time.

- 1 Press the \odot^\ominus (OFF-TIMER) button. The \odot (OFF) mark blinks on the display.



ON-Timer




- The device will turn on at the designated times.

- 1 Press the $\oplus\odot$ (ON-TIMER) button. The \odot (ON) mark blinks on the display.




ON/OFF-Timer




- The device will turn on (off) and off (on) at the designated times.
- The switching occurs first at the preset time that comes earlier.
- The arrow mark appearing on the display indicates the sequence of switching operations.


- 1 Press the \odot^\ominus (ON-OFF) button so that the \odot (OFF) mark blinks.



- 2 Set the turn-off time with the TIMER control button.
Press the \mid (RESERVE) button.



- 3 Press the $\oplus\odot$ (ON-TIMER) button so that the \odot (OFF) mark lights and the \odot (ON) mark blinks.



How to Cancel Reservation

Point the signal window of the remote controller toward the indoor unit, and press the \circ (CANCEL) button.

The \odot (RESERVED) sign goes out with a beep and the \odot (TIMER) lamp turns off on the indoor unit.

NOTE

You can set only one of the OFF-timer, ON-timer and ON/OFF-timer.



2 Press the (TIME) button.

3 Set the current time with the TIMER control button.



Example: The current time is 1:30 p.m.

4 Press the (TIME) button again. The time indication starts lighting instead of flashing.



- The time indication will disappear automatically in 10 second.
- To check the current time setting, press the (TIME) button twice.

The setting of the current time is now complete.

2 Set the turn-off time with the TIMER control button.



3 Point the signal window of the remote controller toward the indoor unit, and press the (RESERVE) button.

The (OFF) mark starts lighting instead of flashing and the sign (RESERVED) lights. A beep occurs and the (TIMER) lamp lights on the indoor unit.



Example: The device will turn off at 11:00p.m.

The setting of turn-off time is now complete.

2 Set the turn-on time with the TIMER control button.




3 Point the signal window of the remote controller toward the indoor unit, and press the (RESERVE) button.

The (ON) mark starts lighting instead of flashing and the (RESERVED) sign lights. A beep occurs and the (TIMER) lamp lights on the indoor unit.


Example:
The device will turn on at 7:00 a.m.
The setting of the turn-on time is now complete.

4 Set the turn-on time with the TIMER control button.



5 Point the signal window of the remote controller toward the indoor unit, and press the (RESERVE) button.

The (ON) mark starts lighting instead of flashing and the (RESERVED) sign lights. A beep occurs and the (TIMER) lamp lights on the indoor unit.



Example:
The device will turn off at 10:30 p.m. and it will be turned on at 7:00 a.m.
The settings of the turn-on/off times are now complete.

- The timer may be used in three ways: off-timer, on-timer, and ON/OFF (OFF/ON)-timer. Set the current time at first because it serves as a reference.

- As the time settings are stored in memory in the remote controller, you only have to press the (RESERVE) button in order to use the same settings next time.



HOW TO EXCHANGE THE BATTERIES IN THE REMOTE CONTROLLER

1

Remove the cover as shown in the figure and take out the old batteries.




2

Install the new batteries.

The direction of the batteries should match the marks in the case.

Push and pull to the direction of arrow



CAUTION

1. Do not use new and old batteries, or different kinds of batteries together.
2. Take out the batteries when you do not use the remote controller for 2 or 3 months.

TEMPORARY SWITCH

If the remote controller does not work due to battery failure, press this switch to start and stop operation.

- This temporary operation will be at the setting made most recently. (The unit will immediately go into automatic operation once power is switched on.)

CIRCUIT BREAKER


When you do not use the room air conditioner, set the circuit breaker to "OFF".



THE IDEAL WAYS OF OPERATION

ENGLISH


Suitable Room Temperature



⚠ Warning

Freezing temperature is bad for health and a waste of electric power.

Install curtain or blinds



It is possible to reduce heat entering the room through windows.

Ventilation


⚠ Caution

Do not close the room for a long period of time. Occasionally open the door and windows to allow the entrance of fresh air.




Effective Usage Of Timer

At night, please use the “OFF or ON timer operation mode”, together with your wake up time in the morning. This will enable you to enjoy a comfortable room temperature. Please use the timer effectively.



Do Not Forget To Clean The Air Filter

Dusty air filter will reduce the air volume and the cooling efficiency. To prevent from wasting electric energy, please clean the filter every 2 weeks.



Please Adjust Suitable Temperature For Baby And Children

Please pay attention to the room temperature and air flow direction when operating the unit for baby, children and old folks who have difficulty in movement.






FOR USER'S INFORMATION

The Air Conditioner And The Heat Source In The Room


⚠ Caution

If the amount of heat in the room is above the cooling capability of the air conditioner (for example: more people entering the room, using heating equipments and etc.), the preset room temperature cannot be achieved.



Not Operating For A Long Time

When the indoor unit is not to be used for a long period of time, please switch off the power from the mains. If the power from mains remains "ON", the indoor unit still consumes about 8W in the operation control circuit even if it is in "OFF" mode.



When Lightning Occurs

⚠ Warning


To protect the whole unit during lightning, please stop operating the unit and remove the plug from the socket.



Interference From Electrical Products

⚠ Caution

To avoid noise interference, please place the indoor unit and its remote controller at least 1m away from electrical products.





ATTACHING THE AIR CLEANSING FILTERS


ENGLISH

⚠ CAUTION

Cleaning and maintenance must be carried out only by qualified service personal. Before cleaning, stop operation and switch off the power supply.


1 Open the front panel.

- Pull up the front panel by holding it at both sides with both hands.




2 Remove the filter.

- Push upward to release the claws and pull out the filter.




3 Attaching the air cleansing filters to the filter.

- Attach the air cleansing filters to the frame by gently compress its both sides and release after insertion into filter frame.




⚠ CAUTION

Do not bend the air cleansing filter as it may cause damage to the structure.



4 Attach the filters.

- Attach the filters by ensuring that the surface written "FRONT" is facing front.
- After attaching the filters, push the front panel at three arrow portion as shown in figure and close it.



NOTE

- In case of removing the air cleansing filters, please follow the above procedures.
- The cooling capacity is slightly weakened and the cooling speed becomes slower when the air cleansing filters are used. So, set the fan speed to "HIGH" when using it in this condition.
- Do not operate the air conditioner without filter. Dust may enter the air conditioner and fault may occur.



MAINTENANCE

CAUTION

Cleaning and maintenance must be carried out only by qualified service personal. Before cleaning, stop operation and switch off the power supply.

1. AIR FILTER

Clean the air filter, as it removes dust inside the room. In case the air filter is full of dust, the air flow will decrease and the cooling capacity will be reduced. Further, noise may occur. Be sure to clean the filter following the procedure below.

PROCEDURE

1 Open the front panel and remove the filter

- Gently lift and remove the air cleansing filter from the air filter frame.




2

Vacuum dust from the air filter and air cleansing filter using vacuum cleaner. If there is too much dust, air filter only rinse under running tap water and gently brush it with soft bristle brush. Allow filters to dry in shade.



3

- Re-insert the air cleansing filter to the filter frame. Set the filter with "FRONT" mark facing front, and slot them into the original state.
- After attaching the filters, push the front panel at three arrow portions as shown in figure and close it.



CAUTION

- Do not wash with hot water at more than 40°C. The filter may shrink.
- When washing it, shake off moisture completely and dry it in the shade; do not expose it directly to the sun. The filter may shrink.
- Do not use detergent on the air cleansing filter as some detergent may deteriorate the filter electrostatic performance.

Servicing the electrical dust collector's electrical terminals

1

Use the remote control to stop all operations and remove the electrical power plug (or push the circuit breaker to its "OFF" position)

3

Using a toothbrush, remove all dirt from the electrical dust collector's electrical terminals.


- Brushing the electrical terminals with a toothbrush will remove the dirt (must use a dry toothbrush).

4

Re-install the front panel (For the front panel re-installation instructions, refer to page 19) insert the electrical plug (or push the circuit breaker to its "ON" position)

2

Remove the front panel (For the front panel removal instructions, refer to page 19)



Electrical dust collector's electrical terminals

CAUTION

- Before servicing, use the remote control to switch off all operations and pull out the electrical plug (or push the circuit breaker to its "OFF" position)
- Do not touch the electrical terminals when the electrical dust collector is operating. High tension electrical power may cause serious electric shocks.
- Caution should be taken to prevent the electrical dust collector's electrical terminals from coming into contact with water, as it may cause serious electric shocks.





ENGLISH


2. Washable Front Panel

- Remove the front panel and wash with clean water.
Wash it with a soft sponge.
After using neutral detergent, wash thoroughly with clean water.
- When front panel is not removed, wipe it with a soft dry cloth. Wipe the remote controller thoroughly with a soft dry cloth.
- Wipe the water thoroughly.
If water remains at indicators or signal receiver of indoor unit, it causes trouble.


Method of removing the front panel.
Be sure to hold the front panel with both hands to detach and attach it.



Removing the Front Panel



Attaching the Front Panel



- When the front panel is fully opened with both hands, push the right arm to the inside to release it, and while closing the front panel slightly, put it out forward.

- Move the projections of the left and right arms into the **Flanges** in the unit and securely insert them into the holes.

⚠ CAUTION

- Do not splash or direct water to the body of the unit when cleaning it as this may cause short circuit.
- Never use hot water (above 40°C), benzine, gasoline, acid, thinner or a brush, because they will damage the plastic surface and the coating.






⚠ CAUTION

Cleaning and maintenance must be carried out only by qualified service personal. Before cleaning, stop operation and switch off the power supply.

3. MAINTENANCE AT BEGINNING OF LONG OFF PERIOD

- Running the unit setting the operation mode to (FAN) and the fan speed to HI for about half a day on a fine day, and dry the whole of the unit.
- Switch off the power plug.



REGULAR INSPECTION

PLEASE CHECK THE FOLLOWING POINTS BY QUALIFIED SERVICE PERSONAL EITHER EVERY HALF YEARLY OR YEARLY. CONTACT YOUR SALES AGENT OR SERVICE SHOP.

1		Is the earth line disconnected or broken?
2		Is the mounting frame seriously affected by rust and is the outdoor unit tilted or unstable?
3		Is the plug of power line firmly plugged into the socket? (Please ensure no loose contact between them).



AFTER SALE SERVICE AND WARRANTY

ENGLISH

WHEN ASKING FOR SERVICE, CHECK THE FOLLOWING POINTS.

CONDITION	CHECK THE FOLLOWING POINTS
If the remote controller is not transmitting a signal. Remote controller display is dim or blank.) 	<ul style="list-style-type: none">● Do the batteries need replacement?● Is the polarity of the inserted batteries correct?
When it does not operate 	<ul style="list-style-type: none">● Is the fuse all right?● Is the voltage extremely high or low?● Is the circuit breaker "ON"?● Is the setting of operation mode different from other indoor units?
When it does not cool well When it does not heat well 	<ul style="list-style-type: none">● Is the air filter blocked with dust?● Does sunlight fall directly on the outdoor unit?● Is the air flow of the outdoor unit obstructed?● Are the doors or windows opened, or is there any source of heat in the room?● Is the set temperature suitable?● Are the air inlets or air outlets of indoor and outdoor units blocked?● Is the fan speed "LOW" or "SILENT"?



Notes

- In quiet operation or stopping the operation, the following phenomena may occasionally occur, but they are not abnormal for the operation.
 - (1) Slight flowing noise of refrigerant in the refrigerating cycle.
 - (2) Slight rubbing noise from the fan casing which is cooled and then gradually warmed as operation stops.
- The odor will possibly be emitted from the room air conditioner because the various odor, emitted by smoke, foodstuffs, cosmetics and so on, sticks to it. So the air filter and the evaporator regularly must be cleaned to reduce the odor.

- Please contact your sales agent immediately if the air conditioner still fails to operate normally after the above inspections. Inform your agent of the model of your unit, production number, date of installation. Please also inform him regarding the fault.
- Power supply shall be connected at the rated voltage, otherwise the unit will be broken or could not reach the specified capacity.

NOTE:

- If the supply cord is damaged, it must be replaced by the special cord obtainable at authorized service parts centers.
- On switching on the equipment, particularly when the room light is dimmed, a slight brightness fluctuation may occur. This is of no consequence.
The conditions of the local Power Supply Companies are to be observed.

- The moveable panels are not moving
 - Check to ensure whether the front panels have been installed in a proper manner.

