

HITACHI



PM**NO. 0214E**

SERVICE MANUAL

TECHNICAL INFORMATION

RAD-25NH4/RAC-25NH4
RAD-40NH4/RAC-50NH4

REFER TO THE FOUNDATION MANUAL

FOR SERVICE PERSONNEL ONLYRAD-25NH4
RAD-40NH4RAC-25NH4
RAC-50NH4

CONTENTS

SPECIFICATIONS	4
HOW TO USE	6
CONSTRUCTION AND DIMENSIONAL DIAGRAM	25
MAIN PARTS COMPONENT	27
WIRING DIAGRAM	29
CIRCUIT DIAGRAM	31
PRINTED WIRING BOARD LOCATION DIAGRAM	37
BLOCK DIAGRAM	39
BASIC MODE	41
REFRIGERATING CYCLE DIAGRAM	55
AUTO SWING FUNCTION	57
DESCRIPTION OF MAIN CIRCUIT OPERATION	58
SERVICE CALL Q & A	89
TROUBLE SHOOTING	92
PARTS LIST AND DIAGRAM	112

SPECIFICATIONS

TYPE		DC INVERTER (CEILING CASSETTE TYPE)			
		INDOOR UNIT	OUTDOOR UNIT	INDOOR UNIT	OUTDOOR UNIT
MODEL		RAD-25NH4	RAC-25NH4	RAD-40NH4	RAC-50NH4
POWER SOURCE		1 PHASE, 50 Hz, 220-240V		1 PHASE, 50 Hz, 220-240V	
COOLING	TOTAL INPUT (W)	720 (220~980)		1,400 (220~1,560)	
	TOTAL AMPERES (A)	3.31-3.03		6.43-5.89	
	CAPACITY	(kW)		2.50 (1.00 ~ 3.00)	
		(B.T.U./h)		4.00 (1.00 ~ 4.50)	
HEATING					
	TOTAL INPUT (W)	1,000 (210 ~ 1,280)		1,770 (210 ~ 1,920)	
	TOTAL AMPERES (A)	4.59-4.21		8.13-7.45	
	CAPACITY	(kW)		3.80 (1.10 ~ 4.80)	
		(B.T.U./h)		5.20 (1.10 ~ 5.80)	
DIMENSIONS (mm)	W	750	750	750	850
	H	235	570	235	650
	D	400	280	400	298
NET WEIGHT (kg)		19	38	19	60

SPECIFICATIONS AND PARTS ARE SUBJECT TO CHANGE FOR IMPROVEMENT

ROOM AIR CONDITIONER


INDOOR UNIT + OUTDOOR UNIT

JUNE 2004

Refrigeration & Air-Conditioning Division

SAFETY DURING REPAIR WORK

1. In order to disassemble and repair the unit in question, be sure to disconnect the power cord plug from the power outlet before starting the work.



2. If it is necessary to replace any parts, they should be replaced with respective genuine parts for the unit, and the replacement must be effected in correct manner according to the instructions in the Service Manual of the unit.

If the contacts of electrical parts are defective, replace the electrical parts without trying to repair them.



3. After completion of repairs, the initial state should be restored.
4. Lead wires should be connected and laid as in the initial state.
5. Modification of the unit by user himself should absolutely be prohibited.
6. Tools and measuring instruments for use in repairs or inspection should be accurately calibrated in advance.
7. In installing the unit having been repaired, be careful to prevent the occurrence of any accident such as electrical shock, leak of current, or bodily injury due to the drop of any part.
8. To check the insulation of the unit, measure the insulation resistance between the power cord plug and grounding terminal of the unit. The insulation resistance should be $1\text{M}\Omega$ or more as measured by a 500V DC megger.
9. The initial location of installation such as window, floor or the other should be checked for being and safe enough to support the repaired unit again. If it is found not so strong and safe, the unit should be installed at the initial location reinforced or at a new location.
10. Any inflammable thing should never be placed about the location of installation.
11. Check the grounding to see whether it is proper or not, and if it is found improper, connect the grounding terminal to the earth.



WORKING STANDARDS FOR PREVENTING BREAKAGE OF SEMICONDUCTORS

1. Scope

The standards provide for items to be generally observed in carrying and handling semiconductors in relative manufacturers during maintenance and handling thereof. (They apply the same to handling of abnormal goods such as rejected goods being returned).

2. Object parts

- (1) Micro computer
- (2) Integrated circuits (IC)
- (3) Field-effect transistors (FET)
- (4) P.C. boards or the like on which the parts mentioned in (1) and (2) of this paragraph are equipped.

3. Items to be observed in handling

- (1) Use a conductive container for carrying and storing of parts. (Even rejected goods should be handled in the same way).




Fig. 1. Conductive Container

- (2) When any part is handled uncovered (in counting, packing and the like), the handling person must always use himself as a body earth. (Make yourself a body earth by passing one M ohm earth resistance through a ring or bracelet).
- (3) Be careful not to touch the parts with your clothing when you hold a part even if a body earth is being taken.
- (4) Be sure to place a part on a metal plate with grounding.
- (5) Be careful not to fail to turn off power when you repair the printed circuit board. At the same time, try to repair the printed circuit board on a grounded metal plate.




Fig. 2. Body Earth

- (6) Use a three wire type soldering iron including a grounding wire.




Fig. 3. Grounding of the working table




Fig. 4. Grounding a soldering iron

Use a high insulation mode (100V, 10MΩ or higher) when ordinary iron is to be used.

- (7) In checking circuits for maintenance, inspection or some others, be careful not to have the test probes of the measuring instrument shortcircuit a load circuit or the like.

 CAUTION

1. In quiet operation or stopping the running, slight flowing noise of refrigerant in the refrigerating cycle is heard occasionally, but this noise is not abnormal for the operation.
2. When it thunders near by, it is recommend to stop the operation and to disconnect the power cord plug from the power outlet for safety.
3. The room air conditioner does not start automatically after recovery of the electric power failure for preventing fuse blowing. Re-press START/STOP button after 3 minutes from when unit stopped.
4. If the room air conditioner is stopped by adjusting thermostat, or missoperation, and re-start in a moment, there is occasion that the cooling and heating operation does not start for 3 minutes, it is not abnormal and this is the result of the operation of IC delay circuit. This IC delay circuit ensures that there is no danger of blowing fuse or damaging parts even if operation is restarted accidentally.
5. This room air conditioner should not be used at the cooling operation when the outside temperature is below 10°C (50°F).
6. This room air conditioner (the reverse cycle) should not be used when the outside temperature is below -15°C (5°F).
If the reverse cycle is used under this condition, the outside heat exchanger is frosted and efficiency falls.
7. When the outside heat exchanger is frosted, the frost is melted by operating the hot gas system, it is not trouble that at this time fan stops and the vapour may rise from the outside heat exchanger.


SPECIFICATIONS

MODEL		RAD-25NH4 RAD-40NH4	RAC-25NH4	RAC-50NH4
FAN MOTOR		20W	40 W	
FAN MOTOR CAPACITOR		NO	NO	
FAN MOTOR PROTECTOR		NO	NO	
COMPRESSOR		—	JU1012D	JU1013D
COMPRESSOR MOTOR CAPACITOR		NO	NO	
OVERLOAD PROTECTOR		NO	YES	
OVERHEAT PROTECTOR		NO	YES	
FUSE (for MICROPROCESSOR)		NO	3.0A	
POWER RELAY		NO	G4A	
POWER SWITCH		NO	NO	
TEMPORARY SWITCH		YES	NO	
SERVICE SWITCH		NO	YES	
TRANSFORMER		NO	NO	
VARISTOR		NO	450NR	
NOISE SUPPRESSOR		NO	YES	
THERMOSTAT		YES(IC)	YES(IC)	
REMOTE CONTROL SWITCH (LIQUID CRYSTAL)		YES	NO	
REFRIGERANT CHARGING VOLUME (Refrigerant 410A)	UNIT	-----	1150g	1400g
	PIPES (MAX. 20m)	WITHOUT REFRIGERANT BECAUSE COUPLING IS FLARE TYPE.		

[Indoor unit installation]

⚠ CAUTION

Always install the indoor unit level.
Units not installed level may leak.



- If connect indoor unit "RAD-40NH4" with outdoor unit "RAC-50NH4", optional flare adaptor for piping is necessary.

[Flare adaptor for piping: $\phi 9.52$ (3/8") $\rightarrow$ $\phi 12.7$ (1/2")
{Parts number TA261D-4 001}]

SAFETY PRECAUTION

- Please read the “Safety Precaution” carefully before operating the unit to ensure correct usage of the unit.
- Pay special attention to signs of “**▲ Warning**” and “**▲ Caution**”. The “Warning” section contains matters which, if not observed strictly, may cause death or serious injury. The “Caution” section contains matters which may result in serious consequences if not observed properly. Please observe all instructions strictly to ensure safety.
- The signs indicate the following meanings. (The following are examples of signs.)



This sign in the figure indicates prohibition.




Indicates the instructions that must be followed.

- Please keep this manual after reading.


PRECAUTIONS DURING INSTALLATION

WARNING	• Do not reconstruct the unit. Water leakage, fault, short circuit or fire may occur if you reconstruct the unit by yourself.	 PROHIBITION
	• Please ask your sales agent or qualified technician for the installation of your unit. Water leakage, short circuit or fire may occur if you install the unit by yourself.	
	• Please use earth line. Do not place the earth line near water or gas pipes, lightning-conductor, or the earth line of telephone. Improper installation of earth line may cause electric shock.	 CONNECT EARTH LINE
CAUTION	• Be sure to use the specified piping set for R410A. Otherwise, this may result in broken copper pipes or faults.	
	• A circuit breaker should be installed depending on the mounting site of the unit. Without a circuit breaker, the danger of electric shock exists.	
	• Do not install the unit near location where there is flammable gas. The outdoor unit may catch fire if flammable gas leaks around it. Piping shall be suitable supported with a maximum spacing of 1m between the supports.	 PROHIBITION
	• Please ensure smooth flow of water when installing the drain hose.	
	• Make sure that a single phase 230V power source is used. The use of other power sources may cause electrical components to overheat and lead to fire.	 PROHIBITION

PRECAUTIONS DURING SHIFTING OR MAINTENANCE

WARNING	• Should abnormal situation arise (like burning smell), please stop operating the unit and turn off the circuit breaker. Contact your agent. Fault, short circuit or fire may occur if you continue to operate the unit under abnormal situation.	
	• Please contact your agent for maintenance. Improper self maintenance may cause electric shock and fire.	
	• Please contact your agent if you need to remove and reinstall the unit. Electric shock or fire may occur if you remove and reinstall the unit yourself improperly.	

PRECAUTIONS DURING OPERATION

WARNING	• Avoid an extended period of direct air flow for your health.	 PROHIBITION
	 PROHIBITION • Do not put objects like thin rods into the panel of blower and suction side because the high-speed fan inside may cause danger.	
	• Do not use any conductor as fuse wire, this could cause fatal accident.	 PROHIBITION
	 • During thunder storm, please stop operating the unit and turn off the circuit breaker.	
	• Spray cans and other combustibles should not be located within a meter of the air outlets of both indoor and outdoor units. As a spray can's internal pressure can be increased by hot air, a rupture may result.	 PROHIBITION

PRECAUTIONS DURING OPERATION

CAUTION

- The product shall be operated under the manufacturer specification and not for any other intended use.



- Do not attempt to operate the unit with wet hands, this could cause fatal accident.

- When operating the unit with burning equipments, regularly ventilate the room to avoid oxygen insufficiency.




- Do not direct the cool air coming out from the air-conditioner panel to face household heating apparatus as this may affect the working of apparatus such as the electric kettle, oven etc.

- Please ensure that outdoor mounting frame is always stable, firm and without defect. If not, the outdoor unit may collapse and cause danger.




- Do not wash the unit with water or place a water container such as a vase on the indoor unit.
Electrical leakage could be present and cause electric shock.

- Do not place plants directly under the air flow as it is bad for the plants.



- Be sure to stop the operation by using the remote controller and turn off the circuit breaker during cleaning, the high-speed fan inside the unit may cause danger.

- Turn off the circuit breaker if the unit is not be operated for a long period.



- Do not climb on the outdoor unit or put objects on it.

- When operating the unit with the door and windows opened, (the room humidity is always above 80%) and with the air deflector facing down or moving automatically for a long period of time, water will condense on the air deflector and drips down occasionally. This will wet your furniture. Therefore, do not operate under such condition for a long time.



- If the amount of heat in the room is above the cooling or heating capability of the unit (for example: more people entering the room, using heating equipments and etc.), the preset room temperature cannot be achieved.

- Indoor unit cleaning must be performed by authorized personnel only. Consult your sales agent.
Using a commercially available detergent or similar can damage the plastic parts or clog the drain pipe, causing water to drip with potential electric shock hazard.



- Do not touch the air outlet, bottom surface and aluminum fin of the outdoor unit.
You may get hurt.

- Do not touch the refrigerant pipe and connecting valve.
Burns may result.



MULTI-AIR CONDITIONER

With this multi-air conditioner, several indoor units can be connected to one outdoor unit to be driven. You can operate the required number of indoor units.

Combination of operations:

When operation mode is selected:

- You cannot operate the indoor units in the following combinations.

One unit	Other unit
Heating	Cooling
	Dehumidifying
	Circulating (fan)


- The indoor unit which is switched on first continues to operate, but other indoor units which is switched on later does not operate while the lamp lights.
- To restart an indoor unit which was operated later, stop the indoor unit which was operated first or later and reset the type of operation, then perform operation again.

During automatic operation:

- When heating operation is automatically selected for the first indoor unit, the next indoor unit will then start to heat. Also, if cooling or dehumidifying is automatically selected for the first indoor unit, the next indoor unit will also start to cool or dehumidify.

Adjusting the number of indoor units:

Decrease the number of indoor units to be operated especially when it is very hot or very cold or when you want to reach the preset temperature quickly.




Stopped indoor units:

When an indoor unit is operated in the cooling, heating or dehumidifying mode in one room, the sound of refrigerant flow may be heard from a stopped indoor unit or a stopped indoor unit may become warm. This is because the indoor unit returns refrigerant to the outdoor unit to be ready for operation.

NAMES AND FUNCTIONS OF EACH PART


INDOOR UNIT



MODEL NAME AND DIMENSIONS

MODEL	WIDTH	HEIGHT	DEPTH
RAD-25NH4 RAD-40NH4 (INDOOR UNIT)	750mm (29-17/32")	235mm (9-1/4")	400mm (15-3/4")


INDOOR UNIT INDICATORS



NAMES AND FUNCTIONS OF EACH PART

REMOTE CONTROLLER

- This controls the operation of the indoor unit. The range of control is about 7 meters. If indoor lighting is controlled electronically, the range of control may be shorter.
This unit can be fixed on a wall using the fixture provided. Before fixing it, make sure the indoor unit can be controlled from the remote controller.
- Handle the remote controller with care. Dropping it or getting it wet may compromise its signal transmission capability.
- After new batteries are inserted into the remote controller, the unit will initially require approximately 10 seconds to respond to commands and operate.



Signal emitting window/transmission sign

Point this window toward the indoor unit when controlling it.
The transmission sign blinks when a signal is sent.

Display

This indicates the room temperature selected, current time, timer status, function and intensity of circulation selected.

START/STOP button

Press this button to start operation. Press it again to stop operation.

SLEEP button

Use this button to set the sleep timer.

TEMPERATURE buttons

Use these buttons to raise or lower the temperature setting. (Keep pressed, and the value will change more quickly.)

TIME button

Use this button to set and check the time and date.

RESET buttons

FUNCTION selector

Use this button to select the operating mode. Every time you press it, the mode will change from (AUTO) to (HEAT) to (DEHUMIDIFY) to (COOL) and to (FAN) cyclically.

FAN SPEED selector

This determines the fan speed. Every time you press this button, the intensity of circulation will change from (AUTO) to (HI) to (MED) to (LOW). (This button allows selecting the optimal or preferred fan speed for each operation mode.)

AUTO SWING button

Controls the angle of the horizontal air deflector.

TIMER control

Use these buttons to set the timer.

OFF-TIMER button

Select the turn OFF time.

ON-TIMER button


Select the turn ON time.

RESERVE button

Time setting reservation.

CANCEL button

Cancel time reservation.



	AUTO
	HEAT
	DEHUMIDIFY
	COOL
	FAN
	FAN SPEED LOW MED HI
	SLEEPING
	STOP (CANCEL)
	START (RESERVE)
	START/STOP
	TIME
	TIMER SET
	TIMER SELECTOR ON TIMER OFF TIMER
	AUTO SWING

Precautions for use

- Do not put the remote controller in the following places.
 - In direct sunlight
 - In the vicinity of a heater.
- Handle the remote controller carefully. Do not drop it on the floor, and protect it from water.
- Once the outdoor unit stops, it will not restart for about 3 minutes (unless you turn the power switch off and on or unplug the power cord and plug it in again).
This is to protect the device and does not indicate a failure.
- If you press the FUNCTION selector button during operation, the device may stop for about 3 minutes for protection.

VARIOUS FUNCTIONS


■ Auto Restart Control

- If there is a power failure, operation will be automatically restarted when the power is resumed with previous operation mode and airflow direction.
(As the operation is not stopped by remote controller.)
- If you intend not to continue the operation when the power is resumed, switch off the power supply. When you switch on the circuit breaker, the operation will be automatically restarted with previous operation mode and airflow direction.

Note: 1. If you do not require Auto Restart Control, please consult your sales agent.
2. Auto Restart Control is not available when Timer or Sleep Timer mode is set.

AUTOMATIC OPERATION

The device will automatically determine the mode of operation, HEAT, COOL, or DEHUMIDIFY, depending on the initial room temperature. The selected mode of operation will change when the room temperature varies. However, the mode of operation will not change when indoor unit connected to multi type outdoor unit.



1

Press the FUNCTION selector so that the display indicates the  (AUTO) mode of operation.


- When AUTO has been selected, the device will automatically determine the mode of operation, HEAT, COOL, or DEHUMIDIFY, depending on the current room temperature.

START
STOP

Press the  (START/STOP) button.
Operation starts with a beep.
Press the button again to stop operation.

- As the settings are stored in memory in the remote controller, you only have to press the  (START/STOP) button next time.


You can raise or lower the temperature setting as necessary by maximum of 3°C.



Press the temperature button and the temperature setting will change by 1°C each time.


- The preset temperature and the actual room temperature may vary somewhat depending on conditions.

Press the  (FAN SPEED) button, AUTO and LOW is available.



HEATING OPERATION

- Use the device for heating when the outdoor temperature is under 21°C.
When it is too warm (over 21°C), the heating function may not work in order to protect the device.
- In order to keep reliability of the device, please use this device above -15°C of the outdoor temperature.



1 Press the FUNCTION selector so that the display indicates ☀ (HEAT).

Set the desired FAN SPEED with the  (FAN SPEED) button (the display indicates the setting).

-  (AUTO) : The fan speed changes automatically according to the temperature of the air which blows out.
-  (HI) : Economical as the room will become warm quickly.
But you may feel a chill at the beginning.
-  (MED) : Quiet.
-  (LOW) : More quiet.

2

Set the desired room temperature with the TEMPERATURE buttons (the display indicates the setting).

3

The temperature setting and the actual room temperature may vary somewhat depending on conditions.

START STOP Press the ① (START/STOP) button. Heating operation starts with a beep. Press the button again to stop operation.

■ As the settings are stored in memory in the remote controller, you only have to press the ① (START/STOP) button next time.

■ Defrosting

Defrosting will be performed about once an hour when frost forms on the heat exchange of the outdoor unit, for 5~10 minutes each time.

During defrosting operation, the operation lamp blinks in cycle of 3 seconds on and 0.5 second off.


The maximum time for defrosting is 20 minutes.

However, if it is connected to multi type outdoor unit, the maximum time for defrosting is 15 minutes.

(If the piping length used is longer than usual, frost will likely to form.)

DEHUMIDIFYING OPERATION

Use the device for dehumidifying when the room temperature is over 16°C.
When it is under 15°C, the dehumidifying function will not work.



1

Press the FUNCTION selector so that the display indicates
○ (DEHUMIDIFY).
The FAN SPEED is set at LOW automatically.
The FAN SPEED button does not work.

**START
STOP**

Press the ① (START/STOP) button.

- When you want to change the operation mode, please use the FUNCTION selector.
- Set the desired temperature is available.
- You also can use the FUNCTION selector to select this operation.


■ Dehumidifying Function

- Dehumidifying takes place with a target temperature which is slightly lower than the room temperature setting. (However, target temperature is 16°C for a temperature setting of 16°C.)
If the room temperature becomes lower than the target value, operation stops. If the room temperature becomes higher than the target value, operation restarts.
- The preset room temperature may not be reached depending on the number of people present in the room or other room conditions.

COOLING OPERATION

Use the device for cooling when the outdoor temperature is 22-42°C.

If humidity is very high (over 80%) indoors, some dew may form on the air outlet grille of the indoor unit.



1

Press the FUNCTION selector so that the display indicates * (COOL).

2

Set the desired FAN SPEED with the  (FAN SPEED) button (the display indicates the setting).

 (AUTO) : The FAN SPEED is HI at first and varies to MED automatically when the preset temperature has been reached.

 (HI) : Economical as the room will become cool quickly.

 (MED) : Quiet.

 (LOW) : More quiet.

3

Set the desired room temperature with the TEMPERATURE buttons (the display indicates the setting).

The temperature setting and the actual room temperature may vary somewhat depending on conditions.


**START
STOP**

Press the  (START/STOP) button. Cooling operation starts with a beep. Press the button again to stop operation. The cooling function does not start if the temperature setting is higher than the current room temperature (even though the  (OPERATION) lamp lights). The cooling function will start as soon as you set the temperature below the current room temperature.

■ As the settings are stored in memory in the remote controller, you only have to press the  (START/STOP) button next time.

FAN OPERATION

You can use the device simply as an air circulator. Use this function to dry the interior of the indoor unit at the end of summer.



1

Press the FUNCTION selector so that the display indicates (FAN).

2

Press the (FAN SPEED) button.



(HI) : The strongest air blow.



(MED) : Quiet.



(LOW) : More quiet.

**START
STOP**


Press the ① (START/STOP) button. Fan operation starts with a beep.
Press the button again to stop operation.

FAN SPEED (AUTO)

... When the AUTO fan speed mode is set in the cooling/heating operation:


For the heating operation	- The fan speed will automatically change according to the temperature of discharged air. - As room temperature reaches the preset temperature, a very light breeze will blow.
For the cooling operation	- Operation starts in the “HI” mode to reach the preset temperature. - As room temperature approaches the preset temperature, fan speed automatically switches to “LOW”.

HOW TO SET THE TIMER




Time, Day, Month

After you change the batteries;




1 Set the current month and day with the TIMER control button.

OFF-Timer




You can set the device to turn off at the present time.

1 Press the (OFF-TIMER) button. The (OFF) mark blinks on the display.



ON-Timer


The device will turn on at the designated times.



1 Press the (ON-TIMER) button. The (ON) mark blinks on the display.




ON/OFF-Timer




- The device will turn on (off) and off (on) at the designated times
- The switching occurs first at the preset time that comes earlier
- The arrow mark appearing on the display indicates the sequence of switching operations.


1 Press the (ON-OFF) button so that the (OFF) mark blinks.



2 Set the turn-off time with the TIMER control button. Press the (RESERVE) button.



3 Press the (ON-TIMER) button so that the (OFF) mark lights and the (ON) mark blinks.



How to Cancel Reservation


Point the signal window of the remote controller toward the indoor unit, and press the (CANCEL) button.

The (RESERVED) sign goes out with a beep and the (TIMER) lamp turns off on the indoor unit.


NOTE

You can set only one of the OFF-timer, ON-timer and ON/OFF-timer.

2 Set the ☹ (TIME) button.



3 Set the current time with the TIMER control button.




Example: The current time is 1:30p.m.

4 Press the ☹ (TIME) button again. The time indication starts lighting instead of flashing.



- The time indication will disappear automatically in 10 seconds.
- To check the current time setting, press the ☹ (TIME) button twice. The setting of the current time is now complete.

2 Set the turn-off time with the TIMER control button.




3 Point the signal window of the remote controller toward the indoor unit, and press the I (RESERVE) button.

The ○ (OFF) mark starts lighting instead of flashing and the ☹ (RESERVED) sign lights. A beep occurs and the ☹ (TIMER) lamp lights on the indoor unit.



Example: The device will turn off at 11:00p.m.
The setting of turn-off time is now complete.

2 Set the turn-on time with the TIMER control button.




3 Point the signal window of the remote controller toward the indoor unit, and press the I (RESERVE) button.

The I (ON) mark starts lighting instead of flashing and the ☹ (RESERVED) sign lights. A beep occurs and the ☹ (TIMER) lamp lights on the indoor unit.




Example:
The device will turn on at 7:00 a.m.
The setting of the turn-on time is now complete.

4 Set the turn-on time with the TIMER control button.



5 Point the signal window of the remote controller toward the indoor unit, and press the I (RESERVE) button.

The I (ON) mark starts lighting instead of flashing and the ☹ (RESERVED) sign lights. A beep occurs and the ☹ (TIMER) lamp lights on the indoor unit.




Example:
The device will turn off at 10:30p.m. and it will be turned on at 7:00 a.m.
The settings of the turn-on/off time are now complete.


- The timer may be used in three ways: off-timer, on-timer and ON/OFF (OFF/ON)-timer. Set the current time at first because it serves as a reference.
- As the time settings are stored in memory in the remote controller, you only have to press the I (RESERVE) button in order to use the same settings next time.

HOW TO SET THE SLEEP TIMER


Set the current time at first if it is not set before (see the pages for setting the current time). Press the  (SLEEP) button and the display changes as shown below.




SLEEP

Mode	Indication
Sleep Timer	 A diagram showing a sequence of arrows: 1 hour → 2 hours → 3 hours → 7 hours. Below these, a long arrow points from 'Sleep timer off' back to the start of the sequence.

Sleep Timer: The device will continue working for the desired number of hours and then turn off.
Point the signal window of the remote controller toward the indoor unit, and press the SLEEP button.
The timer information will be displayed on the remote controller. The TIMER lamp lights with a beep from the indoor unit. When the sleep timer has been set, the display indicates the turn-off time.

The display shows a star icon, '3 H', and '2:38' with 'AM' to its right.


Example: If you set 3 hours sleep time at 11:38 p.m., the turn-off time is 2:38 a.m.

Two circular buttons labeled 'Sleep timer' and 'Start' with an arrow pointing from 'Sleep timer' to 'Start'.

The device will be turned off by the sleep timer and turned on by on-timer.

1 Set the ON-timer.

2 Press the  (SLEEP) button and set the sleep timer.

The display shows a star icon, '2 H', and '1:38' with 'AM' to its right. Below '2 H' is a downward arrow. To the right of '1:38' is a clock icon. Below the clock icon is '6:00' with 'AM' to its left.

For heating:
In this case, the device will turn off in 2 hours (at 1:38 a.m.) and it will be turned on at 6:00 next morning.

How to Cancel Reservation


Point the signal window of the remote controller toward the indoor unit, and press the  (CANCEL) button.
The  (RESERVED) sign goes out with a beep and the  (TIMER) lamp turns off on the indoor unit.

ADJUSTING THE AIR DEFLECTORS


1. NON DUCT

Adjustment of the conditioned air in the upward and downward directions.


According to “Dehumidifying” or “Cooling” operation, the horizontal air deflector is automatically set to the proper angle suitable for each operation. The deflector can be swung up and down and also set to the desired angle using the “ (AUTO SWING)” button. (If the angle of the deflector is changed, it will not return to the auto-set position after operations start unless the operation mode is switched.)



- If the “ (AUTO SWING)” button is pressed once, the horizontal air deflector swings up and down. If the button is pressed again, the deflector stops in its current position.
- Use the horizontal air deflector within the adjusting range shown on the right.
- When the auto swing operation is performed, if the horizontal air deflector is moved manually, the swing range may drift. However, it will return to the original operation range after a short time.



2. FULL DUCT • SEMI DUCT



- As shown in the diagram, perform by holding the horizontal air deflector.
- When adjusting the air direction, use a stepladder, etc.
- For full duct type and semi duct type, auto air deflector is not provided.

CAUTION

- When operating the unit in cooling operation with the air deflector facing down and moving automatically for a long period of time, water will condensed on the air deflector and drips down occasionally. This will wet your furniture.


HOW TO CHANGE THE BATTERIES IN THE REMOTE CONTROLLER

1 Remove the cover as shown in the figure and remove the old batteries.

2 Install the new batteries.
The direction of the batteries should match the marks in the case.

⚠ CAUTION


1. Do not mix new and old batteries, or different type of batteries together.
2. Remove the batteries when you do not use the remote controller for 2 or 3 months.



TEMPORARY SWITCH

Use the temporary switch when operation cannot be done with the remote controller.

1. By pressing the temporary switch, the operation is done in previously set operation mode.
When the operation is done using the temporary switch after the power source is turned off and turned on again, the operation is done in automatic mode.
2. When the operation is stopped or when the operation is done with the remote controller again. Press the temporary switch once again.



CIRCUIT BREAKER

When you do not use the room air conditioner, set the circuit breaker to "OFF".

HOW TO USE THE AIR CONDITIONER EFFECTIVELY

1. An average room temperature setting is probably the best for you as well as being economical.

- Excessive cooling or heating is not recommended for health reasons. High electricity bills may also result.
- Close the curtains or blinds to prevent heat from flowing into or escaping the room as well as to make more effective use of electricity.



2. At intervals, the doors and windows should be opened to let fresh air in.

⚠ CAUTION

Make sure the room is ventilated when operating the air conditioner at the same time as other heating appliances.



3. Using the timer is recommended before going to sleep or going out.



4. The following must never be used for cleaning the indoor and outdoor units:

- Benzine, thinner and scrub can damage plastic surfaces or coating.
- Hot water above 40°C can shrink the filter and deform plastic parts.



5. Do not block the air intake and air outlet.

- Do not block the air outlets and intakes of the indoor and outdoor units with curtains or other obstacles which could degrade air conditioner performance and cause unit failure.

MAINTENANCE

⚠ WARNING

- Before cleaning, stop unit operation with the remote controller and turn off the circuit breaker.

⚠ CAUTION



- Do not expose the unit to water as it may cause an electric shock.
- For cleaning inside the air conditioner, consult your sales agent.
- Avoid using detergent when cleaning the heat exchanger of the indoor unit. Unit failure may result.
- When cleaning the heat exchanger with a vacuum cleaner, make sure to wear gloves so as not to injure your hands on the heat exchanger fins.

1. AIR FILTER

Clean the air filter, as it removes dust inside the room.
Be sure to clean the filter once every two weeks so as not to consume electricity unnecessarily.

PROCEDURE

- 1** Remove suction grille before removing filter.
 - Lift up one side of suction grille and remove by inclining it (refer to diagram).
 - Press claw downward to remove filter.
- 2** Remove dust from the filter using a vacuum cleaner.
If there is too much dust, use neutral detergent. After using neutral detergent, wash with clean water and dry in the shade.
- 3** Install the filters.
Slightly lift the suction grille and close as original state.



⚠ CAUTION

- Do not wash with hot water at more than 40°C. The filter may shrink.
- When washing it, shake off moisture completely and dry it in the shade; do not expose it directly to the sun. The filter may shrink.
- Do not operate the air conditioner with the filter removed. Dust may enter the air conditioner and cause trouble.

2. CLEANING OF SUCTION GRILLE

- Wipe it with a soft dry cloth.
- When it is excessively dirty, wipe with soft cloth soaked in lukewarm water or neutral detergent. Then wipe thoroughly with a soft dry cloth.


⚠ CAUTION

- Never clean with hot water (above 40°C), benzine, gasoline, acid, thinner or a brush, because it will damage the plastic surface and the coating.



3. MAINTENANCE AT BEGINNING OF LONG OFF PERIOD

- Running the unit setting the operation mode to $\rightarrow$ (FAN) and the fan speed to HI for about half a day on a fine day, and dry the whole of the unit.
- Turn off the circuit breaker.



INFORMATION

CAPABILITIES

Heating Capability

- This room air conditioner utilizes a heat pump system that absorbs exterior heat and brings it into a room to be heated. As the ambient temperature gets lower, heating capability will also lower. In such a situation, the PAM and inverter work to increase compressor rpm to keep the unit's heating capability from decreasing. If the unit's heating performance is still unsatisfactory, other heating appliances should be used to augment this unit's performance.
- The air conditioner is designed to heat an entire room so that it may take some time before you feel warm. Timer operation is recommended for effective preheating ahead of the desired time.

CAUTION

Do not use a stove or any other high-temperature devices in proximity to the indoor unit.



Cooling and Dehumidifying Capabilities

- If the heat present in a room exceeds the unit's cooling capacity (for example, if there are many people in the room or other heating appliances are used), the preset room temperature may not be reached.

VARIOUS FUNCTIONS



- When fan speed, room temperature are set with the remote controller before starting manual operation and the buttons are released, the indication of settings will go off in 10 seconds and only the operation mode will be displayed.
- Pressing the  button while the unit is in operation will let the protective circuit work so that the unit will not operate for approximately 3 minutes.
- If you feel cold wind during warming operation with the  (HI) fan speed or want to make the unit operation quieter after the room is heated, use of  (AUTO) setting is recommended.
- With the  (LOW) setting, the unit's cooling capability will lower slightly.

TIMER PROGRAMMING/SLEEP TIMER OPERATION

- When the timer has been programmed, the unit will not operate even if the set time is reached unless the unit receives a signal from the remote controller. Confirm that timer programming is complete (beep) and the TIMER lamp of the indoor unit lights.
- If the  (SLEEP) button is pressed while the ON/OFF timer is programmed, the sleep timer takes priority.
- During sleep timer operation, the fan speed sets to  (LOW) regardless of the preset speed. The remote controller display indication will remain unchanged even with the  (LOW) setting.




REGULAR INSPECTION

PLEASE CHECK THE FOLLOWING POINTS EVERY EITHER HALF YEARLY OR YEARLY. CONTACT YOUR SALES AGENT SHOULD YOU NEED ANY HELP.

1		 WARNING	Check to see if the unit's earth line has been connected correctly. If the earth line is disconnected or faulty, unit failure or electric shock hazard may result.
2		 WARNING	Check to see if the mounting frame has rusted excessively or if the outdoor unit has tilted or become unstable. It could collapse or fall, causing injury.

AFTER SALES SERVICE AND WARRANTY

WHEN ASKING FOR SERVICE, CHECK THE FOLLOWING POINTS.

CONDITION	CHECK THE FOLLOWING POINTS
 If the remote controller is not transmitting a signal. (Remote controller display is dim or blank.)	• Do the batteries need replacement? • Is the polarity of the inserted batteries correct?
 When it does not operate.	• Is the fuse all right? • Is the voltage extremely high or low? • Is the circuit breaker "ON"? • Is the setting of operation mode different from other indoor units?
 When it does not cool well. When it does not heat well.	• Is the air filter blocked with dust? • Is the set temperature suitable? • Have the top and bottom air deflectors been adjusted to their correct positions according to the operation mode selected? • Are the air inlets or air outlets of indoor and outdoor units blocked? • Is the fan speed "LOW"?

■ The following phenomena do not indicate unit failure.

Hissing or fizzy sounds	Refrigerant flow noise in the pipe or valve sound generated when flow rate is adjusted.
Squeaking noise	Noise generated when the unit expands or contracts due to temperature changes.
Rustling noise	Noise generated with the indoor unit fan's rpm changing such as operation start times.
Clicking noise	Noise of the motorized valve when the unit is switched on.
Changing operation noise	Operation noise changes due to power variations according to room temperature changes.
Mist emission	Mist is generated as the air within the room is suddenly cooled by conditioned air.
Steam emitted from the outdoor unit	Water generated during defrosting operation evaporates and steam is emitted.
Odors	Caused as the smells and particles of smoke, food, cosmetics, etc. present in room air become attached the unit and blown off into the room again.
Perking noise	Noise of the ventilation fan sucking in air present in the drain hose and blowing out dehumidifying water that had accumulated in the condensed water collector. For details, consult your sales agent.

The outdoor unit continues to operate even if operation is stopped.	Defrosting is underway (as the heating operation is stopped, the microcomputer checks frost accumulated in the indoor unit and instructs the unit to perform automatic defrosting if necessary).
Even if the air conditioner operation is stopped, noise will be generated from the indoor unit.	This is the noise of the pump thoroughly discharging condensed water accumulated during cooling or dehumidifying even after operation is stopped.
Does not reach the temperature setting.	Actual room temperature may deviate slightly from the remote controller's temperature setting depending on the number of people in the room, indoor or outdoor conditions and influence of other rooms' conditions when the air conditioner is used for more than one room at the same time.

- If the unit still fails to operate normally after performing the above inspections, turn the circuit breaker off and contact your sales agent immediately.

Contact your sales agent immediately if the following phenomena should occur:



- The circuit breaker switches off or the fuse blows frequently.
- The switch operation is not stable.
- Foreign matter or water accidentally enters the unit interior.
- The power cord gets excessively hot or its insulation is torn or stripped.
- TIMER lamp on the indoor unit display blinks.
(As the nature of the failure can be identified by the blinking cycle, check the blinking cycle before turning off the circuit breaker.)



Notes

- In quiet operation or stopping the running, the following phenomena may occasionally occur, but they are not abnormal for the operation.
 - (1) Slight flowing noise of refrigerant in the refrigerating cycle.
 - (2) Slight rubbing noise from the fan casing which is cooled and then gradually warmed as operation stops.
- The odor will possibly be emitted from the room air conditioner because the various odor, emitted by smoke, foodstuffs, cosmetics and so on, sticks to it. So please clean the air filter and the evaporator regularly to reduce the odor.

- Please contact your sales agent immediately if the air conditioner still fails to operate normally after the above inspections. Inform your agent of the model of your unit, production number, date of installation. Please also inform him regarding the fault.

Please note:

On switching on the equipment, particularly when the room light is dimmed, a slight brightness fluctuation may occur. This is of no consequence.

The conditions of the local Power Supply Companies are to be observed.

Note

- Avoid to use the room air conditioner for cooling operation when the outside temperature is below 21°C (70°F).


The recommended maximum and minimum operating temperatures of the hot and cold sides should be as below:

		Cooling		Heating	
		Minimum	Maximum	Minimum	Maximum
Indoor	Dry bulb °C	21	32	20	27
	Wet bulb °C	15	23	12	19
Outdoor	Dry bulb °C	21	43	2	21
	Wet bulb °C	15	26	1	15

CONSTRUCTION AND DIMENSIONAL DIAGRAM

MODEL RAD-25NH4, RAD-40NH4

Unit: mm




Cautions:


1. Use insulated pipes for both large and small diameters.
2. An connection cable.

CONSTRUCTION AND DIMENSIONAL DIAGRAM FOR OUTDOOR

MODEL RAC-25NH4



MODEL RAC-50NH4



MAIN PARTS COMPONENT



THERMOSTAT

Thermostat Specifications

MODEL			RAD-25NH4/RAD-40NH4	
THERMOSTAT MODEL			IC	
OPERATION MODE			COOL	HEAT
TEMPERATURE °C (°F)	INDICATION 16	ON	14.9 (59.3)	20.4 (68.8)
		OFF	14.3 (58.3)	21.0 (69.1)
	INDICATION 24	ON	22.9 (73.7)	28.4 (83.1)
		OFF	22.3 (72.7)	29.0 (84.1)
	INDICATION 32	ON	30.9 (88.1)	36.4 (97.7)
		OFF	30.3 (87.1)	37.0 (98.8)

FAN MOTOR

Fan Motor Specifications

MODEL	RAD-25NH4 RAD-40NH4	RAC-25NH4 RAC-50NH4
POWER SOURCE	DC: 0 ~ 35V	DC360V
OUTPUT	20W	40W
CONNECTION		

BLU : BLUE

YEL : YELLOW

BRN : BROWN

WHT : WHITE

GRY : GRAY

ORN : ORANGE

GRN : GREEN

RED : RED


BLK : BLACK


PNK : PINK

VIO : VIOLET

COMPRESSOR MOTOR

Compressor Motor Specifications

MODEL		RAC-25NH4	RAC-40NH4
COMPRESSOR MODEL		JU1012D	JU1013D
PHASE		SINGLE	
RATED VOLTAGE		AC 220 ~ 240 V	
RATED FREQUENCY		50 Hz	
POLE NUMBER		4	
CONNECTION			
RESISTANCE VALUE (Ω)	20°C (68°F)	2M = 1.05	
	75°C (167°F)	2M = 1.28	



CAUTION

When the refrigerating cycle has been operated for a long time with the capillary tubes clogged or crushed or with too little refrigerant, check the color of the refrigerating machine oil inside the compressor. If the color has been changed conspicuously, replace the compressor.


WIRING DIAGRAM

MODEL RAD-25NH4 / RAC-25NH4
RAD-40NH4 / RAC-40NH4

BLU	: BLUE	YEL	: YELLOW	BRN	: BROWN	WHT	: WHITE
GRY	: GRAY	ORN	: ORANGE	GRN	: GREEN	RED	: RED
BLK	: BLACK	PNK	: PINK	VIO	: VIOLET		


INDOOR UNIT

OUTDOOR UNIT




CIRCUIT DIAGRAM

Remote Control



MODEL RAD-25NH4
RAD-40NH4



SYMBOL	Ω	λ	μ	PM	FORM
R11	27K	15%	V/D	C	
R12	30K	15%	V/C	C	
R13	0.3	15%		H	
R14	750	15%	V/C	C	
R15	560	15%	V/C	C	
R17	68K	15%	V/C	C	
R18	75K	12%	V/C	C	
R19	6.8K	12%	V/C	C	
R20					
R21	0.56	15%	1/4W	C	
R22	100	15%	V/C	C	
R23	33K	15%	V/C	C	
R24	100	15%	V/C	C	
R25					
R26					
R27					
R28	10K	15%	V/C	C	
R30					
R31	12.7K	11%	V/C	C	
R32	12.7K	11%	V/C	C	
R33	10K	15%	V/C	C	
R35	1K	15%	V/C	C	
R36	1K	15%	V/C	C	
R37	1K	15%	V/C	C	
R40	390	15%	V/C	C	
R402	390	15%	V/C	C	
R403	5.1K	15%	V/C	C	
R404	5.1K	15%	V/C	C	
R49		15%	V	A	

SYMBOL	Ω	#%	PM	FORM
RE00	10K	±5%	1/16	C
RE01	10K	±5%	1/16	C
RE02	0	±5%	1/16	C
PE11	10K	±5%	1/16	C
PE12	10K	±5%	1/16	C
PE15	10K	±5%	1/16	C
RE21	10K	±5%	1/16	C
RE22	1K	±5%	1/16	C
PE31	10K	±5%	1/16	C
PE32	1K	±5%	1/16	C
PE33	10K	±5%	1/16	C
PE34	1K	±5%	1/16	C
PE35	0K	±5%	1/16	C
PE36	1K	±5%	1/16	C
PE37	0K	±5%	1/16	C
PE38	1K	±5%	1/16	C
RE39				
PE41	3.9K	±5%	1/4	C
RE41	10K	±5%	1/16	C
RE02	10K	±5%	1/16	C
RE04	10K	±5%	1/16	C
RE10	10K	±5%	1/16	C
RE11	1K	±5%	1/16	C
RE12	10K	±5%	1/16	C
RE20	1K	±5%	1/16	C
RE21	10K	±5%	1/16	C
RE41	10K	±5%	1/16	C
RE42	10K	±5%	1/16	C
RE43	10K	±5%	1/16	C
RE44	10K	±5%	1/16	C

SYMBOL	Ω	η	PM	FORM
R645	10K	45K	V/C	C
R646	1K	45K	V/C	C
R647	1K	45K	V/C	C
R650	1K	45K	V/C	C
R651	1K	45K	V/C	C
R652	100	45K	V/C	C
R653	1K	45K	V/C	C
R654	10K	45K	V/C	C
R655	10K	45K	V/C	C
R656	10K	45K	V/C	C
R657	10K	45K	V/C	C
R658	10K	45K	V/C	C
R701	1K	45K	V/C	C
R711	3K	45K	V/C	C
R712	3K	45K	V/C	C
R722	0.3K	45K	V/C	C
R741	10	55K	V/C	C
R742	10	55K	V/C	C
R743	10	55K	V/C	C
R744	10	55K	V/C	C
R745	30	55K	V/C	C
R746	30	55K	V/C	C
R761				
R763	10K	45K	V/C	C
R764	1K	45K	V/C	C
R803	120K	45K	V/C	C
R804	120K	45K	V/C	C
R805	120K	45K	V/C	C
R806	120K	45K	V/C	C
R807	4.3K	45K	V/C	C
R810	680	45K	V/C	C
R811	2K	45K	V/C	C

SYMBOL	Ω	η (%)	WFO	FORM
HB12	39	$\pm 5\%$	I/B	C
HB13	39	$\pm 5\%$	I/B	C
HB21	1K	$\pm 5\%$	I/B	C
HB22	10K	$\pm 1\%$	I/B	C
HB23	10K	$\pm 1\%$	I/B	C
HB24	6.25K	$\pm 1\%$	I/B	C
HB25	10K	$\pm 1\%$	I/B	C
HB26	1K	$\pm 5\%$	I/B	C
HB27	3K	$\pm 5\%$	I/B	C
HB28	10K	$\pm 5\%$	I/B	C
HB29	5.1K	$\pm 5\%$	I/B	C
HB30	1K	$\pm 5\%$	I/B	C
HB31	1K	$\pm 1\%$	I/D	C
HB32	8.2K	$\pm 5\%$	I/B	C
HB33	8.25K	$\pm 1\%$	I/B	C
HB34	0.5K	$\pm 5\%$	I/B	C
HB35	0.7K	$\pm 1\%$	I/B	C
HB36	1K	$\pm 1\%$	I/B	C
HB37	2.7K	$\pm 5\%$	I/B	C
HB11	1K	$\pm 5\%$	I/A	C
HB12	47	$\pm 5\%$	I/D	C
HB13	1K	$\pm 5\%$	I/A	C
HB14	1K	$\pm 5\%$	I/A	C
HB15	1K	$\pm 5\%$	I/A	C
HB16	3.3K	$\pm 5\%$	I/B	C
HB17	3.3K	$\pm 5\%$	I/B	C
HB18	8K	$\pm 1\%$	I/B	C
HB19	8K	$\pm 1\%$	I/B	C
HB20	2.2K	$\pm 1\%$	I/B	C
HB21	10K	$\pm 5\%$	I/B	C
HB22	3K	$\pm 5\%$	I/B	C
HB23	10K	$\pm 5\%$	I/B	C

SYMBOL	IF	V	TYPE	FORM
C101	0.72	50	F	H
C102	330	63	D	PPH
C103	470P	530	C	C
C111	2.2	10	Q	QB
C112	1.00P	50	Q	C
C113	0.007	25	Q	C
C114	720	35	D	PPH
C115				
C116				
C121	0.1	25	Q	C
C122	0.0	10	D	PPH
C123	0.1	25	Q	C
C127				
C302	0.1	25	Q	C
C302	0.1	25	Q	C
C303	0.1	25	Q	C
C304	0.1	25	Q	C
C401	0.1	25	Q	C
Q13				
Q14				
C501	0.1	25	Q	C
C502	0.1	25	Q	C
C505	0.1	25	Q	C
C506	0.1	25	Q	C
C507	0.1	25	Q	C
C521	0.1	25	Q	C
C522	0.22	10	Q	C

SYMBOL	#F	V	TYPE	FORM
C523	0.1	25	CFI	C
C524	0.1	25	CFI	C
C541	000	50	DFFI	R
C601	0.1	25	CFI	C
C610	100P	50	CFI	C
C620	0.1	25	CFI	C
C651	0.1	25	CFI	C
C711	0.1	25	CFI	C
C712				
C752				
C803	0.1	25	CFI	C
C804	50P	50	DFFI	C
C802	0.2	25	F	H
C803	0.1	25	CFI	C
C804				
C821	0.01	50	F	H
C822	100P	50	CFI	C
C823	0.047	25	CFI	C
C824	0.01	50	CFI	C
C825	0.1	25	CFI	C
C901	330	63	DFFI	H
C903	100P	50	CFI	C
C904	0.1	25	CFI	C
C905		16	CFI	C
C909	10	16	1000	H
C916				
C932	1	16	CFI	C

SYMBOL	MODEL	FORM
G111	2S-J510	C
G112	2SC5209H	C
G113	2SC5209H	C
G114		C
G115	2SA1162Y	C
G116	RN1102	C
G521	RN1102	C
G541	2SD1266-P	H
G711	2SC4738GRY	C
G712	2SC344 IE	C
G722	RN1102	C
G801	RN1102	C
G802	RN2102	C
G803	2SC344 IE	C
G804	2SC4738GRY	C
G901	2S-D245	C
G902	2SD2462C	C
G903	2SC360	C
G932	2SC5209H	C
G933	2SC4738GRY	C

SYMBOL	MODEL	FORM
IC101	NUM36340M	C
RES2	MC78C05T	H
IC140	BR2CXDAF	C
IC501	AN-7711	C
IC521	HNVD142C	C
IC711	ULM9034NS	C
IC731	NUM3930M	C
IC901	NUM3930M	C

OSCILLATOR

SYMBOL	MODEL	FREQ.	FORM
RES1	ICST1554F10M4C	10 Hz	H

ZENER DIODE

SYMBOL	MODEL	FORM
ZD111	PDZ-2U2	C
ZD121	PLZ6.8A	C
ZD131	PLZ6.8A	C
ZD541	ROZ2U2Z	C
ZD901	UDZ-5B	C

SYMBOL	MODEL NO.	COLOR	FORM	REMARK
CN1	PH-4P (TOP ENTRY)	WHITE	H	ROOM/HEAT EXCHG TERMISTOR
CN2	XA-2P-V2 (TOP ENTRY)	IVORY	H	DRAIN PUMP
CN5	ZR-3P (TOP ENTRY)	IVORY	H	EFPROM / TEST
CN6	ZR-3P (TOP ENTRY)	IVORY	H	FLASH ROM
CN7	PH-4P (TOP ENTRY)	WHITE	H	STEPPING MOTOR
CN8	PH-4P (TOP ENTRY)	WHITE	H	STEPPING MOTOR
CN9	XH-4P (TOP ENTRY)	BLACK	H	HA
CN10	XA-4P (TOP ENTRY)	IVORY	H	INDOOR PAM FAN
CN11	EL-8P (TOP ENTRY)	WHITE	H	I.R BOARD
CN12A	PH-8P (TOP ENTRY)	WHITE	H	I.R BOARD
CN12B	XH-2P-V2 (TOP ENTRY)	WHITE	H	PSV SUPPLY
CN14				
CN16	XA-2P (TOP ENTRY)	IVORY	H	FLOAT SW

SYMBOL	MODEL	FORM
BZ	PKM13EPY	H


SYMBOL	MODEL	FORM
IRR	GP1J28RA	H

SYMBOL	MODEL	COLOR	FORM
LD1	SEL5720K	YEL	H
LD2	SEL5920A	GRN	H

SYMBOL	MODEL	CUR	FORM
ICP1	CCP2E-20	0.8A	C
ICP2	CCP2E-50	2.0A	C
ICP3			

DIODE		
SYMBOL	MODEL	FORM
D101	G4DL-6140	H
D111	D1FS6	C
D401	DAN202K	C
D402	ISS355	C
D403	DAP202K	C
D712	DAN202K	C
D821	ISS355	C
D901	LF801	C
D902	D1FL20U	C
D932	DAN202K	C

MODEL RAC-25NH4
RAC-50NH4



CAPACITORS									
MARK	RATING	TEMPERATURE	TYPE	HEIGHT	WIDTH	DEPTH	WEIGHT	RESISTANCE	REMARKS
C001	0.01	50	C	P	H	N			
C002	0.01	50	C	P	H	N			
C003	0.05	50	C	P	H	N			
C004	0.05	50	C	P	H	N			
C005	0.05	50	C	P	H	N			
C006	0.01	50	C	P	H	N			
C007	0.01	50	C	P	H	N			
C008	0.1	50	C	P	H	N			
C009	0.1	50	C	P	H	N			
C010	0.01	50	C	P	H	N			
C011	0.01	50	C	P	H	N			
C012	0.01	50	C	P	H	N			
C013	0.01	50	C	P	H	N			
C014	0.01	50	C	P	H	N			
C015	0.01	50	C	P	H	N			
C101	0.082	63	F	H	N				
C102	0.01	50	C	P	H	N			
C103	0.1	50	C	P	H	N			
C104	1000P	50	C	P	H	N			
C105	100	0	D	R	N	VR			
C106	0.07	2.2	50	C	P	H	N		
C201	0.047	25	C	C	H	VR			
C202	0.047	25	C	C	H	VR			
C203	0.047	25	C	C	H	VR			
C204	0.047	25	C	C	H	VR			
C205	0.047	25	C	C	H	VR			
C206	0.047	25	C	C	H	VR			
C207	0.047	25	C	C	H	VR			
C208	0.047	25	C	C	H	VR			
C209	0.047	25	C	C	H	VR			
C210	0.047	25	C	C	H	VR			
C211	0.047	25	C	C	H	VR			
C212	0.047	25	C	C	H	VR			
C213	0.047	25	C	C	H	VR			
C214	0.047	25	C	C	H	VR			
C215	0.047	25	C	C	H	VR			
C216	0.047	25	C	C	H	VR			
C217	0.047	25	C	C	H	VR			
C218	0.047	25	C	C	H	VR			
C219	0.047	25	C	C	H	VR			
C220	0.047	25	C	C	H	VR			
C221	0.047	25	C	C	H	VR			
C222	0.047	25	C	C	H	VR			
C223	0.047	25	C	C	H	VR			
C224	0.047	25	C	C	H	VR			
C225	0.047	25	C	C	H	VR			
C226	0.047	25	C	C	H	VR			
C227	2200P	50	C	C	H	VR			
C301	0.1	16	C	C	H	VR			
C302	0.1	16	C	C	H	VR			
C303	0.1	16	C	C	H	VR			
C304	0.1	16	C	C	H	VR			
C305	0.1	16	C	C	H	VR			
C401	0.01	25	D	R	N	VR			
C404	100	25	D	R	N	FF			
C405	0.1	16	C	C	H	VR			
C406	0.1	16	C	C	H	VR			
C408	0.1	16	C	C	H	VR			
C501	0.00068	50	C	C	H	VR			
C601	0.00068	50	C	C	H	VR			
C602	0.00068	50	C	C	H	VR			
C603	0.00068	50	C	C	H	VR			
C604	0.00068	50	C	C	H	VR			
C605	0.001	50	C	C	H	VR			
C606	0.001	50	C	C	H	VR			
C607	0.001	50	C	C	H	VR			
C608	0.001	50	C	C	H	VR			
C609	0.001	50	C	C	H	VR			
C610	0.001	50	C	C	H	VR			
C801	0.5	50	F	R	N				
C802	0.022	50	C	P	H	N			
C803	0.01	25	C	P	H	N			
C804	0.01	25	C	P	H	N			
C805	68	50	D	R	N	FF			
C806	0.5	50	F	R	N				
C807	0.01	25	C	P	H	N			
C808	0.01	25	C	P	H	N			
C809	0.5	50	F	R	N				
C810	0.01	25	C	P	H	N			
C811	0.01	25	C	P	H	N			
C812	0.01	25	C	P	H	N			
C901	0.01	9K	C	H	N				
C903	10	25	D	R	N				
C905	1000P	2K	C	P	H	VR			
C906	470P	50	C	P	H	VR			
C907	1800P	50	C	P	H	VR			
C908	1	50	C	P	H	N			
C909	0.01	50	C	P	H	N			
C910	330	50	D	R	N	VR			
C911	330	50	D	R	N	VR			
C912	330	25	D	R	N	FF			
C913	330	25	D	R	N	FF			
C914	270	16	D	R	N	FF			
C915	10	20	D	R	N	VR			
C916	0.1	50	C	P	H	N			
C998	0.001	50	C	P	H	N			
C999	0.01	50	C	P	H	N			
C991	90	10	D	R	N	FF			
C992	0.1	50	C	P	H	N			
C993	10	50	C	P	H	N			
C994	0.1	50	C	P	H	N			

PHOTOCOUPLERS				
MARK	MÔDEL	MEANTING	BRAND	REMARK
P01	TLPS2-1	H	M	
P02	TLPS2-1	H	M	
P0102	TLPS2-1	H	M	
P0701	TLPS2-1	H	M	

VARIABLE RESISTOR				
	RATING	MEANTING	BRAND	REMARK
VR1	200Ω, 300mV	A	M	

FUSE				
MARK	MÔDEL	MEANTING	BRAND	REMARK
RF FUSE1	JUMPER	A	M	
F001	250V1NC 25A	H	M	250V 25A
F002	N20S-250-2A	H	M	250V 2A
F101	N20S-250-2A	H	M	250V 2A


PRINTED WIRING BOARD LOCATION DIAGRAM

MODEL RAD-25NH4, RAD-40NH4


MAIN P.W.B.

Marking on P.W.B.

COMPONENT SIDE



SOLDERING SIDE




MAIN P.W.B. Marking on P.W.B



BLOCK DIAGRAM

MODEL RAD-25NH4 / RAC-25NH4
RAD-40NH4 / RAC-50NH4



BASIC MODE


MODEL RAD-25NH4, RAD-40NH4

Operation mode		Fan	Cooling	Dehumidifying (dehumidifying operation by the function select button only, not including that engaged by the dehumidify button)	Heating	Auto
Basic operation of start/stop switch		Start/stop switch Operation lamp Start Stop Start Stop				
Timer functions	Off-timer	Start/stop switch Operation lamp Cancel switch Operation temp Timer lamp Timer memory </				

Table 1 Mode data file

	RAD-25NH4	RAD-40NH4
LABEL NAME	VALUE	
WMAX	4400 min ⁻¹	5400 min ⁻¹
WMAX2	4500 min ⁻¹	5400 min ⁻¹
WSTD	3500 min ⁻¹	4700 min ⁻¹
WBEMAX	2800 min ⁻¹	3500 min ⁻¹
CMAX	2700 min ⁻¹	4700 min ⁻¹
CMAX2	2800 min ⁻¹	4700 min ⁻¹
CSTD	2450 min ⁻¹	4300 min ⁻¹
CKYMAX	2200 min ⁻¹	3500 min ⁻¹
CJKMAX	1800 min ⁻¹	2700 min ⁻¹
CBEMAX	1600 min ⁻¹	2000 min ⁻¹
WMIN	1500 min ⁻¹	1800 min ⁻¹
CMIN	1500 min ⁻¹	1800 min ⁻¹
STARTMC	60 Seconds	60 Seconds
DWNRATEW	80%	80%
DWNRATEC	80%	80%
SHIFTW	5.00°C	5.00°C
SHIFTC	1.66°C	1.66°C
CLMXTP	30.00°C	30.00°C
YNEOF	20.00°C	20.00°C
TEION	2.00°C	2.00°C
TEIOF	9.00°C	9.00°C
SFTDSW	2.00°C	2.00°C
DFTIM1	50 Minutes	55 Minutes
DFTIM2	60 Minutes	60 Minutes
DFTIM3	90 Minutes	90 Minutes

Basic Cooling Operation



Notes:



- (1) Condition for entering into Cool Dashed mode. When fan set to “Hi” or “Auto mode” and temperature difference between indoor temperature and set temperature has a corresponding compressor rpm (calculated value in Table 7) larger than WMAX.
- (2) Cool Dashed will release when i) a maximum 25 minutes is lapsed and ii) room temperature is lower than set temperature -3°C (thermo off) and iii) when room temperature has achieved setting temperature -1°C then maximum Cool Dashed time will be revised to 20 minutes. And iv) indoor fan is set to Lo and Med fan mode and v) change operation mode.
- (3) During Cool Dashed operation, thermo off temperature is set temperature (with shift value) -3°C . After thermo off, operation continue in Fuzzy control mode.
- (4) Compressor minimum “ON” time and “OFF” time is 3 minutes.
- (5) During normal cooling mode, compressor maximum rpm CMAX will maintain for 60 minutes if indoor temperature is lower than CLMXTP. No time constrain if indoor temperature is higher than CLMXTP.
- (6) When fan is set to “Hi”, compressor rpm will be limited to CKYMAX.
- (7) When fan is set to “Med”, compressor rpm will be limited to CJKMAX.
- (8) When fan is set to “Lo”, compressor rpm will be limited to CBEMAX.
- (9) During Cool Dashed, when room temperature reaches set temperature -1°C compressor rpm is actual rpm x DWNRATEC.

Table 2 ΔTCMAX


Temperature difference	Calculated compressor rpm
1.66	2265 min ⁻¹
2	2435 min ⁻¹
2.33	2600 min ⁻¹
2.66	2765 min ⁻¹
3	2935 min ⁻¹
3.33	3100 min ⁻¹
3.66	3265 min ⁻¹
4	3435 min ⁻¹
4.33	3600 min ⁻¹
4.66	3765 min ⁻¹
5	3935 min ⁻¹
5.33	4100 min ⁻¹
5.66	4265 min ⁻¹
6	4435 min ⁻¹
6.33	4600 min ⁻¹
6.66	4765 min ⁻¹
7	4935 min ⁻¹
7.33	5100 min ⁻¹
7.66	5265 min ⁻¹
8	5435 min ⁻¹
8.33	5600 min ⁻¹
8.66	5765 min ⁻¹
9	5935 min ⁻¹
9.33	6100 min ⁻¹
9.66	6265 min ⁻¹
10	6435 min ⁻¹
10.33	6600 min ⁻¹
10.66	6765 min ⁻¹
11	6935 min ⁻¹

Note:

- 1. See the data in Table 1 on page 43 for each constant in capital letters in the diagrams.




Dehumidifying



Notes:

- (1) If the room temperature is (cooling preset temperature) - (1.33°C) or less after 30 seconds from starting the operation, the operation is done assuming as the preset temperature = (room temperature at the time) - (2°C).
- (2) The indoor fan is operated in the "Lo" mode. During thermo OFF indoor fan will be OFF for 5 minutes and ON for 1 minute.
- (3) When the operation is started by the thermostat turning ON, the start of the indoor fan is delayed 32 seconds after the start of compressor operation.
- (4) The compressor is operated forcedly for 3 minutes after operation is started.
- (5) The minimum ON time and OFF time of the compressor are 3 minutes.

Basic Heating Operation



Notes:

- (1) Condition for entering into Hot Dashed mode. When fan set to “Hi” or “Auto mode” and i) Indoor temperature is lower than 18°C, and ii) outdoor temperature is lower than 10°C, and iii) Temperature difference between indoor temperature and set temperature has a corresponding compressor rpm (calculated value in Table 3) larger than WMAX.
- (2) Hot Dashed will release when i) Room temperature has achieved the set temperature + SFTDSW. ii) Thermo off.
- (3) During Hot Dashed operation, thermo off temperature is set temperature (with shift value) +3°C. After thermo off, operation continue in Fuzzy control mode.
- (4) Compressor minimum “ON” time and “OFF” time is 3 minutes.
- (5) During normal heating mode, compressor maximum rpm WMAX will maintain for 120 minutes if indoor temperature is higher than 18°C. No time limit constrain if indoor temperature is lower than 18°C and outdoor temperature is lower than 2°C.
- (6) During Hotkeep or Defrost mode, indoor operation lamp will blink at interval of 3 seconds “ON” and 0.5 second “OFF”.
- (7) When heating mode starts, it will enter into Hotkeep mode if indoor heat exchanger temperature is lower than YNEOF + 0.33°C.
- (8) When fan is set to “Med” or “Lo”, compressor rpm will be limited to WBEMAX.
- (9) In “Ultra-Lo” fan mode, if indoor temperature is lower than 18°C, indoor fan will stop. If indoor temperature is higher than 18°C + 0.33°C, fan will continue in “Ultra-Lo” mode. During Hotkeep or Defrost mode, fan will continue in “Ultra-Lo” mode.
- (10) During Hot Dashed or outdoor temperature is lower than –5°C, compressor rpm is WMAX2.
- (11) During Hot Dashed, when room temperature reaches set temperature + SFTDSW compressor rpm is actual rpm x DWNRATEW.


Table 3 ΔTWMAX

Temperature difference	Calculated compressor rpm
1.66	1965 min ⁻¹
2	2135 min ⁻¹
2.33	2300 min ⁻¹
2.66	2465 min ⁻¹
3	2635 min ⁻¹
3.33	2800 min ⁻¹
3.66	2965 min ⁻¹
4	3135 min ⁻¹
4.33	3300 min ⁻¹
4.66	3465 min ⁻¹
5	3635 min ⁻¹
5.33	3800 min ⁻¹
5.66	3965 min ⁻¹
6	4135 min ⁻¹
6.33	4300 min ⁻¹
6.66	4465 min ⁻¹
7	4635 min ⁻¹
7.33	4800 min ⁻¹
7.66	4965 min ⁻¹
8	5135 min ⁻¹
8.33	5300 min ⁻¹
8.66	5465 min ⁻¹
9	5635 min ⁻¹
9.33	5800 min ⁻¹
9.66	5965 min ⁻¹
10	6135 min ⁻¹
10.33	6300 min ⁻¹
10.66	6465 min ⁻¹
11	6635 min ⁻¹

Notes:


1. See the data in Table 1 on page 43 for each constant in capital letters in the diagrams.

Reversing Valve Defrosting




- Notes:
- (1) The defrosting inhibit period is set as shown in the diagram below. When defrosting has finished once, the inhibit period is newly set, based on the outdoor temperature when the compressor was started. During this period, the defrost signal is not accepted.
 - (2) If the difference between the room and outdoor temperature is large when defrosting is finished, the maximum compressor speed (WMAX) or (WMAX2) can be continued for 120 minutes maximum.
 - (3) The defrosting period is 12 minutes maximum.
 - (4) When operation is stopped during defrosting, it is switched to auto refresh defrosting.
 - (5) Auto refresh defrosting cannot be engaged within 15 minutes after operation is started or defrosting is finished.

Setting Defrosting Inhibit Period



- Notes:
- (1) The first inhibit time after operation start is set to DFTIM1.
 - (2) From the second time onwards, the inhibit time is set according to the time required for defrosting.
Reverse cycle operation time $\geq$ [DEFCOL] : DFTIM1 is set.
Reverse cycle operation time $<$ [DEFCOL] : The time corresponding to outdoor temperature is set.

Heating Sleep Operation



- Notes:
- (1) The sleep operation starts when the sleep key is pressed.
 - (2) When the sleep key is set, the maximum compressor speed is limited to WSTD+2000/2, and the indoor fan is set to "sleep Lo".
 - (3) 30 minutes after the sleep key is set, the sleep shift of set temperature starts.
 - (4) The maximum sleep shift of set temperature is 5°C, and the minimum is 12°C.
 - (5) If the operation mode is changed during sleep operation, the changed operation mode is set and sleep control starts.
 - (6) The indoor fan speed does not change even when the fan speed mode is changed. (Lo)
 - (7) When defrosting is to be set during sleep operation, defrosting is engaged and sleep operation is restored after defrosting.
 - (8) When operation is stopped during sleep operation, the set temperature when stopped, as well as the time, continue to be counted.
 - (9) If the set time is changed during sleep operation, all data including set temperature, time, etc. is cleared and restarted.
 - (10) If sleep operation is canceled by the cancel key or sleep key, all data is cleared.

REFRIGERATING CYCLE DIAGRAM


MODEL RAD-25NH4

RAC-25NH4

COOLING, DEHUMIDIFYING, DEFROSTING

OUTDOOR UNIT


INDOOR UNIT



HEATING

OUTDOOR UNIT

INDOOR UNIT




REFRIGERATING CYCLE DIAGRAM


MODEL RAD-40NH4

RAC-50NH4

COOLING, DEHUMIDIFYING, DEFROSTING



HEATING



AUTO SWING FUNCTION

MODEL: RAD-25NH4, RAD-40NH4

INPUT SIGNAL	PRESENT CONDITION			OPERATING SPECIFICATION	REFERENCE
	OPERATION	OPERATION MODE	AIR DEFLECTOR		
KEY INPUT	STOP	EACH MODE	STOP	ONE SWING (CLOSING AIR DEFLECTOR) ① DOWNWARD ② UPWARD	INITIALIZE AT NEXT OPERATION.
			DURING ONE SWING	STOP AT THE MOMENT.	
	DURING OPERATION	AUTO COOL COOL FAN AUTO DRY DRY	STOP	START SWINGING ① DOWNWARD ② UPWARD ③ DOWNWARD	
			DURING SWINGING	STOP AT THE MOMENT.	
THERMO. ON (INTERNAL FAN ON) THERMO. ON (INTERNAL FAN OFF)	DURING OPERATION	AUTO HEAT HEAT CIRCULATOR	STOP	START SWINGING ① DOWNWARD ② UPWARD ③ DOWNWARD	
			DURING SWINGING	STOP AT THE MOMENT.	
		AUTO DRY DRY AUTO HAET HEAT CIRCULATOR	TEMPORARY STOP	START SWING AGAIN.	
			DURING SWINGING	STOP SWINGING TEMPORARILY. (SWING MODE IS CLEARED IF SWING COMMAND IS TRANSMITTED DURING TEMPORARY STOP.)	
MAIN SWITCH ON	STOP	COOL FAN DRY HEAT CIRCULATOR	STOP DURING ONE SWING	INITIALIZE ① DOWNWARD ② UPWARD	
			STOP DURING ONE SWING	INITIALIZE ① DOWNWARD	
MAIN SWITCH OFF	DURING OPERATION	EACH MODE	STOP DURING SWINGING	ONE SWING (CLOSING AIR DEFLECTOR) ① DOWNWARD ② UPWARD	INITIALIZE AT NEXT OPERATION.
			DURING INITIALIZING		
CHANGE OF OPERATION	DURING OPERATION	EACH MODE	STOP	INITIALIZING CONDITION OF EACH MODE.	
			DURING SWINGING	STOP SWINGING AND MODE BECOMES INITIALIZING CONDITION.	

DESCRIPTION OF MAIN CIRCUIT OPERATION

MODEL RAD-25NH4, RAD-40NH4

1. Reset Circuit




Fig. 1-1




Fig. 1-2

- The reset circuit initializes the microcomputer program when power is ON or OFF.
- Low voltage at pin ⑦ resets the microcomputer and Hi activates the microcomputer.
- When power "ON" 5V voltage rises and reaches 4.4V, pin ① of IC521 is set to "Hi". At this time the microcomputer starts operation.
- When power "OFF" voltage drops and reaches 4.2V, pin ① of IC521 is set to "Low". This will RESET the microcomputer.

2. Receiver Circuit




Fig. 2-1

- The light receiver unit receives the infrared signal from the wireless remote control. The receiver amplifies and shapes the signal and outputs it.

3. Buzzer Circuit




Fig. 3-1 Buzzer Circuit

- When the buzzer sounds, an approx. 3.9kHz square signal is output from buzzer output pin (30) of the microcomputer. After the amplitude of this signal has been set to 12Vp-p by a transistor, it is applied to the buzzer. The piezoelectric element in the buzzer oscillates to generate the buzzer's sound.




Fig. 3-2 Buzzer Operation

4. Auto Sweep Motor Circuit




Fig.4-1

- Fig. 4-1 shows the Auto sweep motor drive circuit; the signals shown in Fig.4-2 are output from pins ⑮ – ⑱ of microcomputer.




Fig.4-2 Microcomputer Output Signals

- As the microcomputer's outputs change as shown in Fig.4-2, the core of the auto sweep motor is excited to turn the rotor. Table 4-1 shows the rotation angle of horizontal air deflectors.

Table 4-1 Auto sweep Motor Rotation

	Rotation angle per step (°)	Time per step (ms.)
Horizontal air deflectors	0.0882	10

- The air deflectors are driven by the stepping motors, which are instructed by the microcomputer.
- The air deflectors on the left and right are each driven by two stepping motors.
- The stepping motors and main unit are connected via relay connectors. The air deflectors will not operate unless the relay connectors are connected: Securely connect the relay connectors identified by colors when attaching the panel.
- Before removing the panel for servicing, be sure to disconnect the relay connector to protect the lead wires.

5. Room Temperature Thermistor Circuit

- Fig. 5-1 shows the room temperature thermistor circuit.




Fig. 5-1

- The voltage at (A) depends on the room temperature as shown in Fig. 5-2.




Fig. 5-2

6. Heat exchanger temperature thermistor circuit




Fig. 6-1

- The circuit detects the indoor heat exchanger temperature and controls the following.
 - (1) Preheating.
 - (2) Low-temperature defrosting during cooling and dehumidifying operation.
 - (3) Detection of the reversing valve non-operation or heat exchanger temperature thermistor open.

The voltage at (A) depends on the heat exchanger temperature as shown in Fig. 6-2.




Fig. 6-2

7. Initial Setting Circuit (IC401)

- When power is supplied, the microcomputer reads the data in IC401 (E²PROM) and sets the preheating activation value and the rating and maximum speed of the compressor, etc. to their initial values.
- Data of self-diagnosis mode is stored in IC401; data will not be erased even when power is turned off.




Fig. 7-1

Model RAC-25NH4, RAC-50NH4

1. Power Circuit




Fig. 1-1

- This circuit full-wave rectifies 220-240V AC applied between terminals L and N, and boosts it to a required voltage with the active module, to create a DC voltage.

The voltage becomes 260-360V when the compressor is operated

(1) Active module

The active filter, consisting of a reactor and switching element, eliminates higher harmonic components contained in the current generated when the compressor is operated, and improves the power-factor.

(2) Diode stacks

These rectify the 220-240V AC from terminals L and N to a DC power supply.

< Reference >

- In case of malfunction or defective connection: Immediately after the compressor starts, it may stop due to “abnormally low speed” active error, etc.

The compressor may continue to operate normally, but the power-factor will decrease, the operation current will increase, and the overcurrent breaker of the household power board will probably activate.

- In case of active module faulty or defective connection:

Although the compressor continues to operate normally, the power-factor will decrease, the operation current will increase, and the overcurrent breaker of the household power board will probably activate.

< Reference >

- If diode stack 1 is faulty, the compressor may stop due to “Ip”, “abnormally low speed”, etc. immediately after it starts, or it may not operate at all because no DC voltage is generated between the positive ⊕ and negative ⊖ terminals.

If diode stack 1 is faulty, be aware that the 25A fuse might also have blown.

- If diode stack 2 is faulty, DC voltage may not be generated and the compressor may not operate at all. Also, be aware that the 3A fuse might have blown.

(3) Smoothing capacitor (C501, C502, C503)

This smoothes (averages) the voltage rectified by the diode stacks.

<Notes> Smoothing capacitor C501 is not available for model RAC-25NH4 and RAC-35NH4.




Fig. 1-2




Fig. 1-3

- Be careful to avoid an electric shock as a high voltage is generated. Also take care not to cause a short-circuit through incorrect connection of test equipment terminals. The circuit board could be damaged.

(4) Smoothing capacitor (C010, C011)

This smoothes (averages) the voltage rectified by the diode stack2. A DC voltage is generated in the same way as in Fig. 1-3.

Voltage between + side of C010 and – side of C011 is about 330V.

(5) C001 to C003, C012 to C015, C007, C008, NF COIL1, COIL, absorb electrical noise generated during operation of compressor, and also absorb external noise entering from power line to protect electronic parts.

(6) Surge absorber, Varistor 1, 2, 3, absorbs external power surge.

(7) Inrush protective resistor (R007, R008)

This works to protect from overcurrent when power is turned on.

< Reference >

- When inrush protective resistor is defective, diode stack may malfunction. As a result, DC voltage is not generated and no operation can be done.

2. Indoor/Outdoor Interface Circuit

- The interface circuit superimposes an interface signal on the DC 35V line supplied from the outdoor unit to perform communications between indoor and outdoor units. This circuit consists of a transmitting circuit which superimposes an interface signal transmit from the microcomputer on the DC 35V line and a transmitting circuit which detects the interface signal on the DC 35V line and outputs it to the microcomputer.
- Communications are performed by mutually transmitting and receiving the 4-frame outdoor request signal one frame of which consists of a leader of approx. 100 ms., start bit, 8-bit data and stop bit and the command signal with the same format transmit from the indoor unit.
- Communication signal from outdoor microcomputer to indoor microcomputer. At first outdoor microcomputer will send a request signal (SDO) to indoor microcomputer. A high-frequency IF signal approx. 38 KHz is generated and modulated by the request signal (SDO) inside the outdoor microcomputer then output to pin (11) of microcomputer. This modulated IF signal is output to pin (30) of HIC and amplified by amp. This signal is superimposed to DC 35V line via C801 and L801.
To prevent erroneous reception, the outdoor microcomputer is designed so that it cannot receive a signal while it is outputting a request signal.
The receiving circuit in the indoor unit consists of a comparator and transistor. The interface signal from the outdoor unit on the DC 35V line is supplied to C821, where DC components are eliminated, and is then shaped by the comparator. The shaped signal is detected by diode, amplified by amp, and output to pin (49) of the indoor microcomputer.
Fig. 2-2 shows the voltages at each component when data is transferred from the outdoor microcomputer to the indoor microcomputer.
- Communication signal from indoor microcomputer to outdoor microcomputer. The request signal (SDO) generates by indoor microcomputer is output to pin (50), and amplifies by C801. IF signal approx. 38 kHz is generated by comparator, then modulate by the request signal from pin (50) of indoor microprocessor. This modulated IF signal is then amplified and superimposed to DC 35V line via L801 and C802 of indoor interface circuit.
Fig. 2-3 shows the voltages at each component when data is transferred from outdoor microcomputer to indoor microcomputer.
The circuit operation of the outdoor receiving circuit is same as indoor receiving circuit.

- Fig. 2-1 shows the interface circuit used for the indoor and outdoor microcomputers to communicate with each other.




Fig. 2-1 Indoor/outdoor interface Circuit




Fig. 2-2 Voltages Waveforms of indoor / Outdoor Microcomputers (Outdoor to Indoor Communications)





Fig. 2-3 Voltages Waveforms of indoor / Outdoor Microcomputers (Indoor to Outdoor Communications)

[Serial Communications Format during Normal Communications]

(1) Outdoor microcomputer (HIC) to indoor microcomputer



(2) Indoor microcomputer to outdoor microcomputer (HIC)




Fig. 2-4

[Serial Communications Data]

(1) Outdoor message

Character No.	0								1								2								3							
Bit No.	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7
Contents	Multi-bit		During forced operation	Defrost request signal	Self-diagnosis (0 LSB)	Self-diagnosis (1)	Self-diagnosis (2)	Self-diagnosis (3 MSB)	Outside temperature (0 LSB)	Outside temperature (1)	Outside temperature (2)	Outside temperature (3)	Outside temperature (4)	Outside temperature (5)	Outside temperature (6)	Outside temperature (7 MSB)	Compressor during operation	Actual compressor rotation speed (0 LSB)	Actual compressor rotation speed (1)	Actual compressor rotation speed (2)	Actual compressor rotation speed (3)	Actual compressor rotation speed (4)	Actual compressor rotation speed (5 MSB)		Fan-7-step request							
Data	1/0	0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	0	1	0	0	0	0	0	0

(2) Indoor message

Character No.	0								1								2								3							
Bit No.	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7
Contents	Operation mode (0 LSB)	Operation mode (1)	Operation mode (2 MSB)	Indoor in-operation bit	Capacity code (0 LSB)	Capacity code (1)	Capacity code (2)	Capacity code (3 MSB)	Fan (0 LSB)	Fan (1	Fan (2 MSB)	2-way valve	Reversing valve			Compressor ON	Compressor command speed (0 LSB)	Compressor command speed (1)	Compressor command speed (2)	Compressor command speed (3)	Compressor command speed (4)	Compressor command speed (5)	Compressor command speed (6)	Compressor command speed (7 MSB)	15/20(A)	OVL up		Compressor minimum rotation speed (0 LSB)	Compressor minimum rotation speed (1)	Compressor minimum rotation speed (2)	Compressor minimum rotation speed (3)	Compressor minimum rotation speed (4 MSB)
Data	1/0	1/0	1/0	1/0	0	0	0	0	1/0	1/0	1/0	0	1/0	0	0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0

3. Power Module Circuit

- Fig. 3-1 shows the system power module and its peripheral circuit. The three transistors on the positive ⊕ side, the upper arm, and the three transistors on the negative ⊖ side, the lower arm.




Fig. 3-1 Power module circuit (U⁺ is ON, V⁻ is ON)

- DC 260-360V is input to system power module and system power module switches power supply current according to rotation position of magnet rotor. The switching order is as shown in Fig. 3-2.




Fig. 3-2 Switching order of power module

- Upper arm transistor is controlled to ON/OFF by 3.3kHz chopper signal. Rotation speed of the compress is proportional to duty ratio (ON time/ ON time + OFF time) of this chopper signal.
- Time T in Fig. 3-2 shows the switching period, and relation with rotation speed (N) of the compressor is shown by formula below;

$$N = 60/2 \times 1/T$$

- Fig. 3-3 shows voltage waveform at each point shown in Figs. 3-1 and 3-4. First half of upper arm is chopper, second half is ON, and first half of lower arm is chopper, second half is ON.




Fig. 3-3 Voltage waveform at each point

- When power is supplied $U^+ \rightarrow U^-$, because of that U^+ is chopped, current flows as shown below; (B)

 - (1) When U^+ transistor is ON: U^+ transistor $\rightarrow$ U coil $\rightarrow$ V coil $\rightarrow$ V^- transistor $\rightarrow$ DC current detection resistor $\rightarrow$ Point (B) (Fig. 3-1)
 - (2) When U^+ transistor is OFF: (by inductance of motor coil) U coil $\rightarrow$ V coil $\rightarrow$ V^- transistor $\rightarrow$ Return diode $\rightarrow$ Point (A) (Fig. 3-4)




Fig. 3-4 Power module circuit (U^+ is ON, V^- is ON)

- Since current flows at point ⑥ only when U^+ transistor is ON, the current waveform at point ⑥ becomes intermittent waveform as shown in Fig. 3-3. Since current at point ⑥ is approximately proportional to the input current of the air conditioner, input current is controlled by using DC current (I_d) detection resistor.

<Reference>

If power module is detective, self diagnosis lamps on the control P.W.B. may indicate as shown below:




Fig. 3-5

Table 3-1

Self-diagnosis	Self-diagnosis lamp and mode	
I_p (peak current cut)	LD301	Blinks 2 times
Abnormal low speed rotation	LD301	Blinks 3 times
Switching incomplete	LD301	Blinks 4 times

- Simplified check of power module (Lighting mode when operated with compressor leads disconnected)
 - (1) Disconnect connector of 3-pole (WHT, YEL, RED) lead wire connecting to compressor located at the lower part of electric parts box.
 - (2) Set to compressor operation state (other than FAN mode) and press Start/stop switch of remote control.
 - (3) If normal operation continues for more than 1 minute (LD303 lights), power module is considered normal.
- * Refer to other item (troubleshooting on page 94) for independent checking of power module.

4. Power Circuit for P.W.B.

- Fig. 4-1 shows the power circuit for P.W.B. and waveform at each point.




Fig. 4-1 Power circuit for P.W.B.

- In the power circuit for P.W.B., power supply for microcomputer, peripheral circuits, and system power module driver circuit and, as well as DC 35V, are produced by switching power circuit.
- Switching power circuit performs voltage conversion effectively by switching transistor IC901 to convert DC 330V voltage to high frequency of about 20kHz to 200kHz.
- Transistor IC901 operates as follows:

(1) Shifting from OFF to ON

- DC about 330V is applied from smoothing capacitors C010 ⊕ and C011 ⊖ in the control power circuit. With this power, current flows to pin ④ of IC901 via R903 and R904 and IC901 starts to turn ON. Since voltage in the direction of arrow generates at point ③ at the same time, current passing through R910 and D903 is positive-fed back to IC901.

(2) During ON

- The drain current at IC901 increases linearly. During this period, the gate voltage and current become constant because of the saturation characteristics of the transformer.

(3) Shifting from ON to OFF

- This circuit applies a negative feedback signal from the 12V output. When the voltage across C919 reaches the specified value, REG2 turns on and current flows to PQ2 ①-②. This turns the secondary circuits on, sets IC901 pin ① to “Hi”, and turns IC901 off.

(4) During OFF

- While IC901 is on, the following energy charges the primary windings of the transformer:

Energy=LI²/2. Here, L : Primary inductance

I : Current when IC1 is off

This energy discharges to the secondary windings during power off. That is, C910, C911, C912, C914 is charged according to the turn ratio of each winding.

- At the start, an overcurrent flows to IC901 because of the charged current at C910, C911, C912, C914.
- The drain current at IC901 generates a voltage across R906. If it exceeds the IC901 base voltage, it sets the IC901 gate voltage to “Hi”.
- R906 limits the gate voltage to prevent excessive collector current from flowing to IC901.

<Reference>

If the power circuit for P.W.B. seems to be faulty:

- (1) Make sure that 5V and 12V on the control P.W.B., upper arm U, V and W, and the lower arm power voltage are the specified values.

- (2) When only the 5V output is low:

REG 1 (regulator) faulty, 5V-0V shorted, output is too high, or REG 1 is abnormal.

- (3) When 12V and 5V are abnormal:

The following defects can be considered:

- ① Fan, operation, power, rush prevention relay (shorting in relay, etc.)
- ② Microcomputer is abnormal.
- ③ REG 1 (regulator is abnormal), etc.

Shorting on primary circuits.

When shorting occurs in the secondary circuits, there is no abnormality in the primary circuits because of overcurrent protection.

The voltage rises when an opening occurs in the primary circuits, or the feedback system is abnormal.

- (4) When 15V and 17V are abnormal:

D908, D909 or drive circuit is abnormal.

- (5) When all voltage are abnormal:

IC901, R906, etc. are possibly abnormal.

- * If IC901 is abnormal, be aware that other components, such as the power module, REG (regulator), etc. are possibly defective.

[When the switching power supply seems to be abnormal, the voltage between IC901 pin ④ (to be measured at the leads of R904 and R903) and IC901 pin ⑤ (to be measured at R906 lead) may be between 11 and 16V. This is because the protection circuit of IC901 is operating.]

5. Reversing valve control circuit




Fig. 5 – 1

- Reversing valve control circuit can switch reversing valve ON/OFF according to instruction from indoor microcomputer depending on the operation condition shows in Table 5-1.
Voltage at each point in each operation condition is approximately as shown below when measured by tester. (When collector voltage of Q701 is measured)

Table 5-1

Operation condition		Collector voltage of Q701
Cooling	General operation of Cooling	About 35V
Heating	In normal heating operation	About 0.8V
	MAX. rotation speed instructed by indoor microcomputer after defrost is completed	About 0.8V
	Defrosting	About 35V
Dehumidifying	Sensor dry	About 35V

6. Rotor magnetic pole position detection circuit




Fig. 6-1 Rotor magnetic pole position detection circuit and voltage waveform at each point

- To detect U phase, voltage at point (C) is produced by driving motor induced voltage signal (voltage at point (A)) and 1/2 voltage of Vd (voltage at point (B)), and comparing with comparator.
- For V phase and W phase, voltage at point (D) and voltage at point (E) are produced in the same way as above. Voltage at point (C) is taken into indoor unit microcomputer, switching timing to U⁺ transistor from W⁺ transistor is produced by delaying 30° from rise waveform, ignoring spike voltage. In addition, switching timing to U-transistor from W-transistor is produced by delaying 30° from fall waveform.
- For V phase and W phase, in the same way as above, drive signals are produced from voltages at point (D) and point (E). Phases are shifted by 120° and 240°, respectively, comparing with U phase.

7. Drive Circuit

Fig. 7-1 shows the drive circuit.
The circuits for U phase, V phase and W phase have the same Configuration.

- In low speed rotation mode (PWM range), as shown in Fig. 7-2, 0-5V chopper signal is output from microcomputer for each phase. Signal output from microcomputer is output to IC1 and is inverted by active Lo to become 0-15V chopper signal; it is then drive the transistor of each phase.
- In high speed rotation mode (PWM range), as shown in Fig. 7-3, 0-5V drive signal is output from microcomputer for each phase (with no chopper because of full duty). Signal output from microcomputer is input to IC1 and is inverted by active Lo to become 0-15V drive signal; it is then drive the transistor of each phase.




Fig.. 7-1

[Low speed rotation mode]




Fig. 7-2

[High speed rotation mode]




Fig. 7-3

8. HIC and Peripheral Circuits

- Fig. 8-1 shows the micro computer and its peripheral circuits, Table 8-1, the basic operations of each circuit block, and Fig. 8-2, the system configuration.




Fig. 8-1 Microcomputer and Peripheral Circuits

Table 8-1

Circuit block	Basic operation
Peak current cutoff circuit	Detects DC current flowing power module and during overcurrent (instantaneous value) flows, stops upper/lower arm drive circuits and also produces Ip signal by which drive signal output is stopped.
Set value circuit	Compares voltage detected, amplified and input to HIC with set voltage value in microcomputer, and controls overload when set value exceeds input voltage.
Voltage amplifier circuit	Voltage-amplifies DC current level detected by the detection resistor and inputs this to microcomputer. Internal or external overload is judged in microcomputer.
Reset circuit	Produces reset voltage.
Trip signal synthesis circuit	Modulates chopper signal to drive signal and stops according to presence/absence of Ip signal or reset signal.




Fig. 8-2

- The following describes the operations of each circuit in detail.

(1) Peak current cut off circuit

Fig.8-3 Peak Current Cut off Circuit and Waveforms at Each Section.




Fig.8-3

- The I_p cut off circuit detects an instantaneous excessive current and stops inverter to protect parts such as SPM2, etc.
- As shown in diagram, if current exceeding 21A (27A for RAC-50NH4) flows, voltage at point (A) recognized by detecting resistor is input to pin ⑩ of SPM2 – HIC, and voltage divided by R41 and R43 is input to pin ⑨ of IC1. Since threshold of IC1 is exceeded in this case, Lo signal is input from pin ⑧ (Voltage at point (B)). When Lo signal is input to pin ⑰ of microcomputer, microcomputer stops drive output.
- When drive output from microcomputer is stopped, all drive output goes Hi, and microcomputer is initialized to enter drive signal standby mode. 3 minutes later, microcomputer outputs drive signal again, to start operation.

(2) Overload control circuit (OVL control circuit)

- Overload control is to decrease the speed of the compressor and reduce the load when the load on the air conditioner increases to an overload state, in order to protect the compressor, electronic components and power breaker.
- Overloads are judged by comparing the DC current level and set value.
- Fig. 8-4 shows the overload control system configuration and Fig. 8-5 is a characteristic diagram of overload judgement values. There are two judgement methods-external judgement which compares the externally set value with the DC current value regardless of the rotation speed and internal judgement which compares the set value that varies according to the rotation speed programmed in the microcomputer software with the DC current value.




Fig. 8-4 Overload Control System Configuration




Fig. 8-5

①. Overload external judgement circuit

- Fig. 8-1. The filter consisting of R245 and C217 removes high harmonic components from the voltage generated by the current flowing to Detection resistor; R245 and C217 average the voltage. This voltage is then input to IC4 pin ⑤ is then amplified and supplied to microcomputer pin ⑥⑩. The microcomputer compares this input with the internally set value, and if the input exceeds the set value, it enters overload control status.
- Fig. 8-7 shows the rotation speed control. When the voltage at pin ⑥⑩ of the microcomputer exceeds the set value, the microcomputer decreases the rotation speed of the compressor and reduces the load regardless of the rotation speed commanded by the indoor microcomputer.




Fig. 8-6




Fig. 8-7

②. Voltage amp. circuit

- The voltage amp. circuit amplifies the DC current level detected by the detection resistor after being converted to a voltage and supplies it to the microcomputer. Receiving this, the microcomputer converts it to a digital signal and compares it with the internal data to judge whether or not overload control is required.

< During overload control >

- The filter consisting of R245 and C217 removes high harmonic components from the voltage generated from the DC current flowing to the detection resistor, and supplies it to IC4 pin ⑤ IC4 forms a non-inverting voltage amp. circuit together with the peripheral elements.
- The microcomputer stores the set values which vary according to the rotation speed. When the DC current level exceeds the set value, the microcomputer enters the overload control state.
- The set Value is determined by the amplification of the voltage amp. circuit.

- Amplification : high → DC current : low
- Amplification : low → DC current: high

- R500, R253, detect the DC voltage at the power circuit. The microcomputer receives a DC voltage (260-380V) via HIC ③⑦ and applies correction to the overload set value so the DC current is low (high) when the DC voltage is high (low).

(Since the load level is indicated by the DC voltage multiplied by DC current, R247, R248, R249 are provided to perform the same overload judgement even when the voltage varies.)




Fig. 8-8

< During start current control >

- It is required to maintain the start current (DC current) constant to smooth the start of the DC motor for the compressor.
- RAC-25NH4, RAC-35NH4, RAC-50NH4 uses software to control the start current.
- The start current varies when the supply voltage varies. This control method copes with variations in the voltages as follows.

(1) Turns on the power module's U^+ and V^- transistors so the current flows to the motor windings as shown in Fig8-9.

(2) Varies the turn-ON time of the W^+ transistor according to the DC voltage level and the start is controlled so the start current is approx. 10A as shown in Fig. 8-10.




Fig. 8-9




Fig. 8-10

9. Temperature Detection Circuit




Fig. 9-1

- The Over heat thermistor circuit detects the temperature at the surface of the compressor head, the Defrost. thermistor circuit detects the defrosting operation temperature.
- A thermistor is a negative resistor element which has the characteristics that the higher (lower) the temperature, the lower (higher) the resistance.
- When the compressor is heated, the resistance of the Over heat thermistor becomes low and voltage at pin ⑥② of microcomputer is increased.
- Microcomputer compares the voltage present at pin ⑥② with the internal set value, if it is exceeded the set value microcomputer judges that the compressor is overheated and stops operation.
- When frost forms on the outdoor heat exchanger, the temperature at the exchanger drops abruptly. Therefore the resistance of the Defrost. thermistor becomes high and the voltage at pin ⑥③ of microcomputer drops.
If this voltage becomes lower than the set value stored inside, the microcomputer starts defrosting control.
- During defrosting operation the microcomputer transfers the defrosting condition command to the indoor microcomputer via the circuit interface.
- The microcomputer always reads the outdoor temperature via a thermistor (microcomputer pin ⑥④), and transfers it to the indoor unit, thus controlling the compressor rotation speed according to the value set at the EEPROM in the indoor unit, and switching the operation status (outdoor fan on/off, etc.) in the dry mode.

The following shows the typical values of outdoor temperature in relation to the voltage:

Table 9-1

Outdoor temperature (°C)	-10	0	10	20	30	40
Microcomputer pin ⑤ voltage (V)	1.19	1.69	2.23	2.75	3.22	3.62

<Reference>

When the thermistor is open, in open status, or is disconnected, microcomputer pins ⑥②–⑥④ are approx. 0V; when the thermistor is shorted, they are approx. 5 V, and LD301 blinks seven times.

However, an error is detected only when the OH thermistor is shorted; in such a case, the blinking mode is entered 12 minutes after the compressor starts operation.

10. Reset Circuit




Fig. 10-1

- The reset circuit initializes the microcomputer program when Power is "ON" or "OFF".
- Low voltage at pin (48) resets the microcomputer, and HI activates the microcomputer.
- Fig. 10-1 shows the reset circuit and Fig. 10-2 shows waveform at each point when power is turned on and off.
- When power is turned on, 12V line and 5V line voltages rise and 12V line voltage reaches 10.9V and reset voltage input to pin (48) of microcomputer is set to Hi.
- Reset voltage will be hold "Hi" until the 12V line voltage drops to 9.90V even though the power shuts down.




Fig. 10-2

11. Outdoor DC Fan Motor control circuit.




Fig. 11-1

- This model uses DC Fan Motor which has a controller circuit in the Motor.
- This DC Fan Motor will rotate by control voltage apply to Vsp input. (Voltage range: 1.7 to 7V DC)
Vsp high : Faster ; Vsp low : slower ; Vsp lower than 1.7V : stop
- Motor will output FG pulse by following this motor revolution.
- Outdoor Microprocessor will output PWM control signal from FMCHOP terminal by following the instruction from indoor Microprocessor.
- This PWM control signal will convert to Vsp voltage by smoothing circuit (Q101 & RC filter)
- Fan motor will start to rotate when Vsp was proceeding over than 1.7V, and generate FG pulse by rotation speed.
- FG pulse will feed back to Outdoor Microprocessor through PQ102.
- PQ102 is the isolator between Microprocessor circuit and DC Fan Motor circuit, which has to match the Fan Motor revolution with instructed revolution. Such as...
FG feedback: Faster – Instruction: Slower ... Decrease pulse width
FG feedback: Slower – Instruction: Faster ... Increase pulse width
- FG pulse is also used for Fan Motor failure detection
- Microprocessor will monitor FG pulse 30 seconds after start the fan motor. If there is no signal detected, it will consider that the Fan Motor was malfunction and stop the operation. In this case, LD302 on control PWB will blink 12 times. (Fan Motor lock detected)
- R107 and IC4 are used for Fan Motor over current

< Reference >

- When operation stop with LD301 blinks 12 times, it may be caused by faulty DC fan motor.
- In this case, please check CN6 and CN12 connection first. It makes Fan Motor Lock also if those connectors are in misconnection.
- DC Fan Motor has broken when 2A Fuse was burned. Please replace both DC Fan Motor and 2A Fuse together.
- It will makes "Fan Lock Stop" when something has disturb the Fan rotation by inserting materials into propeller fan or ice has growing inside of outdoor unit by snowing.
- It may make "Fan Lock Stop" by strong wind (ex. 17m/sec or above) against the Fan rotation. In this case, unit will be restart again after a while.
- In case of "Fan Lock Stop" even though the DC Fan Motor is rotating correctly, the possible casue is Fan Motor problem or PQ102 on board or control board problem. Stop after the Fan motor runs 2 minutes, Fan Motor may be broken.


< Caution >

- Please take care for the electrical shock by high voltage of DC Fan Motor power source which is common with compressor when you are servicing this unit.
- You can not confirm the coil and wiring of Motor due to the built in control circuit in Fan Motor.

12. Power Factor Control Circuit

Power factor is controlled to almost 100%. (Effective use of power)

With IC in ACT module, control is performed so that input current waveform will be similar to waveform of input voltage



(Even if voltage is applied, current does not flow)

* Assuming the same current capacity (20A), power can be used about 10% effective, comparing with current use (power factor of 90%), and maximum capacity is thereby improved.

SERVICE CALL Q & A

Model RAD-25NH4
RAD-40NH4

COOLING MODE

Q1 The compressor has stopped suddenly during cooling operation.



A1 Check if the indoor heat exchanger is frosted. Wait for 3-4 minutes until it is defrosted.

If the air conditioner operates in cooling mode when it is cold, the evaporator may get frosted.

DEHUMIDIFYING MODE

Q2 Sound of running water is heard from indoor unit during dehumidifying.



A2 Normal sound when refrigerant flows in pipe.

Q3 Compressor occasionally does not operate during dehumidifying.



A3 Compressor may not operate when room temperature is 10°C or less. It also stops when the humidity is preset humidity or less.

HEATING MODE

Q4 The circulation stops occasionally during Heating mode.



A4 It occurs during defrosting. Wait for 5-10 minutes until the condenser is defrosted.

Q5 When the fan speed is set at HIGH or MED, the flow is actually Weak.



A5 At the beginning of heating, the fan speed remains LOW for 30 seconds. If HIGH is selected, it switches to LOW and again to MED after additional 30 seconds.

Q6 Heating operation stops while the temperature is preset at "30".



A6 If temperature is high in the outdoor, heating operation may stop to protect internal devices.

AUTO FRESH DEFROSTING

Q7 After the ON/OFF button is pressed to stop heating, the outdoor unit is still working with the OPERATION lamp lighting.



A7 Auto Fresh Defrosting is carried out : the system checks the outdoor heat exchanger and defrosts it as necessary before stopping operation.

AUTO OPERATION

Q8 Fan speed does not change when fan speed selector is changed during auto operation.



A8 At this point fan speed is automatic.

NICE TEMPERATURE RESERVATION

Q9 When on-timer has been programmed, operation starts before the preset time has been reached.



A9 This is because "Nice temperature reservation" function is operating. This function starts operation earlier so the preset temperature is reached at the preset time. Operation may start maximum 60 minutes before the preset time.

Q10 Does "Nice temperature reservation" function operate during dehumidifying?



A10 It does not work. It works only during cooling and heating.

Q11 Even if the same time is preset, the operation start time varies.



A11 This is because "Nice temperature reservation" function is operating. The start time varies according to the load of room. Since load varies greatly during heating, the operation start time is corrected, so it will vary each day.

INFRARED REMOTE CONTROL

Q12 Timer cannot be set.



A12 Has the clock been set? Timer cannot be set unless the clock has been set.

Q13 The current time display disappears soon.



A13 The current time disappears in approx. 10 seconds. The time set display has priority.


When the current time is set the display flashes for approx 3 minutes.

Q14 The timer has been programmed, but the preset time disappears.



A14 Is the current time past the preset time? When the preset time reaches the current time, it disappears.

OTHERS




TROUBLE SHOOTING

Model **RAC-25NH4**
 RAC-50NH4

PRECAUTIONS FOR CHECKING




1. Remember that the 0V line is biased to 155-170V in reference to the ground level.
2. Also note that it takes about 10 minutes until the voltage fall after the power switch is turned off.



Across (a) – (b) (0V line)..... approx 260-360V
 Across (a) – ground..... approx 155-170V
 Across (b) (0V line)– ground..... approx 155-170V



When using an oscilloscope, never ground it. Don't forget that high voltages as noted above may apply to the oscilloscope.




DISCHARGE PROCEDURE AND POWER SHUT OFF METHOD FOR POWER CIRCUIT



Caution

- Voltage of about 300-330V is charged between both ends of smoothing capacitors
- During continuity check for each part of circuit in indoor unit electrical parts, disconnect red/gray lead wire connected from diode stack to system power module (SPM2) to prevent secondary trouble. (Be sure to discharge smoothing capacitor)

1. Turn OFF the Power supply to the outdoor unit.
2. After power is turned off, wait for 10 minutes or more. Then, remove electrical parts cover and apply soldering iron of 30 to 75W for 15 seconds or more to P2 and N1 terminals on system power module, in order to discharge voltage in smoothing capacitor.
3. Remove receptacle of red/gray lead wire connected to system power module from diode stack before performing operation check of each circuit.




System power module


Do not use a soldering iron with transformer: If one is used, thermal fuse inside transformer will be blown

As shown above, apply soldering iron to metal parts (receptable) inside the sleeve corresponding to P1 and N1 terminals of system power module: Do this with smoothing capacitors kept connected. By removing red/gray lead wire from diode stack, power supply can be shut off. (corresponding to ⊕ and ⊖ terminals of system power module)

RAC-25NH4




RAC-50NH4



CHECKING THE INDOOR/OUTDOOR UNIT ELECTRICAL PARTS AND REFRIGERATING CYCLE

**Model RAC-25NH4
RAC-50NH4**




TROUBLESHOOTING WHEN TIMER LAMP BLINKS.

Model RAD-25NH4, RAD-40NH4

Perform troubleshooting according to the number of times the indoor timer lamp and outdoor LD301 blink.

SELF-DIAGNOSIS LIGHTING MODE

Model: RAD-25NH4, RAD-40NH4

No.	Timer indicator flashing mode	Reason for display	Section of estimated fault
1	 5sec. Once	Four-way valve faulty The room heat exchange temperature is low during heating, or it is high during cooling.	(1) Four-way valve faulty. (2) Disconnection in heat exchange thermistor (only during heating)
2	 5sec. Twice	Outdoor unit forced operation The outdoor unit is in forced operation or undergoing balancing after forced operation.	Service SW in outdoor electrical parts turned ON.
3	 5sec. 3 times	Indoor/outdoor interface faulty The interface signal from the outdoor unit has been interrupted.	(1) Indoor interface circuit (2) Outdoor interface circuit
4	 5sec. 4 times	Outdoor electrical assembly defective.	Please check at the outdoor electrical led lamp blinking (LD301) and refer to self diagnosis lighting mode for outdoor unit.
5	 5sec. 6 times	Abnormal water level detection All stop when the float switch has been activated.	(1) Drain stopped up (2) Drain pump (3) Float switch
6	 5sec. 7 times	Drain pump forced operation. When the knob of drain pump test switch at Indoor P.W.B main slide to 'test' position.	(1) Indoor P.W.B. Main.
7	 5sec. 9 times	Room thermistor or heat exchanger thermistor is faulty When room thermistor or heat exchanger thermistor is opened circuit or short circuit.	(1) Room thermistor (2) Heat exchanger thermistor
8	 5sec. 10 times	DC fan motor overcurrent detection Overcurrent in indoor DC fan motor has been detected.	(1) Indoor fan locked (2) Indoor fan motor (3) Indoor P.W.B. Main
※1 9	 5sec. 13 times	IC401 data reading fault There was error in the data read from IC401	IC401 faulty

( -- Lights for 0.35 sec. at interval of 0.35 sec..)

<Cautions>

- (1) If the interface circuit is faulty when power is supplied, the self-diagnosis display will not be displayed.
- (2) If the indoor unit does not operate at all, check to see if the F-cable is connected or disconnected.
- (3) To check operation again when the timer lamp is blinking, you can use the remote control for operation (except for mode mark ※1).

SELF-DIAGNOSIS LIGHTING MODE


MODEL: RAC-25NH4, RAC-50NH4



DANGER (DC360V)

- SWITCH OFF MAIN POWER SUPPLY TO THE OUTDOOR UNIT AT LEAST 10 MINUTES BEFORE START THE SERVING WORK.
- MAKE SURE THE DC VOLTAGE LEVEL AT MEASURING POSITION (P1) AND (N1) IS LESS THAN 10V.
- DO NOT TOUCH THE SCREWS OF THE SYSTEM POWER MODULE WHEN THE UNIT IS TURNED ON. HIGH VOLTAGE STILL REMAIN EVEN AFTER THE UNIT IS TURNED OFF.
- DO NOT TOUCH ANY OTHER PARTS EXCEPT THE SERVICE SWITCH WHEN SERVICE OPERATION IS CONDUCTED.

SELF-DIAGNOSIS LIGHTING MODE ■ LIT ■ BLINKING □ OFF

LD301	LD302	SELF-DIAGNOSIS NAME	DETAILS	MAIN CHECK POINT
[1] DURING OPERATION				
☐	☐	NORMAL OPERATION	COMPRESSOR OPERATION	LD303 LIGHTS. ■
☐	☐	OVERLOAD (1)	 THIS SHOWS AN OVERLOAD, NOT MALFUNCTION.	
☐	☐	OVERLOAD (2)	UNDER OVERLOAD CONDITION, THE ROTATION SPEED IS CONTROLLED AUTOMATICALLY IN ORDER TO PROTECT THE COMPRESSOR.	
☐	☐	OVERLOAD (3)		


[2] DURING STOP

LD303	LD304	SELF-DIAGNOSIS NAME	DETAILS	MAIN CHECK POINT
☐	☐	NORMAL STOP	INDOOR THERMOSTAT OFF. MAIN OPERATION OFF.	NOT MALFUNCTION.
☐	☐	RESET STOP	WHEN STOPPED WITH POWER RESET. (NORMAL WHEN POWER HAS BEEN TURNED ON).	① P.W.B.s (POWER CIRCUIT, HIC, ETC.)
☐	☐	PEAK CURRENT CUT	OVER CURRENT IS DETECTED.	① SYSTEM POWER MODULE ② COMPRESSOR ③ P.W.B.s
☐	☐	ABNORMAL LOW SPEED ROTATION	POSITION DETECTION SIGNAL IS NOT INPUT DURING OPERATION.	① SYSTEM POWER MODULE ② COMPRESSOR ③ P.W.B.s
☐	☐	SWITCHING FAILURE	FAIL TO SWITCH FROM INITIAL LOW FREQUENCY SYNC. TO POSITION DETECTION SYNC.	① SYSTEM POWER MODULE ② COMPRESSOR ③ P.W.B.s
☐	☐	OVERLOAD LOWER LIMIT CUT	OVERLOAD CONDITION STILL PERSISTING EVEN WHEN ROTATION SPEED IS BELOW THE LOWER RPM LIMIT.	① OUTDOOR UNIT IS EXPOSED TO DIRECT SUNLIGHT OR ITS AIRFLOW BLOCKED. ② FAN MOTOR ③ FAN MOTOR CIRCUIT ④ THE VOLTAGE IS EXTREMELY LOW.
☐	☐	OH THERMISTOR	OH THERMISTOR IS OPERATING.	① LEAK OF REFRIGERANT ② COMPRESSOR ③ OH THERMISTOR CIRCUIT ④ FAN MOTOR ⑤ FAN MOTOR CIRCUIT
☐	☐	TEMP. RISE	THERMISTOR IS OPENED OR SHORTED.	① THERMISTOR ② CONNECTION OF THERMISTOR IS FAULTY ③ THERMISTOR CIRCUIT
☐	☐	ABNORMAL THERMISTOR		
☐	☐	ACCELERATION DEFECTIVE	NO ACCELERATION ABOVE THE LOWER LIMIT OF THE ROTATION SPEED.	① LEAK OF REFRIGERANT ② COMPRESSOR
☐	☐	COMMUNICATION ERROR	COMMUNICATION BETWEEN INDOOR UNIT AND OUTDOOR UNIT ARE INTERRUPTED.	① C/D CABLE IS REVERSED ② CABLE IS DISCONNECTED ③ INTERFACE CIRCUIT OF INDOOR AND OR OUTDOOR UNIT
☐	☐	POWER SUPPLY VOLTAGE ERROR	POWER SUPPLY VOLTAGE IS INCORRECT.	① POWER SUPPLY VOLTAGE ② RECEPTACLE OF WIRE AT SYSTEM POWER MODULE IS NOT PROPERLY INSERTED
☐	☐	FAN LOCK ERROR	OUTDOOR FAN RPM IS NOT ROTATE AS INTENDED RPM.	① FAN MOTOR ② FAN MOTOR CIRCUIT
☐	☐	EEPROM READING ERROR	MICROCOMPUTER CANNOT READ THE DATA IN EEPROM.	① HIC
☐	☐	ACTIVE CONVERTER DEFECTIVE	OVER VOLTAGE IS DETECTED BY SYSTEM POWER MODULE.	① SYSTEM POWER MODULE

* EXAMPLE OF BLINKING (5 TIMES) ■■■■■ 2SEC (■■■■■ •• LIGHTS FOR 0.25 SEC. AT INTERVAL OF 0.25 SEC.)

WIRING DIAGRAM


BLK : BLACK GRY : GRAY
BLU : BLUE RED : RED
BRN : BROWN WHT : WHITE
GRN : GREEN YEL : YELLOW



SERVICE OPERATION

COLLECT REFRIGERANT FROM INDOOR UNIT AND STORE AT OUTDOOR UNIT.

1. SWITCH OFF THE MAIN POWER SUPPLY AND THEN SWITCH IT ON AGAIN. WAIT FOR 1 MINUTE.
2. PRESS AND HOLD THE SERVICE SWITCH FOR 1 SECOND TO START OUTDOOR UNIT IN COOLING OPERATION. IN ORDER TO PREVENT PARTS FROM DAMAGE, DO NOT OPERATE THE OUTDOOR UNIT FOR MORE THAN 5 MINUTES.
3. PRESS AND HOLD THE SERVICE SWITCH FOR 1 SECOND TO STOP THE SERVICE OPERATION.
4. REPEAT STEP 1 TO 3 IF SERVICE OPERATION NEED TO BE REPEATED.



MEASURING POSITION OF DC VOLTAGE (P1) '+ve'.

MEASURING POSITION OF DC VOLTAGE (N1) '-ve'.

SYSTEM POWER MODULE

HIC

P.W.B.s

LD301

LD302

LD303

SERVICE SWITCH


SCREW (DANGER OF ELECTRIC SHOCK)

CONNECTING CORD


1HRA81018A

CHECKING INDOOR UNIT ELECTRICAL PARTS


1. Power does not come on (no operation)




2. Outdoor unit does not operate (but receives remote infrared signal)




3. Only indoor fan does not operate (other is normal)




4. Indoor fan speed does not change (other is normal)




5. Air deflector does not move (other is normal)



**6. All systems stop from several seconds to several minutes after operation is started
(all indicators are also off)**





CHECKING THE REMOTE CONTROLLER





CHECKING THE OUTDOOR UNIT ELECTRICAL PARTS


MODEL RAC-25NH4, RAC-50NH4












POWER CIRCUIT

Phenomenon 1 <Rotation speed does not increase>



Overvoltage defect: system power module faulty (15-times blinking)

CHECKING THE REFRIGERATING CYCLE

(JUDGING BETWEEN GAS LEAKAGE AND COMPRESSOR DEFECTIVE)

1. Troubleshooting procedure (No operation, No heating, No cooling)

Connect U,V,W phase leads to the power module again and operate the air conditioner.

Is the self-diagnosis lamp mode as shown on the right?

YES

Stop to operate and check the gas pressure in balancing mode.

Gas leaking
(less than 4kg/cm²G)
(less than 0.39 MPaG)

Gas leaks.
Repair and seal refrigerant.

Normal
(0.39-0.98 MPaG)
(4-10 kg/cm²G)

● Checking the system power module

When the self-diagnosis lamp lights in the same condition as above.

The compressor is defective. Replace it and seal refrigerant.

(If the compressor checker for an inverter type air conditioner is available, re-check using it.)

Perform a final check of operation.

Lighting mode Self-diagnosis lamp	Blinks 2 times	Blinks 3 times	Blinks 4 times	Blinks 5 times	Blinks 6 times	Blinks 8 times
LD301						
Time until the lamp lights	Approx. 10 seconds			Approx. 10 seconds	Within Approx. 30 seconds	Approx. 10 seconds
Possible malfunctioning part	Compressor			Gas leakage		Compressor

 Blinking

 off

HOW TO CHECK SYSTEM POWER MODULE

Checking system power module using tester



Set tester to resistance range (X 100)

If indicator does not swing in the following conductivity check, the system power module is normal.

(In case of digital tester, since built-in battery is set in reverse direction, $\oplus$ and $\ominus$ terminals are reversed.)

CAUTION

If inner circuit of system power module is disconnected (open), the indicator of tester will not swing and this may assumed as normal. In this case, if indicator swings when $\oplus$ and $\ominus$ terminals are connected in reverse of diagram below, it is normal. Furthermore, compare how indicator swings at U, V and W phases. If indicator swings the same way at each point, it is normal.




HOW TO OPERATE USING THE SERVICE SWITCH THE OUTDOOR UNIT

MODEL RAC-25NH4, RAC-50NH4


1. Turn off the power supply to outdoor unit and then turn on again.
2. Remove the electrical box cover.

LD303 (red) will light and the unit will operate in the forced cooling mode at this time.

Never operate the unit for more than 5 minutes.



Service switch
(forced-cooling mode is set by pressing for 1 second or more, and stopped by pressing again.)



(Cautions)

- (1) If interface signal (DC 35V) terminals C and D are not connected when the outdoor unit is in forced cool mode, the outdoor unit defect indicator (LD301) will blink 9 times during operation to indicate communication error.
- (2) If checking is done with the compressor connector disconnected, the unit will continue normal operation when the electrical parts are normal, or it will repeat operating for approx. one minute and stop due to overload power limit cut, or it will operate in the overload status.


Be sure to push the service switch again to stop the forced cool operation.

HOW TO OPERATE THE OUTDOOR UNIT INDEPENDENTLY

1. Connect the large dia. pipe side and small dia. pipe side service valves using a pipe.

Connect the small diameter service valve and the large diameter service valve using the reducing union and copper pipe as shown on the right.

Charge refrigerant of 300g after vacuuming (※ 1)



Parts to be prepared




- (1) Reducing union
2/8" (6.35mm)
1/2" (12.7mm)
- (2) Copper pipe (2/8" and 1/2")
- (3) Shorting leads
2 leads approx. 10 cm long with alligator clip or IC clip

Do not operate for more than 5 minutes

The operation method is the same as "How to operate using the connector to servicing the outdoor unit".

※ 1 The charging amount of 300g is equivalent to the load in normal operation.


SYSTEM POWER MODULE DIAGNOSIS

Circuit diagram of the device (excepting the reflux diode)	
Circuit diagram of the module	
Terminals symbol mark of the module ※ See next page for measuring value using tester	

PARTS LIST AND DIAGRAM

INDOOR UNIT

MODEL : RAD-25NH4, RAD-40NH4



MODEL RAD-25NH4

NO.	PART NO. RAD-25NH4	Q'TY / UNIT	PARTS NAME
1	RAD-28MX 001	1	DRAIN PAN
2	RAMD-350BW 003	2	FAN MOTOR SUPPORT RUBBER
3	RAMD-350BW 004	2	SPECIAL SCREW
4	RAMD-28GX 002	1	PUMP ASSEMBLY
5	RAMD-350BW 010	1	DRAIN HOSE
6	RAMD-350BW 009	1	PUMP HOSE
7	RAMD-350BW 011	1	FLOAT SWITCH
8	RAD-28MX 801	1	EVAPORATOR ASSEMBLY
9	RAD-28MX 802	1	PIPE SET
10	RAD-25QH4 906	1	BULB SUPPORT
11	RAD-32CNH2 906	2	SIROCCO FAN
12	RA-353B 004	2	FAN BOLT
13	RAD-32CNH2 905	1	FAN MOTOR 20W, 1kg
15	RAMD-40GX 002	1	THERMISTOR (HEAT)
16	RAD-28MX 005	1	THERMISTOR (TEMPERATURE)
17	RAD-25NH4 901	1	P.W.B. (MAIN)
24	RAC4010KX2 008	1	FERITE CORE (935)
31	RAC-228JX 014	2	SLIDE SWITCH
43	ATI-0972B 936	1	TERMINAL BOARD (2P)
45	RAD-25NH4 902	1	P.W.B. (INDICATION)
53	RAD-25QH4 905	1	REMOTE CONTROL ASSEMBLY
54	RAMJ-250BW 009	1	INSULATOR PIPE
55	RAS-258JX 004	1	REMOCON SUPPORT
56	RAD-28MX 009	1	INSULATOR PIPE (236L)
58	RAD-28QH1 904	1	UPPER PLATE (2)
59	RAD-25QH4 904	1	UPPER PLATE (1)
61	RAD-28QH1 907	1	FAN MOTOR SUPPORT
62	RAD-25QH4 901	1	BASE (FAN MOTOR)
66	RAS-2236W 025	1	LED-YELLOW (SEL2713K)
67	RAS-25DXD 002	1	LIGHT RECEIVING UNIT
68	RAS-2553W 020	1	LED-GREEN (SEL2413E)
69	RAS-2810KX 043	1	CURRENT PROTECTOR (0.8A)


NO.	PART NO. RAD-25NH4		Q'TY / UNIT	PARTS NAME
70	RAS-2810KX	044	1	CURRENT PROTECTOR (2.0A)
74	RAD-25NH4	903	1	LED COVER
76	RAD-28MX	003	1	DRAIN PIPE
77	RAS5645TWU	008	1	DRAIN CAP
78	RAS-287AX	801	1	UNION (2)
79	RAS-287AX	802	1	UNION (3)

MODEL RAD-40NH4

NO.	PART NO. RAD-40NH4	Q'TY / UNIT	PARTS NAME
1	RAD-28MX 001	1	DRAIN PAN
2	RAMD-350BW 003	2	FAN MOTOR SUPPORT RUBBER
3	RAMD-350BW 004	2	SPECIAL SCREW
4	RAD-28MX 002	1	PUMP ASSEMBLY
5	RAMD-350BW 010	1	DRAIN HOSE
6	RAMD-350BW 009	1	PUMP HOSE
7	RAMD-350BW 011	1	FLOAT SWITCH
8	RAD-28MX 801	1	EVAPORATOR ASSEMBLY
9	RAD-28MX 802	1	PIPE SET
10	ATI-0972B 935	1	BULB SUPPORT
11	RAD-32CNH2 906	2	SIROCCO FAN
12	RA-353B 004	2	FAN BOLT
13	RAD-32CNH2 905	1	FAN MOTOR 20W, 1kg
15	RAMD-40GX 002	1	THERMISTOR (HEAT)
16	RAD-28MX 005	1	THERMISTOR (TEMPERATURE)
17	RAD-40NH4 901	1	P.W.B. (MAIN)
24	RAC4010KX2 008	1	FERITE CORE (935)
31	RAC-228JX 014	2	SLIDE SWITCH
43	ATI-0972B 936	1	TERMINAL BOARD (2P)
45	RAD-25NH4 902	1	P.W.B. (INDICATION)
53	RAD-25QH4 905	1	REMOTE CONTROL ASSEMBLY
54	RAMJ-250BW 009	1	INSULATOR PIPE
55	RAS-258JX 004	1	REMOCON SUPPORT
56	RAD-28MX 009	1	INSULATOR PIPE (236L)
58	RAD-28QH1 904	1	UPPER PLATE (2)
59	RAD-25QH4 904	1	UPPER PLATE (1)
61	RAD-28QH1 907	1	FAN MOTOR SUPPORT
62	RAD-25QH4 901	1	BASE (FAN MOTOR)
66	RAS-2236W 025	1	LED-YELLOW (SEL2713K)
67	RAS-25DXD 002	1	LIGHT RECEIVING UNIT
68	RAS-2553W 020	1	LED-GREEN (SEL2413E)
69	RAS-2810KX 043	1	CURRENT PROTECTOR (0.8A)

NO.	PART NO. RAD-40NH4		Q'TY / UNIT	PARTS NAME
70	RAS-2810KX	044	1	CURRENT PROTECTOR (2.0A)
74	RAD-25NH4	903	1	LED COVER
76	RAD-28MX	003	1	DRAIN PIPE
77	RAS5645TWU	008	1	DRAIN CAP
78	RAS-287AX	801	1	UNION (2)
79	RAS-287AX	802	1	UNION (3)

OUTDOOR UNIT **MODEL : RAC-25NH4, RAC-50NH4**



MODEL RAC-25NH4

NO.	PART NO. RAC-25NH4		Q'TY / UNIT	PARTS NAME
1	PMRAC-25NH4	918	1	BASE
2	PMRAC-25NH4	908	1	COMPRESSOR
3	KPNT1	001	6	PUSH NUT
4	RAC-2226HV	805	3	COMPRESSOR RUBBER
5	PMRAC-25NH4	901	1	CONDENSER
6	PMRAC-25NH4	902	1	REVERSING VALVE
7	PMRAC-25NH4	903	1	ELECTRICAL EXPANSION COIL
8	PMRAC-25NH4	904	1	VALVE (2S)
9	PMRAC-25NH4	905	1	VALVE (4S)
10	PMRAC-40CNH2	914	1	THERMISTOR (OH)
11	PMRAC-25NH4	909	1	OVERHEAT THERMISTOR SUPPORT
12	PMRAC-25NH4	910	1	OVERLOAD RELAY COVER
14	PMRAC-40CNH2	915	1	THERMISTOR (DEFROST)
15	PMRAC-07CHV1	921	1	COIL (REVERSING VALVE)
16	PMRAC-40CNH2	908	1	REACTOR
17	PMRAC-25NH4	906	1	P.W.B (MAIN)
20	PMRAC-25NH4	912	1	SYSTEM POWER MODULE
21	PMRAC-40CNH2	902	1	DIODE STACK (D25VB60)
22	PMRAC-25NH4	913	1	TERMINAL BOARD (4P)
23	PMRAC-40CNH2	916	1	THERMISTOR (OUTSIDE TEMPERATURE)
24	PMRAC-25CNH2	902	1	PROPELLER FAN
26	PMRAC-25NH4	914	1	SUPPORT (FAN MOTOR)
27	PMRAC-40CNH2	919	1	FAN MOTOR (40W)
28	PMRAC-51CA1	901	1	CABINET
29	PMRAC-51CA1	908	1	NET
30	PMRAC-51CA1	909	1	TOP COVER
31	PMRAC-25NH4	917	1	SIDE PLATE-R
32	PMRAC-25NH4	915	1	STRAINER
33	PMRAC-25NH4	907	1	STRAINER
35	PMRAC-09CHA1	903	1	GRILL
38	PMRAC-25NH4	916	1	EXPANSION VALVE

MODEL RAC-50NH4

NO.	PART NO. RAC-50NH4	Q'TY / UNIT	PARTS NAME
1	PMRAC-50NH4 901	1	BASE
2	PMRAC-50NH4 907	1	COMPRESSOR
3	KPNT1 001	4	PUSH NUT
4	RAC-2226HV 805	3	COMPRESSOR RUBBER
5	PMRAC-50NH4 902	1	CONDENSER
6	PMRAC-25NH4 902	1	REVERSING VALVE
7	PMRAC-25NH4 903	1	ELECTRICAL EXPANSION COIL
8	PMRAC-50NH4 903	1	VALVE (2S)
9	PMRAC-50NH4 904	1	VALVE (4S)
10	PMRAC-40CNH2 914	1	THERMISTOR (OH)
11	PMRAC-25NH4 909	1	OVERHEAT THERMISTOR SUPPORT
12	PMRAC-25NH4 910	1	OVERLOAD RELAY COVER
14	PMRAC-40CNH2 915	1	THERMISTOR (DEFROST)
15	PMRAC-07CHV1 921	1	COIL (REVERSING VALVE)
16	PMRAC-40CNH2 908	1	REACTOR
17	PMRAC-50NH4 905	1	P.W.B (MAIN)
20	PMRAC-40CNH2 901	1	SYSTEM POWER MODULE
21	PMRAC-40CNH2 902	1	DIODE STACK (D25VB60)
22	PMRAS-10C6M 002	2	TERMINAL BOARD (2P)
23	PMRAC-40CNH2 916	1	THERMISTOR (OUTSIDE TEMPERATURE)
24	PMRAC-40CNH2 917	1	PROPELLER FAN
26	PMRAC-40CNH2 918	1	SUPPORT (FAN MOTOR)
27	PMRAC-40CNH2 919	1	FAN MOTOR (40W)
28	PMRAC-40CNH2 904	1	CABINET
29	PMRAC-40CNH2 921	1	NET
30	PMRAC-40CNH2 922	1	TOP COVER
31	PMRAC-50NH4 910	1	SIDE PLATE-R
32	PMRAC-50NH4 906	1	STRAINER
33	PMRAC-50NH4 909	1	STRAINER
34	PMRAC-40CNH2 926	1	SIDE PLATE-L
35	PMRAC-40CNH2 928	1	GRILL
38	PMRAC-25NH4 916	1	EXPANSION VALVE

HITACHI

**RAD-25NH4/RAC-25NH4
RAD-40NH4/RAC-50NH4**

PM NO. 0214E

Printed in Malaysia