

Air Flow Direction Setting

Set the air flow direction of indoor units as given in the table below. (Set when optional air outlet blocking pad has been installed.) The second code No. is factory set to "01."

Setting Table

Mode No.	First Code No.	Second Code No.	Setting
13 (23)	1	01	F : 4-direction air flow
		02	T : 3-direction air flow
		03	W : 2-direction air flow

Setting of Air Flow Direction Adjustment

Only the model FXKQ has the function.


When only the front-flow is used, sets yes/no of the swing flap operation of down-flow.

Setting Table

Setting	Mode No.	First Code No.	Second Code No.
Down-flow operation: Yes	13 (23)	3	01
Down-flow operation: No			02

Setting of Air Flow Direction Adjustment Range

Make the following air flow direction setting according to the respective purpose.



(S2537)

Setting Table

Mode No.	First Code No.	Second Code No.	Setting
13 (23)	4	01	Upward (Draft prevention)
		02	Standard
		03	Downward (Ceiling soiling prevention)

Air flow rate switching at discharge grille for field air flow rate switching

When the optional parts (high performance filter, etc.) is installed, sets to change fan speed for securing air flow rate.

Follow the instruction manual for the optional parts to enter the setting numbers.

Setting of the static pressure selection (for FXDQ model)

Model No.	First Code No.	Second Code No.	External static pressure
13 (23)	5	01	Standard (15Pa)
		02	High static pressure (44Pa)

4.4.1.7 Outdoor Air Processing Unit-Field Setting (Remote Control)

Mode No.	Setting SW No.	Setting contents	Setting position No.														
			01	02	03	04	05	06	07	08	09	10	11	12	13	14	15
10 (20)	0	Stain of filter	2500hr	1250hr	—	—	—	—	—	—	—	—	—	—	—	—	
	3	Filtering time cumulation	Display	No display	—	—	—	—	—	—	—	—	—	—	—	—	
12 (22)	1	External ON/OFF input	Forced stop	ON-OFF control	—	—	—	—	—	—	—	—	—	—	—		
	5	Power failure automatic reset	Not equipped	Equipped	—	—	—	—	—	—	—	—	—	—	—		
14 (24)	3	Discharge temperature (cooling)	13°C	14	15	16	17	18	19	20	21	22	23	24	25	25	25
	4	Discharge temperature (heating)	18°C	19	20	21	22	23	24	25	26	27	28	29	30	30	30

Note) Bold face in indicates the default setting.


4.4.1.8 Centralized Control Group No. Setting

BRC1A Type

In order to conduct the central remote control using the central remote control and the unified ON/OFF controller, Group No. settings should be made by group using the operating remote control.

Make Group No. settings for central remote control using the operating remote control.

1. While in normal mode, press and hold the “ ” switch for a period of four seconds or more to set the system to “Field Setting Mode”.
2. Select the MODE No. “00” with the “ ” button.
3. Use the “ ” button to select the group No. for each group.
(Group numbers increase in the order of 1-00, 1-01, ... 1-15, 2-00, ... 4-15.)
4. Press “ ” to set the selected group No.
5. Press “ ” to return to the NORMAL MODE.









Note:


- For infrared remote control, see the following.
- For setting group No. of HRV and wiring adapter for other air conditioners, etc., refer to the instruction manual attached.

NOTICE


Enter the group No. and installation place of the indoor unit into the attached installation table. Be sure to keep the installation table with the operation manual for maintenance.

**BRC7C Type
BRC7E Type
BRC4C Type**

- Group No. setting by infrared remote control for centralized control
- 1. When in the normal mode, push “  ” button for 4 seconds or more, and operation then enters the “field set mode.”
- 2. Set mode No. “00” with “  ” button.
- 3. Set the group No. for each group with “  ” “  ” button (advance/backward).
- 4. Enter the selected group numbers by pushing “  ” button.
- 5. Push “  ” button and return to the normal mode.



Group No. Setting Example



Caution

When turning the power supply on, the unit may often not accept any operation while "88" is displaying after all indications were displayed once for about 1 minute on the liquid crystal display. This is not an operative fault.

4.4.1.9 Setting of Operation Control Mode from Remote Control (Local Setting)

The operation control mode is compatible with a variety of controls and operations by limiting the functions of the operation remote control. Furthermore, operations such as remote control ON/OFF can be limited in accordance with the combination conditions. (Refer to information in the table below.)

Central remote control is normally available for operations. (Except when centralized monitor is connected)

4.4.1.10 Contents of Control Modes


Twenty modes consisting of combinations of the following five operation modes with temperature and operation mode setting by remote control can be set and displayed by operation modes 0 through 19.

- ◆ ON/OFF control impossible by remote control
Used when you want to turn on/off by central remote control only.
(Cannot be turned on/off by remote control.)
- ◆ OFF control only possible by remote control
Used when you want to turn on by central remote control only, and off by remote control only.
- ◆ Centralized
Used when you want to turn on by central remote control only, and turn on/off freely by remote control during set time.
- ◆ Individual
Used when you want to turn on/off by both central remote control and remote control.
- ◆ Timer operation possible by remote control
Used when you want to turn on/off by remote control during set time and you do not want to start operation by central remote control when time of system start is programmed.

How to Select Operation Mode

Whether operation by remote control will be possible or not for turning on/off, controlling temperature or setting operation mode is selected and decided by the operation mode given on the right edge of the table below.


Example



Control mode	Control by remote control					Control mode	
	Operation		OFF	Temperature control	Operation mode setting		
	Unified operation, individual operation by central remote control, or operation controlled by timer	Unified OFF, individual stop by central remote control, or timer stop					
ON/OFF control impossible by remote control	Rejection (Example)	Rejection (Example)	Rejection (Example)	Rejection	Acceptance	0	
OFF control only possible by remote control				Acceptance	Acceptance (Example)	Acceptance (Example)	1(Example)
	Rejection		Rejection		11		
Centralized	Acceptance		Acceptance	Acceptance	Rejection	Acceptance	2
					Rejection	Rejection	12
Individual	Acceptance		Acceptance	Acceptance	Acceptance	Acceptance	3
		Rejection			Rejection	13	
Timer operation possible by remote control	Acceptance (During timer at ON position only)	Acceptance (During timer at ON position only)	Acceptance	Rejection	Acceptance	4	
				Rejection	Rejection	14	
				Acceptance	Acceptance	5	
				Rejection	Rejection	15	
				Rejection	Acceptance	6	
				Acceptance	Acceptance	7 *1	
				Rejection	Rejection	16	
				Acceptance	Acceptance	8	
				Rejection	Acceptance	9	
				Acceptance	Rejection	17	
				Rejection	Acceptance	18	
				Acceptance	Rejection	19	

Do not select "timer operation possible by remote control" if not using a remote control. Operation by timer is impossible in this case.

*1. Factory setting



4.4.2 Field Setting from Outdoor Unit

4.4.2.1 Field Setting from Outdoor Unit

■ List of Field Setting Items

This following section indicates the list of field setting items. For the lists of dip switch contents, Setting mode 1, and Setting mode 2, refer to information in tables shown on the following page onward.

For setting items of (*1), refer to detailed information provided on page 111 onward.

Setting item		Content and objective of setting	Overview of setting procedure	
Function setting	1	Setting of COOL/HEAT selection (*1) *Heat Pump model only	<ul style="list-style-type: none"> ■ COOL/HEAT selection methods are selectable from the following <ol style="list-style-type: none"> (1) Control by each outdoor unit using the indoor unit remote control (2) Control by each outdoor unit using the COOL/HEAT selection remote control (3) Batch control by outdoor unit group using the indoor unit remote control (4) Batch control by outdoor unit group using the COOL/HEAT selection remote control ■ In order to use the COOL/HEAT selection remote control, set the DS1-1 on the outdoor unit PC board to OUT. ■ For outdoor unit group control, set the system to "BATCH MASTER" or "SLAVE" while in "Setting mode 1". Then, make setting of COOL/HEAT batch address. 	
	2	Setting of low noise operation (*1)	A. Use external input to step down the upper limit of the fan (factory set to Step 8), providing low noise level. <ol style="list-style-type: none"> (1) Mode 1: Step 6 or lower (2) Mode 2: Step 5 or lower (3) Mode 3: Step 4 or lower 	<ul style="list-style-type: none"> ■ Use the "External control adapter for outdoor unit". Set to "External control adapter for outdoor unit" with No. 12 of "Setting mode 2" and select the mode with No. 25. If necessary, set the "Capacity priority setting" to ON with No. 29.
			B. The low noise operation aforementioned is enabled in nighttime automatic low noise operation mode. Start time: Selectable in the range of 20:00 to 24:00 hours. End time: Selectable in the range of 06:00 to 08:00 hours. (Use the said time as a guide since the start time and the end time are estimated according to outdoor temperatures.)	<ul style="list-style-type: none"> ■ Make this setting while in "Setting mode 2". Select a mode with No. 22 of "Setting mode 2". Select the start time with No. 26 and the end time with No. 27. If necessary, set the "Capacity priority setting" to ON with No. 29.
	3	Setting of demand operation (*1)	<ul style="list-style-type: none"> ■ Used to place limits on the compressor operating frequency to control the upper limit of power consumption. <ol style="list-style-type: none"> (1) Mode 1 of Demand 1: 60% or less of rating (2) Mode 2 of Demand 1: 70% or less of rating (3) Mode 3 of Demand 1: 80% or less of rating (4) Demand 2: 40% or less of rating ■ For setting with the use of "external control adapter": Set the system to "External control adapter for outdoor unit" with No. 12 of Setting mode 2" and select the mode with No. 30. ■ For setting only in "Setting mode 2": Set the system to Constant demand mode with No. 32 of "Setting mode 2" and select the mode with No. 30. 	
	4	Setting of AirNet address	<ul style="list-style-type: none"> ■ Used to make address setting with AirNet connected. ■ Set the AirNet to an intended address using binary numbers with No. 13 of "Setting mode 2". 	
	5	Setting of hot water heater	<ul style="list-style-type: none"> ■ Make this setting to conduct heating operation using the hot water heater. ■ Set No. 16 of "Setting mode 2" to ON. 	
6	Setting of high static pressure	<ul style="list-style-type: none"> ■ Make this setting to operate a system with diffuser duct while in high static pressure mode. (Use this setting mode when shields are installed on upper floors or balconies.) * In order to mount the diffuser duct, remove the cover from the outdoor unit fan. ■ Set No. 18 of "Setting mode 2" to ON. 		

Setting item		Content and objective of setting	Overview of setting procedure	
Service setting	1	Indoor unit fan forced H operation	<ul style="list-style-type: none"> Used to operate the indoor unit in the stopped state in forced H operation mode. 	<ul style="list-style-type: none"> Set No. 5 of "Setting mode 2" to indoor unit forced fan H.
	2	Indoor unit forced operation	<ul style="list-style-type: none"> Used to operate the indoor unit in forced operation mode. 	<ul style="list-style-type: none"> Set No. 6 of "Setting mode 2" to indoor unit forced operation mode.
	3	Change of targeted evaporating temperature (in cooling)	<ul style="list-style-type: none"> In cooling operation, used to change the targeted evaporating temperature for compressor capacity control. 	<ul style="list-style-type: none"> Select high side or low side with No. 8 of "Setting mode 2".
	4	Change of targeted condensing temperature (in heating)	<ul style="list-style-type: none"> In heating operation, used to change the targeted condensing temperature for compressor capacity control. 	<ul style="list-style-type: none"> Select high side or low side with No. 9 of "Setting mode 2".
	5	Setting of defrost selection *Heat Pump model only	<ul style="list-style-type: none"> Used to change a temperature at which the defrost operation is initiated, thus making the initiation easy or hard. 	<ul style="list-style-type: none"> Select fast side or slow side with No. 10 of "Setting mode 2".
	6	Setting of sequential startup	<ul style="list-style-type: none"> Used to start units not in sequence but simultaneously. 	<ul style="list-style-type: none"> Set No. 11 of "Setting mode 2" to NONE.
	7	Emergency operation	<ul style="list-style-type: none"> If the compressor has a failure, used to prohibit the operation of compressor(s) concerned or outdoor unit(s) concerned and to conduct emergency operation of the system only with operable compressor(s) or outdoor unit(s). 	<ul style="list-style-type: none"> Make this setting while in "Setting mode 2". For system with a single outdoor unit: Set with No. 19 or 42. For system with multiple outdoor units: Set with No. 38, 39, or 40.
	8	Additional refrigerant charging (*1)	<ul style="list-style-type: none"> If a necessary amount of refrigerant cannot be charged due to the stop of outdoor unit, operate the outdoor unit and then refill refrigerant. 	<ul style="list-style-type: none"> Set No. 20 of "Setting mode 2" to ON and then charge refrigerant.
	9	Refrigerant recovery mode (*1)	<ul style="list-style-type: none"> Used to recover refrigerant on site. With operations of indoor and outdoor units prohibited, fully open the expansion valve of the indoor and outdoor units. 	<ul style="list-style-type: none"> Set No. 21 of "Setting mode 2" to ON.
	10	Vacuuming mode (*1)	<ul style="list-style-type: none"> Used to conduct vacuuming on site. Fully open the expansion valves of the indoor and outdoor units, and energize part of solenoid valves. Use a vacuum pump to conduct vacuuming. 	<ul style="list-style-type: none"> Set No. 21 of "Setting mode 2" to ON.
	11	ENECUT test operation	<ul style="list-style-type: none"> Used to forcedly turn ON the ENECUT. (Be noted this mode is not functional with the indoor unit remote control turned ON.) 	<ul style="list-style-type: none"> Set No. 24 of "Setting mode 2" to ON.
	12	Power transistor check mode	<ul style="list-style-type: none"> Used for the troubleshooting of DC compressors. Inverter waveform output makes it possible to judge whether a malfunction results from the compressor or the PC board. 	<ul style="list-style-type: none"> Set No. 28 of "Setting mode 2" to ON.
	13	Setting of model with spare PC board	<ul style="list-style-type: none"> In order to replace the PC board by a spare one, be sure to make model setting. 	<ul style="list-style-type: none"> For this setting, set the DS2-2, -3, and-4 switches on the PC board to the model concerned.

For setting items of (*1), refer to detailed information provided on page 112 onward.

■ Setting by dip switches

Using dip switches on the PC board enables field setting shown below. However, make no changes of factory settings except for DS1-1.

Dipswitch		Setting item	Description
No.	Setting		
DS1-1	ON	Cool / Heat select	Used to set cool / heat select by Cool/Heat selector equipped with outdoor unit. • Heat Pump model only
	OFF (Factory set)		
DS1-2 ~DS1-4	ON	Not used	Do not change the factory settings.
	OFF (Factory set)		
DS2-1 ~4	ON	Not used	Do not change the factory settings.
	OFF (Factory set)		

■ **Setting by pushbutton switches**


The following settings are made by pushbutton switches on PC board.
 In case of multi-outdoor unit system, various items should be set with the master unit.
 (Setting with the slave unit is disabled.)

The master unit and slave unit can be discriminated with the LED display as shown below.

LED display

		MODE H1P	TEST H2P	COOL/HEAT select			Low noise H6P	Demand H7P	Multi; H8P
				IND H3P	MASTER H4P	SLAVE H5P			
Single-outdoor-unit system		●	●	○	●	●	●	●	●
Outdoor-multi system	Master	●	●	○	●	●	●	●	○
	Slave 1	●	●	●	●	●	●	●	◐
	Slave 2	●	●	●	●	●	●	●	●

(Factory setting)



(V2760)

There are the following three setting modes.

① **Setting mode 1 (H1P off)**

Initial status (when normal) : Used to select the cool/heat setting. Also indicates during “abnormal”, “low noise control” and “demand control”.


② **Setting mode 2 (H1P on)**

Used to modify the operating status and to set program addresses, etc. Usually used in servicing the system.


③ **Monitor mode (H1P blinks)**

Used to check the program made in Setting mode 2.

■ **Mode changing procedure 1**



■ **Mode changing procedure 2**




(V2762)

a. "Setting mode 1"


This mode is used to set and check the following items.

1. Set items In order to make COOL/HEAT selection in a batch of outdoor unit group, change the setting.
 - COOL/HEAT selection (IND) Used to select COOL or HEAT by individual outdoor unit (factory set).
 - COOL/HEAT selection (MASTER) Used to select COOL or HEAT by outdoor unit group with the master unit.
 - COOL/HEAT selection (SLAVE) Used to select COOL or HEAT by outdoor unit group with the slave unit.
2. Check items The following items can be checked.
 - (1) Current operating conditions (Normal / Abnormal / In check operation)
 - (2) Setting conditions of COOL/HEAT selection (Individual / Batch master / Batch slave)
 - (3) Low noise operating conditions (In normal operation / In low noise operation)
 - (4) Demand operating conditions (In normal operation / In demand operation)

Procedure for changing COOL/HEAT selection setting



Procedure for checking check items



(V2763)

b. “Setting mode 2”

Push and hold the **MODE (BS1)** button for 5 seconds and set to “Setting mode 2”.

<Selection of setting items>

Push the **SET (BS2)** button and set the LED display to a setting item shown in the table on the right.
 ↓
 Push the **RETURN (BS3)** button and decide the item. (The present setting condition is blinked.)

<Selection of setting conditions>

Push the **SET (BS2)** button and set to the setting condition you want.
 ↓
 Push the **RETURN (BS3)** button and decide the condition.

Push the **RETURN (BS3)** button and set to the initial status of “Setting mode 2”

* If you become unsure of how to proceed, push the **MODE (BS1)** button and return to setting mode 1.

(V2764)

No.	Setting item	Description
0	Digital pressure gauge kit display	Used to make setting of contents to display on the digital pressure gauges (e.g. pressure sensors and temperature sensors)
1	Cool/heat unified address	Sets address for cool/heat unified operation.
2	Low noise/demand address	Address for low noise/demand operation
3	Test operation settings	Used to conduct test operation without making changes to the PCB and replacing the refrigerant, after the completion of maintenance.
5	Indoor unit forced fan H	Allows forced operation of indoor unit fan while unit is stopped. (H tap)
6	Indoor unit forced operation	Allows forced operation of indoor unit.
8	Te setting	Target evaporation temperature for cooling
9	Tc setting	Target condensation temperature for heating
10	Defrost changeover setting	Changes the temperature condition for defrost and sets to quick defrost or slow defrost.
11	Sequential operation setting	Sets sequential operation (Factory set to ON)
12	External low noise setting / Demand setting	Reception of external low noise or demand signal
13	AIRNET address	Set address for AIRNET.
16	Setting of hot water	Make this setting to conduct heating operation with hot water heater.
18	High static pressure setting	Make this setting in the case of operating in high static pressure mode with diffuser duct mounted. (In order to mount the diffuser duct, remove the cover from the outdoor unit fan.)
19	Emergency operation (STD compressor operation prohibited)	Used to operate system only with inverter compressor when STD compressor malfunctions. This is a temporary operation extremely impairing comfortable environment. Therefore, prompt replacement of the compressor is required. (This operation, however, is not set with RXYQ5, 8P.)
20	Additional refrigerant charge operation setting	Carries out additional refrigerant charge operation.
21	Refrigerant recovery/vacuuming mode setting	Sets to refrigerant recovery or vacuuming mode.
22	Night-time low noise setting	Sets automatic nighttime low noise operation in a simple way. The operating time is based on “Starting set” and “Ending set”.
24	ENECUT test operation	Used to forcedly turn ON the ENECUT. (Be noted that the ENECUT is only functional with outdoor unit in the stopped state - Japanese domestic model only.)
25	Setting of external low noise level	Sets low noise level when the low noise signal is input from outside.
26	Night-time low noise operation start setting	Sets starting time of nighttime low noise operation. (Night-time low noise setting is also required.)
27	Night-time low noise operation end setting	Sets ending time of nighttime low noise operation. (Night-time low noise setting is also required.)
28	Power transistor check mode *Check after disconnection of compressor wires	Used for trouble diagnosis of DC compressor. Since the waveform of inverter is output without wiring to the compressor, it is convenient to probe whether the trouble comes from the compressor or PC board.
29	Capacity precedence setting	If the capacity control is required, the low noise control is automatically released by this setting during carrying out low noise operation and nighttime low noise operation.

No.	Setting item	Description
30	Demand setting 1	Changes target value of power consumption when demand control 1 is input.
32	Normal demand setting	Normally enables demand control 1 without external input. (Effective to prevent a problem that circuit breaker of small capacity is shut down due to large load.)
35	Setting of difference in elevation for the outdoor unit	Make the setting when the outdoor unit is installed 40 m or more below the indoor unit.
38	Emergency operation (Setting for the master unit operation prohibition in multi-outdoor-unit system)	Used to temporarily prohibit the applicable outdoor unit from operating should there be any faulty part in multi-outdoor-unit system. Since the comfortable environment is extremely impaired, prompt replacement of the part is required.
39	Emergency operation (Setting for the slave unit 1 operation prohibition in multi-outdoor-unit system)	
40	Emergency operation (Setting for the slave unit 2 operation prohibition in multi-outdoor-unit system)	
42	Emergency operation (prohibition of INV compressor operation)	If the INV compressor has a failure, used to run the system only with STD compressor(s). This is a temporary running of the system until the compressor is replaced, thus making comfort extremely worse. Therefore, it is recommended to replace the compressor as soon as possible. (Be noted this setting is not available on model RXYQ5, 8PY1.)

No.	Setting item display							Setting condition display	
	Setting item	MODE H1P	TEST H2P	C/H selection			Low noise H6P		
				IND H3P	Master H4P	Slave H5P			
0	Digital pressure gauge kit display	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	Address 0 <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> Binary number 1 <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> (4 digits) ~ 15 <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/>
1	Cool / Heat Unified address	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	Address 0 <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> * Binary number 1 <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> (6 digits) ~ 31 <input type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/>
2	Low noise/demand address	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	Address 0 <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> * Binary number 1 <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> (6 digits) ~ 31 <input type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/>
3	Test operation	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	Test operation: ON <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> Test operation: OFF <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> *
5	Indoor forced fan H	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	Normal operation <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> * Indoor forced fan H <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/>
6	Indoor forced operation	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	Normal operation <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/> * Indoor forced operation <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/>
8	Te setting	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	High <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> Normal (factory setting) <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input checked="" type="radio"/> * Low <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/>
9	Tc setting	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	High <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> Normal (factory setting) <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input checked="" type="radio"/> * Low <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/>
10	Defrost changeover setting	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	Quick defrost <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> Normal (factory setting) <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input checked="" type="radio"/> * Slow defrost <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/>
11	Sequential operation setting	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	OFF <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> ON <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> *
12	External low noise/demand setting	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	External low noise/demand: NO <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/> * External low noise/demand: YES <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input checked="" type="radio"/>
13	Airnet address	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	Address 0 <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> * Binary number 1 <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> (6 digits) ~ 63 <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/>
16	Setting of hot water heater	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	OFF <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> * ON <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/>
18	High static pressure setting	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	High static pressure setting: OFF <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> * High static pressure setting: ON <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/>
19	Emergency operation (STD compressor is inhibited to operate.)	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	OFF <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> * STD 1, 2 operation: Inhibited <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/> STD 2 operation: Inhibited <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input checked="" type="radio"/>
20	Additional refrigerant charging operation setting	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	Refrigerant charging: OFF <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/> * Refrigerant charging: ON <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input checked="" type="radio"/>
21	Refrigerant recovery/vacuumping mode setting	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	Refrigerant recovery / vacuumping: OFF <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/> * Refrigerant recovery / vacuumping: ON <input type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input checked="" type="radio"/>

No.	Setting item display								Setting condition display
	Setting item	MODE H1P	TEST H2P	C/H selection			Low noise H6P	Demand H7P	
				IND H3P	Master H4P	Slave H5P			
									* Factory set
22	Night-time low noise setting	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	OFF <input type="radio"/> ● ● ● ● ● ● ● ● * Level 1 (outdoor fan with 6 step or <input type="radio"/> ● ● ● ● ● ● ● ● Level 2 (outdoor fan with 5 step or <input type="radio"/> ● ● ● ● ● ● ● ● Level 3 (outdoor fan with 4 step or <input type="radio"/> ● ● ● ● ● ● ● ●
24	ENECUT test operation (Domestic Japan only)	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	ENECUT output OFF <input type="radio"/> ● ● ● ● ● ● ● ● * ENECUT output forced ON <input type="radio"/> ● ● ● ● ● ● ● ●
25	Low noise setting	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	Level 1 (outdoor fan with 6 step or lower) <input type="radio"/> ● ● ● ● ● ● ● ● Level 2 (outdoor fan with 5 step or lower) <input type="radio"/> ● ● ● ● ● ● ● ● * Level 3 (outdoor fan with 4 step or lower) <input type="radio"/> ● ● ● ● ● ● ● ●
26	Night-time low noise operation start setting	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	About 20:00 <input type="radio"/> ● ● ● ● ● ● ● ● About 22:00 (factory setting) <input type="radio"/> ● ● ● ● ● ● ● ● * About 24:00 <input type="radio"/> ● ● ● ● ● ● ● ●
27	Night-time low noise operation end setting	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	About 6:00 <input type="radio"/> ● ● ● ● ● ● ● ● About 7:00 <input type="radio"/> ● ● ● ● ● ● ● ● About 8:00 (factory setting) <input type="radio"/> ● ● ● ● ● ● ● ● *
28	Power transistor check mode	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	OFF <input type="radio"/> ● ● ● ● ● ● ● ● * ON <input type="radio"/> ● ● ● ● ● ● ● ●
29	Capacity precedence setting	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	OFF <input type="radio"/> ● ● ● ● ● ● ● ● * ON <input type="radio"/> ● ● ● ● ● ● ● ●
30	Demand setting 1	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	60 % demand <input type="radio"/> ● ● ● ● ● ● ● ● 70 % demand <input type="radio"/> ● ● ● ● ● ● ● ● * 80 % demand <input type="radio"/> ● ● ● ● ● ● ● ●
32	Normal demand setting	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	OFF <input type="radio"/> ● ● ● ● ● ● ● ● * ON <input type="radio"/> ● ● ● ● ● ● ● ●
35	Setting of difference in elevation for the outdoor unit	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	Normal <input type="radio"/> ● ● ● ● ● ● ● ● 65 m or less <input type="radio"/> ● ● ● ● ● ● ● ● 90 m or less <input type="radio"/> ● ● ● ● ● ● ● ●
38	Emergency operation (Master unit with multi-outdoor-unit system is inhibited to operate.)	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	OFF <input type="radio"/> ● ● ● ● ● ● ● ● * Master unit operation: Inhibited <input type="radio"/> ● ● ● ● ● ● ● ●
39	Emergency operation (Slave unit 1 with multi-outdoor-unit system is inhibited to operate.)	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	OFF <input type="radio"/> ● ● ● ● ● ● ● ● * Slave unit 1 operation: Inhibited <input type="radio"/> ● ● ● ● ● ● ● ●
40	Emergency operation (Slave unit 2 with multi-outdoor-unit system is inhibited to operate.)	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	OFF <input type="radio"/> ● ● ● ● ● ● ● ● * Slave unit 2 operation: Inhibited <input type="radio"/> ● ● ● ● ● ● ● ●
42	Emergency operation (prohibition of INV compressor operation)	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	Normal operation <input type="radio"/> ● ● ● ● ● ● ● ● * Emergency operation (prohibition of INV compressor operation) <input type="radio"/> ● ● ● ● ● ● ● ●

c. Monitor mode

To enter the monitor mode, push the **MODE (BS1)** button when in "Setting mode 1".

<Selection of setting item>

Push the **SET (BS2)** button and set the LED display to a setting item.

<Confirmation on setting contents>

Push the **RETURN (BS3)** button to display different data of set items.

Push the **RETURN (BS3)** button and switches to the initial status of "Monitor mode".

* Push the **MODE (BS1)** button and returns to "Setting mode 1".

(V2765)

No.	Setting item	LED display							Data display
		H1P	H2P	H3P	H4P	H5P	H6P	H7P	
0	Various settings	●	●	●	○	●	●	●	Lower 4 digits
1	C/H unified address	●	●	●	●	●	●	○	Lower 6 digits
2	Low noise/demand address	●	●	●	●	●	○	●	
3	Not used	●	●	●	●	●	○	○	
4	Airnet address	●	●	●	●	○	●	●	
5	Number of connected indoor units	●	●	●	●	○	●	○	
6	Number of connected BS units	●	●	●	●	○	○	●	
7	Number of connected zone units (excluding outdoor and BS unit)	●	●	●	●	○	○	○	
8	Number of outdoor units	●	●	●	○	●	●	●	
9	Number of connected BS units	●	●	●	○	●	●	○	Lower 4 digits: upper
10	Number of connected BS units	●	●	●	○	●	○	●	Lower 4 digits: lower
11	Number of zone units (excluding outdoor and BS unit)	●	●	●	○	●	○	○	Lower 6 digits
12	Number of terminal blocks	●	●	●	○	○	●	●	Lower 4 digits: upper
13	Number of terminal blocks	●	●	●	○	○	●	○	Lower 4 digits: lower
14	Contents of malfunction (the latest)	●	●	●	○	○	○	●	Malfunction code table
15	Contents of malfunction (1 cycle before)	●	●	●	○	○	○	○	
16	Contents of malfunction (2 cycle before)	●	●	○	●	●	●	●	
20	Contents of retry (the latest)	●	●	○	●	○	●	●	
21	Contents of retry (1 cycle before)	●	●	○	●	○	●	○	
22	Contents of retry (2 cycle before)	●	●	○	●	○	○	●	
25	Number of multi connection outdoor units	●	●	○	○	●	●	○	Lower 6 digits


The numbers in the "No." column represent the number of times to press the SET (BS2) button.

Setting item 0 Display contents of "Number of units for various settings"

EMG operation / backup operation setting	ON	●	●	●	○	●	●	●
	OFF	●	●	●	●	●	●	●
Defrost select setting	Short	●	●	●	●	○	●	●
	Medium	●	●	●	●	●	●	●
	Long	●	●	●	●	●	●	●
Te setting	H	●	●	●	●	○	●	●
	M	●	●	●	●	●	○	●
	L	●	●	●	●	●	●	●
Tc setting	H	●	●	●	●	●	○	●
	M	●	●	●	●	●	●	○
	L	●	●	●	●	●	●	●


Push the SET button and match with the LEDs No. 1 - 15, push the RETURN button, and confirm the data for each setting.

★ Data such as addresses and number of units is expressed as binary numbers; the two ways of expressing are as follows:



The No. 1 cool/heat unified address is expressed as a binary number consisting of the lower 6 digits. (0 - 63)

In ① the address is 010110 (binary number), which translates to $16 + 4 + 2 = 22$ (base 10 number). In other words, the address is 22.



The number of terminal blocks for No. 12 and 13 is expressed as an 8-digit binary number, which is the combination of four upper, and four lower digits for No. 12 and 13 respectively. (0 - 128)

In ② the address for No. 12 is 0101, the address for No. 13 is 0110, and the combination of the two is 01010110 (binary number), which translates to $64 + 16 + 4 + 2 = 86$ (base 10 number). In other words, the number of terminal block is 86.

★ See the preceding page for a list of data, etc. for No. 0 - 22.


4.4.2.2 Cool / Heat Mode Switching (*Heat Pump model only)

There are the following 4 cool/heat switching modes.

- ① Set cool/heat separately for each outdoor unit system by indoor unit remote control.
- ② Set cool/heat separately for each outdoor unit system by cool/heat switching remote control.
- ③ Set cool/heat for more than one outdoor unit system simultaneously in accordance with unified master outdoor unit by indoor unit remote control.
- ④ Set cool/heat for more than one outdoor unit system simultaneously in accordance with unified master outdoor unit by cool/heat switching remote control.

① Set Cool / Heat Separately for Each Outdoor Unit System by Indoor Unit Remote Control

- ◆ It does not matter whether or not there is outdoor - outdoor unit wiring.
- ◆ Set outdoor unit PC board DS1-1 to IN (factory set).
- ◆ Set cool/heat switching to IND (individual) for "Setting mode 1" (factory set).
- ◆ Set the master unit (= indoor unit having the right to select the cooling/heating operation mode).



<Set the master unit (= indoor unit having the right to select the cooling/heating operation mode).>

In the case of wired remote controls

- After the check operation, "CHANGEOVER UNDER CONTROL" is flashing in all connected remote controls.
- Select an indoor unit to be used as the master unit in accordance with the request from the customer. (It is recommended to select an indoor unit which will be used most often as the master unit.)
- Press the operation mode selector button in the remote control of the indoor unit selected as the master unit.
- In that remote control, "CHANGEOVER UNDER CONTROL" disappears. That remote control will control changeover of the cooling/heating operation mode.
- In other remote controls, "CHANGEOVER UNDER CONTROL" lights.


For the details, refer to the installation manual supplied together with the indoor unit.

In the case of infrared remote controls

- After the check operation, the timer lamp is flashing in all connected indoor units.
- Select an indoor unit to be used as the master unit in accordance with the request from the customer. (It is recommended to select an indoor unit which will be used most often as the master unit.)
- Press the operation selector mode button in the remote control of the indoor unit selected as the master unit. A "peep" sound is emitted, and the timer lamp turns off in all indoor units.
- That indoor unit will control changeover of the cooling/heating operation mode.


② Set Cool / Heat Separately for Each Outdoor Unit System by Cool / Heat Switching remote control

- ◆ It does not matter whether or not there is outdoor - outdoor unit wiring.
- ◆ Set outdoor unit PC board DS1-1 to OUT (factory set).
- ◆ Set cool/heat switching to IND (individual) for “Setting mode 1” (factory set).



③ Set Cool / Heat for More Than One Outdoor Unit System Simultaneously in Accordance with Unified Master Outdoor Unit by Indoor Unit Remote Control

- ◆ Install the external control adapter for outdoor unit on either the outdoor-outdoor, indoor-outdoor transmission line.
- ◆ Set outdoor unit PC board DS1-1 to IN (factory set).
- ◆ In setting mode 1, set the outdoor unit you want to give cool/heat selection permission to as the group master, and set the other outdoor units as group slave units.
- ◆ Set the outdoor unit external control adapter SS1 to BOTH (factory set) or C/H, and SS2 to OFF (factory set).




(V3060)

Multi outdoor units connection


④ Set Cool / Heat for More Than One Outdoor Unit System Simultaneously in Accordance with Unified Master Outdoor Unit by Cool / Heat Switching Remote Control

- ◆ Install the external control adapter for outdoor unit on either the outdoor-outdoor, indoor-outdoor transmission line.
- ◆ Mount the COOL/HEAT selection remote control to the master outdoor unit for the unified control.
- ◆ Set the DS1-1 on the PC board of master outdoor unit to OUT.
- ◆ In setting mode 1, set the outdoor unit you want to give cool/heat selection permission to as the group master, and set the other outdoor units as group slave units.
- ◆ Set the outdoor unit external control adapter SS1 to BOTH (factory set) or C/H, and SS2 to OFF (factory set).



<Master unit>

<Slave unit>




(V3060-1)

Multi outdoor units connection

Supplementation on ③ and ④.

When switching cool/heat for each adapter PC board with the use of more than one adapter PC board, set the address of the external control adapter for outdoor unit PC board DS1 and DS2 so that it matches the unified cool/heat address of outdoor unit main PC board.



(V2723)

Address setting for ③ and ④ (Set lower 5 digits with binary number.) [No.0 to No.31]

Address No.	Outdoor unit PC board LED Set with setting mode 2		External control adaptor for outdoor unit	
	DS2	DS1	DS2	DS1
No 0	○ ●	● ● ● ● ● 0		
No 1	○ ●	● ● ● ● ○ 1		
No 2	○ ●	● ● ● ○ ● 2		
No 3	○ ●	● ● ● ○ ○ 3		
No 4	○ ●	● ● ○ ● ● 4		
}	}	}	}	}
No 30	○ ●	○ ○ ○ ○ ● 30		
No 31	○ ●	○ ○ ○ ○ ○ 31		

○ ON ● OFF Upper position (ON) lower position (OFF)
(The shaded part shows knob)

(V2724)

4.4.2.3 Setting of Low Noise Operation and Demand Operation

Setting of Low Noise Operation

By connecting the external contact input to the low noise input of the outdoor unit external control adapter (optional), you can lower operating noise by 2-3 dB.

Setting	Content
Mode 1	Set the outdoor unit fan to Step 6 or lower.
Mode 2	Set the outdoor unit fan to Step 5 or lower.
Mode 3	Set the outdoor unit fan to Step 4 or lower.

A. When the low noise operation is carried out by external instructions (with the use of the external control adapter for outdoor unit)

1. While in "Setting mode 2", set the setting condition for set item No. 12 (Setting of external low noise/demand operation) to "YES".
2. If necessary, while in "Setting mode 2", select the setting condition (i.e., "Mode 1", "Mode 2", or "Mode 3") for set item No. 25 (Setting of external low noise level).
3. If necessary, while in "Setting mode 2", set the setting condition for the set item No. 29 (Setting of capacity precedence) to "ON".
(If the condition is set to "ON", when the air-conditioning load reaches a high level, the low noise operation command will be ignored to put the system into normal operation mode.)

B. When the low noise operation is carried out automatically at night (The external control adapter for outdoor unit is not required)

1. While in "Setting mode 2", select the setting condition (i.e., "Mode 1", "Mode 2", or "Mode 3") for set item No. 22 (Setting of nighttime low noise level).
2. If necessary, while in "Setting mode 2", select the setting condition (i.e., "20:00", "22:00", or "24:00") for set item No. 26 (Setting of start time of nighttime low noise operation).
(Use the start time as a guide since it is estimated according to outdoor temperatures.)
3. If necessary, while in "Setting mode 2", select the setting condition (i.e., "06:00", "07:00", or "08:00") for set item No. 27 (Setting of end time of nighttime low noise operation).
(Use the end time as a guide since it is estimated according to outdoor temperatures.)
4. If necessary, while in "Setting mode 2", set the setting condition for set item No. 29 (Setting of capacity precedence) to "ON".
(If the condition is set to "ON", when the air-conditioning load reaches a high level, the system will be put into normal operation mode even during nighttime.)

Image of operation in the case of A




Image of operation in the case of B





Image of operation in the case of A and B



Setting of Demand Operation

By connecting the external contact input to the demand input of the outdoor unit external control adapter (optional), the power consumption of unit operation can be saved suppressing the compressor operating condition.

Set item	Condition	Content
Demand 1	Mode 1	The compressor operates at approx. 60% or less of rating.
	Mode 2	The compressor operates at approx. 70% or less of rating.
	Mode 3	The compressor operates at approx. 80% or less of rating.
Demand 2	—	The compressor operates at approx. 40% or less of rating.

A. When the demand operation is carried out by external instructions (with the use of the external control adapter for outdoor unit).

1. While in "Setting mode 2", set the setting condition for set item No. 12 (Setting of external low noise/demand operation) to "YES".
2. If necessary, while in "Setting mode 2", select the set item No. 30 (Setting of Demand 1 level) and then set the setting condition to targeted mode.

B. When the Normal demand operation is carried out. (Use of the external control adapter for outdoor unit is not required.)

1. While in "Setting mode 2", make setting of the set item No. 32 (Setting of constant demand) to "ON".
2. While in "Setting mode 2", select the set item No. 30 (Setting of Demand 1 level) and then set the setting condition to targeted mode.

Image of operation in the case of A




Image of operation in the case of B





Image of operation in the case of A and B



**Detailed Setting
Procedure of Low
Noise Operation
and Demand
Control****1. Setting mode 1 (H1P off)**

- ① In setting mode 2, push the BS1 (MODE button) one time. → Setting mode 1 is entered and H1P off.
During the setting mode 1 is displayed, "In low noise operation" and "In demand control" are displayed.

2. Setting mode 2 (H1P on)

- ① In setting 1, push and hold the BS1 (MODE button) for more than 5 seconds. → Setting mode 2 is entered and H1P lights.
- ② Push the BS2 (SET button) several times and match the LED display with the Setting No. you want.
- ③ Push the BS3 (RETURN button) one time, and the present setting content is displayed.
→ Push the BS2 (SET button) several times and match the LED display with the setting content (as shown below) you want.
- ④ Push the BS3 (RETURN button) two times. → Returns to ①.
- ⑤ Push the BS1 (MODE button) one time. → Returns to the setting mode 1 and turns H1P off.

○: ON ●: OFF ◐: Blink

Setting No.	Setting contents	① Setting No. indication							② Setting No. indication							Setting contents	③ Setting contents indication (Initial setting)							
		H1P	H2P	H3P	H4P	H5P	H6P	H7P	H1P	H2P	H3P	H4P	H5P	H6P	H7P		H1P	H2P	H3P	H4P	H5P	H6P	H7P	
12	External low noise / Demand setting	○	●	●	●	●	●	●	○	●	●	○	○	●	●	NO (Factory set)	○	●	●	●	●	●	●	◐
																YES	○	●	●	●	●	●	◐	●
22	Night-time low noise setting								○	●	○	●	○	○	●	OFF (Factory setting)	○	●	●	●	●	●	●	●
																Mode 1	○	●	●	●	●	●	◐	●
																Mode 2	○	●	●	●	●	●	◐	●
																Mode 3	○	●	●	●	●	●	◐	◐
25	External low noise setting								○	●	○	○	●	●	○	Mode 1	○	●	●	●	●	●	◐	
																Mode 2 (Factory setting)	○	●	●	●	●	●	◐	●
																Mode 3	○	●	●	●	●	◐	●	●
26	Night-time low noise start setting								○	●	○	○	●	○	●	PM 8:00	○	●	●	●	●	●	◐	
																PM 10:00 (Factory setting)	○	●	●	●	●	●	◐	●
																PM 0:00	○	●	●	●	●	◐	●	●
27	Night-time low noise end setting								○	●	○	○	●	○	○	AM 6:00	○	●	●	●	●	●	◐	
																AM 7:00	○	●	●	●	●	●	◐	●
																AM 8:00 (Factory setting)	○	●	●	●	●	◐	●	●
29	Capacity precedence setting								○	●	○	○	○	●	○	Low noise precedence (Factory setting)	○	●	●	●	●	●	◐	
																Capacity precedence	○	●	●	●	●	●	◐	●
30	Demand setting 1								○	●	○	○	○	○	●	60 % of rated power consumption	○	●	●	●	●	●	◐	
																70 % of rated power consumption (Factory setting)	○	●	●	●	●	●	◐	●
																80 % of rated power consumption	○	●	●	●	●	◐	●	●
32	Normal demand setting								○	●	●	●	●	●	●	OFF (Factory setting)	○	●	●	●	●	●	◐	
																ON	○	●	●	●	●	●	◐	●

Setting mode indication section

Setting No. indication section

Set contents indication section

4.4.2.4 Setting of Refrigerant Recovery Mode

When carrying out the refrigerant collection on site, fully open the respective expansion valve of indoor and outdoor units.

All indoor and outdoor unit's operation are prohibited.

[Operation procedure]

- ① In **setting mode 2** with units in stop mode, set "Refrigerant Recovery / Vacuuming mode" to ON. The respective expansion valve of indoor and outdoor units are fully opened. (H2P turns to display "TEST OPERATION" (blinks), "TEST OPERATION" and "UNDER CENTRALIZED CONTROL" are displayed on the remote control, and the all indoor / outdoor unit operation is prohibited.
After setting, do not cancel "Setting Mode 2" until completion of refrigerant recovery operation.
 - ② Collect the refrigerant using a refrigerant recovery unit. (See the instruction attached to the refrigerant recovery unit for more detail.)
 - ③ Press Mode button "BS1" once and reset "Setting Mode 2".
-

4.4.2.5 Setting of Vacuuming Mode

In order to perform vacuuming operation at site, fully open the expansion valves of indoor and outdoor units and turn on some solenoid valves.


[Operating procedure]

- ① With **Setting Mode 2** while the unit stops, set "Refrigerant recovery / Vacuuming mode" to ON. The expansion valves of indoor and outdoor units fully open and some of solenoid valves open.
(H2P blinks to indicate the test operation, and the remote control displays "Test Operation" and "Under centralized control", thus prohibiting operation.)
After setting, do not cancel "Setting Mode 2" until completion of Vacuuming operation.
- ② Use the vacuum pump to perform vacuuming operation.
- ③ Press Mode button "BS1" once and reset "Setting Mode 2".

4.4.2.6 Check Operation Detail.

CHECK OPERATION FUNCTION

(Press the MODE button BS1 once and set to SETTING MODE 1 (H1P: OFF))



5. Caution for Refrigerant Leaks

5.1 Caution for Refrigerant Leaks

5.1.1 Introduction

Points to note in connection with refrigerant leaks

The installer and system specialist shall secure safety against leakage according to local regulations or standards. The following standards may be applicable if local regulations are not available.


5.1.2 Maximum Concentration Level

The maximum charge of refrigerant and the calculation of the maximum concentration of refrigerant is directly related to the humanly occupied space in to which it could leak.

The unit of measurement of the concentration is kg/m³ (the weight in kg of the refrigerant gas in 1m³ volume of the occupied space).

Compliance to the local applicable regulations and standards for the maximum allowable concentration level is required.

In Australia the maximum allowed concentration level of refrigerant to a humanly space is limited to 0.35 kg/m³ for R-407C, and 0.44 kg/m³ for R-410A.



Pay special attention to the place, such as a basement, etc., where refrigerant can stay, since refrigerant is heavier than air.

5.1.3 Procedure for Checking Dangerous Concentration

Check the Dangerous concentration in accordance with steps (1)-(4) below and take whatever action is necessary.

Step1: Calculate the amount of refrigerant (kg) charged to each system separately.

(Amount of refrigerant in a single indoor unit system)	+	(Additional charging amount)	=	Total amount of refrigerant (kg) in the system

Amount of refrigerant with which the system is charged before leaving the factory

Amount of refrigerant added locally in accordance with the length or diameter of the refrigerant piping




Notes: Where a single refrigerant facility is divided into 2 entirely independent refrigerant systems then use the amount of refrigerant with which each separate system is charged.

Step 2:


Calculate the smallest room volume (m³)

In a case like the following calculate the volume of (a), (b) as a single room or as the smallest room.

A. Where there are no smaller room divisions.




B. Where there is a room division but there is an opening between the rooms sufficiently large to permit a free flow of air back and forth.



(Where there is an opening without a door or where there are openings above and below the door which are each equivalent in size to 0.15% or more of the floor area.)

C. Where there is a gas leak detection alarm device linked to a mechanical ventilator in the smallest room then the next smallest room will become the measurement target.



Step 3:

Calculate the refrigerant density using the results of the calculations in Step (1) and (2) above.

Total volume of refrigerant in the refrigerant system

_____ <= Dangerous concentration (kg/m³)

Size (m³) of the smallest room in which there is an indoor unit installed

in the case of: R-407C = 0.35kg/m³, R-410A = 0.44kg/m³


If the result of the above calculation exceeds the dangerous concentration level then make similar calculations for the second then third smallest room and so on until the result falls short of the concentration level.

Step 4:**Dealing with situations where the result exceeds the dangerous concentration level.**

Where the installation of a facility results in a concentration in excess of the dangerous concentration level then it may be necessary to revise the system design to some extent or else take one of the following courses of action.

Action 1: Making openings which will allow the air to flow freely into the room. Make openings above and below the door which are each equivalent in size to 0.15% or more of the floor area or make a doorless opening.

Action 2: Fit a mechanical ventilator linked to a gas leak detection alarm device.


**Notes:**

This precaution shows the requirement of EN.

The precaution should be followed in accordance of local code.

6. Hand Over to Customer

6.1 Operational Steps



(V1050)

Important Points

- The measurements taken during the test run should be recorded and kept on a test run inspection sheet.
- Do not forget to record the **length of the refrigerant piping** and the **refrigerant additional charging volume** on the plate on the back of the outdoor unit external notice board, as this information will be required for servicing the system.
- Explain to the customer how to operate the equipment and let him try it.
- Assemble all the relevant diagrams and other printed matter which is required to operate the system and hand it all over to the customer (on the spot) and tell him to keep it.

List of equipment which has been delivered

Contract drawings

It is essential to prepare a control wiring diagram which clarifies the refrigerant system and the control system.


1 set of operation manuals

Names of those responsible for the work (emergency contact address)

Equipment guarantees

(V1143)

- Make the service contact address clear.



7. Appendix

7.1 Operating Noise of Indoor Units

7.1.1 Difference between Catalogue Data and Actual Noise

Operating noise differs depending on the place of measurement (room) because of the various degrees with which the room reverberates the sound. To determine the amount of reverberation under uniform conditions, the unit has been measured in a dead room with results having been compiled in the below table. The actual sound produced in unit operation can be determined from Table 1.

Sound pressure rise due to room reverberation (Higher than catalogue data)




Table 1

		A	B	C
Room Interior Detection	Floor	Mortar	Linoleum tile	Carpet
	Walls	Mortar	Plaster	Fiberglass + Saroncross finish
	Ceiling	Mortar	mineral wool tile	Fiberglass + Saroncross finish
Average Absorbed Sound (Room with Approx. 50 m ² Floor Area)		0.05	0.12	0.25
Estimated value to be added to catalogue value		11~12	8~8.5	5~6

Classifications of indoor unit environments (reference data)

Table 2

Classification	Environment	Example	Faint Noises (NOTE 2)	Recommended Operating Noise on Site
1	Non-active places requiring silence	Reception rooms, libraries, sitting rooms, hospitals (examining rooms) (NOTE 1)	~35	~40
2	Sedate business activities that do not disturb people even over time	Quiet offices, classrooms, small conference rooms, lobbies	~40	~45
3	Somewhat quiet settings that permit soft-spoken conversation, typical activities	Small offices, large conferences rooms, quiet stores, restaurants	~45	~50
4	Somewhat loud settings that permit regular conversation, brisk activity	Large offices, typical stores, cafeterias	~50	~55
5	Loud places that permit conversation in a loud voice, highly active place with many people	Loud large-side offices, large cafeterias, loud stores	~55	~60
6	Rather loud settings	Factories, gymnasiums, recreational places like pachinko parlors	~60	~65



- Notes:**
1. Excluding bedrooms
 2. Reference values of faint noises in the place of usage

7.1.2 Faint Noises and Correcting Operating Noise with Respect to Faint Noises

Faint noises are defined as peripheral sounds existing while the unit is not running, which are picked up when measuring operating noise. If these faint noises are 10 dB or more than the noise produced by the unit, the measured value can be taken as the operating noise of the unit. But, the difference must be corrected if less than 10 dB, because of the effect these noises have on the actual measured value. Also, when the sound meter remains unchanged even while the unit is stopped, we can determine the operational noise to be at least 10 dB less than the faint noises, but we cannot pinpoint the operating noise exactly. For example, if the faint noises are some 65 dB and the noise produced by the unit in operation is 70 dB, the indicated difference comes to 5 dB. Using Table 3, we recommend you correct the operating noise by about 2 dB to 68 dB.


Table 3 Correcting the effect of faint noises

Unit: dB

Difference between when noise is produced and when not	1	2	3	4	5	6	7	8	9	10
Corrective Value	-6.9	-4.4	-3.0	-2.3	-1.7	-1.25	-0.95	-0.75	-0.60	-0.45

7.1.3 Calculating Operating Noise

When two or more units are running at the same time, the amount of operating noise they produce rises. The total amount of noise produced can be obtained ahead of time with Chart 4.



Sample calculation 1

L_1 and L_2 are given as compounded sounds of 50 and 49 dB respectively. Since $L_1 - L_2 = 50 - 49 = 1$, the corrective value is 2.5, therefore $50 + 2.5 = 52.5$ dB.


Sample calculation 2

When sounds of 40 dB, 38 dB, 37 dB and 40 dB are placed in order of magnitude, we obtain the following:

40 dB, 40 dB, 38 dB, 37 dB

To start, the difference between 40 dB and 40 dB is 0, therefore we take a corrective value of 3dB and obtain $40 + 3 = 43$ dB. The compounded sound of 43 dB and 38 dB has a 5.0 dB difference, thus a corrective value of 1.2 dB, which gives us 44.2 dB from $43 + 1.2$. In the same manner, the corrective value for 44.2 dB and 37 dB is approximately 0.7 dB, or in other words, $44.2 + 0.7 = 44.9$ dB.

7.2 Piping Installation Point




Since there is a possibility that oil may be collected on a stop machine side, install piping between outdoor units to go to level or go up to an outdoor unit, and to make a slope.

(V3036)

The projection part between multi connection piping kits



When the piping length between the multi connection kits or between multi connection kit and outdoor unit is 2m or more, prepare a vertical projection part (200mm or more as shown below) only on the gas pipe line location less than 2m from multi connection kit.

In the case of 2m or less



(V3037)


In the case of 2m or more



(V3038)

<The Example of A Wrong Pattern>


Wrong



Oil is collected to the outdoor unit at the time of a stop, because of bottom omission of piping.

(V3039)

Wrong




Oil is collected to the low level outdoor unit at the time of a stop, because of downward slope of piping.




The example of installation on which oil is not collected.

Good



Vertical Projection

Good



(V3040)

Max. allowable Piping Length	Outdoor Unit - Multi Connection Piping Kit	Actual piping length 10m or less, equivalent length 13m or less
	Multi Connection Piping Kit - Indoor Unit	Actual piping length 165m or less, equivalent length 190m or less, the total extension 1000m or less
	REFNET Joint - Indoor Unit	Actual piping length 40m or less (Refer to Page 285, 286 Note 2 in case of up to 90m)
Allowable Level Difference	Outdoor Unit - Outdoor Unit	5m or less
	Outdoor Unit - Indoor Unit	50m or less ★ 90m or less (when an outdoor unit is lower than indoor units: 40m or less in case of RX(Y)Q5P)
	Indoor Unit - Indoor Unit	15m or less

Note: ★ Available on request if the outdoor unit is above.

7.3 Example of Connection (R-410A type)

Example of connection


(Connection of 8 indoor units)

- (*1) “ ← ” indicate the Outdoor unit multi connection piping kit
- (*2) In case of multi outdoor system, re-read to the first Outdoor unit multi connection piping kit as seen from the indoor unit.

7.3.1 Branch with Refnet Joint

Heat Pump 50Hz/60Hz, Cooling Only 50Hz (RX(Y)Q5~54P, 50PH)

(Connection of 8 indoor units Heat pump system)



*2 In case of multi outdoor system, re-read to the first Outdoor unit multi connection piping kit as seen from the indoor unit.


Maximum allowable length

Between outdoor (*2) and indoor units

- Actual pipe length
Pipe length between outdoor (*2) and indoor units $\leq 165\text{m}$
Example unit 8: $a + b + c + d + e + f + g + p \leq 165\text{m}$
- Equivalent length
Equivalent pipe length between outdoor (*2) and indoor units $\leq 190\text{m}$ *(See Note 1)
(assume equivalent pipe length of refnet joint to be 0.5m, that of refnet header to be 1m, calculation purposes)
- Total extension length
Total piping length from outdoor unit (*2) to all indoor units $\leq 1000\text{m}$

Between outdoor unit and Outdoor unit multi connection piping kit (Only for multi system)

- Actual pipe length
Pipe length between outdoor unit and Outdoor unit multi connection piping kit $\leq 10\text{m}$
- Equivalent length
Equivalent length between outdoor unit and Outdoor unit multi connection piping kit $\leq 13\text{m}$



$r \leq 10\text{m}$ (Equivalent length: $\leq 13\text{m}$)
 $s \leq 10\text{m}$ (Equivalent length: $\leq 13\text{m}$)
 $t \leq 10\text{m}$ (Equivalent length: $\leq 13\text{m}$)

Allowable height length

Between outdoor and indoor units

- Difference in height
Difference in height between outdoor and indoor units ($H1$) $\leq 50\text{m}$
($\leq 90\text{m}$ if the outdoor unit is below)

Between indoor and indoor units

- Difference in height
Difference in height between adjacent indoor units ($H2$) $\leq 15\text{m}$

Between outdoor and outdoor units

- Difference in height
Difference in height between outdoor unit ($H3$) $\leq 5\text{m}$

Allowable length after the branch


- Actual pipe length
Pipe length from first refrigerant branch kit (either refnet joint or refnet header) to indoor unit $\leq 40\text{m}$
*(See Note 2)
Example unit 8: $b + c + d + e + f + g + p \leq 40\text{m}$ *(See Note 2)



Refer Note 1 and Note 2 on page 143, 144.

7.3.2 Branch with Refnet Joint and Refnet Header

Heat Pump 50Hz/60Hz, Cooling Only 50Hz (RX(Y)Q5~54P, 50PH)
 (Connection of 8 indoor units Heat pump system)




*2 In case of multi outdoor system, re-read to the first Outdoor unit multi connection piping kit as seen from the indoor unit.

Maximum allowable length

- Between outdoor (*2) and indoor units
 - Actual pipe length
 - Pipe length between outdoor (*2) and indoor units $\leq 165\text{m}$
 - Example unit 6: $a + b + h \leq 165\text{m}$, unit 8: $a + i + k \leq 165\text{m}$
 - Equivalent length
 - Equivalent pipe length between outdoor (*2) and indoor units $\leq 190\text{m}$ *(See Note 1)
 (assume equivalent pipe length of refnet joint to be 0.5m, that of refnet header to be 1m, calculation purposes)
 - Total extension length
 - Total piping length from outdoor unit (*2) to all indoor units $\leq 1000\text{m}$

Between outdoor unit and Outdoor unit multi connection piping kit
 (Only for multi system)

- Actual pipe length
 - Pipe length between outdoor unit and Outdoor unit multi connection piping kit $\leq 10\text{m}$
- Equivalent length
 - Equivalent length between outdoor unit and Outdoor unit multi connection piping kit $\leq 13\text{m}$



$r \leq 10\text{m}$ (Equivalent length: $\leq 13\text{m}$)
 $s \leq 10\text{m}$ (Equivalent length: $\leq 13\text{m}$)
 $t \leq 10\text{m}$ (Equivalent length: $\leq 13\text{m}$)

Allowable height

- Between outdoor and indoor units
 - Difference in height
 - Difference in height between outdoor and indoor units ($H1$) $\leq 50\text{m}$
 ($\leq 90\text{m}$ if the outdoor unit is below)
- Between indoor and indoor units
 - Difference in height
 - Difference in height between adjacent indoor units ($H2$) $\leq 15\text{m}$
- Between outdoor and outdoor units
 - Difference in height
 - Difference in height between outdoor unit ($H3$) $\leq 5\text{m}$

Allowable length after the branch

- Actual pipe length
 - Pipe length from first refrigerant branch kit (either refnet joint or refnet header) to indoor unit $\leq 40\text{m}$
 - *(See Note 2)
 - Example unit 6: $b + h \leq 40\text{m}$, unit 8: $i + k \leq 40\text{m}$ *(See Note 2)




Refer Note 1 and Note 2 on page 143, 144.

7.3.3 Branch with Refnet Header

Heat Pump 50Hz/60Hz, Cooling Only 50Hz (RX(Y)Q5~54P, 50PH)

(Connection of 8 indoor units Heat pump system)




*2 In case of multi outdoor system, re-read to the first Outdoor unit multi connection piping kit as seen from the indoor unit.

Maximum allowable length

- Between outdoor (*2) and indoor units
 - Actual pipe length
 - Pipe length between outdoor (*2) and indoor units $\leq 165\text{m}$
 - Example unit 8: $a + i \leq 165\text{m}$
 - Equivalent length
 - Equivalent pipe length between outdoor (*2) and indoor units $\leq 190\text{m}$ *(See Note 1)
(assume equivalent pipe length of refnet joint to be 0.5m, that of refnet header to be 1m, calculation purposes)
 - Total extension length
 - Total piping length from outdoor unit (*2) to all indoor units $\leq 1000\text{m}$

Between outdoor unit and Outdoor unit multi connection piping kit (Only for multi system)

- Actual pipe length
 - Pipe length between outdoor unit and Outdoor unit multi connection piping kit $\leq 10\text{m}$
- Equivalent length
 - Equivalent length between outdoor unit and Outdoor unit multi connection piping kit $\leq 13\text{m}$



$r \leq 10\text{m}$ (Equivalent length: $\leq 13\text{m}$)
 $s \leq 10\text{m}$ (Equivalent length: $\leq 13\text{m}$)
 $t \leq 10\text{m}$ (Equivalent length: $\leq 13\text{m}$)

Allowable height

- Between outdoor and indoor units
 - Difference in height
 - Difference in height between outdoor and indoor units ($H1$) $\leq 50\text{m}$
($\leq 90\text{m}$ if the outdoor unit is below)
- Between indoor and indoor units
 - Difference in height
 - Difference in height between adjacent indoor units ($H2$) $\leq 15\text{m}$
- Between outdoor and outdoor units
 - Difference in height
 - Difference in height between outdoor unit ($H3$) $\leq 5\text{m}$

Allowable length after the branch

- Actual pipe length
 - Pipe length from first refrigerant branch kit (either refnet joint or refnet header) to indoor unit $\leq 40\text{m}$
 - *(See Note 2)
 - Example unit 8: $i \leq 40\text{m}$



Refer Note 1 and Note 2 on page 143, 144.

7.4 Refrigerant Branch Kit Selection

Refrigerant branch kits can only be used with R-410A.

7.4.1 How to Select the Refnet Joint

Heat Pump 50Hz/60Hz, Cooling Only 50Hz (RX(Y)Q5~54P, 50PH)

- When using REFNET joint at the first branch counted from the outdoor unit side. Choose from the following table in accordance with the outdoor unit capacity type. (Example: REFNET joint A)


Outdoor unit capacity type	Refrigerant branch kit name
5HP type	KHRP26A22T
8, 10HP type	KHRP26A33T
12~22HP type	KHRP26A72T
12~22HP type~	KHRP26A73T + KHRP26M73TP

- Choose the REFNET joints other than that for the first branch from the following table in accordance with the total capacity index of all the indoor units connected below the REFNET joint.


Indoor unit total capacity index	Refrigerant branch kit name
< 200	KHRP26A22T
200 ≤ x < 290	KHRP26A33T
290 ≤ x < 640	KHRP26A72T
640 ≤	KHRP26A73T + KHRP26M73TP

*Example of downstream indoor units


- example in case of refnet joint C; indoor units 3 + 4 + 5 + 6 + 7 + 8,



- example in case of refnet joint B indoor units 7 + 8
example in case of refnet joint header; indoor units 1 + 2 + 3 + 4 + 5 + 6



- example in the case of refnet header; indoor units 1 + 2 + 3 + 4 + 5 + 6 + 7 + 8




7.4.2 How to Select the Refnet Header (Heat Pump/Cooling Only RX(Y)Q5~54P, 50PH)

- Choose from the following table in accordance with the total capacity of all the indoor units connected below the REFENT header.
- Note: 250 type cannot be connected below the REFENT header.


Indoor unit total capacity index	Refrigerant branch kit name
< 200	KHRP26M22H (Max. 4 branch)
200 ≤ x < 290	KHRP26M33H (Max. 8 branch)
290 ≤ x < 640	KHRP26M72H (Max. 8 branch) (See Note 3 - Next page)
640 ≤	KHRP26M73H (Max. 8 branch) + KHRP26M73HP

*Example of downstream indoor units


1. example in case of refnet joint C; indoor units 3 + 4 + 5 + 6 + 7 + 8



2. example in case of refnet joint B indoor units 7 + 8,
example in case of refnet header ; indoor units 1 + 2 + 3 + 4 + 5 + 6



3. example in the case of refnet header; indoor units 1 + 2 + 3 + 4 + 5 + 6 + 7 + 8



7.4.3 How to Select the Outdoor Unit Multi Connection Piping Kit (This is Required when the System is Multi Outdoor Unit System.)

Heat Pump 50Hz/60Hz, Cooling Only 50Hz

- Choose from the following table in accordance with the number of outdoor units.

Number of outdoor units	Connection piping kit name
2 units	BHFP22P100
3 units	BHFP22P151

7.5 Pipe Size Selection


7.5.1 Heat Pump 50Hz/60Hz, Cooling Only 50Hz (RX(Y)Q5~54P, 50PH)

Pipe size selection

⚠ Caution

The thickness of the pipes in the table shows the requirements of Japanese High Pressure Gas Control law. (As of Jan. 2003)
The thickness and material shall be selected in accordance with local code.

For the multi outdoor unit system, select in accordance with the following figure.



Piping between Outdoor unit and first refrigerant branch kit.

Piping between first Outdoor unit multi connection piping kit and first refrigerant branch kit. (Part A)

- Choose from the following table in accordance with the outdoor unit capacity type.

Piping between Outdoor unit multi connection piping kits. (Part B)

Piping between outdoor unit and Outdoor unit multi connection piping kit. (Part C)

- Choose from the following table in accordance with the total capacity type of all the outdoor units connected above Outdoor unit multi connection piping kit.

(Unit:mm)

Outdoor unit capacity type	Piping size (O.D.)	
	Gas pipe	Liquid pipe
5HP type	φ15.9	φ9.5
8HP type	φ19.1	
10HP type	φ22.2	
12~16HP type	φ28.6	φ12.7
18~22HP type		φ15.9
24HP type	φ34.9	φ19.1
26~34HP type		
36~54HP type	φ41.3	

(See 7.7 Note 1)

Temper grade and wall thickness for pipes.

(Temper grade, O type and 1/2H type indicate the material types specified in JIS H 3300.)

(Unit:mm)

Temper grade	O Type				1/2H Type							
Copper tube O.D	φ6.4	φ9.5	φ12.7	φ15.9	φ19.1	φ22.2	φ25.4	φ28.6	φ31.8	φ34.9	φ38.1	φ41.3
Copper tube W.T (Minimum requirement)	0.80	0.80	0.80	0.99	0.80	0.80	0.88	0.99	1.10	1.21	1.32	1.43

Piping between refrigerant branch kits

- Choose from the following table in accordance with the total capacity index of all the indoor units connected below this.
- Do not let the connection piping exceed the main refrigerant piping size.

(Unit:mm)

Indoor unit total capacity index	Piping size (O.D.)	
	Gas pipe	Liquid pipe
< 150	φ15.9	φ9.5
150 ≤ x < 200	φ19.1	
200 ≤ x < 290	φ22.2	
290 ≤ x < 420	φ28.6	φ12.7
420 ≤ x < 640		φ15.9
640 ≤ x < 920	φ34.9	φ19.1
920 ≤	φ41.3	

Piping between refrigerant branch kit and indoor unit

- Match to the size of the connection piping on the indoor unit.

(Unit:mm)

Indoor unit capacity type	Piping size (O.D.)	
	Gas pipe	Liquid pipe
20 · 25 · 32 · 40 · 50 type	φ12.7	φ6.4
63 · 80 · 100 · 125 type	φ15.9	φ9.5
200 type	φ19.1	
250 type	φ22.2	

7.6 How to Calculate the Additional Refrigerant to be Charged

7.6.1 Heat Pump 50Hz/60Hz, Cooling Only 50Hz (RX(Y)Q5~54P, 50PH)


Additional refrigerant to be charged R (Kg)
 R should be rounded off in units of 0.1Kg.

i Note: If a negative result is gotten for R from the formula below, no refrigerant needs to be added.

$$R = \left(\begin{array}{l} \text{Total length (m)} \\ \text{of liquid piping} \\ \text{size at } \phi 22.2 \end{array} \right) \times 0.37 + \left(\begin{array}{l} \text{Total length (m)} \\ \text{of liquid piping} \\ \text{size at } \phi 19.1 \end{array} \right) \times 0.26 + \left(\begin{array}{l} \text{Total length (m)} \\ \text{of liquid piping} \\ \text{size at } \phi 15.9 \end{array} \right) \times 0.18 + \left(\begin{array}{l} \text{Total length (m)} \\ \text{of liquid piping} \\ \text{size at } \phi 12.7 \end{array} \right) \times 0.12$$

$$+ \left(\begin{array}{l} \text{Total length (m)} \\ \text{of liquid piping} \\ \text{size at } \phi 9.5 \end{array} \right) \times 0.059 + \left(\begin{array}{l} \text{Total length (m)} \\ \text{of liquid piping} \\ \text{size at } \phi 6.4 \end{array} \right) \times 0.022$$

*Example for refrigerant branch using refnet joint and refnet header for RX(Y)Q34P



If the outdoor unit is RX(Y)Q34 type and the piping lengths are as at right

a: $\phi 19.1 \times 30\text{m}$	d: $\phi 9.5 \times 10\text{m}$	g: $\phi 6.4 \times 10\text{m}$	j: $\phi 6.4 \times 10\text{m}$
b: $\phi 15.9 \times 10\text{m}$	e: $\phi 9.5 \times 10\text{m}$	h: $\phi 6.4 \times 20\text{m}$	k: $\phi 6.4 \times 9\text{m}$
c: $\phi 9.5 \times 10\text{m}$	f: $\phi 9.5 \times 10\text{m}$	i: $\phi 12.7 \times 10\text{m}$	

$$R = \underset{\uparrow a}{30 \times 0.26} + \underset{\uparrow b}{10 \times 0.18} + \underset{\uparrow j}{10 \times 0.12} + \underset{\uparrow c+d+e+f}{40 \times 0.059} + \underset{\uparrow g+h+j+k}{49 \times 0.022} = 14.238$$

\downarrow
14.2

i Note: The amount of refrigerant to be added to the unit should be written on the included "Added Refrigerant" plate and attached to the rear side of the front cover. (Refer page 145)


7.7 Size of Main Gas and Liquid Pipes and Allowable Length

7.7.1 Heat Pump 50Hz/60Hz, Cooling Only 50Hz (RX(Y)Q5~54P, 50PH)

*Note 1

When the equivalent pipe length between outdoor and indoor units is 90m or more, the size of main pipes (both gas-side and liquid-side) must be increased.

Depending on the length of the piping, the capacity may drop, but even in such case it is able to increase the size of main pipes.



■ Diameter of above case

Model	Gas	Liquid
RX(Y)Q5 Type	φ19.1	Not Increased
RX(Y)Q8 Type	φ22.2	φ12.7
RX(Y)Q10 Type	φ25.4*	φ12.7
RX(Y)Q12 Type	Not Increased	φ15.9
RX(Y)Q14 Type	Not Increased	φ15.9
RX(Y)Q16 Type	φ31.8*	φ15.9
RX(Y)Q18 Type	φ31.8*	φ19.1

Model	Gas	Liquid
RX(Y)Q34 Type	φ38.1*	φ22.2
RX(Y)Q36 Type	Not Increased	φ22.2
RX(Y)Q38 Type	Not Increased	φ22.2
RX(Y)Q40 Type	Not Increased	φ22.2
RX(Y)Q42 Type	Not Increased	φ22.2
RX(Y)Q44 Type	Not Increased	φ22.2
RX(Y)Q46 Type	Not Increased	φ22.2


Model	Gas	Liquid
RX(Y)Q20 Type	φ31.8*	φ19.1
RX(Y)Q22 Type	φ31.8*	φ19.1
RX(Y)Q24 Type	Not Increased	φ19.1
RX(Y)Q26 Type	φ38.1*	φ22.2
RX(Y)Q28 Type	φ38.1*	φ22.2
RX(Y)Q30 Type	φ38.1*	φ22.2
RX(Y)Q32 Type	φ38.1*	φ22.2

Model	Gas	Liquid
RX(Y)Q48 Type	Not Increased	φ22.2
RX(Y)Q50 Type	Not Increased	φ22.2
RX(Y)Q52 Type	Not Increased	φ22.2
RX(Y)Q54 Type	Not Increased	φ22.2

*If available on the site, use this size. Otherwise, it can not be increased.

***Note 2**

Allowable length after the first refrigerant branch kit to indoor units is 40 m or less, however it can be extended up to **90 m** if all the following conditions are satisfied. (In case of “**Branch with REFNET joint**”)

Required Conditions	Example Drawings	
1. It is necessary to increase the pipe size between the first branch kit and the final branch kit. (Reducers must be procured on site) However, the pipes that are same pipe size with main pipe must not be increased.	$\boxed{8} b + c + d + e + f + g + p \leq 90 \text{ m}$ increase the pipe size of b, c, d, e, f, g Increase the pipe size as follows $\phi 9.5 \rightarrow \phi 12.7 \quad \phi 15.9 \rightarrow \phi 19.1 \quad \phi 22.2 \rightarrow \phi 25.4^* \quad \phi 34.9 \rightarrow \phi 38.1^*$ $\phi 12.7 \rightarrow \phi 15.9 \quad \phi 19.1 \rightarrow \phi 22.2 \quad \phi 28.6 \rightarrow \phi 31.8^*$	
2. For calculation of Total extension length, the actual length of above pipes must be doubled. (except main pipe and the pipes that are not increased)		
3. Indoor unit to the nearest branch kit $\leq 40 \text{ m}$		$h, i, j, \dots, p \leq 40 \text{ m}$
4. The difference between [Outdoor unit to the farthest indoor unit] and [Outdoor unit to the nearest indoor unit] $\leq 40 \text{ m}$		The farthest indoor unit $\boxed{8}$ The nearest indoor unit $\boxed{1}$ $(a + b + c + d + e + f + g + p) - (a + h) \leq 40 \text{ m}$

*If available on the site, use this size. Otherwise it can not be increased.

***Note 3**

If the pipe size above the REFNET header is $\phi 34.9$ or more, KHRP26M73HP is required.

7.8 Record of Field Setting and Additional Refrigerant Charge

Fill the following record and put it on the back side of electrical board.

Request for indication of setting contents, additional refrigerant charging amount and installation date

After filling out the below, please put it on the back side of an ex-board.

1. Record for setting contents for the setting contents of ㊦ ~ ㊨ in the [setting mode 2.] mark ○ in the right table.

㊦ Night - Time low noise setting	OFF • Level 1 • Level 2 • level 3
㊧ External low noise level setting	Level 1 • Level 2 • level 3
㊨ Demand level setting	Level 1 • Level 2 • level 3
㊩ External low noise demand setting	OFF • ON
㊪ High static pressure setting	OFF • ON

2. Record for additional refrigerant charging amount make sure to record the additional refrigerant charging amount. (If do not use automatic refrigerant charging, calculated and charge the additional refrigerant charging amount following as shown on the below.)

Additional charging amount kg	Refrigerant amount for field piping			
	Liquid pipe size (mm)	Refrigerant amount per 1m (kg/m)	Length of liquid pipe (m)	Total
(Round off to one decimal place.)	∅ 22.2	0.37	X	=
	∅ 19.1	0.26	X	=
	∅ 15.9	0.18	X	=
	∅ 12.7	0.12	X	=
	∅ 9.5	0.059	X	=
	∅ 6.4	0.022	X	=

3. Record of installation date

DA . MO . YR

3P176431

7.9 Outdoor Unit Multi Connection Piping Kit

7.9.1 BHFP22P100 · 151

Component parts ■ This kit contains the following parts. <Do not throw away any of the accessories until installation is complete>

Kit name	Shape					insulating tube for gas pipe	insulating tube for liquid pipe
	Gas-side joint	Liquid-side joint	Gas-side reducer		Liquid-side reducer		
BHFP 22 P100			(1)	(2)	(1)	Big 1 pc	Small 1 pc
			(3)	(7)	(3)		
BHFP 22 P151	(1)	(1)	(1)	(2)	(1)	Big 2 pc	Small 2 pc
	(2)	(2)	(3)	(4)	(2)		
			(5)	(6)	(3)		
			(8)	(9)	(4)		
			(10)		(5)		

Caution • Please be sure to read this manual before installation and follow the instruction carefully when performing installation work.
 • See the outdoor unit's installation manual for outdoor unit installation.
 • Installation of interconnecting piping between the outdoor units, REFNET joint or REFNET header will be needed separately

Selection Procedure

Number of outdoor units connected	2 units	3 units
Outdoor unit Multi Connection Piping Kit	BHFP22P100	BHFP22P151

- 2 or 3 outdoor units can be connected.
- There are restrictions on the combination and the installation order of outdoor units, so please refer to "the Engineering Data of VRV III" and "the installation manual" (attached sheet of outdoor unit) for details.

Field supply parts

■ The following parts are needed to connect this kit and are not included

Field supply parts		Selection Procedure
Name	Q'ty	
Insulation for piping	1set	See the "Connecting Pipe Sizes and location of cutting the joint" for details on the necessary size.
Connection piping		
Elbow	1pc	Prepare a gas pipe diameter for the upper outdoor unit as listed in "Connecting Pipe Size and location of cutting the joint."
Tape	1set	For insulation materials

Caution

- Quantity and selection procedure of elbow only applies to a front or bottom connection.
- For a lower front connection the quantity and selection procedure are different, so please refer to the instructions for a lower front connection.
- A joint for the same diameter pipes is needed only for a bottom connection. See the instructions for the bottom connection, for details on quantity and specifications.
- The min. thickness of the pipes in this manual shows the requirements of Japanese High Pressure Gas Control law. (As of Jan. 2003)
- And the temper grade (O,1/2H) shows the material type of JIS h 3300. The tickness and material shall be selected in accordance with local for the design pressure 4.0MPa (40bar).


(Unit : mm)

Temper grade	O Type					1/2H Type						
Copper tube O.D.	Ø 6.4	Ø 9.5	Ø 12.7	Ø 15.9	Ø 19.1	Ø 22.2	Ø 25.4	Ø 28.6	Ø 31.8	Ø 34.9	Ø 38.1	Ø 41.3
Copper tube W.T. (Minimum requirement)	Ø 0.80	Ø 0.80	Ø 0.80	Ø 0.99	Ø 0.80	Ø 0.80	Ø 0.88	Ø 0.99	Ø 1.10	Ø 1.21	Ø 1.31	Ø 1.43

⚠ To the piping installer When installing this kit, please apply the following restrictions




Restrictions on Installing Multi Connection Piping Kit

- Install the joint horizontally so that the caution label attached to joint comes to the top. Do not tilt the joint more than $\pm 15^\circ$. (See Fig. 1). In addition, do not install the joint vertically. (See Fig. 2)
- Make sure the piping up to the joint is straight for more than 500mm. Do not bend the field piping within this range. If a straight field piping more than 120mm is connected, more than 500mm of straight section can be ensured. (See Fig. 3)
- Improper installation may lead to malfunction of the outdoor unit.



Installation examples

- The figure at the lower shows a typical front connection. Make sure to follow the installation restrictions and carry out installation taking the field requirements into consideration.
- This manual explains the front connection <Ex. of construction 1>.
- For 3-unit installation on Ex. of construction 5 and 6, in some cases the reducers (5), (6) or (10) for gas piping and the reducers (2) and (3) for liquid piping may be used on the 1st joint (section shown with ←). See the figure at the right for details of connection.
- When the size of the Gas-side pipe between the Gas-side joint (1) and Gas-side joint (2) on the 3-units system or the size of the main pipe is $\varnothing 41.3$ or $\varnothing 34.9$. Gas-side reducer (7), (8) and (9) will be used. See the figure at the right for details of connection.
- When the size of the Liquid-side pipe between the Liquid-side joint (1) and Liquid-side joint (2) on the 3-units system is $\varnothing 12.7$. Liquid-side reducer (3) will be used. And when the side of main pipe is $\varnothing 15.9$. Liquid-side reducer (4) will be used. See the figure at the right for details of connection.



BHFP22P100 Installation Instructions

Caution There are some restrictions on the interconnecting piping between the outdoor units. See the installation attached to the outdoor units and make sure to carry out proper piping. If the piping restrictions are not observed, it may result in malfunction of the unit.

Connecting pipe sizes and location of cutting the joint

Select cutting point of a joint or a reducer which is suitable for the size of the interconnecting pipes determined according to the table below and cut it with a pipe cutter. (units: mm)

Outdoor unit capacity type	Pipe size (O.D. x min. thickness [temper grade])	
	Gas pipe	Liquid pipe
8HP	φ19,1×0,80[1/2H]	φ9,5×0,80[0]
10HP	φ22,2×0,80[1/2H]	
12~16HP	φ28,6×0,99[1/2H]	φ12,7×0,80[0]
18HP		φ15,9×0,99[0]

Outdoor Unit Multi Connection Piping Kit
Follow "Restrictions on installing Multi Connection Piping Kit"


• Select the pipe size according to the total capacity of outdoor unit.

Outdoor unit total capacity type	Pipe size (O.D. x min. thickness [temper grade])	
	Gas pipe	Liquid pipe
16HP	φ28,6×0,99[1/2H]	φ12,7×0,80[0]
18~22HP		φ15,9×0,99[0]
24HP	φ34,9×1,21[1/2H]	φ19,1×0,80[1/2H]
26~34HP		
36HP	φ41,3×1,43[1/2H]	

- When upsizing the main pipe, use the gas side reducer (2)
- If the pipe size of φ19.1 or larger is used, the O material may be insufficient to withstand the specified pressure. Therefore, make sure to use the 1/2H material with thickness of 1.0mm or more. When using the O material for the pipe size of φ19.1, a thickness of 1.2 or more is required. In this case, the connection must be brazed.


Cutting procedure

• Use pipe cutter for cutting




1 Installation examples Procedure for Front Connection

1-1 Exterior view



1-2 Finished dimensions

• For installations where the A dimensions exceed 290mm, extend the field supply interconnecting pipe between the joint and the outdoor unit.



2 Connection of gas and liquid pipes

2-1 Cutting the field supply gas pipes

- Cut the pipes according to Table 1.

Caution • This table shows the case when the A dimensions shown in 1-2 Finished dimensions is 290 mm. If the A dimensions exceed 290 mm, see Table 1 and adjust the dimensions of the gas pipe 1 and 2.
 • The L dimensions of the gas pipe 2 in Table 1 show those when the field supply elbows have B dimension in Table 2. If the B dimension is not same with Table 2, see Table 1 and 2, and adjust them accordingly.

Table 1






Model type	Gas pipe 1 (field supply)		Gas pipe 2 (field supply)	
	L (mm)		L (mm)	
8HP	75		287	
10HP	81		257	
12~18HP	125		223	

Table 2

Model type	Elbow (field supply)	
	B (mm)	
8HP	17	
10HP	23	
12~18HP	29	

2-2 Connection of pipes

- Connect the gas and liquid pipes as shown in the figure at the right. (When connecting the pipes, first connect the gas-side joint and the gas-side reducer (1), the liquid-side joint and the gas-side reducer (1))
- See 1-2 Finished dimensions for the location (height) of the joint.
- See the caution section in the installation manual attached to the outdoor unit for brazing pipes and connecting pipes with flare nuts.
- Install the joint in such a way that the attached face of the caution label becomes horizontal (See the View A)



③ The work after the kit is connected

Connection of piping between the outdoor unit and the indoor unit


Air tight test

} Follow the instructions in the installation manual included with the outdoor unit, when performing installation work.

Insulation of joints


- (1) Fit the insulation to the reducer and temporarily keep it in place with tape.
- (2) Fit the insulation to the joint and temporarily keep it in place with tape without leaving a gap between the insulation mating faces. (See the figure at the right.)
- (3) Seal the seam between the insulation and the field supply piping insulation with the field supply tape.
- (4) Wrap the tape around the insulation attached to the joint without leaving a gap.

(// section shown in the figure at the right)




1 Installation examples Prodecure for Lower Front Connection

1-1 Exterior view



1-2 Finished dimensions

- A standard installation has the following dimensions
- When the dimensions exceed the standard installation, extend the pipes between the outdoor unit and the joint (field supply)



2 Connection of gas and liquid pipes

2-1 Cutting the field supply gas pipe 1 to 4



- Cut the pipes according to Table 3
- CAUTION** • The L dimension of the gas pipe 1 to 4 in Table 3 show those when the field supply elbows have B dimension in Table 2 shown in Procedure for Front Connection, 2 Connection of gas and liquid pipes.
If the B dimensions are not same with Table 2, see Table 2 and 3, and adjust them accordingly.

Table 3

Model type	Gas pipe 1 (field supply)		Gas pipe 2 (field supply)		Gas pipe 3 (field supply)		Gas pipe 4 (field supply)	
	L(mm)		L(mm)		L(mm)		L(mm)	
8HP	130		165		59		237	
10HP	100		135		83		225	
12-18 HP	66		101		149		213	

2-2 Connection of pipes

- Connect the gas and liquid pipes as shown in the figure at the right.
(When connecting the pipes, first connect the gas-side joint and the gas-side reducer(1), the liquid-side joint and the liquid-side reducer (1))
- See the caution section in the installation manual attached to the outdoor unit for brazing pipes and connecting pipes with flare nuts.
- Install the joint in such a way that the attached face of the caution label becomes horizontal (See the View A).



3 The work after the kit is connected


Connection of piping between the outdoor unit and the indoor unit

Follow the instructions in the installation manual included with the outdoor unit, when performing installation work.

Air tight test

Insulation of joints


- (1) Fit the insulation to the reducer and temporarily keep it in place with tape.
- (2) Cut insulating tube along the slit.
Fit the insulation to the joint and temporarily keep it in place with tape without leaving a gap between the insulation mating faces.
- (3) Seal the seam between the insulation and the field supply piping insulation with the field supply tape.
- (4) Wrap the tape around the insulation attached to the joint without leaving a gap.
(Hatched section shown in the figure at the right.)



1 Installation examples Procedure for Bottom Connection

CAUTION This installation is only possible if there is enough space to perform brazing and racking underneath the outdoor unit. If a centralized drain pan kit and/or vibration proof base are used, the dimensions marked with "*" in the figure below will vary, so see the table below and determine the length of the field pipes

1-1 Exterior view



2 Connection of gas and liquid pipes

2-1 Cutting the field supply gas pipe 1 and 2 and the Gas-side accessory pipe (3) attached to the outdoor unit

• Cut the pipes according to Table 4 or 5.
CAUTION • The "L" dimension of the gas pipe 1 in Table 4 and the gas pipe 2 in Table 5 are identical to the "B" dimensions in table 2, those of "field supply elbows" shown in the procedure of front connection, which are equivalent to "straight size joint" without stopper. If the "B" dimensions are not identical to table 2 or "straight size joint" is with stopper, adjust them as table 2, 4 and 5 show

■ Table 4 (For Outdoor unit A Side)

Model type	Gas-side accessory pipe (3)			cutting position M	Gas-pipe 1 (field supply)			
	B (mm)				L (mm)			
	* dimensions				* dimensions			
	For 100	For 139	For 233		For 100	For 139	For 233	
8HP	102	63	48		unnecessary	79		
10HP	72	33	25					86
12HP ~ 18HP	0 (no cutting)	53	0 (no cutting)					92


■ Table 5 (For outdoor unit B Side)

Model type	Gas-side accessory pipe (3)			cutting position M	Gas-pipe 2 (field supply)		
	B (mm)				L (mm)		
	dimensions				* dimensions		
	For 100	For 139	For 233		For 100	For 139	For 233
8HP	0 (no cutting)	0 (no cutting)	0 (no cutting)		76	115	209
10HP	18	0 (no cutting)	0 (no cutting)		88	109	203
12HP ~ 18HP	32	0 (no cutting)	0 (no cutting)		96	103	197

2-2 Connection of pipes

- Remove the knockout plate on the bottom frame. (See the installation manual attached to the outdoor unit)
- Connect the gas and liquid pipe as shown in the figure below. (When connecting the pipes, first connect the gas-side joint and the gas-side reducer (1), the liquid-side joint and the liquid-side reducer (1)).
- See the caution section in the installation manual attached to the outdoor unit for brazing pipes and connecting pipes with flare nuts.
- Install the joint in such a way that the attached face of the caution label becomes horizontal. (See the view A)
- Connect the liquid side reducer (1) tilting approx. 10° and bend the field supplied liquid pipe up to the stop valve as shown in the figure below. (See the view A)

CAUTION • If the liquid side reducer is connected vertically without bending the liquid pipes, the insulation will not fit.



3 The work after the kit is connected


Connection of piping between the outdoor unit and the indoor unit

Follow the instructions in the installation manual included with the outdoor unit, when performing installation work.

Air tight test

Insulation of joints

- (1) Fit the insulation to the reducer and temporarily keep it in place with tape.
- (2) Cut insulating tube along the slit. (See the figure at the right.)
Fit the insulation to the joint and temporarily keep it in place with tape without leaving a gap between the insulation mating faces.
- (3) Seal the seam between the insulation and the field supply piping insulation with the field supply tape.
- (4) Wrap the tape around the insulation attached to the joint without leaving a gap.
(Hatched section shown in the figure at the right.)



BHFP22P151 Installation Instructions

CAUTION There are some restrictions on the interconnecting piping between the outdoor units. See the installation manual attached to the outdoor units and make sure to carry out proper piping. If the piping restrictions are not observed, it may result in malfunction of the unit.

Connecting Pipe Sizes and location of cutting the joint

Select cutting point of a joint or a reducer which is suitable for the size of the interconnecting pipes determined according to the table below and cut it with a pipe cutter.

Pipe between outdoor unit Multi Connection Piping Kit
Select the pipe size according to the total capacity of the outdoor unit (unit B, C).

Main pipe
Select the pipe size according to the total capacity of the outdoor unit to be connected upstream (unit A, B, C)


Outdoor unit capacity type	Pipe size (O.D. x min. thickness [temper grade]) (units:mm)	
	Gas pipe	Liquid pipe
8HP	Ø19.1x0.80[1/2H]	Ø 9.5x0.80[0]
10 HP	Ø22.2x0.80[1/2H]	Ø12.7x0.80[0]
12-16HP	Ø28.6x0.99[1/2H]	Ø15.9x0.99[0]
18HP	Ø41.3x1.43[1/2H]	Ø19.1x0.80[1/2H]

Outdoor Unit Multi Connecting Piping Kit
Follow "Restrictions on Installing Multi Connection Piping Kit"

Outdoor unit total capacity (unit A, B,C) or the total capacity of the outdoor unit to be connected upstream (unit B, C)	Pipe size (O.D. x min. thickness [temper grade]) (units:mm)	
	Gas pipe	Liquid pipe
16HP	Ø19.1x0.80[1/2H]	Ø 12.7x0.80[0]
18-22HP	Ø28.6x0.99[1/2H]	Ø15.9x0.99[0]
24HP	Ø34.9x1.21[1/2H]	Ø19.1x0.80[1/2H]
26-34HP	Ø41.3x1.43[1/2H]	Ø19.1x0.80[1/2H]
36HP	Ø41.3x1.43[1/2H]	Ø19.1x0.80[1/2H]


Cutting procedure

- Use pipe cutter for cutting




1 Installation examples Procedure for Front Connection

1-1 Exterior view



1-2 Finished dimensions

- For installations where the A dimensions exceed 284 mm, extend the field supply interconnecting pipe between the joint and the outdoor unit.



2 Connection of gas and liquid pipes

2-1 Cutting the field supply gas pipes



- Cut the pipes according to Table 6.
- **CAUTION** This table shows the case when the A dimensions shown in "1-2 Finished dimensions" is 284mm. If the A dimensions exceed 284mm, see Table 6 and adjust the dimensions of the gas pipe 1 and 2 and 3.
- The L dimensions of the gas pipe 3 in Table 6 show those when the field supply elbows have B dimension in Table 2 shown in BHFP22P151 Installation instruction, 2 connection of gas and liquid pipes. If the B dimensions are not the same with Table 2, see Table 2 and 6, and adjust them accordingly

Table 6

Model type	Gas pipe 1 (field supply)		Gas pipe 2 (field supply)		Gas pipe 3 (field supply)	
	L(mm)		L(mm)		L(mm)	
8HP	51		69		282	
10HP	57		75		252	
12-18 HP	101		119		218	

2-2 Connection of pipes

- Connect the gas and liquid pipes as shown in the figure at the right.
- When connecting the pipes, first connect the gas-side joint and the gas-side reducer(1), the liquid-side joint and the liquid-side reducer (1)
- See "1-2 Finished dimensions" for the location (height) of the joint.
- See the caution section in the installation manual attached to the outdoor unit for brazing pipes and connecting pipes with flare nuts.
- Install the joint in such a way that the attached face of the caution label becomes horizontal (See the View A).



3 The work after the kit is connected

Connection of piping between the outdoor unit and the indoor unit

Follow the instructions in the installation manual included with the outdoor unit, when performing installation work.


Air tight test

Insulation of joints

- See "The work after the kit is connected" for a front connection in "BHFP22P151 Installation Instructions."


1 Installation examples Procedure for Front Connection

1-1 Exterior view



1-2 Finished dimensions

- A standard installation has the following dimensions.
- When the dimensions exceed the standard installation, extend the pipes between the outdoor unit and the joint. (field supply)



2 Connection of gas and liquid pipes

2-1 Cutting the field supply gas pipes

- Cut the pipes according to Table 7.

CAUTION • The L dimensions of the gas pipe 1 to 5 in Table 7 show those when the field supply elbows have B dimension in Table 2 shown in BHFP22P100 Installation instruction, 2 connection of gas and liquid pipes and the field supply joint for the same diameter pipes are without stopper. If the B dimensions are not the same with Table 2 or the joint for the same diameter pipes have stopper, see Table 2 and 7, and adjust them accordingly.



Table 7

Model type	Gas pipe 1 (field supply)		Gas pipe 2 (field supply)		Gas pipe 3 (field supply)	
	L (mm)		L (mm)		L (mm)	
8HP	130		147		182	
10HP	100		117		152	
12-18 HP	66		83		118	

Model type	Gas pipe 4 (field supply)		Gas pipe 5 (field supply)	
	L (mm)		L (mm)	
8HP	59		237	
10HP	83		225	
12-18 HP	149		213	

2-2 Connection of pipes

- Connect the gas and liquid pipes as shown in the figure at the left.
(When connecting the pipes, first connect the gas-side joint and the gas-side reducer (1), the liquid-side joint and the liquid-side reducer (1).)
- See the caution section in the installation manual attached to the outdoor unit for brazing pipes and connecting pipes with flare nuts.
- Install the joint in such a way that the attached face of the caution label becomes horizontal (See the View A).



③ The work after the kit is connected

Connection of piping between the outdoor unit and the indoor unit

Air tight test

Insulation of joints


} Follow the instructions in the installation manual included with the outdoor unit, when performing installation work.

- See “The work after the kit is connected” for a lower front connection in “BHFP22P100 Installation Instructions.”


1 Installation examples Procedure for Bottom Connection

CAUTION This installation is only possible if there is enough space to perform brazing and racking underneath the outdoor unit. If a centralized drain pan kit and/or vibration proof base are used, the dimensions marked with "*" in the figure below will vary, so see the table below and determine the length of the field pipes.

1-1 Exterior view



Separately-sold item also used	*dimensions
Central drain pan kit	139
Vibration absorption stand	233
Vibration absorption stand + central drain pan kit	



2 Connection of gas and liquid pipes

2-1 Cutting the field supply gas pipe 1 and 2 and the Gas-side accessory pipe (3) attached to the outdoor unit

• Cut the pipes according to Table 8 or 9.

CAUTION • The "L" dimension of the gas pipe 1 in Table 8 and the gas pipe 2 in Table 9 are identical to the "B" dimensions in table 2, those of "field supply elbows" shown in the procedure of front connection, which are equivalent to "straight size joint" without stopper. If the "B" dimensions are not identical to table 2 or "straight size joint" is with stopper, adjust them as table 2, 8 and 9 show.

■ Table 8 (For outdoor unit A, B Side)

Model type	Gas-side accessory pipe (3)			cutting position	Gas-pipe 1 (field supply)		
	B (mm)				L (mm)		
	* dimensions				* dimensions		
	For 100	For 139	For 233		For 100	For 139	For 233
8HP	102	63	48			79	
10HP	72	33	25			86	
12HP ~ 18HP	0 (no cutting)	53	0 (no cutting)			92	133


■ Table 9 (For outdoor unit C Side)

Model type	Gas-side accessory pipe (3)			cutting position	Gas-pipe 2 (field supply)		
	B (mm)				L (mm)		
	* dimensions				* dimensions		
	For 100	For 139	For 233		For 100	For 139	For 233
8HP	0 (no cutting)	0 (no cutting)	0 (no cutting)		76	115	209
10HP	18	0 (no cutting)	0 (no cutting)		88	109	203
12HP ~ 18HP	32	0 (no cutting)	0 (no cutting)		96	103	197

2-2 Connection of pipes

- Remove the knockout plate on the bottom frame. (See the installation manual attached to the outdoor unit)
- Connect the gas and liquid pipe as shown in the figure below. (When connecting the pipes, first connect the gas-side joint and the gas-side reducer (1), the liquid-side joint and the liquid-side reducer (1)).
- See the caution section in the installation manual attached to the outdoor unit for brazing pipes and connecting pipes with flare nuts.
- Install the joint in such a way that the attached face of the caution label becomes horizontal. (See the view A)
- Connect the liquid side reducer (1) tilting approx. 10° and bend the field supplied liquid pipe up to the stop valve as shown in the figure below. (See the view A)

CAUTION • If the liquid side reducer is connected vertically without bending the liquid pipes, the insulation will not fit.



3 The work after the kit is connected

Connection of piping between the outdoor unit and the indoor unit

Air tight test

Insulation of joints

Follow the instructions in the installation manual included with the outdoor unit, when performing installation work.



• See "The work after the kit is connected" for a front connection in "BHFP22P100 Installation Instructions."

7.10 REFNET Joint and Header


7.10.1 REFNET Joint (Branch Kit)

KHRP26A22T

Gas Side





Liquid Side




C : D3K05234A

KHRP26A33T

Gas Side





Liquid Side





C : D3K05235B

KHRP26A72T

Gas Side





Liquid Side





C : D3K05236A

KHRP26A73T

Gas Side





Liquid Side



C : D3K05237A



7.10.2 REFNET Header (Branch Kit)

KHRP26M22H





D3K03629C

KHRP26M33H





D3K03630C

KHRP26M72H



D3K03631C

KHRP26M73H



D3K03632C

7.10.3 Reducer

7.10.4.1 Pipe size reducer (For R-410A)

KHRP26M73TP • 73HP

KHRP25M72TP • 73TP • 72HP

- This includes the following parts.

	pipe size reducer ①	pipe size reducer ②	pipe size reducer ③	pipe size reducer ④	pipe size reducer ⑤	
SHAPE						
Quantity	KHRP26M73TP	1pc.	1pc.	2pc.	—	
	KHRP26M73HP	1pc.	—	1pc.	—	
	KHRP25M72TP	—	—	—	1pc.	1pc.
	KHRP25M72HP	—	—	—	—	1pc.
	KHRP25M73TP	1pc.	1pc.	3pc.	1pc.	—

- This kit is the reducer of the branch piping kit (refnet joint • header).
Check the proper model of the branch piping kit.

Kit name	Branch piping kit
KHRP26M73TP	KHRP26M73T (gas side)
KHRP26M73HP	KHRP26M73H (gas side) • KHRP25M73H (suction gas side)
KHRP25M72TP	KHRP25M72T (discharge gas side)
KHRP25M72HP	KHRP25M72T (discharge gas side)
KHRP25M73TP	KHRP25M73T (suction, discharge side)


Installation procedure

Refer to the installation manual of the branch piping kit.

- Joint size are as follows

<p>pipe size reducer ①</p>	<p>pipe size reducer ②</p>	<p>pipe size reducer ③</p>
<p>pipe size reducer ④</p>	<p>pipe size reducer ⑤</p>	

- (1) Select the field piping size according to the installation manual of the outdoor unit.
- (2) Connect the PIPE SIZE REDUCER suitable for the field piping size to the branch piping kit.
ex.) Connect the reducers to the branch piping kit. KHRP26M73T.
• For inlet piping size is Ø 41.3 and outlet 1 piping size is Ø 34.9




3P113129A


7.10.4 REFNET Joints and Headers

7.10.4.1 REFNET Joints


For gas and liquid branch pipes




- Make sure that all branch pipes are fitted such that they branch either horizontally or vertically.




- When the size of the selected field piping is different from that of branch pipe then the connecting section should be cut with a pipe cutter as shown in the figure below.




- When you are cutting an inlet or outlet pipe with a pipe cutter make sure that you make the cut in the center of the connection area.




- Branch pipes must be insulated in accordance with the handbook which comes with each kit.




7.10.4.2 REFNET Header




- When the number of indoor units to be connected to the branch pipes is less than the number of branch pipes available for connection then cap pipes should be fitted to the surplus branches.




- When the size of the selected field piping is different from that of branch pipe then the connecting section should be cut with a pipe cutter as shown in the figure below.



- When field piping is connected to the B section of the inlet/outlet pipe on the outdoor unit side of the liquid pipe header.
- Cut the B section with a pipe cutter as shown below and connect it to the A section.
- Connect the flared section of the field pipe to the B section.




- Fit the branch pipe so that the branch lies in a horizontal plane.




- The branch pipe must be insulated in accordance with the instruction manual which comes with each kit.


1. Use the insulator included in the kit to insulate the header.



2. Joints between insulators included in the kit and those already applied to the field piping should be sealed with the tape which is also included in each kit.



3. Any cap pipes should also be insulated using the insulator provided with each kit and then taped as described above.



7.11 VRV Inspection Sheet

Inspection date: _____

Delivery date: _____

Transfer date: _____

Owner		System name	
-------	--	-------------	--

Outdoor units

	Installation location	Model	Unit No.
Outdoor unit system name			
Outdoor unit 1			
Outdoor unit 2			
Outdoor unit 3			

Indoor units

No.	Installation location	Model	Unit No.	Group No.	No.	Installation location	Model	Unit No.	Group No.
1					21				
2					22				
3					23				
4					24				
5					25				
6					26				
7					27				
8					28				
9					29				
10					30				
11					31				
12					32				
13					33				
14					34				
15					35				
16					36				
17					37				
18					38				
19					39				
20					40				

Field settings

C/H SELECT (setting mode 1)			C/H SELECT setting (DS1-1)			Low noise operation			Sequential start	
IND	MASTER	SLAVE	ON	OFF		ON	OFF		ON	OFF
Tc			Te			Defrost SETTING			Refrigerant addition/replenishment	
H	M	L	H	M	L	H	M	L	kg	

Company name _____

Inspector _____

(V1091)

Before turning on the power

System name _____

	Inspection item	Inspection method	Standard (guideline)	Measurement values				Decision			
	Breaker capacity	Visual inspection	Specified capacity	G	NG						
Outdoor unit 1	Refrigerant piping system	Gas detector	No leaks	G	NG						
	Heat exchanger	Visual inspection	No clogging or damage	G	NG						
	Terminal connection section	Screwdriver, etc.	No looseness	G	NG						
	Fan motor electrical insulation	500-V megatester	1 MΩ or more				MΩ				
	Compressor electrical insulation	500-V megatester	1 MΩ or more	INV	MΩ	STD1	MΩ	STD2	MΩ		
	Installation	Visual inspection	Short circuit, etc.	G	NG						
Outdoor unit 2	Refrigerant piping system	Gas detector	No leaks	G	NG						
	Heat exchanger	Visual inspection	No clogging or damage	G	NG						
	Terminal connection section	Screwdriver, etc.	No looseness	G	NG						
	Fan motor electrical insulation	500-V megatester	1 MΩ or more				MΩ				
	Compressor electrical insulation	500-V megatester	1 MΩ or more								
	Installation	Visual inspection	Short circuit, etc.	G	NG						
Outdoor unit 3	Refrigerant piping system	Gas detector	No leaks	G	NG						
	Heat exchanger	Visual inspection	No clogging or damage	G	NG						
	Terminal connection section	Screwdriver, etc.	No looseness	G	NG						
	Fan motor electrical insulation	500-V megatester	1 MΩ or more				MΩ				
	Compressor electrical insulation	500-V megatester	1 MΩ or more								
	Installation	Visual inspection	Short circuit, etc.	G	NG						
Indoor unit	Refrigerant system	Gas detector	No leaks	Room 1	G NG	Room 2	G NG	Room 3	G NG	Room 4	G NG
				Room 5	G NG	Room 6	G NG	Room 7	G NG	Room 8	G NG
				Room 9	G NG	Room 10	G NG	Room 11	G NG	Room 12	G NG
				Room 13	G NG	Room 14	G NG	Room 15	G NG	Room 16	G NG
				Room 17	G NG	Room 18	G NG	Room 19	G NG	Room 20	G NG
				Room 21	G NG	Room 22	G NG	Room 23	G NG	Room 24	G NG
				Room 25	G NG	Room 26	G NG	Room 27	G NG	Room 28	G NG
				Room 29	G NG	Room 30	G NG	Room 31	G NG	Room 32	G NG
				Room 33	G NG	Room 34	G NG	Room 35	G NG	Room 36	G NG
				Room 37	G NG	Room 38	G NG	Room 39	G NG	Room 40	G NG
	Air filter	Visual inspection	No clogging or damage	Room 1	G NG	Room 2	G NG	Room 3	G NG	Room 4	G NG
				Room 5	G NG	Room 6	G NG	Room 7	G NG	Room 8	G NG
				Room 9	G NG	Room 10	G NG	Room 11	G NG	Room 12	G NG
				Room 13	G NG	Room 14	G NG	Room 15	G NG	Room 16	G NG
				Room 17	G NG	Room 18	G NG	Room 19	G NG	Room 20	G NG
				Room 21	G NG	Room 22	G NG	Room 23	G NG	Room 24	G NG
				Room 25	G NG	Room 26	G NG	Room 27	G NG	Room 28	G NG
				Room 29	G NG	Room 30	G NG	Room 31	G NG	Room 32	G NG
				Room 33	G NG	Room 34	G NG	Room 35	G NG	Room 36	G NG
				Room 37	G NG	Room 38	G NG	Room 39	G NG	Room 40	G NG
	Heat exchanger	Visual inspection	No clogging or damage	Room 1	G NG	Room 2	G NG	Room 3	G NG	Room 4	G NG
				Room 5	G NG	Room 6	G NG	Room 7	G NG	Room 8	G NG
				Room 9	G NG	Room 10	G NG	Room 11	G NG	Room 12	G NG
				Room 13	G NG	Room 14	G NG	Room 15	G NG	Room 16	G NG
				Room 17	G NG	Room 18	G NG	Room 19	G NG	Room 20	G NG
				Room 21	G NG	Room 22	G NG	Room 23	G NG	Room 24	G NG
				Room 25	G NG	Room 26	G NG	Room 27	G NG	Room 28	G NG
				Room 29	G NG	Room 30	G NG	Room 31	G NG	Room 32	G NG
				Room 33	G NG	Room 34	G NG	Room 35	G NG	Room 36	G NG
				Room 37	G NG	Room 38	G NG	Room 39	G NG	Room 40	G NG

	Inspection item	Inspection method	Standard (guideline)	Measurement values				Decision
				Room 1 G NG	Room 2 G NG	Room 3 G NG	Room 4 G NG	
Indoor unit	Fan motor electrical insulation	500-V megatester	1 MΩ or more	Room 5 G NG	Room 6 G NG	Room 7 G NG	Room 8 G NG	
				Room 9 G NG	Room 10 G NG	Room 11 G NG	Room 12 G NG	
				Room 13 G NG	Room 14 G NG	Room 15 G NG	Room 16 G NG	
				Room 17 G NG	Room 18 G NG	Room 19 G NG	Room 20 G NG	
				Room 21 G NG	Room 22 G NG	Room 23 G NG	Room 24 G NG	
				Room 25 G NG	Room 26 G NG	Room 27 G NG	Room 28 G NG	
				Room 29 G NG	Room 30 G NG	Room 31 G NG	Room 32 G NG	
				Room 33 G NG	Room 34 G NG	Room 35 G NG	Room 36 G NG	
	Room 37 G NG	Room 38 G NG	Room 39 G NG	Room 40 G NG				
	Auxiliary heater electrical insulation	500-V megatester	1 MΩ or more	Room 1 G NG	Room 2 G NG	Room 3 G NG	Room 4 G NG	
				Room 5 G NG	Room 6 G NG	Room 7 G NG	Room 8 G NG	
				Room 9 G NG	Room 10 G NG	Room 11 G NG	Room 12 G NG	
				Room 13 G NG	Room 14 G NG	Room 15 G NG	Room 16 G NG	
				Room 17 G NG	Room 18 G NG	Room 19 G NG	Room 20 G NG	
				Room 21 G NG	Room 22 G NG	Room 23 G NG	Room 24 G NG	
				Room 25 G NG	Room 26 G NG	Room 27 G NG	Room 28 G NG	
				Room 29 G NG	Room 30 G NG	Room 31 G NG	Room 32 G NG	
	Room 33 G NG	Room 34 G NG	Room 35 G NG	Room 36 G NG				
	Room 37 G NG	Room 38 G NG	Room 39 G NG	Room 40 G NG				
	Installation	Visual inspection	Short circuit, etc.	Room 1 G NG	Room 2 G NG	Room 3 G NG	Room 4 G NG	
				Room 5 G NG	Room 6 G NG	Room 7 G NG	Room 8 G NG	
				Room 9 G NG	Room 10 G NG	Room 11 G NG	Room 12 G NG	
				Room 13 G NG	Room 14 G NG	Room 15 G NG	Room 16 G NG	
				Room 17 G NG	Room 18 G NG	Room 19 G NG	Room 20 G NG	
				Room 21 G NG	Room 22 G NG	Room 23 G NG	Room 24 G NG	
				Room 25 G NG	Room 26 G NG	Room 27 G NG	Room 28 G NG	
				Room 29 G NG	Room 30 G NG	Room 31 G NG	Room 32 G NG	
	Room 33 G NG	Room 34 G NG	Room 35 G NG	Room 36 G NG				
Room 37 G NG	Room 38 G NG	Room 39 G NG	Room 40 G NG					

(V1092)

During operation

System name _____

	Inspection item	Inspection method	Standard (guideline)	Measurement values				Decision		
Outdoor unit 1	Main power supply voltage	Tester	Rated voltage ±10%	R-S	V	S-T	V	R-T	V	
	Operation circuit voltage	Tester	Rated voltage ±10%					V		
	Fan rotation direction	Visual inspection	Forward rotation	G NG						
	Fan noise/vibration	Listening	No noise or vibration							
	Fan operation current	Clamp meter		RED WHITE BLACK A A A						
	Suction air temperature	Thermometer	Temperature differential 9~11deg. when cooling, 2~3.5deg. when heating					°C		
	Discharge air temperature	Thermometer						°C		
	Compressor discharge pressure	Pressure gauge						MPa		
	Compressor suction pressure	Pressure gauge						MPa		
	Compressor operating current	Clamp meter	Phase differential within 1A	INV	U()A,	V()A,	W()A			
				STD1	R()A,	S()A,	T()A			
				STD2	R()A,	S()A,	T()A			
	Compressor operating frequency	Clamp meter		INV					Hz	
Suction pipe temperature	Thermometer	3~15°C	INV	°C	STD1	°C	STD2	°C		
Discharge pipe temperature	Thermometer	85~105°C	INV	°C	STD1	°C	STD2	°C		
Clank case heater	Touch	Warm	INV	G-NG	STD1	G-NG	STD2	G-NG		
Outdoor unit 2	Main power supply voltage	Tester	Rated voltage ±10%	R-S	V	R-S	V	R-S	V	
	Operation circuit voltage	Tester	Rated voltage ±10%					V		
	Fan rotation direction	Visual inspection	Forward rotation	G NG						
	Fan noise/vibration	Listening	No noise or vibration							
	Fan operation current	Clamp meter		RED WHITE BLACK A A A						
	Suction air temperature	Thermometer	Temperature differential 9~11deg. when cooling, 2~3.5deg. when heating					°C		
	Discharge air temperature	Thermometer						°C		
	Compressor discharge pressure	Pressure gauge						MPa		
	Compressor suction pressure	Pressure gauge						MPa		
	Compressor operating current	Clamp meter	Phase differential within 1A	INV	U()A,	V()A,	W()A			
				STD1	R()A,	S()A,	T()A			
				STD2	R()A,	S()A,	T()A			
	Compressor operating frequency	Clamp meter		INV					Hz	
Suction pipe temperature	Thermometer	3~15°C	INV	°C	STD1	°C	STD2	°C		
Discharge pipe temperature	Thermometer	85~105°C	INV	°C	STD1	°C	STD2	°C		
Clank case heater	Touch	Warm	INV	G-NG	STD1	G-NG	STD2	G-NG		
Outdoor unit 3	Main power supply voltage	Tester	Rated voltage ±10%	R-S	V	R-S	V	R-S	V	
	Operation circuit voltage	Tester	Rated voltage ±10%					V		
	Fan rotation direction	Visual inspection	Forward rotation	G NG						
	Fan noise/vibration	Listening	No noise or vibration							
	Fan operation current	Clamp meter		RED WHITE BLACK A A A						
	Suction air temperature	Thermometer	Temperature differential 9~11deg. when cooling, 2~3.5deg. when heating					°C		
	Discharge air temperature	Thermometer						°C		
	Compressor discharge pressure	Pressure gauge						MPa		
	Compressor suction pressure	Pressure gauge						MPa		
	Compressor operating current	Clamp meter	Phase differential within 1A	INV	U()A,	V()A,	W()A			
				STD1	R()A,	S()A,	T()A			
				STD2	R()A,	S()A,	T()A			
	Compressor operating frequency	Clamp meter		INV					Hz	
Suction pipe temperature	Thermometer	3~15°C	INV	°C	STD1	°C	STD2	°C		
Discharge pipe temperature	Thermometer	85~105°C	INV	°C	STD1	°C	STD2	°C		
Clank case heater	Touch	Warm	NV	G-NG	STD1	G-NG	STD2	G-NG		

(V1093)

During operation

System name

	Inspection item	Inspection method	Standard (guideline)	Measurement values				Decision				
				Room 1	Room 2	Room 3	Room 4					
Indoor unit	Power supply voltage	Tester	Rated voltage ±10%	Room 1	V	Room 2	V	Room 3	V	Room 4	V	
				Room 5	V	Room 6	V	Room 7	V	Room 8	V	
				Room 9	V	Room10	V	Room11	V	Room12	V	
				Room13	V	Room14	V	Room15	V	Room16	V	
				Room17	V	Room18	V	Room19	V	Room20	V	
				Room21	V	Room22	V	Room23	V	Room24	V	
				Room25	V	Room26	V	Room27	V	Room28	V	
				Room29	V	Room30	V	Room31	V	Room32	V	
	Suction air temperature	Thermometer	Thermometer differential 9~13 °C when cooling, 15~20 °C when heating	Room 1	°C	Room 2	°C	Room 3	°C	Room 4	°C	
				Room 5	°C	Room 6	°C	Room 7	°C	Room 8	°C	
				Room 9	°C	Room10	°C	Room11	°C	Room12	°C	
				Room13	°C	Room14	°C	Room15	°C	Room16	°C	
				Room17	°C	Room18	°C	Room19	°C	Room20	°C	
				Room21	°C	Room22	°C	Room23	°C	Room24	°C	
				Room25	°C	Room26	°C	Room27	°C	Room28	°C	
				Room29	°C	Room30	°C	Room31	°C	Room32	°C	
	Discharge air temperature	Thermometer	Thermometer differential 9~13 °C when cooling, 15~20 °C when heating	Room 1	°C	Room 2	°C	Room 3	°C	Room 4	°C	
				Room 5	°C	Room 6	°C	Room 7	°C	Room 8	°C	
				Room 9	°C	Room10	°C	Room11	°C	Room12	°C	
				Room13	°C	Room14	°C	Room15	°C	Room16	°C	
				Room17	°C	Room18	°C	Room19	°C	Room20	°C	
				Room21	°C	Room22	°C	Room23	°C	Room24	°C	
				Room25	°C	Room26	°C	Room27	°C	Room28	°C	
				Room29	°C	Room30	°C	Room31	°C	Room32	°C	
	Fan rotation direction	Visual inspection	Forward rotation	Room 1	G NG	Room 2	G NG	Room 3	G NG	Room 4	G NG	
				Room 5	G NG	Room 6	G NG	Room 7	G NG	Room 8	G NG	
				Room 9	G NG	Room 10	G NG	Room 11	G NG	Room 12	G NG	
				Room 13	G NG	Room 14	G NG	Room 15	G NG	Room 16	G NG	
				Room 17	G NG	Room 18	G NG	Room 19	G NG	Room 20	G NG	
				Room 21	G NG	Room 22	G NG	Room 23	G NG	Room 24	G NG	
				Room 25	G NG	Room 26	G NG	Room 27	G NG	Room 28	G NG	
				Room 29	G NG	Room 30	G NG	Room 31	G NG	Room 32	G NG	
	Fan noise/vibration	Listening	No noise or vibration	Room 1	G NG	Room 2	G NG	Room 3	G NG	Room 4	G NG	
				Room 5	G NG	Room 6	G NG	Room 7	G NG	Room 8	G NG	
				Room 9	G NG	Room 10	G NG	Room 11	G NG	Room 12	G NG	
				Room 13	G NG	Room 14	G NG	Room 15	G NG	Room 16	G NG	
				Room 17	G NG	Room 18	G NG	Room 19	G NG	Room 20	G NG	
				Room 21	G NG	Room 22	G NG	Room 23	G NG	Room 24	G NG	
				Room 25	G NG	Room 26	G NG	Room 27	G NG	Room 28	G NG	
				Room 29	G NG	Room 30	G NG	Room 31	G NG	Room 32	G NG	
Fan operating current	Clamp meter		Room 1	A	Room 2	A	Room 3	A	Room 4	A		
			Room 5	A	Room 6	A	Room 7	A	Room 8	A		
			Room 9	A	Room10	A	Room11	A	Room12	A		
			Room13	A	Room14	A	Room15	A	Room16	A		
			Room17	A	Room18	A	Room19	A	Room20	A		
			Room21	A	Room22	A	Room23	A	Room24	A		
			Room25	A	Room26	A	Room27	A	Room28	A		
			Room29	A	Room30	A	Room31	A	Room32	A		
Room33	A	Room34	A	Room35	A	Room36	A					
Room37	A	Room38	A	Room39	A	Room40	A					

(V1094)


7.12 Piping System Diagrams

7.12.1 Outdoor Unit

7.12.1.1 Heat Pump/Cooling Only 50Hz


RXYQ5PY1

RXQ5PY1




3D050782

RXYQ8PY1
RXQ8PY1




3D050783

RXYQ10PY1, RXYQ12PY1
 RXQ10PY1, RXQ12PY1



3D050784


**RXYQ14PY1, RXYQ16PY1, RXYQ18PY1
RXQ14PY1, RXQ16PY1, RXQ18PY1**



3D050785A


7.12.1.2 Heat Pump 60Hz

RXYQ5PYL




3D055764A

RXYQ8PYL




3D055765A

RXYQ10PYL, RXYQ12PYL



3D055766B


RXYQ14PYL, RXYQ16PYL, RXYQ18PYL



3D050785A

7.12.2 Indoor Unit

FXCQ, FXFQ, FXKQ, FXSQ, FXMQ, FXHQ, FXAQ, FXLQ, FXNQ




4D040157

Code	Name	Code	Main function	Code
(1)	Electronic expansion valve	Y1E	Used for gas superheated degree control while in cooling operation or subcooled degree control while in heating operation.	(1)
(2)	Suction air temperature thermistor	R1T	Used for thermostat control.	(2)
(3)	Liquid pipe	R2T	Used for gas superheated degree control while in cooling operation or subcooled degree control while in heating operation.	(3)
(4)	Gas pipe	R3T	Used for gas superheated degree control while in cooling operation.	(4)

(mm)

Capacity	GAS	Liquid
20 / 25 / 32 / 40 / 50M(A)	φ12.7	φ6.4
63 / 80 / 100 / 125M(A)	φ15.9	φ9.5
200M(A)	φ19.1	φ9.5
250M(A)	φ22.2	φ9.5

FXZQ



Th1: Thermistor for suction air temp.

Th2: Thermistor for liquid air temp.

Th3: Thermistor for gas line temp.


4D040157

■ Refrigerant pipe connection port diameters

(mm)

Model	Gas	Liquid
FXZQ20M / 25M / 32M / 40M / 50M	$\phi 12.7$	$\phi 6.4$

FXDQ




4D043864J

■ Refrigerant pipe connection port diameters

Model	Gas	Liquid
FXDQ20N(A), P / 25N(A), P / 32N(A), P / 40N(A) / 50N(A)VE(T)	φ12.7	φ6.4
FXDQ63N(A)VE(T)	φ15.9	φ9.5

(mm)

FXMQ125MF / 200MF / 250MFV1



4D018650B


■ Refrigerant pipe connection port diameters

Model	Gas	Liquid
FXMQ125MFV1	φ15.9	φ9.5
FXMQ200MFV1	φ19.1	φ9.5
FXMQ250MFV1	φ22.2	φ9.5

(mm)


FXUQ + BEVQ

Indoor unit



4D037995G

Connection Unit






4D034127B

7.13 Wiring Diagrams (Heat Pump 50Hz/60Hz, Cooling Only 50Hz)

7.13.1 Heat Pump 50Hz/60Hz Outdoor Unit

RXYQ5PY1, RXYQ5PYL




L1-RED	L2-BLK	L3-WHT	N-BLU	K4R	Magnetic relay (Y2S)	S1PH	Pressure switch (high)
A1P	Printed circuit board (Main)	K5R	Magnetic relay (Y3S)	V1CP	Safety devices input	V1TR	Power module (A3P, A4P)
A2P	Printed circuit board (Noise filter)	K7R	Magnetic relay (E1HC)	V2R	Diode bridge (A3P)	X1A, X2A	Connector (MIF)
A3P	Printed circuit board (FAN)	K11R	Reactor	X1M	Terminal strip (Power supply)	X1M	Terminal strip (Control) (A1P)
A4P	Printed circuit board (ABC IP)	L1R	Motor (Compressor)	Y1E	Terminal strip (ABC IP) (A3P)	Y2E	Electronic expansion valve (Main)
BS1-5	Push button switch (Mode, set, return, test, reset)	M1C	Motor (Fan)	Y1S	Electronic expansion valve (Subcool)	Y2S	Solenoid valve (Hot gas)
C1	Capacitor	PS	Switching power supply (A1P, A3P)	Y3S	Solenoid valve (Oil)	Z1C-5C	Solenoid valve (4 way valve)
G63, C66	Capacitor	O1RP	Phase reversal detect circuit	R1T	Noise filter (Ferrite core)	Z1F	Noise filter (With surge absorber)
DS1, DS2	DIP switch	R10	Resistor (Current sensor) (A4P)	F1U	Resistor (Heat exc. delay)		
E1HC	Crankcase heater	R50, R59	Resistor	F1U, F2U	Thermistor (Heat exc. delay)		
F1U	Fuse (T, 3.15A, 250V) (A4P)	R1T	Resistor (Current limiting)	H1P-8P	Thermistor (Heat exc. delay)		
F400U	Fuse (T, 6.3A, 250V) (A2P)	R2T	Thermistor (Fan) (A1P)	L1P	Thermistor (Heat exc. delay)		
H1P-8P	Pilotlamp (Service monitor-orange) (H2P) Prepare, test	R2T	Thermistor (Suction)	L1R	Thermistor (Heat exc. delay)		
HAP	Pilotlamp (Service monitor-green)	R4T	Thermistor (MTC discharge)	K1, K3	Thermistor (Heat exc. delay)		
K1, K3	Magnetic relay	R5T	Thermistor (LightUp R4T)	K2, K4	Thermistor (Heat exc. delay)		
K2, K4	Magnetic relay	R6T	Thermistor (Service monitor-green)	K3R	Pressure sensor (high)		
K3R	Magnetic relay (Y1S)	S1NPH	Magnetic contactor (MTC)		Pressure sensor (low)		
		S1S	Cool/Heat Selector				
		S2S	Selector switch (Fan/Cool/Heat)				

- Notes**
- This wiring diagram is applied only to the outdoor unit.
 - Field wiring.
 - Terminal wiring.
 - Terminal earth (screw).
 - When using the optional adaptor, refer to the installation manual of the optional adaptor.
 - For connection to indoor-outdoor transmission F1+F2, outdoor-outdoor transmission F1+F2.
 - How to use BS1-5 and DS1-3 switch, refer to "service precaution" label on EL COMPO. BOX COVER.
 - When operating, do not touch the protection device (S1PH).
 - Colors (BLK: Black, RED: red, BLC: blue, WHT: white, PNC: Pink, YLW: Yellow, BRN: brown, GRY: gray, GRN: green, ORG: Orange).




3D050464J

RXYQ8PY1, RXYQ8PYL



3D050454J

RXYQ10PY1, RXYQ10PYL




L1-RED	L2-WHT	L3-BLK	N-BLU	A1P	X3R	S1PH, S2PH	Pressure switch (high)
A2P	Printed circuit board (Main)	X3R	Magnetic relay (Y1S)	A3P	K4R	T1A	Current sensor (A6P)
A4P	Printed circuit board (Noise filter)	K5R	Magnetic relay (Y2S)	A5P	K7R	V1CP	Safety devices input
A6P	Printed circuit board (FAN)	K8R	Magnetic relay (E1HC)	V2R	M1F	V2R	Power module (A3P, A4P)
BS1-5	Printed circuit board (ABC I/P)	L1R	Magnetic relay (E2HC)	X1A, X2A	Reactor	X1A, X2A	Diode bridge (A3P)
C1	Push button switch	M1C, M2C	Motor (Compressor)	X1M	M1F	X1M	Connector (M1F)
C63, C66	Capacitor	PS	Motor (Fan)	X1M	O1RP	X1M	Terminal strip (Power supply)
DS1, DS2	DIP switch	R10	Phase reversal detect circuit	X1M	R10	X1M	Terminal strip (ABC I/P) (A5P)
E1HC, E2HC	Crankcase heater	R50, R59	Resistor (Current sensor) (A4P, A5P)	Y1E	Y1E	Y1E	Electronic expansion valve (Main)
F1U, F2U	Fuse (6A, DC650V) (A4P)	R95	Resistor (Current limiting)	Y2S	Y2S	Y2S	Solenoid valve (Hot gas)
F400U	Fuse (T, 3.15A, 250V) (A1P)	R1T	Thermistor (Air) (A1P)	Y2S	Y2S	Y2S	Solenoid valve (Oil)
H1P, 8P	Fuse (T, 6.3A, 250V) (A2P)	R2T	Thermistor (Fin) (A3P)	Z1C-5C	Z1C-5C	Z1C-5C	Solenoid valve (4 way valve)
HAP	Pilotlamp (Service monitor-orange)	R3T	Thermistor (Suction)	Z1F	Z1F	Z1F	Noise filter (Fertile core)
K1, K3	Malfunction detection—Light up	R4T	Thermistor (M1C, M2C discharge)				Noise filter (With surge absorber)
K2, K4	Thermistor (Service monitor-green)	R5T	Thermistor (Heat exc. detect)				
K2M	Magnetic relay	R6T	Thermistor (Liq. pipe)				
K1R	Magnetic relay (Accumulator)	R7T	Thermistor (Heat exc. outlet)				
	Magnetic contactor (M1C)	S1NPH	Pressure sensor (high)				
	Magnetic contactor (M2C)	S1NPL	Pressure sensor (low)				
	Magnetic relay (K2M)	S2S	Pressure sensor (low)				

- Notes**
- This wiring diagram is applied only to the outdoor unit.
 - Field wiring.
 - Terminal strip.
 - When using the optional adapter, refer to the installation manual of the optional adapter.
 - For connection wiring to indoor-outdoor transmission F1 • F2, outdoor-outdoor transmission F1 • F2, Outdoor-Multi Transmission Q1 • Q2 (only for RXYQ), refer to the installation manual.
 - How to use BS1-5 and DS1-3 switch, refer to "service precaution" label on EL COMPO BOX COVER.
 - When operating, don't shortcircuit the protection device (S1PH, S2PH).
 - Colors (BLK:Black, RED:red, BLU:blue, WHT:white, PNK:Pink, YLW:Yellow, BRN:brown, GRY:gray, GRN:green, ORG:orange).




3D050455H

RXYQ12PY1, RXYQ12PYL



7.13.2 Cooling Only Outdoor Unit

RXQ5PY1




L1-RED	L2-WHT	L3-BLK	N-BLU
A1P	K4R	Magnetic relay (Y2S)	S1PH
A2P	K5R	Magnetic relay (Y3S)	V1CP
A3P	K7R	Magnetic relay (E1HC)	V1R
A4P	K11R	Magnetic relay (Y4S)	V2R
A5P	L1R	Reactor	X1A, X2A
BS1-5	M1C	Motor (Compressor)	X1M
C1	M1F	Motor (Fan)	Terminal strip (Power supply)
C63, C66	PS	Switching power supply (A1P, A3P)	Electronic expansion valve (Main)
DS1, DS2	O1RP	Capacitor	Solenoid valve (Hot gas)
E1HC	R10	DIP switch	Solenoid valve (Oil)
F1U	R50, R59	Resistor (Current limiting)	Solenoid valve (4 way valve)
F400U	R95	Fuse (T, 3.15A, 250V) (A1P)	Solenoid valve (Injection)
F400U	R11	Fuse (T, 6.3A, 250V) (A2P)	Noise filter (Ferrite core)
H1P-8P	R2T	Pilotlamp (Service monitor-orange)	Noise filter (With surge absorber)
HAP	R3T	Pilotlamp (Service monitor-orange)	
K1, K3	R4T	Magnetic relay	
K2, K4	R6T	Magnetic relay	
K3R	R6T	Magnetic relay	
	S1MPL	Magnetic relay (MTS)	

- Notes**
- This wiring diagram is applied only to the outdoor unit.
 - Terminal strip: Connector (Terminal) (Protective earth screw)
 - Field wiring: Terminal strip
 - When using the optional adapter, refer to the installation manual of the optional adapter.
 - For connection wiring to indoor-outdoor transmission F1 • F2, outdoor-outdoor transmission F1 • F2, refer to the installation manual.
 - How to use BS1-5 and DS1-3 switch, refer to "service precaution" label on EL COMPO BOX COVER.
 - When operating, don't shortcircuit the protection device (S1PH).
 - Colors (BLK:Black, RED:red, BLU:blue, WHT:white, PNK:Pink, YLW:Yellow, BRN:brown, GRY:gray, GRN:green, ORG:orange).

3D055257A

RXQ8PY1




L1-RED	L2-WHT	L3-BLK	N-BLU
A1P	Printed circuit board (Main)	K4R	Magnetic relay (Y2S)
A2P	Printed circuit board (Noise filter)	K5R	Magnetic relay (Y3S)
A3P	Printed circuit board (INV)	L1R	Magnetic relay (E1HC)
A4P	Printed circuit board (FAN)	M1C	Reactor
A5P	Printed circuit board (ABC/IP)	M1F	Motor (Compressor)
BS1-5	Push button switch (Mode set, return, test, reset)	PS	Motor (Fan)
C1	Capacitor	Q1RP	Switching power supply (A1P/A3P)
C63, C66	Capacitor	R10	Phase reversal detect circuit
DS1, DS2	DIP switch	R50, R59	Resistor (Current sensor) (A4P)
E1HC	Crankcase heater	R95	Resistor (Current limiting)
F1U	Fuse (8A, DC650V) (A4P)	R11	Thermistor (Air) (A1P)
F1U, F2U	Fuse (T, 3.15A, 250V) (A1P)	R1T	Thermistor (Fin) (A3P)
F400U	Fuse (T, 6.3A, 250V) (A2P)	R2T	Thermistor (Suction)
H1P-8P	Pilotlamp (Service monitor-orange) (H2P) Prepare test	R3T	Thermistor (MTC discharge)
HAP	Pilotlamp (Service monitor-green) (H2P) Prepare test	R4T	Thermistor (Heat exc. deicer)
K1, K3	Magnetic relay	R5T	Thermistor (Heat exc. outlet)
K2, K4	Magnetic relay	R6T	Thermistor (Light pipe)
K3R	Magnetic relay (Y1S)	R7T	Thermistor (Accumulator)
		STNPH	Pressure sensor (High)
		STNPL	Pressure sensor (Low)
		STPH	Pressure switch (high)
		V1CP	Safety devices input
		V2R	Diode bridge (A3P)
		V2A	Diode bridge (A3P)
		X1A, X2A	Connector (M1F)
		X1M	Terminal strip (Power supply)
		X1P	Terminal strip (Control) (A1P)
		Y1E	Electronic expansion valve (Main)
		Y2E	Electronic expansion valve (Subcool)
		Y2S	Solenoid valve (Hot gas)
		Y3S	Solenoid valve (Oil)
		Z1C-5C	Solenoid valve (4 way valve)
		Z1F	Noise filter (Ferrite core)
			Noise filter (With surge absorber)

- Notes**
- This wiring diagram is applied only to the outdoor unit.
 - Terminal strip: Terminal strip
 - Field wiring: Field wiring
 - When using the optional adapter, refer to the installation manual of the optional adapter.
 - For connection wiring to indoor-outdoor transmission F1 • F2, outdoor-outdoor transmission F1 • F2, Outdoor-Multi Transmission Q1 • Q2, refer to the installation manual.
 - How to use BS1-5 and DS1-3 switch, refer to "service precaution" label on EL COMPO BOX COVER.
 - When operating, don't shortcircuit the protection device (STPH).
 - Colors (BLK:Black, RED:red, BLU:blue, WHT:white, PNK:Pink, YLW:Yellow, BRN:brown, GRY:gray, ORG:orange).

3D055258A

RXQ10PY1




L1-RED	L2-WHT	L3-BLK	N-BLU	K3R	S1PH,S2PH	Pressure switch (high)
A1P	Printed circuit board (Main)	K4R	Printed circuit board (Noise filter)	T1A	T1A	Current sensor (A6P)
A2P	Printed circuit board (INV)	K6R	Printed circuit board (FAN)	V1COP	V1COP	Safety devices input
A3P	Printed circuit board (FAN)	K7R	Printed circuit board (ABC /IP)	V1R	V1R	Power module (A3P-A4P)
A4P	Printed circuit board (Current sensor)	K8R	Push button switch	V2R	V2R	Diode bridge (A3P)
A6P	Capacitor	L1R	(Mode, set, return, test, reset)	X1A, X2A	X1A, X2A	Connector (M1F)
BST-5	DIP switch	M1C	Capacitor	X1M	X1M	Terminal strip (Power supply)
C1	Fuse (6A, DC650V) (A4P)	M1F	Fuse (T: 3.15A, 250V) (A1P)	X1M	X1M	Terminal strip (Control) (A1P)
C63,C66	Fuse (T: 6.3A, 250V) (A2P)	O1RP	Fuse (T: 3.15A, 250V) (A1P)	Y1E	Y1E	Electronic expansion valve (Main)
DST,DS2	Pilotlamp (Service monitor-orange)	R10	Fuse (T: 3.15A, 250V) (A1P)	Y2E	Y2E	Electronic expansion valve (Subcool)
E1HC,E2HC	Pilotlamp (Service monitor-green)	R11	Fuse (T: 3.15A, 250V) (A1P)	Y2S	Y2S	Solenoid valve (Hot Gas)
F1U,F2U	Malfunction detection—Light up	R12	Fuse (T: 3.15A, 250V) (A1P)	Y3S	Y3S	Solenoid valve (Oil)
F400U	Malfunction detection—Light up	R13	Fuse (T: 3.15A, 250V) (A1P)	Z1C-7C	Z1C-7C	Solenoid valve (4 Way valve)
H1P-8P	Malfunction detection—Light up	R14	Fuse (T: 3.15A, 250V) (A1P)	Z1F	Z1F	Noise filter (Ferrite core)
HAP	Malfunction detection—Light up	R15	Fuse (T: 3.15A, 250V) (A1P)			Noise filter (With surge absorber)
K1,K3	Thermistor (Heat exc. deicer)	R16	Fuse (T: 3.15A, 250V) (A1P)			
K2,K4	Thermistor (Heat exc. outlet)	R17	Fuse (T: 3.15A, 250V) (A1P)			
K2M	Thermistor (Liq. pipe)	R18	Fuse (T: 3.15A, 250V) (A1P)			
K1R	Thermistor (Accumulator)	R19	Fuse (T: 3.15A, 250V) (A1P)			
	Thermistor (High)	R20	Fuse (T: 3.15A, 250V) (A1P)			
	Thermistor (Low)	R21	Fuse (T: 3.15A, 250V) (A1P)			
	Pressure sensor (High)	R22	Fuse (T: 3.15A, 250V) (A1P)			
	Pressure sensor (Low)	R23	Fuse (T: 3.15A, 250V) (A1P)			
		R24	Fuse (T: 3.15A, 250V) (A1P)			
		R25	Fuse (T: 3.15A, 250V) (A1P)			
		R26	Fuse (T: 3.15A, 250V) (A1P)			
		R27	Fuse (T: 3.15A, 250V) (A1P)			
		R28	Fuse (T: 3.15A, 250V) (A1P)			
		R29	Fuse (T: 3.15A, 250V) (A1P)			
		R30	Fuse (T: 3.15A, 250V) (A1P)			
		R31	Fuse (T: 3.15A, 250V) (A1P)			
		R32	Fuse (T: 3.15A, 250V) (A1P)			
		R33	Fuse (T: 3.15A, 250V) (A1P)			
		R34	Fuse (T: 3.15A, 250V) (A1P)			
		R35	Fuse (T: 3.15A, 250V) (A1P)			
		R36	Fuse (T: 3.15A, 250V) (A1P)			
		R37	Fuse (T: 3.15A, 250V) (A1P)			
		R38	Fuse (T: 3.15A, 250V) (A1P)			
		R39	Fuse (T: 3.15A, 250V) (A1P)			
		R40	Fuse (T: 3.15A, 250V) (A1P)			
		R41	Fuse (T: 3.15A, 250V) (A1P)			
		R42	Fuse (T: 3.15A, 250V) (A1P)			
		R43	Fuse (T: 3.15A, 250V) (A1P)			
		R44	Fuse (T: 3.15A, 250V) (A1P)			
		R45	Fuse (T: 3.15A, 250V) (A1P)			
		R46	Fuse (T: 3.15A, 250V) (A1P)			
		R47	Fuse (T: 3.15A, 250V) (A1P)			
		R48	Fuse (T: 3.15A, 250V) (A1P)			
		R49	Fuse (T: 3.15A, 250V) (A1P)			
		R50	Fuse (T: 3.15A, 250V) (A1P)			
		R51	Fuse (T: 3.15A, 250V) (A1P)			
		R52	Fuse (T: 3.15A, 250V) (A1P)			
		R53	Fuse (T: 3.15A, 250V) (A1P)			
		R54	Fuse (T: 3.15A, 250V) (A1P)			
		R55	Fuse (T: 3.15A, 250V) (A1P)			
		R56	Fuse (T: 3.15A, 250V) (A1P)			
		R57	Fuse (T: 3.15A, 250V) (A1P)			
		R58	Fuse (T: 3.15A, 250V) (A1P)			
		R59	Fuse (T: 3.15A, 250V) (A1P)			
		R60	Fuse (T: 3.15A, 250V) (A1P)			
		R61	Fuse (T: 3.15A, 250V) (A1P)			
		R62	Fuse (T: 3.15A, 250V) (A1P)			
		R63	Fuse (T: 3.15A, 250V) (A1P)			
		R64	Fuse (T: 3.15A, 250V) (A1P)			
		R65	Fuse (T: 3.15A, 250V) (A1P)			
		R66	Fuse (T: 3.15A, 250V) (A1P)			
		R67	Fuse (T: 3.15A, 250V) (A1P)			
		R68	Fuse (T: 3.15A, 250V) (A1P)			
		R69	Fuse (T: 3.15A, 250V) (A1P)			
		R70	Fuse (T: 3.15A, 250V) (A1P)			
		R71	Fuse (T: 3.15A, 250V) (A1P)			
		R72	Fuse (T: 3.15A, 250V) (A1P)			
		R73	Fuse (T: 3.15A, 250V) (A1P)			
		R74	Fuse (T: 3.15A, 250V) (A1P)			
		R75	Fuse (T: 3.15A, 250V) (A1P)			
		R76	Fuse (T: 3.15A, 250V) (A1P)			
		R77	Fuse (T: 3.15A, 250V) (A1P)			
		R78	Fuse (T: 3.15A, 250V) (A1P)			
		R79	Fuse (T: 3.15A, 250V) (A1P)			
		R80	Fuse (T: 3.15A, 250V) (A1P)			
		R81	Fuse (T: 3.15A, 250V) (A1P)			
		R82	Fuse (T: 3.15A, 250V) (A1P)			
		R83	Fuse (T: 3.15A, 250V) (A1P)			
		R84	Fuse (T: 3.15A, 250V) (A1P)			
		R85	Fuse (T: 3.15A, 250V) (A1P)			
		R86	Fuse (T: 3.15A, 250V) (A1P)			
		R87	Fuse (T: 3.15A, 250V) (A1P)			
		R88	Fuse (T: 3.15A, 250V) (A1P)			
		R89	Fuse (T: 3.15A, 250V) (A1P)			
		R90	Fuse (T: 3.15A, 250V) (A1P)			
		R91	Fuse (T: 3.15A, 250V) (A1P)			
		R92	Fuse (T: 3.15A, 250V) (A1P)			
		R93	Fuse (T: 3.15A, 250V) (A1P)			
		R94	Fuse (T: 3.15A, 250V) (A1P)			
		R95	Fuse (T: 3.15A, 250V) (A1P)			
		R96	Fuse (T: 3.15A, 250V) (A1P)			
		R97	Fuse (T: 3.15A, 250V) (A1P)			
		R98	Fuse (T: 3.15A, 250V) (A1P)			
		R99	Fuse (T: 3.15A, 250V) (A1P)			
		R100	Fuse (T: 3.15A, 250V) (A1P)			

- Notes**
- This wiring diagram is applied only to the outdoor unit.
 - Terminal strip wiring.
 - When using the optional adapter, refer to the installation manual of the optional adapter.
 - For connection wiring to indoor-outdoor transmission F1 • F2, outdoor-outdoor transmission F1 • F2, Outdoor-Multi Transmission Q1 • Q2, refer to the installation manual.
 - How to use BST-5 and DST-3 switch, refer to 'service precaution' label on EL COMPO. BOX COVER.
 - When operating, don't shortcircuit the protection device (S1PH,S2PH).
 - Colors (BLK:Black, RED:red, BLU:blue, WHT:white, PNK:Pink, YLW:Yellow, BRN:brown, GRY:gray, GRN:green, ORG:orange).


3D055259A

RXQ12PY1



3D055260A

RXQ14PY1, RXQ16PY1, RXQ18PY1



LT-RED	L2-WHT	L3-BLK	N-BLU	Component
A1P	K3R	K4R	SINPL	Pressure switch (low)
A2P	K5R	K6R	SIPH,3PH	Pressure switch (high)
A3P	K7R	K8R	T1A	Current sensor (A6P, A7P)
A4P, A8P	K9R	K10R	V1CP	Safety devices input
A5P	K11R	K12R	V1R	Power module (A3P, A4P, A8P)
A6P, A7P	K13R	K14R	V2R	Diode bridge (A3P)
BS1-5	K15R	K16R	X1A-4A	Connector (M1F, M2F)
C1	M1C, M3C	M2C	X1M	Terminal strip (Power supply)
C63, C66	M1F, M2F	M3C	X1M	Terminal strip (Control) (A1P)
DS1, DS2	PS	PS	Y1E	Electronic expansion valve (Main)
E1HC, 3HC	Q1RP	Q2RP	Y2E	Solenoid expansion valve (Subcool)
F1U	R10	R50, R59	Y2S	Solenoid valve (Hot Gas)
F1U, F2U	R85	R85	Y3S	Solenoid valve (Oil)
F400U	R11	R11	Z1C-7C, Z9C	Noise filter (Ferrite core)
H1P-8P	R1T	R1T	Z1F	Noise filter (With surge absorber)
HAP	R2T	R2T		
K1, K3	R3T, R32T	R3T, R32T		
K2, K4	R4T	R4T		
K2M, K3M	R5T	R5T		
K1R, K2R	R6T	R6T		
	R7T	R7T		
	SINPH	SINPH		

- Notes**
- This wiring diagram is applied only to the outdoor unit.
 - Terminal strip: ; Field wiring: .
 - : Terminal strip; : Protective earth (screw).
 - When using the optional adapter, refer to the installation manual of the optional adapter.
 - For connection wiring to indoor-outdoor transmission F1 • F2, outdoor-outdoor transmission F1 • F2, Outdoor-Multi Transmission Q1 • Q2, refer to the installation manual.
 - How to use BS1-5 and DS1-3 switch, refer to "service precaution" label on EL COMPO BOX COVER.
 - When operating, don't short-circuit the protection device (S1PH, S3PH).
 - Colors (BLK:Black, RED:red, BLU:blue, WHT:white, PNK:Pink, YLW:yellow, BRN:brown, GRY:gray, GRN:green, ORG:orange).

3D055261A

7.13.3 Field Wiring Heat Pump, Cooling Only (50Hz/60Hz)


RX(Y)Q5P, 8P, 10P, 12P, 14P, 16P, 18PY1

RXYQ5P, 8P, 10P, 12P, 14P, 16P, 18PYL

3D051452D

6. Unit shall be grounded in compliance with the applicable local and national codes.
 7. Wiring shown are general points-of-connection guides only and are not intended for or to include all details for a specific installation.
 8. Be sure to install the switch and the fuse to the power line of each equipment
 9. Install the main switch that can interrupt all the power sources in an integrated manner because this system consists of the equipment utilizing the multiple power sources.
 10. If there exists the possibility of reversed phase, lose phase, momentary blackout or the power goes on and off while the product is operating, attach a reversed phase protection circuit locally.
- Running the product in reversed phase may break the compressor and other parts.



- NOTES
1. All wiring, components and materials to be produced on the site must comply with the applicable local and national codes.
 2. Use copper conductors only.
 3. As for details, see wiring diagram.
 4. Install circuit breaker for safety.
 5. All field wiring and components must be provided by licensed electrician.



RX(Y)Q20P, 22P, 24P, 26P, 28P, 30P, 32P, 34P, 36PY1
RXYQ20P, 22P, 24P, 26P, 28P, 30P, 32P, 34P, 36PYL

Notes

- 1) All wiring, components and materials to be procured on the site must comply with the applicable local and national codes.
 - 2) Use copper conductors only.
 - 3) As for details, see wiring diagram.
 - 4) Install circuit breaker for safety.
 - 5) All field wiring and components must be provided by licensed electrician.
 - 6) Unit shall be grounded in compliance with the applicable local and national codes.
 - 7) Wiring shown are general points-of-connection guides only are not intended for or to include all details for or to specific installation.
 - 8) Be sure to install the switch and the fuse to the power line of each equipment.
 - 9) Install the main switch that can interrupt all the power sources in an integrated manner because this system consists of the equipment utilizing the multiple power sources.
 - 10) The capacity of UNIT 1 must be larger than UNIT 2 when the power source is connected in series between the units.
 - 11) If there exists the possibility of reversed phase, loose phase, momentary blackout or the power goes on and off while the product is operating, attach a reversed phase protection circuit locally.
- Running the product in reversed phase may break the compressor and other parts.




3D052261B

RX(Y)Q38P, 40P, 42P, 44P, 46P, 48P, 50P, 52P, 54PY1
RXYQ238P, 40P, 42P, 44P, 46P, 48P, 50P, 52P, 54PYL


Notes

- 1) All wiring, components and materials to be procured on the site must comply with the applicable local and national codes.
 - 2) Use copper conductors only.
 - 3) As for details, see wiring diagram.
 - 4) Install circuit breaker for safety.
 - 5) All field wiring and components must be provided by licensed electrician.
 - 6) Unit shall be grounded in compliance with the applicable local and national codes.
 - 7) Wiring shown are general points-of-connection guides only are not intended for or to include all details for or to specific installation.
 - 8) Be sure to install the switch and the fuse to the power line of each equipment.
 - 9) Install the main switch that can interrupt all the power sources in an integrated manner because this system consists of the equipment utilizing the multiple power sources.
 - 10) The capacity of UNIT1 must be larger than UNIT2.
 - 11) If there exists the possibility of reversed phase, lose phase, momentary blackout or the power goes on and off while the product is operating, attach a reversed phase protection circuit locally.
- Running the product in reversed phase may break the compressor and other parts.

When the power source is supplied to each outdoor unit individually.



When the power source is connected in series between the units.



C: 3D052262B