

# Service Manual

## SPLIT GA Series



[Applied Models]

●Non-Inverter Pair : Cooling Only

# Non Inverter Pair

## ●Cooling Only

### Indoor Unit

FT50GAVE	FT50GAVEA	FT50GAVAL
FT60GAVE	FT60GAVEA	FT60GAVAL

### Outdoor Unit

R50GV1	R50GV19	R50GAV1A	R50GVAL
R60GV1	R60GV19	R60GAV1A	R60GVAL
R50GV1K	R50GV1K9	R50GAV1A9	R50GVAL9
R60GV1K	R60GV1K9	R60GAV1A9	R60GVAL9



1. Introduction .....	V
1.1 Safety Cautions.....	V
<b>Part 1 List of Function .....</b>	<b>1</b>
1. Functions.....	2
1.1 List of Functions .....	2
<b>Part 2 Specifications .....</b>	<b>3</b>
1. Specifications .....	4
1.1 Cooling Only.....	4
<b>Part 3 Printed Circuit Board Connector Wiring Diagram .....</b>	<b>7</b>
1. Printed Circuit Board Connector Wiring Diagram and Name .....	8
1.1 FT50/60GAVE , FT50/60GAVEA , FT50/60GAVAL.....	8
<b>Part 4 Main Function.....</b>	<b>11</b>
1. General Functionality .....	12
1.1 General Functionality .....	12
<b>Part 5 System Configuration.....</b>	<b>21</b>
1. Instruction.....	22
1.1 FT50 / 60GAVE, FT50 / 60GAVEA, FT50 / 60GAVAL.....	22
<b>Part 6 Service Diagnosis.....</b>	<b>37</b>
1. Caution for Diagnosis.....	38
1.1 Troubleshooting with The Operation Lamp .....	38
2. Problem Symptoms and Measures .....	39
2.1 General Check .....	39
2.2 Troubleshooting (Fault Diagnosis and Countermeasure).....	40
3. Service Check Function .....	44
3.1 Remote Controller Display .....	44
4. Troubleshooting by Indication on the Remote Controller .....	45
4.1 Indoor Units .....	45
4.2 Faulty PCB .....	46
4.3 Freeze-Up Protection (Thermistor Activation) .....	47
4.4 Operation Halt Due to Fan Motor (AC Motor) or Related Abnormality .....	48
4.5 Operation Halt Due to Detection of Thermistor or Related Abnormality .....	49
4.6 Faulty Indoor Unit PCB.....	50
5. Check .....	51
5.1 How to Check .....	51
<b>Part 7 Removal Procedure .....</b>	<b>53</b>
1. For FT50 / 60GAVE, FT50 / 60GAVEA, T50 / 60GAVAL .....	54
1.1 Removal of Air Filter.....	54

1.2	Removal of Front Grille .....	56
1.3	Opening and Closing of Service Cover / Changing Settings at Installation Site.....	57
1.4	Removal of Front Panel.....	58
1.5	Removal of Horizontal and Vertical Blades .....	60
1.6	Removal of Drain Pan .....	61
1.7	Removal of PC Board.....	63
1.8	Removal of Electrical Parts Box .....	66
1.9	Removal of Swing Motor Assembly.....	68
1.10	Piping of Drain Hose at Left Side .....	69
1.11	Removal of Heat Exchanger .....	70
1.12	Removal of Fan Rotor and Motor .....	75
2.	For R60GV1(K)(9), R60GAV1A(9), R60GVAL(9) .....	76
2.1	Removal of Outer Panel .....	76
2.2	Removal of Electrical Parts Box .....	77
2.3	Removal of Compressor.....	80
<b>Part 8</b>	<b>Others .....</b>	<b>83</b>
1.	Others .....	84
1.1	Points of Installation Work.....	84
<b>Part 9</b>	<b>Appendix.....</b>	<b>87</b>
1.	Piping Diagram.....	88
1.1	Indoor Unit.....	88
1.2	Outdoor Unit.....	89
2.	Wiring Diagram .....	91
2.1	Indoor Unit.....	91
2.2	Outdoor Unit.....	92
<b>Index</b>	<b>.....</b>	<b>i</b>
<b>Drawings &amp; Flow Charts</b>	<b>.....</b>	<b>iii</b>



# 1. Introduction

## 1.1 Safety Cautions

### Cautions and Warnings

- Be sure to read the following safety cautions before conducting repair work.
- The caution items are classified into “ **Warning**” and “ **Caution**”. The “ **Warning**” items are especially important since they can lead to death or serious injury if they are not followed closely. The “ **Caution**” items can also lead to serious accidents under some conditions if they are not followed. Therefore, be sure to observe all the safety caution items described below.
- About the pictograms
  - △ This symbol indicates an item for which caution must be exercised.  
The pictogram shows the item to which attention must be paid.
  - This symbol indicates a prohibited action.  
The prohibited item or action is shown inside or near the symbol.
  - This symbol indicates an action that must be taken, or an instruction.  
The instruction is shown inside or near the symbol.
- After the repair work is complete, be sure to conduct a test operation to ensure that the equipment operates normally, and explain the cautions for operating the product to the customer

### 1.1.1 Caution in Repair

 <b>Warning</b>	
Be sure to disconnect the power cable plug from the plug socket before disassembling the equipment for a repair. Working on the equipment that is connected to a power supply can cause an electrical shock. If it is necessary to supply power to the equipment to conduct the repair or inspecting the circuits, do not touch any electrically charged sections of the equipment.	
If the refrigerant gas discharges during the repair work, do not touch the discharging refrigerant gas. The refrigerant gas can cause frostbite.	
When disconnecting the suction or discharge pipe of the compressor at the welded section, release the refrigerant gas completely at a well-ventilated place first. If there is a gas remaining inside the compressor, the refrigerant gas or refrigerating machine oil discharges when the pipe is disconnected, and it can cause injury.	
If the refrigerant gas leaks during the repair work, ventilate the area. The refrigerant gas can generate toxic gases when it contacts flames.	
The step-up capacitor supplies high-voltage electricity to the electrical components of the outdoor unit. Be sure to discharge the capacitor completely before conducting repair work. A charged capacitor can cause an electrical shock.	
Do not start or stop the air conditioner operation by plugging or unplugging the power cable plug. Plugging or unplugging the power cable plug to operate the equipment can cause an electrical shock or fire.	

 <b>Caution</b>	
Do not repair the electrical components with wet hands. Working on the equipment with wet hands can cause an electrical shock.	
Do not clean the air conditioner by splashing water. Washing the unit with water can cause an electrical shock.	
Be sure to provide the grounding when repairing the equipment in a humid or wet place, to avoid electrical shocks.	
Be sure to turn off the power switch and unplug the power cable when cleaning the equipment. The internal fan rotates at a high speed, and cause injury.	
Do not tilt the unit when removing it. The water inside the unit can spill and wet the furniture and floor.	
Be sure to check that the refrigerating cycle section has cooled down sufficiently before conducting repair work. Working on the unit when the refrigerating cycle section is hot can cause burns.	
Use the welder in a well-ventilated place. Using the welder in an enclosed room can cause oxygen deficiency.	

### 1.1.2 Cautions Regarding Products after Repair

 <b>Warning</b>	
Be sure to use parts listed in the service parts list of the applicable model and appropriate tools to conduct repair work. Never attempt to modify the equipment. The use of inappropriate parts or tools can cause an electrical shock, excessive heat generation or fire.	
When relocating the equipment, make sure that the new installation site has sufficient strength to withstand the weight of the equipment. If the installation site does not have sufficient strength and if the installation work is not conducted securely, the equipment can fall and cause injury.	
Be sure to install the product correctly by using the provided standard installation frame. Incorrect use of the installation frame and improper installation can cause the equipment to fall, resulting in injury.	For integral units only
Be sure to install the product securely in the installation frame mounted on a window frame. If the unit is not securely mounted, it can fall and cause injury.	For integral units only
Be sure to use an exclusive power circuit for the equipment, and follow the technical standards related to the electrical equipment, the internal wiring regulations and the instruction manual for installation when conducting electrical work. Insufficient power circuit capacity and improper electrical work can cause an electrical shock or fire.	

 <b>Warning</b>	
Be sure to use the specified cable to connect between the indoor and outdoor units. Make the connections securely and route the cable properly so that there is no force pulling the cable at the connection terminals. Improper connections can cause excessive heat generation or fire.	
When connecting the cable between the indoor and outdoor units, make sure that the terminal cover does not lift off or dismount because of the cable. If the cover is not mounted properly, the terminal connection section can cause an electrical shock, excessive heat generation or fire.	
Do not damage or modify the power cable. Damaged or modified power cable can cause an electrical shock or fire. Placing heavy items on the power cable, and heating or pulling the power cable can damage the cable.	
Do not mix air or gas other than the specified refrigerant (R22) in the refrigerant system. If air enters the refrigerating system, an excessively high pressure results, causing equipment damage and injury.	
If the refrigerant gas leaks, be sure to locate the leak and repair it before charging the refrigerant. After charging refrigerant, make sure that there is no refrigerant leak. If the leak cannot be located and the repair work must be stopped, be sure to perform pump-down and close the service valve, to prevent the refrigerant gas from leaking into the room. The refrigerant gas itself is harmless, but it can generate toxic gases when it contacts flames, such as fan and other heaters, stoves and ranges.	
When replacing the coin battery in the remote controller, be sure to disposed of the old battery to prevent children from swallowing it. If a child swallows the coin battery, see a doctor immediately.	

 <b>Caution</b>	
Installation of a leakage breaker is necessary in some cases depending on the conditions of the installation site, to prevent electrical shocks.	
Do not install the equipment in a place where there is a possibility of combustible gas leaks. If a combustible gas leaks and remains around the unit, it can cause a fire.	
Be sure to install the packing and seal on the installation frame properly. If the packing and seal are not installed properly, water can enter the room and wet the furniture and floor.	For integral units only

### 1.1.3 Inspection after Repair

 <b>Warning</b>	
Check to make sure that the power cable plug is not dirty or loose, then insert the plug into a power outlet all the way. If the plug has dust or loose connection, it can cause an electrical shock or fire.	
If the power cable and lead wires have scratches or deteriorated, be sure to replace them. Damaged cable and wires can cause an electrical shock, excessive heat generation or fire.	
Do not use a joined power cable or extension cable, or share the same power outlet with other electrical appliances, since it can cause an electrical shock, excessive heat generation or fire.	

 <b>Caution</b>	
Check to see if the parts and wires are mounted and connected properly, and if the connections at the soldered or crimped terminals are secure. Improper installation and connections can cause excessive heat generation, fire or an electrical shock.	
If the installation platform or frame has corroded, replace it. Corroded installation platform or frame can cause the unit to fall, resulting in injury.	
Check the grounding, and repair it if the equipment is not properly grounded. Improper grounding can cause an electrical shock.	
Be sure to measure the insulation resistance after the repair, and make sure that the resistance is 1 Mohm or higher. Faulty insulation can cause an electrical shock.	
Be sure to check the drainage of the indoor unit after the repair. Faulty drainage can cause the water to enter the room and wet the furniture and floor.	

### 1.1.4 Using Icons

Icons are used to attract the attention of the reader to specific information. The meaning of each icon is described in the table below:

### 1.1.5 Using Icons List

Icon	Type of Information	Description
 Note:	Note	A “note” provides information that is not indispensable, but may nevertheless be valuable to the reader, such as tips and tricks.
 Caution	Caution	A “caution” is used when there is danger that the reader, through incorrect manipulation, may damage equipment, lose data, get an unexpected result or has to restart (part of) a procedure.
 Warning	Warning	A “warning” is used when there is danger of personal injury.
	Reference	A “reference” guides the reader to other places in this binder or in this manual, where he/she will find additional information on a specific topic.

# Part 1

# List of Function

1. Functions.....	2
1.1 List of Functions .....	2

# 1. Functions

## 1.1 List of Functions

Category	Functions	FT50-60GAVE(A)/GAVAL R50-60GV1/GAV1A/GVAL(K)(9)	Category	Functions	FT50-60GAVE(A)/GAVAL R50-60GV1/GAV1A/GVAL(K)(9)
Basic Function	Inverter (with Inverter Power Control)	—	Health Health & Clean	Air Purifying Filter with Bacteriostatic, Virustatic & Deodorizing Functions	○
	Operation Limit for Cooling (°C)★1	19.4 ~54		Longlife Filter	—
	Microprocessor Control	○		Ultra-Longlife Filter (Option)	—
	PAM Control	—		Photocatalytic Deodorizing Filter	—
Compressor	Oval Scroll Compressor (DAIKIN SCROLL)	—		Photocatalytic Filter with UV Lamp	—
	Swing Compressor(DAIKIN ROTARY)	—		Mold Proof Air Filter	○
	Rotary Compressor	○		Washable Grille	○
	Reluctance DC Motor	—		Filter Cleaning Indicator	○
Comfortable Airflow	Power-Airflow Flap	○	Timer	Good-Sleep Cooling Operation	—
	Power-Airflow Dual Flaps	—		72-Hour On/Off Timer	—
	Power-Airflow Diffuser	○		24-Hour On/Off Timer	○
	Wide-Angle Louvers	○		Night Set Mode	○
	Vertical Auto-Swing (Up and Down)	○	Worry Free "Reliability & Durability"	Just Fit Thermostatic Timer	—
	Horizontal Auto-Swing (Right and Left)	★2		Auto-Restart (after Power Failure)	○
	3-D Airflow	—		Self-Diagnosis (Digital, LED) Display	○
	3-Step Airflow (H/P Only)	—		The Remote Controller Loss Prevention with the Chain (Option)	○
"Comfortable Control" Comfort Control	Auto Fan Speed	○	Flexibility	Wiring-Error Check	—
	Silent Operation Control (Automatic)	—		Multi-Split / Split Type Compatible Indoor Unit ★3	○
	Outdoor Unit Silent Operation (Manual)	—		Flexible Voltage Correspondence	—
	Intelligent Eye	—	High Ceiling Application	—	
	Quick Warming Function	—	Chargeless	10m	
	Hot-Start Function	—	Remote Control	5-Rooms Centralized Controller (Option)	○
	Automatic Defrosting	—		Remote Control Adaptor (Option) (Normal Open-Pulse)	○
Operation	Automatic Operation	—		Remote Control Adaptor (Normal Open Contact)	○
	Programme Dry Function	○		DIII-NET Compatible (Adaptor)	—
	Fan Only	○			
Lifestyle Convenience	New Powerful Operation (Non-Inverter)	○	Remote Controller	Wireless	○
	Inverter Powerful Operation	—		Wired	—
	Priority-Room Setting	—			
	Laundry Programme Operation	—			
	Home Leave Operation	—			
	Power Selection	—			
	Indoor Unit On/Off Switch	○			
	Signal Reception Indicator	○			
Temperature Display	—				

Note: ○ : Holding Functions  
— : No Functions

★1 R50-60GAV1A : 19.4°C~46°C  
★2 Apply only for FT50-60GAVAL  
★3 For FT50-60GAVAL : [—]

# Part 2 Specifications

1. Specifications .....	4
1.1 Cooling Only .....	4

# 1. Specifications

## 1.1 Cooling Only

V1 : 50Hz, 220-240V V1A : 50Hz, 220-230-240V

Model	Indoor Units		FT50GAVE	FT50GAVEA		FT60GAVE	FT60GAVEA	
	Outdoor Units		R50GV1(9)	R50GAV1A(9)	R50GV1K(9)	R60GV1(9)	R60GAV1A(9)	R60GV1K(9)
Capacity Rated			kW			5.3		
			Btu/h			18,100		
			kcal/h			4,560		
Moisture Removal			L/h			2.9		
Running Current (Rated)	A		10.1-11.0	10.1-11.2-11.2	10.1-11.0	11.8-11.4	11.8-11.3-11.3	11.8-11.4
Power Consumption (Rated)	W		2,000-2,180	2,000-2,120-2,120	2,000-2,180	2,410-2,500-2,500		
Power Factor	%		90.0-82.6	90.0-82.3-81.1	90.0-82.6	92.8-91.4	92.8-96.2-92.2	92.8-91.4
COP	W/W		2.65-2.43	2.65-2.50-2.50	2.65-2.43	2.66-2.56-2.56		
Piping Connections	Liquid	mm	φ6.4			φ6.4		
	Gas	mm	φ15.9			φ15.9		
	Drain	mm	φ18.0			φ18.0		
Heat Insulation			Both Liquid and Gas Pipes			Both Liquid and Gas Pipes		
Indoor Unit			FT50GAVE	FT50GAVEA		FT60GAVE	FT60GAVEA	
Front Panel Color			Almond White			Almond White		
Air Flow Rate	m <sup>3</sup> /min (cfm)	H	14.0 (494)			14.0 (494)		
		M	12.0 (424)			12.4 (438)		
		L	10.0 (353)			10.8 (381)		
Fan	Type	Cross Flow Fan			Cross Flow Fan			
	Motor Output	W	54			54		
	Speed	Steps	5 Steps and Auto			5 Steps and Auto		
Air Direction Control			Right, Left, Horizontal and Downward			Right, Left, Horizontal and Downward		
Air Filter			Removal-Washable-Mildew Proof			Removal-Washable-Mildew Proof		
Running Current (Rated)	A		0.19-0.18-0.17			0.19-0.18-0.17		
Power Consumption (Rated)	W		40			40		
Power Factor	%		95.7-96.6-98.0			95.7-96.6-98.0		
Temperature Control			Microcomputer Control			Microcomputer Control		
Dimension (HxWxD)	mm		298x1,050x190			298x1,050x190		
Packaged Dimension	mm		1,183x367x289			1,183x367x289		
Weight	kg		12			12		
Gross Weight	kg		16			16		
Operation Sound	H/M/L	dBA	43/39/35			46/42/38		
Outdoor Unit			R50GV1	R50GAV1A	R50GV1K(9)	R60GV1	R60GAV1A	R60GV1K(9)
Casing Color			Ivory White			Ivory White		
Compressor	Type	Hermetically Sealed Rotary Type			Hermetically Sealed Rotary Type			
	Model	RC70AV1TRT			NH41VMDT			
Refrigerant Oil	Motor Output	W	1,700			2,200		
	Type	SUNISO 4GSD.I.			MS-32			
Refrigerant	Charge	L	0.85			1.20		
	Type	R22			R22			
Air Flow Rate	Charge	kg	1.10	1.20	1.10	1.50		
	m <sup>3</sup> /min (cfm)	H	29-29.5-30 (1,024-1,041-1,059)			40-40.5-41 (1,412-1,430-1,447)		
Fan	L	—			23-24-25 (812-847-883)			
	Type	Propeller			Propeller			
Running Current (Rated)	Motor Output	W	45			53		
	A	9.91-10.83	9.91-11.02-11.03	9.91-10.83	11.61-11.23	11.61-11.12-11.13	11.61-11.23	
Power Consumption (Rated)	W	1,960-2,140	1,960-2,080-2,080	1,960-2,140	2,370-2,460-2,460			
Power Factor	%	89.9-82.3	90.0-82.1-78.6	90.0-82.3	92.8-91.3	92.8-96.2-92.1	92.8-91.3	
Starting Current	A	43-47	43-44-45	43-45	55-58-60			
Dimensions (HxWxD)	mm		540x750x270			685x800x300		
Packaged Dimension	mm		940x360x609			955x390x732		
Weight	kg		42			61		
Gross Weight	kg		45			66		
Operation Sound	dBA		49-50-50			54-55-55		
Drawing No.			3D029060	3D028525	3D029102	3D029061	3D028526	3D029103

**Notes:**

- MAX. interunit piping length: 30m
- MAX. interunit height difference: 15m
- Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
- The data are based on the conditions shows in the table below.

FT50/60GAVE (220V)

Standard	Cooling	Piping Length
JIS C 9612	Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	5m

FT50/60GAVEA (230/240V)

Standard	Cooling	Piping Length	Power Source
AS/NZS3823, 1	Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	7.5m	50Hz 230/240V

Conversion Formulae

$$\begin{aligned} \text{kcal/h} &= \text{kW} \times 860 \\ \text{Btu/h} &= \text{kW} \times 3414 \\ \text{cfm} &= \text{m}^3/\text{min} \times 35.3 \end{aligned}$$

60Hz, 200V

Model	Indoor Units		FT50GAVAL		FT60GAVAL		
	Outdoor Units		R50GVAL(9)		R60GVAL(9)		
Capacity Rated	kW		5.6		6.8		
	Btu/h		19,100		23,200		
	kcal/h		4,800		5,850		
Capacity (SSA-385/386)	kW		4.5		5.6		
	Btu/h		15,400		19,100		
	kcal/h		3,900		4,800		
Moisture Removal		L/h	2.9		5.2		
Running Current (Rated) [JIS/SSA]		A	10.5/12.0		12.8/14.7		
Power Consumption (Rated) [JIS/SSA]		W	2,180/2,500		2,680/3,060		
Power Factor [JIS/SSA]		%	94.4/94.7		95.2/94.6		
COP [JIS/SSA]		W/W	2.57/1.80		2.54/1.83		
Piping Connections	Liquid	mm	φ6.4		φ6.4		
	Gas	mm	φ15.9		φ15.9		
	Drain	mm	φ18.0		φ18.0		
Heat Insulation		Both Liquid and Gas Pipes				Both Liquid and Gas Pipes	
Indoor Unit		FT50GAVAL		FT60GAVAL			
Front Panel Color		Almond White		Almond White			
Air Flow Rate	m <sup>3</sup> /min (cfm)	H	12.9 (455)		14.0 (494)		
		M	11.5 (406)		12.4 (438)		
		L	10.0 (353)		10.8 (381)		
Fan	Type	Cross Flow Fan		Cross Flow Fan			
	Motor Output	W	54		54		
	Speed	Steps	5 Steps and Auto		5 Steps and Auto		
Air Direction Control		Right, Left, Horizontal and Downward				Right, Left, Horizontal and Downward	
Air Filter		Removal-Washable				Removal-Washable	
Running Current (Rated) [JIS/SSA]		A	0.14/0.14		0.19/0.19		
Power Consumption (Rated) [JIS/SSA]		W	30/30		40/40		
Power Factor [JIS/SSA]		%	97.4/97.4		95.7/95.7		
Temperature Control		Microcomputer Control				Microcomputer Control	
Dimension (HxWxD)		mm	298x1,050x190		298x1,050x190		
Packaged Dimension		mm	1,183x367x289		1,183x367x289		
Weight		kg	12		12		
Gross Weight		kg	16		16		
Operation Sound	H/ML	dBA	41/38/34		46/42/38		
Outdoor Unit		R50GVAL(9)		R60GVAL(9)			
Casing Color		Ivory White				Ivory White	
Compressor	Type	Hermetically Sealed Rotary Type				Hermetically Sealed Rotary Type	
	Model	RC60VHTNRT				RC75VHTR2T	
	Motor Output	W	1,500		1,800		
Refrigerant Oil	Type	SUNISO 4GSD.I.				SUNISO 4GSD.I.	
	Charge	L	0.85		1.0		
Refrigerant	Type	R22				R22	
	Charge	kg	1.15		1.6		
Air Flow Rate	m <sup>3</sup> /min (cfm)	H	30 (1,059)		44 (1,553)		
Fan	Type	Propeller				Propeller	
	Motor Output	W	45		53		
Running Current (Rated) [JIS/SSA]		A	10.36/11.86		12.61/14.51		
Power Consumption (Rated) [JIS/SSA]		W	2,150/2,470		2640/3020		
Power Factor [JIS/SSA]		%	94.3/94.7		95.2/94.6		
Starting Current		A	43		53		
Dimensions (HxWxD)		mm	540x750x270		685x800x300		
Packaged Dimension		mm	940x360x609		955x390x732		
Weight		kg	41		51		
Gross Weight		kg	45		56		
Operation Sound		dBA	52		55		
Drawing No.		3D029062		3D029063			

**Notes:**

- MAX. interunit piping length: 30m
- MAX. interunit height difference: 15m
- Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
- The data are based on the conditions shows in the table below.

Standard	Cooling	Piping Length
JIS C 9612	Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	5m
SSA-385/386	Indoor ; 29°CDB/19°CWB Outdoor ; 46°CDB/24°CWB	7.5m

- Operative up to 54°C.

**Conversion Formulae**

$$\begin{aligned} \text{kcal/h} &= \text{kW} \times 860 \\ \text{Btu/h} &= \text{kW} \times 3414 \\ \text{cfm} &= \text{m}^3/\text{min} \times 35.3 \end{aligned}$$



# Part 3 Printed Circuit Board Connector Wiring Diagram

1. Printed Circuit Board Connector Wiring Diagram and Name .....	8
1.1 FT50/60GAVE , FT50/60GAVEA , FT50/60GAVAL .....	8

# 1. Printed Circuit Board Connector Wiring Diagram and Name

## 1.1 FT50/60GAVE , FT50/60GAVEA , FT50/60GAVAL

Printed Circuit Board (1) (Control PCB)

Printed Circuit Board (2) (Powers Supply PCB)

Printed Circuit Board (3) (Receiver Sensor PCB)

Printed Circuit Board (4) (Display PCB)

### Name of Connector

#### Printed Circuit Board (1) (Control PCB)

- |        |   |
|--------|---|
| 1) S6  | : Connector for swing motor (Vertical Flap) |
| 2) S7  | : Connector for fan motor (Hall IC output)  |
| 3) S21 | : Connector for Home Automation             |
| 4) S24 | : Connector for Display PCB                 |
| 5) S26 | : Connector for Receiver Sensor PCB         |
| 6) S32 | : Connector for heat exchange thermistor    |
| 7) S37 | : Connector for Power Supply PCB            |

#### Printed Circuit Board (2) (Power Supply PCB)

- |         |                             |
|---------|-----------------------------|
| 1) S36  | : Connector for Control PCB |
| 2) S201 | : Connector for fan motor   |

#### Printed Circuit Board (3) (Receiver Sensor PCB)

- |        |                             |
|--------|-----------------------------|
| 1) S27 | : Connector for Control PCB |
| 2) S31 | : Connector for thermistor  |

#### Printed Circuit Board (4) (Display PCB)

- |        |                             |
|--------|-----------------------------|
| 1) S25 | : Connector for Control PCB |
|--------|-----------------------------|



#### Note:

Other Designations

#### Printed Circuit Board (1) (Control PCB)

- |        |  |
|--------|--|
| 1) JA  | : ADDRESS SETTING JAMPER                                 |
| JB     | : Fan speed setting when compressor is OFF on thermistor |
| JC     | : Power failure recovery function                        |
| 2) SW8 | : Filter cleaning indicator reset switch                 |
| 3) BZ  | : Buzzer   |

#### Printed Circuit Board (2) (Power Supply PCB)

- |        |                       |
|--------|-----------------------|
| 1) V1  | : Varistor            |
| 2) FU1 | : Fuse (AC250V 3.15A) |


#### Printed Circuit Board (3) (Receiver Sensor PCB)

- |        |                           |
|--------|---------------------------|
| 1) SW7 | : OPERATION SWITCH        |
| 2) WLU | : Infrared receiving unit |


#### Printed Circuit Board (4) (Display PCB)

- |         |                                     |
|---------|-------------------------------------|
| 1) LED3 | : LED for operation                 |
| 2) LED4 | : LED for timer                     |
| 3) LED5 | : LED for filter cleaning indicator |

**Printed Circuit Board (1) (Control PCB)**




**Printed Circuit Board (2) (Power Supply PCB)**




**Printed Circuit Board (3), (4) (Receiver Sensor and Display PCB)**

Receiver Sensor PCB




Display PCB




(R2005)

PCB (1)




C : 2P058884H

PCB (2)




C : 2P058885C

PCB (3)



C : 3P005575C

PCB (4)



# Part 4

# Main Function


1. General Functionality .....	12
1.1 General Functionality .....	12

# 1. General Functionality

## 1.1 General Functionality

### 1.1.1 Cooling Monitoring Function

Monitoring function is activated while cooling and program dry operation are suspended.



(R1882)

ToF: Compressor recycling guard timer (3-minute timer)

TM1: 5-minute timer

TM2: 4-minute timer

⟨A⟩ At cooling: Temperature set by wireless remote controller

At program dry operation: Temperature at suspension

⟨B⟩ Temperature set by wireless remote controller +1 deg. (Cooling operation)

Temperature set (Program dry operation)

Even if the suction temperature remains in the differential range, a compressor is cycled ON and OFF.

DETAIL: When the suction temperature rises again to ⟨A⟩ (point b) after the suction temperature is dropped to ⟨A⟩ and the compressor turns OFF (point a) the 5-minute timer starts.

After that, when the suction temperature is within the differential range, even after a lapse of 5 minutes, the compressor is forced to turn ON (point c).

When the suction temperature is still in the differential range, after another 4 minutes of compressor ON, the compressor is forced to turn OFF (point d).

The 5 and 4-minute timers are effective only within the differential temperature range, and when the air suction temperature is reached to ⟨B⟩ or ⟨A⟩ while the timers are counting, timers are reset and the compressor is turned ON or OFF.

(Note, however, that function of placing the compressor in a 3-minute compressor recycling guard timer is provided at point e.)

While the compressor is OFF, the indoor fan operation is controlled by tap A during cooling mode.

In the program dry mode, the indoor fan starts operating five seconds after the compression starts, and it stops operating when the compressor shuts down.

	A
FT50 / 60GA Series	Remote controller setting

### 1.1.2 Program Dry Operation


By the function of the microcomputer, program dry operation reduces the humidity keeping the temperature in a minimum drop. Room temperature and air volume can not be controlled by room temperature adjusting button and air volume adjusting button because they are controlled automatically. When the program dry function starts, dry operation is provided, and then it repeats 6-minute suspension and 4-minute dry operation alternately. When the room temperature rises, it repeats the above process from the beginning.

Room temperature at starting of program dry operation	Program dry activating temperature *1	Differential *2
Above 24°C	Room temperature at starting of program dry operation	1.5 deg
18°C ~ 24°C	Room temperature at starting of program dry operation	1.0 deg
Bellow 18°C	18°C	1.0 deg


\*1 Dry operation activating (compressor on) temperature

\*2 Room temperature difference between activation and suspension of dry operation

Program dry operating condition



- Note:**
1. The program dry function is not operated when the room temperature is at 18°C or less.
  2. In monitoring operation, fan rotates 5 seconds after the compressor starts its operation.



(R2008)

### 1.1.3 Freeze Protection Function


When the indoor heat exchanger temperature falls below “A” °C in cooling or program dry operation,

- the compressor and the outdoor fan are forced to turn OFF, and
- the indoor fan rotates at the L tap (in cooling operation) or W2 tap (in program dry operation).

Note that this function is not activated for 6 minutes after compressor turns ON.

When the indoor heat exchanger reaches “B” °C, the compressor and the outdoor fan restart the operations. However, because the compressor recycling guard timer (3-minute timer) takes priority, the compressor and the outdoor fan don't restart the operation during this timer is ON.


	A	B	W2
FT50 / 60GA Series	3	13	LL



(R1883)

### 1.1.4 Dew Condensation Protection Function

When the cumulative time of the cooling or program dry operation with the temperature of the indoor unit heat exchanger below the preset temperature (7°C) for dew condensation protection function reaches 30 minutes, the dew condensation protection function activates. When the dew condensation protection function turns on, the flap moves to the dew condensation protection flap position, and the lower-limit value of the indoor fan rotation speed rises by 10 rpm every three minutes (L tap + 100 rpm as the upper limit of the lower-limit setting). If the flap angle is changed during this process, the flap remains in that position for 30 minutes, then moves to the dew condensation protection flap position. When the operation stops, or when the unit operates in a mode other than the cooling and program dry modes for 30 continuous minutes, the dew condensation protection function is canceled.




### 1.1.5 Timer Function

Refer to "Timer Operation" on page 31.


### 1.1.6 Auto-fan Speed

In cooling operation, if automatic airflow has been selected, the wind flow is determined according to the room temperature and the temperature setting.



### 1.1.7 Auto-swing of Flaps

Auto-swing angles are about "A" degrees when the fan is ON, and about "B" degrees when the cooling or program dry operation is ON. The up-and-down swing of the flaps widens the direction of wind.




**Notes on flap angles**

- The diffuser is kept open in DRY, COOL or FAN mode.

Fan, cooling, dry operation

	A	B
FT50, 60GA Series	20°	15° ↔ 40°



5° (15°) DRY-COOL  
25° (40°) FAN

**NOTE**

Unless [SWING] is selected, you should set the flap at a near-horizontal angle in COOL or DRY mode to obtain the best performance.

(R2368)

### 1.1.8 3-minutes Standby Function

When the compressor turns OFF, it doesn't turn ON for 3 minutes.

### 1.1.9 ON-OFF Operation from the Unit

The unit can be turned ON from the switch on the front panel. This is handy when the remote controller cannot be found or if the batteries are dead.

Pressing the switch again will turn the unit OFF.

When turned ON from the unit itself, the unit runs as follows.

Operation mode	Cool
Fan speed	Auto
Set temperature	22°C

### 1.1.10 Auto-restart Function

If there is a power cut when the unit is operating, it will automatically resume the same operating mode when the power is restored.



**Note:**

It takes 3 minutes to restart the operation because the 3-minute standby function is activated.


#### Store Data

- 
- Power ON/OFF
  - Operation mode
  - Set temperature
  - Fan operation mode
  - Swing ON/OFF
  - Flap angle
  - ON/OFF Timer

### 1.1.11 Night Set Mode

This mode automatically keeps temperature slightly higher than the temperature setting. In this way, there is no need to worry about overcooling while sleeping, and it also saves on electricity.

- Set the OFF timer.
- The unit will cool the room at the set temperature for 1 hour from when the timer starts counting.
- After that, the unit will raise temperature 0.5°C higher than the set temperature and cool for 30 minutes.
- After that, the unit will raise temperature another 0.5°C and continue cooling at that temperature.
- Setting the OFF timer forcibly changes the airflow adjustment to the tap-L setting.
- It is possible to change the airflow setting while the OFF timer is in operation. However, changing the airflow setting cancels the shift-up of the set temperature.



(R1885)




**Notes:** No higher temperature setting on program dry or auto operation.

### 1.1.12 Test Run Function

A compressor test run can be made regardless of room temperature and without turning the compressor ON-OFF from the thermistor.

The compressor can be turned ON for A minutes in either the cool or dry mode, even though the compressor is OFF on the thermostat. This is done by setting the test mode from the remote controller.



(R1886)

Trial operation from Remote Controller	
(1)	Press ON/OFF button to turn on the system.
(2)	Simultaneously press DOWN, UP, and MODE buttons.
(3)	Press MODE button twice. (“T” will appear on the display to indicate that Trial Operation mode is selected.)
(4)	Trial run mode terminates in approx. A minutes and switches into normal mode. To quit a trial operation, press ON/OFF button.

- After trial operation is complete, set the temperature to a normal level (26°C to 28°C).
- For protection, the machine disables restart operation for 3 minutes after it is turned off.

### 1.1.13 Powerful Operation

During cool and program dry operation, when the POWERFUL button on the remote controller is pressed, the thermistor setting is changed to the lowest setting of the remote controller and the fan runs at the maximum rpm (Note). During fan operation, air is blown at the maximum fan rpm.

**Note ... Max. fan rpm = H tap set by remote controller + 50 rpm**



Notes:

- In **COOL mode**  
To maximize the cooling effect, the temperature setting is fixed to 18°C and the air flow rate is fixed to the maximum setting.  
(H tap + 50 r.p.m)  
The temperature and air flow settings are not variable.
- In **DRY mode**  
The temperature setting is lowered by 3°C and the air flow rate is slightly increased. You can repeat POWERFUL operation if you need even more dehumidification.

### 1.1.14 Filter Check Indicator


- **The filter check indicator located at the center of the unit will indicate the time for cleaning the air filters.**

The indicator will indicate an appropriate cleaning time depending on the environment (dusty place or not). This will prevent you from forgetting filter cleaning and also prevent performance drop that might be caused by using clogged filters and wasteful use of electricity by approximately 8%.


**[Contents of indication]**

- **Sensed by the operation hours and the fan motor voltage**

1) Filter clogging (\*)



2) Accumulated operation hours




Indicates the earlier one of the above 1) or 2).

\* This indicator utilizes the characteristic that the fan motor voltage drops as the crossflow fan gets clogged; it does not detects the amount of filter clogging.

**Note:**

- When the power supply is reset, the accumulated operation hour is not reset.
- After cleaning and mounting the filters, press the reset button located inside the panel of the unit.



(R2370)



# Part 5

# System Configuration

1. Instruction .....	22
1.1 FT50 / 60GAVE, FT50 / 60GAVEA, FT50 / 60GAVAL.....	22

# 1. Instruction

## 1.1 FT50 / 60GAVE, FT50 / 60GAVEA, FT50 / 60GAVAL

### Safety Precautions

- Read the following warnings and cautions carefully before operating the system and use it correctly.
- This manual classifies the precautions to the user into two categories on the right. Be sure to follow all as they are all important to ensure safety.
- After reading this manual, keep it in a place easily accessible to the user for future reference.

#### WARNING

- **Do not expose your body to the cool air for a long time, do not cool the room too much.**  
It will affect your physical conditions and cause health problems.
- **Do not put a finger, a rod or other objects into the air outlet or inlet.**  
As the fan is rotating at a high speed, it will cause injury.
- **Do not attempt to repair, relocate, modify or reinstall the air conditioner by yourself.**  
Incorrect work will cause electric shocks, fire etc. For repairs and reinstallation, consult the shop where you bought the air conditioner.
- **If anything abnormal such as a burning smell occurs, stop the operation immediately and turn the breaker OFF.**  
Continued abnormal operation will cause troubles, electric shocks, fire etc. If anything is abnormal, consult the shop where you bought the air conditioner.
- **If the air conditioner is not cooling or heating properly, the refrigerant may be leaking, so see the dealer where the unit was purchased. Check with a qualified repairman before attempting any repairs, which might accompany addition of refrigerant.**  
The refrigerant used in the air conditioner is safe. Although leaks should not occur, if for some reason any refrigerant happens to leak into the room, make sure it does not come in contact with any flame, such as fan heaters, kerosene heaters, or gas ranges, as this may result noxious substances being generated.

#### CAUTION

- **Do not use the air conditioner for preservation purposes.**  
Do not use it for preserving precision instruments, foods, plants, animals, works of fine arts etc. Performance or quality may deteriorate and animal or plant life may be shorter.
- **Do not operate the air conditioner with a wet hand.**  
It may cause an electric shock.
- **Ventilate the room from time to time.**  
Be careful especially when using a burning appliance in the same room. Insufficient ventilation may cause shortage of oxygen.
- **Before cleaning, be sure to stop the operation and turn the breaker OFF.**  
As a fan is rotating at a high speed, cleaning during operation may cause injury.
- **After a long use, check the unit stand and fittings for damage.**  
The unit may drop and cause injury if damage is left unrepaired.
- **Do not stand or sit on the outdoor unit. Do not place any object on the unit.**  
The object or the person may fall down or drop, causing injury.

#### ⚠ WARNING

Failure to follow a warning is very likely to result in such grave consequences as death or serious injury.

#### ⚠ CAUTION

Failure to follow a caution may result in serious injury or property damage, and in certain conditions, may result in a grave consequence.

- ‘ **Do not place under the indoor or outdoor unit anything which must be kept away from moisture.**  
Indoor unit : moisture in the air may condense and drip in certain conditions.  
outdoor unit : during cooling operation, condensation may drip from the piping connections.
- ‘ **Do not wash the unit with water.**  
It may cause an electric shock.
- ‘ **Do not place a burning appliance in places exposed to the air flow from the unit or under the indoor unit.**  
It may cause incomplete combustion or deformation of the unit from heat.
- ‘ **Do not place a vessel containing water on the unit.**  
Water may penetrate into the unit and degrade electrical insulations, resulting in an electric shock.
- ‘ **Do not expose plants or animals directly to the air flow.**  
It may cause adverse effects on the plant or the animal.
- ‘ **Do not block air inlets nor outlets.**  
Impaired air flow may result in insufficient performance or troubles.
- ‘ **Do not allow children to mount on the outdoor unit or avoid placing any object on it.**  
Falling or tumbling may result in injury.

## Installation

### WARNING

- ‘ **Do not attempt to install the air conditioner by yourself.**  
Consult the service shop or a qualified technician.  
Incorrect work will result in water leakage, electric shocks or fire. For installation, consult the service shop where you bought the unit or a qualified technician.
- ‘ **The air conditioner must be earthed.**  
Incomplete earthing may result in electric shocks. Do not connect the earth line to a gas pipe, water pipe, lightning rod, or a telephone earth line.

### CAUTION

- ‘ **Depending on the environment, an earth leakage breaker must be installed.**  
Lack of an earth leakage breaker may result in electric shocks.
- ‘ **Do not install the air conditioner in places where flammable gas may leak.**  
If leaked gas should accumulate near the unit, fire may occur.
- ‘ **Arrange the drain hose to ensure smooth drainage.**  
Incomplete drainage may cause wetting of the building, furniture etc.
- ‘ **Do not connect the air conditioner to a power supply different from the specification.**  
It may cause trouble or fire.

**Installation site**

- › To install the air conditioner in the following types of environments, consult the shop.
  - ‘ Places with an oily ambient or where steam or soot occurs.
  - ‘ Salty environment such as coastal areas.
  - ‘ Places where sulfide gas occurs such as hot springs.
  - ‘ Places where snow may block the outdoor unit.

The drain from the outdoor unit must be discharged to a place of good drainage.

**Consider nuisance to your neighbours from noises**

- › For installation, choose a place as described below.
  - ‘ A place solid enough to bear the weight of the unit which does not amplify the operation noise or vibration.
  - ‘ A place from where the air discharged from the outdoor unit or the operation noise will not annoy your neighbours.

**Electrical work**


- › For power supply, be sure to use a separate power circuit dedicated to the air conditioner.

**System relocation**

- › Relocating the air conditioner requires specialized knowledge and skills. Please consult the shop where you bought the air conditioner if relocation is necessary for moving or remodeling.

Names of Parts


**Indoor unit**



**Opening the front grille**

How to open the front grille: (See Page 8.)

**CAUTION**  
 Before opening the front grille, be sure to stop the operation and turn the breaker OFF. If the power is on, the fan may rotate inside and may cause injury.



**Receiver:**

- It receives signals from the remote controller.
- When the unit receives a signal, you will hear a short beep.

**Room temperature sensor:**

- It senses the air temperature around the unit.


**ON/OFF switch**

- Push this switch once to start operation. Push once again to stop it.
- The operation mode refer to the following table.

	Mode	Temperature setting	Air flow rate
FT	COOL	22°C	AUTO


- This switch is useful when the remote controller is missing.

## Remote controller



<ARC423A18>


## Outdoor unit



## Preparation before Operation

### Remote controller

#### > Setting the batteries



- 1** Press  with a finger and slide the front cover to take it off.
- 2** Set two dry batteries (AAA).
- 3** Set the front cover as before.
  - This will cause the figures on the display to flash. Set the clock at this point.


### ATTENTION

#### About batteries

- When replacing the batteries, use batteries of the same type, and replace the two old batteries together.
- When the system is not used for a long time, take the batteries out.
- When the operation display screen of the remote controller is hard to see and the reception become hard, replace the batteries with new AAA batteries.
- The attached batteries are provided for the initial use of the system. The usable period of the batteries may be short depending on the manufactured date of the air conditioner.


#### > Operating the remote controller

- To use the remote controller, aim the transmitter at the indoor unit. If there is anything to block signals between the unit and the remote controller, such as a curtain, the unit will not operate.
- Do not drop the remote controller. Do not get it wet.
- The maximum distance for communication is about 7 m.



#### > To fix the remote controller holder on the wall

- 1** Choose a place from where the signals reach the unit.
- 2** Fix the holder to a wall, a pillar, etc. with the screws supplied with the holder.
- 3** Place the remote control in the remote control holder.



- To remove, pull it upwards

### ATTENTION

#### About the remote controller


- Never expose the remote controller to direct sunlight.
- Dust on the signal transmitter or receiver will reduce the sensitivity. Wipe off dust with soft cloth.
- Signal communication may be disabled if an electronic-starter-type fluorescent lamp (such as inverter-type lamps) is in the room. Consult the shop if that is the case.
- If the remote control signals happen to operate another appliance, move that appliance to somewhere else, or consult the shop.

## Indoor unit

### > Setting the air purifying filters


#### 1 Open the front grille.

- Hold the grille by the tabs on the two sides and lift it until it stops with a click. (about 60°)



#### 2 Pull out the air filters.

- Push upwards the tab at the center of each air filter, then pull it down.



#### 3 Set the air purifying filters.


- Attach an air purifying filter to each air filter. (See page 12 "Care and cleaning")

#### 4 Set the air filters in their original positions and close the front grille.

- Operation without air filters may result in troubles as dust will accumulate inside the indoor unit.

### > Setting the clock

#### 1 Press




#### 2 Press to set the clock to the present time.



- Holding down () or () button rapidly increases or decreases the time display.

#### 3 Press



### > Turn the breaker ON

- Turning ON the breaker opens the flap, then closes it again. (This is a normal procedure.)

## NOTE

### Tips for saving energy

- Be careful not to cool the room too much. Keeping the temperature setting at a moderate level helps save energy.

#### Recommended temperature setting

For cooling: 26°C – 28°C

- Cover windows with a blind or a curtain. Blocking sunlight and air from outdoors increases the cooling effect.
- Clogged air filters cause inefficient operation and waste energy. Clean them once in about every two weeks.

### Please note


- The air conditioner always consumes 15 – 35 watts of electricity even while it is not operating.
- If you are not going to use the air conditioner for a long period, for example in spring or autumn, turn the breaker OFF.
- Use the air conditioner in the following conditions.

Mode	Operating conditions	If operation is continued out of this range
COOL	Outdoor temperature : 19 to 46 °C Indoor temperature : 18 to 32 °C Indoor humidity : 80% max.	<ul style="list-style-type: none"> <li>A safety device may work to stop the operation. (In multi system, it may work to stop the operation of the outdoor unit only.)</li> <li>Condensation may occur on the indoor unit and drip.</li> </ul>
DRY	Outdoor temperature : 21 to 46 °C Indoor temperature : 18 to 32 °C Indoor humidity : 80% max.	<ul style="list-style-type: none"> <li>A safety device may work to stop the operation.</li> <li>Condensation may occur on the indoor unit and drip.</li> </ul>

**DRY · COOL · FAN Operation**  
**Adjusting the Air Flow Direction**

The air conditioner operates with the settings of your choice. From the next time on, the air conditioner will operate with the same settings.


**1** Press **MODE** and select a mode.



Each pressing of the button advances the mode setting in sequence.



**2** Press **ON/OFF**.



Then OPERATION lamp lights up.

> **To stop:**

Press **ON/OFF** once again.

Then OPERATION lamp goes off.

> **To change the temperature setting:**

DRY or FAN mode	COOL mode
The temperature setting is not variable.	Press  to raise / lower the temperature.
	Set to the temperature you like.

> **To change the air flow rate setting:**

Press **FAN**.

DRY or FAN mode	COOL mode
The air flow rate setting is not variable.	Five levels of air flow rate setting from “” to “” plus “” are available.

At smaller air flow rates, cooling or heating effect is also smaller.

> **To change the air flow direction:**  
 (See page 9.)

You can adjust the air flow direction to increase your comfort.

**Adjusting the horizontal blade (flap)**

Press **SWING**.


Every time the button is pressed, “” appears or disappears.

..... The flap automatically swings up and down.

..... To stop the flap at an angle you like, press **SWING**.

**Notes on flap angles**


- When **SWING** is selected, the flap swinging range depends on the operation mode. (See the figure.)
- The real flap angles are differ from the display of remote controller.



**ATTENTION**

Always use a remote controller to adjust the flap angle. If you attempt to move it forcibly with hand when it is swinging, the mechanism may be broken.

**Adjusting the vertical blade (louvre)**



Hold the knob and move the louvre. (You will find a knob on the left-side and the right-side blades.)

**ATTENTION**


Be careful when adjusting the louvre. Inside the air outlet, a fan is rotating at a high speed.

## Powerful Operation

POWERFUL operation quickly maximizes the cooling effect in any operation mode. You can get the maximum capacity with a touch of a button.

- Pressing the (POWERFUL) button during operation starts POWERFUL operation.
- POWERFUL operation ends in 20 minutes. Then the system automatically operates again with the settings which were used before POWERFUL operation.
- During you use "POWERFUL operation", the other functions will not go on.

**1** Press  .



› **To cancel POWERFUL operation:**

Press  .

### Notes on POWERFUL operation

- **In COOL mode**  
To maximize the cooling effect, the capacity of outdoor unit must be increased and the air flow rate be fixed to the maximum setting. The temperature and air flow settings are not variable.
- **In DRY mode**  
The temperature setting is lowered by 3°C and the air flow rate is slightly increased.
- **In FAN mode**  
The air flow rate is fixed to the maximum setting.


**Timer Operation**

Timer functions are useful for automatically switching the air conditioner on or off at night or in the morning. You can also use OFF TIMER and ON TIMER in combination.

**OFF TIMER operation**

Check that the clock is correct. If not, set the clock to the present time. (See page 8.)

1 Press **OFF** while the air conditioner is operating.




\* Previous time setting appears on display.

2 Press **TIMER** until the time setting reaches the point you like.

Every pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.

3 Press **OFF** once again.



Then the TIMER lamp lights up.

> **To cancel the timer:**

Press **CANCEL**.

Then the TIMER lamp goes off.


**Notes on OFF TIMER**

**NIGHT SET MODE**  
When the OFF TIMER is set, the air conditioner automatically adjusts the temperature setting (0.5°C up in COOL) to prevent excessive cooling for your pleasant sleep.

**ON TIMER operation**

Check that the clock is correct. If not, set the clock to the present time. (See page 8.)

1 Press **ON** while the air conditioner is not operating.




\* Previous time setting appears on display.

2 Press **TIMER** until the time setting reaches the point you like.

Every pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.

3 Press **ON** once again.



Then the TIMER lamp lights up.

**Combining ON TIMER and OFF TIMER**

A sample setting for combining the two timers is shown below.

(Example)

Present time: 11:00 PM  
(The unit operating)  
OFF TIMER at 0:00 a.m. ) Combined  
ON TIMER at 7:00 a.m.



**Notes on ON,OFF TIMER**

- When TIMER is set, the present time is not displayed.
- Once you set ON,OFF TIMER, the time setting is kept in the memory. (The memory is canceled when remote controller batteries are replaced.)
- When operating the unit via the ON/OFF Timer, the actual length of operation may vary from the time entered by the user. (Maximum approx. 10 minutes.)

**ATTENTION**

- In the following cases, set the timer again.
  - After a breaker has turned OFF.
  - After a power failure.
  - After replacing batteries in the remote controller.


Care and Cleaning

**CAUTION**  
 Before cleaning, be sure to stop the operation and turn the breaker OFF.


**Cleaning the air filters**

(It is recommended to clean them every two weeks.)


- 1 Open the front grille.**  
 Hold the grille by the tabs on the two sides and lift it until it stops with a click. (about 60°)




- 2 Pull out the air filters.**  
 Push a little upwards the tab at the center of each air filter, the pull it down.



- 3 Take off the air purifying filters and clean them.**  
 Wash them with water, or clean them with a vacuum cleaner.  
 If the dust does not come off easily, wash them with neutral detergent thinned with lukewarm water, then dry them up in the shade.



- 4 Set the air purifying filters and the air filters as they were and close the front grille.**



- Insert claws of the filters into slots of the front panel. The front grille should lock at both sides and at the point in the middle. Push the grille at the 4 points indicated by ↓.

**NOTE**  
 In a dusty environment, clean the air filters at least once in every two weeks.  
 Operation with dusty air filters lowers the cooling capacity and wastes energy.

**Cleaning the indoor and outdoor units and the remote controller**

- Wipe them with dry soft cloth.  
 For cleaning, do not use water hotter than 40°C, benzine, gasoline, thinner, nor other volatile oils, polishing compound, scrubbing brushes nor other hard stuff.

**Replacing air purifying filters**



(It is recommended to replace them every three months.)

- Air purifying filters need to be replaced regularly.

- 1 Open the front grille and pull out the air filters.**
- 2 Take off the air purifying filters.**
- 3 Detach the filter element and attach a new one.**


Air purifying filter frame

Air filter



- Hold the recessed parts of the frame and unhook the four claws.

- 4 Attach the air purifying filter.**
- 5 Set the air filters as they were and close the front grille.**



(Push the grille at the 4 points, two at both sides and in the middle.)

**NOTE**  
 To order air purifying filters, contact the service shop where you bought the air conditioner.  
 Once the air purifying filter element gets dirty, it is not reusable but must be thrown away.  
 Operation with dirty air purifying filters :  
 • cannot clean the air.  
 • results in poor cooling.  
 • may cause odour.

Item	Part No.
Air purifying filter (with frame)	KAF918A41
Air purifying filter (without frame)	KAF918A42

## Cleaning the front grille

You may remove the front grille for cleaning.




### CAUTION

- When removing or attaching the front grille, use a robust and stable stool and watch your steps carefully.
- When removing or attaching the front grille, support the grille securely with hand to prevent it from falling.
- For cleaning, do not use water hotter than 40°C, benzene, gasoline, thinner, nor other volatile oils, polishing compound, scrubbing brushes nor othe hard stuff.
- After cleaning, make sure that the front grille is securely fixed.


### 1 Open the front grille.

- Hold the grille by the tabs on the two sides and lift it until it stops with a click.



### 2 Remove the front grille.

- Supporting the front grille with one hand, release the lock by sliding down the knob with the other hand.
- To remove the front grille, pull it toward yourself with both hands.





### 3 Clean the front grille.

- You may wipe it with a soft cloth soaked in water.
- Only neutral detergent may be used.
- You may wash the grille with water. After washing, dry it with cloth, then dry it up in the shade.

### 4 Attach the front grille.

- Set the 3 keys of the front grille into the slots and push them in all the way.
- Supporting the front grille with one hand, fit the lock by sliding up the knob with the other hand.
- Close the front grille slowly in this state. (Push the grille at the 3 points, two at both sides and in the middle.)



## Check

Check that the base, stand and other fittings of the outdoor unit are not decayed or corroded.

Check that nothing blocks the air inlets and the outlets of the indoor unit and the outdoor unit.

Check that the earth wire is not disconnected or broken.

Check that the drain comes smoothly out of the drain hose during COOL or DRY operation.

- If no drain water is seen, water may be leaking from the indoor unit. Stop operation and consult the service shop if this is the case.

## Before a long idle period

1 Operate the fan alone for several hours on a fine day to dry out the inside.

1 Press **MODE** and select “”.

2 Press .

- 2 Clean the air filters and set them again.
- 3 Take out batteries from the remote controller.
- 4 Turn OFF the breaker for the room air conditioner.

**Trouble Shooting**

‘ **These cases are not troubles.**

The following cases are not air conditioner troubles but have some reasons. You may just continue using it.

<b>Case</b>	<b>Explanation</b>
<p><b>Operation does not start soon.</b>                      ‘ <b>When ON/OFF button was pressed soon after operation was stopped.</b>                      ‘ <b>When the mode was reselected.</b></p>	<p>‘ This is to protect the air conditioner.                      You should wait for about 3 minutes.</p>
<p><b>The outdoor unit emits water or steam.</b></p>	<p>› In COOL or DRY mode                      ● Moisture in the air condenses into water on the cool surface of outdoor unit piping and drips.</p>
<p><b>Mists come out of the indoor unit.</b></p>	<p>› This happens when the air in the room is cooled into mist by the cold air flow during cooling operation.</p>
<p><b>The indoor unit gives out odour.</b></p>	<p>› This happens when smells of the room, furniture, or cigarettes are absorbed into the unit and discharged with the air flow.                      (If this happens, we recommend you to have the indoor unit washed by a technician. Consult the service shop where you bought the air conditioner.)</p>
<p><b>The outdoor fan rotates while the air conditioner is not in operation.</b></p>	<p>› After operation is stopped:                      ● The outdoor fan continues rotating for another 60 seconds for system protection.                      › While the air conditioner is not in operation:                      ● When the outdoor temperature is very high, the out door fan starts rotating for system protection.</p>
<p><b>The operation stopped suddenly. (OPERATION lamp is on)</b></p>	<p>› For system protection, the air conditioner may stop operating on a sudden large voltage fluctuation. It automatically resumes operation in about 3 minutes.</p>

‘ **Check again**

Please check again before calling a repair person.

<b>Case</b>	<b>Check</b>
<b>The air conditioner does not operate. (OPERATION lamp is off)</b>	<ul style="list-style-type: none"> <li>‘ Hasn't a breaker turned OFF or a fuse blown?</li> <li>‘ Isn't it a power failure?</li> <li>‘ Are batteries set in the remote controller?</li> <li>‘ Is the timer setting correct?</li> </ul>
<b>Cooling effect is poor.</b>	<ul style="list-style-type: none"> <li>‘ Are the air filters clean?</li> <li>‘ Is there anything to block the air inlet or the outlet of the indoor and the outdoor units?</li> <li>‘ Is the temperature setting appropriate?</li> <li>‘ Are the windows and doors closed?</li> <li>‘ Are the air flow rate and the air direction set appropriately?</li> </ul>
<b>Operation stops suddenly. (OPERATION lamp blinks.)</b>	<ul style="list-style-type: none"> <li>‘ Are the air filters clean?</li> <li>‘ Is there anything to block the air inlet or the outlet of the indoor and the outdoor units?</li> </ul> <p>Clean the air filters or take all obstacles away and turn the breaker OFF. Then turn it ON again and try operating the air conditioner with the remote controller. If the lamp still blinks, call the service shop where you bought the air conditioner.</p>
<b>An abnormal functioning happens during operation.</b>	<ul style="list-style-type: none"> <li>‘ The air conditioner may malfunction with lightening or radio waves. Turn the breaker OFF, turn it ON again and try operating the air conditioner with the remote controller.</li> </ul>

• **Call the service shop immediately.**

**⚠ WARNING**

- › When an abnormality (such as a burning smell) occurs, stop operation and turn the breaker OFF.  
Continued operation in an abnormal condition may result in troubles, electric shocks or fire.  
Consult the service shop where you bought the air conditioner.
- › Do not attempt to repair or modify the air conditioner by yourself.  
Incorrect work may result in electric shocks or fire.  
Consult the service shop where you bought the air conditioner.

If one of the following symptoms takes place, call the service shop immediately.

- › **The power cord is abnormally hot or damaged.**
- › **An abnormal sound is heard during operation.**
- › **The safety breaker, a fuse, or the earth leakage breaker cuts off the operation frequently.**
- › **A switch or a button often fails to work properly.**
- › **There is a burning smell.**
- › **Water leaks from the indoor unit.**

Turn the breaker OFF and call the service shop.

› **After a power failure**  
The air conditioner automatically resumes operation in about three minutes. You should just wait for a while.

› **Lightening**  
If lightening may strike the neighbouring area, stop operation and turn the breaker OFF for system protection.

**We recommend periodical maintenance**

In certain operating conditions, the inside of the air conditioner may get foul after several seasons of use, resulting in poor performance. It is recommended to have periodical maintenance by a specialist aside from regular cleaning by the user. For specialist maintenance, contact the service shop where you bought the air conditioner.  
The maintenance cost must be born by the user.

# Part 6

## Service Diagnosis

1. Caution for Diagnosis.....	38
1.1 Troubleshooting with The Operation Lamp .....	38
2. Problem Symptoms and Measures .....	39
2.1 General Check .....	39
2.2 Troubleshooting (Fault Diagnosis and Countermeasure).....	40
3. Service Check Function .....	44
3.1 Remote Controller Display .....	44
4. Troubleshooting by Indication on the Remote Controller .....	45
4.1 Indoor Units .....	45
4.2 Faulty PCB .....	46
4.3 Freeze-Up Protection (Thermistor Activation) .....	47
4.4 Operation Halt Due to Fan Motor (AC Motor) or Related Abnormality .....	48
4.5 Operation Halt Due to Detection of Thermistor or Related Abnormality .....	49
4.6 Faulty Indoor Unit PCB.....	50
5. Check .....	51
5.1 How to Check.....	51

# 1. Caution for Diagnosis


## 1.1 Troubleshooting with The Operation Lamp

The Operation lamp flashes when any of the following errors is detected.

When a protection device of the indoor or outdoor unit is activated or when the thermistor malfunctions, disabling equipment operation.

### 1.1.1 Location of Operation Lamp

FT50 / 60GAVE  
FT50 / 60GAVEA  
FT50 / 60GAVAL



(R2015)

## 2. Problem Symptoms and Measures


### 2.1 General Check

Problem Symptom	Check Item	Details of Measure	Page No. to be referred
None of The Units Operates.	Check the power supply.	Check to make sure that the rated voltage is supplied.	—
	Check the type of the indoor units.	Check to make sure that the indoor unit type is compatible with the outdoor unit.	—
	Check the outside air temperature.	Operation cannot be used when the outside temperature is below 19.4 °C.	—
	Diagnosis with remote controller indication	—	45
	Check the remote controller addresses.	Check to make sure that address settings for the remote controller and indoor unit are correct.	—
Operation Sometimes Stops.	Check the power supply.	A power failure of 2 to 10 cycles can stop air conditioner operation. (Operation lamp OFF)	—
	Check the outside air temperature.	Operation cannot be used when the outside temperature is below 19.4°C.	—
	Diagnosis with remote controller indication	—	45
Some indoor units do not operate.	Check the type of the indoor units.	Check to make sure that the indoor unit type is compatible with the outdoor unit.	—
	Diagnosis with remote controller indication	—	45
Equipment operates but does not cool, or does not heat (only for heat pump model).	Check for thermistor detection errors.	Check to make sure that the main unit's thermistor has not dismantled from the pipe holder.	—
	Diagnosis with remote controller indication	—	45
	Diagnosis by service port pressure and operating current	Check for insufficient gas.	—
Large Operating Noise and Vibrations	Check the installation condition.	Check to make sure that the required spaces for installation (specified in the Engineering data, etc.) are provided.	—

## 2.2 Troubleshooting (Fault Diagnosis and Countermeasure)


### Case 1

Phenomenon : **Air conditioner does not operate.**



### Case 2

Phenomenon : **Air conditioner does not operate with wireless remote controller.**




\* Indoor unit has emergency operation switch.

(R1979)


### Case 3

Phenomenon : **Air conditioner does not operate, and LED for operation blinks.**



Case 4

Air conditioner does not operate, and LED for operation blinks.



\* 1 Hall IC should be checked with power on, operation off and connectors connected.


CONNECTION OF HALL IC LEAD WIRES ARE AS SHOWN BELOW.

- — Gray (power)
- — Purple (signal)
- — Blue (GND)

(R1981)

Case 5


Phenomenon : Air conditioner does not come into cooling though indoor fan is operating.



(R1982)

Case 6

Phenomenon : Air conditioner does not come into cooling though indoor fan is operating.




(R1983)

### 3. Service Check Function

#### 3.1 Remote Controller Display

The temperature display sections on the main unit indicate corresponding codes.

1. When the timer cancel button is held down for 5 seconds, a "00" indication flashes on the temperature display section.



(R2157)

2. Press the timer cancel button repeatedly until a continuous beep is produced.

■ The code indication changes in the sequence shown below, and notifies with along beep.

No.	Code	No.	Code	No.	Code
1	00	11	E7	21	UR
2	U4	12	C7	22	R5
3	F3	13	H8	23	J9
4	E6	14	J3	24	E8
5	L5	15	R3	25	P4
6	R6	16	R1	26	L3
7	E5	17	C4	27	L4
8	LC	18	C5	28	H6
9	C9	19	H9	29	H7
10	U0	20	J6	30	U2



**Note:**

1. A short beep and two consecutive beeps indicate non-corresponding codes.
2. To cancel the code display, hold the timer cancel button down for 5 seconds. The code display also cancels itself if the button is not pressed for 1 minute.

## 4. Troubleshooting by Indication on the Remote Controller

### 4.1 Indoor Units

- : Not used for troubleshooting

\* : Varies depending on the cases.

Indication on the remote controller	Description of The Fault	Details of fault (Refer to the indicated page.)
00	Indoor unit in normal condition (Conduct a diagnosis of the outdoor unit.)	—
A1	Faulty indoor unit PCB	46
A5	Operation halt due to the freeze protection function	47
A6	Faulty fan motor (AC motor stop)	48
C4	Heat exchanger temperature thermistor or related abnormality	49
C9	Suction thermistor or related abnormality	49
*	Faulty indoor unit PCB	50

## 4.2 Faulty PCB

Remote  
Controller  
Display

*A1*

Indoor unit LED  
Display

Method of  
Malfunction  
Detection

Evaluation of zero-cross detection of power supply by indoor unit.


Malfunction  
Decision  
Conditions

When there is no zero-cross detection in approximately 10 continuous seconds.

Supposed  
Causes

- Faulty indoor unit PCB
- Faulty connector connection

Troubleshooting



(R1985)

 **Note:** Connector Nos. vary depending on models.  
Control connector.....S26 and S27

## 4.3 Freeze-Up Protection (Thermistor Activation)

Remote  
Controller  
Display

AS

Indoor unit LED  
Display

Method of  
Malfunction  
Detection

- The freeze protection control (operation halt) is activated during cooling operation according to the temperature detected by the indoor unit heat exchanger thermistor.

Malfunction  
Decision  
Conditions

- Freeze protection  
When the indoor unit heat exchanger temperature is below 0°C during cooling operation.

Supposed  
Causes

- Operation halt due to clogged air filter of the indoor unit.
- Operation halt due to dust accumulation on the indoor unit heat exchanger.
- Operation halt due to short-circuit.
- Detection error due to faulty indoor unit heat exchanger thermistor.
- Detection error due to faulty indoor unit PCB.

Troubleshooting




Check No.5  
Refer to P.51



**Caution**

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R1986)

## 4.4 Operation Halt Due to Fan Motor (AC Motor) or Related Abnormality

Remote Controller Display

*RE*

Indoor unit LED Display

Method of Malfunction Detection

The rotation speed detected by the hall IC during fan motor operation is used to determine abnormal fan motor operation.

Malfunction Decision Conditions

When the detected rotation speed is less than 50% of the HH tap under maximum fan motor rotation demand.

Supposed Causes

- Operation halt due to short circuit inside the fan motor winding.
- Operation halt due to breaking of wire inside the fan motor.
- Operation halt due to breaking of the fan motor lead wires.
- Operation halt due to faulty capacitor of the fan motor.
- Detection error due to faulty indoor unit PCB (1).


### Troubleshooting

  
**Check No.16**  
 Refer to P.52



**Caution**

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R1987)

## 4.5 Operation Halt Due to Detection of Thermistor or Related Abnormality

Remote  
Controller  
Display

**C4, C9**

Indoor unit LED  
Display

Method of  
Malfunction  
Detection

The temperatures detected by the thermistors are used to determine thermistor errors.

Malfunction  
Decision  
Conditions

When the thermistor input is more than 4.96 V or less than 0.04 V during compressor operation\*.

\* (reference)

When above about 212°C (less than 120 Ω ) or below about -50°C (more than 1,860 kΩ).



**Note:** The values vary slightly in some models.

Supposed  
Causes

- Faulty connector connection
- Faulty thermistor
- Faulty PCB

Troubleshooting




**Check No.5**  
Refer to P.51



**Caution**

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.




**C4** : Heat exchanger temperature thermistor.

**C9** : Suction air thermistor

## 4.6 Faulty Indoor Unit PCB

Remote Controller Display	*
Indoor unit LED Display	
Method of Malfunction Detection	The proper program operation of the microcomputer is checked by the program.
Malfunction Decision Conditions	When the microcomputer program does not function properly.
Supposed Causes	<ul style="list-style-type: none"> <li>■ Microcomputer program is in abnormal condition due to an external factor.                             <ul style="list-style-type: none"> <li>*Noise</li> <li>*Momentary voltage drop.</li> <li>*Momentary power failure, ect.</li> </ul> </li> <li>■ Faulty indoor unit PCB.</li> </ul>

### Troubleshooting



# 5. Check

## 5.1 How to Check



### 5.1.1 Thermistor Resistance Check

**Check No.5**

Remove the connectors of the thermistors on the PCB, and measure the resistance of each thermistor using tester.


The relationship between normal temperature and resistance is shown in the graph and the table below.

Temperature (°C)	Thermistor R25°C=20kΩ B=3950
-20	211.0 (kΩ)
-15	150
-10	116.5
-5	88
0	67.2
5	51.9
10	40
15	31.8
20	25
25	20
30	16
35	13
40	10.6
45	8.7
50	7.2



For the models whose thermistor is directly equipped on the printed circuit board;

- Remove the signal receiver and the display printed circuit board (disconnect the connector too), and then measure ohm by an ohmmeter at the both ends.
- The relation between temperature and resistance is in common with the existing models.



## 5.1.2 Inverter Units Hall IC Check

### Check No.16



1. Check the connector connection.
2. With the power ON, operation OFF, and the connector connected, check the following.
  - \*Output voltage of about 5 V between pins 1 and 3.
  - \*Generation of 3 pulses between pins 2 and 3 when the fan motor is operating.

Failure of (1) → faulty PCB → Replace the PCB.

Failure of (2) → faulty hall IC → Replace the fan motor.

Both (1) and (2) result → Replace the PCB.

The connector has 3 pins, and there are two patterns of lead wire colors.



(R1990)

# Part 7





## Removal Procedure

1. For FT50 / 60GAVE, FT50 / 60GAVEA, FT50 / 60GAVAL .....	54
1.1 Removal of Air Filter .....	54
1.2 Removal of Front Grille .....	56
1.3 Opening and Closing of Service Cover / Changing Settings at Installation Site.....	57
1.4 Removal of Front Panel.....	58
1.5 Removal of Horizontal and Vertical Blades .....	60
1.6 Removal of Drain Pan .....	61
1.7 Removal of PC Board.....	63
1.8 Removal of Electrical Parts Box .....	66
1.9 Removal of Swing Motor Assembly.....	68
1.10 Piping of Drain Hose at Left Side .....	69
1.11 Removal of Heat Exchanger .....	70
1.12 Removal of Fan Rotor and Motor .....	75
2. For R60GV1(K)(9), R60GAV1A(9), R60GVAL(9) .....	76
2.1 Removal of Outer Panel .....	76
2.2 Removal of Electrical Parts Box .....	77
2.3 Removal of Compressor.....	80

# 1. For FT50 / 60GAVE, FT50 / 60GAVEA, FT50 / 60GAVAL

## 1.1 Removal of Air Filter

**Procedure**  **Warning** Be sure to turn off all power supplies before disassembling work.

Step	Procedure	Points
1. External features	 <p>Display section on main unit</p>	 <p>(R2280)</p>
2. Removing air filters	<p>1 Pull protrusions on left and right sides of grille with fingers and open front grille all the way.</p>  <p>(R2282)</p>	<p>ON/OFF switch on main unit also functions as remote controller signal receiving section.</p>
2	<p>Lift center section of air filter and disengage hooks at two locations.</p>  <p>(R2283)</p>	

Step	Procedure	Points
3	Remove air filter by pulling forward.	<ul style="list-style-type: none"><li>■ Left and right filters are interchangeable.</li><li>■ To re-install, insert air filter along the guide.</li></ul>

(R2284)

## 1.2 Removal of Front Grille

**Procedure**



**Warning** Be sure to turn off all power supplies before disassembling work.




Step	Procedure	Points
<ul style="list-style-type: none"> <li>■ Pull protrusions on left and right sides of front panel and open grille until it locks in position.</li> </ul>	<p style="text-align: right;">(R2286)</p>	
<p>1 Slide down locking switch at the center of front grille and disjoin hinge.</p>	<p style="text-align: right;">(R2287)</p>	
<p>2 Remove front grille from the unit.</p>	<p style="text-align: right;">(R2288)</p>	<ul style="list-style-type: none"> <li>■ Lift front panel until a clicking sound is produced.</li> </ul>
<p style="text-align: right;">(R2289)</p>		

# 1.3 Opening and Closing of Service Cover / Changing Settings at Installation Site

**Procedure**



**Warning** Be sure to turn off all power supplies before disassembling work.

Step	Procedure	Points
<p>1. External features</p> <p>1 Remove service cover mounting screw. (M4 x 12 black)</p> <p>2 Take off cover by pulling down.</p>	 <p style="text-align: right;">(R2293)</p> 	
<p>2. Changing settings at installation site</p>		
<p>1 Filter sign can be reset.</p>	 <p style="text-align: right;">(R2294)</p>	

# 1.4 Removal of Front Panel






**Procedure**





**Warning**

Be sure to turn off all power supplies before disassembling work.

Step	Procedure	Points
1	Lift horizontal blade to open position.	
2	Remove screw covers at three locations, then remove screws. (M4 x 16 x 3 pcs.) Front cover can be now dismounted from the unit.	



Step	Procedure	Points
<p>3 To remove front panel, take out air filter and disengage two hooks on upper side of than three hooks on lower side of flap.</p>		
<p>4 Top side is provided with four hooks. To disengage, move front panel forward while twisting it.</p>		<p>■ Four hooks are provided on top side of front panel.</p>

# 1.5 Removal of Horizontal and Vertical Blades

**Procedure**



**Warning** Be sure to turn off all power supplies before disassembling work.

Step	Procedure	Procedure	Points
<p>1 Lift horizontal blade to open position.</p> <p>2 Disengage horizontal blade from three blade retaining sections.</p> <p>3 Bend blade slightly and remove it from the unit.</p>		<p>(R2303)</p>	
		<p>(R2304)</p> <p>(R2305)</p>	<p>■ Re-installation</p> <ol style="list-style-type: none"> <li>1. Set blade onto the alignment key on right side first.</li> <li>2. Engage blade retaining sections at 3 locations.</li> </ol> <p>(R2306)</p>
<p>4 Disengage vertical blades from bottom catch by bending them slightly.</p> <p>5 Pull the vertical blades forward to remove.</p>		<p>(R2306)</p>	





# 1.6 Removal of Drain Pan

**Procedure**



**Warning** Be sure to turn off all power supplies before disassembling work.

Step	Procedure	Points
<ul style="list-style-type: none"> <li>■ Remove front grille.</li> <li>■ Remove electrical box.</li> </ul>	<p style="text-align: right;">Thin cloth (R2308)</p>	<ul style="list-style-type: none"> <li>■ Wrap a thin cloth around the tip of screwdriver, and pry open the cover.</li> <li>■ This step is not necessary for backside piping.</li> </ul>
<p>1 Remove bottom cover to access drain hose (for left-handed piping).</p>	<p style="text-align: right;">(R2309)</p>	
<p>2 Remove two screws that secure bottom frame to mounting plate.</p>	<p style="text-align: right;">(R2310)</p>	<p>Listen to clicking sound to ensure secure mounting of parts.</p> <p style="text-align: right;">(R2311)</p>
<p>3 Push two positions at lower part of the unit to disengage bottom frame hooks from mounting plate. Lift the unit slightly and pull out drain hose.</p>	<p style="text-align: right;">Rubber band Plastic bag (R2312)</p>	<ul style="list-style-type: none"> <li>■ Be careful not to soil the floor with drain water.</li> </ul>
<p>4 Lift the unit slightly and pull out drain hose.</p>		

Step	Procedure	Points
5	Disengage hook on left side.	 <p>(R2313)</p>
6	Dismount left side of drain pan from the unit.	 <p>(R2314)</p>
7	Dismount right side of drain pan from the unit.	 <p>(R2315)</p>
8	Disconnect drain hose.	<p><b>Warning!</b> Hold the bottom of drain hose and disconnect drain hose.</p>  <p>(R2316)</p>





# 1.7 Removal of PC Board

**Procedure**



**Warning** Be sure to turn off all power supplies before disassembling work.

Step	Procedure	Points
<p>■ Remove front panel.</p>	<p>(R2317)</p>	
<p>1 Remove water-proofing plate. Cover can be removed by moving hook outward.</p>	<p>(R2319) Held in place by this hook.</p>	<p>(R2318)</p>
<p>2 Electrical box cover is secured in position by two hook.</p>	<p>(R2320)</p>	





Step	Procedure	Points
3	Disconnect earth wire.  <p>(R2321)</p>	
4	Disconnect heat exchanger thermistor.  <p>(R2322)</p>	
5	Disconnect swing motor wire harness.	When disconnecting wire harness, pull out the connector holding terminal section of connector. Do not hold lead wire.
6	Pull out printed circuit board, and unplug wire harness connector.  <p>(R2323)</p>	
7	Remove P.C. Board.  <p>(R2324)</p>	




Step	Procedure	Points
8	<p>Pull out power supply printed circuit board slightly.</p>	
9	<p>After disconnecting power supply terminal and motor wire harness, remove power supply printed circuit board.</p> <p>Fan motor : S1</p>	

## 1.8 Removal of Electrical Parts Box

**Procedure**  **Warning** Be sure to turn off all power supplies before disassembling work.




Step	Procedure	Points
Remove thermistors, earth wire and connectors (S1, S6)		
1	Remove screw located at right lower side of electrical box. (M4 x 16)	
2	Disconnect swing motor wire harness.	
3	Lift up electrical parts box slightly and disengage hook located at bottom side.	
4	Disengage hook located at top side.	



Step	Procedure	Points
5	<p>Unplug connector of fan motor wire harness. (S1)</p>  <p>(R2332)</p>	
6	<p>Move electrical box slightly to right, then pull out box forward.</p>  <p>Drain guide</p> <p>(R2333)</p>  <p>(R2334)</p>	<p><b>⚠ Caution!</b> Do not catch the putty on protrusion of drain guide in the flame protection panel.</p>

## 1.9 Removal of Swing Motor Assembly

**Procedure**  **Warning** Be sure to turn off all power supplies before disassembling work.

Step	Procedure	Points
<ul style="list-style-type: none"> <li>■ Remove front panel.</li> <li>■ Remove the electric parts box.</li> </ul>	 <p style="text-align: right;">(R2335)</p>	<p>The number of motors varies depending on the model.</p>
<p>1 Remove two screws holding swing motor in place. (M4 x 8)</p>	 <p style="text-align: right;">(R2336)</p>	
<p>2 Remove two screws holding swing motor mechanism in place. (M4 x 8)</p>	 <p style="text-align: right;">(R2337)</p>	





## 1.10 Piping of Drain Hose at Left Side

**Procedure**






**Warning** Be sure to turn off all power supplies before disassembling work.





Step	Procedure	Points
Remove drain pan. (Refer page 61.)		
1	Pull out drain plug located on left side of drain pan with fingers.	
2	Insert drain hose.	<p><b>Warning!</b> Hold the bottom of drain hose and insert drain hose properly.</p>
3	Insert drain plug into the opening on right side, and press it in using hexagon wrench (4 mm).	
4	Place drain hose into left side of the unit, and mount drain pan.	
<p>■ Make sure to check draining the water properly.</p>		








# 1.11 Removal of Heat Exchanger


**Procedure**  **Warning** Be sure to turn off all power supplies before disassembling work.

Step	Procedure	Points
<ul style="list-style-type: none"> <li>■ Conduct pump-down operation.</li> </ul>		
<p>1 Remove bottom cover located at lower part of the unit and disconnect two screws.</p> <p>2 Push two positions at lower part of the unit to disengage bottom frame hooks from mounting plate. Lift the unit slightly. Refer page 61.</p>	 <p style="text-align: right;">(R2343)</p>	<p> <b>Warning!</b> If gas leaks, repair the leak location, then collect all refrigerant from the unit. Conduct vacuum drying, and charge proper amount of refrigerant.</p> <p> <b>Warning!</b> Do not mix any gas (including air) other than the specified refrigerant (R22) into refrigerating cycle. (Mixing of air or other gas causes abnormal temperature rise in refrigerating cycle, and this results in pipe rupture or personal injuries.)</p>
<p>3 Remove insulation tube, and disconnect liquid pipe at the flare.</p>	 <p style="text-align: right;">(R2344)</p>	<ul style="list-style-type: none"> <li>■ Use two wrenches to disconnect pipe.</li> <li>■ Be careful not to scratch the wall.</li> </ul>
<p>4 Disconnect gas pipe at the flare.</p>	 <p style="text-align: right;">(R2345)</p>	<ul style="list-style-type: none"> <li>■ After pipes are disconnected, close all pipe openings with caps to prevent dust and moisture from entering pipes.</li> </ul>

Step	Procedure	Points
<p>■ For removal of front grille, drain pan, electrical box and other parts, see reference pages.</p>		
<p>1. Lifting heat exchanger</p>		
<p>1 Remove screw holding heat exchanger mounting plate in place.</p>	   <p style="text-align: right;">(R2346)</p>	
<p>2 While raising heat exchanger, pull it forward and disengage hooks.</p>		
<p>3 Lift heat exchanger.</p>	 <p style="text-align: right;">(R2347)</p>	<p><b>⚠ Caution!</b> When removing or re-installing heat exchanger, be sure to wear protective gloves or wrap heat exchanger with cloths. (Fins can cut fingers.)</p>

Step	Procedure	Points
2.	Remove the heat exchanger from the right side plate.	
1	<p data-bbox="204 320 459 387">There are hooks on right side plate.</p>   <p data-bbox="916 1106 975 1128">(R2348)</p>	

Step	Procedure	Points
3. Loosening pipe retaining plate		
1	<p>Disengage hook on pipe retaining plate.</p>  <p>(R2349)</p>	
2	<p>Pull auxiliary pipe forward to an angle of 10 to 20 degree.</p>  <p>10~20 degree (R2350)</p>	<p>■ Be careful to prevent pipe deformation.</p>
3	<p>Pull out heat exchanger toward front.</p>  <p>(R2351)</p>	






Step	Procedure	Points
4	<p>Pull out the heat exchanger along the pipe from the unit.</p>  <p>(R2352)</p>	<p><b>Warning!</b> Do not mix any gas (including air) other than the specified refrigerant (R22) into refrigerating cycle. (Mixing of air or other gas causes abnormal temperature rise in refrigerating cycle, and this results in pipe rupture or personal injuries.)</p> <p><b>Warning!</b> If gas leaks, repair the leak location, then collect all refrigerant from the unit. Conduct vacuum drying, and charge proper amount of refrigerant.</p> <p><b>Caution!</b> When removing or re-installing heat exchanger, be sure to wear protective gloves or wrap heat exchanger with cloths. (Fins can cut fingers.)</p>

## 1.12 Removal of Fan Rotor and Motor

### Procedure



**Warning** Be sure to turn off all power supplies before disassembling work.



Step	Procedure	Points
<ul style="list-style-type: none"> <li>■ Remove front panel, drain pan, electrical parts box and heat exchanger from the unit.</li> </ul>	 <p style="text-align: right;">(R2281)</p>	
1	Remove three screws on right side panel.	
2	Remove fan rotor and motor together from the unit.	
3	Loosen the hexagon head set screw on the fan rotor, and remove the motor. ⊕ screwdriver can be also used.	 <p style="text-align: right;">(R2285)</p>
4	Press the bearing with finger from the outside to remove it.	<p><b>⚠ WARNING</b>  (In case of installing fan rotor and motor)  <b>Make sure to insert the set screw in the groove of fan motor shaft.</b>  <b>Set the fan motor in right.</b></p> <ul style="list-style-type: none"> <li>■ Set the bottom of motor name plate to the edge of motor base.</li> </ul>
		 <p style="text-align: right;">(R2290)</p>

## 2. For R60GV1(K)(9), R60GAV1A(9), R60GVAL(9)

### 2.1 Removal of Outer Panel

**Procedure**




**Warning** Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.






Step	Procedure	Points
1	To dismount top panel, remove four mountin screws (A).	 <p>Top panel</p> <p>Service cover</p> <p>Side panel</p> <p>Screw with washer (R2291)</p>
2	To dismount front panel, remove six mounting screws (B).	(R2307)
3	To dismount service cover, remove two mounting screws.	 <p>Interconnecting wire terminal</p> <p>Power supply terminal</p> <p>Earth terminal</p> <p>(R2292)</p>
4	To dismount side panel, remove six mounting screws (C).	(R2295)



## 2.2 Removal of Electrical Parts Box

**Procedure**

**Warning** Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1	Remove wire harness connectors from printed circuit board and a coil for four-way valve. (remove one screw)	
2	Remove screw holding solenoid coil in place.	 <p>* RY50G only Four way valve</p> <p>Four way valve coil</p> <p>(R2353)</p>
3	Dismount air thermistor and heat exchange thermistor.	 <p>Attach to the 3rd row of heat exchanger pipe at 30mm from the left end.</p> <p>Route thermistor wire through the specified section to prevent wire pinching.</p> <p>Thermistor retaining spring</p> <p>Thermistor</p> <p>(R2354)</p>




Step	Procedure	Points
4	<p>Remove top insulation material from compressor.</p>  <p>(R2355)</p>	<ul style="list-style-type: none"> <li>Terminal code is printed. Do not scorch the indication with the flame of welder. Also record terminal code on a memo paper in case the indication becomes illegible.</li> </ul>
5	<p>Remove terminal cover.</p>  <p>(R2356)</p>	 <p>(R2357)</p>
6	<p>Remove compressor protective device and three terminals together with mounting plate.</p>  <p>(R2359)</p>	 <p>(R2358)</p> <ul style="list-style-type: none"> <li>Connect lead wires to proper fasten terminals.                     <ul style="list-style-type: none"> <li>S .....Yellow</li> <li>M.....Red</li> <li>C .....Blue</li> </ul> </li> </ul>



Step	Procedure	Points
7	<p>Remove the screw.</p>  <p>(R2360)</p>	
8	<p>Take off the electrical parts box.</p>  <p>(R2361)</p>	

## 2.3 Removal of Compressor

### Procedure

**⚠ Warning** Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
<ul style="list-style-type: none"> <li>Make sure that there is no refrigerant in the unit before disassembling.</li> </ul>	 <p>(R2362)</p>	<p><b>⚠ WARNING</b>                      If refrigerant gas leaks during servicing work, ventilate the area. (If refrigerant gas contacts flames, hazardous gas can generate.)</p> <ul style="list-style-type: none"> <li>When removing sound-insulation material, do not pull it with excessive force, since it is inserted between pipes.</li> </ul>
<p>1 Pull out sound insulation material (side insulation) from right side.</p> <p>2 Disconnect suction pipe and discharge pipe of compressor at brazed sections.</p>	 <p>(R2364)</p>	 <p>(R2363)</p>

Step	Procedure	Points
3	<p>After disconnecting refrigerant pipes, remove three washer nuts that secure compressor in place. Use open-end wrench to remove washer nut (a) located on right front side.</p>	 <p>Open-end wrench (R2365)</p>
4	<p>Use T-handle box wrench to loosen nuts (b) and (c).</p>	 <p>T-handle box wrench (R2366)</p>



# Part 8 Others

1. Others .....	84
1.1 Points of Installation Work.....	84

# 1. Others

## 1.1 Points of Installation Work

### 1.1.1 Method of Operating Air Conditioners Individually (When Two Units are Installed in One Room)


- **How to set the different addresses.**
- When two indoor units are installed in one room, the two wireless remote controllers can be set for different addresses.

#### PCB in the indoor unit

- Remove the front panel.
- Remove the sensor parts cover (2-screws), then remove the electric parts box (1-screw).
- Slide the metallic cover to remove it. (4-claws on the electric parts box.)
- Cut the jumper JA on PCB.

#### Wireless remote controller

- Cut the jumper J4.



### 1.1.2 Centralized Control (For KRC72, KRP413A1S)

For an explanation on usage, see the option handbook. However, do the following when using the KRP413A1S (Contact connection centralized control PC board).

Cut jumper JC on the indoor PC Board.




**Note :** The power failure recovery function is controlled by the ON signal from the centralized control PC Board. The following may occur if the unit is used without cutting jumper JC.

- If the unit was running when a power failure occurred, it may not resume operation after recovering from a power failure.

### 1.1.3 Dry Keep Change-over Switch

Jumper (On indoor PC Board)	Function	When connected (factory set)	When cut
JC	Power failure recovery function	Auto start	Unit does not resume operation after recovering from a power failure. Timer ON-OFF settings are cleared.
JB	Fan speed setting when compressor is OFF on thermostat.	Fan speed setting ; Remote controller setting	Fan rpm is set to "0" <Fan stop>
JA	When two indoor units are installed in one room, the two wireless remote controllers can be set for different addresses.	1 (★)	2 (★)

- ★ Match the numbers printed at the backside of the wireless remote controller and allocate them to each indoor unit.






# Part 9 Appendix

1. Piping Diagram.....	88
1.1 Indoor Unit.....	88
1.2 Outdoor Unit.....	89
2. Wiring Diagram .....	91
2.1 Indoor Unit.....	91
2.2 Outdoor Unit.....	92

# 1. Piping Diagram

## 1.1 Indoor Unit

FT50 / 60GAVE(A)  
FT50 / 60GAVAL




REFRIGERANT FLOW  
← COOLING

C : 4D005343C

# 1.2 Outdoor Unit

R50 / 60GV1(9) , R50GV1K(9)




NOTE:  
1.GAS PIPE SPECIFICATION

R25	9.5CuT
R35	12.7CuT
R45,R50,R60	15.9CuT


DW521-856F

R60GV1K(9)



DW527-236A

R50 / 60GAV1A(9) , R50 / 60GVAL(9)




4D028567

# 2. Wiring Diagram


## 2.1 Indoor Unit

### FT50 / 60GAVE(A)



3D027718A


### FT50 / 60GAVAL



3D027720

## 2.2 Outdoor Unit

### R50GV1(K)(9) , R50GVAL(9),




C11R,C12R :RUNNING CAPACITOR  
 F1U :FUUSE  
 F1S :SURGE ARRESTER  
 F2S :SURGE ARRESTER  
 K1M :COMPRESSOR RELAY  
 L :LIVE  
 M1C :COMPRESSOR MOTOR

M1F :FAN MOTOR  
 N :NEUTRAL  
 Q1L :OVERLOAD PROTECTOR  
 X11A :CONNECTOR  
 X1M :TERMINAL STRIP

NOTES  
 1. REFER TO THE NAMEPLATE FOR THE POWER REQUIREMENTS.

3D005285A

### R50GAV1A(9)




C11R,C12R: RUNNING CAPACITOR  
 F1S,F2S : SURGE ARRESTER  
 F1U : FUSE  
 K1M : COMPRESSOR RELAY

L : LIVE  
 M1C : COMPRESSOR MOTOR  
 M1F : FAN MOTOR  
 N : NEUTRAL  
 Q1L : OVERLOAD PROTECTOR  
 X11A : CONNECTOR  
 X1M : TERMINAL STRIP


3D028077

**R60GVAL(9)**




3D005750A

**R60GV1(K)(9)**



3D004030A

R60GAV1A(9)



3D028078

# Index

## Numerics

3-minutes Standby Function .....16

## A

A1 .....46

A5 .....47

A6 .....48

Auto-fan Speed .....15

Auto-restart Function .....16

Auto-swing of Flaps .....15

## C

C4 .....49

C9 .....49

Centralized Control (For KRC72, KRP413A1S) .....84

Control PCB .....8

COOL mode .....18

Cooling Monitoring Function .....12

## D

Dew Condensation Protection Function .....15

Display PCB .....8

Dry Keep Change-over Switch .....85

DRY mode .....18

## F

Faulty Indoor Unit PCB .....50

Faulty PCB .....46

Filter Check Indicator .....18

Freeze Protection Function .....14

Freeze-Up Protection (Thermistor Activation) .....47

FT50 / 60GAVE, FT50 / 60GAVEA, FT50 / 60GAVAL

Adjusting the Air Flow Direction .....29

Care and Cleaning .....32

DRY · COOL · FAN Operation .....29

Names of Parts .....25

Opening and Closing of Service Cover / Changing

Settings at Installation Site .....57

Piping of Drain Hose at Left Side .....69

Powerful Operation .....30

Preparation before Operation .....27

Removal of Air Filter .....54

Removal of Drain Pan .....61

Removal of Electrical Parts Box .....66

Removal of Fan Rotor and Motor .....75

Removal of Front Grille .....56

Removal of Front Panel .....58

Removal of Heat Exchanger .....70

Removal of Horizontal and Vertical Blades .....60

Removal of PC Board .....63

Removal of Swing Motor Assembly .....68

Safety Precautions .....22

Timer Operation .....31

Trouble Shooting .....34

Functions .....2

## G

General Check .....39

General Functionality .....12

## I

Instruction .....22

Inverter Units Hall IC Check .....52

## L

Location of Operation Lamp

FT50 / 60GAVAL .....38

FT50 / 60GAVE .....38

FT50 / 60GAVEA .....38

## M

Method of Operating Air Conditioners (When

Two Units are Installed in One Room) .....84

## N

Night Set Mode .....17

## O

ON-OFF Operation from The Unit .....16

Operation Halt Due to Detection of Thermistor or

Related Abnormality .....49

Operation Halt Due to Fan Motor (AC Motor) or

Related Abnormality .....48

## P

Points of Installation Work .....84

Powerful Operation .....18

Powers supply PCB .....8

Problem Symptoms and Measures .....39

Program Dry Operation .....13

## R

R60GV1(K)(9), R60GAV1A(9), R60GVAL(9)

Removal of Compressor .....80

Removal of Electrical Parts Box .....77

Removal of Outer Panel .....76

Receiver sensor PCB .....8

Remote Controller Display .....44

## S

Specification

Cooling Only .....4

Store Data .....16

## T

Test Run function .....17

Thermistor Resistance Check .....51

Timer Function .....15

Trial operation from Remote Controller .....17

---

Troubleshooting	
(Fault Diagnosis and Countermeasure)	
Air conditioner does not come into cooling	
though indoor fan is operating .....	42, 43
Air conditioner does not operate .....	40
Air conditioner does not operate with wireless	
remote controller .....	40
Air conditioner does not operate, and LED for	
operation blinks .....	40, 41
Troubleshooting by Indication	
on the Remote Controller	
Indoor Units .....	45
Troubleshooting with The Operation Lamp .....	38

# Drawings & Flow Charts

<b>A</b>			<b>N</b>	
Auto-fan Speed .....	15		Night Set Mode .....	17
Auto-swing of Flaps .....	15			
<b>C</b>			<b>O</b>	
Control PCB .....	9		Operation Halt Due to Detection of Thermistor or Related Abnormality .....	49
Cooling Monitoring Function .....	12		Operation Halt Due to Fan Motor (AC Motor) or Related Abnormality .....	48
<b>D</b>			<b>P</b>	
Dew Condensation Protection Function .....	15		Piping Diagram	
Dry Keep Change-over Switch .....	85		FT50 / 60GAVAL .....	88
<b>F</b>			FT50 / 60GAVE(A) .....	88
Faulty Indoor Unit PCB .....	50		R50 / 60GAV1A(9) , R50 / 60GVAL(9) .....	90
Faulty PCB .....	46		R50 / 60GV1(9) , R50GV1K(9) .....	89
Filter Check Indicator .....	18		R60GV1K(9) .....	89
Freeze Protection Function .....	14		Power Supply PCB .....	9
Freeze-Up Protection (Thermistor Activation) .....	47		Program Dry Operation .....	13
FT50 / 60GAVE, FT50 / 60GAVEA, FT50 / 60GAVAL			<b>R</b>	
Adjusting the Air Flow Direction .....	29		R60GV1(K)(9), R60GAV1A(9), R60GVAL(9)	
Care and Cleaning .....	32		Removal of Compressor .....	80
DRY · COOL · FAN Operation .....	29		Removal of Electrical Parts Box .....	77
Names of Parts .....	25		Removal of Outer Panel .....	76
Opening and Closing of Service Cover / Changing Settings at Installation Site .....	57		Receiver Sensor and Display PCB .....	9
Piping of Drain Hose at Left Side .....	69		Remote Controller Display .....	44
Powerful Operation .....	30		<b>T</b>	
Preparation before Operation .....	27		Test Run Function .....	17
Removal of Air Filter .....	54		Thermistor Resistance Check .....	51
Removal of Drain Pan .....	61		Troubleshooting	
Removal of Electrical Parts Box .....	66		(Fault Diagnosis and Countermeasure)	
Removal of Fan Rotor and Motor .....	75		Air conditioner does not come into cooling though indoor fan is operating .....	42, 43
Removal of Front Grille .....	56		Air conditioner does not operate .....	40
Removal of Front Panel .....	58		Air conditioner does not operate with wireless remote controller .....	40
Removal of Heat Exchanger .....	70		Air conditioner does not operate, and LED for operation blinks .....	40, 41
Removal of Horizontal and Vertical Blades .....	60		<b>W</b>	
Removal of PC Board .....	63		Wiring Diagram	
Removal of Swing Motor Assembly .....	68		FT50 / 60GAVAL .....	91
Safety Precautions .....	22		FT50 / 60GAVE(A) .....	91
Timer Operation .....	31		R50GAV1A(9) .....	92
Trouble Shooting .....	34		R50GV1(K)(9) , R50GVAL(9) .....	92
<b>I</b>			R60GAV1A(9) .....	94
Instruction .....	22		R60GV1(K)(9) .....	93
Inverter Units Hall IC Check .....	52		R60GVAL(9) .....	93
<b>L</b>				
Location of Operation Lamp				
FT50 / 60GAVAL .....	38			
FT50 / 60GAVE .....	38			
FT50 / 60GAVEA .....	38			
<b>M</b>				
Method of Operating Air Conditioners (When Two Units are Installed in One Room) .....	84			

**DAIKIN INDUSTRIES, LTD.**

Head office:

Umeda Center Bldg., 4-12, Nakazaki-Nishi 2-chome,  
Kita-ku, Osaka, 530-8323 Japan

Tokyo office:

Shinjuku Sumitomo Bldg., 6-1 Nishi-Shinjuku  
2-chome, Shinjuku-ku, Tokyo, 163-0235 Japan

---

**DAIKIN EUROPE NV**

Zandvoordestraat 300, B-8400 Oostende, Belgium