

## Service Manual

## SUPER MULTIME

E/F/G/K-Series







[Applied Models]

• Inverter Multi : Cooling Only

● Inverter Multi : Heat Pump

## SUPER MULTI NX E-Series F-Series G-Series K-Series

#### Cooling Only

Outdoor Unit 3MKS50E3V1B	4MKS58E3V1B	4MKS75F2V1B	5MKS90E2V3B
Indoor Unit FTXS25J2V1B FTXS35J2V1B FTXS42J2V1B FTXS50J2V1B FTXS60GV1B FTXS71GV1B	FFQ25B9V1B FFQ35B9V1B FFQ50B9V1B FFQ60B9V1B	FHQ35BWV1B FHQ50BWV1B FHQ60BWV1B	FDBQ25B8V1 FBQ35C8VEB FBQ50C8VEB FBQ60C8VEB
●Heat Pump			
Outdoor Unit 3MXS40K2V1B 3MXS52E3V1B	3MXS68G2V1B 4MXS68F2V1B	4MXS80E2V3B 5MXS90E2V3B	
Indoor Unit FTXG25JV1BW FTXG25JV1BA FTXG35JV1BW FTXG35JV1BA FTXG50JV1BW FTXG50JV1BA CTXS15K2V1B FTXS20K2V1B FTXS25K2V1B CTXS35K2V1B FTXS25J2V1B FTXS35J2V1B FTXS42J2V1B FTXS42J2V1B FTXS71GV1B	FVXG25K2V1B FVXG35K2V1B FVXG50K2V1B FVXS25FV1B FVXS35FV1B FVXS50FV1B FLXS25BAVMB FLXS35BAVMB FLXS50BAVMB FLXS60BAVMB FDXS25E7VMB FDXS35E7VMB FDXS35C7VMB FDXS60C7VMB	FCQG35FVEB FCQG50FVEB FCQG60FVEB FFQ25B9V1B FFQ35B9V1B FFQ50B9V1B FFQ60B9V1B FHQ35BWV1B FHQ50BWV1B FHQ60BWV1B FDBQ25B8V1 FBQ35C8VEB FBQ50C8VEB FBQ60C8VEB	

i Table of Contents

	1.	Introduction	
		1.2 Used Icons	
Part 1	List of	Functions	1
	1.	Cooling Only	2
		1.1 Outdoor Unit	
		1.2 Indoor Unit	3
	2.	Heat Pump	6
		2.1 Outdoor Unit      2.2 Indoor Unit	
Part 2	Specifi	cations	14
	-		
	1.	Cooling Only	
		1.2 Indoor Unit	
	2	Heat Pump	
	۷.	2.1 Outdoor Unit	
		2.2 Indoor Unit	
Part 3	Printed	l Circuit Board Connector Wiring Diagrar	n37
	1.	Outdoor Unit	38
		Indoor Unit	
		2.1 FTXG25/35/50JV1BW(A)	
		2.2 FTXS20/25K2V1B, CTXS15/35K2V1B	
		2.3 FTXS25/35/42/50J2V1B	46
		2.4 FTXS60/71GV1B	49
		2.5 FVXG25/35/50K2V1B	
		2.6 FVXS25/35/50FV1B	
		2.7 FLXS25/35/50/60BAVMB	_
		2.8 FDXS25/35E7VMB, FDXS50/60C7VMB	
		2.9 FCQG35/50/60FVEB	
		2.10 FFQ25/35/50/60B9V1B	
		2.11 FHQ35/50/60BWV1B	
		2.12 FDBQ25B8V12.13 FBQ35/50/60C8VEB	
	2	Wired Remote Controller	
	3.	3.1 BRC1D528	
		3.2 BRC1E52A7, BRC1E52B7	
Part 4	Functio	on and Control	75
	1.	Indoor Unit Control (RA Models)	76
		1.1 Temperature Control	
		1.2 Frequency Principle	76
		1.3 Operation Starting Control	
		1.4 Airflow Direction Control	
		1.5 Fan Speed Control for Indoor Unit	
		1.6 RADIANT Operation	
		1.7 Program Dry Operation	85

Table of Contents

		1.8 Automatic Operation	86
		1.9 Thermostat Control	87
		1.10 NIGHT SET Mode	89
		1.11 ECONO Operation	90
		1.12 HOME LEAVE Operation	
		1.13 INTELLIGENT EYE Operation	92
		1.14 2-Area INTELLIGENT EYE Operation	
		1.15 Inverter POWERFUL Operation	
		1.16 Multi-Colored Indicator Lamp / TIMER Lamp	
		1.17 Other Functions	
	2.	Indoor Unit Control (SA Models)	
		2.1 Drain Pump Control	
		2.2 Thermostat Sensor in Remote Controller	
		2.3 Freeze Prevention Control	
		2.4 Hot Start Control (In Heating Operation Only)	
		Function of Thermistor	
	4.	Control Specification	
		4.1 Mode Hierarchy	
		4.2 Frequency Control	
		4.3 Controls at Mode Changing / Start-up	
		4.4 Discharge Pipe Temperature Control	
		4.5 Input Current Control	
		4.6 Freeze-up Protection Control	
		4.7 Heating Peak-cut Control	
		4.8 Outdoor Fan Control	
		4.9 Liquid Compression Protection Function	
		4.10 Defrost Control	
		4.11 Low Hz High Pressure Limit	
		4.13 Malfunctions	
		4. 10 Manufolions	122
Part 5	Onerat	ion Manual	124
ait o	Operat		
	1.	System Configuration	125
	2.	RA Indoor Unit	126
		2.1 FTXG, FTXS-K, CTXS, FVXG Series - ARC466A1, A2, A6	126
		2.2 FTXS-J, FTXS-G, FVXS Series - ARC452A1, A3	178
		2.3 FLXS, FDXS Series - ARC433B67, B69	218
	3.	SA Indoor Unit	233
		3.1 BRC1D528	
Part 6	Service	Diagnosis	248
	4	To Harbard at 1951 FD	050
	1.	Troubleshooting with LED	
		1.1 Indoor Unit	
	_	1.2 Outdoor Unit	
		Problem Symptoms and Measures	
	3.	Service Check Function	254
		3.1 RA Indoor Unit - FTXG, FTXS, CTXS, FVXG, FVXS, FLXS,	
		FDXS Series	
		3.2 SA Indoor Unit - FCQG, FFQ, FHQ, FDBQ, FBQ Series	
	4.	Code Indication on Remote Controller	267

iii Table of Contents

	4.1	RA Indoor Unit - FTXG, FTXS, CTXS, FVXG, FVXS, FLXS, FDXS Series	007
	4.0		
	4.2	SA Indoor Unit - FCQG, FFQ, FHQ, FDBQ, FBQ Series	
	4.3	Sub Codes for SA Indoor Unit	
	4.4	Outdoor Unit	
5.		bleshooting for RA Indoor Unit - FTXG, FTXS, CTXS, FVXG, FV S, FDXS Series	
	5.1	Indoor Unit PCB Abnormality	
	5.2	Freeze-up Protection Control or Heating Peak-cut Control	
	5.3	Fan Motor or Related Abnormality	
	5.4	Radiant Panel Temperature Rise, Indoor Electronic Expansion Valve	
		(Motor Operated Valve) Abnormality, Freeze-up Protection Control	
		(FVXG Series Only)	.278
	5.5	Thermistor or Related Abnormality (RA Indoor Unit)	.280
	5.6	Front Panel Open / Close Fault (FTXG Series Only)	
	5.7	Signal Transmission Error (between Indoor Unit and Outdoor Unit)	.282
	5.8	Unspecified Voltage (between Indoor Unit and Outdoor Unit)	.283
6.	Trou	bleshooting for SA Indoor Unit - FCQG, FFQ, FHQ, FDBQ,	
-		Series	.284
	6.1	Indoor Unit PCB Abnormality	.284
	6.2	Drain Water Level System Abnormality	
	6.3	Fan Motor or Related Abnormality	.287
	6.4	Swing Motor Lock (FHQ Series Only)	.289
	6.5	Drain System Abnormality	.290
	6.6	Thermistor or Related Abnormality (SA Indoor Unit)	.291
	6.7	Remote Controller Thermistor Abnormality	.292
	6.8	Signal Transmission Error	
		(between Indoor Unit and Remote Controller)	.293
	6.9	Signal Transmission Error	
		(between MAIN Remote Controller and SUB Remote Controller)	
	6.10	Field Setting Abnormality	.295
7.	Trou	bleshooting for Outdoor Unit	.296
	7.1	Refrigerant Shortage	
	7.2	Low-voltage Detection or Over-voltage Detection	
	7.3	Signal Transmission Error (on Outdoor Unit PCB)	.300
	7.4	Unspecified Voltage (between Indoor Unit and Outdoor Unit) /	
		Anti-icing Function in Other Rooms	
	7.5	Anti-icing Function	
	7.6	Outdoor Unit PCB Abnormality	
	7.7	OL Activation (Compressor Overload)	
	7.8	Compressor Lock	
	7.9	DC Fan Lock	
		Input Overcurrent Detection	
		Discharge Pipe Temperature Control	
		High Pressure Control in Cooling	
		Compressor Sensor System Abnormality	
		Position Sensor Abnormality	
		CT or Related Abnormality	
		Thermistor or Related Abnormality (Outdoor Unit)	
		Electrical Box Temperature Rise	
		Output Overcurrent Detection	.ა∠ i 323

Table of Contents iv

		8.	Check	325
			8.1 Thermistor Resistance Check	325
			8.2 Fan Motor Connector Check	326
			8.3 Hall IC Check	327
			8.4 Indoor Electronic Expansion Valve Coil Check	327
			8.5 Power Supply Waveform Check	328
			8.6 Outdoor Electronic Expansion Valve Check	329
			8.7 Four Way Valve Performance Check	330
			8.8 Inverter Unit Refrigerant System Check	330
			8.9 "Inverter Checker" Check	331
			8.10 Rotation Pulse Check on the Outdoor Unit PCB	332
			8.11 Installation Condition Check	333
			8.12 Discharge Pressure Check	333
			8.13 Outdoor Fan System Check	334
			8.14 Capacitor Voltage Check	334
			8.15 Power Module Check	335
Part 7	Rem	ova	al Procedure	336
		1.	Outdoor Unit: 40-75 Class	337
			1.1 Removal of Outer Panels	337
			1.2 Removal of Electrical Box	341
			1.3 Removal of PCBs	349
			1.4 Removal of Outdoor Fan / Fan Motor	
			1.5 Removal of Sound Blankets	356
			1.6 Removal of Coils / Thermistors	360
			1.7 Removal of Distributor	363
			1.8 Removal of Four Way Valve	
			1.9 Removal of Compressor	365
		2.	Outdoor Unit: 80/90 Class	367
			2.1 Removal of Outer Panels	367
			2.2 Removal of Electrical Box	382
			2.3 Removal of PCBs	388
			2.4 Removal of Fan Motor	392
			2.5 Removal of Coils / Thermistors	393
			2.6 Removal of Sound Blankets	399
			2.7 Removal of Compressor	402
Part 8	Trial	O	peration and Field Settings	403
		1.	Pump Down Operation	404
		2.	Forced Operation	405
			Wiring Error Check Function	
			Trial Operation	
		•	4.1 RA Indoor Unit - FTXG, FTXS, CTXS, FVXG, FVXS, FLXS,	
			FDXS Series	
			4.2 SA Indoor Unit - FCQG, FFQ, FHQ, FDBQ, FBQ Series	410
		5.	Field Settings	412
			5.1 Outdoor Unit	412
			5.2 RA Indoor Unit - FTXG, FTXS, CTXS, FVXG, FVXS, FLXS,	
			FDXS Series	
			5.3 SA Indoor Unit - FCQG_FFQ_FHQ_FDBQ_FBQ Series	419

v Table of Contents

	Application of Silicon Grease to a Power Transistor     and a Diode Bridge	423
Part 9	Appendix	
	1. Piping Diagrams	425
	1.1 Outdoor Unit	
	1.2 Indoor Unit	430
	2. Wiring Diagrams	437
	2.1 Outdoor Unit	
	2.2 Indoor Unit	442

Table of Contents vi

Introduction SiBE121135

#### 1. Introduction

#### 1.1 Safety Cautions

## Cautions and Warnings

- Be sure to read the following safety cautions before conducting repair work.
- The caution items are classified into "♠ Warning" and "♠ Caution". The "♠ Warning" items are especially important since they can lead to death or serious injury if they are not followed closely. The "♠ Caution" items can also lead to serious accidents under some conditions if they are not followed. Therefore, be sure to observe all the safety caution items described below.
- About the pictograms
  - $\triangle$  This symbol indicates the item for which caution must be exercised.
    - The pictogram shows the item to which attention must be paid.
- This symbol indicates the prohibited action.
  - The prohibited item or action is shown in the illustration or near the symbol.
- This symbol indicates the action that must be taken, or the instruction. The instruction is shown in the illustration or near the symbol.
- After the repair work is complete, be sure to conduct a test operation to ensure that the equipment operates normally, and explain the cautions for operating the product to the customer.

#### 1.1.1 Cautions Regarding Safety of Workers

∕ <b>N</b> Warning	
Be sure to disconnect the power cable plug from the plug socket before disassembling the equipment for repair.  Working on the equipment that is connected to the power supply may cause an electrical shock.  If it is necessary to supply power to the equipment to conduct the repair or inspecting the circuits, do not touch any electrically charged sections of the equipment.	9.5
If the refrigerant gas is discharged during the repair work, do not touch the discharged refrigerant gas. The refrigerant gas may cause frostbite.	$\bigcirc$
When disconnecting the suction or discharge pipe of the compressor at the welded section, evacuate the refrigerant gas completely at a well-ventilated place first.  If there is gas remaining inside the compressor, the refrigerant gas or refrigerating machine oil discharges when the pipe is disconnected, and it may cause injury.	0
If the refrigerant gas leaks during the repair work, ventilate the area. The refrigerant gas may generate toxic gases when it contacts flames.	0
The step-up capacitor supplies high-voltage electricity to the electrical components of the outdoor unit.  Be sure to discharge the capacitor completely before conducting repair work. A charged capacitor may cause an electrical shock.	A
Do not start or stop the air conditioner operation by plugging or unplugging the power cable plug. Plugging or unplugging the power cable plug to operate the equipment may cause an electrical shock or fire.	$\bigcirc$

SiBE121135 Introduction

<u> </u>	
Be sure to wear a safety helmet, gloves, and a safety belt when working at a high place (more than 2 m). Insufficient safety measures may cause a fall accident.	
In case of R-410A refrigerant models, be sure to use pipes, flare nuts and tools for the exclusive use of the R-410A refrigerant.  The use of materials for R-22 refrigerant models may cause a serious accident such as a damage of refrigerant cycle as well as an equipment failure.	

<u> Caution</u>	
Do not repair the electrical components with wet hands. Working on the equipment with wet hands may cause an electrical shock.	
Do not clean the air conditioner by splashing water. Washing the unit with water may cause an electrical shock.	
Be sure to provide the grounding when repairing the equipment in a humid or wet place, to avoid electrical shocks.	
Be sure to turn off the power switch and unplug the power cable when cleaning the equipment.  The internal fan rotates at a high speed, and may cause injury.	0=5
Be sure to conduct repair work with appropriate tools. The use of inappropriate tools may cause injury.	0
Be sure to check that the refrigerating cycle section has cooled down enough before conducting repair work.  Working on the unit when the refrigerating cycle section is hot may cause burns.	0
Use the welder in a well-ventilated place. Using the welder in an enclosed room may cause oxygen deficiency.	0

Introduction SiBE121135

## 1.1.2 Cautions Regarding Safety of Users

<b>N</b> Warning	
Be sure to use parts listed in the service parts list of the applicable model and appropriate tools to conduct repair work. Never attempt to modify the equipment.  The use of inappropriate parts or tools may cause an electrical shock, excessive heat generation or fire.	0
If the power cable and lead wires have scratches or deteriorated, be sure to replace them.  Damaged cable and wires may cause an electrical shock, excessive heat generation or fire.	0
Do not use a joined power cable or extension cable, or share the same power outlet with other electrical appliances, since it may cause an electrical shock, excessive heat generation or fire.	
Be sure to use an exclusive power circuit for the equipment, and follow the local technical standards related to the electrical equipment, the internal wiring regulations, and the instruction manual for installation when conducting electrical work.  Insufficient power circuit capacity and improper electrical work may cause an electrical shock or fire.	0
Be sure to use the specified cable for wiring between the indoor and outdoor units. Make the connections securely and route the cable properly so that there is no force pulling the cable at the connection terminals. Improper connections may cause excessive heat generation or fire.	•
When wiring between the indoor and outdoor units, make sure that the terminal cover does not lift off or dismount because of the cable. If the cover is not mounted properly, the terminal connection section may cause an electrical shock, excessive heat generation or fire.	0
Do not damage or modify the power cable.  Damaged or modified power cable may cause an electrical shock or fire.  Placing heavy items on the power cable, and heating or pulling the power cable may damage the cable.	
Do not mix air or gas other than the specified refrigerant (R-410A / R-22) in the refrigerant system.  If air enters the refrigerating system, an excessively high pressure results, causing equipment damage and injury.	
If the refrigerant gas leaks, be sure to locate the leaking point and repair it before charging the refrigerant. After charging refrigerant, make sure that there is no refrigerant leak.  If the leaking point cannot be located and the repair work must be stopped, be sure to perform pump-down and close the service valve, to prevent the refrigerant gas from leaking into the room. The refrigerant gas itself is harmless, but it may generate toxic gases when it contacts flames, such as fan and other heaters, stoves and ranges.	0
When relocating the equipment, make sure that the new installation site has sufficient strength to withstand the weight of the equipment. If the installation site does not have sufficient strength and if the installation work is not conducted securely, the equipment may fall and cause injury.	0

SiBE121135 Introduction

<b>N</b> Warning	
Check to make sure that the power cable plug is not dirty or loose, then insert the plug into a power outlet securely. If the plug has dust or loose connection, it may cause an electrical shock or fire.	0
Be sure to install the product correctly by using the provided standard installation frame. Incorrect use of the installation frame and improper installation may cause the equipment to fall, resulting in injury.	For unitary type only
Be sure to install the product securely in the installation frame mounted on the window frame.  If the unit is not securely mounted, it may fall and cause injury.	For unitary type only
When replacing the coin battery in the remote controller, be sure to dispose of the old battery to prevent children from swallowing it. If a child swallows the coin battery, see a doctor immediately.	0

<u> </u>	
Installation of a leakage breaker is necessary in some cases depending on the conditions of the installation site, to prevent electrical shocks.	0
Do not install the equipment in a place where there is a possibility of combustible gas leaks.  If the combustible gas leaks and remains around the unit, it may cause a fire.	
Check to see if the parts and wires are mounted and connected properly, and if the connections at the soldered or crimped terminals are secure. Improper installation and connections may cause excessive heat generation, fire or an electrical shock.	•
If the installation platform or frame has corroded, replace it. Corroded installation platform or frame may cause the unit to fall, resulting in injury.	0
Check the grounding, and repair it if the equipment is not properly grounded. Improper grounding may cause an electrical shock.	

Introduction SiBE121135

/I Caution	
Be sure to measure the insulation resistance after the repair, and make sure that the resistance is 1 M $\Omega$ or higher. Faulty insulation may cause an electrical shock.	0
Be sure to check the drainage of the indoor unit after the repair. Faulty drainage may cause the water to enter the room and wet the furniture and floor.	0
Do not tilt the unit when removing it. The water inside the unit may spill and wet the furniture and floor.	$\bigcirc$
Be sure to install the packing and seal on the installation frame properly. If the packing and seal are not installed properly, water may enter the room and wet the furniture and floor.	For unitary type only

## 1.2 Used Icons

Icons are used to attract the attention of the reader to specific information. The meaning of each icon is described in the table below:

Icon	Type of Information	Description
Note:	Note	A "note" provides information that is not indispensable, but may nevertheless be valuable to the reader, such as tips and tricks.
Caution	Caution	A "caution" is used when there is danger that the reader, through incorrect manipulation, may damage equipment, loose data, get an unexpected result or has to restart (part of) a procedure.
Warning	Warning	A "warning" is used when there is danger of personal injury.
<b>C</b>	Reference	A "reference" guides the reader to other places in this binder or in this manual, where he/she will find additional information on a specific topic.

# Part 1 List of Functions

1.	Cooli	ing Only	2
		Outdoor Unit	
		Indoor Unit	
2.	Heat	Pump	6
		Outdoor Unit	
	2.2	Indoor Unit	7

List of Functions 1

Cooling Only SiBE121135

## 1. Cooling Only

## 1.1 Outdoor Unit

Category	Functions	3MKS50E3V1B, 4MKS58E3V1B 4MKS75F2V1B	5MKS90E2V3B	Category	Functions	3MKS50E3V1B, 4MKS58E3V1B 4MKS75F2V1B	5MKS90E2V3B
Basic Function	Inverter (with Inverter Power Control)	•	•	Health & Clean	Air-Purifying Filter	_	_
T dilotion	Operation Limit for Cooling (°CDB)	−10 ~46	10 ~46	Oloui!	Photocatalytic Deodorizing Filter	_	_
	Operation Limit for Heating (°CWB)	_	_		Air-Purifying Filter with Photocatalytic	_	_
	PAM Control	•	•		Deodorizing Function		
	Standby Electricity Saving	_	_	-	Titanium Apatite Photocatalytic Air- Purifying Filter		_
Compressor	Oval Scroll Compressor	_	_	-			
	Swing Compressor	•	•	-	Air Filter (Prefilter)	_	_
	Rotary Compressor		_	-	Wipe-Clean Flat Panel	_	
0 ( )	Reluctance DC Motor  nfortable Power-Airflow Flap  — —	-	Washable Grille	_			
Airflow			_	Timer	MOLD PROOF Operation	_	_
	Power-Airflow Dual Flaps				Good-Sleep Cooling Operation	_	
	Power-Airflow Diffuser		_		WEEKLY TIMER Operation	_	_
	Wide-Angle Louvers	_	_	-	24-Hour ON/OFF TIMER	_	_
	Vertical Auto-Swing (Up and Down)		_	\\\\-\\\\-\\\\\-\\\\\\\\\\\\\\\\\\\\\\	NIGHT SET Mode	_	_
	Horizontal Auto-Swing (Right and Left) 3-D Airflow	_	_	Worry Free "Reliability &	Auto-Restart (after Power Failure)	_	_
	0 - 1	_	_	"Reliability & Durability"	Self-Diagnosis (Digital, LED) Display	•	•
Comfort Control	COMFORT AIRFLOW Operation  Auto Fan Speed				Wiring Error Check Function  Anti-Corrosion Treatment of Outdoor Heat Exchanger	•	•
Control	Indoor Unit Quiet Operation	_	_	Flexibility	Multi-Split / Split Type Compatible Indoor Unit		
	NIGHT QUIET Mode (Automatic)	•	•	-	H/P, C/O Compatible Indoor Unit		
	OUTDOOR UNIT QUIET Operation (Manual)	•	•		Flexible Power Supply Correspondence	_	_
	2-Area INTELLIGENT EYE Operation	_	_	-	High Ceiling Application	_	_
	INTELLIGENT EYE Operation	_	_	1	Chargeless	•	65 m
	Quick Warming Function (Preheating Operation)	_	_		Either Side Drain (Right or Left)	_	_
	Hot-Start Function	_	_	1	Power Selection	_	_
	Automatic Defrosting	1 —	_	Remote	5 Dears Cantralinad Castella (C. 11)		
Operation	Automatic Operation	_	_	Control	5-Room Centralized Controller (Option)	_	_
	Program Dry Operation	_	_		Remote Control Adaptor (Normal Open		
	Fan Only	<b> </b>	_	1	Pulse Contact) (Option)	_	_
Lifestyle Convenience	New POWERFUL Operation (Non-Inverter)	_	_		Remote Control Adaptor (Normal Open Contact) (Option)	_	_
	Inverter POWERFUL Operation	_	_	]	DIII-NET Compatible (Adaptor) (Option)	_	_
	Priority-Room Setting	•	•	Remote	Wireless (Option)	_	_
	COOL / HEAT Mode Lock	_	_	Controller	Wired	_	_
	HOME LEAVE Operation	_	_				
	ECONO Operation	_	_				
	Indoor Unit [ON/OFF] Button	_	_				
	Signal Receiving Sign	_	_				
	R/C with Back Light						
	Temperature Display	_					

Note: ● : Holding Functions

— : No Functions

SiBE121135 Cooling Only

## 1.2 Indoor Unit

Category	Functions	FTXS25/35/42/50J2V1B	FTXS60/71GV1B	Category	Functions	FTXS25/35/42/50J2V1B	FTXS60/71GV1B
Basic Function	Inverter (with Inverter Power Control)	•	•	Health & Clean	Air-Purifying Filter	_	
Function	Operation Limit for Cooling (°CDB)	_	_	Clean	Photocatalytic Deodorizing Filter	_	
	Operation Limit for Heating (°CWB)	_			Air-Purifying Filter with Photocatalytic	_	_
	PAM Control	_	_	=	Deodorizing Function		
0	Standby Electricity Saving	_	_	-	Titanium Apatite Photocatalytic Air- Purifying Filter	•	•
Compressor	Oval Scroll Compressor	_	_			_	_
	Swing Compressor	_	_		Air Filter (Prefilter)	•	•
	Rotary Compressor Reluctance DC Motor	_	_		Wipe-Clean Flat Panel Washable Grille	•	•
Comfortable	Power-Airflow Flap	_	$\vdash$	Timer			_
Airflow	Power-Airflow Dual Flaps	•	-		MOLD PROOF Operation		
	Power-Airflow Diffuser	•	•		Good-Sleep Cooling Operation	_	-
	Wide-Angle Louvers	•	-		WEEKLY TIMER Operation 24-Hour ON/OFF TIMER	•	•
	Vertical Auto-Swing (Up and Down)	•			NIGHT SET Mode	•	•
	Horizontal Auto-Swing (Right and Left)	•		Worry Free	Auto-Restart (after Power Failure)	•	•
	3-D Airflow	•		"Reliábility &	Self-Diagnosis (Digital, LED) Display	•	•
	COMFORT AIRFLOW Operation	•	•	_ Durability"	Wiring Error Check Function	_	
Comfort Control	Auto Fan Speed	•	•	-	Anti-Corrosion Treatment of Outdoor Heat Exchanger	_	_
Control	Indoor Unit Quiet Operation	•	•	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	•	•
	NIGHT QUIET Mode (Automatic)	_	_		H/P, C/O Compatible Indoor Unit	•	•
	OUTDOOR UNIT QUIET Operation (Manual)	•	•	-	Flexible Power Supply Correspondence		_
	2-Area INTELLIGENT EYE Operation	•	_		High Ceiling Application		
	INTELLIGENT EYE Operation	_	•		Chargeless	l	_
	Quick Warming Function (Preheating Operation)	_	_		Either Side Drain (Right or Left)	•	•
	Hot-Start Function	_	_		Power Selection	_	
	Automatic Defrosting	_	_	Remote Control	5-Room Centralized Controller (Option)	•	•
Operation	Automatic Operation	_	_	Control	Remote Control Adaptor (Normal Open	•	•
	Program Dry Operation	•	•	  -	Pulse Contact) (Option)		-
	Fan Only	•	•	_	Remote Control Adaptor (Normal Open Contact) (Option)	•	•
Lifestyle Convenience	New POWERFUL Operation (Non-Inverter)	_	_		DIII-NET Compatible (Adaptor) (Option)	•	•
	Inverter POWERFUL Operation	•	•	Remote Controller	Wireless	•	•
	Priority-Room Setting			33.12.01101	Wired (Option)	•	•
	COOL / HEAT Mode Lock	<u> </u>	<u> </u>				<u> </u>
	HOME LEAVE Operation	$\vdash$					<u> </u>
	ECONO Operation	•	•				<u> </u>
	Indoor Unit [ON/OFF] Button	•	•				<u> </u>
	Signal Receiving Sign	•	•				<u> </u>
	R/C with Back Light	$\vdash$					
Note: •	Temperature Display			l			

Note: ● : Holding Functions
— : No Functions

List of Functions 3

Cooling Only SiBE121135

Category	Functions	FFQ25/35/50/60B9V1B	Category	Functions	FFQ25/35/50/60B9V1B
Basic	Inverter (with Inverter Power Control)	•	Health &	Air-Purifying Filter	_
Function	Operation Limit for Cooling (°CDB)	_	Clean	Photocatalytic Deodorizing Filter	
	Operation Limit for Heating (°CWB)	_		Air-Purifying Filter with Photocatalytic	
	PAM Control	_		Deodorizing Function	
	Standby Electricity Saving	_		Titanium Apatite Photocatalytic Air-Purifying	_
Compressor	Oval Scroll Compressor	_	_	Filter	
	Swing Compressor	_		Longlife Filter	•
	Rotary Compressor	_		Wipe-Clean Flat Panel	_
	Reluctance DC Motor	_		Washable Grille	•
Comfortable Airflow	Power-Airflow Flap	_		Filter Cleaning Indicator	•
Airilow	Power-Airflow Dual Flaps	_		Self-Cleaning Decoration Panel (Option)	_
	Power-Airflow Diffuser	_	Timer	MOLD PROOF Operation	_
	Wide-Angle Louvers	_		Good-Sleep Cooling Operation	_
	Vertical Auto-Swing (Up and Down)	•		Schedule Timer Operation	<b>●</b> <b>★</b> 2
	Horizontal Auto-Swing (Right and Left)	_		72-Hour ON/OFF TIMER	<b>●</b> <b>★</b> 1
(	3-D Airflow	_		NIGHT SET Mode	_
	COMFORT AIRFLOW Operation	_	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	•
Comfort	Auto Fan Speed	_		Self-Diagnosis (Digital, LED) Display	•
Control	Indoor Unit Quiet Operation	_		Wiring Error Check Function	_
	NIGHT QUIET Mode (Automatic)	_		Anti-Corrosion Treatment of Outdoor Heat Exchanger	_
	OUTDOOR UNIT QUIET Operation (Manual)	_	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	•
	2-Area INTELLIGENT EYE Operation	_		H/P, C/O Compatible Indoor Unit	•
	INTELLIGENT EYE Operation	_		Flexible Power Supply Correspondence	_
	Quick Warming Function (Preheating Operation)	_		High Ceiling Application	_
	Hot-Start Function	_		Chargeless	_
	Automatic Defrosting	_	_	Either Side Drain (Right or Left)	_
Operation	Automatic Operation	_		Power Selection	_
	Program Dry Operation	•	Remote Control	5-Room Centralized Controller (Option)	_
	Fan Only	•	Control	Remote Control Adaptor (Normal Open Pulse	_
Lifestyle Convenience	New POWERFUL Operation (Non-Inverter)	_		Contact) (Option)	
Convenience	Inverter POWERFUL Operation	_		Remote Control Adaptor (Normal Open Contact) (Option)	_
	Priority-Room Setting			DIII-NET Compatible (Adaptor) (Option)	•
	COOL / HEAT Mode Lock	_	Remote Controller	Wireless (Option)	•
	HOME LEAVE Operation	_	Controller	Wired (Option)	•
	ECONO Operation				
	Indoor Unit [ON/OFF] Button	<b>●</b> <b>★</b> 1			
	Signal Receiving Sign	• ★1			
	Temperature Display	_			
Note:	: Holding Functions		<b>★</b> 1·	with wireless remote controller	

**Note:** ● : Holding Functions

— : No Functions

★1: with wireless remote controller★2: with wired remote controller

SiBE121135 Cooling Only

Category	Functions	FHQ35/50/60BWV1B	FDBQ25B8V1 FBQ35/50/60C8VEB	Category	Functions	FHQ35/50/60BWV1B	FDBQ25B8V1 FBQ35/50/60C8VEB
Basic Function	Inverter (with Inverter Power Control)	•	•	Health & Clean	Air-Purifying Filter	_	_
Function	Operation Limit for Cooling (°CDB)	_	_	Clean	Photocatalytic Deodorizing Filter	_	_
	Operation Limit for Heating (°CWB)	_	_		Air-Purifying Filter with Photocatalytic	_	
	PAM Control	_	_		Deodoriźing Function		
	Standby Electricity Saving	_	_		Titanium Apatite Photocatalytic Air- Purifying Filter	_	
Compressor	Oval Scroll Compressor	_	_		, ,		
	Swing Compressor	_	_		Longlife Filter	•	•
	Rotary Compressor	_	_		Wipe-Clean Flat Panel	_	_
O fo - d - b l -	Reluctance DC Motor	_	_		Washable Grille	•	_
Comfortable Airflow	Power-Airflow Flap	_	_		Filter Cleaning Indicator	•	•
-	Power-Airflow Dual Flaps		_	Timer	Self-Cleaning Decoration Panel (Option)	_	_
	Power-Airflow Diffuser	_	_		MOLD PROOF Operation	_	_
	Wide-Angle Louvers	_	_		Good-Sleep Cooling Operation	_	_
	Vertical Auto-Swing (Up and Down)	•	_		Schedule Timer Operation	<b>★</b> 2	<b>★</b> 2
	Horizontal Auto-Swing (Right and Left)	_	_		72-Hour ON/OFF TIMER	• <b>★</b> 1	_
	3-D Airflow	_	_		NIGHT SET Mode	_	_
+	COMFORT AIRFLOW Operation	_	_	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	•	•
Control	Auto Fan Speed	_	_		Self-Diagnosis (Digital, LED) Display	•	•
Control	Indoor Unit Quiet Operation	_	_		Wiring Error Check Function	_	_
	NIGHT QUIET Mode (Automatic)	_	_		Anti-Corrosion Treatment of Outdoor Heat Exchanger	_	_
	OUTDOOR UNIT QUIET Operation (Manual)	_	_	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	•	•
	2-Area INTELLIGENT EYE Operation	_	_		H/P, C/O Compatible Indoor Unit	•	•
	INTELLIGENT EYE Operation	_	_		Flexible Power Supply Correspondence	_	_
	Quick Warming Function (Preheating Operation)	_	_		High Ceiling Application	•	_
	Hot-Start Function	_	_		Chargeless	_	_
	Automatic Defrosting	_	_		Either Side Drain (Right or Left)		_
Operation	Automatic Operation	_	_		Power Selection	_	_
	Program Dry Operation	•	•	Remote	5-Room Centralized Controller (Option)	_	_
	Fan Only	•	•	Control	Remote Control Adaptor (Normal Open		
Lifestyle Convenience	New POWERFUL Operation (Non-Inverter)	_	_		Pulse Contact) (Option)		_
	Inverter POWERFUL Operation	_	_		Remote Control Adaptor (Normal Open Contact) (Option)		_
	Priority-Room Setting				DIII-NET Compatible (Adaptor) (Option)	•	•
	COOL / HEAT Mode Lock	_	_	Remote	Wireless (Option)	•	_
	HOME LEAVE Operation			Controller	Wired (Option)	•	•
	ECONO Operation						
	Indoor Unit [ON/OFF] Button	<b>●</b> <b>★</b> 1					
	Signal Receiving Sign	◆ <b>★</b> 1					
	Temperature Display	<u> </u>					

**Note:** ● : Holding Functions

--: No Functions

★1: with wireless remote controller

★2: with wired remote controller

List of Functions 5

Heat Pump SiBE121135

## 2. Heat Pump

## 2.1 Outdoor Unit

Category	Functions	3MXS40K2V1B, 3MXS52E3V1B 3MXS68G2V1B, 4MXS68F2V1B	4MXS80E2V3B, 5MXS90E2V3B	Category	Functions	3MXS40K2V1B, 3MXS52E3V1B 3MXS68G2V1B, 4MXS68F2V1B	4MXS80E2V3B, 5MXS90E2V3B
Basic	Inverter (with Inverter Power Control)	•	•	Health &	Air-Purifying Filter	_	_
Function	Operation Limit for Cooling (°CDB)	−10 ~46	−10 ~46	Clean	Photocatalytic Deodorizing Filter	_	_
	Operation Limit for Heating (°CWB)	–15 ~15.5	–15 ~15.5		Air-Purifying Filter with Photocatalytic Deodorizing Function	_	_
	PAM Control	•	•		Titanium Apatite Photocatalytic Air-		
	Standby Electricity Saving	_	_		Purifying Filter		
Compressor	Oval Scroll Compressor	_	_		Air Filter (Prefilter)	_	_
	Swing Compressor	•	•		Wipe-Clean Flat Panel	_	_
	Rotary Compressor	_	_		Washable Grille	_	_
	Reluctance DC Motor	•	•		MOLD PROOF Operation	_	_
Comfortable	Power-Airflow Flap	_	_		Good-Sleep Cooling Operation	_	_
Airflow	Power-Airflow Dual Flaps	_	_	Timer	WEEKLY TIMER Operation	_	_
	Power-Airflow Diffuser	_	_	Worry Free "Reliability & Durability"	24-Hour ON/OFF TIMER	_	_
	Wide-Angle Louvers	_	_		NIGHT SET Mode	_	_
H-	Vertical Auto-Swing (Up and Down)	_	_		Auto-Restart (after Power Failure)	_	_
	Horizontal Auto-Swing (Right and Left)	_	_		Self-Diagnosis (Digital, LED) Display	•	•
	3-D Airflow	_	_		Wiring Error Check Function	•	•
	COMFORT AIRFLOW Operation	_	_		Anti-Corrosion Treatment of Outdoor Heat Exchanger	•	•
Comfort Control	Auto Fan Speed	_	_	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	_	_
	Indoor Unit Quiet Operation	_	_		H/P, C/O Compatible Indoor Unit	_	_
	NIGHT QUIET Mode (Automatic)	•	•		Flexible Power Supply Correspondence	_	_
	OUTDOOR UNIT QUIET Operation (Manual)	•	•		High Ceiling Application	_	_
	2-Area INTELLIGENT EYE Operation	_	_		Chargeless	30 m	30 m
	INTELLIGENT EYE Operation	_	_		Either Side Drain (Right or Left)	_	_
	Quick Warming Function (Preheating Operation)	•	•		Power Selection	_	_
	Hot-Start Function Automatic Defrosting	_		Remote Control	5-Room Centralized Controller (Option)	_	_
Operation	Automatic Operation	_	_		Damata Cantual Adamta (Alamata)		$\vdash$
Speration	Program Dry Operation	$\perp$			Remote Control Adaptor (Normal Open Pulse Contact) (Option)	—	—
	Fan Only	$\vdash$			/ / /		$\vdash$
Lifestyle Convenience	New POWERFUL Operation (Non-Inverter)				Remote Control Adaptor (Normal Open Contact) (Option)	_	_
257511151166	Inverter POWERFUL Operation	<u> </u>	_		DIII-NET Compatible (Adaptor) (Option)	<u> </u>	$\vdash = \vdash$
	Priority-Room Setting	•	•	Remote	Wireless (Option)	<u> </u>	
	COOL / HEAT Mode Lock	•	•	Controller	Wired	_	
	HOME LEAVE Operation						$\vdash$
	ECONO Operation	<del>  _  </del>	_				
	Indoor Unit [ON/OFF] Button	<del>  _  </del>	_				
	Signal Receiving Sign	=					
	R/C with Back Light	<del>-</del>	<u> </u>				
	Temperature Display	$\vdash$					
Note:	: Holding Functions	<u> </u>		<u> </u>	I	<u> </u>	

**Note:** ● : Holding Functions

— : No Functions

SiBE121135 Heat Pump

## 2.2 Indoor Unit

Category	Functions	FTXG25/35/50JV1BW(A)	Category	Functions	FTXG25/35/50JV1BW(A)
Basic Function	Inverter (with Inverter Power Control)	•	Health & Clean	Air-Purifying Filter	_
T direction	Operation Limit for Cooling (°CDB)	_	Olean	Photocatalytic Deodorizing Filter	_
	Operation Limit for Heating (°CWB)	_	_	Air-Purifying Filter with Photocatalytic Deodorizing Function	_
	PAM Control	_	=	Titanium Apatite Photocatalytic Air-Purifying	•
	Standby Electricity Saving	_	=	Filter	
Compressor	Oval Scroll Compressor	_		Air Filter (Prefilter)	•
	Swing Compressor	_		Wipe-Clean Flat Panel	•
	Rotary Compressor	_		Washable Grille	_
O a series de la la	Reluctance DC Motor	_		MOLD PROOF Operation	_
Comfortable Airflow	Power-Airflow Flap	_	Timer  Worry Free "Reliability & Durability"	Good-Sleep Cooling Operation	
	Power-Airflow Dual Flaps Power-Airflow Diffuser	•		WEEKLY TIMER Operation 24-Hour ON/OFF TIMER	•
		-		NIGHT SET Mode	
	Wide-Angle Louvers  Vertical Auto-Swing (Up and Down)	•		Auto-Restart (after Power Failure)	•
	Horizontal Auto-Swing (Op and Down)			Self-Diagnosis (Digital, LED) Display	•
3	3-D Airflow			Wiring Error Check Function	
	COMFORT AIRFLOW Operation	•			
	Auto Fan Speed	•		Anti-Corrosion Treatment of Outdoor Heat Exchanger	_
Control	Indoor Unit Quiet Operation	•	Flexibility		
	NIGHT QUIET Mode (Automatic)			Multi-Split / Split Type Compatible Indoor Unit	•
	OUTDOOR UNIT QUIET Operation (Manual)	•	1	H/P, C/O Compatible Indoor Unit	_
	INTELLIGENT EYE Operation	•		Flexible Power Supply Correspondence	_
	2-Area INTELLIGENT EYE Operation	_	=	High Ceiling Application	_
	Quick Warming Function (Preheating Operation)	_		Chargeless	_
	Hot-Start Function	•	=	Either Side Drain (Right or Left)	•
	Automatic Defrosting	_	1	Power Selection	_
Operation	Automatic Operation	•	Remote		_
	Program Dry Operation	•	Control	5-Room Centralized Controller (Option)  Remote Control Adaptor (Normal Open Pulse	•
Lifestule	Fan Only	•	-	Contact) (Option)	•
Lifestyle Convenience	New POWERFUL Operation (Non-Inverter)	_	_	Remote Control Adaptor (Normal Open Contact) (Option)	•
	Inverter POWERFUL Operation	•		DIII-NET Compatible (Adaptor) (Option)	•
	Priority-Room Setting	_	Remote Controller	Wireless	•
	COOL / HEAT Mode Lock			Wired (Option)	•
	HOME LEAVE Operation	_	1		
	ECONO Operation	•			
	Indoor Unit [ON/OFF] Button	•	1		
	Signal Receiving Sign	_	1		
	Multi-Colored Indicator Lamp (Multi-Monitor Lamp)	•			
	R/C with Back Light	•			
	Temperature Display				

**Note:** ● : Holding Functions

— : No Functions

List of Functions 7

Heat Pump SiBE121135

Category	Functions	FTXS20/25K2V1B	CTXS15/35K2V1B	Category	Functions	FTXS20/25K2V1B	CTXS15/35K2V1B
Basic Function	Inverter (with Inverter Power Control)	•	•	Health & Clean	Air-Purifying Filter	_	_
T dilotion	Operation Limit for Cooling (°CDB)	_		Olouri	Photocatalytic Deodorizing Filter	_	_
	Operation Limit for Heating (°CWB)	_	_		Air-Purifying Filter with Photocatalytic Deodorizing Function	_	_
	PAM Control	_	_	=	Titanium Apatite Photocatalytic Air- Purifying Filter	•	•
	Standby Electricity Saving —  pressor Oval Scroll Compressor —	_		, ,			
Compressor		_	_		Air Filter (Prefilter)	•	•
	Swing Compressor	_	_		Wipe-Clean Flat Panel	•	•
	Rotary Compressor	_			Washable Grille		_
	Reluctance DC Motor	_	_		MOLD PROOF Operation		_
Comfortable Airflow	Power-Airflow Flap	•	•		Good-Sleep Cooling Operation	_	_
7	Power-Airflow Dual Flaps	_	_	Timer	WEEKLY TIMER Operation	•	•
	Power-Airflow Diffuser	_	_	Worry Free "Reliability & Durability"	24-Hour ON/OFF TIMER	•	•
-	Wide-Angle Louvers	•	•		NIGHT SET Mode	•	•
	Vertical Auto-Swing (Up and Down)	•	•		Auto-Restart (after Power Failure)	•	•
	Horizontal Auto-Swing (Right and Left)	_	_		Self-Diagnosis (Digital, LED) Display	•	•
Comfort	3-D Airflow	_	_		Wiring Error Check Function	_	_
	COMFORT AIRFLOW Operation	•	•		Anti-Corrosion Treatment of Outdoor Heat Exchanger	_	_
Comfort Control	Auto Fan Speed	•	•	Flexibility	+		
	Indoor Unit Quiet Operation	•	•		Multi-Split / Split Type Compatible Indoor Unit	•	_
	NIGHT QUIET Mode (Automatic)	_	_				
	OUTDOOR UNIT QUIET Operation (Manual)	•	•		H/P, C/O Compatible Indoor Unit	_	_
	INTELLIGENT EYE Operation	•	•	-	Flexible Power Supply Correspondence	_	_
	2-Area INTELLIGENT EYE Operation	_	_		High Ceiling Application		_
	Quick Warming Function (Preheating Operation)	_	_	_	Chargeless	_	_
	Hot-Start Function	•	•		Either Side Drain (Right or Left)	•	•
	Automatic Defrosting	_	_		Power Selection	_	_
Operation	Automatic Operation  Program Dry Operation	•	•	Remote Control	5-Room Centralized Controller (Option)	•	•
	Fan Only	•	•		Remote Control Adaptor (Normal Open Pulse Contact) (Option)	•	•
Lifestyle Convenience	New POWERFUL Operation (Non-Inverter)	_	_		Remote Control Adaptor (Normal Open Contact) (Option)	•	•
	Inverter POWERFUL Operation	•	•	1	DIII-NET Compatible (Adaptor) (Option)	•	•
	Priority-Room Setting	_	_	Remote	Wireless	•	•
	COOL / HEAT Mode Lock	_	_	Controller	Wired (Option)	•	•
	HOME LEAVE Operation	_	_				
	ECONO Operation	•	•				
	Indoor Unit [ON/OFF] Button	•	•				
	Signal Receiving Sign	•	•				
	Multi-Colored Indicator Lamp (Multi- Monitor Lamp)	-	_				
	R/C with Back Light	•	•				
1	Temperature Display						

**Note:** ● : Holding Functions

--: No Functions

SiBE121135 Heat Pump

Category	Functions	FTXS25/35/42/50J2V1B	FTXS60/71GV1B	Category	Functions	FTXS25/35/42/50J2V1B	FTXS60/71GV1B
Basic Function	Inverter (with Inverter Power Control)	•	•	Health & Clean	Air-Purifying Filter	_	
Tunction	Operation Limit for Cooling (°CDB)	_	_	Clean	Photocatalytic Deodorizing Filter	_	
	Operation Limit for Heating (°CWB)	_	_		Air-Purifying Filter with Photocatalytic Deodorizing Function	_	
	PAM Control	_	_		Titanium Apatite Photocatalytic Air-	•	•
	Standby Electricity Saving	_	_		Purifying Filter		
Compressor	Oval Scroll Compressor	_	_		Air Filter (Prefilter)	•	•
	Swing Compressor	_	_		Wipe-Clean Flat Panel	•	•
	Rotary Compressor	_	_		Washable Grille	_	_
	Reluctance DC Motor	_			MOLD PROOF Operation	_	
Comfortable Airflow	Power-Airflow Flap	_			Good-Sleep Cooling Operation	_	
7 tilliow	Power-Airflow Dual Flaps	•	•	Timer	WEEKLY TIMER Operation	•	•
	Power-Airflow Diffuser	_		Worry Free "Reliability & Durability"	24-Hour ON/OFF TIMER	•	•
	Wide-Angle Louvers	•	•		NIGHT SET Mode	•	•
	Vertical Auto-Swing (Up and Down)	•	•		Auto-Restart (after Power Failure)	•	•
	Horizontal Auto-Swing (Right and Left)	•	•		Self-Diagnosis (Digital, LED) Display	•	•
	3-D Airflow	•	•		Wiring Error Check Function	_	_
	COMFORT AIRFLOW Operation	•	•		Anti-Corrosion Treatment of Outdoor Heat Exchanger	_	_
Control	Auto Fan Speed	•	•	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	•	•
	Indoor Unit Quiet Operation	•	•		H/P, C/O Compatible Indoor Unit	•	•
	NIGHT QUIET Mode (Automatic)	_	_		Flexible Power Supply Correspondence	_	_
	OUTDOOR UNIT QUIET Operation (Manual)	•	•		High Ceiling Application	_	_
	2-Area INTELLIGENT EYE Operation	•	_		Chargeless	_	_
	INTELLIGENT EYE Operation	_	•		Either Side Drain (Right or Left)	•	•
	Quick Warming Function (Preheating Operation)	_	_		Power Selection	_	
	Hot-Start Function	•	•	Remote Control	5-Room Centralized Controller (Option)	•	•
	Automatic Defrosting	_	_	Control	Cristin Communication (Cpush,		
Operation	Automatic Operation  Program Dry Operation	•	•	-	Remote Control Adaptor (Normal Open Pulse Contact) (Option)	•	•
	Fan Only	•	•		Remote Control Adaptor (Normal Open Contact) (Option)	•	•
Lifestyle Convenience	New POWERFUL Operation (Non-Inverter)	_	_		DIII-NET Compatible (Adaptor) (Option)	•	•
	Inverter POWERFUL Operation	•	•	Remote	Wireless	•	•
	Priority-Room Setting	_	_	Controller	Wired (Option)	•	•
	COOL / HEAT Mode Lock	_	_				
	HOME LEAVE Operation						
	ECONO Operation	•	•				
	Indoor Unit [ON/OFF] Button	•	•				
	Signal Receiving Sign	•	•				
	Multi-Colored Indicator Lamp (Multi- Monitor Lamp)	_	_				
	R/C with Back Light	_	_				
	Temperature Display						
Note:	• : Holding Functions						

**Note:** ● : Holding Functions

— : No Functions

List of Functions 9

Heat Pump SiBE121135

Category	Functions	FVXG25/35/50K2V1B	FVXS25/35/50FV1B	Category	Functions	FVXG25/35/50K2V1B	FVXS25/35/50FV1B
Basic	Inverter (with Inverter Power Control)	•	•	Health &	Air-Purifying Filter	_	
Function	Operation Limit for Cooling (°CDB)	_	_	Clean	Photocatalytic Deodorizing Filter	_	
	Operation Limit for Heating (°CWB)	_	_		Air-Purifying Filter with Photocatalytic Deodorizing Function	_	_
	PAM Control	_			Titanium Apatite Photocatalytic	•	•
	Standby Electricity Saving	_	_		Air-Purifying Filter		
Compressor	Oval Scroll Compressor	_	_	1	Air Filter (Prefilter)	•	•
	Swing Compressor	_	_	1	Wipe-Clean Flat Panel	_	•
	Rotary Compressor	_	_	1	Washable Grille	_	
	Reluctance DC Motor	_	_		MOLD PROOF Operation	_	
Comfortable Airflow	Power-Airflow Flap		_		Good-Sleep Cooling Operation	_	
Allilow	Power-Airflow Dual Flaps	_	_	Timer	WEEKLY TIMER Operation	•	•
	Power-Airflow Diffuser	_	_	_	24-Hour ON/OFF TIMER	•	•
	Wide-Angle Louvers	•	•		NIGHT SET Mode	•	•
	Vertical Auto-Swing (Up and Down)	•	•	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	•	•
	Horizontal Auto-Swing (Right and Left)	_	_		Self-Diagnosis (Digital, LED) Display	•	•
	3-D Airflow	_	_		Wiring Error Check Function	_	
	COMFORT AIRFLOW Operation	_	_		Anti-Corrosion Treatment of Outdoor Heat Exchanger	_	_
Control	Auto Fan Speed	•	•	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	•	•
	Indoor Unit Quiet Operation	•	•		H/P, C/O Compatible Indoor Unit	_	•
	NIGHT QUIET Mode (Automatic)	_	_		Flexible Power Supply Correspondence	_	
	OUTDOOR UNIT QUIET Operation (Manual)	•	•		High Ceiling Application	_	_
	2-Area INTELLIGENT EYE Operation		_		Chargeless	_	
	INTELLIGENT EYE Operation		_		Either Side Drain (Right or Left)	_	
	Quick Warming Function (Preheating Operation)	_	_		Power Selection	_	_
	Hot-Start Function	•	•	Remote Control	5-Room Centralized Controller (Option)	•	•
	Automatic Defrosting	_	_	Control	Remote Control Adaptor (Normal Open Pulse Contact) (Option)	•	•
Operation	Automatic Operation	•	•		Remote Control Adaptor (Normal Open Contact) (Option)	•	•
	RADIANT Operation	•	Ę	Devent	DIII-NET Compatible (Adaptor) (Option)	•	•
	Program Dry Operation	•	•	Remote Controller	Wireless	•	•
Lifestyle Convenience	Fan Only  New POWERFUL Operation (Non-Inverter)	_	_		Wired (Option)	•	
Convenience	Inverter POWERFUL Operation	•	•				
	Priority-Room Setting	+	+				
	COOL / HEAT Mode Lock	$\vdash$	$\vdash$				<del>                                     </del>
	HOME LEAVE Operation	$\vdash$	$\vdash$				<del>                                     </del>
	ECONO Operation	•	-				
	Indoor Unit [ON/OFF] Button	•	•				
		•					
	Signal Receiving Sign  Multi-Colored Indicator Lamp (Multi-		-				
	Monitor Lamp)	_	_				
	R/C with Back Light	•	•				<u> </u>
	Temperature Display  • : Holding Functions						<u> </u>

**Note:** ● : Holding Functions

— : No Functions

SiBE121135 Heat Pump

r	1		1	T			
Category	Functions	FLXS25/35/50/60BAVMB	FDXS25/35E7VMB FDXS50/60C7VMB	Category	Functions	FLXS25/35/50/60BAVMB	FDXS25/35E7VMB FDXS50/60C7VMB
Basic	Inverter (with Inverter Power Control)	•	•	Health &	Air-Purifying Filter	•	_
Function	Operation Limit for Cooling (°CDB)	_	_	Clean	Photocatalytic Deodorizing Filter	•	_
	Operation Limit for Heating (°CWB)	_	_		Air-Purifying Filter with Photocatalytic Deodorizing Function		_
	PAM Control	_	_		Titanium Apatite Photocatalytic Air-		
	Standby Electricity Saving	_	_		Purifying Filter		
Compressor	Oval Scroll Compressor	_	_		Air Filter (Prefilter)	•	•
	Swing Compressor	_	_		Wipe-Clean Flat Panel		_
	Rotary Compressor	_	_		Washable Grille	_	_
	Reluctance DC Motor	_	_		MOLD PROOF Operation	-	_
Comfortable	Power-Airflow Flap	_	_		Good-Sleep Cooling Operation	l	_
Airflow	Power-Airflow Dual Flaps	_	_	Timer	WEEKLY TIMER Operation		_
	Power-Airflow Diffuser	_	_		24-Hour ON/OFF TIMER	•	•
	Wide-Angle Louvers	_	_		NIGHT SET Mode	•	•
	Vertical Auto-Swing (Up and Down)	•	_	Worry Free	Auto-Restart (after Power Failure)	•	•
	Horizontal Auto-Swing (Right and Left)	_	_	"Reliábility & Durability"	Self-Diagnosis (Digital, LED) Display	•	•
	3-D Airflow	_	_		Wiring Error Check Function	_	_
	COMFORT AIRFLOW Operation	_	_		Anti-Corrosion Treatment of Outdoor Heat Exchanger	_	_
Comfort Control	Auto Fan Speed	•	•	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	•	•
	Indoor Unit Quiet Operation	•	•		H/P, C/O Compatible Indoor Unit	_	_
	NIGHT QUIET Mode (Automatic)	_	_		Flexible Power Supply Correspondence	•	•
	OUTDOOR UNIT QUIET Operation (Manual)	•	•		High Ceiling Application	_	_
	2-Area INTELLIGENT EYE Operation	_	_		Chargeless	_	_
	INTELLIGENT EYE Operation	_	_		Either Side Drain (Right or Left)		_
	Quick Warming Function (Preheating Operation)	_	_		Power Selection		_
	Hot-Start Function	•	•	Remote	5-Room Centralized Controller (Option)		
	Automatic Defrosting	_	_	Control	o risem centralized controller (option)		
Operation	Automatic Operation	•	•		Remote Control Adaptor (Normal Open	•	•
	Program Dry Operation	•	•		Pulse Contact) (Option)		
	Fan Only	•	•		Remote Control Adaptor (Normal Open	_	
Lifestyle Convenience	New POWERFUL Operation (Non- Inverter)	_	_		Contact) (Option)	•	•
	Inverter POWERFUL Operation	•	•		DIII-NET Compatible (Adaptor) (Option)	•	•
	Priority-Room Setting	<u> </u>	<u> </u>	Remote Controller	Wireless	•	•
	COOL / HEAT Mode Lock		<u> </u>	Johnsoner	Wired (Option)	_	•
	HOME LEAVE Operation	•	•				<u> </u>
	ECONO Operation						<u> </u>
	Indoor Unit [ON/OFF] Button	•	•				<u> </u>
	Signal Receiving Sign	•	•				
	Multi-Colored Indicator Lamp (Multi- Monitor Lamp)	_	_				
	R/C with Back Light	_	_				<u> </u>
	Temperature Display	_	-				
Note:	<ul><li>: Holding Functions</li></ul>						

**Note:** ● : Holding Functions

— : No Functions

List of Functions 11

Heat Pump SiBE121135

Category	Functions	FCQG35/50/60FVEB	FFQ25/35/50/60B9V1B	Category	Functions	FCQG35/50/60FVEB	FFQ25/35/50/60B9V1B
Basic	Inverter (with Inverter Power Control)	•	•	Health &	Air-Purifying Filter	_	
Function	Operation Limit for Cooling (°CDB)	_	_	Clean	Photocatalytic Deodorizing Filter	_	
	Operation Limit for Heating (°CWB)	_	_		Air-Purifying Filter with Photocatalytic Deodorizing Function	_	_
	PAM Control	_	_		Titanium Apatite Photocatalytic Air-	_	_
	Standby Electricity Saving	_	_	1	Purifying Filter		<u> </u>
Compressor	Oval Scroll Compressor	_	_	-	Longlife Filter	•	•
	Swing Compressor	_	_	-	Wipe-Clean Flat Panel	_	
	Rotary Compressor	_	_	-	Washable Grille	•	•
0 ( )	Reluctance DC Motor	_	_	-	Filter Cleaning Indicator	•	•
Comfortable Airflow	Power-Airflow Flap	_	_	-	Self-Cleaning Decoration Panel (Option)	•	_
7	Power-Airflow Dual Flaps		_	-	MOLD PROOF Operation		
	Power-Airflow Diffuser	_	_		Good-Sleep Cooling Operation	_	
	Wide-Angle Louvers	_	_	Timer	Schedule Timer Operation	<b>★</b> 2	<b>★</b> 2
	Vertical Auto-Swing (Up and Down)	•	•		72-Hour ON/OFF TIMER	<b>◆</b>	<b>◆</b> <b>★</b> 1
	Horizontal Auto-Swing (Right and Left)	_	_		NIGHT SET Mode	_	_
	3-D Airflow	_	_	Worry Free "Reliability &	Auto-Restart (after Power Failure)	•	•
	COMFORT AIRFLOW Operation	_	_	Durability"	Self-Diagnosis (Digital, LED) Display	•	•
Comfort Control	Auto Fan Speed		_		Wiring Error Check Function	_	
Control	Indoor Unit Quiet Operation	_	_		Anti-Corrosion Treatment of Outdoor Heat Exchanger	_	_
	NIGHT QUIET Mode (Automatic)	_	_	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	•	•
	OUTDOOR UNIT QUIET Operation (Manual)		_		H/P, C/O Compatible Indoor Unit	•	•
	2-Area INTELLIGENT EYE Operation	_	_		Flexible Power Supply Correspondence	_	_
	INTELLIGENT EYE Operation	_	_		High Ceiling Application	_	_
	Quick Warming Function (Preheating Operation)	_	_		Chargeless	_	_
	Hot-Start Function	•	•		Either Side Drain (Right or Left)	_	_
	Automatic Defrosting	_	_		Power Selection	_	_
Operation	Automatic Operation	•	•	Remote Control	5-Room Centralized Controller (Option)	_	_
	Program Dry Operation	•	•	Control	Remote Control Adaptor (Normal Open	_	_
Lifestyle	Fan Only  New POWERFUL Operation (Non-	-	•		Pulse Contact) (Option)  Remote Control Adaptor (Normal Open		
Convenience	Inverter)	1		-	Contact) (Option)	_	<u> </u>
	Inverter POWERFUL Operation	_	_		DIII-NET Compatible (Adaptor) (Option)	•	•
	Priority-Room Setting			Remote Controller	Wireless (Option)	•	•
	COOL / HEAT Mode Lock	$\vdash$	_		Wired (Option)	•	•
	HOME LEAVE Operation		_				<u> </u>
	ECONO Operation	_	_				
	Indoor Unit [ON/OFF] Button	*1	*1				
	Signal Receiving Sign	◆ <b>★</b> 1	<b>◆</b> <b>★</b> 1				
	Temperature Display	_	_				

Note: • : Holding Functions

--: No Functions

★1: with wireless remote controller★2: with wired remote controller

SiBE121135 Heat Pump

Category	Functions	FHQ35/50/60BWV1B	FDBQ25B8V1 FBQ35/50/60C8VEB	Category	Functions	FHQ35/50/60BWV1B	FDBQ25B8V1 FBQ35/50/60C8VEB
Basic Function	Inverter (with Inverter Power Control)	•	•	Health &	Air-Purifying Filter	_	_
Function	Operation Limit for Cooling (°CDB)	_	_	Clean	Photocatalytic Deodorizing Filter	_	
	Operation Limit for Heating (°CWB)	_	_		Air-Purifying Filter with Photocatalytic Deodorizing Function	_	_
	PAM Control	_	_		Titanium Apatite Photocatalytic Air-	_	_
_	Standby Electricity Saving	_	_	1	Purifying Filter		
Compressor	Oval Scroll Compressor	_	_	1	Longlife Filter	•	•
	Swing Compressor	_	_		Wipe-Clean Flat Panel	_	_
	Rotary Compressor	_	_		Washable Grille	•	_
	Reluctance DC Motor		_		Filter Cleaning Indicator	•	•
Comfortable Airflow	Power-Airflow Flap		_		Self-Cleaning Decoration Panel (Option)	_	_
Aimow	Power-Airflow Dual Flaps	_	_		MOLD PROOF Operation	_	
	Power-Airflow Diffuser	_	_		Good-Sleep Cooling Operation	_	
	Wide-Angle Louvers	_	_	Timer	Schedule Timer Operation	<b>◆</b> <b>★</b> 2	•
	Vertical Auto-Swing (Up and Down)	•	_		72-Hour ON/OFF TIMER	<b>●</b> <b>★</b> 1	_
	Horizontal Auto-Swing (Right and Left)	_	_		NIGHT SET Mode	_	_
	3-D Airflow	_	_	Worry Free	Auto-Restart (after Power Failure)	•	•
	COMFORT AIRFLOW Operation	_	_	"Reliability & Durability"	Self-Diagnosis (Digital, LED) Display	•	•
Comfort	Auto Fan Speed	_	_	]	Wiring Error Check Function	_	_
Control	Indoor Unit Quiet Operation	_	_		Anti-Corrosion Treatment of Outdoor Heat Exchanger	_	_
	NIGHT QUIET Mode (Automatic)	_	_	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	•	•
	OUTDOOR UNIT QUIET Operation (Manual)	_	_		H/P, C/O Compatible Indoor Unit	•	•
	2-Area INTELLIGENT EYE Operation	_	_		Flexible Power Supply Correspondence	_	_
	INTELLIGENT EYE Operation	_	_		High Ceiling Application	•	_
	Quick Warming Function (Preheating Operation)	_	_		Chargeless	1	_
	Hot-Start Function	•	•		Either Side Drain (Right or Left)	_	_
	Automatic Defrosting	_	_		Power Selection	_	_
Operation	Automatic Operation	•	•	Remote	5-Room Centralized Controller (Option)	_	_
	Program Dry Operation	•	•	Control	Remote Control Adaptor (Normal Open		_
	Fan Only	•	•		Pulse Contact) (Option)		
Lifestyle Convenience	New POWERFUL Operation (Non-Inverter)	_	_		Remote Control Adaptor (Normal Open Contact) (Option)	_	_
	Inverter POWERFUL Operation	_	_		DIII-NET Compatible (Adaptor) (Option)	•	•
	Priority-Room Setting	_	_	Remote Controller	Wireless (Option)	•	_
	COOL / HEAT Mode Lock	_	_	Controller	Wired (Option)	•	•
	HOME LEAVE Operation		-				
	ECONO Operation						
	Indoor Unit [ON/OFF] Button	<b>●</b> <b>★</b> 1	_				
	Signal Receiving Sign	<b>●</b> <b>★</b> 1	_				
	Temperature Display	-	_				
Note:	: Holding Functions			<b>★</b> 1·	with wireless remote controller		·

—: No Functions

★1: with wireless remote controller★2: with wired remote controller

List of Functions 13

# Part 2 Specifications

1.	Cooli	ing Only	15
		Outdoor Unit	
	1.2	Indoor Unit	17
2.	Heat	Pump	22
		Outdoor Unit	
	2.2	Indoor Unit	25

SiBE121135 Cooling Only

## 1. Cooling Only

## 1.1 Outdoor Unit

50 Hz, 230 V

Model			3MKS50E3V1B	4MKS58E3V1B
Casing Color			Ivory White	Ivory White
	Туре		Hermetically Sealed Swing Type	Hermetically Sealed Swing Type
Compressor	Model		2YC36BXD	2YC36BXD
	Motor Output	W	1,100	1,100
Defrigerent Oil	Model		FVC50K	FVC50K
Refrigerant Oil	Charge	L	0.65	0.65
Refrigerant	Туре		R-410A	R-410A
Reingerani	Charge	kg	2.0	2.0
	Н	2/22:2	45	45
Airdan Data	L	m³/min	45	45
Airflow Rate	Н	-6	1,589	1,589
	L	cfm —	1,589	1,589
	Туре		Propeller	Propeller
F	Motor Output	W	53	53
Fan	Running Current	Α	H: 0.33 / L: 0.33	H: 0.33 / L: 0.33
	Power Consumption	W	H: 43 / L: 43	H: 43 / L: 43
Starting Current		Α	5.3	6.7
Dimensions (H	Dimensions (H × W × D)		735 × 936 × 300	735 × 936 × 300
Packaged Dim	nensions (H × W × D)	mm	797 × 992 × 390	797 × 992 × 390
Weight (Mass)		kg	49	49
Gross Weight	(Gross Mass)	kg	56	56
Sound Pressu	re Level	dB(A)	46	46
Sound Power	Level	dB	59	59
	Liquid	mm	φ 6.4 × 3	φ 6.4 × 4
Piping Connection	Gas	mm	ф 9.5 × 3	φ 9.5 × 2, φ 12.7 × 2
Connection	Drain	mm	ф 18.0	ф 18.0
Heat Insulation	า		Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
No. of Wiring (	Connection		3 for Power Supply, 4 for Interunit Wiring	3 for Power Supply, 4 for Interunit Wiring
Max. Interunit Piping Length		m	50 (for Total of Each Room)	50 (for Total of Each Room)
wax. interunit	Piping Length	m	25 (for One Room)	25 (for One Room)
Amount of Additional Charge g/m		g/m	Chargeless	Chargeless
Mary Installatio	an Haisht Difference	m	15 (between Indoor Unit and Outdoor Unit)	15 (between Indoor Unit and Outdoor Unit)
ıvıax. mstallatio	on Height Difference	m	15 (between Indoor Units)	15 (between Indoor Units)
Drawing No.			3D054330#1	3D054329#1

Note:

The data are based on the conditions shown in the table below.

Cooling	Piping Length
Indoor ; 27°CDB / 19°CWB Outdoor ; 35°CDB	7.5 m

Conversion Formulae  $kcal/h = kW \times 860$   $Btu/h = kW \times 3412$  $cfm = m^3/min \times 35.3$ 

Cooling Only SiBE121135

#### 50 Hz, 230 V

Model			4MKS75F2V1B	5MKS90E2V3B		
Casing Color			Ivory White	Ivory White		
	Туре		Hermetically Sealed Swing Type	Hermetically Sealed Swing Type		
Compressor	Model		2YC45DXD	2YC63BXD		
	Motor Output	W	1,380	1,920		
Deficience and Oil	Model		FVC50K	FVC50K		
Refrigerant Oil	Charge	L	0.65	0.75		
) of rice rest	Туре		R-410A	R-410A		
Refrigerant	Charge	kg	2.3	2.95		
	Н		52.7	54.5		
	М	m³/min	49.4	_		
i de Dele	L		43.5	46		
irflow Rate	Н		1,861	1,924		
	М	cfm	1,744	_		
	L		1,536	1,624		
	Туре		Propeller	Propeller		
	Motor Output	W	53	66		
Fan	Running Current	Α	H: 0.20 / M: 0.16 / L: 0.10	H: 0.97 / L: 0.69		
	Power Consumption	W	H: 70 / M: 58 / L: 36	H: 86 / L: 55		
Starting Curren	t	Α	6.2	11.4		
Dimensions (H	$\times$ W $\times$ D)	mm	735 × 936 × 300	770 × 900 × 320		
Packaged Dime	ensions (H × W × D)	mm	797 × 992 × 390	900 × 925 × 390		
Veight (Mass)	, ,	kg	57	69		
Gross Weight (	Gross Mass)	kg	61	78		
Sound Pressur	e Level	dB(A)	48	48		
Sound Power L	.evel	dB	61	62		
	Liquid	mm	φ 6.4 × 4	φ 6.4 × 5		
Piping Connection	Gas	mm	φ 9.5 × 2, φ 12.7 × 1, φ 15.9 × 1	$\phi$ 9.5 × 2, $\phi$ 12.7 × 1, $\phi$ 15.9 × 2		
onnection	Drain	mm	ф 18.0	ф 25.0		
leat Insulation		•	Both Liquid and Gas Pipes	Both Liquid and Gas Pipes		
No. of Wiring Connection			3 for Power Supply, 4 for Interunit Wiring	3 for Power Supply, 4 for Interunit Wiring		
		m	60 (for Total of Each Room)	75 (for Total of Each Room)		
lax. Interunit F	riping Length	m	25 (for One Room)	25 (for One Room)		
mount of Add	itional Charge	g/m	Chargeless	20 (65 m or more)		
		m	15 (between Indoor Unit and Outdoor Unit)	15 (between Indoor Unit and Outdoor Unit)		
/lax. Installatio	n Height Difference	m	15 (between Indoor Units)	7.5 (between Indoor Units)		
Orawing No.		'	3D056453	3D063120		

Note:

The data are based on the conditions shown in the table below.

Cooling	Piping Length
Indoor ; 27°CDB / 19°CWB	5 m (4MKS75F2V1B)
Outdoor ; 35°CDB	7.5 m (5MKS90E2V3B)

 $\begin{aligned} & \text{Conversion Formulae} \\ & \text{kcal/h} = \text{kW} \times 860 \\ & \text{Btu/h} = \text{kW} \times 3412 \\ & \text{cfm} = \text{m}^3\text{/min} \times 35.3 \end{aligned}$ 

SiBE121135 Cooling Only

## 1.2 Indoor Unit

#### **Wall Mounted Type**

50 Hz, 220 - 230 - 240 V

Model			FTXS25J2V1B	FTXS35J2V1B	
Rated Capacity			2.5 kW Class	3.5 kW Class	
Front Panel Color			White	White	
Н			10.8 (381)	11.4 (403)	
Airflow Rate	M	m³/min	7.9 (279)	8.7 (307)	
Alfilow hate	L	(cfm)	5.2 (184)	5.8 (205)	
	SL		3.7 (131)	4.4 (155)	
	Туре		Cross Flow Fan	Cross Flow Fan	
Fan	Motor Output	W	23	23	
	Speed	Steps	5 Steps, Quiet, Auto	5 Steps, Quiet, Auto	
Air Direction C	ontrol		Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward	
Air Filter			Removable / Washable / Mildew Proof	Removable / Washable / Mildew Proof	
Running Curre	nt (Rated)	Α	0.09 - 0.08 - 0.08	0.12 - 0.12 - 0.11	
Power Consur	nption (Rated)	W	18 - 18 - 18	26 - 26 - 26	
Power Factor	(Rated)	%	90.9 - 97.8 - 93.8	98.5 - 94.2 - 98.5	
Temperature (	Control		Microcomputer Control	Microcomputer Control	
Dimensions (H	$I \times W \times D$ )	mm	295 × 800 × 215	295 × 800 × 215	
Packaged Dim	ensions $(H \times W \times D)$	mm	289 × 870 × 366	289 × 870 × 366	
Weight (Mass)		kg	9	10	
Gross Weight	(Gross Mass)	kg	13	14	
Sound Pressure Level	H/M/L/SL	dB(A)	41 / 33 / 25 / 22	45 / 37 / 29 / 23	
Sound Power Level dB		dB	57	61	
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes	
	Liquid	mm	ф 6.4	ф 6.4	
Piping Connection	Gas	mm	ф 9.5	ф 9.5	
	Drain	mm	ф 18.0	ф 18.0	
Drawing No.			3D070570A	3D070571A	

Model			FTXS42J2V1B	FTXS50J2V1B	
Rated Capacity	1		4.2 kW Class	5.0 kW Class	
Front Panel Co	Front Panel Color		White	White	
	Н		11.3 (399)	11.6 (410)	
Airflow Rate	М	m³/min	9.0 (318)	9.2 (325)	
Allilow hate	L	(cfm)	6.8 (240)	7.0 (247)	
	SL		5.9 (208)	6.0 (212)	
	Туре		Cross Flow Fan	Cross Flow Fan	
Fan	Motor Output	W	23	23	
	Speed	Steps	5 Steps, Quiet, Auto	5 Steps, Quiet, Auto	
Air Direction C	ontrol		Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward	
Air Filter			Removable / Washable / Mildew Proof	Removable / Washable / Mildew Proof	
Running Curre	nt (Rated)	Α	0.11 - 0.11 - 0.11	0.12 - 0.12 - 0.11	
Power Consum	ption (Rated)	W	24 - 24 - 24	26 - 26 - 26	
Power Factor (	Rated)	%	99.2 - 94.9 - 90.9	98.5 - 94.2 - 98.5	
Temperature C	ontrol		Microcomputer Control	Microcomputer Control	
Dimensions (H	$\times$ W $\times$ D)	mm	295 × 800 × 215	295 × 800 × 215	
Packaged Dim	ensions $(H \times W \times D)$	mm	289 × 870 × 366	289 × 870 × 366	
Weight (Mass)		kg	10	10	
Gross Weight (	Gross Mass)	kg	14	14	
Sound Pressure Level	H/M/L/SL	dB(A)	45 / 39 / 33 / 30	46 / 40 / 34 / 31	
Sound Power Level dB		dB	61	62	
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes	
Dining	Liquid	mm	ф 6.4	ф 6.4	
Piping Connection	Gas	mm	ф 9.5	ф 12.7	
200011011	Drain	mm	ф 18.0	ф 18.0	
Drawing No.			3D070572A	3D070573A	

Conversion Formulae

 $kcal/h = kW \times 860$   $Btu/h = kW \times 3412$   $cfm = m^3/min \times 35.3$ 

Cooling Only SiBE121135

#### 50 Hz, 220 - 230 - 240 V

Model			FTXS60GV1B	FTXS71GV1B	
Rated Capacity	1		6.0 kW Class	7.1 kW Class	
Front Panel Color			White	White	
	Н		16.0 (565)	17.2 (607)	
Airflow Rate	M	m³/min	13.5 (477)	14.5 (512)	
Alfilow Hate	L	(cfm)	11.3 (399)	11.5 (406)	
	SL		10.1 (357)	10.5 (371)	
	Туре		Cross Flow Fan	Cross Flow Fan	
Fan	Motor Output	W	43	43	
	Speed	Steps	5 Steps, Quiet, Auto	5 Steps, Quiet, Auto	
Air Direction C	ontrol		Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward	
Air Filter			Removable / Washable / Mildew Proof	Removable / Washable / Mildew Proof	
Running Curre	nt (Rated)	Α	0.19 - 0.18 - 0.17	0.21 - 0.20 - 0.19	
Power Consun	nption (Rated)	W	40 - 40 - 40	45 - 45 - 45	
Power Factor (	Rated)	%	95.7 - 96.6 - 98.0	97.4 - 97.8 - 98.7	
Temperature C	ontrol		Microcomputer Control	Microcomputer Control	
Dimensions (H	$\times$ W $\times$ D)	mm	290 × 1,050 × 250	290 × 1,050 × 250	
Packaged Dim	ensions (H × W × D)	mm	361 × 1,145 × 364	361 × 1,145 × 364	
Weight (Mass)		kg	12	12	
Gross Weight	Gross Mass)	kg	18	18	
Sound Pressure Level	H/M/L/SL	dB(A)	45 / 41 / 36 / 33	46 / 42 / 37 / 34	
Sound Power Level dB		dB	61	62	
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes	
5	Liquid	mm	ф 6.4	ф 6.4	
Piping Connection	Gas	mm	ф 12.7	ф 15.9	
Commodium	Drain	mm	ф 18.0	ф 18.0	
Drawing No.			3D065735A	3D065737A	

Conversion Formulae  $kcal/h = kW \times 860$   $Btu/h = kW \times 3412$  $cfm = m^3/min \times 35.3$ 

SiBE121135 Cooling Only

#### **Ceiling Mounted Cassette Type**

#### 50 Hz, 230 V

Model			FFQ25B9V1B	FFQ35B9V1B
Rated Capacit	Rated Capacity		2.5 kW Class	3.5 kW Class
	Model		BYFQ60B8W1	BYFQ60B8W1
Decoration	Color		White	White
Panel	Dimensions $(H \times W \times D)$	mm	55 × 700 × 700	55 × 700 × 700
	Weight (Mass)	kg	2.7	2.7
Airflow Rate	Н	m³/min	9.0 (318)	10.0 (353)
Allilow hate	L	(cfm)	6.5 (230)	6.5 (230)
	Туре		Turbo Fan	Turbo Fan
Fan	Motor Output	W	55	55
	Speed	Steps	2 Steps	2 Steps
Air Direction C	ontrol		Horizontal, Downward	Horizontal, Downward
Running Curre	nt (Rated)	Α	0.37	0.40
Power Consur	nption (Rated)	W	73	84
Power Factor	(Rated)	%	85.8	91.3
Temperature (	Control		Microcomputer Control	Microcomputer Control
Dimensions (H	l × W × D) ★	mm	260 (286) × 575 × 575	260 (286) × 575 × 575
Packaged Dim	ensions (H × W × D)	mm	370 × 687 × 674	370 × 687 × 674
Weight (Mass)		kg	17.5	17.5
Gross Weight	(Gross Mass)	kg	21	21
Sound Pressure Level	H/L	dB(A)	29.5 / 24.5	32.0 / 25.0
Sound Power Level dB		dB	46.5	49.0
Heat Insulation		•	Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
D: :	Liquid	mm	ф 6.4	ф 6.4
Piping Connection	Gas	mm	ф 9.5	ф 9.5
Commodion	Drain	mm	VP20 (O.D. φ 26 / I.D. φ 20)	VP20 (O.D. φ 26 / I.D. φ 20)
Drawing No.			3D060406	3D060408

Model			FFQ50B9V1B	FFQ60B9V1B	
Rated Capacity			5.0 kW Class	6.0 kW Class	
	Model		BYFQ60B8W1	BYFQ60B8W1	
Decoration	Color		White	White	
Panel	Dimensions $(H \times W \times D)$	mm	55 × 700 × 700	55 × 700 × 700	
	Weight (Mass)	kg	2.7	2.7	
Airflow Rate	Н	m³/min	12.0 (424)	15.5 (530)	
Allilow hate	L	(cfm)	8.0 (283)	10.0 (353)	
	Туре		Turbo Fan	Turbo Fan	
Fan	Motor Output	W	55	55	
	Speed	Steps	2 Steps	2 Steps	
Air Direction C	Air Direction Control		Horizontal, Downward	Horizontal, Downward	
Running Curre	Running Current (Rated) A		0.49	0.61	
Power Consumption (Rated) W		W	97	120	
Power Factor	Power Factor (Rated) %		86.1	85.5	
Temperature (	Control		Microcomputer Control	Microcomputer Control	
Dimensions (H	× W × D) ★	mm	260 (286) × 575 × 575	260 (286) × 575 × 575	
Packaged Dim	ensions $(H \times W \times D)$	mm	370 × 687 × 674	370 × 687 × 674	
Weight (Mass)		kg	17.5	17.5	
Gross Weight	(Gross Mass)	kg	21	21	
Sound Pressure H/L dB( Level		dB(A)	36.0 / 27.0	41.0 / 32.0	
Sound Power	_evel	dB	53.0	58.0	
Heat Insulation	1		Both Liquid and Gas Pipes	Both Liquid and Gas Pipes	
Division	Liquid	mm	ф 6.4	ф 6.4	
Piping Connection	Gas	mm	ф 12.7	ф 12.7	
Cominection	Drain	mm	VP20 (O.D. φ 26 / I.D. φ 20)	VP20 (O.D. φ 26 / I.D. φ 20)	
Drawing No.			3D060410	3D040431	

igstar ( ) : dimension including control box

Conversion Formulae  $kcal/h = kW \times 860$   $Btu/h = kW \times 3412$  $cfm = m^3/min \times 35.3$ 

Cooling Only SiBE121135

#### **Ceiling Suspended Type**

#### 50 Hz, 220 - 230 - 240 V

Model			FHQ35BWV1B	FHQ50BWV1B	
Rated Capacity			3.5 kW Class	5.0 kW Class	
Panel Color			White	White	
Airflow Rate	Н	m³/min	13.0 (459)	13.0 (459)	
Allilow hate	L	1117/111111	10.0 (353)	10.0 (353)	
	Туре		Sirocco Fan	Sirocco Fan	
Fan	Motor Output	W	62	62	
	Speed	Steps	2 Steps	2 Steps	
Air Direction C	Control		Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward	
Air Filter	Air Filter		Removable / Washable / Mildew Proof	Removable / Washable / Mildew Proof	
Temperature (	Temperature Control		Microcomputer Control	Microcomputer Control	
Dimensions (F	Dimensions $(H \times W \times D)$ mm		195 × 960 × 680	195 × 960 × 680	
Packaged Dim	Packaged Dimensions (H × W × D) mm		279 × 1,046 × 818	279 × 1,046 × 818	
Weight (Mass)	)	kg	24	25	
Gross Weight	(Gross Mass)	kg	31	32	
Sound Pressure Level	H/L	dB(A)	37 / 32	38 / 33	
Sound Power	Level	dB	53	54	
Heat Insulation	n		Both Liquid and Gas Pipes	Both Liquid and Gas Pipes	
Distant	Liquid	mm	ф 6.4	ф 6.4	
Piping Connection	Gas	mm	ф 9.5	ф 12.7	
Commodium	Drain	mm	VP20 (O.D. φ 26 / I.D. φ 20)	VP20 (O.D. φ 26 / I.D. φ 20)	
Drawing No.			3D075708	3D075709	

Model			FHQ60BWV1B	
Rated Capacity			6.0 kW Class	
Panel Color			White	
Airflow Rate	Н	m³/min	17.0 (600)	
Allilow hate	L	III9/IIIIII	13.0 (459)	
	Туре		Sirocco Fan	
Fan	Motor Output	W	62	
	Speed	Steps	2 Steps	
Air Direction C	ontrol		Right, Left, Horizontal, Downward	
Air Filter			Removable / Washable / Mildew Proof	
Temperature Control			Microcomputer Control	
Dimensions $(H \times W \times D)$ mm		mm	195 × 1,160 × 680	
Packaged Dim	nensions (H × W × D)	mm	279 × 1,246 × 818	
Weight (Mass)	)	kg	27	
Gross Weight	(Gross Mass)	kg	35	
Sound Pressure Level	H/L	dB(A)	39 / 33	
Sound Power	Level	dB	55	
Heat Insulation			Both Liquid and Gas Pipes	
5: -	Liquid	mm	ф 6.4	
Piping Connection	Gas	mm	ф 12.7	
Commodium	Drain	mm	VP20 (O.D. φ 26 / I.D. φ 20)	
Drawing No.			3D075710	

Conversion Formulae  $kcal/h = kW \times 860$   $Btu/h = kW \times 3412$  $cfm = m^3/min \times 35.3$ 

SiBE121135 Cooling Only

#### **Ceiling Mounted Built-in Type**

#### 50 Hz, 230 V

50 Hz, 220 - 230 - 240 V / 60 Hz, 220 V

Model		FDBQ25B8V1		FBQ35C8VEB	
Rated Capacity			2.5 kW Class	3.5 kW Class	
Model			_	BYBS45DJW1	
Decoration	Color		_	White	
Panel	Dimensions (H x W x	( D)	_	55 × 800 × 500	
	Weight (Mass)	kg	_	3.5	
Airflow Rate	Н	m³/min	6.5	16.0	
Alfilow Hate	L	m³/min	5.2	11.0	
	Туре		Sirocco Fan	Sirocco Fan	
Fan	Motor Output	W	10	140	
Speed		Steps	2 Steps	2 Steps	
Air Filter			Resin net with mold resistance	Resin net with mold resistance	
Dimensions $(H \times W \times D)$ mm		mm	230 × 652 × 502	300 × 700 × 700	
Packaged Dim	ensions $(H \times W \times D)$	mm	301 × 753 × 584	325 × 920 × 900	
Weight (Mass)		kg	17	25	
Gross Weight (	(Gross Mass)	kg	18	28	
Sound Pressure Level	H/L	dB(A)	35 / 28	37 / 29	
Sound Power Level H/L dB		dB	55 / 49	63 / —	
Heat Insulation			_	Both Liquid and Gas Pipes	
D''	Liquid	mm	ф 6.35	ф 6.35 (Flare)	
Piping Connection	Gas	mm	ф 9.52	φ 9.52 (Flare)	
COMMODITION	Drain	mm	O.D. ф 27.2	VP25 (O.D. φ 32 / I.D. φ 25)	

Model			FBQ50C8VEB	FBQ60C8VEB	
Rated Capacity			5.0 kW Class	6.0 kW Class	
Model			BYBS45DJW1	BYBS71DJW1	
Decoration	Color		White	White	
Panel	Dimensions (H × W ×	D)	55 × 800 × 500	55 × 1,100 × 500	
	Weight (Mass)	kg	3.5	4.5	
Airflow Rate	Н	m³/min	16.0	18.0	
Alfilow hate	L	mymm	11.0	15.0	
	Туре		Sirocco Fan	Sirocco Fan	
Fan	Motor Output W		140	350	
Speed		Steps	2 Steps	2 Steps	
Air Filter	Air Filter		Resin net with mold resistance	Resin net with mold resistance	
Dimensions (H	Dimensions (H × W × D) mm		$300 \times 700 \times 700$	300 × 1,000 × 700	
Packaged Dim	ensions $(H \times W \times D)$	mm	$355 \times 920 \times 900$	355 × 1,220 × 900	
Weight (Mass)		kg	25	34	
Gross Weight	(Gross Mass)	kg	28	41	
Sound Pressure Level	H/L	dB(A)	37 / 29	37 / 29	
Sound Power Level H / L dB		dB	63 / —	57 / —	
Heat Insulation	Heat Insulation		Both Liquid and Gas Pipes	Both Liquid and Gas Pipes	
Distant	Liquid	mm	ф 6.35 (Flare)	ф 6.35 (Flare)	
Piping Connection	Gas	mm	ф 12.7 (Flare)	ф 12.7 (Flare)	
Commodium	Drain	mm	VP25 (O.D. \( \phi \) 32 / I.D. \( \phi \) 25)	VP25 (O.D. φ 32 / I.D. φ 25)	

Conversion Formulae

 $kcal/h = kW \times 860$   $Btu/h = kW \times 3412$   $cfm = m^3/min \times 35.3$ 

Heat Pump SiBE121135

## 2. Heat Pump

## 2.1 Outdoor Unit

50 Hz, 230 V

Model			3MXS40	K2V1B	3MXS52	E3V1B	
Model	wodei		Cooling	Heating	Cooling	Heating	
Casing Color			Ivory White		lvory	Ivory White	
Туре			Hermetically Sealed Swing Type		Hermetically Sea	aled Swing Type	
Compressor	Model		2YC36	BXD	2YC3	6BXD	
	Motor Output	W	1,10	00	1,1	00	
Refrigerant Oil	Model		FVC:	50K	FVC	50K	
Henigerani Oii	Charge	L	0.6		0.6	35	
Refrigerant	Туре		R-41	0A	R-4	10A	
Hemgerani	Charge	kg	2.0	0	2.	0	
	Н	m³/min	45	45	45	45	
Airflow Rate	L	111-7111111	41	41	45	41	
Allilow Hate	Н	cfm	1,589	1,589	1,589	1,589	
	L	Cilli	1,448	1,448	1,589	1,448	
Туре			Prope	eller	Prop	eller	
Fan	Motor Output	W	53		5	3	
ıan	Running Current	Α	H: 0.33 / L: 0.29		H: 0.33 /	L: 0.29	
	Power Consumption	W	H: 43 / L: 34		H: 43 / L: 34		
Starting Currer		Α	4.0		6.		
Dimensions (H		mm	735 × 936 × 300		735 × 93		
	ensions $(H \times W \times D)$	mm	797 × 992 × 390		797 × 99	02 × 390	
Weight (Mass)		kg	49		4:		
Gross Weight (		kg	56		56		
Sound Pressur		dB(A)	46	47	46	47	
Sound Power L	evel	dB	59	60	59	60	
Dining	Liquid	mm	ф 6.4	×3	ф 6.4 × 3		
Piping Connection	Gas	mm	ф 9.5	×3	φ 9.5 × 2,	φ 12.7 × 1	
	Drain	mm	ф 18		ф 1		
Heat Insulation			Both Liquid an		Both Liquid ar		
No. of Wiring C	onnection		3 for Power Supply, 4		3 for Power Supply,		
Max. Interunit F	Pining Langth	m	50 (for Total of		50 (for Total o		
		m	25 (for On	,	25 (for Or	,	
Amount of Add	itional Charge	g/m	20 (30 m or more)		20 (30 m	,	
May Installatio	n Height Difference	m	15 (between Indoor U	,	15 (between Indoor U		
	Ti ricigiii Dilletelloe	m	7.5 (between I		,	7.5 (between Indoor Units)	
Drawing No.			3D074	4741	3D054	3D054327#1	

Note:

The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB / 19°CWB	Indoor ; 20°CDB	5 m (3MXS40K2V1B)
Outdoor ; 35°CDB	Outdoor ; 7°CDB / 6°CWB	7.5 m (3MXS52E3V1B)

Conversion Formulae  $kcal/h = kW \times 860$   $Btu/h = kW \times 3412$  $cfm = m^3/min \times 35.3$ 

SiBE121135 Heat Pump

#### 50 Hz, 230 V

Model		3MXS68	BG2V1B	4MXS68	8F2V1B		
wodei	Wiodei		Cooling	Heating	Cooling	Heating	
Casing Color		Ivory White		Ivory White			
Туре		Hermetically Sealed Swing Type		Hermetically Sealed Swing Type			
Compressor	Model		2YC4	5DXD	2YC4	5DXD	
	Motor Output	W	1,3	380	1,3	380	
Refrigerant Oil	Model		FVC	50K	FVC	50K	
nelligerani Oli	Charge	L	0.	65	0.0	65	
Refrigerant	Туре		R-4	10A	R-4	10A	
nemgerani	Charge	kg	2.	59	2.	.6	
	Н		52.7	46.4	52.7	46.4	
	M	m³/min	49.4	44.5	49.4	44.5	
Airflow Rate	L		43.5	16.3	43.5	16.3	
Allilow hate	Н		1,861	1,638	1,861	1,638	
	M	cfm	1,744	1,571	1,744	1,571	
	L		1,536	576	1,536	576	
	Туре		Propeller		Propeller		
Fon	Motor Output W		53		53		
Fan	Running Current	Α	H: 0.20 / M: 0.16 / L: 0.10	H: 0.16 / M: 0.14 / L: 0.03	H: 0.20 / M: 0.16 / L: 0.10	H: 0.16 / M: 0.14 / L: 0.03	
	Power Consumption	W	H: 70 / M: 58 / L: 36	H: 55 / M: 48 / L: 10	H: 70 / M: 58 / L: 36	H: 55 / M: 48 / L: 10	
Starting Currer		Α	6.2		6.	.2	
Dimensions (H		mm	735 × 93	36 × 300	735 × 93	36 × 300	
Packaged Dim	ensions $(H \times W \times D)$	mm	797 × 99	92 × 390	797 × 99	92 × 390	
Weight (Mass)		kg	5	8	5	8	
Gross Weight	(Gross Mass)	kg	6	3	6	3	
Sound Pressur	re Level	dB(A)	48	49	48	49	
Sound Power I	Level	dB	61	_	61		
Dining	Liquid	mm	ф 6.4	4 × 3	φ 6.4 × 4		
Piping Connection	Gas	mm	φ 9.5 × 1,	φ 12.7 × 2	φ 9.5 × 2, φ 12.7 × 2		
	Drain	mm	φ 1	8.0	ф 18.0		
Heat Insulation	1		Both Liquid a	nd Gas Pipes	Both Liquid and Gas Pipes		
No. of Wiring Connection		3 for Power Supply, 4 for Interunit Wiring		3 for Power Supply, 4 for Interunit Wiring			
Max. Interunit	Pining Length	m	50 (for Total o		60 (for Total o		
		m	25 (for One Room)		25 (for Or	/	
Amount of Ado	litional Charge	g/m	20 (30 m	,	20 (30 m	,	
May Installation	on Height Difference	m	Λ	Init and Outdoor Unit)	15 (between Indoor U	,	
ivian. Histalialia	AT FROIGHT DIHETERICE	m	7.5 (between Indoor Units)		7.5 (between Indoor Units)		
Drawing No.			3D058	8720A	3D05	3D056404	

Note:

The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB / 19°CWB Outdoor ; 35°CDB	Indoor ; 20°CDB Outdoor ; 7°CDB / 6°CWB	5 m

Conversion Formulae  $kcal/h = kW \times 860$   $Btu/h = kW \times 3412$  $cfm = m^3/min \times 35.3$ 

Heat Pump SiBE121135

#### 50 Hz, 230 V

Model			4MXS8	0E2V3B	5MXS90E	5MXS90E2V3B	
wodei	wodei		Cooling	Heating	Cooling	Heating	
Casing Color			Ivory White		Ivory White		
Туре			Hermetically Sealed Swing Type		Hermetically Sealed Swing Type		
Compressor	Model		2YC6	S3BXD	2YC63E	3XD	
	Motor Output	W	1,	920	1,92	0	
Refrigerant Oil	Model		FVC	C50K	FVC5	0K	
neiligerani Oii	Charge	L	0.	.75	0.75	5	
Defrigerent	Туре		R-4	110A	R-410	)A	
Refrigerant	Charge	kg	2	.99	2.99	)	
	Н		54.5	46.0	57.1	52.5	
	М	m³/min	_	_	54.5	_	
Airflow Rate	L		46	14.7	46.0	14.7	
Alfilow Hate	Н		1,924	1,624	2,016	1,854	
	M	cfm	_	_	1,924	_	
	L		1,624	519	1,624	519	
Type			Proj	peller	Propel	ller	
Fan	Motor Output	W	(	66	66		
	Running Current	Α	H: 0.97 / L: 0.69	H: 0.69 / L: 0.05	H: 1.02 / M: 0.97 / L: 0.69	H: 0.90 / L: 0.05	
	Power Consumption	W	H: 86 / L: 55	H: 55 / L: 9	H: 95 / M: 86 / L: 55	H: 78 / L: 9	
Starting Currer	nt	Α	9.7		11.8	3	
Dimensions (H	$I \times W \times D$ )	mm	770 × 9	00 × 320	770 × 900	× 320	
Packaged Dim	ensions (H × W × D)	mm	900 × 9	25 × 390	900 × 925	× 390	
Weight (Mass)		kg		72	73		
Gross Weight	(Gross Mass)	kg	3	30	80		
Sound Pressu	re Level	dB(A)	48	49	52	52	
Sound Power	Level	dB	60	_	66	_	
	Liquid	mm	φ 6.	4 × 4	φ 6.4 × 5		
Piping Connection	Gas	mm	φ 9.5 × 1, φ 12.	7 × 1, φ 15.9 × 2	φ 9.5 × 2, φ 12.7 × 1, φ 15.9 × 2		
Commodium	Drain	mm	φ 2	25.0	ф 25.0		
Heat Insulation	1		Both Liquid a	and Gas Pipes	Both Liquid and Gas Pipes		
No. of Wiring (	Connection		3 for Power Supply,	4 for Interunit Wiring	3 for Power Supply, 4	for Interunit Wiring	
May Interior	Pining Longth	m	70 (for Total o	of Each Room)	75 (for Total of I	Each Room)	
Max. Interunit	riping Lengui	m	25 (for O	ne Room)	25 (for One	Room)	
Amount of Ado	ditional Charge	g/m	20 (30 m	or more)	20 (30 m o	r more)	
May Installatio	on Height Difference	m	15 (between Indoor l	Unit and Outdoor Unit)	15 (between Indoor Un	it and Outdoor Unit)	
ıvıax. IIIStailatiC	on neight billerence	m	7.5 (between	Indoor Units)	7.5 (between Ir	7.5 (between Indoor Units)	
Drawing No.			3D06	63118	3D063	119	

Note:

The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB / 19°CWB Outdoor ; 35°CDB	Indoor ; 20°CDB Outdoor ; 7°CDB / 6°CWB	7.5 m

Conversion Formulae  $kcal/h = kW \times 860$   $Btu/h = kW \times 3412$  $cfm = m^3/min \times 35.3$ 

SiBE121135 Heat Pump

# 2.2 Indoor Unit

# **Wall Mounted Type**

50 Hz, 220 - 230 - 240 V

Model			FTXG2	JV1BW	FTXG25JV1BA	
Woder			Cooling	Heating	Cooling	Heating
Rated Capacit	Rated Capacity		2.5 kV	/ Class	2.5 kW	/ Class
Front Panel C	olor		WI	nite	Sil	ver
	Н		8.8 (311)	9.6 (339)	8.8 (311)	9.6 (339)
Airflow Rate	M	m³/min	6.8 (240)	7.9 (279)	6.8 (240)	7.9 (279)
Allilow hate	L	(cfm)	4.7 (166)	6.2 (219)	4.7 (166)	6.2 (219)
	SL		3.8 (134)	5.4 (191)	3.8 (134)	5.4 (191)
	Туре		Cross F	low Fan	Cross F	low Fan
Fan	Motor Output	W	2	29	2	9
	Speed	Steps	5 Steps, 0	Quiet, Auto	5 Steps, C	Quiet, Auto
Air Direction C	Control		Right, Left, Horiz	ontal, Downward	Right, Left, Horiz	ontal, Downward
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof	
Running Curre	ent (Rated)	Α	0.09 - 0.08 - 0.08	0.12 - 0.11 - 0.11	0.09 - 0.08 - 0.08	0.12 - 0.11 - 0.11
Power Consur	mption (Rated)	W	18 - 18 - 18	24 - 24 - 24	18 - 18 - 18	24 - 24 - 24
Power Factor	(Rated)	%	90.9 - 97.8 - 93.8	90.9 - 94.9 - 90.9	90.9 - 97.8 - 93.8	90.9 - 94.9 - 90.9
Temperature (	Control		Microcomputer Control		Microcomp	uter Control
Dimensions (H	$H \times W \times D$ )	mm	295 × 915 × 155		295 × 915 × 155	
Packaged Dim	nensions (H × W × D)	mm	285 × 1,003 × 377		285 × 1,003 × 377	
Weight (Mass)	)	kg	1	1	11	
Gross Weight	(Gross Mass)	kg	1	5	1	6
Sound Pressure Level	H/M/L/SL	dB(A)	38 / 32 / 25 / 22	39 / 34 / 28 / 25	38 / 32 / 25 / 22	39 / 34 / 28 / 25
Sound Power Level dB		dB	54	55	54	55
Heat Insulation	n		Both Liquid a	nd Gas Pipes	Both Liquid a	nd Gas Pipes
Dining	Liquid	mm	ф	6.4	ф	6.4
Piping Connection	Gas	mm	ф	9.5	φ:	9.5
	Drain	mm	ф 16.0 с	or ф 18.0	φ 16.0 or φ 18.0	
Drawing No.	<del></del>		3D06	6165A	3D06	6436A

NA - 4 - 1			FTXG35	JV1BW	FTXG3	5JV1BA
Model			Cooling	Heating	Cooling	Heating
Rated Capacity			3.5 kW	Class	3.5 kW	/ Class
Front Panel Co	olor		Wh	nite	Sil	ver
	Н		10.1 (357)	10.8 (381)	10.1 (357)	10.8 (381)
Airflow Rate	M	m³/min	7.3 (258)	8.6 (304)	7.3 (258)	8.6 (304)
Alfilow Hate	L	(cfm)	4.6 (162)	6.4 (226)	4.6 (162)	6.4 (226)
	SL		3.9 (138)	5.6 (198)	3.9 (138)	5.6 (198)
	Туре		Cross F	low Fan	Cross F	low Fan
Fan	Motor Output	W	2	9	2	29
	Speed	Steps	5 Steps, C	Quiet, Auto	5 Steps, C	Quiet, Auto
Air Direction C	ontrol		Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof	
Running Curre	nt (Rated)	Α	0.13 - 0.12 - 0.12	0.16 - 0.15 - 0.14	0.13 - 0.12 - 0.12	0.16 - 0.15 - 0.14
Power Consur	nption (Rated)	W	26 - 26 - 26	32 - 32 - 32	26 - 26 - 26	32 - 32 - 32
Power Factor	Rated)	%	90.9 - 94.2 - 90.3	90.9 - 92.8 - 95.2	90.9 - 94.2 - 90.3	90.9 - 92.8 - 95.2
Temperature 0	Control		Microcomputer Control		Microcomputer Control	
Dimensions (H	$\times$ W $\times$ D)	mm	295 × 915 × 155		295 × 915 × 155	
Packaged Dim	ensions (H × W × D)	mm	285 × 1,003 × 377		285 × 1,003 × 377	
Weight (Mass)		kg	1	1	11	
Gross Weight	(Gross Mass)	kg	1	5	1	6
Sound Pressure Level	H/M/L/SL	dB(A)	42 / 34 / 26 / 23	42 / 36 / 29 / 26	42 / 34 / 26 / 23	42 / 36 / 29 / 26
Sound Power	_evel	dB	58	58	58	58
Heat Insulation	Heat Insulation		Both Liquid a	nd Gas Pipes	Both Liquid a	nd Gas Pipes
Distant.	Liquid	mm	φ (	6.4	ф	6.4
Piping Connection	Gas	mm	φ;	9.5	φ:	9.5
Commodium	Drain	mm	ф 16.0 c	r φ 18.0	ф 16.0 с	or φ 18.0
Drawing No.			3D066	6437A	3D06	6438B

Conversion Formulae

 $kcal/h = kW \times 860$   $Btu/h = kW \times 3412$   $cfm = m^3/min \times 35.3$ 

Heat Pump SiBE121135

#### 50 Hz, 220 - 230 - 240 V

			FTXG50	JV1BW	FTXG5	0JV1BA
Model			Cooling	Heating	Cooling	Heating
Rated Capacity			5.0 kW	/ Class	5.0 kW Class	
Front Panel Co	olor		WI	nite	Sil	ver
	Н		10.3 (364)	11.4 (402)	10.3 (364)	11.4 (402)
A:ufla Data	M	m³/min	8.5 (300)	9.8 (346)	8.5 (300)	9.8 (346)
Airflow Rate	L	(cfm)	6.7 (237)	8.1 (286)	6.7 (237)	8.1 (286)
	SL		5.7 (201)	7.1 (251)	5.7 (201)	7.1 (251)
	Туре		Cross F	low Fan	Cross F	low Fan
Fan	Motor Output	W	4	.0	4	.0
	Speed	Steps	5 Steps, C	Quiet, Auto	5 Steps, C	Quiet, Auto
Air Direction C	ontrol		Right, Left, Horiz	ontal, Downward	Right, Left, Horiz	ontal, Downward
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof	
Running Curre	nt (Rated)	Α	0.16 - 0.15 - 0.14	0.19 - 0.18 - 0.17	0.16 - 0.15 - 0.14	0.19 - 0.18 - 0.17
Power Consur	nption (Rated)	W	32 - 32 - 32	38 - 38 - 38	32 - 32 - 32	38 - 38 - 38
Power Factor	Rated)	%	90.9 - 92.8 - 95.2	90.9 - 91.8 - 93.1	90.9 - 92.8 - 95.2	90.9 - 91.8 - 93.1
Temperature 0	Control		Microcomputer Control		Microcomputer Control	
Dimensions (H	$\times$ W $\times$ D)	mm	295 × 915 × 155		295 × 915 × 155	
Packaged Dim	ensions (H × W × D)	mm	285 × 1,003 × 377		285 × 1,003 × 377	
Weight (Mass)		kg	1	1	11	
Gross Weight	(Gross Mass)	kg	1	5	16	
Sound Pressure Level	H/M/L/SL	dB(A)	44 / 40 / 35 / 32	44 / 40 / 35 / 32	44 / 40/ 35 / 32	44 / 40 / 35 / 32
Sound Power Level dB		dB	60	60	60	60
Heat Insulation			Both Liquid a	nd Gas Pipes	Both Liquid a	nd Gas Pipes
5	Liquid	mm	φ.	6.4	ф	6.4
Piping Connection	Gas	mm	φ 1	2.7	φ 1	2.7
Connection	Drain	mm	φ 1	8.0	ф 18.0	
Drawing No.			3D07	1585	3D07	2083A

Model			CTXS1	5K2V1B	FTXS20K2V1B	
wodei			Cooling	Heating	Cooling	Heating
Rated Capacit	У		1.5 kV	V Class	2.0 kW Class	
Front Panel Co	olor		W	hite and the second sec	WI	nite
	Н		7.9 (279)	9.0 (318)	8.8 (311)	9.5 (335)
Airflow Rate	M	m³/min	6.3 (222)	7.5 (265)	6.7 (237)	7.8 (275)
Allilow Hate	L	(cfm)	4.7 (166)	6.0 (212)	4.7 (166)	6.0 (212)
	SL		3.9 (138)	4.3 (152)	3.9 (138)	4.3 (152)
	Туре		Cross F	Flow Fan	Cross F	low Fan
Fan	Motor Output	W		16	1	6
	Speed	Steps	5 Steps, 0	Quiet, Auto	5 Steps, 0	Quiet, Auto
Air Direction C	ontrol		Right, Left, Horiz	zontal, Downward	Right, Left, Horiz	ontal, Downward
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof	
Running Curre	nt (Rated)	Α	0.19 - 0.18 - 0.17	0.19 - 0.18 - 0.17	0.19 - 0.18 - 0.17	0.19 - 0.18 - 0.17
Power Consur	nption (Rated)	W	40 - 40 - 40	40 - 40 - 40	40 - 40 - 40	40 - 40 - 40
Power Factor	Rated)	%	95.7 - 96.6 - 98.0	95.7 - 96.6 - 98.0	95.7 - 96.6 - 98.0	95.7 - 96.6 - 98.0
Temperature 0	Control		Microcomputer Control		Microcomp	uter Control
Dimensions (H	$\times$ W $\times$ D)	mm	289 × 780 × 215		289 × 780 × 215	
Packaged Dim	ensions (H × W × D)	mm	274 × 850 × 346		274 × 850 × 346	
Weight (Mass)		kg		8	8	
Gross Weight	(Gross Mass)	kg		12	1	2
Sound Pressure Level	H/M/L/SL	dB(A)	37 / 31 / 25 / 21	38 / 33 / 28 / 21	40 / 32 / 24 / 19	40 / 34 / 27 / 19
Sound Power Level dE		dB	53	54	56	56
Heat Insulation	1		Both Liquid a	and Gas Pipes	Both Liquid a	nd Gas Pipes
Distant	Liquid	mm	ф	6.4	ф	6.4
Piping Connection	Gas	mm	ф	9.5	ф	9.5
Commodium	Drain	mm	φ.	18.0	ф 1	8.0
Drawing No.			3D0	74531	3D07	74533

Conversion Formulae  $kcal/h = kW \times 860$   $Btu/h = kW \times 3412$  $cfm = m^3/min \times 35.3$ 

SiBE121135 Heat Pump

#### 50 Hz, 220 - 230 - 240 V

Model			FTXS2	5K2V1B	CTXS3	5K2V1B
		Cooling	Heating	Cooling	Heating	
Rated Capacit	Rated Capacity		2.5 kV	/ Class	3.5 kW Class	
Front Panel Co	olor		W	nite	WI	nite
	Н		9.1 (321)	10.0 (353)	9.2 (325)	10.1 (357)
Airflow Rate	M	m³/min	7.0 (247)	8.0 (282)	7.2 (254)	8.1 (286)
Alfilow Rate	L	(cfm)	5.0 (177)	6.0 (212)	5.2 (184)	6.3 (222)
	SL		3.9 (138)	4.3 (152)	3.9 (138)	4.3 (152)
	Туре		Cross F	low Fan	Cross F	low Fan
Fan	Motor Output	W	1	6	1	6
	Speed	Steps	5 Steps, 0	Quiet, Auto	5 Steps, C	Quiet, Auto
Air Direction C	ontrol		Right, Left, Horiz	ontal, Downward	Right, Left, Horiz	ontal, Downward
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof	
Running Curre	nt (Rated)	Α	0.19 - 0.18 - 0.17	0.19 - 0.18 - 0.17	0.19 - 0.18 - 0.17	0.19 - 0.18 - 0.17
Power Consun	nption (Rated)	W	40 - 40 - 40	40 - 40 - 40	40 - 40 - 40	40 - 40 - 40
Power Factor (	Rated)	%	95.7 - 96.6 - 98.0	95.7 - 96.6 - 98.0	95.7 - 96.6 - 98.0	95.7 - 96.6 - 98.0
Temperature C	Control		Microcomputer Control		Microcomputer Control	
Dimensions (H	$\times$ W $\times$ D)	mm	289 × 780 × 215		289 × 780 × 215	
Packaged Dim	ensions (H × W × D)	mm	274 × 850 × 346		274 × 850 × 346	
Weight (Mass)		kg		8	8	
Gross Weight	(Gross Mass)	kg	1	2	1	2
Sound Pressure Level	H/M/L/SL	dB(A)	41 / 33 / 25 / 19	41 / 34 / 27 / 19	42 / 35 / 28 / 21	41 / 36 / 30 / 21
Sound Power Level dB		dB	57	57	58	57
Heat Insulation			Both Liquid a	nd Gas Pipes	Both Liquid a	nd Gas Pipes
Liquid		mm	ф	6.4	ф	6.4
Piping Connection	Gas	mm	ф	9.5	φ 9.5	
202011011	Drain	mm	φ 1	8.0	φ 1	8.0
Drawing No.			3D07	74534	3D074535	

Model			FTXS2	J2V1B	FTXS3	FTXS35J2V1B	
Wodei			Cooling	Heating	Cooling	Heating	
Rated Capacity	Rated Capacity		2.5 kW	Class	3.5 kW Class		
Front Panel Co	lor		Wh	nite	WI	nite	
	Н		10.8 (381)	11.9 (420)	11.4 (403)	12.4 (438)	
Airflow Rate	М	m³/min	7.9 (279)	9.1 (321)	8.7 (307)	9.5 (335)	
Allilow Hate	L	(cfm)	5.2 (184)	6.4 (226)	5.8 (205)	6.8 (240)	
	SL		3.7 (131)	5.9 (208)	4.4 (155)	6.0 (212)	
	Туре		Cross F	low Fan	Cross F	low Fan	
Fan	Motor Output	W	2	3	2	23	
	Speed	Steps	5 Steps, C	Quiet, Auto	5 Steps, 0	Quiet, Auto	
Air Direction C	ontrol		Right, Left, Horiz	ontal, Downward	Right, Left, Horiz	ontal, Downward	
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof		
Running Curre	nt (Rated)	Α	0.09 - 0.08 - 0.08	0.10 - 0.10 - 0.09	0.12 - 0.12 - 0.11	0.13 - 0.13 - 0.12	
Power Consun	ption (Rated)	W	18 - 18 - 18	21 - 21 - 21	26 - 26 - 26	28 - 28 - 28	
Power Factor (	Rated)	%	90.9 - 97.8 - 93.8	95.5 - 91.3 - 97.2	98.5 - 94.2 - 98.5	97.9 - 93.6 - 97.2	
Temperature C	ontrol		Microcomputer Control		Microcomp	uter Control	
Dimensions (H	$\times W \times D$ )	mm	295 × 800 × 215		295 × 800 × 215		
Packaged Dim	ensions $(H \times W \times D)$	mm	289 × 870 × 366		289 × 870 × 366		
Weight (Mass)		kg	9	9	10		
Gross Weight	Gross Mass)	kg	1	3	1	4	
Sound Pressure Level	H/M/L/SL	dB(A)	41 / 33 / 25 / 22	42 / 35 / 28 / 25	45 / 37 / 29 / 23	45 / 39 / 29 / 26	
Sound Power Level dB		dB	57	58	61	61	
Heat Insulation	Heat Insulation		Both Liquid a	nd Gas Pipes	Both Liquid a	nd Gas Pipes	
Liquid		mm	ф	5.4	ф	6.4	
Piping Connection	Gas	mm	φ:	9.5		9.5	
	Drain	mm	φ 1	8.0	ф 18.0		
Drawing No.			3D070	)565A	3D07	0566A	

Conversion Formulae  $kcal/h = kW \times 860$   $Btu/h = kW \times 3412$  $cfm = m^3/min \times 35.3$ 

Heat Pump SiBE121135

# 50 Hz, 220 - 230 - 240 V

Model			FTXS4	2J2V1B	FTXS5	0J2V1B
Wodel			Cooling	Heating	Cooling	Heating
Rated Capacity			4.2 kV	V Class	5.0 kW Class	
Front Panel Co	olor		WI	hite	W	hite
	Н		11.3 (399)	12.2 (431)	11.6 (410)	12.1 (427)
Airflow Rate	M	m³/min	9.0 (318)	9.7 (343)	9.2 (325)	9.8 (346)
Alfilow hate	L	(cfm)	6.8 (240)	7.3 (258)	7.0 (247)	7.6 (268)
	SL		5.9 (208)	6.4 (228)	6.0 (212)	6.7 (237)
	Туре		Cross F	low Fan	Cross F	low Fan
Fan	Motor Output	W	2	23	2	23
	Speed	Steps	5 Steps, 0	Quiet, Auto	5 Steps, 0	Quiet, Auto
Air Direction C	ontrol		Right, Left, Horiz	ontal, Downward	Right, Left, Horiz	ontal, Downward
Air Filter			Removable / Washable / Mildew Proof		Removable / Wash	able / Mildew Proof
Running Curre	nt (Rated)	Α	0.11 - 0.11 - 0.11	0.14 - 0.14 - 0.13	0.12 - 0.12 - 0.11	0.15 - 0.14 - 0.14
Power Consum	nption (Rated)	W	24 - 24 - 24	30 - 30 - 30	26 - 26 - 26	32 - 32 - 32
Power Factor (	Rated)	%	99.2 - 94.9 - 90.9	97.4 - 93.2 - 96.2	98.5 - 94.2 - 98.5	97.0 - 99.4 - 95.2
Temperature C	Control		Microcomputer Control		Microcomputer Control	
Dimensions (H	$\times$ W $\times$ D)	mm	295 × 800 × 215		295 × 800 × 215	
Packaged Dim	ensions $(H \times W \times D)$	mm	289 × 870 × 366		289 × 870 × 366	
Weight (Mass)		kg	1	0	10	
Gross Weight	(Gross Mass)	kg	1	4	1	4
Sound Pressure Level	H/M/L/SL	dB(A)	45 / 39 / 33 / 30	45 / 39 / 33 / 30	46 / 40 / 34 / 31	47 / 41 / 34 / 31
Sound Power Level dB		dB	61	61	62	63
Heat Insulation			Both Liquid a	ind Gas Pipes	Both Liquid a	ind Gas Pipes
Dining	Liquid	mm	ф	6.4	ф	6.4
Piping Connection	Gas	mm	ф	9.5	ф 12.7	
Commodium	Drain	mm	φ 1	18.0	ф 18.0	
Drawing No.			3D07	0567A	3D07	0568A

Model			FTXS	60GV1B	FTXS7	1GV1B
Model			Cooling	Heating	Cooling	Heating
Rated Capacity			6.0 k\	V Class	7.1 kW Class	
Front Panel Co	olor		W	hite	WI	nite
	Н		16.0 (565)	17.2 (607)	17.2 (607)	19.5 (689)
Airflow Rate	M	m³/min	13.5 (477)	14.9 (526)	14.5 (512)	16.7 (590)
Allilow hate	L	(cfm)	11.3 (399)	12.6 (445)	11.5 (406)	14.2 (501)
	SL		10.1 (357)	11.3 (399)	10.5 (371)	12.6 (445)
	Туре		Cross	Flow Fan	Cross F	low Fan
Fan	Motor Output	W		43	4	13
	Speed	Steps	5 Steps,	Quiet, Auto	5 Steps, C	Quiet, Auto
Air Direction C	ontrol		Right, Left, Hori	zontal, Downward	Right, Left, Horiz	ontal, Downward
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof	
Running Curre	ent (Rated)	Α	0.19 - 0.18 - 0.17	0.21 - 0.20 - 0.19	0.21 - 0.20 - 0.19	0.28 - 0.27 - 0.26
Power Consur	nption (Rated)	W	40 - 40 - 40	45 - 45 - 45	45 - 45 - 45	60 - 60 - 60
Power Factor	(Rated)	%	95.7 - 96.6 - 98.0	97.4 - 97.8 - 98.7	97.4 - 97.8 - 98.7	97.4 - 96.6 - 96.2
Temperature (	Control		Microcomputer Control		Microcomputer Control	
Dimensions (H	$1 \times W \times D$ )	mm	290 × 1,050 × 250		290 × 1,050 × 250	
Packaged Dim	nensions (H × W × D)	mm	361 × 1,	145 × 364	361 × 1,145 × 364	
Weight (Mass)		kg		12	12	
Gross Weight	(Gross Mass)	kg		18	18	
Sound Pressure Level	H/M/L/SL	dB(A)	45 / 41 / 36 / 33	44 / 40 / 35 / 32	46 / 42 / 37 / 34	46 / 42 / 37 / 34
Sound Power Level dB		dB	61	60	62	62
Heat Insulation	า		Both Liquid a	and Gas Pipes	Both Liquid a	nd Gas Pipes
Dining	Liquid	mm	ф	6.4	ф	6.4
Piping Connection	Gas	mm	ф	12.7	φ 1	5.9
Commodium	Drain	mm	ф	18.0	φ 1	8.0
Drawing No.			3D06	5512A	3D06	5513A

Conversion Formulae

 $kcal/h = kW \times 860$   $Btu/h = kW \times 3412$  $cfm = m^3/min \times 35.3$ 

SiBE121135 Heat Pump

# Floor Standing Type

#### 50 Hz, 220 - 230 - 240 V

Model		FVXG25K2V1B		FVXG35K2V1B		
		Cooling	Heating	Cooling	Heating	
Rated Capacity		2.5 kW	/ Class	3.5 kW Class		
olor		Wh	nite	Wh	ite	
Н		8.9 (314)	9.9 (349)	9.1 (321)	10.2 (360)	
М	m³/min	7.0 (247)	7.8 (275)	7.2 (254)	8.0 (282)	
L	(cfm)	5.3 (187)	5.7 (201)	5.3 (187)	5.8 (205)	
SL		4.5 (159)	4.7 (166)	4.5 (159)	5.0 (177)	
Туре		Cross F	low Fan	Cross F	low Fan	
Motor Output	W	3	2	3:	2	
Speed	Steps	5 Steps, C	Quiet, Auto	5 Steps, C	uiet, Auto	
ontrol		Right, Lef	ft, Upward	Right, Lef	t, Upward	
		Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof		
nt (Rated)	Α	0.10 - 0.09 - 0.09	0.11 - 0.11 - 0.10	0.11 - 0.10 - 0.10	0.12 - 0.12 - 0.11	
nption (Rated)	W	19 - 19 - 19	22 - 22 - 22	21 - 21 - 21	24 - 24 - 24	
Rated)	%	86.4 - 91.8 - 88.0	90.9 - 87.0 - 91.7	86.8 - 91.3 - 87.5	90.9 - 87.0 - 90.9	
Control		Microcomputer Control		Microcomputer Control		
$\times$ W $\times$ D)	mm	600 × 950 × 215		600 × 950 × 215		
ensions $(H \times W \times D)$	mm	761 × 1,030 × 314		761 × 1,030 × 314		
	kg	2	2	22		
(Gross Mass)	kg	2	18	2	8	
H/M/L/SL	dB(A)	38 / 32 / 26 / 23	39 / 32 / 26 / 22	39 / 33 / 27 / 24	40 / 33 / 27 / 23	
Sound Power Level dB		54	55	55	56	
1		Both Liquid a	nd Gas Pipes	Both Liquid ar	nd Gas Pipes	
Liquid	mm		-	φ 6		
Gas	mm	φ:	9.5	φ 9	9.5	
Drain	mm	φ1	8.0	ф 1	8.0	
		3D07	1592	3D07	1593	
	Interpretation (Rated)  Interpretation (Rated)  Rated)  Control  X W X D)  Rensions (H X W X D)  (Gross Mass)  H / M / L / SL  Liquid  Gas	H	Cooling   2.5 kW   2.5 kW   M   M   M   M   M   M   M   M   M	Section   Sect	Cooling   Heating   Cooling	

Model			FVXG5	0K2V1B				
Wodei			Cooling	Heating				
Rated Capacity			5.0 kW Class					
Front Panel Co	olor		White					
	H		10.6 (374)	12.2 (431)				
Airflow Rate	M	m³/min	8.9 (314)	10.0 (353)				
Allilow Hate	L	(cfm)	7.3 (258)	7.8 (275)				
	SL		6.0 (212)	6.8 (240)				
	Туре		Cross F	Flow Fan				
Fan	Motor Output	W	;	32				
	Speed	Steps	5 Steps, 0	Quiet, Auto				
Air Direction C	ontrol		Right, Le	Right, Left, Upward				
Air Filter			Removable / Washable / Mildew Proof					
Running Curre	nt (Rated)	Α	0.17 - 0.16 - 0.15	0.18 - 0.17 - 0.17				
Power Consun	nption (Rated)	W	32 - 32 - 32	35 - 35 - 35				
Power Factor (	Rated)	%	85.6 - 87.0 - 88.9 88.4 - 89.5 - 85.8					
Temperature C	Control		Microcomputer Control					
Dimensions (H	$\times$ W $\times$ D)	mm	600 × 950 × 215					
Packaged Dim	ensions $(H \times W \times D)$	mm	761 × 1,030 × 314					
Weight (Mass)		kg		22				
Gross Weight	(Gross Mass)	kg	:	28				
Sound Pressure Level	H/M/L/SL	dB(A)	44 / 40 / 36 / 32	46 / 40 / 34 / 30				
Sound Power	_evel	dB	56	58				
Heat Insulation	1	•	Both Liquid a	and Gas Pipes				
Liquid		mm	ф	6.4				
Piping Connection	Gas	mm	φ 12.7					
Connection	Drain	mm	ф 18.0					
Drawing No.			3D0	71594				

Conversion Formulae  $kcal/h = kW \times 860$   $Btu/h = kW \times 3412$  $cfm = m^3/min \times 35.3$ 

Heat Pump SiBE121135

## 50 Hz, 220 - 230 - 240 V

Model			FVXS2	5FV1B	FVXS3	5FV1B
Wodel			Cooling	Heating	Cooling	Heating
Rated Capacity			2.5 kW	/ Class	3.5 kW Class	
Front Panel Co	olor		Wi	nite	Wi	nite
	Н		8.2 (290)	8.8 (311)	8.5 (300)	9.4 (332)
Airflow Rate	M	m³/min	6.5 (230)	6.9 (244)	6.7 (237)	7.3 (258)
Allilow hate	L	(cfm)	4.8 (169)	5.0 (177)	4.9 (173)	5.2 (184)
	SL		4.1 (145)	4.4 (155)	4.5 (159)	4.7 (166)
	Туре		Turbo	o Fan	Turbo	o Fan
Fan	Motor Output	W	4	.8	4	8
	Speed	Steps	5 Steps, C	Quiet, Auto	5 Steps, C	Quiet, Auto
Air Direction C	ontrol		Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable / Wash	able / Mildew Proof	Removable / Wash	able / Mildew Proof
Running Curre	nt (Rated)	Α	0.14 - 0.13 - 0.12	0.15 - 0.14 - 0.13	0.14 - 0.13 - 0.12	0.15 - 0.14 - 0.13
Power Consur	nption (Rated)	W	15 - 15 - 15	17 - 17 - 17	15 - 15 - 15	17 - 17 - 17
Power Factor	Rated)	%	48.7 - 50.2 - 52.1	51.5 - 52.8 - 54.5	48.7 - 50.2 - 52.1	51.5 - 52.8 - 54.5
Temperature 0	Control		Microcomputer Control		Microcomputer Control	
Dimensions (H	$\times$ W $\times$ D)	mm	600 × 700 × 210		600 × 700 × 210	
Packaged Dim	ensions (H × W × D)	mm	696 × 786 × 286		696 × 786 × 286	
Weight (Mass)		kg	1	4	14	
Gross Weight	(Gross Mass)	kg	1	8	1	8
Sound Pressure Level	H/M/L/SL	dB(A)	38 / 32 / 26 / 23	38 / 32 / 26 / 23	39 / 33 / 27 / 24	39 / 33 / 27 / 24
Sound Power	evel	dB	54	54	55	55
Heat Insulation	Heat Insulation		Both Liquid a	nd Gas Pipes	Both Liquid a	nd Gas Pipes
D: :	Liquid	mm	φ.	6.4	ф	6.4
Piping Connection	Gas	mm	φ:	9.5	ф 9.5	
Commodium	Drain	mm	φ 2	20.0	φ 20.0	
Drawing No.			3D07	71661	3D071662	

Model			F	VXS50FV1B			
woder			Cooling	Heating			
Rated Capacity			5.0 kW Class				
Front Panel C	olor		White				
	Н		10.7 (378)	11.8 (417)			
Airflow Rate	M	m³/min	9.2 (325)	10.1 (357)			
Alfilow hate	L	(cfm)	7.8 (275)	8.5 (300)			
	SL		6.6 (233)	7.1 (251)			
	Туре			Turbo Fan			
Fan	Motor Output	W		48			
	Speed	Steps	5 Ste	eps, Quiet, Auto			
Air Direction C	Control		Right, Left,	Horizontal, Downward			
Air Filter			Removable / Washable / Mildew Proof				
Running Curre	ent (Rated)	Α	0.18 - 0.17 - 0.16	0.20 - 0.19 - 0.18			
Power Consur	mption (Rated)	W	27 - 27 - 27	34 - 34 - 34			
Power Factor	(Rated)	%	68.1 - 69.1 - 70.3 77.3 - 77.8 - 78.7				
Temperature (	Control		Microcomputer Control				
Dimensions (F	$1 \times W \times D$ )	mm	600 × 700 × 210				
Packaged Dim	nensions (H × W × D)	mm	696 × 786 × 286				
Weight (Mass)		kg		14			
Gross Weight	(Gross Mass)	kg		18			
Sound Pressure Level	H/M/L/SL	dB(A)	44 / 40 / 36 / 32	45 / 40 / 36 / 32			
Sound Power	Level	dB	56	57			
Heat Insulation	n	•	Both Lic	quid and Gas Pipes			
Liquid		mm		φ 6.4			
Piping Connection	Gas	mm		φ 12.7			
Connection	Drain	mm	ф 20.0				
Drawing No.	*		3D071663				

Conversion Formulae  $kcal/h = kW \times 860$   $Btu/h = kW \times 3412$  $cfm = m^3/min \times 35.3$ 

SiBE121135 Heat Pump

# Floor / Ceiling Suspended Dual Type

#### 50 Hz, 220 - 230 - 240 V

Model			FLXS2	BAVMB	FLXS35	BAVMB
Wiodei			Cooling	Heating	Cooling	Heating
Rated Capacity			2.5 kV	V Class	3.5 kW Class	
Front Panel Co	olor		Almon	d White	Almono	d White
	Н		7.6 (268)	9.2 (325)	8.6 (304)	9.8 (346)
Airflow Rate	М	m³/min	6.8 (240)	8.3 (293)	7.6 (268)	8.9 (314)
Alliow Hate	L	(cfm)	6.0 (212)	7.4 (261)	6.6 (233)	8.0 (282)
	SL		5.2 (184)	6.6 (233)	5.6 (198)	7.2 (254)
	Туре		Siroc	co Fan	Siroco	o Fan
Fan	Motor Output	W	;	34	3	4
	Speed	Steps	5 Steps, 6	Quiet, Auto	5 Steps, C	Quiet, Auto
Air Direction C	ontrol		Right, Left, Horiz	zontal, Downward	Right, Left, Horiz	ontal, Downward
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof	
Running Curre	ent (Rated)	Α	0.33 - 0.32 - 0.31	0.36 - 0.34 - 0.33	0.38 - 0.36 - 0.35	0.38 - 0.36 - 0.35
Power Consur	nption (Rated)	W	70 - 70 - 70	74 - 74 - 74	78 - 78 - 78	78 - 78 - 78
Power Factor	(Rated)	%	96.4 - 95.1 - 94.1	93.4 - 94.6 - 93.4	93.3 - 94.2 - 92.9	93.3 - 94.2 - 92.9
Temperature (	Control		Microcomputer Control		Microcomputer Control	
Dimensions (H	$1 \times W \times D$ )	mm	490 × 1,050 × 200		490 × 1,050 × 200	
Packaged Dim	nensions (H × W × D)	mm	280× 1,100 × 566		280 × 1,100 × 566	
Weight (Mass)	)	kg	-	16	16	
Gross Weight	(Gross Mass)	kg	2	22	2	2
Sound Pressure Level	H/M/L/SL	dB(A)	37 / 34 / 31 / 28	37 / 34 / 31 / 29	38 / 35 / 32 / 29	39 / 36 / 33 / 30
Sound Power Level dB		dB	53	53	54	55
Heat Insulation			Both Liquid a	and Gas Pipes	Both Liquid a	nd Gas Pipes
D'	Liquid	mm	ф	6.4	φ (	6.4
Piping Connection	Gas	mm	ф	9.5	ф 9	9.5
Commodium	Drain	mm	φ.	18.0	ф 1	8.0
Drawing No.			3D0	59564	3D05	9567

## 50 Hz, 220 - 230 - 240 V

## 50 Hz, 230 V

Model			FLXS50	BAVMB	FLXS60BAVMB		
wodei	wodei		Cooling	Heating	Cooling	Heating	
Rated Capacit	у		5.0 kV	V Class	6.0 kV	/ Class	
Front Panel Co	olor		Almon	d White	Almon	d White	
	Н		11.4 (403)	12.1 (427)	12.0 (424)	12.8 (452)	
Airflow Rate	М	m³/min	10.0 (353)	9.8 (346)	10.7 (378)	10.6 (374)	
Allilow hate	L	(cfm)	8.5 (300)	7.5 (265)	9.3 (328)	8.4 (297)	
	SL		7.5 (265)	6.8 (240)	8.3 (293)	7.5 (265)	
	Туре		Siroco	co Fan	Siroco	co Fan	
Fan	Motor Output	W	3	34	3	34	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, 0	Quiet, Auto	
Air Direction C	ontrol		Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward		
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof		
Running Curre	nt (Rated)	Α	0.48 - 0.45 - 0.43	0.47 - 0.45 - 0.44	0.47	0.45	
Power Consur	nption (Rated)	W	96 - 96 - 96	96 - 96 - 96	98	96	
Power Factor	(Rated)	%	90.9 - 92.8 - 93.0	92.8 - 92.8 - 90.9	90.7	92.8	
Temperature (	Control		Microcomputer Control		Microcomputer Control		
Dimensions (H	$I \times W \times D$ )	mm	490 × 1,050 × 200		490 × 1,050 × 200		
Packaged Dim	ensions $(H \times W \times D)$	mm	280 × 1,	100 × 566	280 × 1,100 × 566		
Weight (Mass)		kg	1	17	17		
Gross Weight	(Gross Mass)	kg	2	24	24		
Sound Pressure Level	H/M/L/SL	dB(A)	47 / 43 / 39 / 36	46 / 41 / 35 / 33	48 / 45 / 41 / 39	47 / 42 / 37 / 34	
Sound Power	Level	dB	63	62	64	63	
Heat Insulation		•	Both Liquid a	and Gas Pipes	Both Liquid a	nd Gas Pipes	
	Liquid	mm	ф	6.4	ф	6.4	
Piping Connection	Gas	mm	φ :	12.7	φ 12.7		
Connection	Drain	mm	φ 18.0		ф 18.0		
Drawing No.	•		3D071657		3D050882		

Conversion Formulae

 $kcal/h = kW \times 860$   $Btu/h = kW \times 3412$   $cfm = m^3/min \times 35.3$ 

**Heat Pump** SiBE121135

# **Duct Connected Type**

50 Hz, 230 V

Model			FDXS2	5E7VMB	FDXS35E7VMB		
Wodel			Cooling	Heating	Cooling	Heating	
Rated Capacit	у		2.5 kV	V Class	3.5 kW Class		
	Н		8.7 (307)	8.7 (307)	8.7 (307)	8.7 (307)	
Airflow Rate	М	m³/min	8.0 (282)	8.0 (282)	8.0 (282)	8.0 (282)	
Allilow hate	L	(cfm)	7.3 (258)	7.3 (258)	7.3 (258)	7.3 (258)	
	SL		6.2 (219)	6.2 (219)	6.2 (219)	6.2 (219)	
	Туре		Siroc	co Fan	Siroc	co Fan	
Fan	Motor Output	W	(	62	(	52	
	Speed	Steps	5 Steps,	Quiet, Auto	5 Steps, 0	Quiet, Auto	
Air Filter			Removable / Wasl	nable / Mildew Proof	Removable / Wash	nable / Mildew Proof	
Running Curre	nt (Rated)	A	0.48	0.48	0.48	0.48	
Power Consur	nption (Rated)	W	71	71	71	71	
Power Factor	(Rated)	%	64.3	64.3	64.3	64.3	
Temperature 0	Control		Microcomputer Control		Microcomp	uter Control	
Dimensions (H	$I \times W \times D$ )	mm	200 × 700 × 620		200 × 7	00 × 620	
Packaged Dim	ensions $(H \times W \times D)$	mm	274 × 906 × 751		274 × 906 × 751		
Weight (Mass)		kg		21	21		
Gross Weight	(Gross Mass)	kg		29	29		
Sound Pressure Level	H/M/L/SL	dB(A)	35 / 33 / 31 / 29	35 / 33 / 31 / 29	35 / 33 / 31 / 29	35 / 33 / 31 / 29	
Sound Power	Level	dB	53	53	53	53	
External Static Pressure Pa		Pa	,	30		30	
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid a	and Gas Pipes	
Liquid		mm	ф	6.4	ф	6.4	
Piping Connection	Gas	mm	ф	9.5	φ 9.5		
Connection	Drain	mm	VP20 (O.D. ¢	26 / I.D. φ 20)	VP20 (O.D. φ 26 / I.D. φ 20)		
Drawing No.			3D0	60029	3D0	60030	

Model -		FDXS50C7VMB		FDXS60C7VMB		
		Cooling	Heating	Cooling	Heating	
1		5.0 kW	Class	6.0 kW Class		
Н		12.0 (424)	12.0 (424)	16.0 (565)	16.0 (565)	
M	m³/min	11.0 (388)	11.0 (388)	14.8 (523)	14.8 (523)	
L	(cfm)	10.0 (353)	10.0 (353)	13.5 (477)	13.5 (477)	
SL		8.4 (297)	8.4 (297)	11.2 (395)	11.2 (395)	
Туре		Siroco	o Fan	Siroco	co Fan	
Motor Output	W	13	30	1:	30	
Speed	Steps	5 Steps, C	Quiet, Auto	5 Steps, 0	Quiet, Auto	
		Removable / Wash	able / Mildew Proof	Removable / Wash	able / Mildew Proof	
nt (Rated)	Α	0.64	0.64	0.74	0.74	
ption (Rated)	W	140	140	160	160	
Rated)	%	95.1	95.1	94.0	94.0	
ontrol		Microcomputer Control		Microcomputer Control		
$\times$ W $\times$ D)	mm	200 × 900 × 620		200 × 1,100 × 620		
ensions (H × W × D)	mm	266 × 1,106 × 751		266 × 1,306 × 751		
	kg	27		30		
Gross Mass)	kg	3	4	37		
H/M/L/SL	dB(A)	37 / 35 / 33 / 31	37 / 35 / 33 / 31	38 / 36 / 34 / 32	38 / 36 / 34 / 32	
_evel	dB	55	55	56	56	
Pressure	Pa	4	0	4	.0	
Heat Insulation		Both Liquid a	nd Gas Pipes	Both Liquid a	nd Gas Pipes	
Liquid	mm	φ 6	6.4	ф	6.4	
Gas	mm	ф 1	2.7	ф 1	2.7	
Drain	mm	VP20 (O.D. φ	26 / I.D. φ 20)	VP20 (O.D. ф	26 / I.D. φ 20)	
		3D06	0033	3D06	5477	
	H M L SL Type Motor Output Speed  Int (Rated) Intion (Rated) Intio	H	Cooling   5.0 kW   12.0 (424)   M   12.0 (424)   M   11.0 (388)   L   (cfm)   10.0 (353)   SL   8.4 (297)   Type   Sirocc   Motor Output   W   13   Speed   Steps   5 Steps   5 Steps   Growth of the test of th	Total Control Contro	Cooling   Heating   Cooling	

Conversion Formulae

32 Specifications

 $\begin{aligned} & \text{kcal/h} = \text{kW} \times 860 \\ & \text{Btu/h} = \text{kW} \times 3412 \\ & \text{cfm} = \text{m}^3/\text{min} \times 35.3 \end{aligned}$ 

SiBE121135 **Heat Pump** 

# **Ceiling Mounted Cassette Type**

#### 50 Hz, 220 - 230 - 240 V

Model		FCQG3	5FVEB	FCQG50FVEB			
Wodei			Cooling	Heating	Cooling	Heating	
Rated Capacity	1		3.5 kW	Class	5.0 kW	Class	
	Model		BYCQ140D7W1 / BYCQ140	D7W1W / BYCQ140D7GW1	BYCQ140D7W1 / BYCQ140	D7W1W / BYCQ140D7GW1	
	Color		Fresh	White	Fresh	White	
Decoration Panel	Dimensions $(H \times W \times D)$	mm	$60 \times 950 \times 950 / 60 \times 950$	0 × 950 / 145 × 950 × 950	60 × 950 × 950 / 60 × 950	0 × 950 / 145 × 950 × 950	
T diloi	Weight (Mass)	kg	5.4 / 5.4	4 / 10.3	5.4 / 5.	4 / 10.3	
	Air Filter		Resin net with r	mold resistance	Resin net with	mold resistance	
	Н		12.5	12.5	12.6	12.6	
Airflow Rate	M	m³/min	10.6	10.6	10.7	10.7	
	L		8.7	8.7	8.7	8.7	
	Туре		Turbo Fan		Turbo Fan		
Fan	Motor Output	W	48		48		
	Speed	Steps	3 Steps		3 Steps		
Dimensions (H	$\times$ W $\times$ D)	mm	204 × 840 × 840		204 × 840 × 840		
Packaged Dime	ensions $(H \times W \times D)$	mm	220 × 880 × 880		220 × 880 × 880		
Weight (Mass)		kg	18		19		
Gross Weight (	Gross Mass)	kg	22		23		
Sound Pressure Level	H/M/L	dB(A)	31 / 29 / 27		31 / 29 / 27		
Sound Power Level	Н	dB	4	49		49	
Heat Insulation		Foamed polystyrene /	Foamed polyethylene	Foamed polystyrene /	Foamed polyethylene		
D: :	Liquid	mm	ф 6.35 (Flare)		φ 6.35 (Flare)		
Piping Connection	Gas	mm	ф 9.52	(Flare)	ф 12.7 (Flare)		
	Drain	mm	VP25 (O.D. φ 32 / I.D. φ 25)		VP25 (O.D. φ 32 / I.D. φ 25)		
Drawing No.		•	3D07	6994	3D07	6994	

Madal			FCQG	60FVEB			
Model			Cooling	Heating			
Rated Capacity			6.0 kW	/ Class			
	Model		BYCQ140D7W1 / BYCQ140D7W1W / BYCQ140D7GW1				
B	Color		Fresh	White			
Decoration Panel	Dimensions $(H \times W \times D)$	mm	$60 \times 950 \times 950 / 60 \times 950$	0 × 950 / 145 × 950 × 950			
	Weight (Mass)	kg	5.4 / 5.	4 / 10.3			
	Air Filter		Resin net with	mold resistance			
	Н		13.6	13.6			
Airflow Rate	М	m³/min	11.2	11.2			
	L		8.7	8.7			
	Туре		Turbo Fan				
Fan	Motor Output	W	48				
	Speed	Steps	3 Steps				
Dimensions (H	$\times$ W $\times$ D)	mm	204 × 840 × 840				
Packaged Dime	ensions (H × W × D)	mm	220 × 880 × 880				
Weight (Mass)		kg	19				
Gross Weight (	Gross Mass)	kg	2	3			
Sound Pressure Level	H/M/L	dB(A)	33 / 31 / 28				
Sound Power Level	н	dB	51				
Heat Insulation			Foamed polystyrene /	Foamed polyethylene			
Division	Liquid	mm	φ 6.35 (Flare)				
Piping Connection	Gas	mm	φ 12.7 (Flare)				
202011011	Drain	mm	VP25 (O.D. φ 32 / I.D. φ 25)				
Drawing No.			3D07	3D076994			

Conversion Formulae

 $kcal/h = kW \times 860$   $Btu/h = kW \times 3412$   $cfm = m^3/min \times 35.3$ 

Heat Pump SiBE121135

# 50 Hz, 230 V

Model			FFQ25B9V1B		FFQ35B9V1B		
			Cooling	Heating	Cooling	Heating	
Rated Capacity			2.5 kV	V Class	3.5 kW Class		
	Model		BYFQ6	60B8W1	BYFQ6	60B8W1	
Decoration	Color		W	hite	W	hite	
Panel	Dimensions $(H \times W \times D)$	mm	55 × 70	00 × 700	55 × 70	00 × 700	
	Weight (Mass)	kg	2	2.7	2	2.7	
Airflow Rate	Н	m³/min	9.0 (318)	9.0 (318)	10.0 (353)	10.0 (353)	
Allilow hate	L	(cfm)	6.5 (230)	6.5 (230)	6.5 (230)	6.5 (230)	
	Туре		Turb	o Fan	Turb	o Fan	
Fan	Motor Output	W	Ę	55	Ę	55	
	Speed	Steps	2 Steps		2 Steps		
Air Direction C	ontrol		Horizontal, Downward		Horizontal, Downward		
Running Curre	ent (Rated)	Α	0.37	0.32	0.40	0.36	
Power Consur	nption (Rated)	W	73	64	84	76	
Power Factor	(Rated)	%	85.8	87.0	91.3	91.8	
Temperature (	Control		Microcomputer Control		Microcomputer Control		
Dimensions (H	1 × W × D) ★	mm	260 (286) × 575 × 575		260 (286) × 575 × 575		
Packaged Dim	nensions (H × W × D)	mm	370 × 687 × 674		370 × 687 × 674		
Weight (Mass)		kg	17	7.5	17.5		
Gross Weight	(Gross Mass)	kg	2	21	21		
Sound Pressure Level	H/L	dB(A)			32.0 / 25.0		
Sound Power Level dB		dB	40	6.5	4:	9.0	
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid a	and Gas Pipes	
D'	Liquid	mm	φ 6.4		ф	6.4	
Piping Connection	Gas	mm	φ 9.5		φ 9.5		
Drain		mm	VP20 (O.D φ	26 / I.D ф 20)	VP20 (O.D φ 26 / I.D φ 20)		
Drawing No.			3D06	60405	3D06	60407	

			FFQ50	B9V1B	FFQ60B9V1B		
Model	Model		Cooling	Heating	Cooling	Heating	
Rated Capacity			5.0 kW	/ Class	6.0 kW Class		
	Model		BYFQ6	0B8W1	BYFQ6	60B8W1	
Decoration	Color		WI	nite	WI	nite	
Panel	Dimensions $(H \times W \times D)$	mm	55 × 70	0×700	55 × 70	0 × 700	
	Weight (Mass)	kg	2	.7	2	.7	
Airflow Rate	Н	m³/min	12.0 (424)	12.0 (424)	15.0 (530)	15.0 (530)	
Airtiow Hate	L	(cfm)	8.0 (283)	8.0 (283)	10.0 (353)	10.0 (353)	
	Туре		Turbo	o Fan	Turbo	Fan	
Fan	Motor Output	W	5	5	5	5	
	Speed	Steps	2 Steps		2 Steps		
Air Direction C	Control		Horizontal, Downward		Horizontal, Downward		
Running Curre	ent (Rated)	Α	0.49	0.45	0.61	0.56	
Power Consur	mption (Rated)	W	97	89	120	111	
Power Factor	(Rated)	%	86.1	86.0	85.5	86.2	
Temperature (	Control		Microcomputer Control		Microcomputer Control		
Dimensions (H	1 × W × D) ★	mm	260 (286) × 575 × 575		260 (286) × 575 × 575		
Packaged Dim	nensions (H × W × D)	mm	370 × 687 × 674		370 × 687 × 674		
Weight (Mass)	)	kg	17	7.5	17.5		
Gross Weight	(Gross Mass)	kg	2	:1	21		
Sound Pressure Level	H/L	dB(A)	36.0	/ 27.0	41.0 / 32.0	41.0 / 32.0	
Sound Power Level dB		dB	53.0		58.0	_	
Heat Insulation			Both Liquid a	nd Gas Pipes	Both Liquid a	nd Gas Pipes	
<b>5</b>	Liquid	mm	φ.	6.4	ф	6.4	
Piping Connection	Gas	mm	φ 1	2.7	φ 12.7		
0011110011011	Drain	mm	VP20 (O.D φ	26 / I.D ф 20)	VP20 (O.D φ 26 / I.D φ 20)		
Drawing No.			3D06	60409	3D04	10436	

**Note:** ★ ( ) : dimension including control box

Conversion Formulae  $kcal/h = kW \times 860$   $Btu/h = kW \times 3412$  $cfm = m^3/min \times 35.3$ 

SiBE121135 Heat Pump

# **Ceiling Suspended Type**

#### 50 Hz, 220 - 230 - 240 V

Model			FHQ35BWV1B		FHQ50BWV1B		
wodei	wiodei		Cooling Heating		Cooling Heating		
Rated Capacit	Rated Capacity		3.5 kW Class		5.0 kW Class		
Panel Color			W	hite	W	hite	
Airflow Rate	Н	m³/min	13.0 (459)	13.0 (459)	13.0 (459)	13.0 (459)	
Alfilow hate	L	mymin =	10.0 (353)	10.0 (353)	10.0 (353)	10.0 (353)	
	Туре		Siroc	co Fan	Siroc	co Fan	
Fan	Motor Output	W	(	62	6	62	
	Speed	Steps	2 S	iteps	2 S	teps	
Air Direction C	ontrol		Right, Left, Horiz	zontal, Downward	Right, Left, Horiz	zontal, Downward	
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof		
Temperature C	Control		Microcomputer Control		Microcomputer Control		
Dimensions (H	$\times$ W $\times$ D)	mm	195 × 960 × 680		195 × 960 × 680		
Packaged Dim	ensions $(H \times W \times D)$	mm	279 × 1,046 × 818		279 × 1,046 × 818		
Weight (Mass)		kg	24		25		
Gross Weight	(Gross Mass)	kg	3	31	3	32	
Sound Pressure Level	H/L	dB(A)	37	/ 32	38 / 33		
Sound Power I	_evel	dB	Ę	53	54		
Heat Insulation			Both Liquid a	and Gas Pipes	Both Liquid a	and Gas Pipes	
Dining	Liquid	mm	ф	6.4	ф	6.4	
Piping Connection	Gas	mm	φ 9.5		ф 12.7		
Commodition	Drain	mm	VP20 (O.D. φ 26 / I.D. φ 20)		VP20 (O.D. φ 26 / I.D. φ 20)		
Drawing No.			3D0	75705	3D075706		

Model	Model		FHQ60BWV1B				
Wodei			Cooling	Heating			
Rated Capacity	1		6.0 kW	Class			
Panel Color			Wh	ite			
Airflow Rate	Н	m³/min	17.0 (600)	16.0 (565)			
Allilow hate	L	1119/111111	13.0 (459)	13.0 (459)			
	Туре		Siroco	o Fan			
Fan	Motor Output	W	6	2			
	Speed	Steps	2 St	eps			
Air Direction C	ontrol		Right, Left, Horiz				
Air Filter			Removable / Washable / Mildew Proof				
Temperature C	ontrol		Microcomputer Control				
Dimensions (H	$\times$ W $\times$ D)	mm	195 × 1,160 × 680				
Packaged Dim	ensions $(H \times W \times D)$	mm	279 × 1,246 × 818				
Weight (Mass)		kg	27				
Gross Weight (	Gross Mass)	kg	35				
Sound Pressure Level	H/L	dB(A)	39 /	33			
Sound Power I	_evel	dB	55				
Heat Insulation	Heat Insulation		Both Liquid and Gas Pipes				
Liquid		mm	φ 6.4				
Piping Connection	Gas	mm	ф 12.7				
	Drain mm		VP20 (O.D. φ 26 / I.D. φ 20)				
Drawing No.			3D075707				

Conversion Formulae

 $kcal/h = kW \times 860$   $Btu/h = kW \times 3412$   $cfm = m^3/min \times 35.3$ 

Heat Pump SiBE121135

# **Ceiling Mounted Built-in Type**

# 50 Hz, 230 V

50 Hz, 220 - 230 - 240 V / 60 Hz, 220 V

Model			FDBQ	25B8V1	FBQ35	C8VEB
Model	viodei		Cooling Heating		Cooling Heating	
Rated Capacity			2.5 kV	V Class	3.5 kW Class	
	Model		-	_	BYBS4	5DJW1
Decoration	Color		-	_	Wh	nite
Panel	Dimensions (H x W x	( D)	-	_	55 × 80	0 × 500
	Weight (Mass)	kg	-	_	3.	5
Airflow Rate	Н	m³/min	6.5	6.95	16	5.0
Alfilow hate	L	mymm	5.2	5.2	11.0	
	Туре		Siroc	co Fan	Siroco	o Fan
Fan	Motor Output	W	10		140	
	Speed	Steps	2 Steps		2 Steps	
Air Filter			Resin net with mold resistance		Resin net with mold resistance	
Dimensions (H	$I \times W \times D$ )	mm	230 × 652 × 502		$300 \times 700 \times 700$	
Packaged Dim	ensions $(H \times W \times D)$	mm	301 × 753 × 584		325 × 920 × 900	
Weight (Mass)		kg	17		25	
Gross Weight	(Gross Mass)	kg	•	18	2	8
Sound Pressure Level	H/L	dB(A)	35 / 28	35 / 29	37 /	/ 29
Sound Power Level	H/L	dB	55 / 49		63 / —	
Heat Insulation			_		Both Liquid and Gas Pipes	
Distant	Liquid	mm	ф	5.35	φ 6.35 (Flare)	
Piping Connection	Gas	mm	ф 9	9.52	φ 9.52 (Flare)	
0011110011011	Drain	mm	O.D.	ф 27.2	VP25 (O.D. φ	32 / I.D. ф 25)

Model			FBQ50	C8VEB	FBQ60C8VEB		
wodei			Cooling	Heating	Cooling	Heating	
Rated Capacity	1			5.0 kW Class 6.0 kW Class		V Class	
	Model		BYBS4	5DJW1	BYBS7	71DJW1	
Decoration	Color		Wh	ite	W	hite	
Panel	Dimensions (H $\times$ W $\times$ D	)	55 × 80	0 × 500	55 × 1,1	00 × 500	
	Weight (Mass)	kg	3	5	4	.5	
Airflow Rate	Н	m³/min	16	.0	1:	8.0	
Allilow hate	L	1117/111111	11	11.0		5.0	
	Туре		Siroco	o Fan	Siroc	co Fan	
Fan	Motor Output	W	140		350		
	Speed	Speed Steps 2 Steps		eps	2 Steps		
Air Filter			Resin net with mold resistance		Resin net with mold resistance		
Dimensions (H	$\times$ W $\times$ D)	mm	$300 \times 700 \times 700$		300 × 1,000 × 700		
Packaged Dim	ensions $(H \times W \times D)$	mm	355 × 920 × 920		355 × 1,220 × 900		
Weight (Mass)		kg	25		3	34	
Gross Weight (	Gross Mass)	kg	28		4	11	
Sound Pressure Level	H/L	dB(A)	37	29	37 / 29		
Sound Power Level	H/L	dB	63	63 / —		/—	
Heat Insulation	Heat Insulation		Both Liquid and Gas Pipes		Both Liquid a	and Gas Pipes	
Distan	Liquid	mm	\$ 6.35		φ 6.35 (Flare)		
Piping Connection	Gas	mm	ф 12.7	(Flare)	φ 12.7 (Flare)		
	Drain	mm	VP25 (O.D. φ		VP25 (O.D. ф	32 / I.D. ф 25)	

Conversion Formulae

 $kcal/h = kW \times 860$   $Btu/h = kW \times 3412$  $cfm = m^3/min \times 35.3$ 

# Part 3 Printed Circuit Board Connector Wiring Diagram

1.	Outa	oor Unit	.38
2.	Indoo	or Unit	.41
	2.1	FTXG25/35/50JV1BW(A)	41
	2.2	FTXS20/25K2V1B, CTXS15/35K2V1B	44
	2.3	FTXS25/35/42/50J2V1B	.46
	2.4	FTXS60/71GV1B	.49
	2.5	FVXG25/35/50K2V1B	.52
	2.6	FVXS25/35/50FV1B	.55
		FLXS25/35/50/60BAVMB	
		FDXS25/35E7VMB, FDXS50/60C7VMB	
	2.9	FCQG35/50/60FVEB	.61
	2.10	FFQ25/35/50/60B9V1B	64
	2.11	FHQ35/50/60BWV1B	.66
	2.12	FDBQ25B8V1	.68
	2.13	FBQ35/50/60C8VEB	.70
3.	Wire	d Remote Controller	.73
	3.1	BRC1D528	73
	3.2	BRC1E52A7, BRC1E52B7	74

Outdoor Unit SiBE121135

# 1. Outdoor Unit

# Connectors and Other Parts

PCB (1): Main PCB			
Connector for terminal board (indoor - outdoor transmission)			
Connector for COOL / HEAT mode lock			
* Refer to page 413 for detail.			
Connector for electronic expansion valve coil A port			
Connector for electronic expansion valve coil B port			
Connector for electronic expansion valve coil C port			
Connector for electronic expansion valve coil D port (for 4 and 5-room model)			
Connector for electronic expansion valve coil E port (for 5-room model only)			
Connector for overload protector			
Connector for service monitor PCB			
Connector for outdoor fan motor			
Connector for four way valve coil			
Connector for thermistors			
(outdoor temperature, outdoor heat exchanger, discharge pipe temperature)			
Connector for gas pipe thermistors			
Connector for liquid pipe thermistors			
Connector for terminal board (power supply)			
Connector for reactor			
Connector for earth			
Connector for compressor			
Fuse (30 A, 250 V)			
Fuse (3.15 A, 250 V)			
Varistor			
(for 40 - 58 class)			
(for 68 - 90 class)			


## PCB (2): Service Monitor PCB

1) S52, S102	Connector for main PCB
2) LED A	LED for service monitor (green)
3) LED1 - LED4	LED for service monitor (red)
4) LED 5	LED for service monitor (red) (for 5-room model only)
5) SW1	Forced operation [ON/OFF] switch
	* Refer to page 405 for detail.
6) SW2	Operation mode switch
	* Refer to page 405 for detail.
7) SW3	Wiring error check switch
	* Refer to page 406 for detail.
8) SW4	Priority room setting switch
	* Refer to page 412 for detail.
9) SW5	NIGHT QUIET mode setting switch
	* Refer to page 414 for detail.


SiBE121135 Outdoor Unit

#### **PCB Detail**

PCB (1): Main PCB (40/50/52/58 class)




PCB (1): Main PCB (68/75 class)




Outdoor Unit SiBE121135


PCB (1): Main PCB (80/90 class)



PCB (2): Service Monitor PCB (for 3 or 4-room model)



PCB (2): Service Monitor PCB (for 5-room model)



3P173588-1

# 2. Indoor Unit

# 2.1 FTXG25/35/50JV1BW(A)

# Connectors and Other Parts

#### [A1P]: Control PCB

1) S21	Connector for centralized control (HA)
2) S25	Connector for INTELLIGENT EYE sensor PCB
3) S32	Indoor heat exchanger thermistor
4) S41	Connector for swing motors
5) S42	Connector for reduction motor (front panel mechanism) and limit switch
6) S46	Connector for signal receiver / display PCB
7) S200	Connector for fan motor
8) H1, H2, H3,	Connector for terminal board
FG	
9) JB	Fan speed setting when compressor stops for thermostat OFF
JC	Power failure recovery function (auto-restart)
	* Refer to page 418 for detail.
10) LED A	LED for service monitor (green)
11) F1U	Fuse (3.15 A, 250 V)
12) V1	Varistor

#### [A2P]: Signal Receiver / Display PCB


1) S51	Connector for control PCB
2) S52	Connector for room temperature thermistor
3) S1W	Forced cooling operation [ON/OFF] button
4) H1P	LED for operation (multi-color)
5) H2P	LED for INTELLIGENT EYE (green)
6) JA	Address setting jumper
	* Refer to page 415 for detail.

#### [A3P]: INTELLIGENT EYE Sensor PCB


1) S36 Connector for control PCB

## **PCB Detail**


[A1P]: Control PCB



[A2P]: Signal Receiver / Display PCB



[A3P]: INTELLIGENT EYE Sensor PCB



3P255914-1

# 2.2 FTXS20/25K2V1B, CTXS15/35K2V1B

#### Connectors and Other Parts

#### PCB(1): Control PCB

S6 Connector for swing motor (horizontal blade)
 S25 Connector for INTELLIGENT EYE sensor PCB

3) S26 Connector for display PCB

4) S32 Connector for indoor heat exchanger thermistor

5) S200 Connector for fan motor

6) S403 Connector for adaptor PCB (option)

7) FG1, FG2 Connector for terminal board (frame ground)

8) H1, H2, H3 Connector for terminal board (indoor - outdoor transmission)

9) V1 Varistor

10)JA Address setting jumper

\* Refer to page 415 for detail.

11) JB Fan speed setting when compressor stops for thermostat OFF

JC Power failure recovery function (auto-restart)

\* Refer to page 418 for detail.

12)LED A LED for service monitor (green)

13)FU1 (F1U) Fuse (3.15 A, 250 V)

#### PCB (2): Display PCB

1) S27 Connector for control PCB

2) SW1 (S1W) Forced cooling operation [ON/OFF] button

3) LED1 (H1P) LED for operation (green)4) LED2 (H2P) LED for timer (yellow)

5) LED3 (H3P) LED for INTELLIGENT EYE (green)

6) RTH1 (R1T) Room temperature thermistor


#### PCB (3): INTELLIGENT EYE Sensor PCB

1) S36 Connector for control PCB


44


#### **PCB Detail**

#### PCB(1): Control PCB




#### PCB(2): Display PCB





## PCB(3): INTELLIGENT EYE Sensor PCB



## 2.3 FTXS25/35/42/50J2V1B

1) S1

# Connectors and Other Parts

#### PCB (1): Control PCB

2) S21 Connector for centralized control (HA)3) S25 Connector for INTELLIGENT EYE sensor PCB

Connector for DC fan motor

4) S32 Indoor heat exchanger thermistor
 5) S41 Connector for swing motors
 6) S46 Connector for display PCB
 7) S47 Connector for signal receiver PCB

8) H1, H2, H3, Connector for terminal board

FG

9) JA Address setting jumper

\* Refer to page 415 for detail.

10) JB Fan speed setting when compressor stops for thermostat OFF

JC Power failure recovery function (auto-restart)

\* Refer to page 418 for detail.

11) LED A LED for service monitor (green)

12) FU1 (F1U) Fuse (3.15 A, 250 V)

13) V1 Varistor

#### PCB (2): Signal Receiver PCB

1) S48 Connector for control PCB

#### PCB (3): Display PCB

1) S49 Connector for control PCB

2) SW1 Forced cooling operation [ON/OFF] button

3) LED1 (H1P) LED for operation (green)4) LED2 (H2P) LED for timer (yellow)


5) LED3 (H3P) LED for INTELLIGENT EYE (green)6) RTH1 (R1T) Room temperature thermistor

#### PCB (4): INTELLIGENT EYE Sensor PCB


1) S26 Connector for control PCB

#### **PCB Detail**


PCB (1): Control PCB




PCB (2): Signal Receiver PCB



PCB (3): Display PCB



PCB (4): INTELLIGENT EYE Sensor PCB



# 2.4 FTXS60/71GV1B

# Connectors and Other Parts

#### PCB (1): Control PCB

S1 Connector for DC fan motor
 S21 Connector for centralized control (HA)
 S25 Connector for INTELLIGENT EYE sensor PCB
 S32 Connector for indoor heat exchanger thermistor
 S41 Connector for swing motors

6) S46 Connector for display PCB
 7) S47 Connector for signal receiver PCB
 8) H1, H2, H3, Connector for terminal board

FG

9) V1 Varistor

10)JA Address setting jumper

\* Refer to page 415 for detail.

11) JB Fan speed setting when compressor stops for thermostat OFF

JC Power failure recovery function (auto-restart)

\* Refer to page 418 for detail.

12)LED A LED for service monitor (green)

13)FU1 (F1U) Fuse (3.15 A, 250 V)

#### PCB (2): Signal Receiver PCB

1) S48 Connector for control PCB

#### PCB (3): Display PCB

1) S49 Connector for control PCB

2) SW1 Forced cooling operation [ON/OFF] button

3) LED1 (H1P) LED for operation (green)4) LED2 (H2P) LED for timer (yellow)


5) LED3 (H3P) LED for INTELLIGENT EYE (green)6) RTH1 (R1T) Room temperature thermistor

#### PCB (4): INTELLIGENT EYE Sensor PCB


1) S36 Connector for control PCB

#### **PCB Detail**


PCB (1): Control PCB




PCB (2): Signal Receiver PCB



PCB (3): Display PCB



PCB (4): INTELLIGENT EYE Sensor PCB



3P227885-1

# 2.5 FVXG25/35/50K2V1B

# Connectors and Other Parts

#### PCB (1): Main PCB 1) S1 Connector for fan motor 2) S2 Connector for terminal board 3) S6 Connector for swing motor 4) S21 Connector for centralized control (HA) 5) S26 Connector for service PCB 6) S30 Connector for indoor electronic expansion valve coil (motor operated valve coil) Connector for indoor heat exchanger thermistor 7) S32 8) S33 Connector for room temperature thermistor 9) S34 Connector for radiant panel thermistors 10)S46 Connector for display PCB 11)FG Connector for earth 12)V1 Varistor 13)JB Fan speed setting when compressor stops for thermostat OFF JC Power failure recovery function \* Refer to page 418 for detail. 14)F1U Fuse (3.15A, 250V) 15)LED A LED for service monitor (green)

#### PCB (2): Display PCB


1)	S56	Connector for main PCB
2)	S1W	Forced cooling operation [ON/OFF] button
3)	H1P	LED for operation (green)
4)	H2P	LED for timer (yellow)
5)	H3P	LED for RADIANT operation (red)

#### PCB (3): Service PCB

1) S27	Connector for main PCB
2) S2W-1	Address setting switch
	* Refer to page 415 for detail.
	* Keep the other switches as factory setting (OFF).


#### **PCB Detail**

PCB (1): Main PCB




2P273247-1

PCB (2): Display PCB



PCB (3): Service PCB



# 2.6 FVXS25/35/50FV1B

# Connectors and Other Parts

#### PCB (1): Sensor PCB

S49 Connector for control PCB
 RTH2 (R1T) Room temperature thermistor

#### PCB (2): Control PCB

1) S1	Connector for fan motor
2) S21	Connector for centralized control (HA)
3) S26	Connector for service PCB
4) S32	Indoor heat exchanger thermistor
5) S41	Connector for lower air outlet motor
6) S42	Connector for swing motor
7) S46	Connector for display PCB
8) S48	Connector for sensor PCB
9) H1, H2, H3	Connector for terminal board
10)E1	Terminal for earth
11)V1, V2	Varistor
12)JA	Address setting jumper
	* Refer to page 415 for detail.
13)JB	Fan speed setting when compressor stops for thermostat OFF
JC	Power failure recovery function

#### PCB (3): Service PCB

14) FU1 (F1U)

15) LED A

1)	S27	Connector for control PCB
2)	SW2-4	Switch for upward airflow limit setting
		* Refer to page 418 for detail.
		* Keep the other switches as factory setting.
3)	SW4 (S4W)	Switch for air outlet selection
		* Refer to page 185, 195 for detail.

\* Refer to page 418 for detail.

LED for service monitor (green)


Fuse (3.15A, 250V)

#### PCB (4): Display PCB


1) S47	Connector for control PCB
2) SW1 (S1W)	Forced cooling operation [ON/OFF] button
3) LED1 (H1P)	LED for operation (green)
4) LED2 (H2P)	LED for timer (yellow)

#### **PCB Detail**


#### PCB (1): Sensor PCB




PCB (2): Control PCB



PCB (3): Service PCB



PCB (4): Display PCB



 $\bigstar$  LED3 does not function.

# 2.7 FLXS25/35/50/60BAVMB

# Connectors and Other Parts

#### PCB (1): Control PCB

1) S6 Connector for swing motor (horizontal swing) 2) S7 Connector for AC fan motor 3) S21 Connector for centralized control (HA) 4) S24 Connector for display PCB 5) S26 Connector for signal receiver PCB 6) S32 Connector for indoor heat exchanger thermistor Connector for power supply PCB 7) S37 8) JA Address setting jumper \* Refer to page 415 for detail. 9) JB Fan speed setting when compressor stops for thermostat OFF JC Power failure recovery function \* Refer to page 418 for detail. 10) SW2 Select switch for installation (ceiling or floor)

Select switch for installation (ceiling or floor)

st Refer to page 418 for detail.

11) LED A LED for service monitor (green)

#### PCB (2): Power Supply PCB

S36 Connector for control PCB
 H1, H2, H3 Connector for terminal board
 H4, H5, H6 Connector for AC fan motor

4) V1 Varistor

5) FU1 Fuse (3.15A, 250V)

#### PCB (3): Display PCB

S25 Connector for control PCB
 LED1 (H1P) LED for operation (green)
 LED2 (H2P) LED for timer (yellow)

4) LED3 (H3P) LED for HOME LEAVE operation (red)


#### PCB (4): Signal Receiver PCB

S27 Connector for control PCB
 S31 (RTH) Room temperature thermistor


3) SW1 (S1W) Forced cooling operation [ON/OFF] button

#### **PCB Detail**


PCB (1): Control PCB




PCB (2): Power Supply PCB



PCB (3): Display PCB



PCB (4): Signal Receiver PCB



# 2.8 FDXS25/35E7VMB, FDXS50/60C7VMB

# Connectors and Other Parts

#### PCB (1): Control PCB

S1 Connector for AC fan motor
 S7 Connector for AC fan motor (Hall IC)
 S21 Connector for centralized control (HA)

4) S26 Connector for display PCB

5) S32 Connector for indoor heat exchanger thermistor

6) H1, H2, H3 Connector for terminal board

7) GND Connector for terminal board (earth)

8) JA Address setting jumper

\* Refer to page 415 for detail.

9) JB Fan speed setting when compressor stops for thermostat OFF

JC Power failure recovery function (auto-restart)

Refer to page 418 for detail.

10) LED A LED for service monitor (green)

11) FU1 (F1U) Fuse (3.15A, 250V)

12) V1 (V1TR) Varistor

#### PCB (2): Display PCB


1) S1 Connector for control PCB

2) SW1 (S1W) Forced cooling operation [ON/OFF] button3) LED1 (H1P) LED for HOME LEAVE operation (red)


4) LED2 (H2P) LED for timer (yellow)
5) LED3 (H3P) LED for operation (green)
6) RTH1 (R1T) Room temperature thermistor

#### **PCB Detail**

PCB (1): Control PCB



PCB (2): Display PCB



SiBE121135 Indoor Unit

## 2.9 FCQG35/50/60FVEB

# Connectors and Other Parts

#### [A1P] 1) X15A Connector for float switch 2) X16A Connector for room temperature thermistor 3) X17A, X18A Connector for indoor heat exchanger thermistor 4) X20A Connector for fan motor Connector for signal receiver PCB 5) X24A (when the wireless remote controller is used) 6) X27A Connector for terminal board (for inter-unit wiring) 7) X30A Connector for terminal board (for wired remote controller) 8) X33A Connector for wiring adaptor PCB (option) 9) X35A Connector for group control adaptor (option) 10) X36A Connector for self-cleaning decoration panel (option) 11) X65A, X70A Connector for [A2P] 12) HAP LED for service monitor (green) 13) SS1 Selector switch for emergency

## [A2P]

1)	X1A, X7A	Connector for [A1P]				
2)	X2A	Connector for sensor kit (option)				
3)	X4A	Connector for humidity sensor PCB [A3P]				
4)	X8A	Connector for self-cleaning decoration panel (option)				
5)	X9A	Connector for swing motors				
6)	X10A	Connector for drain pump motor				
7)	HAP	LED for service monitor (green)				


## [A3P]: Humidity Sensor PCB

1) CN1 Connector for [A2P]

Indoor Unit SiBE121135


## PCB Detail

[A1P]




SiBE121135 **Indoor Unit** 

[A2P]



[A3P]: Humidity Sensor PCB



**Indoor Unit** SiBE121135

## 2.10 FFQ25/35/50/60B9V1B

[A1P]: Control PCB

## **Connectors and Other Parts**

1) X5A Connector for terminal board (for wired remote controlle
---

2) X10A, X11A Connector for transformer 3) X15A Connector for float switch 4) X17A, X18A Connector for indoor heat exchanger thermistor

5) X19A Connector for room temperature thermistor

6) X20A Connector for fan motor

7) X24A Connector for signal receiver PCB

(when the wireless remote controller is used)

Connector for drain pump motor 8) X25A

9) X27A Connector for terminal board (for inter-unit wiring)

10) X33A Connector for wiring adaptor PCB (option) 11) X35A Connector for group control adaptor (option)

12) X36A Connector for swing motor


13) X40A Connector for ON/OFF input from outside (option)

14) X60A, X61A Connector for interface adaptor (option)

15) HAP LED for service monitor (green) 16) SS1 Selector switch for emergency

SiBE121135 Indoor Unit

## PCB Detail [A1P]: Control PCB



Indoor Unit SiBE121135

## 2.11 FHQ35/50/60BWV1B

# Connectors and Other Parts

[A1P]: Contro	PCB
1) X5A	Connector for terminal board (for wired remote controller)

2) X10A, X11A Connector for transformer

3) X14A Connector for limit switch (for swing flap)4) X15A Connector for float switch (option)

5) X17A, X18A Connector for indoor heat exchanger thermistor6) X19A Connector for room temperature thermistor

7) X20A, X26A Connector for fan motor

8) X24A Connector for signal receiver PCB

(when the wireless remote controller is used)

9) X25A Connector for drain pump motor (option)

10) X27A Connector for terminal board (for inter-unit wiring)

11) X29A Connector for swing motor

12) X33A Connector for wring adaptor PCB (option)
 13) X35A Connector for group control adaptor (option)
 14) X40A Connector for ON/OFF input from outside (option)


15) X60A, X61A Connector for interface adaptor (option)

16) HAP LED for service monitor (green)17) SS1 Selector switch for emergency

SiBE121135 Indoor Unit

## **PCB Detail**

[A1P]: Control PCB



Indoor Unit SiBE121135

## 2.12 FDBQ25B8V1

13) SS1

# Connectors and Other Parts

## [A1P]: Control PCB


Connector for terminal board (for wired remote controller) 1) X5A 2) X10A, X11A Connector for transformer 3) X17A Connector for indoor heat exchanger thermistor 4) X18A Connector for liquid pipe thermistor 5) X19A Connector for room temperature thermistor 6) X21A Connector for fan motor 7) X27A Connector for terminal board (for inter-unit wiring) 8) X33A Connector for wiring adaptor PCB (option) 9) X35A Connector for group control adaptor (option) 10) X40A Connector for ON/OFF input from outside (option) 11) X60A, X61A Connector for interface adaptor (option) 12) HAP LED for service monitor (green)

Selector switch for emergency

SiBE121135 Indoor Unit

## **PCB Detail**

[A1P]: Control PCB



Indoor Unit SiBE121135

## 2.13 FBQ35/50/60C8VEB

# Connectors and Other Parts

## [A1P]: Control PCB

1) X15A	Connector for float switch
2) X16A	Connector for room temperature thermistor
3) X17A	Connector for indoor heat exchanger thermistor
4) X18A	Connector for liquid pipe thermistor
5) X25A	Connector for drain pump motor
6) X27A	Connector for terminal board (for inter-unit wiring)
7) X28A	Connector for power supply wiring (option)
8) X30A	Connector for terminal board (for wired remote controller)
9) X33A	Connector for wiring adaptor PCB (option)
10) X35A	Connector for group control adaptor (option)
11) X70A	Connector for fan PCB
12) X85A	Connector for multi zoning (option)
13) HAP	LED for service monitor (green)
14) SS1	Selector switch for emergency


## [A2P]: Fan PCB (for FBQ35/50C8VEB)

1) X3A	Connector for control PCB
2) X6A	Connector for reactor
3) X8A	Connector for fan motor
4) X10A	Connector for terminal board (power supply)
5) F2U	Fuse (5 A, 250 V)
6) F4U	Fuse (6.3 A, 250 V)
7) HAP	LED for service monitor (green)

## [A2P]: Fan PCB (for FBQ60C8VEB)

1) X1A, X2	A Connector for fan motor
2) X3A	Connector for control PCB
3) X6A	Connector for reactor
4) X9A	Connector for capacitor PCB
5) X10A	Connector for terminal board (power supply)
6) F3U	Fuse (6.3 A, 250 V)
7) HAP	LED for service monitor (green)

## [A3P]: Capacitor PCB (FBQ60C8VEB only)




3P217472-1

SiBE121135 Indoor Unit


## **PCB Detail**

[A1P]: Control PCB




Indoor Unit SiBE121135

[A2P]: Fan PCB (for FBQ35/50C8VEB)



[A2P]: Fan PCB (for FBQ60C8VEB)



SiBE121135 Wired Remote Controller

## 3. Wired Remote Controller

## 3.1 BRC1D528


Connectors and Other Parts

P1, P2 Terminal for indoor unit
 R1T Room temperature thermistor

3) SS1 MAIN / SUB setting switch

\* Refer to page 422 for detail.

## **PCB Detail**



Wired Remote Controller SiBE121135


# 3.2 BRC1E52A7, BRC1E52B7

Connectors and Other Parts

P1, P2
 R1T

Terminal for indoor unit Room temperature thermistor

**PCB Detail** 



# Part 4 Function and Control

1.	Indo	or Unit Control (RA Models)	76
	1.1	Temperature Control	76
	1.2	Frequency Principle	76
	1.3	Operation Starting Control	78
	1.4	Airflow Direction Control	79
	1.5	Fan Speed Control for Indoor Unit	82
	1.6	RADIANT Operation	83
	1.7	Program Dry Operation	85
	1.8	Automatic Operation	86
	1.9	Thermostat Control	87
	1.10	NIGHT SET Mode	89
	1.11	ECONO Operation	90
	1.12	HOME LEAVE Operation	91
	1.13	INTELLIGENT EYE Operation	92
	1.14	2-Area INTELLIGENT EYE Operation	93
	1.15	Inverter POWERFUL Operation	95
	1.16	Multi-Colored Indicator Lamp / TIMER Lamp	95
	1.17	Other Functions	97
2.	Indo	or Unit Control (SA Models)	99
	2.1	Drain Pump Control	
	2.2	Thermostat Sensor in Remote Controller	101
	2.3	Freeze Prevention Control	103
	2.4	Hot Start Control (In Heating Operation Only)	104
3.	Fund	ction of Thermistor	.105
4.	Cont	rol Specification	.107
	4.1	Mode Hierarchy	
	4.2	Frequency Control	
	4.3	Controls at Mode Changing / Start-up	
	4.4	Discharge Pipe Temperature Control	
	4.5	Input Current Control	
	4.6	Freeze-up Protection Control	
	4.7	Heating Peak-cut Control	
	4.8	Outdoor Fan Control	
	4.9	Liquid Compression Protection Function	115
	4.10	Defrost Control	
		Low Hz High Pressure Limit	
		Outdoor Electronic Expansion Valve Control	
		Malfunctions	


## 1. Indoor Unit Control (RA Models)

## 1.1 Temperature Control

## Definitions of Temperatures

The definitions of temperatures are classified as following.

- Room temperature: temperature of lower part of the room
- Set temperature: temperature set by remote controller
- Room thermistor temperature: temperature detected by room temperature thermistor
- Target temperature: temperature determined by microcomputer



★ The illustration is for wall mounted type as representative.

# Temperature Control

The temperature of the room is detected by the room temperature thermistor. However, there is a difference between the "temperature detected by room temperature thermistor" and the "temperature of lower part of the room", depending on the type of the indoor unit or installation condition. Practically, the temperature control is done by the "target temperature appropriately adjusted for the indoor unit" and the "temperature detected by room temperature thermistor".

## 1.2 Frequency Principle

# Main Control Parameters

The frequency of the compressor is controlled by the following 2 parameters:

- The load condition of the operating indoor unit
- The difference between the room thermistor temperature and the target temperature

## Additional Control Parameters

The target frequency is adapted by additional parameters in the following cases:

- Frequency restrictions
- Initial settings
- Forced cooling operation


## **Inverter Principle**

To regulate the capacity, a frequency control is needed. The inverter makes it possible to alter the rotation speed of the compressor. The following table explains the conversion principle:

Phase	Description		
1	The supplied AC power source is converted into the DC power source for the present.		
2	<ul> <li>The DC power source is reconverted into the three phase AC power source with variable frequency.</li> <li>When the frequency increases, the rotation speed of the compressor increases resulting in an increased refrigerant circulation. This leads to a higher amount of the heat exchange per unit.</li> <li>When the frequency decreases, the rotation speed of the compressor decreases resulting in a decreased refrigerant circulation. This leads to a lower amount of the heat exchange per unit.</li> </ul>		

# Drawing of Inverter

The following drawing shows a schematic view of the inverter principle:



### **Inverter Features**

The inverter provides the following features:

- The regulating capacity can be changed according to the changes in the outdoor temperature and cooling / heating load.
- Quick heating and quick cooling The compressor rotational speed is increased when starting the heating (or cooling). This enables to reach the set temperature quickly.
- Even during extreme cold weather, high capacity is achieved. It is maintained even when the outdoor temperature is 2°C.
- Comfortable air conditioning
   A fine adjustment is integrated to keep the room temperature constant.
- Energy saving heating and cooling Once the set temperature is reached, the energy saving operation enables to maintain the room temperature at low power.

## **Frequency Limits**

The following functions regulate the minimum and maximum frequency:

Frequency	Functions		
Low	■ Four way valve operation compensation. Refer to page 111.		
High	<ul> <li>Compressor protection function. Refer to page 112.</li> <li>Discharge pipe temperature control. Refer to page 112.</li> <li>Input current control. Refer to page 113.</li> <li>Freeze-up protection control. Refer to page 113.</li> <li>Heating peak-cut control. Refer to page 114.</li> <li>Defrost control. Refer to page 116.</li> </ul>		

## **Forced Operation**

Refer to page 405 for detail.

## 1.3 Operation Starting Control


## **Outline**

## **Wall Mounted Type: FTXG Series**


The system carries out the following control at the beginning to conduct every functional parts properly.

- 1. Opening the front panel fully
- 2. Output of the  $\Delta D$  signal after the front panel starts moving
- 3. Opening the flap fully after the front panel opens fully
- 4. Making the fan rotate when the flap passes over the fan-banned area

### **Control Flow**



## **Timing Chart**



## 1.4 Airflow Direction Control

# Power-Airflow Dual Flaps

The large flap sends a large volume of air downward to the floor. The flap provides an optimum control in cooling, dry, and heating operation.

## <Cooling / Dry>

During cooling or dry operation, the flap retracts into the indoor unit. Then, cool air can be blown far and distributed all over the room.

## <Heating>

During heating operation, the large flap directs airflow downward to spread the warm air to the entire room.

# Wide-Angle Louvers

The louvers, made of elastic synthetic resin, provide a wide range of airflow that guarantees comfortable air distribution.


## **Auto-Swing**

The following table explains the auto-swing process for cooling, dry, heating, and fan: **Wall Mounted Type** 

0 .	Vertical Swing (up and down)			Horizontal	
Series	Cooling	្យ / Dry	Heating	Fan	Swing (right and left)
FTXG	10° 60°	65° (R11662)	20° 25° 75° 75° (R11664)	5° 10° 80° (R11663)	Ι
FTXS-K CTXS-K	5° 45°	(R11256)	15° + 45° (R11257)	5° 45° (R11256)	_
FTXS-J	15° 50°	55° (R12182)	30° 30° 70° 65° (R11402)	8° 30° 65° 80° (R14208)	45° ko (R11404)
FTXS-G	10° + + + + + + + + + + + + + + + + + + +	5° + + + + + + + + + + + + + + + + + + +	15° + + + + + + + + + + + + + + + + + + +	5° + + + + + + + + + + + + + + + + + + +	50° 50° (R2817)

## Floor Standing Type: FVXG Series

The swinging range of the flap is the same in any operation mode.



(R14634)

## Floor Standing Type: FVXS Series

	Vertical Swing (up and down)				
	Cooling / Dry	Cooling / Dry Heating			
Upward airflow limit OFF	\$ \$ \\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \				
	(R6831)	(R6829)			
Upward airflow limit ON	\$ 000 mm	\$\langle \text{\text{\$\sigma_{\circ}}} \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\			
	(R6832)	(R6830)			

## Floor / Ceiling Suspended Dual Type

	Vertical Swing (up and down)		
	Cooling / Dry / Fan	Heating	
Ceiling	AD		
	(R2964)	(R2963)	
Floor	40°	8 6 6	
	(R2967)	(R2966)	


## 3-D Airflow

## Wall Mounted Type: FTXS-J/G Series

Alternative repetition of vertical and horizontal swing motions enables uniform air-conditioning of the entire room. This function is effective for starting the air conditioner.

When the horizontal swing and vertical swing are both set to automatic operation, the airflow becomes 3-D airflow. The horizontal and vertical swing motion is altered and the airflow direction changes in the order shown in the following diagram.

- (1): The vertical blades (louvers) move from the right to the left.
- (2): The horizontal blades (flaps) move downward.
- (3): The vertical blades (louvers) move from the left to the right.
- (4): The horizontal blades (flaps) move upward.



# COMFORT AIRFLOW Operation

## **Wall Mounted Type**

The vertical swing flap is controlled not to blow the air directly at the people in the room.

Cooling / Dry	Heating
<b>A</b>	<b>B</b>
(R11665)	(R12181)

	Α	В
FTXG	5°	75°
FTXS-K, CTXS-K	0°	50°
FTXS-J	8°	80°
FTXS-G	5°	55°

## 1.5 Fan Speed Control for Indoor Unit

### **Outline**

Phase control and fan speed control contains 9 steps: LLL, LL, SL, L, ML, M, MH, H, and HH. The airflow rate can be automatically controlled depending on the difference between the room thermistor temperature and the target temperature. This is done through phase control and Hall IC control.



For more information about Hall IC, refer to the troubleshooting for fan motor on page 274, 277.

## Automatic Fan Speed Control

In automatic fan speed operation, the step "SL" is not available.

	Wall Mounted Type Floor Standing Type		Floor / Ceiling Suspended Dual Type Duct Connected Type	
Step	Cooling	Heating	Cooling	Heating
LLL				
LL		4		$\triangle$
L	4		<b>⟨</b> }	
ML				
М			7.	
MH	47	47	,	47
Н	•	•		•
HH (POWERFUL)	(R11681)	(R6834)	(R6833)	(R6834)


= The airflow rate is automatically controlled within this range when the [FAN] setting button is set to <u>automatic</u>.

## <Cooling>

The following drawing explains the principle of fan speed control for cooling.


## Wall Mounted Type, Floor Standing Type

Room thermistor temperature - target temperature



(R12317)

### Floor / Ceiling Suspended Dual Type, Duct Connected Type



## <Heating>

In heating operation, the fan speed is regulated according to the indoor heat exchanger temperature and the difference between the room thermistor temperature and the target temperature.



- 1. During POWERFUL operation, the fan rotates at H tap + 40 ~ 90 rpm.
- 2. The fan stops during defrost operation.

## COMFORT AIRFLOW Operation

## **Wall Mounted Type**

- The fan speed is controlled automatically.
- The latest command has the priority between POWERFUL and COMFORT AIRFLOW.

<sup>\*</sup>The upper limit is M tap in 30 minutes from the operation start.

## 1.6 RADIANT Operation

### **Outline**

## Floor Standing Type: FVXG Series

The RADIANT operation has 2 operation modes.

- RADIANT 1: RADIANT operation with heating
- RADIANT 2: RADIANT operation only

## 1.6.1 Indoor Electronic Expansion Valve (Motor Operated Valve) Control

# Initializing with Power ON

The indoor electronic expansion valve is initialized when turning on the power.

# Opening Limit Control

Opening limit control limits the opening of the indoor electronic expansion valve in order to keep a specified range during RADIANT operation.


# Starting Operation Control

Starting operation control opens the indoor electronic expansion valve to a certain degree when starting RADIANT operation. The indoor electronic expansion valve is kept open for a certain period.

## Target Panel Temperature Control

When the starting operation control finishes, the target panel temperature control starts and adjusts the opening of the indoor electronic expansion valve to achieve the target panel temperature. The panel temperature is categorized into stop, dropping, keep, up, and return zones.

(The target panel temperature is 55°C at maximum but it may be lower depending on the condition.)



Stop zone	Operation stops, the radiant panel temperature control is carried out.	
Dropping zone	The opening of indoor electronic expansion valve decreases.	
Keep zone	The opening of indoor electronic expansion valve is kept.	
Up zone	The opening of indoor electronic expansion valve increases.	
Return zone	Starting operation control is carried out.	

# Operation Stop Control


### ■ In case operation stops during RADIANT operation (including thermostat off)

In case any of the following events occur while the indoor electronic expansion valve is open, the operation stop control makes the indoor electronic expansion valve close completely.

- Operation ON → OFF
- RADIANT 1 or RADIANT 2 is canceled.
- Thermostat off
- Defrost control

## 1.6.2 Indoor Unit Fan Control

The movement of the indoor unit fan is different whether in RADIANT 1 or RADIANT 2.



(R14637)

## 1.6.3 RADIANT Operation and Optional Function

Some optional function cannot be used with RADIANT 1 or RADIANT 2 at the same time.

Function	RADIANT 1	RADIANT 2
POWERFUL operation	available	not available
ECONO operation	not available	not available
OUTDOOR UNIT QUIET operation	not available	not available

## 1.7 Program Dry Operation


## **Outline**

Program dry operation removes humidity while preventing the room temperature from lowering. Since the microcomputer controls both the temperature and airflow rate, the temperature adjustment and [FAN] setting buttons are inoperable.

### Detail

The microcomputer automatically sets the temperature and airflow rate. The difference between the room thermistor temperature at start-up and the target temperature is divided into two zones. Then, the unit operates an appropriate capacity for each zone to maintain the temperature and humidity at a comfortable level.

Room thermistor temperature at start-up	Target temperature X	Thermostat OFF point Y	Thermostat ON point Z
24°C or more	Room thermistor	X – 2.5°C	X – 0.5°C or Y + 0.5°C (zone B) continues for 10 min.
23.5°C	temperature at start-up	X – 2.0°C	X – 0.5°C or Y + 0.5°C (zone B) continues for 10 min.
17.5°C ≀	18°C	X – 2.0°C	X - 0.5°C = 17.5°C or Y + 0.5°C (zone B) continues for 10 min.



(R11581)

## 1.8 Automatic Operation

### **Outline**

## **Automatic Cooling / Heating Function**

When the automatic operation is selected with the remote controller, the microcomputer automatically determines the operation mode as cooling or heating according to the room temperature and the set temperature at start-up.

The unit automatically switches the operation mode to maintain the room temperature at the set temperature.

Detail

Ts: set temperature (set by remote controller)

Tt: target temperature (determined by microcomputer)

Tr: room thermistor temperature (detected by room temperature thermistor)

C: correction value

1. The set temperature (Ts) determines the target temperature (Tt).

$$(Ts = 18 \sim 30^{\circ}C).$$

2. The target temperature (Tt) is calculated as;

$$Tt = Ts + C$$

where C is the correction value.

 $C = 0^{\circ}C$ 

3. Thermostat ON/OFF point and operation mode switching point are as follows.

Tr means the room thermistor temperature.

(1) Heating → Cooling switching point:

 $Tr \ge Tt + 3.0^{\circ}C$  (FTXG, FTXS-G, FVXG series)

 $Tr \ge Tt + 2.5^{\circ}C$  (other models)

(2) Cooling → Heating switching point:


Tr < Tt - 2.5°C

- (3) Thermostat ON/OFF point is the same as the ON/OFF point of cooling or heating operation.
- 4. During initial operation

Tr ≥ Ts: Cooling operation

Tr < Ts: Heating operation

## FTXG, FTXS-G, FVXG series




Ex: When the target temperature is 25°C

Cooling  $\rightarrow$  23°C: Thermostat OFF  $\rightarrow$  22°C: Switch to heating

Heating → 27°C: Thermostat OFF → 28°C: Switch to cooling

### Other Models



Ex: When the target temperature is 25°C

Cooling  $\rightarrow$  23°C: Thermostat OFF  $\rightarrow$  22°C: Switch to heating

Heating  $\rightarrow$  26.5°C: Thermostat OFF  $\rightarrow$  27.5°C: Switch to cooling

86

## 1.9 Thermostat Control

Thermostat control is based on the difference between the room thermistor temperature and the target temperature.

## **Thermostat OFF Condition**


• The temperature difference is in the zone A.

### **Thermostat ON Condition**


- The temperature difference returns to the zone C after being in the zone A.
- The system resumes from defrost control in any zones except A.
- The operation turns on in any zones except A.
- The monitoring time has passed while the temperature difference is in the zone B. (Cooling / Dry : 10 minutes, Heating / Radiant : 10 seconds)

## <Cooling / Dry>

## **Wall Mounted Type, Floor Standing Type**




## Floor / Ceiling Suspended Dual Type, Duct Connected Type



<Heating / Radiant>


Wall Mounted Type: FTXG, FTXS-G series

Floor Standing Type: FVXG series




Wall Mounted Type: FTXS-K, CTXS-K, FTXS-J series

Floor Standing Type: FVXS series



## Floor / Ceiling Suspended Dual Type, Duct Connected Type



Refer to "Temperature Control" on page 76 for detail.

## 1.10 NIGHT SET Mode

## **Outline**


When the OFF TIMER is set, the NIGHT SET Mode is automatically activated. The NIGHT SET Mode keeps the airflow rate setting.

### Detail

The NIGHT SET Mode continues operation at the target temperature for the first one hour, then automatically raises the target temperature slightly in the case of cooling, or lowers it slightly in the case of heating. This prevents excessive cooling in summer and excessive heating in winter to ensure comfortable sleeping conditions, and also conserves electricity.


## <Cooling>

Ex: Wall Mounted Type, Floor Standing Type



(R10870)

## <Heating / Radiant>




## 1.11 ECONO Operation

## Wall Mounted Type, Floor Standing Type

The "ECONO operation" reduces the maximum operating current and the power consumption. This operation is particularly convenient for energy-saving-oriented users. It is also a major bonus for those whose breaker capacities do not allow the use of multiple electrical devices and air conditioners.

It is easily activated from the wireless remote controller by pushing the [ECONO] button.

- When this function is activated, the maximum capacity also decreases.
- ECONO operation can only be set when the unit is running. Pressing the [ON/OFF] button on the remote controller cancels the function.
- ECONO operation is available when the unit is in AUTO, COOL, DRY, or HEAT operation and not available in RADIANT or FAN operation.
- ECONO operation and POWERFUL operation cannot be used at the same time. The latest command has the priority.



## 1.12 HOME LEAVE Operation

### **Outline**

## Floor / Ceiling Suspended Dual Type, Duct Connected Type

HOME LEAVE operation is a function that allows you to record your favorite set temperature and airflow rate. You can start your favorite operation mode simply by pressing the [HOME LEAVE] button on the remote controller.

### Detail

### 1. Start of Function

The function starts when the [HOME LEAVE] button is pressed in cooling mode, heating mode (including POWERFUL operation), or while the operation is stopped. If this button is pressed in POWERFUL operation, the POWERFUL operation is canceled and this function becomes effective

■ The [HOME LEAVE] button is ineffective in dry mode and fan mode.


## 2. Details of Function

A mark representing HOME LEAVE is indicated on the display of the remote controller. The indoor unit is operated according to the set temperature and airflow rate for HOME LEAVE which were pre-set in the memory of the remote controller.

The LED (red) of indoor unit representing HOME LEAVE lights up. (It goes out when the operation is stopped.)

### 3. End of Function

The function ends when the [HOME LEAVE] button is pressed again during HOME LEAVE operation or when the [POWERFUL] button is pressed.



### **Others**

The set temperature and airflow rate are memorized in the remote controller. When the remote controller is reset due to replacement of battery, it is necessary to set the temperature and airflow rate again for HOME LEAVE operation.

## 1.13 INTELLIGENT EYE Operation


### **Outline**

### Wall Mounted Type: FTXG, FTXS-K, CTXS-K, FTXS-G Series

This function detects the existence of humans in the room with a human motion sensor (INTELLIGENT EYE) and reduces the capacity when there is nobody in the room in order to save electricity.


### Detail

### 1. Detection method by INTELLIGENT EYE



- The sensor detects human motion by receiving infrared rays and displays the pulse wave output.
- A microcomputer in an indoor unit carries out a sampling every 20 msec. and if it detects 10 cycles of the wave in 1 second in total (corresponding to 20 msec. × 10 = 200 msec.), it judges humans are in the room as the motion signal is ON.

## 2. The motions (for example: in cooling)



- When the microcomputer does not have a signal from the sensor in 20 minutes, it judges that nobody is in the room and operates the unit at a temperature shifted from the target temperature. (Cooling / Dry: 1 ~ 2°C higher, Heating: 2°C lower, Auto: according to the operation mode at that time.)
- ★ In FAN operation, the fan speed is reduced by 60 rpm.

### **Others**

■ For dry operation, you cannot set the temperature with a remote controller, but the target temperature is shifted internally.

## 1.14 2-Area INTELLIGENT EYE Operation

### **Outline**


## Wall Mounted Type: FTXS-J Series

The following functions can be performed by a motion sensor (INTELLIGENT EYE).


- 1. Reduction of the capacity when there is nobody in the room in order to save electricity (energy saving operation)
- Dividing the room into plural areas and detecting existence of humans in each area.
   Moving the airflow direction to the area with no human automatically to avoid direct airflow on humans.

#### Detail

### 1. Detection method of INTELLIGENT EYE




- This sensor detects human motion by receiving infrared rays and displays the pulse wave output.
- The microcomputer in the indoor unit carries out a sampling every 20 msec. and if it detects 10 cycles of the wave in one second in total (corresponding to 20 msec.× 10 = 200 msec.), and when the ON signal continues 3 sec., it judges human is in the room as the motion signal is ON
- 2-area INTELLIGENT EYE sensor is divided into 2 areas and detects humans in each area.
- Image of 2-area INTELLIGENT EYE



· A microcomputer judges human existence by the sensor signal from each area A and B.

(R12276)


## 2. Motions (for example: in cooling)



- When the microcomputer does not have a signal from the sensor in 20 minutes, it judges that nobody is in the room and operates the unit in temperature shifted from the target temperature. (Cooling / Dry: 2°C higher, Heating: 2°C lower, Auto: according to the operation mode at that time.)
- ★ In case of FAN operation, the fan speed reduces by 60 rpm.

## 3. Airflow direction in 2-area INTELLIGENT EYE operation

■ Detection method: The opposite area of detected area is set as the target direction.



- 1. Detection signal ON in both area A and B: Shift the airflow direction to area B (left side)
- 2. Detection signal ON in area A: Shift the airflow direction to area B (left side)
- 3. Detection signal ON in area B: Shift the airflow direction to area A (right side)
- 4. Detection signal OFF in both area A and B: No change
- \* When the detection signal is OFF for 20 minutes in both area A and B, the unit starts energy saving operation.

## **Others**

For dry operation, you cannot set the temperature with remote controller, but internally the target temperature is shifted.

## 1.15 Inverter POWERFUL Operation

### **Outline**

In order to exploit the cooling and heating capacity to full extent, operate the air conditioner by increasing the indoor fan rotating speed and the compressor frequency.


### Detail

When the [POWERFUL] button is pressed, the fan speed and target temperature are converted to the following states for 20 minutes.

Operation mode	Fan speed	Target temperature
COOL	H tap + A rpm	18°C
DRY	Dry rotating speed + A rpm	Lowered by 2 ~ 2.5°C
HEAT / RADIANT 1	H tap + A rpm	30 ~ 32°C
FAN	H tap + A rpm	_
AUTO	Same as cooling / heating in POWERFUL operation	The target temperature is kept unchanged.

A = 40 ~ 90 rpm (depending on the model)

## Ex: POWERFUL operation in cooling



## Note:

## For Floor Standing Type: FVXG Series


POWERFUL operation is only available in RADIANT 1 (RADIANT operation with heating), it is not available in RADIANT 2 (RADIANT operation only).

## 1.16 Multi-Colored Indicator Lamp / TIMER Lamp

## **Features**

## **Wall Mounted Type: FTXG Series**

Current operation mode is displayed in color of the lamp of the indoor unit. Operating status can be monitored even in automatic operation in accordance with the actual operation mode.




The lamp color changes according to the operation.


## Brightness Setting

The brightness of the multi-colored indicator lamp can be adjusted L (low), H (high), or OFF.


1. Press the center of the [Temp] button and the [Mode] button at the same time.




\$\mathcal{E}\$ is displayed on the LCD.



2. Select ¿ (light) with the [Temp] ▲ or ▼ button.



- 3. Press the [Mode] button to enter the brightness setting mode.
- 4. Press the [Temp] ▲ or ▼ button to adjust the brightness of the multi-colored indicator lamp.



(R11913)

Press the [Mode] button for 5 seconds to exit from the brightness setting mode.
 (When the remote controller is left untouched for 60 seconds, it returns to the normal mode also.)

# 1.17 Other Functions

# 1.17.1 Hot-Start Function

In order to prevent the cold air blast that normally comes when heating operation is started, the temperature of the indoor heat exchanger is detected, and the airflow is either stopped or made very weak thereby carrying out comfortable heating of the room.

\* The cold air blast is also prevented using similar control when the defrosting operation is started or when the thermostat is turned ON.

# 1.17.2 Signal Receiving Sign

When the indoor unit receives a signal from the remote controller, the unit emits a signal receiving sound.

# 1.17.3 Indoor Unit [ON/OFF] Button


An [ON/OFF] button is provided on the display of the unit.

- Press the [ON/OFF] button once to start operation. Press once again to stop it.
- The [ON/OFF] button is useful when the remote controller is missing or the battery has run out.
- The operation mode refers to the following table.

	Operation mode	Temperature setting	Airflow rate
Cooling Only	COOL	22°C	Automatic
Heat Pump	AUTO	25°C	Automatic

■ In the case of multi system operation, there are times when the unit does not activate with the [ON/OFF] button.

Ex: Wall mounted type FTXS-J series



Note: When the [ON/OFF] button is pressed for 10 seconds or more, the forced operation is stopped.

# 1.17.4 Titanium Apatite Photocatalytic Air-Purifying Filter

This filter combines the Air-Purifying Filter and Titanium Apatite Photocatalytic Deodorizing Filter as a single highly effective filter. The filter traps microscopic particles, decomposes odors and even deactivates bacteria and viruses. It lasts for 3 years without replacement if washed about once every 6 months.

# 1.17.5 Photocatalytic Deodorizing Filter

The photocatalytic deodorizing filter powerfully decomposes odor of tobacco, pet, etc. The deodorizing power is regenerated simply by being exposed to the sunshine. It is recommended to dry the filter in the sun for about 6 hours (after vacuuming the filter) every 6 months.

# 1.17.6 Air-Purifying Filter

The air-purifying filter collects tobacco smoke, pollen, etc. with electrostatic agency. This filter includes a deodorizing active carbon filter that removes minute particles of odor. Replace the air-purifying filter every 3 months.

# 1.17.7 Auto-restart Function

If a power failure (including one for just a moment) occurs during the operation, the operation restarts automatically when the power is restored in the same condition as before the power failure.

Note: It takes

It takes 3 minutes to restart the operation because the 3-minute standby function is activated.

# 1.17.8 WEEKLY TIMER Operation

Up to 4 timer settings can be saved for each day of the week (up to 28 settings in total). Those 3 items of "ON/OFF", "temperature" and "time" can be set.




Refer to "WEEKLY TIMER Operation" on page 167, 208 for detail.

# 1.17.9 Brightness Setting of the Indoor Unit Display

# Floor Standing Type: FVXG Series

Each time you press the [Brightness] button on the remote controller, the brightness of the indoor unit display changes to "high", "low", or "off".

Refer to the operation manual for details.




(R14639)

# 2. Indoor Unit Control (SA Models)

# 2.1 Drain Pump Control

# 2.1.1 When the Float Switch is Tripped While the Cooling Thermostat is ON:




# \*1. (Normal operation):

The purpose of residual operation is to completely drain any moisture adhering to the fin of the indoor heat exchanger when the thermostat goes off during cooling operation.

\*2. (Malfunction residual):

The remote controller displays 83 and the air conditioner comes to an abnormal stop in 5 minutes if the float switch is turned OFF while the cooling thermostat is ON.


# 2.1.2 When the Float Switch is Tripped While the Cooling Thermostat is OFF:



#### \*3. (Malfunction residual):


The remote controller displays 83 and the air conditioner comes to an abnormal stop if the float switch is turned OFF and not turned ON again within 5 minutes while the cooling thermostat is OFF.

# 2.1.3 When the Float Switch is Tripped During Heating Operation:



During heating operation, if the float switch is not reset even after the 5 minutes operation, 5 seconds stop, 5 minutes operation cycle ends, operation continues until the switch is reset.

# 2.1.4 When the Float Switch is Tripped and 8F is Displayed on the Remote Controller:



\*4. (Malfunction residual):

If the float switch is tripped 5 times in succession, a drain malfunction is determined to have occurred. SF is then displayed as operation continues.

\*5. (Malfunction residual):


The remote controller displays 83 and the air conditioner comes to an abnormal stop if the float switch is OFF for more than 5 minutes in the case of \*4.

# 2.2 Thermostat Sensor in Remote Controller

Temperature is controlled by both the thermostat sensor in remote controller and air suction thermostat in the indoor unit. (This is however limited to when the field setting for the thermostat sensor in remote controller is set to "Use.")

# Cooling

If there is a significant difference in the set temperature and the suction temperature, fine adjustment control is carried out using a body thermostat sensor, or using the sensor in the remote controller near the position of the user when the suction temperature is near the set temperature.




# ■ Assuming the set temperature in the figure above is 24°C, and the suction temperature has changed from 18°C to 30°C (A → F):

(This example also assumes there are several other air conditioners, and the suction temperature changes even when the thermostat sensor is off.) Body thermostat sensor is used for temperatures from 18°C to 23°C (A  $\rightarrow$  C). Remote controller thermostat sensor is used for temperatures from 23°C to 27°C (C  $\rightarrow$  E). Body thermostat sensor is used for temperatures from 27°C to 30°C (E  $\rightarrow$  F).

■ Assuming suction temperature has changed from 30°C to 18°C ( $F \rightarrow A$ ):
Body thermostat sensor is used for temperatures from 30°C to 25°C ( $F \rightarrow D$ ).
Remote controller thermostat sensor is used for temperatures from 25°C to 21°C ( $D \rightarrow B$ ).
Body thermostat sensor is used for temperatures from 21°C to 18°C ( $B \rightarrow A$ ).

# Heating

When heating, the hot air rises to the top of the room, resulting in the temperature being lower near the floor where the occupants are. When controlling by body thermostat sensor only, the indoor unit may therefore be turned off by the thermostat before the lower part of the room reaches the set temperature. The temperature can be controlled so the lower part of the room where the occupants are does not become cold by widening the range in which thermostat sensor in remote controller can be used so that suction temperature is higher than the set temperature.



# ■ Assuming the set temperature in the figure above is 24°C, and the suction temperature has changed from 18°C to 28°C (A → D):

(This example also assumes there are several other air conditioners, and the suction temperature changes even when the thermostat sensor is off.) Body thermostat sensor is used for temperatures from 18°C to 25°C (A  $\rightarrow$  C). Remote controller thermostat sensor is used for temperatures from 25°C to 28°C (C  $\rightarrow$  D).

# ■ Assuming suction temperature has changed from 28°C to 18°C (D $\rightarrow$ A): Remote controller thermostat sensor is used for temperatures from 28°C to 23°C (D $\rightarrow$ B). Body thermostat sensor is used for temperatures from 23°C to 18°C (B $\rightarrow$ A).


# 2.3 Freeze Prevention Control

When the temperature detected by liquid pipe thermistor (R2T) of the indoor heat exchanger drops too low, the unit enters freeze prevention control in accordance with the following conditions, and is also set in accordance with the conditions given below.

Conditions for starting: Temperature is  $-1^{\circ}$ C or less for total of 40 min., or temperature is  $-5^{\circ}$ C or less for total of 10 min.

Conditions for cancelling: Temperature is +7°C or more for 10 min. continuously

Ex: Case where temperature is -5°C or less for total of 10 min.




# 2.4 Hot Start Control (In Heating Operation Only)

**Outline** 

At startup with thermostat ON or after the completion of defrosting in heating operation, the indoor unit fan is controlled to prevent cold air from blasting out and ensure startup capacity.

Detail



 $\ensuremath{\mathsf{TH}}_2\ensuremath{\mathsf{:}}$  Temperature (°C) detected with the gas thermistor


TC: High pressure equivalent saturated temperature

SiBE121135 Function of Thermistor


# 3. Function of Thermistor

★ Illustrations are for 4-room models as representative and have 4 lines of indoor unit system (A ~ D). 3-room models have 3 lines (A ~ C) and 5-room models have 5 lines (A ~ E).

# **Cooling Only Model**



# **Heat Pump Model**



# (1) Outdoor Heat Exchanger Thermistor

- The outdoor heat exchanger thermistor is used for controlling the target discharge pipe temperature. The system sets the target discharge pipe temperature according to the outdoor and indoor heat exchanger temperature, and controls the outdoor electronic expansion valve opening so that the target discharge pipe temperature can be obtained.
- In cooling operation, the outdoor heat exchanger thermistor is used for detecting the
  disconnection of the discharge pipe thermistor. When the discharge pipe temperature
  becomes lower than the outdoor heat exchanger temperature, the discharge pipe thermistor
  is judged as disconnected.
- 3. In cooling operation, the outdoor heat exchanger thermistor is used for high pressure protection.

Function of Thermistor SiBE121135

# (2) Discharge Pipe Thermistor

The discharge pipe thermistor is used for controlling discharge pipe temperature. If the
discharge pipe temperature (used in place of the inner temperature of the compressor) rises
abnormally, the operating frequency becomes lower or the operation halts.

2. The discharge pipe thermistor is used for detecting disconnection of the discharge pipe thermistor.

# (3) Gas Pipe Thermistor

 In cooling operation, the gas pipe thermistor is used for gas pipe isothermal control. The system controls outdoor electronic expansion valve opening so that the gas pipe temperature in each room becomes equal.

# (4) Indoor Heat Exchanger Thermistor

- The indoor heat exchanger thermistor is used for controlling the target discharge pipe temperature. The system sets the target discharge pipe temperature according to the outdoor and indoor heat exchanger temperature, and controls the outdoor electronic expansion valve opening so that the target discharge pipe temperature can be obtained.
- 2. In cooling operation, the indoor heat exchanger thermistor is used for freeze-up protection control. If the indoor heat exchanger temperature drops abnormally, the operating frequency becomes lower or the operation halts.
- 3. In cooling operation, the indoor heat exchanger thermistor is used for anti-icing function. If any of the following conditions are met in the room where operation halts, it is assumed as icing.

The conditions are

 $Tc \le -1^{\circ} C$  $Ta - Tc \ge 10^{\circ} C$ 

where Ta is the room temperature and Tc is the indoor heat exchanger temperature.

- 4. In heating operation, the indoor heat exchanger thermistor is used for heating peak-cut control. If the indoor heat exchanger temperature rises abnormally, the operating frequency becomes lower or the operation halts.
- 5. In heating operation, the indoor heat exchanger thermistor is used for detecting the disconnection of the discharge pipe thermistor. When the discharge pipe temperature becomes lower than the maximum indoor heat exchanger temperature, the discharge pipe thermistor is judged as disconnected.
- 6. When only one indoor unit is operating, the indoor heat exchanger thermistor is used for subcooling control. The actual subcool is calculated with the liquid pipe temperature and the indoor heat exchanger temperature. The system controls the outdoor electronic expansion valve openings to obtain the target subcool.
- 7. The indoor heat exchanger thermistor is used for wiring error check function. The refrigerant flows in order from the port A to detect the indoor heat exchanger temperature one by one, and then wiring and piping can be checked.

# (5) Liquid Pipe Thermistor

- When only one indoor unit is in heating, the liquid pipe thermistor is used for subcooling control. The actual subcool is calculated with the liquid pipe temperature and the maximum indoor heat exchanger temperature. The system controls the outdoor electronic expansion valve openings to obtain the target subcool.
- In heating operation, the liquid pipe thermistor is used for liquid pipes isothermal control. The system controls the outdoor electronic expansion valve opening so that the liquid pipe temperatures in each room becomes equal.

# (6) Radiant Panel Thermistors

- The radiant panel thermistors are used for calculating radiant panel surface temperature.
   Due to structural and manufactural restrictions, the radiant panel surface temperature
   cannot be controlled directly with a thermistor. Thermistors are mounted on the radiant panel
   piping in order to calculate the radiant panel surface temperature.
   The indoor electronic expansion valve is controlled according to the radiant panel surface
   temperature.
- 2. The radiant panel thermistors are used for detecting malfunction of the indoor electronic expansion valve.

# 4. Control Specification


# 4.1 Mode Hierarchy

**Outline** 


There are 3 modes; normal operation mode, forced operation mode, and power transistor test mode for installation and servicing.

#### Detail

# **Cooling Only Model**



# **Heat Pump Model**



**1** Note

- Unless specified otherwise, a dry operation command is regarded as cooling operation and a radiant operation command is regarded as heating operation.
- Indoor fan operation cannot be made in multiple indoor units. (A forced fan command is made during forced cooling operation.)

# **Determine Operation Mode**

The system judges the operation mode command which is set by each room in accordance with the procedure, and determines the operation mode of the system.

The following procedure is taken when the modes conflict with each other.

- \*1. The system follows the mode which is set first. (First-push, first-set)
- \*2. For the rooms where the different mode is set, standby mode is activated. (The operation lamp blinks.)

# 4.2 Frequency Control


#### **Outline**

Frequency that corresponds to each room's capacity is determined according to the difference between the target temperature and the temperature of each room.

The function is explained as follows.

- 1. How to determine frequency
- 2. Frequency command from an indoor unit (Difference between a room thermistor temperature and the target temperature)
- 3. Frequency command from an indoor unit (The ranked capacity of the operating room)
- 4. Frequency initial setting
- 5. PI control

When the shift of the frequency is less than zero ( $\Delta$ F<0) by PI control, the target frequency is used as the command frequency.



#### Detail

#### **How to Determine Frequency**

The compressor's frequency is determined by taking the following steps.

# **For Cooling Only Model**

# 1. Determine command frequency

- · Command frequency is determined in the following order of priority.
  - 1. Forced cooling
  - 2. Indoor frequency command

#### 2. Determine upper limit frequency

 The minimum value is set as the upper limit frequency among the frequency upper limits of the following functions:

Compressor protection, input current, discharge pipe temperature, low Hz high pressure limit, freeze-up protection.

#### 3. Determine lower limit frequency

 The maximum value is set as lower limit frequency among the frequency lower limits of the following functions:

Draft prevention, pressure difference upkeep.

#### 4. Determine prohibited frequency

• There is a certain prohibited frequency such as a power supply frequency.

#### For Heat Pump Model

# 1. Determine command frequency

- Command frequency is determined in the following order of priority.
  - 1. Limiting defrost control time
  - 2. Forced cooling / heating
  - 3. Indoor frequency command

# 2. Determine upper limit frequency

 The minimum value is set as upper limit frequency among the frequency upper limits of the following functions:

Compressor protection, input current, discharge pipe temperature, low Hz high pressure limit, heating peak-cut, freeze-up protection, defrost.

# 3. Determine lower limit frequency

 The maximum value is set as the lower limit frequency among the frequency lower limits of the following functions:

Four way valve operation compensation, draft prevention, pressure difference upkeep.

# 4. Determine prohibited frequency

There is a certain prohibited frequency such as a power supply frequency.

# Indoor Frequency Command (\( \D \) signal)

The difference between a room thermistor temperature and the target temperature is taken as the " $\Delta D$  signal" and is used for frequency command.

Temperature difference (°C)	∆D signal						
-2.0	*Th OFF	0	4	2.0	8	4.0	С
-1.5	1	0.5	5	2.5	9	4.5	D
-1.0	2	1.0	6	3.0	Α	5.0	Е
-0.5	3	1.5	7	3.5	В	5.5	F

Values depend on the type of indoor unit.

#### **Indoor Unit Capacity (S value)**

The capacity of the indoor unit is a "S" value and is used for frequency command.

Ex:	Capacity	S value	Capacity	S value
	2.5 kW	25	5.0 kW	50
	3.5 kW	35	6.0 kW	60

## **Frequency Initial Setting**

# <Outline>

When starting the compressor, or when conditions are varied due to the change of the operating room, the frequency must be initialized according to the total of a maximum  $\Delta D$  value of each room and a total value of Q ( $\Sigma Q$ ) of the operating room (the room in which the thermos is set to ON).

Q value: Indoor unit output determined from indoor unit volume, airflow rate and other factors.

<sup>\*</sup>Th OFF = Thermostat OFF

#### PI Control (Determine Frequency Up / Down by $\Delta D$ Signal)

#### 1. P control

A total of the  $\Delta D$  value is calculated in each sampling time (20 seconds), and the frequency is adjusted according to its difference from the frequency previously calculated.

#### 2. I control

If the operating frequency is not change more than a certain fixed time, the frequency is adjusted according to the  $\Sigma\Delta D$  value.

When the  $\Sigma\Delta D$  value is low, the frequency is lowered.

When the  $\Sigma\Delta D$  value is high, the frequency is increased.

# 3. Limit of frequency increasing range

When the difference between input current and input current dropping value is less than 1.5 A, the frequency increasing range must be limited.

# 4. Frequency management when other controls are functioning

· When each frequency is dropping;

Frequency management is carried out only when the frequency drops.

• For limiting lower limit

Frequency management is carried out only when the frequency rises.

#### 5. Upper and lower limit of frequency by PI control

The frequency upper and lower limits are set according to the total of S values. When the indoor unit quiet operation commands come from more than one room or when the outdoor unit quiet operation commands come from all the rooms, the upper limit frequency is lower than the usual setting.

# 4.3 Controls at Mode Changing / Start-up

# 4.3.1 Preheating Operation

#### **Outline**

The inverter operation in open phase starts with the conditions of the preheating command from the outdoor unit.

#### Detail

#### **ON Condition**

- When the outdoor temperature is below 10.5°C, the inverter operation in open phase starts. **OFF Condition**
- When the outdoor temperature is higher than 12°C, the inverter operation in open phase stops.

# 4.3.2 Four Way Valve Switching

#### **Outline**

In heating operation, current is conducted, and in cooling and defrosting operation, current is not conducted. In order to eliminate the switching sound, as the four way valve coil switches from ON to OFF when the heating is stopped, the OFF delay switch of the four way valve is carried out.

#### Detail

# OFF delay switch of four way valve:

The four way valve coil is energized for 150 seconds after the operation is stopped.

# 4.3.3 Four Way Valve Operation Compensation

#### **Outline**

At the beginning of the operation as the four way valve is switched, the pressure difference to activate the four way valve is acquired by having output frequency which is more than a certain fixed frequency, for a certain fixed time.

## **Detail**

# **Starting Conditions**

- 1. When starting the compressor for heating
- 2. When the operation mode changes from the previous time
- 3. When starting the compressor for defrosting
- When starting the compressor for the first time after resetting with the power ON.
   The lower limit of frequency keeps A Hz for 70 seconds with any conditions 1 through 4 above.


	<b>A</b> (Hz)
40/50/52/58 class	48
68/75 class	40
80/90 class	28

# 4.3.4 3-Minute Standby

Turning on the compressor is prohibited for 3 minutes after turning off. (Except when defrosting.)

# 4.3.5 Compressor Protection Function

When turning the compressor from OFF to ON, the upper limit of frequency is set as follows. (The function is not used when defrosting.)




	40/50/52/58 class	68/75/80/90 class
A (Hz)	55	55
B (Hz)	70	65
C (Hz)	85	80
<b>D</b> (seconds)	150 ~ 240	120
E (seconds)	180	200
F (seconds)	300	470

# 4.4 Discharge Pipe Temperature Control

**Outline** 

The discharge pipe temperature is used as the internal temperature of the compressor. If the discharge pipe temperature rises above a certain level, the upper limit of frequency is set to keep the discharge pipe temperature from rising further.

**Detail** 



	40/50/52/58 class	68/75/80/90 class
A (°C)	110	120
B (°C)	103	111
<b>C</b> (°C)	102	109
<b>D</b> (°C)	100	107
E (°C)	95	107

Zone	Control	
Stop zone	When the temperature reaches the stop zone, the compressor stops.	
Dropping zone	The upper limit of frequency decreases.	
Keep zone	The upper limit of frequency is kept.	
Reset zone	The upper limit of frequency is canceled.	


# 4.5 Input Current Control

#### **Outline**

An input current is detected by the CT while the compressor is running, and the frequency upper limit is set from the input current.

In case of heat pump models, this control which is the upper limit control of the frequency takes priority over the lower limit control of four way valve operation compensation.

Detail



## Frequency control in each zone

# Stop zone

After 2.5 seconds in this zone, the compressor is stopped.

#### **Dropping zone**

- The upper limit of the compressor frequency is defined as operation frequency 2 Hz.
- After this, the output frequency is lowered by 2 Hz every second until it reaches the keep zone.

#### Keep zone

The present maximum frequency goes on.

#### Reset zone

Limit of the frequency is canceled.

# Limitation of current dropping and stop value according to the outdoor temperature

• The current drops when outdoor temperature becomes higher than a certain level (depending on the model).


# 4.6 Freeze-up Protection Control

# **Outline**

During cooling operation, the signals sent from the indoor unit control the operating frequency limitation and prevent freezing of the indoor heat exchanger. (The signal from the indoor unit is divided into zones.)

## Detail

The operating frequency limitation is judged with the indoor heat exchanger temperature 2 seconds after operation starts and 30 seconds after the number of operation room is changed.




# 4.7 Heating Peak-cut Control

**Outline** 

During heating operation, the indoor heat exchanger temperature determines the frequency upper limit to prevent abnormal high pressure.

Detail

- The operating frequency is judged with the indoor heat exchanger temperature 2 minutes after the operation starts and **F** seconds after the number of operation room is changed.
- The maximum value of the indoor heat exchanger temperature controls the following (excluding stopped rooms).



Zone	Control	
Stop zone	When the temperature reaches the stop zone, the compressor stops.	
Dropping zone	The upper limit of frequency decreases.	
Keep zone	The upper limit of frequency is kept.	
Up zone	The upper limit of frequency increases.	
Reset zone	The upper limit of frequency is canceled.	

<b>A</b> (°C)	65
B (°C)	55
<b>C</b> (°C)	54
<b>D</b> (°C)	52
E (°C)	50

	F (seconds)
When increase	30
When decrease	2

# 4.8 Outdoor Fan Control

#### 1. Fan ON control to cool down the electrical box

The outdoor fan is turned ON when the electrical box temperature is high while the compressor is OFF.

## 2. Fan OFF control during defrosting

The outdoor fan is turned OFF while defrosting.

#### 3. Fan OFF delay when stopped

The outdoor fan is turned OFF 60 seconds after the compressor stops.

# 4. Fan speed control for pressure difference upkeep

The rotation speed of the outdoor fan is controlled for keeping the pressure difference during cooling operation with low outdoor temperature.

- When the pressure difference is low, the rotation speed of the outdoor fan is reduced.
- When the pressure difference is high, the rotation speed of the outdoor fan is controlled as well as normal operation.

# 5. Fan control when the number of heating room decreases

When the outdoor temperature is more than 10°C, the fan is turned off for 30 seconds.

## 6. Fan speed control during forced operation

The outdoor fan is controlled as well as normal operation during the forced operation.

#### 7. Fan speed control during POWERFUL operation

The rotation speed of the outdoor fan is increased during the POWERFUL operation.

#### 8. Fan speed control during indoor / outdoor unit quiet operation

The rotation speed of the outdoor fan is reduced by the command of the indoor / outdoor unit quiet operation.

# 9. Fan ON/OFF control when operation starts / stops

The outdoor fan is turned ON when the operation starts. The outdoor fan is turned OFF when the operation stops.

# 4.9 Liquid Compression Protection Function

#### **Outline**

In order to obtain the dependability of the compressor, the compressor is stopped according to the outdoor temperature and temperature of the outdoor heat exchanger.

#### Detail

# Operation stops depending on the outdoor temperature

The compressor turns off under the conditions that the system is in cooling operation and outdoor temperature is below  $-12^{\circ}$ C.

# 4.10 Defrost Control

# **Outline**

Defrosting is carried out by the cooling cycle (reverse cycle). The defrosting time or outdoor heat exchanger temperature must be more than a certain value to finish.


#### Detail

# **Conditions for Starting Defrost**

- The starting conditions are determined with the outdoor temperature and the outdoor heat exchanger temperature.
- The system is in heating operation.
- The compressor operates for 6 minutes.
- More than 38 minutes of accumulated time pass after the start of the operation, or ending the previous defrosting.

## **Conditions for Canceling Defrost**

The target heat exchanger temperature as the canceling condition is selected in the range of  $4 \sim 12^{\circ}\text{C}$  according to the outdoor temperature.




	40/50/52/58 class	68/75 class	80/90 class
A (Hz)	62	54	39
B (Hz)	80	82	62

# 4.11 Low Hz High Pressure Limit

#### **Outline**

The upper limit of high pressure in a low Hz zone is set. The upper limit of the indoor heat exchanger temperature is also set by the operating frequency. Zones are divided into three, reset zone, keep zone, and dropping zone, and the frequency control is carried out according to each zone.

#### Detail



	40/50/52/58/68/75 class	80/90 class
A (°C)	60	57
B (°C)	59	56
<b>C</b> (°C)	56	53

Note: Dropping: The system stops 2 minutes after staying in the dropping zone.

# 4.12 Outdoor Electronic Expansion Valve Control

# **Outline**

The following items are included in the outdoor electronic expansion valve control.

# Outdoor electronic expansion valve is fully closed

- 1. Outdoor electronic expansion valve is fully closed when turning on the power.
- 2. Pressure equalizing control

## **Room Distribution Control**

- Gas pipe isothermal control
- 2. SC (subcooling) control
- Liquid pipe temperature control (with all ports connected and all rooms being airconditioned)
- 4. Liquid pipe temperature control for stopped rooms
- 5. Dew prevention control for indoor rotor

# **Open Control**

- 1. Outdoor electronic expansion valve control when starting operation
- 2. Outdoor electronic expansion valve control when the frequency changes
- 3. Outdoor electronic expansion valve control for defrosting
- 4. Outdoor electronic expansion valve control for oil recovery
- 5. Outdoor electronic expansion valve control when a discharge pipe temperature is abnormally high
- Outdoor electronic expansion valve control when the discharge pipe thermistor is disconnected
- 7. Outdoor electronic expansion valve control for indoor unit freeze-up protection

# **Feedback Control**

1. Target discharge pipe temperature control

# Detail

The followings are the examples of the outdoor electronic expansion valve control which function in each operation mode.

Operation pattern  When power is turned on	● : Holding Functions — : No Functions	Gas pipe isothermal control	SC (subcooling) control	Control when the frequency changes	Control for abnormally high discharge pipe temperature	Oil recovery control	Indoor freeze-up protection control	Liquid pipe temperature control	Liquid pipe temperature control for non-operating units	Dew prevention control for indoor rotor
	Fully closed when power is turned on	_	_	_	_	_	_	_	_	_
Cooling, 1 room operation	Open control when starting	_	_	_	•	•	•	_	_	_
	(Control of target discharge pipe temperature)	_	_	•	•	•	•	_	_	•
Cooling, 2 rooms operation to Cooling, 4 rooms operation	Control when the operating room is changed	_	_	_	•	•	•	_	_	•
	(Control of target discharge pipe temperature)	•	_	•	•	•	•	_	_	•
Stop	Pressure equalizing control	_	_	_	_	_	_	_	-	
Heating, 1 room operation	Open control when starting	_	_	_	•	_	_	_	_	_
	(Control of target discharge pipe temperature)	_	◆ <b>★</b> 2	•	•	_	_	• <b>★</b> 1	• <b>★</b> 3	_
Heating, 2 rooms operation	Control when the operating room is changed	_	_	l	•	_	_			_
	(Control of target discharge pipe temperature)	_	• <b>★</b> 2	•	•	_	_	• <b>★</b> 1	<b>◆</b>	_
<b>\</b>	(Defrost control)	_	_	_	_	_	_	_	_	_
Stop	Pressure equalizing control	_	_	_		_	_	_	_	
Heating operation	Open control when starting	_	_	_	•	_	_	_	_	
Control of discharge pipe thermistor disconnection	Continue	_	• <b>★</b> 2	_	_	_	_	• <b>*</b> 1	<b>◆</b>	
Stop	Pressure equalizing control	_	_	_	_	_	_	_		_

(R16007)

★1: When all the indoor units are operating, "liquid pipe temperature control" is conducted.

★2: "SC (subcooling) control" is conducted for the operating indoor units, when some of the units are not operating.

★3: "Liquid pipe temperature control for stopped room" is conducted for the non-operating indoor units.

# 4.12.1 Fully Closing with Power on

The outdoor electronic expansion valve is initialized when the power is turned on. The opening position is set and the pressure equalization is developed.

# 4.12.2 Pressure Equalizing Control

When the compressor is stopped, the pressure equalizing control is activated. The outdoor electronic expansion valve opens, and develops the pressure equalization.

# 4.12.3 Opening Limit Control

#### **Outline**

A maximum and minimum opening of the outdoor electronic expansion valve are limited.

#### Detail

- A maximum outdoor electronic expansion valve opening in the operating room: 450 pulses
- A minimum outdoor electronic expansion valve opening in the operating room: 75 pulses The outdoor electronic expansion valve is fully closed in the room where cooling is stopped and is opened at a fixed degree during defrosting.

# 4.12.4 Starting Operation Control / Changing Operation Room

The outdoor electronic expansion valve opening is controlled when the operation starts, and prevents superheating or liquid compression.

# 4.12.5 Control when the Frequency Changes

When the target discharge pipe temperature control is active, if the target frequency is changed to a specified value in a certain time period, the target discharge pipe temperature control is canceled and the target opening of the outdoor electronic expansion valve is changed.

# 4.12.6 Oil Recovery Function

#### **Outline**

The outdoor electronic expansion valve opening in the cooling stopped room is set as to open for a certain time at a specified interval so that the oil in the cooling stopped room may not be accumulated.

#### **Detail**

During cooling operation, every 1 hour continuous operation, the outdoor electronic expansion valves in the operation stopped room is opened by 80 pulses for specified time.

# 4.12.7 High Discharge Pipe Temperature Control

When the compressor is operating, if the discharge pipe temperature exceeds a certain value, the outdoor electronic expansion valve opens and the refrigerant runs to the low pressure side. This procedure lowers the discharge pipe temperature.

# 4.12.8 Control for Disconnection of the Discharge Pipe Thermistor

#### **Outline**

The disconnection of the discharge pipe thermistor is detected by comparing the discharge pipe temperature with the condensing temperature. If the discharge pipe thermistor is disconnected, the outdoor electronic expansion valve opens according to the outdoor temperature and the operation frequency, and operates for a specified time, and then stops.

After 3 minutes, the operation restarts and checks if the discharge pipe thermistor is disconnected. If the discharge pipe thermistor is disconnected, the system stops after operating for a specified time.

If the disconnection is detected repeatedly, the system is shut down. When the compressor runs for 60 minutes without any error, the error counter is reset.

#### Detail

#### **Detect Disconnection**

When the starting control (660 ~ 810 seconds) finishes, the following adjustment is made.

- 1. When the operation mode is cooling
  - When the following condition is fulfilled, the discharge pipe thermistor disconnection is ascertained.
  - Discharge pipe temperature + 6°C < outdoor heat exchanger temperature
- 2. When the operation mode is heating
  - When the following condition is fulfilled, the discharge pipe thermistor disconnection is ascertained

Discharge pipe temperature + 6°C < highest indoor heat exchanger temperature

#### Adjustment when the thermistor is disconnected

When the disconnection is ascertained, the compressor continues operation for 9 minutes and then stops.

If the compressor stops repeatedly, the system is shut down.

# 4.12.9 Gas Pipe Isothermal Control During Cooling

When the units are operating in multiple rooms, the gas pipe temperature is detected and the outdoor electronic expansion valve opening is adjusted so that the temperature of the gas pipe in each room becomes equal.

- When the gas pipe temperature > the average gas pipe temperature, → open the outdoor electronic expansion valve in that room
- When the gas pipe temperature < the average gas pipe temperature, → close the outdoor electronic expansion valve in that room</p>

The temperatures are monitored every 40 seconds.

# 4.12.10 SC (Subcooling) Control

#### **Outline**

The liquid pipe temperature and the heat exchanger temperature are detected and the outdoor electronic expansion valve opening is compensated so that the SC of each room becomes the target SC.

- When the actual SC is > target SC, open the outdoor electronic expansion valve of the room.
- When the actual SC is < target SC, close the outdoor electronic expansion valve of the room.

#### **Detail**

#### **Start Conditions**


After finishing the starting control ( $660 \sim 810$  seconds), (all) the outdoor electronic expansion valve(s) for the operating room is/are controlled.

# **Determine Outdoor Electronic Expansion Valve Opening**

The outdoor electronic expansion valve opening is adjusted so that the temperature difference between the maximum heat exchanger temperature of connected room and the liquid pipe temperature thermistor becomes constant.

# 4.12.11Target Discharge Pipe Temperature Control

The target discharge pipe temperature is obtained from the indoor and outdoor heat exchanger temperature, and the outdoor electronic expansion valve opening is adjusted so that the actual discharge pipe temperature becomes close to the target discharge pipe temperature. (Indirect SH (superheating) control using the discharge pipe temperature)



The outdoor electronic expansion valve opening and the target discharge pipe temperature are adjusted every 20 seconds. The target discharge pipe temperature is controlled by indoor heat exchanger temperature and outdoor heat exchanger temperature. The opening degree of the outdoor electronic expansion valve is controlled by the followings.

- Target discharge pipe temperature
- Actual discharge pipe temperature
- Previous discharge pipe temperature

# 4.13 Malfunctions

# 4.13.1 Sensor Malfunction Detection

Sensor malfunction may occur either in the thermistor or current transformer (CT) system.

#### **Relating to Thermistor Malfunction**

- 1. Outdoor heat exchanger thermistor
- 2. Discharge pipe thermistor
- 3. Radiation fin thermistor
- 4. Gas pipe thermistor
- 5. Outdoor temperature thermistor
- 6. Liquid pipe thermistor



## **Relating to CT Malfunction**

Refer to "CT or related abnormality" on page 315 for detail.

# 4.13.2 Detection of Overcurrent and Overload

#### **Outline**

In order to protect the inverter, an excessive output current is detected and the OL temperature is observed to protect the compressor.

#### Detail

- If the inverter current exceeds 14 ~ 20 A (depending on the model), the system shuts down the compressor.
- If the OL (compressor head) temperature exceeds 120 ~ 130°C, the compressor stops.


# 4.13.3 Refrigerant Shortage Control

# **Outline**

#### I: Detecting by power consumption


If the power consumption is below the specified value and the frequency is higher than the specified frequency, it is regarded as refrigerant shortage.

The power consumption is low comparing with that in the normal operation when refrigerant is insufficient, and refrigerant shortage is detected by checking power consumption.



#### II: Detecting by discharge pipe temperature

If the discharge pipe temperature is higher than the target discharge pipe temperature, and the outdoor electronic expansion valve is fully open for more than the specified time, it is regarded as refrigerant shortage.





Refer to "Refrigerant shortage" on page 296 for detail.

# 4.13.4 Anti-icing Function

During cooling, if the indoor heat exchanger temperature in the operation stopped room becomes below the specified temperature for the specified time, the outdoor electronic expansion valve is opened in the operation stopped room as specified, and the fully closed operation is carried out. After this, if freezing abnormality occurs more than specified time, the system shuts down as the system abnormality.

# Part 5 Operation Manual

1.	System Configuration	125
2.	RA Indoor Unit	126
	2.1 FTXG, FTXS-K, CTXS, FVXG Series - ARC466A1, A2, A6	126
	2.2 FTXS-J, FTXS-G, FVXS Series - ARC452A1, A3	178
	2.3 FLXS, FDXS Series - ARC433B67, B69	218
3.	SA Indoor Unit	233
-	3.1 BRC1D528	

SiBE121135 System Configuration

# 1. System Configuration

After installation and trial operation of the room air conditioner are completed, the air conditioner should be handled and operated as described in the following pages. Every user should be informed on the correct method of operation and how to check if it can cool (or heat) well, and how to use it efficiently.

Providing instructions to the user can reduce requests for servicing by 80%. However proficient the installation and operating functions of the air conditioning system are, the customer may fault either the room air conditioner or its installation work when it is actually due to improper handling. The installation work and the handing-over of the unit can only be considered completed when its handling has been fully explained to the user without using technical terms, and while imparting full knowledge of the equipment.

RA Indoor Unit SiBE121135

# 2. RA Indoor Unit

# 2.1 FTXG, FTXS-K, CTXS, FVXG Series - ARC466A1, A2, A6

# 2.1.1 Manual Contents and Reference Page

	Wall Moun	Floor Standing Type		
Model Series	FTXG25-50JV1BW(A)	FTXS20/25K2V1B CTXS15/35K2V1B	FVXG25-50K2V1B	
Read Before Operation				
Names of Parts	127	131	135	
Preparation before Operation	139 ★2	139 ★2	139	
Operation				
AUTO · DRY · COOL · HEAT · FAN Operation	141	143	145	
RADIANT Operation	_	_	146	
Temperature Setting	_	_	147	
Adjusting the Airflow Direction and Rate	Direction and Rate 148 150		152	
COMFORT AIRFLOW Operation	154 ★1 154		_	
INTELLIGENT EYE Operation	155 ★1	155	_	
POWERFUL Operation	157 ★1	157	158	
OUTDOOR UNIT QUIET Operation	159 ★2	159 ★2	159	
ECONO Operation	160 ★2	160 ★2	160	
OFF TIMER Operation	161	162	163	
ON TIMER Operation	164	165	166	
WEEKLY TIMER Operation	167 ★2	167 ★2	167	
Note for Multi System	173	173	173	
Quick Reference	175 ★1	176	177	
Drawing No.	3P255639-2A (Reference)	3P297033-1	3P276869-1	

 $<sup>\</sup>bigstar 1:$  Illustrations are for FTXS-K and CTXS-K series as representative.


 $<sup>\</sup>bigstar 2:$  Illustrations are for FVXG series as representative.

SiBE121135 RA Indoor Unit

# 2.1.2 Name of Parts

# FTXG25/35/50JV1BW(A)





# INTELLIGENT EYE lamp - (green)

# Signal receiver and Indoor unit ON/OFF switch

# Signal receiver

- It receives signals from the remote controller.
- When the unit receives a signal, you will hear a beep sound.

Case	Sound type			
Operation start	beep-beep			
Setting changed	beep			
Operation stop	long beep			

# Indoor unit ON/OFF switch

- Press this switch once to start operation.
   Press once again to stop it.
- The operation mode refer to the following table.

Mode	Temperature setting	Airflow rate			
AUTO	25°C	AUTO			

 This switch is useful when the remote controller is missing.

# Multi-monitor lamp and TIMER lamp


#### **Multi-monitor lamp**

• The lamp colour changes according to the operation.


Operation	Multi-monitor lamp		
AUTO	Red/Blue		
DRY	Green		
COOL	Blue		
HEAT	Red		
FAN	White		
TIMER	Orange		

# TIMER lamp


 When operation by timer has been set, the multi-monitor lamp periodically changes to orange. After lighting orange for about 5 seconds, it returns to the colour of the operation mode. The multi-monitor lamp will turn orange on and off in cyclic manner while the air conditioner is not in operation.




RA Indoor Unit SiBE121135



SiBE121135 RA Indoor Unit




RA Indoor Unit SiBE121135





SiBE121135 RA Indoor Unit


# FTXS20/25K2V1B, CTXS15/35K2V1B




RA Indoor Unit SiBE121135










## FVXG25/35/50K2V1B









# 2.1.3 Preparation before Operation

# **Preparation before Operation**



# ■ To set the batteries

- 1. Slide the front cover to take it off.
- 2. Set two dry batteries AAA.LR03 (alkaline).
- 3. Set the front cover as before.




# ■ To fix the remote controller holder on the wall

- 1. Choose a place from where the signals reach the unit.
- 2. Fix the holder to a wall, a pillar, or similar location with the screws procured locally
- 3. Place the remote controller in the remote controller holder.

# ■ To set the luminance of the display

• The luminance of the indoor unit display can be set.





### **NOTE**

#### ■ Notes on batteries

- When replacing the batteries, use batteries of the same type, and replace both old batteries together.
- When the system is not used for a long time, take the batteries out.
- The batteries will last for approximately 1 year. If the remote controller display begins to fade and the degradation of reception performance occurs within a year, however, replace both batteries with new, size AAA.LR03 (alkaline).
- The attached batteries are provided for the initial use of the system.
- The usable period of the batteries may be short depending on the manufactured date of the air conditioner.

#### ■ Notes on remote controller

- Never expose the remote controller to direct sunlight.
- Dust on the signal transmitter or receiver will reduce the sensitivity. Wipe off dust with soft cloth.
- Signal communication may be disabled if an electronic-starter-type fluorescent lamp (such as inverter-type lamps) is in the room. Consult the shop if that is the case.
- If the remote controller signals happen to operate another appliance, move that appliance to somewhere else, or consult the service shop.



# ■ Turn the breaker on

• After the power is turned on, the flap of the indoor unit opens and closes once to set the reference position.

# ■ To set the clock

1. Press 🐵



- " **!?.!!!**" is displayed on the LCD. "MON" and " **④**" blink.
- 2. Press to set the current day of the week.
- **3.** Press (9)



- 4. Press to set the clock to the present time.
  - ullet Holding down lacktriangle or lacktriangle rapidly increases or decreases the time display.
- **5.** Press (9)
  - Point the remote controller at the indoor unit when pressing the buttons.



• ":" blinks.

# **NOTE**

#### ■ Note on setting the clock

• If the indoor unit's internal clock is not set to the correct time, the ON TIMER, OFF TIMER and WEEKLY TIMER will not operate punctually.

# 2.1.4 AUTO · DRY · COOL · HEAT · FAN Operation

# FTXG25/35/50JV1BW(A)



# AUTO · DRY · COOL · HEAT · FAN Operation




The air conditioner operates with the operation mode of your choice. From the next time on, the air conditioner will operate with the same operation mode.

# ■ To start operation

# 1. Press Mode and select an operation mode.

• Each pressing of the button advances the mode setting in sequence.



# 2. Press (b)

- "ON" is displayed on the LCD.
- The multi-monitor lamp lights up.
   The colour of the lamp varies depending on the operation mode.



Operation	Multi-monitor lamp
AUTO	Red/Blue
DRY	Green
COOL	Blue
HEAT	Red
FAN	White

# ■ To stop operation

# Press (b) again.

- "ON" disappears from the LCD.
- The multi-monitor lamp goes off.

# NOTE

MODE	Notes on each operation mode			
HEAT	Since this air conditioner heats the room by taking heat from outdoor air to indoors, the heating capacity becomes smaller in lower outdoor temperatures. If the heating effect is insufficient, it is recommended to use another heating appliance in combination with the air conditioner.  The heat pump system heats the room by circulating hot air around all parts of the room. After the start of HEAT operation, it takes some time before the room gets warmer.  In HEAT operation, frost may occur on the outdoor unit and lower the heating capacity. In that case, the system switches into defrosting operation to take away the frost.  During defrosting operation, hot air does not flow out of indoor unit.			
COOL	This air conditioner cools the room by releasing the heat in the room outside.  Therefore, the cooling performance of the air conditioner may be degraded if the outdoor temperature is high			
DRY	The computer chip works to rid the room of humidity while maintaining the temperature as much as possible. It automatically controls temperature and airflow rate, so manual adjustment of these functions is unavailable.			
AUTO	In AUTO operation, the system selects an appropriate operation mode (COOL or HEAT) based on the room and outside temperatures and starts the operation.     The system automatically reselects setting at a regular interval to bring the room temperature to user-setting level.			
FAN	• This mode is valid for fan only.			



# To change the temperature setting

# Press

 The displayed items on the LCD will change whenever either one of the buttons is pressed.

71	COOL operation	HEAT operation	AUTO operation	DRY or FAN operation
	18-32°C	10-30°C	18-30°C	
	Press ▲ to raise the temperature and press ▼ to lower the temperature.			The temperature setting is not variable.

# ■ Operating conditions

## ■ Recommended temperature setting

- For cooling: 26-28°C
- For heating: 20-24°C

# ■ Tips for saving energy

- Be careful not to cool (heat) the room too much.
- Keeping the temperature setting at a moderate level helps save energy.
- Cover windows with a blind or a curtain.
- Blocking sunlight and air from outdoors increases the cooling (heating) effect.
- Clogged air filters cause inefficient operation and waste energy. Clean them once in about every 2 weeks.

### ■ Notes on the operating conditions

• The outdoor unit consumes some power to have its electric components work even while it is not operating.

Connecting outdoor unit RXG25/35: 1-15W

Other outdoor units: 15-20W

The outdoor unit consumes 40 to 55W of power at the time of compressor preheating.

- If you are not going to use the air conditioner for a long period, for example in spring or autumn, turn the breaker off.
- Use the air conditioner in the following conditions.

MODE	Operating conditions	If operation is continued out of this range
COOL	Outdoor temperature: <2/3/4/5MXS> -10-46°C <rxg> -10-46°C Indoor temperature: 18-32°C Indoor humidity: 80% max.</rxg>	A safety device may work to stop the operation. (In multi system, it may work to stop the operation of the outdoor unit only.) Condensation may occur on the indoor unit and drip.
HEAT	Outdoor temperature : <2MXS> -10-24°C <3/4/5MXS> -15-24°C <rxg> -15-24°C Indoor temperature : 10-30°C</rxg>	A safety device may work to stop the operation.
DRY	Outdoor temperature : <2/3/4/5MXS> -10-46°C <rxg> -10-46°C Indoor temperature : 18-32°C Indoor humidity : 80% max.</rxg>	A safety device may work to stop the operation.     Condensation may occur on the indoor unit and drip.

• Operation outside this humidity or temperature range may cause a safety device to disable the system.

# FTXS20/25K2V1B, CTXS15/35K2V1B



# AUTO · DRY · COOL · HEAT · FAN Operation




The air conditioner operates with the operation mode of your choice. From the next time on, the air conditioner will operate with the same operation mode.

# ■ To start operation

# 1. Press Mode and select an operation mode.

• Each pressing of the button advances the mode setting in sequence.



# 2. Press (b)

- " ON " is displayed on the LCD.
- The OPERATION lamp lights green.



Display


# ■ To stop operation

# Press on/of again.

- "ON" disappears from the LCD.
- The OPERATION lamp goes off.

# **NOTE**

MODE	Notes on each operation mode		
HEAT	<ul> <li>Since this air conditioner heats the room by taking heat from outdoor air to indoors, the heating capacity becomes smaller in lower outdoor temperatures. If the heating effect is insufficient, it is recommended to use another heating appliance in combination with the air conditioner.</li> <li>The heat pump system heats the room by circulating hot air around all parts of the room. After the start of HEAT operation, it takes some time before the room gets warmer.</li> <li>In HEAT operation, frost may occur on the outdoor unit and lower the heating capacity. In that case, the system switches into defrosting operation to take away the frost.</li> </ul>		
	During defrosting operation, hot air does not flow out of indoor unit.		
COOL	This air conditioner cools the room by releasing the heat in the room outside.  Therefore, the cooling performance of the air conditioner may be degraded if the outdoor temperature is high		
DRY	The computer chip works to rid the room of humidity while maintaining the temperature as much as possible. It automatic controls temperature and airflow rate, so manual adjustment of these functions is unavailable.		
AUTO	<ul> <li>In AUTO operation, the system selects an appropriate operation mode (COOL or HEAT) based on the room and outsic temperatures and starts the operation.</li> <li>The system automatically reselects setting at a regular interval to bring the room temperature to user-setting level.</li> </ul>		
FAN	• This mode is valid for fan only.		



# ■ To change the temperature setting

# Press

 The displayed items on the LCD will change whenever either one of the buttons is pressed.

COOL o	peration	HEAT operation	AUTO operation	DRY or FAN operation
18-3	2°C	10-30°C	18-30°C	The state of the s
Press ▲ to raise the temperature and press ▼ to lower the temperature.			The temperature setting is not variable.	

# ■ Operating conditions

## ■ Recommended temperature setting

- For cooling: 26-28°C
- For heating: 20-24°C

### ■ Tips for saving energy

- Be careful not to cool (heat) the room too much.
- Keeping the temperature setting at a moderate level helps save energy.
- Cover windows with a blind or a curtain.
- Blocking sunlight and air from outdoors increases the cooling (heating) effect.
- Clogged air filters cause inefficient operation and waste energy. Clean them once in about every 2 weeks.

## ■ Notes on the operating conditions

The outdoor unit consumes some power to have its electric components work even while it is not operating.
 Connecting outdoor unit RXS20/25: 1-15W

Other outdoor units: 15-20W

The outdoor unit consumes 40 to 55W of power at the time of compressor preheating.

- If you are not going to use the air conditioner for a long period, for example in spring or autumn, turn the breaker off.
- Use the air conditioner in the following conditions.

MODE	Operating conditions	If operation is continued out of this range
COOL	Outdoor temperature: <2MXS> 10-46°C <3/4/5MXS> -10-46°C <rxs> -10-46°C Indoor temperature: 18-32°C Indoor humidity: 80% max.</rxs>	A safety device may work to stop the operation. (In multi system, it may work to stop the operation of the outdoor unit only.)  Condensation may occur on the indoor unit and drip.
HEAT	Outdoor temperature: <2/3/4/5MXS> -15-24°C <rxs> -15-24°C Indoor temperature: 10-30°C</rxs>	A safety device may work to stop the operation.
DRY	Outdoor temperature: <2MXS> 10-46°C <3/4/5MXS> -10-46°C <rxs> -10-46°C Indoor temperature: 18-32°C Indoor humidity: 80% max.</rxs>	A safety device may work to stop the operation.     Condensation may occur on the indoor unit and drip.

• Operation outside this humidity or temperature range may cause a safety device to disable the system.

## FVXG25/35/50K2V1B



# **AUTO · DRY · COOL · HEAT · FAN Operation**




The air conditioner operates with the operation mode of your choice. From the next time on, the air conditioner will operate with the same operation mode.

# ■ To start operation

**1.** Press Mode and select an operation mode.

• Each pressing of the button advances the mode setting in sequence.



- 2. Press (b)
  - " on " is displayed on the LCD.
  - The OPERATION lamp lights green.



# ■ To stop operation

# Press (b) again.

- " ON " disappears from the LCD.
- The OPERATION lamp goes off.

## **NOTE**

MODE	Notes on each operation mode		
HEAT	Since this air conditioner heats the room by taking heat from outdoor air to indoors, the heating capacity becomes a lower outdoor temperatures. If the heating effect is insufficient, it is recommended to use another heating appliance combination with the air conditioner.      The heat pump system heats the room by circulating hot air around all parts of the room. After the start of HEAT optakes some time before the room gets warmer.      In HEAT operation, frost may occur on the outdoor unit and lower the heating capacity. In that case, the system sw into defrosting operation to take away the frost.      During defrosting operation, hot air does not flow out of indoor unit.		
COOL	<ul> <li>This air conditioner cools the room by releasing the heat in the room outside.         Therefore, the cooling performance of the air conditioner may be degraded if the outdoor temperature is high.     </li> <li>When the outdoor temperature is lower than 10°C, do not use COOL operation. If the operation is used when the outdoor temperature is lower than 10°C, the protective function of the main unit works and this disables the operation.</li> </ul>		
DRY	• The computer chip works to rid the room of humidity while maintaining the temperature as much as possible. It automatica controls temperature and airflow rate, so manual adjustment of these functions is unavailable.		
AUTO	<ul> <li>In AUTO operation, the system selects an appropriate operation mode (COOL or HEAT) based on the room and outside temperatures and starts the operation.</li> <li>The system automatically reselects setting at a regular interval to bring the room temperature to user-setting level.</li> </ul>		
FAN	This mode is valid for fan only.		

# 2.1.5 RADIANT Operation



# **RADIANT Operation**




The RADIANT operation provides a comfortable environment with quiet and currentless heating operation in addition to the HEAT operation mode. The RADIANT operation has 2 operation modes.

# ■ To start RADIANT operation

# 1. Press Mode and select an HEAT operation.


• Each pressing of the button advances the mode setting in sequence.



• " is displayed on the LCD.


# 2. Press and select a RADIANT operation.

- " III " is displayed on the LCD.
- The RADIANT lamp lights red.
- This button can be used only in the HEAT operation mode.
- When the RADIANT operation starts, the temperature of the radiant panel increases.





between the set temperature and indoor temperature is large, or to warm up the room quickly.



#### ■ RADIANT2

 Use this operation to prioritize quiet and currentless heating operation, or when the noise from RADIANT1 operation bothers you.
 The gentle breeze operation starts from the beginning.

# **⚠** CAUTION

During the RADIANT operation, the surface temperature of the panel will be about 55°C at maximum.
 Even after the RADIANT operation is finished, the surface temperature of the panel of the air conditioner stays hot for a while. Do not touch the air conditioner until the surface temperature of the panel decreases.
 Be careful that children do not touch the surface of the panel.

## NOTE

# ■ Notes on RADIANT operation

- If RADIANT2 operation does not warm up the room, use HEAT or RADIANT1 operation.
- RADIANT1 can be used with POWERFUL operation. RADIANT2 cannot be used with the POWERFUL operation.
- This operation may not warm up the room adequately depending on conditions such as an extremely low outside temperature and lack of adequate performance.
- The RADIANT operation uses the auto fan speed, so the airflow rate cannot be changed.
- When the indoor units are connected using a multi system, please refer to "Selecting the operation mode" in note for multi system.

# 2.1.6 Temperature Setting



# **Temperature Setting**



# ■ To change the temperature setting

# **Press**

• The displayed items on the LCD will change whenever either one of the buttons is pressed.

COOL operation	HEAT or RADIANT operation	AUTO operation	DRY or FAN operation
18-32°C	10-30°C	18-30°C	
Press ▲ to raise the temperature and press ▼ to lower the temperature.			The temperature setting is not variable.

# Operating conditions

#### ■ Recommended temperature setting

- For cooling: 26-28°C
- For heating: 20-24°C

## ■ Tips for saving energy

- Be careful not to cool (heat) the room too much.
- Keeping the temperature setting at a moderate level helps save energy
- Cover windows with a blind or a curtain.

  Blocking sunlight and air from outdoors increases the cooling (heating) effect.
- Clogged air filters cause inefficient operation and waste energy. Clean them once in about every 2 weeks.

## ■ Notes on the operating conditions

The outdoor unit consumes some power to have its electric components work even while it is not operating.

Connecting outdoor unit RXG25/35: 1-15W

Other outdoor units: 15-20W

The outdoor unit consumes 40 to 55W of power at the time of compressor preheating.

- If you are not going to use the air conditioner for a long period, for example in spring or autumn, turn the breaker off.
- Use the air conditioner in the following conditions.

MODE	Operating conditions	If operation is continued out of this range
COOL	Outdoor temperature: <2/3/4/5MXS> 10-46°C <rxg> 10-46°C Indoor temperature: 18-32°C Indoor humidity: 80% max.</rxg>	A safety device may work to stop the operation. (In multi system, it may work to stop the operation of the outdoor unit only.)  Condensation may occur on the indoor unit and drip.
HEAT or RADIANT	Outdoor temperature: <2MXS> -10-24°C <3/4/5MXS> -15-24°C <rxg> -15-24°C Indoor temperature: 10-30°C</rxg>	A safety device may work to stop the operation.
DRY	Outdoor temperature: <2/3/4/5MXS> 10-46°C <rxg> 10-46°C Indoor temperature: 18-32°C Indoor humidity: 80% max.</rxg>	A safety device may work to stop the operation.     Condensation may occur on the indoor unit and drip.

• Operation outside this humidity or temperature range may cause a safety device to disable the system.

# 2.1.7 Adjusting the Airflow Direction and Rate

FTXG25/35/50JV1BW(A)



# Adjusting the Airflow Direction and Rate



You can adjust the airflow direction to increase your comfort.

# ■ To start auto swing

# Upper and lower airflow direction

# Press ( Swing).

- "()" is displayed on the LCD.
- The flaps (horizontal blades) will begin to swing.



# ■ To set the flaps at desired position

• This function is effective while flaps are in auto swing mode.


# Press (swing) when the flaps have reached the desired position.


• "(3)" disappears from the LCD.


# ■ To adjust the louvers at desired position

## Hold the knob and move the louvers.

- You will find a knob on the left-side and the right-side blades
- When the unit is installed in the corner of a room, the direction of the louvers (vertical blades) should be facing away from the wall.










# ■ To adjust the airflow rate setting

# Press .

• Each pressing of advances the airflow rate setting in sequence.




- When the airflow is set to "\( \frac{1}{2}\)", indoor unit quiet operation will start and the noise from the unit will become quieter.
- In indoor unit quiet operation, the airflow rate is set to a weak level.
- In DRY mode, the airflow rate setting is not variable.

# NOTE

## ■ Note on the angles of the flaps

• The flaps swinging range depends on the operation. (See the figure.)



### ■ Note on airflow rate setting

- At smaller airflow rates, the cooling (heating) effect is also smaller.
- If the air conditioner is operated in COOL or DRY operation with the flaps kept stopped in the downward direction, the flaps will automatically start operating in approximately an hour in order to prevent dew condensation.



- Always use a remote controller to adjust the angles of the flaps. If you attempt to move it forcibly with hand when it is swinging, the mechanism may be broken.
- Be careful when adjusting the louvers.

  Inside the air outlet, a fan is rotating at a high speed.

## FTXS20/25K2V1B, CTXS15/35K2V1B



# **Adjusting the Airflow Direction and Rate**



You can adjust the airflow direction to increase your comfort.

# ■ To start auto swing

# Upper and lower airflow direction

Press (\$Swing).

- "(\$\frac{1}{2}"\) is displayed on the LCD.
- The flap (horizontal blade) will begin to swing.



# ■ To set the flap at desired position

• This function is effective while flap is in auto swing mode.


Press (4 Swing) when the flap has reached the desired position.


• "(3" disappears from the LCD.


# ■ To adjust the louvers at desired position


Hold the knob and move the louvers.

- You will find a knob on the left-side and the right-side blades.
- When the unit is installed in the corner of a room, the direction of the louvers (vertical blades) should be facing away from the wall.










# ■ To adjust the airflow rate setting

# Press 🚱

• Each pressing of advances the airflow rate setting in sequence.





- When the airflow is set to "\* ", indoor unit quiet operation will start and the noise from the unit will become quieter.
- In indoor unit quiet operation, the airflow rate is set to a weak level.
- If the temperature does not reach the desired point in the indoor unit quiet operation, change the airflow rate setting.
- In DRY mode, the airflow rate setting is not variable.


# **NOTE**

### ■ Notes on the angles of the flap

• The flap swinging range depends on the operation. (See the figure.)







• If the air conditioner is operated in COOL or DRY operation with the flap kept stopped in the downward direction, the flap will automatically start operating in approximately an hour in order to prevent dew condensation.

#### ■ Note on airflow rate setting

• At smaller airflow rates, the cooling (heating) effect is also smaller.



- Always use a remote controller to adjust the angles of the flap. If you attempt to move the flap and louvers forcibly with hand when they are swinging, the mechanism may be broken.
- Be careful when adjusting the louvers.

  Inside the air outlet, a fan is rotating at a high speed.

#### FVXG25/35/50K2V1B



# Adjusting the Airflow Direction and Rate



You can adjust the airflow direction to increase your comfort.

# ■ To start auto swing

# Upper and lower airflow direction

Press (\$Swing).

- " <₃" is displayed on the LCD.
- The flap (horizontal blade) will begin to swing.



# ■ To set the flap at desired position

• This function is effective while flap is in auto swing mode.

# Press (§Swing) when the flap has reached the desired position.

• " 📢 " disappears from the LCD.

# ■ To adjust the louvers at desired position

Hold the knob and move the louvers.

- You will find a knob on the left-side and the right-side blades.
- When the unit is installed in the corner of a room, the direction of the louvers (vertical blades) should be facing away from the wall.

If they face the wall, the wall will block off the wind, causing the cooling (or heating) efficiency to drop.

 If the flap is in the way, press (swing) on the remote controller to move the flap out of the way and then adjust the louvers.






# **Adjusting the Airflow Direction and Rate**



# ■ To adjust the airflow rate setting

# Press Pan

• Each pressing of advances the airflow rate setting in sequence.




- When the airflow is set to "★", indoor unit quiet operation will start and the noise from the unit will become quieter.
- In indoor unit quiet operation, the airflow rate is set to a weak level.
- In DRY or RADIANT operation, the airflow rate setting is not variable.

## **NOTE**

## ■ Note on the angles of the flap

• The flap swinging range is the same by all operation. (See the figure.)



#### ■ Note on airflow rate setting

At smaller airflow rates, the cooling (heating) effect is also smaller.



# **CAUTION**

- Always use a remote controller to adjust the angles of the flap. If you attempt to move it forcibly with hand when it is swinging, the mechanism may be broken.
- Be careful when adjusting the louvers.
   Inside the air outlet, a fan is rotating at a high speed.

# 2.1.8 COMFORT AIRFLOW Operation



# **COMFORT AIRFLOW Operation**



The flow of air will be in the upward direction while in COOL operation and in the downward direction while in HEAT operation, which will provide a comfortable wind that will not come in direct contact with people.

# ■ To start COMFORT AIRFLOW operation

# Press 2

- "a" is displayed on the LCD.
- Airflow rate is set to Auto.
   COOL/DRY: The flap will go up.
   HEAT: The flap will go down.

# ■ To cancel COMFORT AIRFLOW operation

# Press again.

- The flaps will return to the memory position from before COMFORT AIRFLOW operation.
- "A" disappears from the LCD.







**HEAT** operation

## **NOTE**

- Notes on COMFORT AIRFLOW operation
  - The flap position will change, preventing air from blowing directly on the occupants of the room.
  - POWERFUL operation and COMFORT AIRFLOW operation cannot be used at the same time.
     Priority is given to the function of whichever button is pressed last.
  - The airflow rate will be set to Auto. If the upper and lower airflow direction is selected, the COMFORT AIRFLOW operation will be canceled.

# 2.1.9 INTELLIGENT EYE Operation



# **INTELLIGENT EYE Operation**



"INTELLIGENT EYE" is the infrared sensor which detects the human movement. If nobody in the room for more than 20 minutes, the operation automatically changes to energy saving operation.

■ To start INTELLIGENT EYE operation

Press Sensor

- " 🔊 " is displayed on the LCD.
- The INTELLIGENT EYE lamp lights green.



Display

■ To cancel INTELLIGENT EYE operation

Press sensor again.

- " man disappears from the LCD.
- The INTELLIGENT EYE lamp goes off.



# **INTELLIGENT EYE Operation**


## [Example]



# When someone is in the room

#### ■ Normal operation

 The air conditioner is in normal operation while the sensor is detecting the movement of people



#### When no one is in the room

- 20 minutes after, start energy saving operation.
  - The set temperature is shifted in ±2°C steps.



# Someone is back in the

#### ■ Back to normal operation.

 The air conditioner will return to normal operation when the sensor detects the movement of people again.

# INTELLIGENT EYE operation is useful for energy saving

#### ■ Energy saving operation

- If no presence detected in the room for 20 minutes, the energy saving operation will start.
- This operation changes the temperature –2°C in HEAT / +2°C in COOL / +1°C in DRY operation from set temperature. When the room temperature exceeds 30°C, the operation changes the temperature +1°C in COOL / +1°C in DRY operation from set temperature.
- This operation decreases the airflow rate slightly in FAN operation only.


#### NOTE

## ■ Notes on INTELLIGENT EYE operation

Application range is as follows.

(Side view)

Vertical angle 90



- Sensor may not detect moving objects further than 7m away. (Check the application range.)
- Sensor detection sensitivity changes according to indoor unit location, the speed of passersby, temperature range, etc.
- The sensor also mistakenly detects pets, sunlight, fluttering curtains and light reflected off of mirrors as passersby.
- INTELLIGENT EYE operation will not go on during POWERFUL operation.
- NIGHT SET mode will not go on during use of INTELLIGENT EYE operation.


# A

# CAUTION

- Do not place large objects near the sensor.
- Also keep heating units or humidifiers outside the sensor's detection area. This sensor can detect undesirable objects.
- Do not hit or violently push the INTELLIGENT EYE sensor. This can lead to damage and malfunction.

# 2.1.10 POWERFUL Operation

## FTXG25/35/50JV1BW(A), FTXS20/25K2V1B, CTXS15/35K2V1B



**POWERFUL Operation** 

POWERFUL operation quickly maximizes the cooling (heating) effect in any operation modes. You can get the maximum capacity.

# To start POWERFUL operation

# Press during operation.

- POWERFUL operation ends in 20 minutes. Then the system automatically operates again with the previous settings which were used before POWERFUL operation.
- " " is displayed on the LCD.

# **■** To cancel POWERFUL operation

# Press 🕶 again

• "\" disappears from the LCD.

### [Example]



- Normal operation
  - When you want to get the cooling effect quickly, start the POWERFUL operation.



- POWERFUL operation
- POWERFUL operation will work for 20 minutes.



Back to normal operation

#### **NOTE**

## ■ Notes on POWERFUL operation

- When using POWERFUL operation, there are some functions which are not available.
- POWERFUL operation cannot be used together with ECONO, COMFORT AIRFLOW or OUTDOOR UNIT QUIET operation.
   Priority is given to the function of whichever button is pressed last.
- POWERFUL operation can only be set when the unit is running. Pressing (b) causes the settings to be canceled, and the "" disappears from the LCD.
- POWERFUL operation will not increase the capacity of the air conditioner if the air conditioner is already in operation with its maximum capacity demonstrated.

## • In COOL and HEAT operation

To maximize the cooling (heating) effect, the capacity of outdoor unit is increased and the airflow rate is fixed to the maximum setting. The temperature and airflow settings are not variable.

### • In DRY operation

The temperature setting is lowered by 2.5°C and the airflow rate is slightly increased.

## • In FAN operation

The airflow rate is fixed to the maximum setting.

#### • In AUTO operation

To maximize the cooling (heating) effect, the capacity of outdoor unit is increased and the airflow rate is fixed to the maximum setting.

#### FVXG25/35/50K2V1B



# **POWERFUL Operation**



POWERFUL operation quickly maximises the cooling (heating) effect in any operation mode. You can get the maximum capacity.

# ■ To start POWERFUL operation

### during operation. Press (

- POWERFUL operation ends in 20 minutes. Then the system automatically operates again with the previous settings which were used before POWERFUL operation.
- " 🗳 " is displayed on the LCD.

# ■To cancel POWERFUL operation

# Powerful Press ( 🍄 ) again.

• " " disappears from the LCD.

## [Example]



· When you want to get the cooling effect quickly, start the POWERFUL operation.



■POWERFUL operation

• POWERFUL operation will work for 20 minutes



## ■Back to normal operation

## NOTE

### ■ Notes on POWERFUL operation

- When using POWERFUL operation, there are some functions which are not available
- POWERFUL operation cannot be used together with RADIANT2, ECONO or OUTDOOR UNIT QUIET operation. Priority is given to the function of whichever button is pressed last.
- POWERFUL operation can only be set when the unit is running. Pressing ( b) causes the settings to be canceled, and the " 🛟 " disappears from the LCD.
- POWERFUL operation will not increase the capacity of the air conditioner if the air conditioner is already in operation with its maximum

#### • In COOL, HEAT and RADIANT1 operation

To maximise the cooling (heating) effect, the capacity of outdoor unit is increased and the airflow rate is fixed to the maximum setting. The temperature and airflow settings are not variable.

### In DRY operation

The temperature setting is lowered by 2.5°C and the airflow rate is slightly increased.

#### In FAN operation

The airflow rate is fixed to the maximum setting

#### In AUTO operation

To maximise the cooling (heating) effect, the capacity of outdoor unit is increased and the airflow rate is fixed to the maximum setting.

# 2.1.11 OUTDOOR UNIT QUIET Operation



# UTDOOR UNIT QUIET Operation



OUTDOOR UNIT QUIET operation lowers the noise level of the outdoor unit by changing the frequency and fan speed on the outdoor unit. This function is convenient during the night.

# To start OUTDOOR UNIT QUIET operation

Press ( 100


• " 1 " is displayed on the LCD.

# ■ To cancel OUTDOOR UNIT QUIET operation

13 Press ( 🕽 again.

• " 1 disappears from the LCD.

# [Example] Using the OUTDOOR UNIT QUIET operation during the night.



• The noise level of the outdoor unit will be lower. This is convenient when you need to consideration for your neighbourhood.

# **NOTE**

## ■ Notes on OUTDOOR UNIT QUIET operation

- This function is available in COOL, HEAT, and AUTO operation.
- This is not available in RADIANT, FAN and DRY operation.

   POWERFUL operation and OUTDOOR UNIT QUIET operation cannot be used at the same time.
- Priority is given to the function of whichever button is pressed last.
- Even the operation is stopped using the remote controller or the indoor unit ON/OFF switch when using OUTDOOR UNIT QUIET operation, "will remain on the remote controller display
- OUTDOOR UNIT QUIET operation will drop neither the frequency nor fan speed if they have been already dropped low enough.

# 2.1.12 ECONO Operation



# **ECONO Operation**



ECONO operation is a function which enables efficient operation by limiting the maximum power consumption value.

This function is useful for cases in which attention should be paid to ensure a circuit breaker will not trip when the product runs alongside other appliances.

# ■ To start ECONO operation

# Press Geono during operation.

• " ▼ " is displayed on the LCD.

# ■ To cancel ECONO operation

# Press (TECONO) again.

#### [Example]

#### Normal operation



 In case the air conditioner and other appliances which require high power consumption are used at same time, a circuit breaker may trip if the air conditioner operate with its maximum capacity.

#### **ECONO** operation




 The maximum power consumption of the air conditioner is limited by using ECONO operation.

The circuit breaker will hardly trip even if the air conditioner and other appliances are used at same time.

• This diagram is a representation for illustrative purposes only.

The maximum running current and power consumption of the air conditioner in ECONO operation vary with the connecting outdoor unit.





From start up until set temperature is reached

# **NOTE**

## ■ Notes on ECONO operation


- ECONO operation can only be set when the unit is running. Pressing (1) causes the settings to be canceled, and the "\stacks" disappears from the LCD.
- ECONO operation is a function which enables efficient operation by limiting the power consumption of the outdoor unit (operating frequency).
- ECONO operation functions in AUTO, COOL, DRY, and HEAT operation.
   This is not available in RADIANT and FAN operation.
- POWERFUL operation and ECONO operation cannot be used at the same time.
- Priority is given to the function of whichever button is pressed last.
- If the level of power consumption is already low, ECONO operation will not drop the power consumption.

# 2.1.13 OFF TIMER Operation

## FTXG25/35/50JV1BW(A)



# **OFF TIMER Operation**



Timer functions are useful for automatically switching the air conditioner on or off at night or in the morning. You can also use OFF TIMER and ON TIMER in combination.

# ■ To use OFF TIMER operation

Check that the clock is correct.
 If not, set the clock to the present time.

1. Press off



- " (I) " is displayed on the LCD.
- . " OFF " blinks.
- "O" and day of the week disappear from the LCD.

# 2. Press until the time setting reaches the point you like.

• Each pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the time setting rapidly.

# 3. Press again.

- " OFF " and setting time are displayed on the LCD.
- The multi-monitor lamp blinks twice.
  The TIMER lamp periodically lights orange.



# ■ To cancel OFF TIMER operation

# Press Cancel

- " OFF " and setting time disappear from the LCD.
- " " and day of the week are displayed on the LCD.

## **NOTE**

### ■ Notes on TIMER operation

- When TIMER is set, the present time is not displayed.
- Once you set ON/OFF TIMER, the time setting is kept in the memory. The memory is canceled when remote controller batteries are replaced.
- When operating the unit via the ON/OFF TIMER, the actual length of operation may vary from the time entered by the user. (Maximum approx. 10 minutes)


#### ■ NIGHT SET mode

• When the OFF TIMER is set, the air conditioner automatically adjusts the temperature setting (0.5°C up in COOL, 2.0°C down in HEAT) to prevent excessive cooling (heating) for your pleasant sleep.

## FTXS20/25K2V1B, CTXS15/35K2V1B



# **OFF TIMER Operation**



Timer functions are useful for automatically switching the air conditioner on or off at night or in the morning. You can also use OFF TIMER and ON TIMER in combination.

# ■ To use OFF TIMER operation

Check that the clock is correct.
 If not, set the clock to the present time.

1. Press off.



- " 0:00 " is displayed on the LCD.
- " OFF " blinks.
- "O" and day of the week disappear from the LCD.

# 2. Press until the time setting reaches the point you like.

Each pressing of either button increases or decreases the time setting by 10 minutes.
 Holding down either button changes the time setting rapidly.

# 3. Press again.

- "OFF" and setting time are displayed on the LCD.
- The TIMER lamp lights yellow.



# ■ To cancel OFF TIMER operation

# Press Cancel

- "OFF" and setting time disappear from the LCD.
- "O" and day of the week are displayed on the LCD.
- The TIMER lamp goes off.

## NOTE

#### ■ Notes on TIMER operation

- When TIMER is set, the present time is not displayed.
- Once you set ON/OFF TIMER, the time setting is kept in the memory. The memory is canceled when remote controller batteries are replaced.
- When operating the unit via the ON/OFF TIMER, the actual length of operation may vary from the time entered by the user. (Maximum approx. 10 minutes)

#### ■ NIGHT SET mode

• When the OFF TIMER is set, the air conditioner automatically adjusts the temperature setting (0.5°C up in COOL, 2.0°C down in HEAT) to prevent excessive cooling (heating) for your pleasant sleep.

#### FVXG25/35/50K2V1B



# **OFF TIMER Operation**



Timer functions are useful for automatically switching the air conditioner on or off at night or in the morning. You can also use OFF TIMER and ON TIMER in combination.

# ■To use OFF TIMER operation

Check that the clock is correct.
 If not, set the clock to the present time.

1. Press off.



- " **[;;[][]** " is displayed on the LCD.
- " OFF " blinks.
- " ② " and day of the week disappear from the LCD.

# 2. Press until the time setting reaches the point you like.

- Each pressing of either button increases or decreases the time setting by 10 minutes.
   Holding down either button changes the time setting rapidly.
- 3. Press again.
  - " OFF" and setting time are displayed on the LCD.
  - The OPERATION lamp blinks and the TIMER lamp lights yellow.



# ■ To cancel OFF TIMER operation

# Press Cancel

- "OFF" and setting time disappear from the LCD.
- " O " and day of the week are displayed on the LCD.

## **NOTE**

#### ■ Notes on TIMER operation

- When TIMER is set, the present time is not displayed
- Once you set ON/OFF TIMER, the time setting is kept in the memory. The memory is canceled when remote controller batteries are replaced.
- When operating the unit via the ON/OFF TIMER, the actual length of operation may vary from the time entered by the user. (Maximum approximately 10 minutes)

#### ■ NIGHT SET mode

• When the OFF TIMER is set, the air conditioner automatically adjusts the temperature setting (0.5°C up in COOL, 2.0°C down in HEAT) to prevent excessive cooling (heating) for your pleasant sleep.

# 2.1.14 ON TIMER Operation

## FTXG25/35/50JV1BW(A)



# **ON TIMER Operation**



# ■ To use ON TIMER operation

• Check that the clock is correct.

If not, set the clock to the present time.

1. Press on



- " 5:00" is displayed on the LCD.
- " ON " blinks.
- "O" and day of the week disappear from the LCD.

# 2. Press until the time setting reaches the point you like.

- Each pressing of either button increases or decreases the time setting by 10 minutes.
   Holding down either button changes the setting rapidly.
- 3. Press again.
  - " ON " and setting time are displayed on the LCD.
  - The multi-monitor lamp blinks twice.
     The TIMER lamp periodically lights orange.




# ■ To cancel ON TIMER operation

Press Cancel

- " ON " and setting time disappear from the LCD.
- " " and day of the week are displayed on the LCD.

# ■ To combine ON TIMER and OFF TIMER

• A sample setting for combining the 2 timers is shown below.



#### NOTE

- In the following cases, set the timer again.
  - After a breaker has turned off.
  - After a power failure.
  - After replacing batteries in the remote controller.

# FTXS20/25K2V1B, CTXS15/35K2V1B



# **ON TIMER Operation**



# ■ To use ON TIMER operation

- Check that the clock is correct.
   If not, set the clock to the present time.
- 1. Press on



- " 5:00" " is displayed on the LCD.
- "ON" blinks.
- "O" and day of the week disappear from the LCD.

# 2. Press until the time setting reaches the point you like.

- Each pressing of either button increases or decreases the time setting by 10 minutes.
   Holding down either button changes the setting rapidly.
- 3. Press again.
  - "ON" and setting time are displayed on the LCD.
  - The TIMER lamp lights yellow.



Displa

# ■ To cancel ON TIMER operation

# Press Cancel

- "ON" and setting time disappear from the LCD.
- "O" and day of the week are displayed on the LCD.
- The TIMER lamp goes off.

# ■ To combine ON TIMER and OFF TIMER

• A sample setting for combining the 2 timers is shown below.



#### NOTE

- In the following cases, set the timer again.
  - After a breaker has turned off.
  - After a power failure.
  - After replacing batteries in the remote controller.

#### FVXG25/35/50K2V1B



# **ON TIMER Operation**



# ■ To use ON TIMER operation

- Check that the clock is correct.
   If not, set the clock to the present time.
- 1. Press on .



- " 5:00 " is displayed on the LCD.
- " ON " blinks.
- " @ " and day of the week disappear from the LCD.

# 2. Press until the time setting reaches the point you like.

- Each pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the time setting rapidly.
- 3. Press again.
  - "ON" and setting time are displayed on the LCD.
  - The OPERATION lamp blinks and the TIMER lamp lights yellow.



# ■To cancel ON TIMER operation

Press Cancel

- " ON " and setting time disappear from the LCD.
- " ① " and day of the week are displayed on the LCD.

# ■ To combine ON TIMER and OFF TIMER

• A sample setting for combining the 2 timers is shown below.



## NOTE

- In the following cases, set the timer again.
  - After a breaker has turned off.
  - After a power failure.
  - After replacing batteries in the remote controller.

# 2.1.15 WEEKLY TIMER Operation




# **WEEKLY TIMER Operation**


Up to 4 timer settings can be saved for each day of the week. It is convenient if the WEEKLY TIMER is set according to the family's life style.

# ■ Using in these cases of WEEKLY TIMER

[Example] The same timer settings are made for the week from Monday through Friday while different timer settings are made for the weekend.




- Up to 4 reservations per day and 28 reservations per week can be set in the WEEKLY TIMER. The effective use of the copy mode ensures ease of making reservations.
- The use of ON-ON-ON-ON settings, for example, makes it possible to schedule operating mode and set temperature changes. Furthermore, by using OFF-OFF-OFF settings, only the turn off time of each day can be set. This will turn off the air conditioner automatically if the user forgets to turn it off.




# **■To use WEEKLY TIMER operation**

## **Setting mode**

• Make sure the day of the week and time are set. If not, set the day of the week and time.





- **1.** Press →
  - The day of the week and the reservation number of the current day will be displayed.
  - 1 to 4 settings can be made per day
- 2. Press to select the desired day of the week and reservation number.
  - Pressing select changes the reservation number and the day of the week.
- 3. Press Next
  - The day of the week and reservation number will be set.
  - " WEEKLY " and " ON " blink.
- 4. Press to select the desired mode.
  - Pressing changes "ON" or " OFF" setting in sequence.

Pressing  ${\color{blue}\blacktriangle}$  alternates the following items appearing on the LCD in rotational sequence.



- In case the reservation has already been set, selecting "blank" deletes the reservation.
- ullet Go to step  $oldsymbol{g}$  if "blank" is selected.
- To return to the day of the week and reservation number setting, press

# **5.** Press Next

- The ON/OFF TIMER mode will be set.
- " WEEKLY " and the time blink.



# **WEEKLY TIMER Operation**



# 6. Press to select the desired time.

- The time can be set between 0:00 and 23:50 in 10 minute intervals.
- To return to the ON/OFF TIMER mode setting, press
- Go to step 9 when setting the OFF TIMER.

## 

- The time will be set.
- " WEEKLY " and the temperature blink.

# 8. Press to select the desired temperature.

- The temperature can be set between 10°C and 32°C. COOL or AUTO: The unit operates at 18°C even if it is set at 10 to 17°C. HEAT or AUTO: The unit operates at 30°C even if it is set at 31 to 32°C.
- To return to the time setting, press
- The set temperature is only displayed when the mode setting is on.

## **9.** Press Next

- Be sure to direct the remote controller toward the indoor unit and check for a receiving tone and flashing the OPERATION lamp.
- The temperature is set while in ON TIMER operation, and the time is set while in OFF TIMER operation.
- The next reservation screen will appear.
- ullet To continue further settings, repeat the procedure from step  ${oldsymbol 4}.$
- The TIMER lamp lights yellow.



# 10. Press to complete the setting.

- " " " is displayed on the LCD and WEEKLY TIMER operation is activated.
- A reservation made once can be easily copied and the same settings used for another day of the week. Refer to copy mode.

## **NOTE**


## ■ Notes on WEEKLY TIMER operation


- Do not forget to set the clock on the remote controller first.
- The day of the week, ON/OFF TIMER mode, time and set temperature (only for ON TIMER mode) can be set with WEEKLY TIMER.
   Other settings for ON TIMER are based on the settings just before the operation.
- Both WEEKLY TIMER and ON/OFF TIMER operation cannot be used at the same time. The ON/OFF TIMER operation has priority if it is set while WEEKLY TIMER is still active. The WEEKLY TIMER will go into standby state, and "
- Shutting the breaker off, power failure, and other similar events will render operation of the indoor unit's internal clock inaccurate. Reset the clock.



#### Copy mode

• A reservation made once can be copied to another day of the week. The whole reservation of the selected day of the week will be copied.





- 2. Press to confirm the day of the week to be copied.
- 3. Press \_\_\_\_\_.
  - The whole reservation of the selected day of the week will be copied.
- 4. Press to select the destination day of the week.
- **5.** Press
  - Be sure to direct the remote controller toward the indoor unit and check for a receiving tone and flashing the OPERATION lamp.
  - The reservation will be copied to the selected day of the week. The whole reservation of the selected day of the week will be copied.
  - ullet To continue copying the settings to other days of the week, repeat step  $oldsymbol{4}$  and step  $oldsymbol{5}$ .
- 6. Press to complete the setting.
  - " OWEEKLY " is displayed on the LCD and WEEKLY TIMER operation is activated.

## **NOTE**

- Note on copy mode
  - The entire reservation of the source day of the week is copied in the copy mode.

In the case of making a reservation change for any day of the week individually after copying the content of weekly reservations, press and change the settings in the steps of setting mode.




# **WEEKLY TIMER Operation**



## ■ Confirming a reservation

• The reservation can be confirmed.



- **1.** Press
  - The day of the week and the reservation number of the current day will be displayed.
- 2. Press to select the day of the week and the reservation number to be confirmed.
  - displays the reservation details.
  - To change the confirmed reserved settings, select the reservation number and press

The mode is switched to setting mode. Go to setting mode step 2.

3. Press 

to exit confirming mode.

## ■ To deactivate WEEKLY TIMER operation

Press while "OWEEKLY" is displayed on the LCD.

- The "OWEEKLY" will disappear from the LCD.
- The TIMER lamp goes off.
- To reactivate the WEEKLY TIMER operation, press again.
- If a reservation deactivated with is activated once again, the last reservation mode



• If not all the reservation settings are reflected, deactivate the WEEKLY TIMER operation once. Then press again to reactivate the WEEKLY TIMER operation.



## ■ To delete reservations

#### The individual reservation

- **1.** Press <u>⊕</u> .
  - The day of the week and the reservation number will be displayed.
- 2. Press to select the day of the week and the reservation number to be deleted.
- - " WEEKLY " and " ON " or " OFF " blink.
- 4. Press and select "blank".
  - Pressing changes ON/OFF TIMER mode.

Pressing  ${\color{red}\blacktriangle}$  alternates the following items appearing on the LCD in rotational sequence.

• The reservation will be no setting with selecting "blank".



- **5.** Press Next.
  - The selected reservation will be deleted.
- - If there are still other reservations, WEEKLY TIMER operation will be activated.

## The reservations for each day of the week

- This function can be used for deleting reservations for each day of the week.
- It can be used while confirming or setting reservations.
- 1. Press to select the day of the week to be deleted.
- **2.** Hold for 5 seconds.
  - The reservation of the selected day of the week will be deleted.

## All reservations

Weekly

## Hold for 5 seconds while normal display.

- Be sure to direct the remote controller toward the indoor unit and check for a receiving tone.
- This operation is not effective while WEEKLY TIMER is being set.
- All reservations will be deleted.

## 2.1.16 Note for Multi System

# **Note for Multi System**

Multi system has one outdoor unit connected to multiple indoor units.


## Selecting the operation mode

With the priority room setting present but inactive or not present.

When more than one indoor unit is operating, priority is given to the first unit that was turned on.

In this case, set the units that are turned on later to the same operation mode as the first unit.

Otherwise, they will enter the standby state, and the OPERATION lamp will flash: this does not indicate malfunction.



## **NOTE**

#### ■ Notes on operation mode for multi system

- COOL, DRY and FAN operation may be used at the same time.
- HEAT and RADIANT operation may be used at the same time.
- AUTO operation automatically selects COOL operation or HEAT operation based on the room temperature

Therefore, AUTO operation is available when selecting the same operation mode as that of the room with the first unit to be turned on.



Normally, the operation mode in the room where the unit is first run is given priority, but the following situations are exceptions, so please keep

If the operation mode of the first room is FAN operation, then using HEAT and RADIANT operation in any room after this will give priority to HEAT and RADIANT operation. In this situation, the air conditioner running in FAN operation will go on standby, and the OPERATION lamp will flash When the RADIANT operation starts when the FAN operation is used in another room, the FAN operation is switched to the HEAT operation.

## With the priority room setting active.

Refer to priority room setting on the next page.

## ■ NIGHT QUIET mode (Available only for COOL operation)

NIGHT QUIET mode requires initial programming during installation. Please consult your retailer or dealer for assistance. NIGHT QUIET mode reduces the operation noise of the outdoor unit during the nighttime hours to prevent annoyance to neighbours

- The NIGHT QUIET mode is activated when the temperature drops 5°C or more below the highest temperature recorded that day. Therefore, when the temperature difference is less than 5°C, this function will not be activated.
- NIGHT QUIET mode reduces slightly the cooling efficiency of the unit.

## ■ OUTDOOR UNIT QUIET operation

Refer to OUTDOOR UNIT QUIET operation.

### With the priority room setting present but inactive or not present.

When using the OUTDOOR UNIT QUIET operation feature with the multi system, set all indoor units to OUTDOOR UNIT QUIET operation using their remote controllers.

When clearing OUTDOOR UNIT QUIET operation, clear one of the operating indoor units using their remote controller. However OUTDOOR UNIT QUIET operation display remains on the remote controller for other rooms. We recommend you release all rooms using their remote controllers.

With the priority room setting active.

Refer to priority room setting on the next page

## **■ COOL/HEAT mode lock**

The COOL/HEAT mode lock requires initial programming during installation. Please consult your authorised dealer for assistance. The COOL/HEAT mode lock sets the unit forcibly to either COOL or HEAT operation. This function is convenient when you wish to set all indoor units connected to the multi system to the same operation mode. During the COOL mode, the DRY operation can also be used. During the HEAT mode, the RADIANT operation can also be used.

#### NOTE

• The COOL/HEAT mode lock cannot be activated together with the priority room setting.

## Priority room setting

The priority room setting requires initial programming during installation. Please consult your authorised dealer for assistance

The room designated as the priority room takes priority in the following situations.

#### **Operation mode priority**

 As the operation mode of the priority room takes precedence, the user can select a different operation mode from other rooms.

#### [Example]

Room A is the priority room in the examples.

When COOL operation is selected in room A while operating the following modes in room B, C and D:

Operation mode in room B, C and D	Status of room B, C and D when the unit in room A is in COOL operation	
COOL or DRY or FAN	Current operation mode maintained	
HEAT and RADIANT	The unit enters standby mode. Operation resumes when the room A unit stops operating.	
AUTO	If the unit is set to COOL operation, it continues. If the unit is set to HEAT operation, it enters standby mode. Operation resumes when the room A unit stops operating.	

## Priority when POWERFUL operation is used

#### [Example]

Room A is the priority room in the examples.

The indoor units in rooms A, B, C and D are all operating. If the unit in room A enters POWERFUL operation, operation capacity will be concentrated in room A. In such a case, the cooling (heating) efficiency of the units in room B, C and D may be slightly reduced.

## Priority when using OUTDOOR UNIT QUIET operation

#### [Example]


• Room A is the priority room in the examples.

Just by setting the unit in room A to QUIET operation, the air conditioner starts OUTDOOR UNIT QUIET operation. You don't have to set all the operated indoor units to QUIET operation.

## 2.1.17 Quick Reference


FTXG25/35/50JV1BW(A)

# **Quick Reference**




FTXS20/25K2V1B, CTXS15/35K2V1B

# **Quick Reference**



## FVXG25/35/50K2V1B

# **Quick Reference**



## 2.2 FTXS-J, FTXS-G, FVXS Series - ARC452A1, A3

## 2.2.1 Manual Contents and Reference Page

Madal Carias	Wall Mou	Floor Standing Type	
Model Series —	FTXS25-50J2V1B	FTXS60/71GV1B	FVXS25-50FV1B
Read Before Operation			
Names of Parts	179	182	185
Operation			
AUTO · DRY · COOL · HEAT · FAN Operation ★	188	188	188
Adjusting the Airflow Direction	190	192	194
COMFORT AIRFLOW and INTELLIGENT EYE Operation	196	200	_
POWERFUL Operation ★	203	203	203
OUTDOOR UNIT QUIET Operation ★	204	204	204
ECONO Operation ★	205	205	205
OFF TIMER Operation ★	206	206	206
ON TIMER Operation ★	207	207	207
WEEKLY TIMER Operation ★	208	208	208
Note for Multi System ★	216	216	216
Drawing No.	3P266959-2A	3P248442-3	3P191290-1K


<sup>★:</sup> The illustrations are for FTXS-J series as representative.

## 2.2.2 Names of Parts

FTXS20/25/35/42/50J2V1B

# **Names of Parts**

## **■** Indoor Unit



## ■Indoor Unit -

- 1. Air filter
- 2. Titanium apatite photocatalytic air-purifying filter:
  - These filters are attached to the inside of the air filters.
- 3. Air inlet
- 4. Front panel
- 5. Panel tab
- 6. Room temperature sensor:
  - It senses the air temperature around the unit.
- 7. INTELLIGENT EYE sensor
- 8. Display
- 9. Air outlet
- 10. Flaps (horizontal blades)
- 11. Louvers (vertical blades):
  - The louvers are inside of the air outlet.
- 12. Model name plate


#### 13. Indoor unit ON/OFF switch:

- Push this switch once to start operation. Push once again to stop it.
- The operation mode refers to the following table.

Model	Mode	Temperature setting	Airflow rate
COOLING ONLY	COOL	22°C	AUTO
HEAT PUMP	AUTO	25°C	AUTO

- This switch is useful when the remote controller is missing.
- 14. OPERATION lamp (green)
- 15. TIMER lamp (yellow)
- 16. INTELLIGENT EYE lamp (green)
- 17. Signal receiver:
  - It receives signals from the remote controller.
  - When the unit receives a signal, you will hear a beep sound.
    - Operation start ..... beep-beep
    - Settings changed ...... beep
    - Operation stop .....long beep

## **■** Remote Controller



### 1. Signal transmitter:

• It sends signals to the indoor unit.

#### 2. Display:

It displays the current settings.
 (In this illustration, each section is shown with its displays ON for the purpose of explanation.)

## 3. FAN setting button:

• It selects the airflow rate setting.

#### 4. POWERFUL button:

POWERFUL operation

#### 5. ON/OFF button:

• Press this button once to start operation. Press once again to stop it.

## 6. TEMPERATURE adjustment buttons:

•It changes the temperature setting.

## 7. MODE selector button:

 It selects the operation mode. (AUTO/DRY/COOL/HEAT/FAN)

## 8. QUIET button:


**OUTDOOR UNIT QUIET operation** 

#### 9. ECONO button:

ECONO operation

#### 10. SWING button:

· Horizontal blades (flaps)



#### 11. SWING button:

· Vertical blades (louvers)

### 12. COMFORT/SENSOR button:

 COMFORT AIRFLOW and INTELLIGENT EYE operation

## 13. WEEKLY/PROGRAM/COPY/BACK/NEXT button:

• WEEKLY TIMER operation

#### 14. SELECT button:

 It changes the ON/OFF TIMER and WEEKLY TIMER settings.

#### 15. OFF TIMER button

16. ON TIMER button

### 17. TIMER CANCEL button:


- It cancels the timer setting.
- It cannot be used for the WEEKLY TIMER operation.

## 18. CLOCK button

## FTXS60/71GV1B

# **Names of Parts**

## **■** Indoor Unit



## ■ Indoor Unit-

- 1. Air filter
- 2. Titanium apatite photocatalytic air-purifying filter:
  - •These filters are attached to the inside of the air filters.
- 3. Air inlet
- 4. Front panel
- 5. Panel tab
- 6. Room temperature sensor:
  - It senses the air temperature around the unit
- 7. INTELLIGENT EYE sensor
- 8. Display
- 9. Air outlet
- 10. Flaps (horizontal blades)
- 11. Louvers (vertical blades):
  - · The louvers are inside of the air outlet.
- 12. Model name plate

#### 13. Indoor unit ON/OFF switch:


- Push this switch once to start operation. Push once again to stop it.
- The operation mode refers to the following table.

Model	Mode	Temperature setting	Airflow rate
COOLING	COOL	22°C	AUTO
HEAT PUMP	AUTO	25°C	AUTO

- This switch is useful when the remote controller is missing.
- 14. OPERATION lamp (green)
- 15. TIMER lamp (yellow)
- 16. INTELLIGENT EYE lamp (green)
- 17. Signal receiver:
  - It receives signals from the remote controller.
  - When the unit receives a signal, you will hear a beep sound.
    - Operation start .....beep-beep
    - Settings changed......beep
    - Operation stop.....long beep

## **Names of Parts**

## **■** Remote Controller



## 1. Signal transmitter:

• It sends signals to the indoor unit.

## 2. Display (LCD):

• It displays the current settings. (In this illustration, each section is shown with its displays on for the purpose of explanation.)

## 3. FAN setting button:

• It selects the airflow rate setting.

#### 4. POWERFUL button:

POWERFUL operation

## 5. ON/OFF button:

Press this button once to start operation.
 Press once again to stop it.

## 6. TEMPERATURE adjustment buttons:

• It changes the temperature setting.

#### 7. MODE selector button:


 It selects the operation mode. (AUTO/DRY/COOL/HEAT/FAN)

### 8. QUIET button:

**OUTDOOR UNIT QUIET operation** 

#### 9. ECONO button:

**ECONO** operation



## 10. SWING button:

• Flaps (horizontal blades)

## 11. SWING button:

· Louvers (vertical blades)

## 12. COMFORT/SENSOR button:

 COMFORT AIRFLOW and INTELLIGENT EYE operation

## 13. WEEKLY/PROGRAM/COPY/BACK/NEXT button:

WEEKLY TIMER operation

## 14. SELECT button:

 It changes the ON/OFF TIMER and WEEKLY TIMER settings.

#### 15. OFF TIMER button

#### 16. ON TIMER button

#### 17. TIMER CANCEL button:


- It cancels the timer setting.
- It cannot be used for the WEEKLY TIMER operation.

#### 18. CLOCK button


## FVXS25/35/50FV1B

# Names of parts

## **■** Indoor Unit



## ■ Opening the Front Panel



## **⚠** CAUTION

Before opening the front panel, be sure to stop the operation and turn the breaker OFF. Do not touch the metal parts on the inside of the indoor unit, as it may result in injury.

## **■ Indoor Unit -**

- 1. Titanium Apatite Photocatalytic Air-Purifying Filter:
  - These filters are attached to the inside of the air filters.
- 2. Air outlet
- 3. Display
- 4. Front panel
- 5. Vertical blades (louvers)
  - The louvers are inside of the air outlet.
- 6. Air inlet
- 7. Air filter
- 8. Horizontal blade (flap)
- 9. Operation lamp (green)
- 10. TIMER lamp (yellow)
- 11. Indoor Unit ON/OFF switch:
  - Push this switch once to start operation. Push once again to stop it.

• The operation mode refers to the following table.

Model	Mode	Temperature setting	Airflow rate
COOLING ONLY	COOL	22°C	AUTO
HEAT PUMP	AUTO	25°C	AUTO

• This switch is useful when the remote controller is missing.

## 12. Signal receiver:


- It receives signals from the remote controller.
- When the unit receives a signal, you will hear a short beep.
  - Operation start ...... beep-beep
  - Settings changed ..... beep
  - Operation stop..... beeeeep

#### 13. Air outlet selection switch

#### 14. Room temperature sensor:

• It senses the air temperature around the unit.

## **■** Remote Controller



<ARC452A1>

## 1. Signal transmitter:

• It sends signals to the indoor unit.

## 2. Display:

It displays the current settings.
 (In this illustration, each section is shown with all its displays ON for the purpose of explanation.)

#### 3. FAN setting button:

· It selects the airflow rate setting.

#### 4. POWERFUL button:

POWERFUL operation

#### 5. ON/OFF button:

Press this button once to start operation.
 Press once again to stop it.

## 6. TEMPERATURE adjustment buttons:


• It changes the temperature setting.

### 7. MODE selector button:

 It selects the operation mode. (AUTO/DRY/COOL/HEAT/FAN)

## 8. QUIET button:

**OUTDOOR UNIT QUIET operation** 



#### 9. ECONO button:

**ECONO** operation

## 10. SWING button:

Adjusting the Airflow Direction

## 11. WEEKLY/PROGRAM/COPY/BACK/NEXT button:

WEEKLY TIMER operation

#### 12. SELECT button:

 It changes the ON/OFF TIMER and WEEKLY TIMER settings.

## 13. OFF TIMER button

14. ON TIMER button

## 15. TIMER CANCEL button:

- · It cancels the timer setting.
- It cannot be used for the WEEKLY TIMER operation.

#### 16. CLOCK button

## 2.2.3 AUTO · DRY · COOL · HEAT · FAN Operation


# **AUTO · DRY · COOL · HEAT · FAN Operation**

The air conditioner operates with the operation mode of your choice

From the next time on, the air conditioner will operate with the same operation mode.

## ■ To start operation

- 1. Press MODE and select a operation mode.
  - Each pressing of the button advances the mode setting in sequence.



Ф0N/0FF

- 2. Press o .
  - "ON" is displayed on the LCD.
  - The OPERATION lamp lights up.



## ■ To stop operation


**ФОN/OFF** 

- 3. Press again.
  - "ON" disappears from the LCD.
  - Then OPERATION lamp goes off.

## ■ To change the temperature setting

4. Press ♠ or ▼.

AUTO or COOL or HEAT operation	·	DRY or FAN operation
Press ▲ raise the temperature and press ▼ lower the temperature.		
Set to the temperature you like.		The temperature setting is not variable.



## ■ To change the airflow rate setting

## 5. Press



AUTO or COOL or HEAT or FAN operation	DRY operation
5 levels of airflow rate setting from "\$\overline{A}\$" plus "\$\overline{A}\$" are available.	The airflow rate setting is not variable.

· Indoor unit quiet operation

When the airflow is set to "\_\_\_\_\_", the noise from the indoor unit will become quieter. Use this when making the noise quieter.

## NOTE

## ■ Notes on HEAT operation

- Since this air conditioner heats the room by taking heat from outdoor air to indoors, the
  heating capacity becomes smaller in lower outdoor temperatures. If the heating effect is
  insufficient, it is recommended to use another heating appliance in combination with the
  air conditioner.
- The heat pump system heats the room by circulating hot air around all parts of the room.

  After the start of heating operation, it takes some time before the room gets warmer.
- In heating operation, frost may occur on the outdoor unit and lower the heating capacity. In that case, the system switches into defrosting operation to take away the frost.
- During defrosting operation, hot air does not flow out of indoor unit.
- A pinging sound may be heard during defrosting operation, which, however does not mean that the air conditioner has failures.

#### ■ Note on COOL operation

• This air conditioner cools the room by releasing the heat in the room outside.

Therefore, the cooling performance of the air conditioner may be degraded if the outdoor temperature is high.

## ■ Note on DRY operation

 The computer chip works to rid the room of humidity while maintaining the temperature as much as possible. It automatically controls temperature and airflow rate, so manual adjustment of these functions is unavailable.

#### ■ Notes on AUTO operation

- In AUTO operation, the system selects an appropriate operation mode (COOL or HEAT) based on the room and outside temperatures and starts the operation.
- The system automatically reselects setting at a regular interval to bring the room temperature to user-setting level.

#### ■ Note on FAN operation

This mode is valid for fan only.

## ■ Note on airflow rate setting

At smaller airflow rates, the cooling (heating) effect is also smaller.

## 2.2.4 Adjusting the Airflow Direction

## FTXS20/25/35/42/50J2V1B

# **Adjusting the Airflow Direction**

You can adjust the airflow direction to increase your comfort.

## ■ To start auto swing

## **Upper and lower airflow direction**

Press ()

- "() is displayed on the LCD.
- The flaps (horizontal blades) will begin to swing.

## Right and left airflow direction

Press


- "#" is displayed on the LCD.
- The louvers (vertical blades) will begin to swing.

## The 3-D airflow direction


Press () and

- "() and " are displayed on the LCD.
- The flaps and louvers move in turn.
- To cancel 3-D airflow, press either or or


The flaps or louvers will stop moving.



• The following illustrations show respective airflow directions.







## ■ To set the flaps or louvers at desired position

• This function is effective while flaps or louvers are in auto swing mode.

Press and when the flaps or louvers have reached the desired position.

- In the 3-D airflow, the flaps and louvers move in turn.
- "(\*)" or "@" " disappears from the LCD.

## **CAUTION**

- Always use a remote controller to adjust the angles of the flaps and louvers. If you attempt to
  move the flaps and louvers forcibly with hand when they are swinging, the mechanism may
  be broken.
- Always use a remote controller to adjust the louvers angles. In side the air outlet, a fan is rotating at a high speed.


## **NOTE**

## ■ Note on the angles of the flaps

• The flaps swinging range depends on the operation. (See the figure.)

## ■ Note on 3-D airflow

 Using 3-D airflow circulates cold air, which tends to collected at the bottom of the room, and hot air, which tends to collect near the ceiling, throughout the room, preventing are as of cold and hot developing.



## FTXS60/71GV1B

# **Adjusting the Airflow Direction**

You can adjust the airflow direction to increase your comfort.

## ■ To start auto swing

## Upper and lower airflow direction

Press ()

- "() is displayed on the LCD.
- The flaps (horizontal blades) will begin to swing.

## Right and left airflow direction

Press .


- "@"" is displayed on the LCD.
- The louvers (vertical blades) will begin to swing.

## The 3-D airflow direction




- "(\*)" and "(\*)" are displayed on the LCD.
- The flaps and louvers move in turn.
- To cancel 3-D airflow, press either or again.


The flaps or louvers will stop moving.



• The following illustrations show respective airflow directions.







192

## ■ To set the flaps or louvers at desired position

• This function is effective while flaps or louvers are in auto swing mode.

Press and when the flaps or louvers have reached the desired position.

- In the 3-D airflow, the flaps and louvers move in turn.
- "() or " disappears from the LCD.

## **A** CAUTION

- Always use a remote controller to adjust the angles of the flaps and louvers. If you attempt to move it forcibly with hand when it is swinging, the mechanism may be broken.
- Always use a remote controller to adjust the louvers angles. In side the air outlet, a fan is rotating at a high speed.


## NOTE

## ■ Note on the angles of the flaps

• The flaps swinging range depends on the operation. (See the figure.)

## ■ Note on 3-D airflow

 Using 3-D airflow circulates cold air, which tends to collected at the bottom of the room, and hot air, which tends to collect near the ceiling, throughout the room, preventing areas of cold and hot developing.




#### FVXS25/35/50FV1B

# **Adjusting the Airflow Direction**

You can adjust the airflow direction to increase your comfort.

## To adjust the horizontal blade (flap)

- 1. Press "SWING button <=""."
  - "(=" is displayed on the LCD and the flaps will begin to swing.
- 2. When the flap has reached the desired position, press "SWING button(♠ " once more.
  - The flap will stop moving.
  - "() " disappears from the LCD.



# ■ To adjust the vertical blades (louvers)

Hold the knob and move the louver. (You will find a knob on the left-side and the right-side blades.)




## Notes on flap and louvers angle

 Unless "SWING" is selected, you should set the flap at a near-horizontal angle in HEAT mode and at a upward position in COOL or DRY mode to obtain the best performance.

#### **■ ATTENTION**

- When adjusting the flap by hand, turn off the unit, and use the remote controller to restart the unit.
- Be careful when adjusting the louvers. Inside the air outlet, a fan is rotating at a high speed.



194

## ■ Airflow selection

• Make airflow selection according to what suits you.

## When setting the airflow selection switch to .....

• Air conditioner automatically decides the appropriate blowing pattern depending on the operating mode/situation.

Operating mode	Situation	Blowing pattern
COOL mode	When the room has become fully cool, or when one hour has passed since turning on the air conditioner.	So that air does not come into direct contact with people, air is blown upper air outlet, room temperature is equalized.
	At start of operation or other times when the room is not fully cooled.	
	At times other than below. (Normal time.)	
HEAT mode		<ul> <li>Air is blown from the upper and lower air outlets for high speed cooling during COOL mode, and for filling the room with warm air during HEAT mode.</li> </ul>
	At start or when air temperature is low.	So that air does not come into direct contact with people. Air is blown upper air outlet.

<sup>•</sup> During Dry mode, so that cold air does not come into direct contact with people, air is blown upper air outlet.

## When setting the air outlet selection switch to \u00e4n.

- Regardless of the operating mode or situation, air blows from the upper air outlet.
- Use this switch when you do not want air coming out of the lower air outlet. (While sleeping etc.)

## **⚠** CAUTION

- Do not try to adjust the flap by hand.
- When adjusting by hand, the mechanism may not operate properly or condensation may drip from air outlets.

## 2.2.5 COMFORT AIRFLOW and INTELLIGENT EYE Operation


FTXS20/25/35/42/50J2V1B

# COMFORT AIRFLOW and INTELLIGENT EYE Operation

## **■ COMFORT AIRFLOW operation**

The flow of air will be in the upward direction while in COOL operation and in the downward direction while in HEAT operation, which will provide a comfortable wind that will not come in direct contact with people.






## ■ INTELLIGENT EYE operation


"INTELLIGENT EYE" is the infrared sensor which detects the human movement. If no one is in the room for more than 20 minutes, the operation automatically changes to energy saving operation.

The INTELLIGENT EYE sensor according to the following situations.

#### ■ A person is detected in area 1.




## ■ People are detected in both areas.




Use the INTELLIGENT EYE Operation in combination with the COMFORT AIRFLOW Operation.

#### ■ A person is detected in area 2.



## ■ No people are detected in the areas.



The air conditioner will go into energy-saving mode after 20 minutes.

\*The wind direction may differ from the illustrated direction depending on the actions and movements of the people in the areas.

## ■ To start operation

Press (\*\*) and select the desired mode.

- Each time the **(R/R)** is pressed a different setting option is displayed on the LCD.




- When the flaps (horizontal blades) are swinging, the operating as above will stop movement of them.
- The INTELLIGENT EYE lamp lights up.
- The lamp will be lit while human movements are detected.



## ■ To cancel operation

Press and select "blank" on the LCD.



Display	Operation mode	Explanation
*	COMFORT AIRFLOW	The flaps will adjust the airflow direction upward while cooling, and adjust the airflow direction downward while heating.
<b>₽</b> n	INTELLIGENT EYE	The sensors will detect the movement of people in the sensing areas and the louvers will adjust the airflow direction to an area where people are not present. When there are no people in the sensing areas, the air conditioner will go into energy-saving mode.
<b>A</b> · <b>*</b>	COMFORT AIRFLOW and INTELLIGENT EYE	The air conditioner will be in COMFORT AIRFLOW operation combined with INTELLIGENT EYE operation.
Blank	No function	-

# COMFORT AIRFLOW and INTELLIGENT EYE Operation


## NOTE

#### ■ Notes on COMFORT AIRFLOW operation

- The flap position will change, preventing air from blowing directly on the occupants of the room.
- POWERFUL operation and COMFORT AIRFLOW operation cannot be used at the same time
- Priority is given to the function of whichever button is pressed last.
- The airflow rate will be set to AUTO. If the upper and lower airflow direction is selected, the COMFORT AIRFLOW operation will be canceled.

## ■ Notes on INTELLIGENT EYE operation

· Application range is as follows.



- While the air conditioner is in INTELLIGENT EYE operation, the louvers will adjust the airflow direction if there are people in the sensing areas of the INTELLIGENT EYE so that the leftward or rightward airflow will not be directed to the people.
- If no people are detected in either area 1 or 2 in 20 minutes, the air conditioner will go into energy-saving mode with the set temperature shifted by 2°C.
- The air conditioner may go into energy-saving operation even if there are people in the areas. This may occur depending on the clothes the people are wearing if there are no movements of the people in the areas.
- The airflow direction from the louvers will be leftward if there are people in both areas 1 and 2 or if there is a person right in front of the sensors because the sensors on the both sides will detect the person.
- Due to the position of the sensor, people might be exposed to the airflow of the indoor unit if they are close to the front side of the indoor unit.
- If there are people close to the front side of the indoor unit or in both areas, it is recommended to use the COMFORT AIRFLOW and INTELLIGENT EYE functions simultaneously. When both of them are in use, the air conditioner will not direct the airflow towards the people.
- Sensor may not detect moving objects further than 7m away. (Check the application range)
- Sensor detection sensitivity changes according to indoor unit location, the speed of passersby, temperature range, etc.
- The sensor also mistakenly detects pets, sunlight, fluttering curtains and light reflected off of mirrors as passersby.
- INTELLIGENT EYE operation will not go on during POWERFUL operation.
- NIGHT SET mode will not go on during use of INTELLIGENT EYE operation.

## **NOTE**

# ■ Note on combination of COMFORT AIRFLOW operation and INTELLIGENT EYE operation

- The airflow rate will be set to AUTO. If the upper and lower airflow direction is selected, the COMFORT AIRFLOW operation will be canceled.
  - Priority is given to the function of whichever button is pressed last.
- The air conditioner can go into operation with the COMFORT AIRFLOW and INTELLIGENT EYE functions combined.

The flaps adjust the airflow direction upward (while in cooling operation) and downward (while in heating operation), during which the sensors of the INTELLIGENT EYE are working to detect the movement of people. When the sensors detect people, the louvers will direct the airflow in such way that it will not be blown directly on them. If there are no people, the air conditioner will go into energy-saving operation after 20 minutes.

## INTELLIGENT EYE operation is useful for energy saving

- Energy saving operation
  - If no presence detected in the room for 20 minutes, the energy saving operation will start.
  - This operation changes the temperature –2°C in HEAT / +2°C in COOL / +2°C in DRY operation from set temperature.
  - This operation decreases the airflow rate slightly in FAN operation only.

## **⚠** CAUTION

- Do not place large objects near the sensor.
   Also keep heating units or humidifiers outside the sensor's detection area. This sensor can detect undesirable objects.
- Do not hit or violently push the INTELLIGENT EYE sensor. This can lead to damage and malfunction.

#### FTXS60/71GV1B


# COMFORT AIRFLOW and INTELLIGENT EYE Operation

## **■ COMFORT AIRFLOW operation**

The flow of air will be in the upward direction while in COOL operation and in the downward direction while in HEAT operation, which will provide a comfortable wind that will not come in direct contact with people.








**HEAT** operation

## ■ INTELLIGENT EYE operation

"INTELLIGENT EYE" is the infrared sensor which detects the human movement. If nobody in the room for more than 20 minutes, the operation automatically changes to energy saving operation.


## [Example]



# When somebody in the room


#### ■ Normal operation

- The air conditioner is in normal operation while the sensor is detecting the movement of people.
- The INTELLIGENT EYE lamp lights up.



When nobody in the room

- 20 minutes after, start energy saving operation.
  - The set temperature is shifted in ±2°C steps.
- The INTELLIGENT EYE lamp is goes off.



## Somebody back in the room

# Back to normal operation.

- The air conditioner will return to normal operation when the sensor detects the movement of people again.
- The INTELLIGENT EYE lamp lights up again.

# ■ To combine COMFORT AIRFLOW and INTELLIGENT EYE operation

The air conditioner can go into operation with the COMFORT AIRFLOW and INTELLIGENT EYE operation combined.

## ■ To start operation

Press (\*\*) and select the desired mode.

- Each time the **(R)/R** is pressed a different setting option is displayed on the LCD.




- When the flaps (horizontal blades) are swinging, the operating as above will stop movement of them.
- The INTELLIGENT EYE lamp lights up.
- The lamp will be lit while human movements are detected.



## ■ To cancel operation

Press and select "blank" on the LCD.



## INTELLIGENT EYE operation is useful for energy saving

- **■** Energy saving operation
  - If no presence detected in the room for 20 minutes, the energy saving operation will start.
  - This operation changes the temperature –2°C in HEAT / +2°C in COOL / +2°C in DRY operation from set temperature.
  - This operation decreases the airflow rate slightly in FAN operation only.

# COMFORT AIRFLOW and INTELLIGENT EYE Operation


## NOTE

#### ■ Notes on COMFORT AIRFLOW operation

- The flap position will change, preventing air from blowing directly on the occupants of the room
- POWERFUL operation and COMFORT AIRFLOW operation cannot be used at the same time.
  - Priority is given to the function of whichever button is pressed last.
- The airflow rate will be set to AUTO. If the upper and lower airflow direction is selected, the COMFORT AIRFLOW operation will be canceled.

#### ■ Notes on INTELLIGENT EYE operation

· Application range is as follows.



- Sensor may not detect moving objects further than 7m away. (Check the application range)
- Sensor detection sensitivity changes according to indoor unit location, the speed of passersby, temperature range, etc.
- The sensor also mistakenly detects pets, sunlight, fluttering curtains and light reflected off of mirrors as passersby.
- INTELLIGENT EYE operation will not go on during POWERFUL operation.
- NIGHT SET mode will not go on during use of INTELLIGENT EYE operation.

## Note on combination of COMFORT AIRFLOW operation and INTELLIGENT EYE operation

- The airflow rate will be set to AUTO. If the upper and lower airflow direction is selected, the COMFORT AIRFLOW operation will be canceled.
  - Priority is given to the function of whichever button is pressed last.

## **A** CAUTION

- Do not place large objects near the sensor.
  - Also keep heating units or humidifiers outside the sensor's detection area. This sensor can detect undesirable objects.
- Do not hit or violently push the INTELLIGENT EYE sensor. This can lead to damage and malfunction.

## 2.2.6 POWERFUL Operation

# **POWERFUL Operation**


POWERFUL operation quickly maximizes the cooling (heating) effect in any operation mode. You can get the maximum capacity.

## ■ To start POWERFUL operation

- 1. Press
  - POWERFUL operation ends in 20 minutes. Then the system automatically operates again with the previous settings which were used before POWERFUL operation.
  - " " is displayed on the LCD.

## **■** To cancel POWERFUL operation

- 2. Press 🗳 again.
  - " disappears from the LCD.



## **NOTE**

## ■ Notes on POWERFUL operation

- When using POWERFUL operation, there are some functions which are not available.
- POWERFUL operation cannot be used together with ECONO, COMFORT AIRFLOW or OUTDOOR UNIT QUIET operation. Priority is given to the function of whichever button is pressed last.
- POWERFUL operation can only be set when the unit is running.
- POWERFUL operation will not increase the capacity of the air conditioner if the air conditioner is already in operation with its maximum capacity demonstrated.

#### • In COOL, HEAT and AUTO mode

To maximize the cooling (heating) effect, the capacity of outdoor unit is increased and the airflow rate is fixed to the maximum setting.

The temperature and airflow settings are not variable.

• In DRY operation

The temperature setting is lowered by 2.5°C and the airflow rate is slightly increased.

• In FAN operation

The airflow rate is fixed to the maximum setting.

## 2.2.7 OUTDOOR UNIT QUIET Operation

# **OUTDOOR UNIT QUIET Operation**


OUTDOOR UNIT QUIET operation lowers the noise level of the outdoor unit by changing the frequency and fan speed on the outdoor unit. This function is convenient during night.

# ■ To start OUTDOOR UNIT QUIET operation

- 1. Press 🏻 🏠
  - " \( \)" is displayed on the LCD.

# ■ To cancel OUTDOOR UNIT QUIET operation

- 2. Press again.
  - " disappears from the LCD.



## NOTE

### ■ Notes on OUTDOOR UNIT QUIET operation

- If using a multi system, the OUTDOOR UNIT QUIET operation will work only when this function is set on all operated indoor units.
- This function is available in COOL, HEAT, and AUTO operation. (This is not available in FAN and DRY operation.)
- POWERFUL operation and OUTDOOR UNIT QUIET operation cannot be used at the same time.
  - Priority is given to the function of whichever button is pressed last.
- Even the operation is stopped using the remote controller or the indoor unit ON/OFF switch when using OUTDOOR UNIT QUIET operation, "m" will remain on the remote controller display.
- OUTDOOR UNIT QUIET operation will drop neither the frequency nor fan speed if the frequency and fan speed have been already dropped low enough.

## 2.2.8 ECONO Operation

# **ECONO Operation**

ECONO operation is a function which enables efficient operation by limiting the maximum power consumption value.


This function is useful for cases in which attention should be paid to ensure a circuit breaker will not trip when the product runs alongside other appliances.


## ■ To start ECONO operation

- 1. Press ▼ECONO .
  - " T " is displayed on the LCD.

# ■ To cancel ECONO operation

- 2. Press \(\sum\_{\text{ECONO}}\) again.
  - " T " disappears from the LCD.





- This diagram is a representation for illustrative purposes only.
- \* The maximum running current and power consumption of the air conditioner in ECONO operation vary with the connecting outdoor unit.

## **NOTE**

## ■ Notes on ECONO operation

- ECONO operation can only be set when the unit is running.
- ECONO operation is a function which enables efficient operation by limiting the power consumption of the outdoor unit (operating frequency).
- ECONO operation functions in AUTO, COOL, DRY and HEAT operation.
- POWERFUL and ECONO operation cannot be used at the same time.
   Priority is given to the function of whichever button is pressed last.
- If the level of power consumption is already low, ECONO operation will not drop the power consumption.

## 2.2.9 OFF TIMER Operation

# **OFF TIMER Operation**

Timer functions are useful for automatically switching the air conditioner on or off at night or in the morning. You can also use OFF TIMER and ON TIMER in combination.

## ■ To use OFF TIMER operation

- Check that the clock is correct.

  If not, set the clock to the present time.
- 1. Press OFF .
  - "OFF" and setting time are displayed on the LCD.
  - "[]:[[][] " is displayed on the LCD.
  - "OFF" blinks.
- 2. Press until the time setting reaches

## the point you like.

- Each pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.
- 3. Press OFF again.
  - The TIMER lamp lights up.



# ■ To cancel the OFF TIMER Operation

- 4. Press CANCEL .
  - "OFF" and setting time disappear from the LCD.
  - "(4)" and day of the week are displayed on the LCD.
  - The TIMER lamp goes off.


## NOTE

## ■ Notes on TIMER operation

- When TIMER is set, the present time is not displayed.
- Once you set ON/OFF TIMER, the time setting is kept in the memory. The memory is canceled when remote controller batteries are replaced.
- When operating the unit via the ON/OFF TIMER, the actual length of operation may vary from the time entered by the user. (Maximum approx. 10 minutes)

## ■ NIGHT SET mode

When the OFF TIMER is set, the air conditioner automatically adjusts the temperature setting (0.5°C up in COOL, 2.0°C down in HEAT) to prevent excessive cooling (heating) for your pleasant sleep.



## 2.2.10 ON TIMER Operation

# **ON TIMER Operation**

# ■ To use ON TIMER operation

- Check that the clock is correct. If not, set the clock to the present time.
- 1. Press ON .
  - "ON" and setting time are displayed on the LCD.
  - "**§:[][**]" is displayed on the LCD.
  - "ON" blinks.
- 2. Press until the time setting reaches

the point you like.

- Each pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.
- 3. Press ON again.
  - The TIMER lamp lights up.




# ■ To cancel ON TIMER operation

- 4. Press CANCEL .
  - "ON" and setting time disappear from the LCD.
  - "4" and day of the week are displayed on the LCD.
  - The TIMER lamp goes off.


## ■ To combine ON TIMER and OFF TIMER

• A sample setting for combining the 2 timers is shown below.



## NOTE

- In the following cases, set the timer again.
  - After a breaker has turned off.
  - After a power failure.
  - After replacing batteries in the remote controller.



## 2.2.11 WEEKLY TIMER Operation


# **WEEKLY TIMER Operation**

Up to 4 timer settings can be saved for each day of the week. It is convenient if the WEEKLY TIMER is set according to the family's life style.

## ■ Using in these cases of WEEKLY TIMER

An example of WEEKLY TIMER settings is shown below.

**Example:** The same timer settings are made for the week from Monday through Friday while different timer settings are made for the weekend.




- Up to 4 reservations per day and 28 reservations per week can be set in the WEEKLY TIMER. The effective use of the copy mode ensures ease of making reservations.
- The use of ON-ON-ON settings, for example, makes it possible to schedule operating mode and set temperature changes. Furthermore, by using OFF-OFF-OFF settings, only the turn-off time of each day can be set. This will turn off the air conditioner automatically if the user forgets to turn it off.

# **WEEKLY TIMER Operation**

# ■ To use WEEKLY TIMER operation

## **Setting mode**

 Make sure the day of the week and time are set. If not, set the day of the week and time.




- 1. Press 🔷 .
  - The day of the week and the reservation number of the current day will be displayed.
  - 1 to 4 settings can be made per day.
- 2. Press to select the desired day of the week and reservation number.
  - Pressing the changes the reservation number and the day of the week.
- 3. Press NEXT.
  - The day of the week and reservation number will be set.
  - " WEEKLY " and " N" blink.
- 4. Press to select the desired mode.





- In case the reservation has already been set, selecting "blank" deletes the reservation.
- Go to step 9 if "blank" is selected.
- 5. Press NEXT
  - The ON/OFF TIMER mode will be set.
  - " WEEKLY " and the time blink.



# 6. Press steet the desired time.

- The time can be set between 0:00 and 23:50 in 10 minute intervals.
- To return to the ON/OFF TIMER mode setting, press
- Go to step 9 when setting the OFF TIMER.

## 7. Press NEXT

BACK .

- The time will be set.
- " WEEKLY " and the temperature blink.

# 8. Press select the desired

## temperature.

The temperature can be set between 10°C and 32°C.
 Cooling: The unit operates at 18°C even if it is set at 10 to 17°C.

Heating: The unit operates at 30°C even if it is set at 31 to 32°C.

- To return to the time setting, press BACK .
- The set temperature is only displayed when the mode setting is on.


# 9. Press NEXT.

- The temperature will be set and go to the next reservation setting.
- To continue further settings, repeat the procedure from step 4.


## 10. Press 💮 to complete the setting.

- Be sure to direct the remote controller toward the indoor unit and check for a receiving tone and flashing the OPERATION lamp.
- " WEEKLY " is displayed on the LCD and WEEKLY TIMER operation is activated.
- The TIMER lamp lights up.
- A reservation made once can be easily copied and the same settings used for another day of the week.

Refer to copy mode.



# **WEEKLY TIMER Operation**



## **NOTE**

## ■ Notes on WEEKLY TIMER operation


- Do not forget to set the clock on the remote control first.
- The day of the week, ON/OFF TIMER mode, time and set temperature (only for ON TIMER mode) can be set with WEEKLY TIMER. Other settings for ON TIMER are based on the settings just before the operation.
- Both WEEKLY TIMER and ON/OFF TIMER operation cannot be used at the same time.
  The ON/OFF TIMER operation has priority if it is set while WEEKLY TIMER is still active.
  The WEEKLY TIMER will go into standby state, and "WEEKLY" will disappear from the LCD.

When ON/OFF TIMER is up, the WEEKLY TIMER will automatically become active.


- Only the time and set temperature with the weekly timer are sent with the Set the weekly timer only after setting the operation mode, the fan strength, and the fan direction ahead of time.
- Shutting the breaker off, power failure, and other similar events will render operation of the indoor unit's internal clock inaccurate. Reset the clock.
- The BACK can be used only for the time and temperature settings. It cannot be used to go back to the reservation number.

## Copy mode

 A reservation made once can be copied another day of the week. The whole reservation of the selected day of the week will be copied.



- 1. Press 🔷
- 2. Press to confirm the day of the week to be copied.
- 3. Press COPY to activate copy mode.
  - The whole reservation of the selected day of the week will be copied.
- 4. Press to select the destination day of the week.




# **WEEKLY TIMER Operation**


## 5. Press COPY.

- The reservation will be copied to the selected day of the week. The whole reservation of the selected day of the week will be copied.
- To continue copying the settings to other days of the week, repeat step 4 and step 5.

## 6. Press 💮 to complete the setting.

• " WEEKLY" is displayed on the LCD and WEEKLY TIMER operation is activated.





## **NOTE**

## ■ Note on COPY MODE

• The entire reservation of the source day of the week is copied in the copy mode. In the case of making a reservation change for any day of the week individually after copying the content of weekly reservations, press and change the settings in the steps of setting mode.

# ■ Confirming a reservation

• The reservation can be confirmed.

## 1. Press 💮


• The day of the week and the reservation number of current day will be displayed.


# 2. Press to select the day of the week and the reservation number to be confirmed.

- Pressing the steet displays the reservation details.
- To change the confirmed reserved settings, select the reservation number and press NEXT.
   The mode is switched to setting mode. Go to setting mode step 4.

## 3. Press 💮 to exit confirming mode.

- " WEEKLY" is displayed on the LCD and WEEKLY TIMER operation is activated.
- The TIMER lamp lights up.





# ■ To deactivate WEEKLY TIMER operation

- 4. Press WEEKLY while " WEEKLY " is displayed on the LCD.
  - " WEEKLY " disappears from the LCD.
  - The TIMER lamp goes off.
  - To reactivate the WEEKLY TIMER operation, press the WEEKLY again.
  - If a reservation deactivated with WEEKLY is activated once again, the last reservation mode will be used.

# **WEEKLY TIMER Operation**

## ■ To delete reservations

## The individual reservation

• Refer to setting mode.

When selecting desired mode at step 4 in setting mode, select "blank". The reservation will be deleted.

## The reservations for each day of the week


- This function can be used for deleting reservations for each day of the week.
- It can be used while confirming or setting reservations.
- 5. Press 🔷 .
- 6. Select the day of the week to be canceled



- 7. Hold WEEKLY for 5 seconds.
  - The reservation of the selected day of the week will be deleted.

## All reservations

- 8. Hold WEEKLY for 5 seconds while normal display.
  - Be sure to direct the remote control toward the main unit and check for a receiving tone.
  - This operation is not effective on the setting display of WEEKLY TIMER.
  - · All reservations will be deleted.



## 2.2.12 Note for Multi System

# **Note for Multi System**

This system has one outdoor unit connected to multiple indoor units.


## ■ Selecting the operation mode

# 1. With the priority room setting present but inactive or not present.

When more than 1 indoor unit is operating, priority is given to the first unit that was turned on.

In this case, set the units that are turned on later to the same operation mode as the first unit.

Otherwise, they will enter the standby state, and the OPERATION lamp will flash: this does not indicate malfunction.



## NOTE

## ■ Notes on operation mode for multi system

- COOL, DRY and FAN operation may be used at the same time.
- AUTO operation automatically selects COOL operation or HEAT operation based on the room temperature.

Therefore, AUTO operation is available when selecting the same operation mode as that of the room with the first unit to be turned on.

# **⚠** CAUTION

 Normally, the operation mode in the room where the unit is first run is given priority, but the following situations are exceptions, so please keep this in mind.
 If the operation mode of the first room is FAN operation, then using HEAT operation in any

If the operation mode of the first room is FAN operation, then using HEAT operation in any room after this will give priority to HEAT operation. In this situation, the air conditioner running in FAN operation will go on standby, and the OPERATION lamp will flash.

## 2. With the priority room setting active.

See "Priority room setting" on the next page.

# ■ NIGHT QUIET mode (Available only for COOL operation)

NIGHT QUIET mode requires initial programming during installation. Please consult your retailer or dealer for assistance.

NIGHT QUIET mode reduces the operation noise of the outdoor unit during the night time hours to prevent annoyance to neighbors.

- The NIGHT QUIET mode is activated when the temperature drops 5°C or more below the highest temperature recorded that day. Therefore, when the temperature difference is less than 5°C, this function will not be activated.
- NIGHT QUIET mode reduces slightly the cooling efficiency of the unit.

# **Note for Multi System**

# ■ OUTDOOR UNIT QUIET operation

## 1. With the priority room setting present but inactive or not present.

When using the OUTDOOR UNIT QUIET operation feature with the Multi system, set all indoor units to OUTDOOR UNIT QUIET operation using their remote controllers.

When clearing OUTDOOR UNIT QUIET operation, clear one of the operating indoor units using their remote controller. However OUTDOOR UNIT QUIET operation display remains on the remote controller for other rooms. We recommend you release all rooms using their remote controllers.

## 2. With the priority room setting active.

See "Priority room setting".

# ■ COOL/HEAT mode lock (Available only for heat pump models)

The COOL/HEAT mode lock requires initial programming during installation. Please consult your authorized dealer for assistance. The COOL/HEAT mode lock sets the unit forcibly to either COOL or HEAT operation. This function is convenient when you wish to set all indoor units connected to the multi system to the same operation mode.

## NOTE

• The COOL/HEAT mode lock cannot be activated together with the priority room setting.

## ■ Priority room setting

The priority room setting requires initial programming during installation. Please consult your retailer or dealer for assistance. The room designated as the priority room takes priority in the following situations;

## 1. Operation mode priority.

As the operation mode of the priority room takes precedence, the user can select a different operation mode from other rooms.

\* Room A is the priority room in the examples.

When COOL operation is selected in room A while operating the following modes in room B, C and D:

•	1 0 0
Operation mode in	Status of room B, C and D when the unit
room B, C and D	in room A is in COOL operation
COOL or DRY or FAN	Current operation mode maintained
HEAT	The unit enters standby mode. Operation resumes when the room A unit stops operating.
AUTO	If the unit is set to COOL operation, it continues. If set to HEAT operation, it enters standby mode. Operation resumes when the room A unit stops operating.

## 2. Priority when POWERFUL operation is used.

\* Room A is the priority room in the examples. ⟨Example⟩

The indoor units in rooms A, B, C and D are all operating. If the unit in room A enters POWERFUL operation, operation capacity will be concentrated in room A. In such a case, the cooling (heating) efficiency of the units in rooms B, C and D may be slightly reduced.

## 3. Priority when using OUTDOOR UNIT QUIET operation.

\* Room A is the priority room in the examples. ⟨Example⟩

Just by setting the unit in room A to QUIET operation, the air conditioner starts OUTDOOR UNIT QUIET operation. You don't have to set all the operated indoor units to QUIET operation.

# 2.3 FLXS, FDXS Series - ARC433B67, B69

# 2.3.1 Manual Contents and Reference Page


	Floor / Ceiling Suspended Dual Type	Duct Connected Type
Model Series	FLXS25-60BAVMB	FDXS25/35E7VMB FDXS50/60C7VMB
Read Before Operation		
Remote Controller	219	220
Operation		
AUTO · DRY · COOL · HEAT · FAN Operation ★	221	221
Adjusting the Airflow Direction	223	_
POWERFUL Operation ★	225	225
OUTDOOR UNIT QUIET Operation ★	226	226
HOME LEAVE Operation ★	227	227
TIMER Operation ★	229	229
Note for Multi System	231	231
Drawing No.	3P194444-5C	3P196326-9C (Reference)

 $<sup>\</sup>bigstar :$  The illustrations are for FLXS series as representative.

## 2.3.2 Remote Controller

## FLXS25/35/50/60BAVMB

## **■** Remote Controller



## 1. Signal transmitter:

• It sends signals to the indoor unit.

## 2. Display:

 It displays the current settings.
 (In this illustration, each section is shown with all its displays ON for the purpose of explanation.)

## 3. HOME LEAVE button:

**HOME LEAVE** operation

## 4. POWERFUL button:

POWERFUL operation

## 5. TEMPERATURE adjustment buttons:

• It changes the temperature setting.

## 6. ON/OFF button:

Press this button once to start operation.
 Press once again to stop it.

## 7. MODE selector button:

- It selects the operation mode. (AUTO/DRY/COOL/HEAT/FAN)
- **8. QUIET button:** OUTDOOR UNIT QUIET operation

## 9. FAN setting button:

• It selects the air flow rate setting.

## 10. SWING button

- 11. ON TIMER button
- 12. OFF TIMER button

## 13. TIMER Setting button:

• It changes the time setting.

## 14. TIMER CANCEL button:

• It cancels the timer setting.


## 15. CLOCK button

## 16. RESET button:

- Restart the unit if it freezes.
- Use a thin object to push.

## FDXS25/35E7VMB, FDXS50/60C7VMB

## **■** Remote Controller



## 1. Signal transmitter:

• It sends signals to the indoor unit.

## 2. Display:

 It displays the current settings.
 (In this illustration, each section is shown with all its displays ON for the purpose of explanation.)

## 3. HOME LEAVE button:

**HOME LEAVE** operation

## 4. POWERFUL button:

POWERFUL operation

## 5. TEMPERATURE adjustment buttons:

• It changes the temperature setting.

## 6. ON/OFF button:

Press this button once to start operation.
 Press once again to stop it.

## 7. MODE selector button:

- It selects the operation mode. (AUTO/DRY/COOL/HEAT/FAN)
- **8. QUIET button:** OUTDOOR UNIT QUIET operation

## 9. FAN setting button:

• It selects the air flow rate setting.

## 10. ON TIMER button

- 11. OFF TIMER button
- 12. TIMER Setting button:
  - It changes the time setting.

## 13. TIMER CANCEL button:

• It cancels the timer setting.

## 14. CLOCK button

## 15. RESET button:

- Restart the unit if it freezes.
- Use a thin object to push.

## 2.3.3 AUTO · DRY · COOL · HEAT · FAN Operation

# **AUTO · DRY · COOL · HEAT · FAN Operation**

The air conditioner operates with the operation mode of your choice.

From the next time on, the air conditioner will operate with the same operation mode.

# To start operation

- 1. Press "MODE selector button" and select a operation mode.
  - Each pressing of the button advances the mode setting in sequence.


AUTO


■: DRY

★: COOL

☀: HEAT

😍 : FAN





- 2. Press "ON/OFF button".
  - · The OPERATION lamp lights up.



# ■ To stop operation

- 3. Press "ON/OFF button" again.
  - Then OPERATION lamp goes off.

# ■ To change the temperature setting

4. Press "TEMPERATURE adjustment button".

DRY or FAN mode	AUTO or COOL or HEAT mode
	Press "▲" to raise the temperature and press
	"▼" to lower the temperature.
The temperature setting is not variable.	Set to the temperature you like.

# ■ To change the air flow rate setting

## 5. Press "FAN setting button".

DRY mode	AUTO or COOL or HEAT or FAN mode
The air flow rate setting is not variable.	Five levels of air flow rate setting from " o " to " o" plus " A " are available.

· Indoor unit quiet operation

When the air flow is set to "♣", the noise from the indoor unit will become quieter. Use this when making the noise quieter.

The unit might lose capacity when the air flow rate is set to a weak level.

## **NOTE**

## ■ Note on HEAT operation

- Since this air conditioner heats the room by taking heat from outdoor air to indoors, the
  heating capacity becomes smaller in lower outdoor temperatures. If the heating effect is
  insufficient, it is recommended to use another heating appliance in combination with the air
  conditioner.
- The heat pump system heats the room by circulating hot air around all parts of the room. After the start of heating operation, it takes some time before the room gets warmer.
- In heating operation, frost may occur on the outdoor unit and lower the heating capacity. In that case, the system switches into defrosting operation to take away the frost.
- During defrosting operation, hot air does not flow out of indoor unit.

## ■ Note on COOL operation

• This air conditioner cools the room by blowing the hot air in the room outside, so if the outside temperature is high, performance drops.

## ■ Note on DRY operation

• The computer chip works to rid the room of humidity while maintaining the temperature as much as possible. It automatically controls temperature and fan strength, so manual adjustment of these functions is unavailable.

## ■ Note on AUTO operation

- In AUTO operation, the system selects a temperature setting and an appropriate operation mode (COOL or HEAT) based on the room temperature at the start of the operation.
- The system automatically reselects setting at a regular interval to bring the room temperature to user-setting level.
- If you do not like AUTO operation, you can manually select the operation mode and setting you like.

## Note on air flow rate setting

• At smaller air flow rates, the cooling (heating) effect is also smaller.

## 2.3.4 Adjusting the Airflow Direction


## FLXS25/35/50/60BAVMB

# **Adjusting the Airflow Direction**

You can adjust the air flow direction to increase your comfort.

# ■ To adjust the horizontal blade (flap)

- 1. Press "SWING button".
  - " ( is displayed on the LCD and the flaps will begin to swing.
- 2. When the flaps have reached the desired position, press "SWING button" once more.
  - The flap will stop moving.
  - " ( isappears from the LCD.




# ■ To adjust the vertical blades (louvers)

• When adjusting the louver, use a robust and stable stool and watch your steps carefully.

Hold the knob and move the louvers.

(You will find a knob on the left side and the right side blades.)



## Notes on flap and louvers angles.


- Unless [SWING] is selected, you should set the flap at a near- horizontal angle in COOL or DRY mode to obtain the best performance.
- In COOL or DRY mode, if the flap is fixed at a downward position, the flap automatically moves in about 60 minutes to prevent condensation on it.

## ■ ATTENTION

 Always use a remote controller to adjust the flap angle.

If you attempt to move it forcibly with hand when it is swinging, the mechanism may be broken.

• Be careful when adjusting the louvers. Inside the air outlet, a fan is rotating at a high speed.



## 2.3.5 POWERFUL Operation

# **POWERFUL Operation**

POWERFUL operation quickly maximizes the cooling (heating) effect in any operation mode. You can get the maximum capacity.


# ■ To start POWERFUL operation

## 1. Press "POWERFUL button".

- POWERFUL operation ends in 20 minutes. Then the system automatically operates again with the settings which were used before POWERFUL operation.
- When using POWERFUL operation, there are some functions which are not available.
- " \(\forall^n\)" is displayed on the LCD.

# ■ To cancel POWERFUL operation

- 2. Press "POWERFUL button" again.
  - "⁴ " disappears from the LCD.



## **NOTE**

## ■ Notes on POWERFUL operation

• In COOL and HEAT mode

To maximize the cooling (heating) effect, the capacity of outdoor unit must be increased and the air flow rate be fixed to the maximum setting.

The temperature and air flow settings are not variable.

• In DRY mode

The temperature setting is lowered by 2.5°C and the air flow rate is slightly increased.

• In FAN mode

The air flow rate is fixed to the maximum setting.

## 2.3.6 OUTDOOR UNIT QUIET Operation

# **OUTDOOR UNIT QUIET Operation**


OUTDOOR UNIT QUIET operation lowers the noise level of the outdoor unit by changing the frequency and fan speed on the outdoor unit. This function is convenient during night.

# ■ To start OUTDOOR UNIT QUIET operation

- 1. Press "QUIET button".
  - " @" is displayed on the LCD.

# ■ To cancel OUTDOOR UNIT QUIET operation

- 2. Press "QUIET button" again.
  - " man disappears from the LCD.



## NOTE

## ■ Note on OUTDOOR UNIT QUIET operation

- This function is available in COOL, HEAT, and AUTO modes.
   (This is not available in FAN and DRY mode.)
- POWERFUL operation and OUTDOOR UNIT QUIET operation cannot be used at the same time.
  - Priority is given to the function of whichever button is pressed last.
- If operation is stopped using the remote controller or the main unit ON/OFF switch when using OUTDOOR UNIT QUIET operation, " @" will remain on the remote controller display.

## 2.3.7 HOME LEAVE Operation

# **HOME LEAVE Operation**

HOME LEAVE operation is a function which allows you to record your preferred temperature and air flow rate settings.


# ■ To start HOME LEAVE operation

- 1. Press "HOME LEAVE button".
  - The HOME LEAVE lamp lights up.



# To cancel HOME LEAVE operation

- 2. Press "HOME LEAVE button" again.
  - The HOME LEAVE lamp goes off.



## Before using HOME LEAVE operation.

■ To set the temperature and air flow rate for HOME LEAVE operation

When using HOME LEAVE operation for the first time, please set the temperature and air flow rate for HOME LEAVE operation. Record your preferred temperature and air flow rate.

	Initial setting		Selectable range	
	temperature	Air flow rate	temperature	Air flow rate
Cooling	25°C	" (A) "	18-32°C	5 step, " 🔁 " and " 強 "
Heating	25°C	" (人)"	10-30°C	5 step, " 🔁 " and " 強 "

- 1. Press "HOME LEAVE button". Make sure " a" is displayed in the remote controller display.
- 2. Adjust the set temperature with " ▲ " or " ▼ " as you like.
- 3. Adjust the air flow rate with "FAN" setting button as you like.

Home leave operation will run with these settings the next time you use the unit. To change the recorded information, repeat steps 1-3.

## ■ What's the HOME LEAVE operation?

Is there a set temperature and air flow rate which is most comfortable, a set temperature and air flow rate which you use the most? HOME LEAVE operation is a function that allows you to record your favorite set temperature and air flow rate. You can start your favorite operation mode simply by pressing the HOME LEAVE button on the remote controller. This function is convenient in the following situations.

## Useful in these cases

## 1.Use as an energy-saving mode.

Set the temperature 2-3°C higher (cooling) or lower (heating) than normal. Setting the fan strength to the lowest setting allows the unit to be used in energy-saving mode. Also convenient for use while you are out or sleeping.

## · Every day before you leave the house...



When you go out, push the "HOME LEAVE Operation" button, and the air conditioner will adjust capacity to reach the preset temperature for HOME LEAVE Operation.



When you return, you will be welcomed by a comfortably air conditioned room.



Push the "HOME LEAVE Operation" button again, and the air conditioner will adjust capacity to the set temperature for normal operation.

#### · Before bed...



Set the unit to HOME LEAVE Operation before leaving the living room when going to bed.



The unit will maintain the temperature in the room at a comfortable level while you sleep.



When you enter the living room in the morning, the temperature will be just right. Disengaging HOME LEAVE Operation will return the temperature to that set for normal operation. Even the coldest winters will pose no problem!

## 2.Use as a favorite mode.

Once you record the temperature and air flow rate settings you most often use, you can retrieve them by pressing HOME LEAVE button. You do not have to go through troublesome remote control operations.

## **NOTE**

- Once the temperature and air flow rate for HOME LEAVE operation are set, those settings will be used whenever HOME LEAVE operation is used in the future. To change these settings, please refer to the "Before using HOME LEAVE operation" section above.
- HOME LEAVE operation is only available in COOL and HEAT mode. Cannot be used in AUTO, DRY, and FAN mode.
- HOME LEAVE operation runs in accordance with the previous operation mode (COOL or HEAT) before using HOME LEAVE operation.
- HOME LEAVE operation and POWERFUL operation cannot be used at the same time.
   Last button that was pressed has priority.
- The operation mode cannot be changed while HOME LEAVE operation is being used.
- When operation is shut off during HOME LEAVE operation, using the remote controller or the indoor unit ON/OFF switch, " a " will remain on the remote controller display.

## 2.3.8 TIMER Operation

# **TIMER Operation**

Timer functions are useful for automatically switching the air conditioner on or off at night or in the morning. You can also use OFF TIMER and ON TIMER in combination.

# ■ To use OFF TIMER operation

- Check that the clock is correct. If not, set the clock to the present time.
- 1. Press "OFF TIMER button".

1:00 is displayed.

⊕ o blinks.

# 2. Press "TIMER Setting button" until the time setting reaches the point you like.

- Every pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.
- Press "OFF TIMER button" again.
  - · The TIMER lamp lights up.



# HOMELEAVE POWERFUL TEMP ON CANCEL OFF TIMER 2 1, 3

# ■ To cancel the OFF TIMER operation

- 4. Press "CANCEL button".
  - · The TIMER lamp goes off.

## **NOTE**

- When TIMER is set, the present time is not displayed.
- Once you set ON, OFF TIMER, the time setting is kept in the memory. (The memory is canceled when remote controller batteries are replaced.)
- When operating the unit via the ON/OFF Timer, the actual length of operation may vary from the time entered by the user. (Maximum approx. 10 minutes)

## ■ NIGHT SET MODE

When the OFF TIMER is set, the air conditioner automatically adjusts the temperature setting (0.5°C up in COOL, 2.0°C down in HEAT) to prevent excessive cooling (heating) for your pleasant sleep.

## ■ To use ON TIMER operation

- Check that the clock is correct. If not, set the clock to the present time
- 1. Press "ON TIMER button".

\( \begin{align\*} \begin{align\*}

اد) blinks.

- 2. Press "TIMER Setting button" until the time setting reaches the point you like.
  - Every pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.
- 3. Press "ON TIMER button" again.
  - The TIMER lamp lights up.






4. Press "CANCEL button".

**TIMER operation** 

• The TIMER lamp goes off.


## ■ To combine ON TIMER and OFF TIMER

• A sample setting for combining the two timers is shown below.



## **ATTENTION**

- In the following cases, set the timer again.
  - After a breaker has turned OFF.
  - After a power failure.
  - After replacing batteries in the remote controller.



## 2.3.9 Note for Multi System

# **Note for Multi System**

<< What is a "Multi System"? >>


This system has one outdoor unit connected to multiple indoor units.

# Selecting the Operation Mode

# 1. With the Priority Room Setting present but inactive or not present.

When more than one indoor unit is operating, priority is given to the first unit that was turned on.

In this case, set the units that are turned on later to the same operation mode (\*1) as the first unit.



Outdoor

Living

room

room

room<sup>∏</sup>

- COOL, DRY and FAN mode may be used at the same time.
- AUTO mode automatically selects COOL mode or HEAT mode based on the room temperature.
   Therefore, AUTO mode is available when selecting the same operation mode as that of the room with the first unit to be turned on.

#### <CAUTION>

Normally, the operation mode in the room where the unit is first run is given priority, but the following situations are exceptions, so please keep this in mind.

If the operation mode of the first room is **FAN Mode**, then using **Heating Mode** in any room after this will give priority to **heating.** In this situation, the air conditioner running in FAN Mode will go on standby, and the operation lamp will flash.

## 2. With the Priority Room Setting active.

See "Priority Room Setting" on the next page.

## NIGHT QUIET Mode (Available only for cooling operation)

NIGHT QUIET Mode requires initial programming during installation. Please consult your retailer or dealer for assistance. NIGHT QUIET Mode reduces the operation noise of the outdoor unit during the night time hours to prevent annoyance to neighbors.

- The NIGHT QUIET Mode is activated when the temperature drops 5°C or more below the highest temperature recorded that day. Therefore, when the temperature difference is less than 5°C, this function will not be activated.
- NIGHT QUIET Mode reduces slightly the cooling efficiency of the unit.

## OUTDOOR UNIT QUIET Operation

## 1. With the Priority Room Setting present but inactive or not present.

When using the OUTDOOR UNIT QUIET operation feature with the Multi system, set all indoor units to OUTDOOR UNIT QUIET operation using their remote controllers.

When clearing OUTDOOR UNIT QUIET operation, clear one of the operating indoor units using their remote controller. However OUTDOOR UNIT QUIET operation display remains on the remote controller for other rooms. We recommend you release all rooms using their remote controllers.

## 2. With the Priority Room Setting active.

See "Priority Room Setting" on the next page.

# Cooling / Heating Mode Lock (Available only for heat pump models)

The Cooling / Heating Mode Lock requires initial programming during installation. Please consult your retailer or dealer for assistance. The Cooling / Heating Mode Lock sets the unit forcibly to either Cooling or Heating Mode. This functions convenient when you wish to set all indoor units connected to the Multi system to the same operation mode.

## ■ Priority Room Setting

The Priority Room Setting requires initial programming during installation. Please consult your retailer or dealer for assistance.

The room designated as the Priority Room takes priority in the following situations;

## 1. Operation Mode Priority.

As the operation mode of the Priority Room takes precedence, the user can select a different operation mode from other rooms.

<Example>

\* Room A is the Priority Room in the examples.

When COOL mode is selected in Room A while operating the following modes in Room B,C and D:

Operation mode in Room B, C and D	Status of Room B, C and D when the unit in Room A is in COOL mode
COOL or DRY or FAN	Current operation mode maintained
HEAT	The unit enters Standby Mode. Operation resumes when the Room A unit stops operating.
AUTO	If the unit is set to COOL mode, operation continues. If set to HEAT mode, it enters Standby Mode. Operation resumes when the Room A unit stops operating.

## 2. Priority when POWERFUL operation is used.

<Example>

\* Room A is the Priority Room in the examples.

The indoor units in Rooms A,B,C and D are all operating. If the unit in Room A enters POWERFUL operation, operation capacity will be concentrated in Room A. In such a case, the cooling (heating) efficiency of the units in Rooms B,C and D may be slightly reduced.

## 3. Priority when using OUTDOOR UNIT QUIET operation.

<Example>


\* Room A is the Priority Room in the examples.


Just by setting the unit in Room A to QUIET operation, the air conditioner starts OUTDOOR UNIT QUIET operation.

You don't have to set all the operated indoor units to QUIET operation.

# 3. SA Indoor Unit

# 3.1 BRC1D528







BRC1D528

Remote controller

Operation manual



THANK YOU FOR PURCHASING THIS CONTROLLER. READ THE MANUAL ATTENTIVELY BEFORE USING THE INSTALLATION. AFTER READING THE MANUAL, STORE IT IN A SAFE PLACE FOR FUTURE USE.



Before initial operation, contact your dealer to obtain all details concerning your air conditioning installation.

## **WARNING**

- Never let the remote controller get wet, this may cause an electric shock or fire.
- Never press the buttons of the remote controller with a hard, pointed object. The remote controller may be damaged.
- Never inspect or service the remote controller yourself, ask a qualified service person to do this.

Contents	page
1. Features and functions	1
2. Name and function of switches and icons	2
3. Setting up the controller	4
4. Description of the operation modes	5
5. Operation	5
6. Programming the schedule timer	10

## 1. Features and functions

The BRC1D528 is a state of the art remote controller that offers full control over your installation.

## BASIC REMOTE CONTROLLER

The basic remote controller functions are:

- ON/OFF,
- operation mode change-over,
- temperature adjustment,
- air volume adjustment
- air flow direction adjustment.

## 2 CLOCK FUNCTION

The clock functions are:

- 24 hours real time clock,
- · day of the week indicator.

## 3 SCHEDULE TIMER FUNCTION

The schedule timer functions are:

- a maximum of 5 actions can be programmed for each day of the week (totalling 35 actions),
- schedule timer can be enabled/disabled at any time.
- linked to a set temperature or a LIMIT operation or an OFF operation,
- "last command" overrules previous command until next scheduled command.

## 4 LIMIT OPERATION

Limit operation provides thermostat control within the range of the set minimum and maximum temperature. The minimum temperature setting will trigger heating, the maximum temperature setting will trigger cooling.

Operation manual

DAIKIN

BRC1D528 Remote controller 4PW23717-1

## 5 LEAVE HOME

The leave home function prevents the room temperature from dropping when the occupants are out for a longer period. If the room temperature drops below 10°C, heating is started automatically. As soon as 15°C is reached, the controller returns to its original status.

## 6 BUTTON PERMISSION LEVEL

Three hierarchical permission levels can be set to limit the user action.

# 2. Name and function of switches and icons (Refer to figure 1)

## 1 ON/OFF BUTTON 💍

Press the ON/OFF button to start or stop the system.

## 2 OPERATION LAMP ()

The operation lamp lights up during operation or blinks if a malfunction occurs.

## 3 OPERATION MODE ICON ❖ ☑ 🔝 🕸 🕸

These icons indicate the current operation mode (FAN, DRY, AUTOMATIC, COOLING, HEATING).

## 4 VENTILATION MODE ICON



These icons indicate the current ventilation mode (HRV only) (AUTOMATIC, HEAT EXCHANGE, BYPASS).

## 5 VENTILATION ICON 🚓

The ventilation icon appears when the ventilation is adjusted with the ventilation amount button (HRV only). Simultaneously, the ventilation amount is indicated by the fan speed icon (see 22).

## AIR CLEANING ICON

This icon indicates that the air cleaning unit (option) is operational.

## 7 LEAVE HOME ICON L+

The leave home icon shows the status of the leave home function

ON	Leave home is enabled
FLASHING	Leave home is active
OFF	Leave home is disabled

## 8 EXTERNAL CONTROL ICON 🙏

This icon indicates that another controller with higher priority is controlling or disabling your installation.

# 9 CHANGE-OVER UNDER CENTRALISED CONTROL ICON

This icon indicates that the change-over of the installation is under centralised control assigned to another indoor unit or optional cool/heat selector connected to the outdoor unit (= master remote controller).

# 10 DAY OF THE WEEK INDICATOR MONTUE WED THU FRI SAT SUN

The day of the week indicator shows the current week day (or the set day when reading or programming the schedule timer).

## 11 CLOCK DISPLAY 88:88

The clock display indicates the current time (or the action time when reading or programming the schedule timer).

BRC1D528 Remote controller 4PW23717-1 **DAIKIN** 

Operation manual

2

## MAXTEMPERATURE IMUM SET # # max

The maximum set temperature indicates the maximum set temperature when in limit operation.

## MINIMUM SET TEMPERATURE

The minimum set temperature indicates the minimum set temperature when in limit operation.

#### SCHEDULE TIMER ICON ①

This icon indicates that the schedule timer is enabled.

## ACTION ICONS 1 2 3 4 5

These icons indicate the actions for each day of the schedule timer.

#### OFFICON OFF

This icon indicates that the OFF action is selected when programming the schedule timer.

INSPECTION REQUIRED / and 66 These icons indicate that inspection is required. Consult your installer.

## SET TEMPERATURE DISPLAY

This indicates the current set temperature of the installation (not shown in LIMIT operation or in FAN or DRY mode).

## SETTING SETTING

Not used, for service purposes only.

#### AIR FLOW DIRECTION ICON 20

This icon indicates the air flow direction (only for installations with motorised air flow Baps).

21 NOT AVAILABLE NOT AVAILABLE NOT AVAILABLE is displayed whenever a non-installed option is addressed or a function is not available.

## FAN SPEED ICON LHHH

This icon indicates the set fan speed.

#### DEFROST/HOTSTART MODE ICON 6/19 23

This icon indicates that the defrost/hotstart mode is active.

## AIR FILTER CLEANING TIME ICON

This icon indicates the air filter must be cleaned. Refer to the manual of the indoor unit.


## ELEMENT CLEANING TIME ICON

This icon indicates the element must be cleaned (HRV only).

## VENTILATION MODE BUTTON

The ventilation mode button operates the HRV; refer to the HRV manual for more details.

## VENTILATION AMOUNT BUTTON



## INSPECTION/TEST OPERATION BUTTON (FIRST

Not used, for service purposes only.

## PROGRAMMING BUTTON ↔

This button is a multi-purpose button.

Depending on the previous manipulations of the user, the programming button can have various functions.

Operation manual 3

DAIKIN

BRC1D528 Remote controller 4PW23717-1

30 SCHEDULE TIMER BUTTON ① 图 This button enables or disables the schedule timer.

## 31 TIME ADJUST BUTTON (A)

These buttons are used to adjust the clock or, when in programming mode, to adjust the programmed action time. Both buttons have an auto-repeat function.

# 32 TEMPERATURE ADJUST BUTTONS

These buttons are used to adjust the current setpoint or, when in programming mode, to adjust the programmed setpoint temperature (step =  $1^{\circ}$ C). Both buttons are also used to adjust the day of the week.

# 33 OPERATION CHANGE/MIN-MIX BUTTON

This button is a multi-purpose button. Depending on the previous manipulations of the user, it can have following functions:

- 1 select the operation mode of the installation (FAN, DRY, AUTOMATIC, COOLING, HEATING)
- 2 toggle between minimum temperature and maximum temperature when in limit operation

## 34 SETPOINT/LIMIT BUTTON (1)

This button toggles between setpoint, limit operation or OFF (programming mode only).

## 35 FAN SPEED BUTTON 🧞 🤣

This button toggles between L (Low), H (High), HH (very High), 函 (Automatic).

# AIR FLOW DIRECTION ADJUST BUTTON

This button enables to adjust the air flow direction.

# 37 AIR FILTER CLEANING TIME ICON RESET BUTTON

This button is used to reset the air filter cleaning time icon.

## 3. Setting up the controller

After initial installation, the user can set the clock and day of the week.

The controller is equipped with a schedule timer that enables the user to operate the installation automatically; setting the clock and day of the week is required to be able to use the schedule timer.

#### 1 CLOCK SETTING FUNCTION

Hold down the  $\bigcirc \boxtimes$  button for 5 seconds. The clock read-out and the day of week indicator will blink, both can now be adjusted.

Use the <code>\BarkinA</code> & <code>\BarkinV</code> buttons to adjust the day of the week. Each time pressing the <code>\BarkinA</code> or <code>\BarkinV</code> buttons will display the next or previous day.

Press the  $\Leftrightarrow$  button to confirm the current set time and day of the week.

If the controller, with blinking clock and day of week read-out, is left untouched for 5 minutes, the clock and day of the week will return to their previous settings; the clock setting function is no longer active.

## 2 SETTING UP THE SCHEDULE TIMER

To set up the schedule timer, refer to chapter 6. "Programming the schedule timer" on page 10.

BRC1D528 Remote controller 4PW23717-1 DAIKIN

Operation manual

4

## 4. Description of the operation modes

## FAN ONLY OPERATION

In this mode, air only circulates without heating or cooling.

## 2 DRY OPERATION •

In this mode, the air humidity will be lowered with a minimal temperature decrease.

The temperature and fan speed are controlled automatically and cannot be controlled by the remote controller

Dry operation will not function if the room temperature is too low.

## 3 AUTOMATIC OPERATION A

In this mode, the controller will automatically switch between heating and cooling as required by the setpoint or limit temperature.


## 4 COOLING OPERATION 🔆

In this mode, cooling will be activated as required by the setpoint or limit temperature.


## 5 HEATING OPERATION

In this mode, heating will be activated as required by the setpoint or limit temperature.

## Hot start (heat pump types only)



This prevents cold air from leaving the indoor unit.



In heating operation, freezing of the outdoor heat exchanger may occur. If so, the heating capacity of the system lowers and the system goes into defrost operation. The indoor unit fan stops and significant is displayed. After maximum 10 minutes of defrost operation, the system returns to heating operation again.

## 6 LIMIT OPERATION $^{ ext{min}}_{\mathbb{C}}$ & $^{ ext{max}}_{\mathbb{C}}$

Limit operation is an additional mode that enables to keep the room temperature within certain limits. The  $\min_{C} \quad \& \max_{C} \quad \text{icons are displayed to confirm the activation of the limit operation.}$ 

## 7 LEAVE HOME **□**+

LEAVE HOME is a feature that enables to keep the room temperature above 10°C when the occupants are out. This function will switch on heating if the installation is switched off.

## 5. Operation

## **Manual operation**

In manual operation, the user decides about the settings of the installation. The last setting remains active until the user changes it.

As the controller can be implemented for a wide variety of installations and features, it might occur that you select a function that is not available on your installation; if this is the case, the NOT AVAILABLE message will appear.

Operation manual 5

DAIKIN

BRC1D528 Remote controller 4PW23717-1

Use the min button to select the desired operation

2	Fan only operation
••	Dry operation
(A)	Automatic operation
*	Cooling operation
**	Heating operation

Press the (1) (2) button to toggle between limit operation and the operations listed above.

In limit operation, use the max button to select minimum and maximum temperature settings. Use the 🖫 🔺 or 🖫 🔻 buttons to adjust the minimum and maximum temperature settings.

## FAN ONLY OPERATION

User adjustable parameters:

- Fan speed, use the 🍪 😵 button,
- Air flow direction adjust, use the ... button,
- Ventilation mode, use the button,
- Ventilation amount, use the 🖧 button.

## DRY OPERATION

User adjustable parameters:

- Air flow direction adjust, use the ... button,
- Ventilation mode, use the button,
- Ventilation amount, use the button.

## **AUTOMATIC OPERATION**

User adjustable parameters:

- Setpoint temperature, use the \$\&\&
- Fan speed, use the 🏖 🏖 button,
- Air flow direction adjust, use the √ button,
- Ventilation mode, use the button,
- Ventilation amount, use the button.

## **COOLING OPERATION**

User adjustable parameters:

- Setpoint temperature, use the 🕒 🔺 & ♠ buttons,
- Fan speed, use the button, Air flow direction adjust, use the
- Ventilation mode, use the button,
- Ventilation amount, use the button.

#### 5 **HEATING OPERATION**

User adjustable parameters:

- Setpoint temperature, use the \$\\_\& buttons,
- Fan speed, use the button,
  Air flow direction adjust, use the vibutton,
  Ventilation mode, use the button,
- Ventilation amount, use the button.

## LIMIT OPERATION

- User adjustable parameters:
   Fan speed, use the ₩ button,
   Air flow direction adjust, use the √ button,
- Ventilation mode, use the button,
- Ventilation amount, use the 😜 button.

**BRC1D528** Remote controller 4PW23717-1

**DAIKIN** 

Operation manual

SiBE121135 SA Indoor Unit

#### ADDITIONAL FEATURES OF THE CONTROLLER

#### 1 LEAVE HOME

Press the () and () v buttons simultaneously to enable the LEAVE HOME function.



KEEP IN MIND THAT THE \_\_\_\_\_\_\_ BUTTON MUST BE OFF TO GUARANTEE TRIGGERING OF THE LEAVE HOME FUNCTION.

#### 2 Adjusting the air flow direction

Use the ••\ button to adjust the air flow direction. Press the button to switch between fixed or variable air flow direction. Use the icon to determine the fixed air flow direction by pressing the ••\ button when the icon indicates the desired direction.



Even if fixed air flow direction is selected, variable air flow direction can be enabled automatically to preserve proper operation of your installation.

#### 3 SCHEDULE TIMER

All features and operation and programming of the schedule timer are described below.

#### Schedule timer operation

In schedule timer operation, the installation is also controlled by the schedule timer. The actions programmed in the schedule timer will be executed automatically.

The schedule timer always executes the last command; this means the user can temporarily overrule the last executed programmed action. Refer to "Manual operation" on page 5. The next programmed action (in the schedule timer) will return control to the schedule timer.

Use the ⊕ ⊠ button to enable or disable the schedule timer.

#### NOTE



The schedule timer overrules the  $\begin{picture}(0,0)\put($ 



The programmed schedule is time driven. Make sure that the clock and day of the week are set correctly. Refer to "CLOCK SETTING FUNCTION" on page 4.



Manually adjust the clock for summertime and wintertime. Refer to "CLOCK SETTING FUNCTION" on page 4.



A power failure exceeding 1 hour will reset the clock and the day of the week. Refer to "CLOCK SETTING FUNCTION" on page 4 to adjust the clock and the day of the week.

The actions programmed in the schedule timer will not be lost after a power failure; reprogramming the schedule timer is not required.

To set up the SCHEDULE TIMER refer to chapter 6. "Programming the schedule timer" on page 10.

Operation manual **7** 

**DAIKIN** 

BRC1D528 Remote controller 4PW23717-1

SA Indoor Unit SiBE121135

#### What can the schedule timer do?

The concept of the schedule timer is simple, straightforward though powerful.

#### The schedule timer can order 3 actions:

- 1 switch on the installation at a scheduled time, in combination with a setpoint (exact temperature control)
- 2 switch off the installation (end of control)
- 3 switch on the installation at a scheduled time, in limit operation

## The schedule timer can accept a maximum of 5 actions per day.

For each day of the week a maximum of 5 actions can be programmed, totalling a maximum of 35 programmed actions. The action that was programmed first for a certain day is action 1, the last programmed action for a day could be action 1 (in case only one action is programmed for that day) to 5.



It is of utmost importance to understand that the number assigned to the programmed action, DOES NOT DETERMINE WHEN the programmed action will be executed. Only the TIME, being a part of the data entered when programming the action, will determine when the programmed action will be executed.

#### What will the schedule timer do?

If enabled, the schedule timer will execute the programmed actions.

It will order the installation to:

 cool or heat, depending on the current operation, if applicable; the setpoint will be displayed.

#### OR

 switch off the installation (the schedule timer remains enabled and reactivates the installation as programmed); the operation lamp will turn off,

#### OR

cool or heat, whichever is required to keep the room temperature within a specified range (limit operation);  $\overset{\text{constant}}{\overset{\text{constant}}}{\overset{\text{constant}}{\overset{\text{constant}}{\overset{\text{constant}}{\overset{\text{constant}}{\overset{\text{constant}}{\overset{\text{constant}}{\overset{\text{constant}}{\overset{\text{constant}}{\overset{constant}}{\overset{constant}}{\overset{constant}}{\overset{constant}}{\overset{const$ 



The schedule timer will change the operation mode in LIMIT operation only.

To be able to verify the programmed actions, you can browse the programmed actions, see below.

#### What will the schedule timer NOT do?

The schedule timer will not:

- control fan speed,
- control air flow direction,
- control ventilation mode,
- · control ventilation amount,
- change the operation mode for a scheduled setpoint.

The parameters listed above can be set manually, without interfering with the schedule timer.

More sophisticated remote controllers are available. Consult your dealer for more information.

## Browsing the programmed actions in the schedule timer (read-out only)

Refer to figure 2.

Browsing the programmed actions of the schedule timer is a sequential process. Only 2 buttons are used to browse the entire schedule timer program.

The  $\leftrightarrow$  button is used to start browsing, to display the next programmed action or to exit browsing when displaying the last programmed action.

BRC1D528 Remote controller 4PW23717-1 **DAIKIN** 

Operation manual

8

**SA Indoor Unit** SiBE121135

The ⊕ ₩ button is used to exit browsing at once (without having to scroll through all programmed

Press the  $\Leftrightarrow$  button to enter the browse mode, the (1) icon appears, WW will blink.

<u>कि</u>

Browsing always starts on Monday and ends on Sunday.

Check the 12345 icon. If at least 1 action is programmed for Monday, 1 will appear.

The clock indicates the time when the programmed action is scheduled, either  $\mathcal{E}\mathcal{H}^{\scriptscriptstyle{\oplus}}_{\scriptscriptstyle{\mathbb{C}}}$ , OFF or  $\mathcal{H}^{\scriptscriptstyle{\oplus}}_{\scriptscriptstyle{\mathbb{C}}}$  and  $\exists \mathcal{I}_{\mathcal{C}}^{\max}$  is being displayed.

The temperatures mentioned above are for clarifying purposes only, temperature values on your controller may vary.

If 1 does not appear, it indicates that there are no programmed actions for Monday.

Press the  $\leftrightarrow$  button again to go to the next day of the week. TF will blink, this indicates that the programmed actions for Tuesday are being browsed.

The process described above is now restarted.

If at least 1 action is programmed for Tuesday, 1 will appear. The clock indicates the time when the programmed action will be enabled, either  $\mathcal{L}^{\mathcal{H}_{\mathbb{C}}^{0}}$  OFF or  $\mathcal{L}_{\mathbb{C}}^{0}$  and  $\mathcal{L}_{\mathbb{C}}^{0}$  is being displayed. If 1 does not appear, it indicates that there are no programmed actions for Tuesday.

Press the  $\Leftrightarrow$  button to display the next programmed action. If a second action is programmed for Tuesday, If will still be blinking and 1 2 will appear.

Assuming that 5 actions were programmed for Tuesday, a total of 5 presses will be required to display all programmed actions.

Continue pressing the  $\Leftrightarrow$  button until the day of the week indicator displays the current day (not blinking), you have now quit browsing.



The number of times that the 

→ button will have to be pressed to quit browsing depends on the number of programmed actions in the schedule timer.

#### How do I interpret the programmed actions

To be able to understand the behaviour of your installation when the schedule timer is enabled, it is important to look at all programmed actions for the current day and maybe the last programmed action of yesterday.

If the first programmed action for today is not active yet, the current status of your installation depends, most probably but not necessarily, on the last programmed action from yesterday. Read the important note below.

If the first programmed action for today is already active, the current status of your installation depends, most probably but not necessarily, on the parameters programmed in the first programmed action for today. Read the important note below.

NOTE



To keep the operation of your installation simple, the schedule timer settings can easily be overruled by altering the current setting ("last command" overrules previous command until next scheduled command).

Conclusion: Although ① is displayed, somebody might have altered the settings. The next programmed action will overrule the altered settings and all settings return as programmed.

Operation manual

DAIKIN

BRC1D528 Remote controller 4PW23717-1

SA Indoor Unit SiBE121135

Programmed actions might overlap; due to the "last command overrules" logic, the last scheduled command will rule.

## How do I interpret the readings on the display when the schedule timer is active

As described above, the schedule timer settings, (and as a consequence the display readings) might be overruled temporarily by a manual intervention.

If you want to be absolutely sure about the schedule timer settings for this very moment, you must browse the schedule timer programmed actions. Refer to "Browsing the programmed actions in the schedule timer" on page 8.

#### 6. Programming the schedule timer

#### What do I have to program?

As the schedule timer is based on a week program (the same actions will be repeated every week) you will have to select the day of the week first.

Now you must choose an action:

- 1 switch on the installation at a scheduled time, in combination with a setpoint (exact temperature control)
- 2 switch off the installation (end of control)
- 3 switch on the installation at a scheduled time, in limit operation

Finally you must enter the time of the day when the action must be enabled.

NOTE

If you program 2 or more actions on the same day and at the same time of the day, only the action with the highest action number (2 - 5) will be executed.

#### **Getting started**

Programming the schedule timer is flexible (you can add, remove or alter programmed actions whenever required) and straightforward (programming steps are limited to a minimum).

Below are some tips and tricks to ensure successful programming of the schedule timer:

- familiarise yourself with the icons and the buttons, you will need them when programming,
- familiarise yourself with the browse function, you will need it to start programming. Refer to "Browsing the programmed actions in the schedule timer" on page 8,
- fill out the form at the end of this manual; note the time and the required action for each day (keep in mind that the number of actions is limited to 5 per day),
- take your time to enter all data accurately,
- try to program the actions for each day in logical sequence (start with action 1 for the first action and end with the highest number for the last action). This is not a requirement but it will make it much easier to interpret the program later,
- keep in mind that you can always alter, add or remove the programmed actions later.

BRC1D528 Remote controller 4PW23717-1 DAIKIN

Operation manual

10

SiBE121135 SA Indoor Unit

#### **Programming**

1 THE SCHEDULE TIMER IS PROGRAMMED FOR THE FIRST TIME

NOTE



When changing day during programming you will have to confirm "the last action". Each day can have 5 programmed actions (numbered 1 to 5) but for some reason you might want to delete one, several or all programmed actions.

Tobe able to delete programmed actions, you must select the last action that you want to keep, this can be 1 to 5 or no action (⊕ is displayed and no action displayed).

All programmed actions with a number HIGHER than the selected one, or all programmed actions if no last action was selected will be deleted.

#### PROGRAMMING THE FIRST DAY OF THE WEEK

NOTE

In the guidelines below it is assumed that you start programming the schedule timer actions on Monday and end with the schedule timer actions for Sunday.

If you prefer NOT to start on Monday, first browse to the desired day and then enter the PROGRAM mode.

In this particular case, no actions have been programmed before, all schedule timer actions are idle.

- Browse to Monday by pressing the 
   button.

  The ⊕ icon appears, MM will blink and one of the icons might be displayed but all other fields remain blank, indicating that no actions are programmed for Monday.
- Press the button to activate the first programmed action.
- A blinking 1 is displayed indicating that the first programmed action for Monday is being programmed; The set temperature and clock display are blinking.
- Press the button to select either set temperature, OFF, or limit operation.
- Enter the desired temperature using the & & T buttons.
- Press the max button to toggle between minimum set temperature and maximum set temperature in limit operation, the selected temperature will blink.
- Enter the time when the action must start using the buttons (min. step = 10 minutes).

NOTE

If, by accident, you pressed the ⇔ button, you activated the next action; 1 2 is displayed (1 steady and 2 blinking).

Press the ↔ button repeatedly until a blinking 1 is displayed. You can now continue adjusting the settings for the first schedule timer action.

Operation manual **DAIKIN** 

BRC1D528 Remote controller 4PW23717-1

SiBE121135 SA Indoor Unit

> If the action and the corresponding time are correct, you can proceed to the second schedule timer action. This is done by pressing the  $\leftrightarrow$  button, the data is saved and the next schedule timer action can be programmed.

Programming the remaining schedule timer actions for the same day is similar.

You can browse the schedule timer actions by pressing the  $\leftrightarrow$  button.

NOTE



Don't worry if you add additional schedule timer actions by pressing the ♦ button repeatedly, they can be deleted when finishing the current day.

When all data for the schedule timer actions for Monday are entered, you must confirm the programmed actions.

Make sure the last schedule timer action you want to keep is selected (schedule timer actions with a higher number will be deleted).

Now you must choose between 2 options:

#### 1 CONFIRM AND COPY TO NEXT DAY

The schedule timer action programmed for the current day are also valid for the next day: use the "confirm last action and copy actions to next day" function by pressing the  $\leftrightarrow$  and (1) buttons simultaneously for 5 seconds.

#### 2 CONFIRM ONLY

The schedule timer action programmed for the current day are only valid for the selected day: use the "confirm last action and go to next day" function by pressing the  $\Leftrightarrow$  button for 5 seconds.

Program mode is quit and depending on the choice made, the programmed actions are saved for Monday (and possibly Tuesday).

#### PROGRAMMING THE OTHER DAYS OF THE WEEK

Programming the other days of the week is identical to programming the first day of the week.  ${1}\!{1}\!{1}\!{1}\!{1}$  is blinking to indicate the selected day,  ${2}\!{1}\!{1}\!{1}$  are steady if actions were copied from Monday to Tuesday, only ① is displayed if no actions were copied from Monday to Tuesday.

#### I WANT TO EDIT PROGRAMMED ACTIONS Editing programmed actions is easy.

Make sure you are not in program mode ( not blinking); if required, press the ⊕ Ø button to quit program mode.

Browse to the programmed actions using the  $\Leftrightarrow$ button, select the day and action you want to edit.

Press the 

→ button for 5 seconds; program mode is enabled, the ① icon and selected action are blinking. Edit the settings using the same buttons described

Select the "last action" using the ↔ button and decide if you do or do not want to copy the programmed action(s) to the next day (pressing the

♠ and ♠ X buttons simultaneously or only the button for 5 seconds).

BRC1D528 Remote controller 4PW23717-1

**DAIKIN** 

Operation manual

12

SiBE121135 SA Indoor Unit

#### I WANT TO DELETE ONE OR MORE PROGRAMMED ACTIONS

Make sure you are not in program mode (⊕ not blinking); if required, press ⊕ 💥 to quit program mode

Browse to the programmed actions using the  $\Leftrightarrow$  button, select the day you want to edit.

Press the  $\Leftrightarrow$  button for 5 seconds; program mode is enabled, the  $\oplus$  icon and selected action are blinking. Select the "last action" you want to keep using the  $\Leftrightarrow$  button. All higher actions will be deleted.

Confirm the deletion by pressing the  $\leftrightarrow$  button for 5 seconds, OR confirm the deletion for the current and the next day too by pressing the  $\leftrightarrow$  and  $\circlearrowleft$  buttons simultaneously for 5 seconds.



In the case above, if for example the last action was 3, the programmed actions 4 and 5 will also be deleted (if they were present).

#### 4 I WANT TO DELETE ALL PROGRAMMED ACTIONS AT ONCE

Quit programming or browsing.

Press the  $\Leftrightarrow$  and  $\clubsuit$  buttons simultaneously for 5 seconds; the  $\circlearrowleft$  icon will invert and disappear to confirm deletion.

#### 7. Maintenance

The remote controller does not need maintenance. Remove dirt with a soft damp cloth.



Only use clear tepid water to moisten the cloth.

#### 8. Troubleshooting

The guidelines below might help to solve your problem. If you cannot remedy the problem, consult your installer.

## No readings on the remote controller (display blank)

Check if the mains power is still applied to your installation.

#### Only 28 is displayed

This indicates that the installation has just been powered, please wait until  $\{ \frac{\partial}{\partial x} \}$  disappears.

## The schedule timer does work but the programmed actions are executed at the wrong time (e.g. 1 hour too late or too early)

Check if the clock and the day of the week are set correctly, correct if necessary (refer to "CLOCK SETTING FUNCTION" on page 4).

## I cannot enable the schedule timer (the $\oplus$ icon blinks for 2 seconds and disappears)

The schedule timer has not been programmed yet. First program the schedule timer (refer to "Programming the schedule timer" on page 10).

## I cannot enable the schedule timer (the $_{\text{AVA|LABLE}}^{\text{NOT}}$ icon is displayed)

The schedule timer can not be enabled when a centralised control is connected.

#### Limit operation cannot be selected

Limit operation is not available for cooling only installations.

Operation manual 13

DAIKIN

BRC1D528 Remote controller 4PW23717-1

4PW23717-1

# Part 6 Service Diagnosis

1.	I rou	bleshooting with LED	.250
	1.1	Indoor Unit	250
	1.2	Outdoor Unit	252
2.	Prob	lem Symptoms and Measures	.253
		rice Check Function	
	3.1	RA Indoor Unit - FTXG, FTXS, CTXS, FVXG, FVXS, FLXS, FDXS Series	
	3.2	SA Indoor Unit - FCQG, FFQ, FHQ, FDBQ, FBQ Series	
4.		e Indication on Remote Controller	
4.	4.1	RA Indoor Unit - FTXG, FTXS, CTXS, FVXG, FVXS, FLXS,	
	4.0	FDXS Series.	
	4.2 4.3	SA Indoor Unit - FCQG, FFQ, FHQ, FDBQ, FBQ Series	
	4.3 4.4	Outdoor Unit	
_			
5.		bleshooting for RA Indoor Unit - FTXG, FTXS, CTXS, FVXG, F	
	5.1	S, FDXS Series	
	5.1	Freeze-up Protection Control or Heating Peak-cut Control	
	5.3	Fan Motor or Related Abnormality	
	5.4	Radiant Panel Temperature Rise, Indoor Electronic Expansion Valve	
	0. 1	(Motor Operated Valve) Abnormality, Freeze-up Protection Control	,
		(FVXG Series Only)	278
	5.5	Thermistor or Related Abnormality (RA Indoor Unit)	
	5.6	Front Panel Open / Close Fault (FTXG Series Only)	
	5.7	Signal Transmission Error (between Indoor Unit and Outdoor Unit)	
	5.8	Unspecified Voltage (between Indoor Unit and Outdoor Unit)	
6.		bleshooting for SA Indoor Unit - FCQG, FFQ, FHQ, FDBQ,	
		Series	
	6.1	Indoor Unit PCB Abnormality	
	6.2 6.3	Drain Water Level System Abnormality	
	6.4	Fan Motor Lock (EHO Series Only)	287 289
	6.5	Swing Motor Lock (FHQ Series Only)	
	6.6	Thermistor or Related Abnormality (SA Indoor Unit)	
	6.7	Remote Controller Thermistor Abnormality (SA Indoor Only)	
	6.8	Signal Transmission Error	252
	0.0	(between Indoor Unit and Remote Controller)	293
	6.9	Signal Transmission Error	00
	0.0	(between MAIN Remote Controller and SUB Remote Controller)	294
	6.10	Field Setting Abnormality	
7.		bleshooting for Outdoor Unit	
٠.	7.1	Refrigerant Shortage	
	7.2	Low-voltage Detection or Over-voltage Detection	
	7.3		

	7.4	Unspecified Voltage (between Indoor Unit and Outdoor Unit) /	
		Anti-icing Function in Other Rooms	301
	7.5	Anti-icing Function	302
	7.6	Outdoor Unit PCB Abnormality	304
	7.7	OL Activation (Compressor Overload)	305
	7.8	Compressor Lock	306
	7.9	DC Fan Lock	307
	7.10	Input Overcurrent Detection	308
	7.11	Discharge Pipe Temperature Control	309
	7.12	High Pressure Control in Cooling	310
	7.13	Compressor Sensor System Abnormality	311
	7.14	Position Sensor Abnormality	313
	7.15	CT or Related Abnormality	315
	7.16	Thermistor or Related Abnormality (Outdoor Unit)	317
	7.17	Electrical Box Temperature Rise	319
	7.18	Radiation Fin Temperature Rise	321
	7.19	Output Overcurrent Detection	323
8.	Chec	k	325
	8.1	Thermistor Resistance Check	325
	8.2	Fan Motor Connector Check	326
	8.3	Hall IC Check	327
	8.4	Indoor Electronic Expansion Valve Coil Check	327
	8.5	Power Supply Waveform Check	328
	8.6	Outdoor Electronic Expansion Valve Check	329
	8.7	Four Way Valve Performance Check	
	8.8	Inverter Unit Refrigerant System Check	330
	8.9	"Inverter Checker" Check	331
	8.10	Rotation Pulse Check on the Outdoor Unit PCB	332
	8.11	Installation Condition Check	333
	8.12	Discharge Pressure Check	333
	8.13	Outdoor Fan System Check	334
	8.14	Capacitor Voltage Check	334
	8.15	Power Module Check	335

## 1. Troubleshooting with LED


### 1.1 Indoor Unit

#### **Operation Lamp**


The operation lamp blinks when any of the following errors is detected.

- 1. When a protection device of the indoor or outdoor unit is activated, or when the thermistor malfunctions
- 2. When a signal transmission error occurs between the indoor and outdoor units. In either case, conduct the diagnostic procedure described in the following pages.


**Wall Mounted Type: FTXG Series** 




Wall Mounted Type: FTXS-K, CTXS-K Series




**Wall Mounted Type: FTXS-J Series** 




**Wall Mounted Type: FTXS-G Series** 




Floor Standing Type: FVXG Series




#### Floor Standing Type: FVXS Series




#### Floor / Ceiling Suspended Dual Type




#### **Duct Connected Type**





#### **BRC1E52A7, BRC1E52B7**





When operation stops suddenly and the operation lamp blinks, it could be "operation mode conflict".

#### Check followings;

Are the operation modes all the same for the indoor units connected to multi system outdoor unit?

If not, set all the indoor units to the same operation mode and confirm that the operation lamp is not blinking.

Moreover, when the operation mode is automatic, set all the indoor unit operation mode as "cooling" or "heating" and check again if the operation lamp is normal.

If the lamp stops blinking after the above steps, there is no malfunction.


\* Operation stops and operation lamp blinks only for indoor unit which different operation mode is set later. (The first set operation mode has priority.)

#### **Service Monitor**

The indoor unit has one green LED (LED A) on the control PCB. When the microcomputer works in order, the LED A blinks.

### 1.2 Outdoor Unit

The outdoor unit has one green LED (LED A) on the PCB. When the LED A blinks, the microcomputer works in order.



(R17270)

There are a green LED (LED A) and red LEDs on the outdoor unit PCB. The LED A indicates microcomputer operation condition. In normal condition, the LED A is blinking and the other LEDs are OFF.

Even after the error is canceled and the unit operates in normal condition, the LED indication remains.

## 2. Problem Symptoms and Measures

Problem Symptom	Check Item	Details of Measure	Reference Page
None of the units operates.	Check the power supply.	Check if the rated voltage is supplied.	_
	Check the types of the indoor units.	Check if the indoor unit type is compatible with the outdoor unit.	_
	Check the outdoor temperature.	Heating operation cannot be used when the outdoor temperature is 20°C or higher, and cooling operation cannot be used when the outdoor temperature is below -10 ~ 10°C (depending on the model).	_
	Diagnose with remote controller indication	_	267
	Check the remote controller addresses.	Check if address settings for the remote controller and indoor unit are correct.	415
Operation sometimes stops.	Check the power supply.	A power failure of 2 to 10 cycles can stop air conditioner operation. (Operation lamp OFF)	_
	Check the outdoor temperature.	Heating operation cannot be used when the outdoor temperature is 20°C or higher, and cooling operation cannot be used when the outdoor temperature is below -10 ~ 10°C (depending on the model).	_
	Diagnose with remote controller indication.	_	267
Some indoor units do not operate.	Check the type of the indoor units.	Check if the indoor unit type is compatible with the outdoor unit.	_
	Diagnose with remote controller indication	_	267
Units operate but do not cool, or do not heat.	Check for wiring and piping errors in the connection between the indoor and outdoor units.	Conduct the wiring/piping error check described on the product diagnosis nameplate.	_
	Check for thermistor detection errors.	Check if the thermistor is mounted securely.	_
	Check for faulty operation of the outdoor electronic expansion valve.	Set all the units to cooling operation, and compare the temperatures of the liquid pipes to see if the each outdoor electronic expansion valve works.	_
	Diagnose with remote controller indication.	_	267
	Diagnose by service port pressure and operating current.	Check for refrigerant shortage.	296
Large operating noise and vibrations	Check the output voltage of the power module.	_	335
	Check the power module.	_	
	Check the installation condition.	Check if the required spaces for installation (specified in the installation manual) are provided.	_

**Service Check Function** SiBE121135


### 3. Service Check Function

#### 3.1 RA Indoor Unit - FTXG, FTXS, CTXS, FVXG, FVXS, FLXS, **FDXS Series**

#### **ARC466 Series Remote Controller** 3.1.1

**Check Method 1** 

1. When the timer cancel button is held down for 5 seconds, 32 is displayed on the temperature display screen.



- 2. Press the timer cancel button repeatedly until a long beep sounds.
- The code indication changes in the sequence shown below.

#### <ARC466A1, A6>

No.	Code	No.	Code	No.	Code
1	88	13	£η	25	UR
2	UY.	14	83	26	UH
3	LS	15	X8	27	PY
4	88	16	XS	28	13
5	Hδ	17	68	29	14
6	X8	18	64	30	89
7	88	19	εs	31	u∂
8	٤٦	20	J3	32	88
9	UC .	21	J8	33	88
10	F3	22	85	34	FR
11	85	23	8:	35	81
12	۶8	24	£ ;	36	<i>P</i> 9

#### <ARC466A2>


NI IOTOURE/							
No.	Code	No.	Code	No.	Code		
1	88	14	En	27	UR		
2	U4	15	83	28	UH		
3	LS	16	X8	29	PY		
4	88	17	X3	30	13		
5	<i>H</i> 8	18	63	31	7.4		
6	HO .	19	54	32	89		
7	88	20	ES	33	U∂		
8	£7	21	£8	34	88		
9	UO .	22	J3	35	88		
10	F3	23	Jδ	36	£8		
11	85	24	85	37	81		
12	F8	25	81	38	29		
13	89	26	ε;				

- 1. A short beep and two consecutive beeps indicate non-corresponding codes.
- 2. To return to the normal mode, hold the timer cancel button down for 5 seconds. When the remote controller is left untouched for 60 seconds, it also returns to the normal mode.
- 3. Not all the error codes are displayed. When you cannot find the error code, try the check method 2. (→ Refer to page 255.)


SiBE121135 Service Check Function

#### **Check Method 2**


1. Press the center of the [Temp] button and the [Mode] button at the same time.




\$5 is displayed on the LCD.




- 2. Select  $\mathfrak L$  (service check) with the [Temp]  $\blacktriangle$  or  $\blacktriangledown$  button.
- 3. Press the [Mode] button to enter the service check mode.



The left-side number blinks.



4. Press the [Temp] ▲ or ▼ button and change the number until you hear the two consecutive beeps or the long beep.



Service Check Function SiBE121135

5. Diagnose by the sound.

★beep: The left-side number does not correspond with the error code.


★tow consecutive beeps: The left-side number corresponds with the error code but the right-side number does not.

★long beep: Both the left-side and right-side numbers correspond with the error code.


The numbers indicated when you hear the long beep are the error code.

Error codes and description → Refer to page 267.


6. Press the [Mode] button.



The right-side number blinks.



7. Press the [Temp] ▲ or ▼ button and change the number until you hear the long beep.



8. Diagnose by the sound.

★beep: The left-side number does not correspond with the error code.


★two consecutive beeps: The left-side number corresponds with the error code but the right-side number does not.

★long beep : Both the left-side and right-side numbers correspond with the error code.

9. Determine the error code.

The numbers indicated when you hear the long beep are the error code. Error codes and description  $\rightarrow$  Refer to page 267.

10. Press the [Mode] button for 5 seconds to exit from the service check mode. (When the remote controller is left untouched for 60 seconds, it returns to the normal mode also.)




SiBE121135 Service Check Function

#### 3.1.2 ARC452 Series Remote Controller

#### **Check Method 1**

1. When the timer cancel button is held down for 5 seconds, aa is displayed on the temperature display screen.





Timer cancel button

< ARC452 Series >

(R14554)

- 2. Press the timer cancel button repeatedly until a long beep sounds.
- The code indication changes in the sequence shown below.

#### <ARC452A1, A3>

No.	Code	No.	Code	No.	Code
1	88	13	٤٦	25	UR
2	uч	14	83	26	UH
3	LS	15	X8	27	PY
4	88	16	XS	28	13
5	HS	17	83	29	18
6	X8	18	٤٢	30	87
7	88	19	ξS	31	u∂
8	٤٦	20	J3	32	88
9	UB	21	J8	33	88
10	F3	22	٤s	34	F.R
11	85	23	8:		
12	F8	24	ε;		




- 1. A short beep or 2 consecutive beeps indicate non-corresponding codes.
- 2. To return to the normal mode, hold the timer cancel button down for 5 seconds. When the remote controller is left untouched for 60 seconds, it also returns to the normal mode.
- Not all the error codes are displayed. When you cannot find the error code, try the check method 2. (→ Refer to page 258.)


Service Check Function SiBE121135

#### **Check Method 2**


 Press the 3 buttons ([TEMP] ▲, [TEMP] ▼, [MODE]) at the same time to enter the diagnosis mode.



The left-side number blinks.




2. Press the [TEMP] ▲ or ▼ button and change the number until you hear the two consecutive beeps or the long beep.




- 3. Diagnose by the sound.
  - $\bigstar$  beep : The left-side number does not correspond with the error code.
  - ★ two consecutive beeps : The left-side number corresponds with the error code but the right-side number does not.
  - ★ long beep: Both the left-side and right-side numbers correspond with the error code.

    The numbers indicated when you hear the long beep are the error code.

    Error codes and description → Refer to page 267.
- 4. Press the [MODE] button.




The right-side number blinks.



SiBE121135 Service Check Function


5. Press the [TEMP] ▲ or ▼ button and change the number until you hear the long beep.




- 6. Diagnose by the sound.
  - ★ beep : The left-side number does not correspond with the error code.
  - ★ two consecutive beeps : The left-side number corresponds with the error code but the right-side number does not.
  - ★ long beep: Both the left-side and right-side numbers correspond with the error code.
- 7. Determine the error code.

The numbers indicated when you hear the long beep are the error code. Error codes and description  $\rightarrow$  Refer to page 267.


8. Press the [MODE] button to exit from the diagnosis mode.



The display  $7^{-}$  means the trial operation mode. Refer to page 408 for trial operation.



9. Press the [ON/OFF] button twice to return to the normal mode.




Note: When the remote controller is left untouched for 60 seconds, it returns to the normal mode.

Service Check Function SiBE121135

#### 3.1.3 ARC433 Series Remote Controller

#### **Check Method 1**

1. When the timer cancel button is held down for 5 seconds, aa is displayed on the temperature display screen.



- 2. Press the timer cancel button repeatedly until a long beep sounds.
- The code indication changes in the sequence shown below.

#### <ARC433B67, B69>

No.	Code	No.	Code	No.	Code
1	88	12	£η	23	XC
2	UЧ	13	X8	24	۱ ع
3	F3	14	J3	25	ዖЧ
4	88	15	83	26	73
5	LS	16	8:	27	۲4
6	88	17	٤٩	28	X8
7	85	18	85	29	X7
8	۶۶	19	XS	30	u≥
9	58	20	JS	31	uн
10	<u> 10</u>	21	UR	32	88
11	٤٦	22	85	33	88




- 1. A short beep or two consecutive beeps indicate non-corresponding codes.
- 2. To return to the normal mode, hold the timer cancel button down for 5 seconds. When the remote controller is left untouched for 60 seconds, it also returns to the normal mode.
- 3. Not all the error codes are displayed. When you cannot find the error code, try the check method 2. (→ Refer to page 261.)


SiBE121135 Service Check Function

#### **Check Method 2**


1. Press the center of the [TEMP] button and the [MODE] button at the same time to enter the diagnosis mode.



The left-side number blinks.




2. Press the [TEMP] ▲ or ▼ button and change the number until you hear the two consecutive beeps or the long beep.




- 3. Diagnose by the sound.
  - $\bigstar$  beep : The left-side number does not correspond with the error code.
  - ★ two consecutive beeps : The left-side number corresponds with the error code but the right-side number does not.
  - ★ long beep : Both the left-side and right-side numbers correspond with the error code.

    The numbers indicated when you hear the long beep are the error code.

    Error codes and description → Refer to page 267.
- 4. Press the [MODE] button.




The right-side number blinks.



Service Check Function SiBE121135

5. Press the [TEMP] ▲ or ▼ button and change the number until you hear the long beep.



6. Diagnose by the sound.

★ beep: The left-side number does not correspond with the error code.


★ two consecutive beeps : The left-side number corresponds with the error code but the right-side number does not.

 $\bigstar$  long beep : Both the left-side and right-side numbers correspond with the error code.


7. Determine the error code.

The numbers indicated when you hear the long beep are the error code. Error codes and description  $\rightarrow$  Refer to page 267.


8. Press the [MODE] button to exit from the diagnosis mode.



The display 7° means the trial operation mode. Refer to page 408 for trial operation.



9. Press the [ON/OFF] button twice to return to the normal mode.



Note: When the remote controller is left untouched for 60 seconds, it returns to the normal mode.


SiBE121135 Service Check Function

## 3.2 SA Indoor Unit - FCQG, FFQ, FHQ, FDBQ, FBQ Series

#### 3.2.1 Relations between Modes


#### **BRC1D528**

The following modes can be selected by using the [Inspection / Test] button on the remote controller.



Service Check Function SiBE121135

#### **BRC1E52A7, BRC1E52B7**




(R12855)

SiBE121135 Service Check Function

#### 3.2.2 BRC1D528

If operation stops due to malfunction, the operation lamp on the remote controller blinks, and error code is displayed. (Even if stop operation is carried out, malfunction contents are displayed when inspection mode is entered.) The error code enables you to tell what kind of malfunction caused operation to stop.

Refer to page 267 for error code and malfunction contents.



**n** Note:


- 1. When you press the [INSPECTION/TEST OPERATION] button, the inspection display blinks.
- 2. While in the inspection mode, press the [ON/OFF] button for 5 seconds or more to clear the failure history indication. In this case, the error code blinks twice and then changes to  $\mathcal{CC}$  (= Normal), the UNIT No. changes to  $\mathcal{CC}$ , and the operation mode automatically switches from the inspection mode to the normal mode (displaying the set temperature).

Service Check Function SiBE121135

### 3.2.3 BRC1E52A7, BRC1E52B7

The following display appears on the screen when a error (or a warning) occurs during operation.

Check the error code and take the corrective action specified for the particular model.



#### (1) Check if it is error or warning.


	Operation status	Di	splay
Abnormal shutdown	The system stops operating.	The operation lamp (green) starts to blink. The message "Error: Press Menu Button" appears and blinks at the bottom of the screen.	Cool Set temperature 28°C Error: Press Menu Button (R12858)
Warning	The system continues its operation.	The operation lamp (green) remains on. The message "Warning: Press Menu Button" appears and blinks at the bottom of the screen.	Cool Set temperature 28°C Warning: Press Menu Button (R12857)

#### (2) Take corrective action.

 $\cdot$  Press the [Menu/Enter] button to check the error code.



· Take the corrective action specific to the model.



## 4. Code Indication on Remote Controller

## 4.1 RA Indoor Unit - FTXG, FTXS, CTXS, FVXG, FVXS, FLXS, FDXS Series

Error Codes	Descrip	otion	Reference Page	
88	Normal condition		_	
8 :	Indoor unit PCB abnormality		270	
8S	Freeze-up protection control or he	eating peak-cut control	272	
88	Fan motor or related abnormality DC motor (wall, floor standing)		274	
1161	Fair motor of related abnormality	AC motor (floor / ceiling, duct)	277	
83	Radiant panel temperature rise, inc (motor operated valve) abnormalit (FVXG series only)	278		
54	Indoor heat exchanger thermistor	or related abnormality	280	
£7	Front panel open / close fault (FT)	Front panel open / close fault (FTXG series only)		
53	Room temperature thermistor or re	elated abnormality	280	
£	Radiant panel thermistor or related only)	280		
#4	Signal transmission error (betwee	282		
UR	Unspecified voltage (between inde	oor unit and outdoor unit)	283	

## 4.2 SA Indoor Unit - FCQG, FFQ, FHQ, FDBQ, FBQ Series

Error Codes	Description	Reference Page
88	Normal condition	_
8 :	Indoor unit PCB abnormality	284
83	Drain water level system abnormality	285
88	Fan motor or related abnormality	287
87	Swing motor lock (FHQ series only)	289
RF.	Drain system abnormality	290
84	Indoor heat exchanger thermistor or related abnormality	291
63	Room temperature thermistor or related abnormality	291
Ed	Remote controller thermistor abnormality	292
US	Signal transmission error (between indoor unit and remote controller)	293
U8	Signal transmission error (between MAIN remote controller and SUB remote controller)	294
UR	Field setting abnormality	295

: Error code displays automatically and system stops.
Inspect and solve the error.

: In the case of the shaded error codes, "inspection" is not displayed. The system operates, but be sure to inspect and solve the error.

### 4.3 Sub Codes for SA Indoor Unit

If an error code like the one shown below is displayed when the navigation remote controller (BRC1E52A7, BRC1E52B7) is in use, make a detailed diagnosis or a diagnosis of the relevant unit referring to the attached list.

Error codes	Description	Troubleshooting
A6 - 01	Fan motor locked	A locked fan motor current has been detected. Turn the fan by hand to check for the connection of connectors.
A6 - 10	Fan overcurrent error	A fan motor overcurrent has been detected. Check for the connection of the connector between the fan motor and the PCB. If the connection is normal, replace the fan motor. If this still cannot solve the error, replace the PCB.
A6 - 11	Fan position detection error	An error in the detection of position of the fan motor. Check for the connection of the connector between the fan motor and the PCB. If the connection is normal, replace the fan motor. If this still cannot solve the error, replace the PCB.
AH - 03	Transmission error (between the self- cleaning decoration panel and the indoor unit) [when the self-cleaning decoration panel is mounted]	Check for the connection of the harness connector between the panel PCB and the indoor unit PCB.
AH - 04	Dust detection sensor error [when the self-cleaning decoration panel is mounted]	Check for the connections of the connector X12A on the panel PCB and the connectors X18A and X19A on the sensor PCBs.
AH - 05	Dust collection sign error [when the self-cleaning decoration panel is mounted]	Check for clogging with dust at the dust collection port as well as in the brush unit, S-shaped pipe, and dust box. Furthermore, check for any stains of the light receiving and emitting parts of the infrared unit.
AH - 06	Air filter rotation error [when the self-cleaning decoration panel is mounted]	Check for anything getting in the way of rotating the filter (e.g. the filter comes off or the drive gear is clogged with foreign matters).
AH - 07	Damper rotation error [when the self-cleaning decoration panel is mounted]	The damper does not rotate normally. Check for any foreign matters around the damper and for the operation of the gear and limit switch.
AH - 08	Filter self-cleaning operation error [when the self-cleaning decoration panel is mounted]	The unit has not yet completed the filter self-cleaning operation even after the lapse of specified period of time. Check for any external noise, etc.
AH - 09	Filter self-cleaning operation start disabled error [when the self-cleaning decoration panel is mounted]	The unit has been put into a state in which the filter self-cleaning operation is disabled. Check the unit for the operating conditions.
C6 - 01	Faulty combination of indoor unit PCB and fan PCB	A combination of indoor unit PCB and fan PCB is defective. Check whether the capacity setting adaptor is correct and the type of the fan PCB is correct.

### 4.4 Outdoor Unit

♡: ON, ●: OFF, ♦: Blinks

Green: Blinks in normal condition Red: OFF in normal condition

Outdoor Unit LED Indication				Error Codes	Description	Reference		
Green							Page	
Α	1	2	3	4	5★			
•		•	•	•	•	88	Normal condition	_
						UR	Unspecified voltage (between indoor unit and outdoor unit)	301
						UH	Anti-icing function in other rooms	301
<b>Φ</b>	•	•	≎	≎	•	(UD)	Refrigerant shortage	296
<b>Φ</b>	₽	•	•	₽	•	ue ue	Low-voltage detection or over-voltage detection	298
•	•	≎	♡	≎	•	un	Signal transmission error (on outdoor unit PCB)	300
◑	⇔	•	≎	≎	•	85	Anti-icing function	302
◑	⇔	≎	≎	•	•	ε:	Outdoor unit PCB abnormality	304
♦	♡	•	≎	•	•	(£5)	OL activation (compressor overload)	305
⊅	•	≎	≎	•	•	(88)	Compressor lock	306
♦	≎	≎	≎	≎	•	87	DC fan lock	307
♦	•	≎	•	≎	•	88	Input overcurrent detection	308
♦	≎	•	≎	•	•	83	Discharge pipe temperature control	309
⊅	♡	•	≎	≎	•	88	High pressure control in cooling	310
⊅	♡	≎	•	•	•	HG	Compressor sensor system abnormality	311
						H8	Position sensor abnormality	313
						H8	CT or related abnormality	315
						XS	Outdoor temperature thermistor or related abnormality	317
						J3	Discharge pipe thermistor or related abnormality	317
						JS	Outdoor heat exchanger thermistor or related abnormality	317
						J8	Liquid pipe thermistor or related abnormality	317
						J3	Gas pipe thermistor or related abnormality	317
						py	Radiation fin thermistor or related abnormality	317
⊅	≎	≎	•	≎	•	13	Electrical box temperature rise	319
<b>(</b>	•	•	•	≎	•	14	Radiation fin temperature rise	321
•	•	•	≎	•	•	LS	Output overcurrent detection	323



- 1. The error codes in the parenthesis ( ) are displayed only when the system is shut down.
- 2. When a sensor error occurs, check the remote controller display to determine which sensor is malfunctioning.

If the remote controller does not indicate the error code, conduct the following procedure.


- \* Turn the power switch off and back on again. If the same LED indication appears again immediately after the power is turned on, the fault is in the thermistor.
- \* If the above condition does not result, the fault is in the CT.
- 3. The indoor unit error code may take the precedence in the remote controller display.
- 4. ★ 3-room models and 4-room models do not have LED5.

## 5. Troubleshooting for RA Indoor Unit - FTXG, FTXS, CTXS, FVXG, FVXS, FLXS, FDXS Series

## 5.1 Indoor Unit PCB Abnormality

Remote Controller Display	8:
Method of Malfunction Detection	The system checks if the circuit works properly within the microcomputer of the indoor unit.
Malfunction Decision Conditions	The system cannot set the internal settings.
Supposed Causes	<ul> <li>Wrong models interconnected</li> <li>Defective indoor unit PCB</li> <li>Disconnection of connector</li> <li>Reduction of power supply voltage</li> </ul>

#### **Troubleshooting**



Note:

Check the following connector.

Model Type	Connector
Wall mounted type	Terminal board ~ Control PCB
Floor standing type	Terminal board ~ Control PCB
Floor / ceiling suspended dual type	S36 ~ S37
Duct connected type	Terminal board ~ Control PCB

## 5.2 Freeze-up Protection Control or Heating Peak-cut Control

#### Remote Controller Display

85

## Method of Malfunction Detection

■ Freeze-up protection control

During cooling operation, the freeze-up protection control (operation halt) is activated

according to the temperature detected by the indoor heat exchanger thermistor.

■ Heating peak-cut control

During heating operation, the temperature detected by the indoor heat exchanger thermistor is used for the heating peak-cut control (operation halt, outdoor fan stop, etc.)

#### Malfunction Decision Conditions

■ Freeze-up protection control

During cooling operation, the indoor heat exchanger temperature is below 0°C.


Heating peak-cut control
 During heating operation, the indoor heat exchanger temperature is above 65°C.

## Supposed Causes

- Short-circuited air
- Clogged air filter of the indoor unit
- Dust accumulation on the indoor heat exchanger
- Defective indoor heat exchanger thermistor
- Defective indoor unit PCB

#### **Troubleshooting**





## 5.3 Fan Motor or Related Abnormality

### 5.3.1 DC Motor (Wall Mounted Type, Floor Standing Type)

Remote
Controller
Display

25

## Method of Malfunction Detection

The rotation speed detected by the Hall IC during fan motor operation is used to determine abnormal fan motor operation.

#### Malfunction Decision Conditions

The detected rotation speed does not reach the demanded rotation speed of the target tap, and is less than 50% of the maximum fan motor rotation speed.

## Supposed Causes


- Disconnection of connector
- Foreign matters stuck in the fan
- Layer short inside the fan motor winding
- Breaking of wire inside the fan motor
- Breaking of the fan motor lead wires
- Defective capacitor of the fan motor
- Defective indoor unit PCB

#### **Troubleshooting**

## Check No.02 Refer to P.326

FTXG, FTXS-J, FTXS-G, FVXG, FVXS Series

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




(R16048)

#### **Troubleshooting**



#### FTXS-K, CTXS-K Series



## 5.3.2 AC Motor (Duct Connected Type, Floor / Ceiling Suspended Dual Type)

Remote Controller Display 85

Method of Malfunction Detection

The rotation speed detected by the Hall IC during fan motor operation is used to determine abnormal fan motor operation.

Malfunction Decision Conditions The detected rotation speed does not reach the demanded rotation speed of the target tap, and is less than 50% of the maximum fan motor rotation speed.


# Supposed Causes

- Layer short inside the fan motor winding
- Breaking of wire inside the fan motor
- Breaking of the fan motor lead wires
- Defective capacitor of the fan motor
- Defective indoor unit PCB

### **Troubleshooting**



Check No.04 Refer to P.327 Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



# 5.4 Radiant Panel Temperature Rise, Indoor Electronic Expansion Valve (Motor Operated Valve) Abnormality, Freeze-up Protection Control (FVXG Series Only)

Remote Controller Display 83

# Method of Malfunction Detection

#### Radiant panel temperature rise

During RADIANT operation, high temperature control (e.g., operation halt, indoor electronic expansion valve closure) is activated according to the temperature detected by the radiant panel thermistors.

#### Indoor electronic expansion valve abnormality

- The indoor electronic expansion valve is required to be fully closed during cooling, dry or heating operation. When the indoor electronic expansion valve is open due to malfunction, the refrigerant flows into the radiant panel and the radiant panel temperature rises or drops.
- The indoor electronic expansion valve is required to be open during RADIANT operation. When the indoor electronic expansion valve is closed due to malfunction, the refrigerant does not flow into the radiant panel and the radiant panel temperature does not rise.
- For multi system

The indoor electronic expansion valve is required to be fully closed in the room where the system does not run. When the indoor electronic expansion valve is open due to malfunction and heating or RADIANT operation is conducted in the other room(s), the refrigerant flows into the radiant panel and the radiant panel temperature rises.

### Freeze-up protection control

The temperature detected by the radiant panel thermistors is used to prevent the indoor unit from freezing during cooling operation.

## Malfunction Decision Conditions

#### Radiant panel temperature rise

The radiant panel surface temperature calculated by the radiant panel thermistors is above 70°C

#### Indoor electronic expansion valve abnormality

- During cooling or dry operation, the temperature detected by the radiant panel thermistor (∮ 4) has dropped.
- lacktriangle During heating operation, the temperature detected by the radiant panel thermistor ( $\phi$  4) has risen
- During RADIANT operation, the temperature detected by the radiant panel thermistor (φ 4) does not rise.
- For multi system

While the system does not run and heating or RADIANT operation is conducted in the other room(s), the temperature detected by the radiant panel thermistor ( $\phi$  4) has risen.

#### Freeze-up protection control

During cooling operation, the operation stops when the temperature detected by the radiant panel thermistor ( $\phi$  4) has dropped.

# Supposed Causes

- Clogged air filter of the indoor unit
- Dust accumulation on the indoor heat exchanger
- Short-circuited air
- Defective radiant panel thermistor(s)
- Defective indoor heat exchanger thermistor
- Defective room temperature thermistor
- Defective indoor electronic expansion valve (or coil)

278


## **Troubleshooting**



Check No.01 Refer to P.325



Check No.06 Refer to P.327



#### **Thermistor or Related Abnormality (RA Indoor Unit)** 5.5

Remote Controller **Display** 

E4, E8, E8

**Method of** Malfunction **Detection** 

The temperatures detected by the thermistors are used to determine thermistor errors.

Malfunction **Decision Conditions** 

The thermistor input is more than 4.96 V or less than 0.04 V during compressor operation.


**Supposed Causes** 

- Disconnection of connector
- Defective thermistor
- Defective indoor unit PCB

#### **Troubleshooting**



Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



धः Indoor heat exchanger thermistor £3: Room temperature thermistor

E: Radiant panel thermistor (FVXG series only)

## 5.6 Front Panel Open / Close Fault (FTXG Series Only)

Remote Controller Display Method of Malfunction Detection


Malfunction Decision Conditions

■ If the error repeats, the system is shut down.

# Supposed Causes

- Defective reduction motor
- Malfunction or deterioration of the front panel mechanism
- Defective limit switch

## **Troubleshooting**



(R17249)

Note

You cannot operate the unit by the remote controller when the front panel mechanism breaks down.

<To the dealers: temporary measure before repair>

- 1. Turn off the power.
- 2. Remove the front panel.
- Turn on the power.(Wait until the initialization finishes.)
- 4. Operate the unit by the indoor unit [ON/OFF] button.

# 5.7 Signal Transmission Error (between Indoor Unit and Outdoor Unit)

Remote Controller Display !!'-!

Method of Malfunction Detection

The data received from the outdoor unit in indoor unit-outdoor unit signal transmission is checked whether it is normal.

Malfunction Decision Conditions

The data sent from the outdoor unit cannot be received normally, or the content of the data is abnormal.

# Supposed Causes


- Wiring error
- Breaking of the connection wires between the indoor and outdoor units (wire No. 3)
- Defective outdoor unit PCB
- Defective indoor unit PCB
- Disturbed power supply waveform

#### **Troubleshooting**





Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



(R15782)

# 5.8 Unspecified Voltage (between Indoor Unit and Outdoor Unit)

## Remote Controller Display

## Method of Malfunction Detection

The supply power is detected for its requirements (different from pair type and multi type) by the indoor / outdoor transmission signal.


## Malfunction Decision Conditions

The pair type and multi type are interconnected.

# Supposed Causes

- Wrong models interconnected
- Wrong wiring of connecting wires
- Wrong indoor unit PCB or outdoor unit PCB mounted
- Defective indoor unit PCB
- Defective outdoor unit PCB

## **Troubleshooting**



# 6. Troubleshooting for SA Indoor Unit - FCQG, FFQ, FHQ, FDBQ, FBQ Series

## 6.1 Indoor Unit PCB Abnormality

Remote Controller Display 8:

Method of Malfunction Detection

The system checks the data from EEPROM.


Malfunction Decision Conditions When the data from the EEPROM is not received correctly


EEPROM (Electrically Erasable Programmable Read Only Memory): A memory chip that holds its content without power. It can be erased, either within the computer or externally and usually requires more voltage for erasure than the common +5 volts used in logic circuits. It functions like non-volatile RAM, but writing to EEPROM is slower than writing to RAM.

Supposed Causes

Defective indoor unit PCB

## **Troubleshooting**





(R11294)

## 6.2 Drain Water Level System Abnormality

Remote Controller Display 83

Method of Malfunction Detection


The float switch detects error.

Malfunction Decision Conditions When the water level reaches its upper limit and when the float switch turns OFF

Supposed Causes

- Defective drain pump
- Improper drain piping work
- Clogged drain piping
- Defective float switch
- Defective indoor unit PCB
- Defective short circuit connector X15A on indoor unit PCB

## **Troubleshooting**



(R17250)

Note:

If 83 is detected by the indoor unit PCB which is not mounted with X15A, the indoor unit PCB is defective.

## 6.3 Fan Motor or Related Abnormality

Remote Controller Display 85

Method of Malfunction Detection

The signal from the fan motor detects abnormal fan speed.

Malfunction Decision Conditions When the fan rotations are not detected while the output voltage to the fan is at its maximum

# Supposed Causes


- Defective indoor fan motor
- Broken or disconnected wire
- Defective contact
- Defective indoor unit PCB

## **Troubleshooting**

## FCQC, FFQ, FDBQ, FBQ Series



Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




(R11296)

## **Troubleshooting**

#### **FHQ Series**

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



Note: There is a possibility of open phase power supply, also check the power supply.

## 6.4 Swing Motor Lock (FHQ Series Only)

Remote Controller Display 87


Method of Malfunction Detection The error is detected by the limit switch when the motor turns.

Malfunction Decision Conditions When the ON/OFF micro-switch for position detection cannot be reversed even though the swing motor is energized for a specified amount of time (about 30 seconds).

Supposed Causes

- Defective swing motor
- Defective micro-switch
- Disconnection of connector
- Defective indoor unit PCB

## **Troubleshooting**



(R16022)

## 6.5 Drain System Abnormality

## Remote Controller Display

## Method of Malfunction Detection

Water leakage is detected based on the float switch ON/OFF changeover while the compressor is not operating.

## Malfunction Decision Conditions


When the float switch changes from ON to OFF while the compressor is OFF

# Supposed Causes

- Error in the drain pipe installation
- Defective float switch
- Defective indoor unit PCB

## **Troubleshooting**

Be sure to turn off the power switch before connecting or disconnecting Caution connectors, or parts may be damaged. Are the float switch and NO The float switch may be the drain pipe normal? defective. Check if the drain-up height and the horizontal pipe length YES exceed the specifications. Is the NO water drain system normal? Clogged water drain system, clogged drain pump, or faulty float switch YES Replace the indoor unit PCB. Check if the drain-up height and the horizontal pipe length exceed the specifications.



## 6.6 Thermistor or Related Abnormality (SA Indoor Unit)

Remote Controller Display Method of Malfunction Detection

The temperatures detected by the thermistors determine thermistor errors.

Malfunction Decision Conditions

The thermistor input is more than 4.96 V or less than 0.04 V during compressor operation.

Supposed Causes

- Disconnection of connector
- Defective thermistor
- Defective indoor unit PCB

## **Troubleshooting**

If the cause of the problem is related to the thermistors, the thermistors should be checked prior to changing the indoor unit PCB.

Check No.01 Refer to P.325


To check the thermistors, proceed as follows:

Step	Action
1	Disconnect the thermistor from the indoor unit PCB.
2	Read the temperature and the resistance value.
3	Check if the measured values correspond with the values in the table of thermistor resistance check.



aution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



६४ : Indoor heat exchanger thermistor (R2T, R3T)

£3: Room temperature thermistor (R1T)

## 6.7 Remote Controller Thermistor Abnormality

## Remote Controller Display

*:* -.

# Method of Malfunction Detection

Even if remote controller thermistor is faulty, system is possible to operate by system thermistor. Malfunction detection is carried out by the temperature detected by remote controller thermistor.

## Malfunction Decision Conditions

When the remote controller thermistor becomes disconnected or shorted while the unit is running.


# Supposed Causes

- Defective thermistor
- Broken wire

## **Troubleshooting**



Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



(R17252)



To delete the record of error codes, press the [ON/OFF] button for 4 seconds or more while the error code is displayed in the inspection mode.

# 6.8 Signal Transmission Error (between Indoor Unit and Remote Controller)

Remote Controller Display 115

Method of Malfunction Detection

Microcomputer checks if transmission between indoor unit and remote controller is normal.


Malfunction Decision Conditions

Normal transmission does not continue for specified period.

Supposed Causes

- Connection of 2 main remote controllers (when using 2 remote controllers)
- Defective indoor unit PCB
- Defective remote controller
- Transmission error caused by noise

## **Troubleshooting**



# 6.9 Signal Transmission Error (between MAIN Remote Controller and SUB Remote Controller)

## Remote Controller Display

# Method of Malfunction Detection

In case of controlling with 2 remote controllers, check the system using micro-computer if signal transmission between indoor unit and remote controller (main and sub) is normal.


## Malfunction Decision Conditions

Normal transmission does not continue for specified period.

# Supposed Causes

- Remote controller is set to "SUB" when using 1 remote controller
- Connection of 2 sub remote controllers (when using 2 remote controllers)
- Defective remote controller PCB

## **Troubleshooting**



## 6.10 Field Setting Abnormality


Remote Controller Display Method of Malfunction Detection

Malfunction Decision Conditions Incorrect field setting

## Supposed Causes

- Defective indoor unit PCB
- Defective outdoor unit PCB
- Defective power supply PCB
- Indoor-outdoor, indoor-indoor unit transmission wiring
- Defective remote controller wiring

## **Troubleshooting**



(R17253)

# 7. Troubleshooting for Outdoor Unit

## 7.1 Refrigerant Shortage

Remote Controller Display 111

Outdoor Unit LED Display

A **(1)** 1 **(0)** 2 **(0)** 3 **(2)** 4 **(3)** 5 **(0)** 

Method of Malfunction Detection

#### Refrigerant shortage detection I:

Refrigerant shortage is detected by checking the input current value and the compressor output frequency. If the refrigerant is short, the input current is smaller than the normal value.

#### Refrigerant shortage detection II:

Refrigerant shortage is detected by checking the discharge pipe temperature and the opening of the outdoor electronic expansion valve. If the refrigerant is short, the discharge pipe temperature tends to rise.

Malfunction Decision Conditions

## Refrigerant shortage detection I:

The following conditions continue for 7 minutes.

- DC current ≤ A × Compressor output frequency + B
- Output frequency > C

	<b>A</b> (–)	<b>B</b> (A)	C (Hz)
40/50/52/58 class	0.01	0.3	54
68/75 class	0.035	0.5	55
80/90 class	0.027	2.0	40

#### Refrigerant shortage detection II:

The following conditions continue for 80 seconds.

- Opening of the outdoor electronic expansion valve ≥ D
- ◆ Discharge pipe temperature > **E** × target discharge pipe temperature + **F**

	<b>D</b> (pulse)	<b>E</b> (–)	F (°C)
Cooling	450	255/256	20
Heating			40

- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 60 minutes without any other error

# Supposed Causes

- Disconnection of the discharge pipe thermistor, indoor or outdoor heat exchanger thermistor, room or outdoor temperature thermistor
- Closed stop valve
- Refrigerant shortage (refrigerant leakage)
- Poor compression performance of compressor
- Defective outdoor electronic expansion valve


## **Troubleshooting**



Check No.01 Refer to P.325



Check No.12 Refer to P.329



(R17254)

Completed.

## 7.2 Low-voltage Detection or Over-voltage Detection

Remote Controller Display Outdoor Unit LED Display

Method of Malfunction Detection

## **★** Indoor Unit

The zero-cross detection of the power supply is evaluated by the indoor unit PCB.

#### **★** Outdoor Unit

## Low-voltage detection:

An abnormal voltage drop is detected by the DC voltage detection circuit.

## Over-voltage detection:

An abnormal voltage rise is detected by the over-voltage detection circuit.

## Malfunction Decision Conditions

#### **★ Indoor Unit**

There is no zero-cross detection in approximately 10 seconds.

#### **★ Outdoor Unit**

#### Low-voltage detection:

- The voltage detected by the DC voltage detection circuit is below 150 V for 0.1 second.
- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 60 minutes without any other error


#### Over-voltage detection:

- An over-voltage signal is fed from the over-voltage detection circuit to the microcomputer.
- The compressor stops if the error occurs, and restarts automatically after 3-minute standby.

# Supposed Causes

- Supply voltage is not as specified.
- Defective DC voltage detection circuit
- Defective over-voltage detection circuit
- Defective PAM control part
- Disconnection of compressor harness
- Noise
- Momentary fall of voltage
- Momentary power failure
- Defective indoor unit PCB

## **Troubleshooting**



## 7.3 Signal Transmission Error (on Outdoor Unit PCB)

Remote Controller Display 1117

Outdoor Unit LED Display

Method of Malfunction Detection

Communication error between microcomputer mounted on the main PCB and PM1.

Malfunction Decision Conditions

- The abnormality is determined when the data sent from the PM1 can not be received for 9 seconds.
- The error counter is reset when the data from the PM1 can be successfully received.


Supposed Causes

■ Defective outdoor unit PCB

## **Troubleshooting**

Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



(R7185)

# 7.4 Unspecified Voltage (between Indoor Unit and Outdoor Unit) / Anti-icing Function in Other Rooms

Remote Controller Display UR, UK

Outdoor Unit LED Display

 $A \diamondsuit 1 \bullet 2 \bullet 3 \bullet 4 \bullet 5 \bullet$ 

Method of Malfunction Detection

A wrong connection is detected by checking the combination of indoor and outdoor units on the microcomputer.


Malfunction Decision Conditions

- Anti-icing function in other rooms
- Unspecified internal and/or external voltages
- Mismatching of indoor and outdoor units

Supposed Causes

- Anti-icing function in other rooms
- Wrong models interconnected
- Wrong indoor unit PCB or outdoor unit PCB mounted

## **Troubleshooting**



Note:

Refer to "Anti-icing function" on page 302 for detail.

## 7.5 Anti-icing Function

Remote Controller Display 212

Outdoor Unit LED Display

Method of Malfunction Detection

During cooling operation, indoor unit icing is detected by checking the temperatures sensed by the indoor heat exchanger thermistor and room temperature thermistor that are located in a shut-down room.

## Malfunction Decision Conditions

- In cooling operation, the both conditions (A) and (B) are met for 5 minutes.
  - (A) Room temperature Indoor heat exchanger temperature ≥ 10°C
  - (B) Indoor heat exchanger temperature  $\leq -1^{\circ}$ C
- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 60 minutes without any other error

# Supposed Causes

- Wrong wiring or piping
- Defective outdoor electronic expansion valve
- Short-circuited air
- Defective indoor heat exchanger thermistor
- Defective room temperature thermistor


## **Troubleshooting**



Check No.01 Refer to P.325



Check No.12 Refer to P.329



## 7.6 Outdoor Unit PCB Abnormality

Remote Controller Display ۶

Outdoor Unit LED Display



Method of Malfunction Detection


Detect within the program of the microcomputer.

Malfunction Decision Conditions The program of the microcomputer is in abnormal running order.

Supposed Causes

- Defective outdoor unit PCB
- Noise
- Momentary fall of voltage
- Momentary power failure

## **Troubleshooting**



(R7183)

## 7.7 OL Activation (Compressor Overload)

Remote Controller Display <u>ES</u>

# Outdoor Unit LED Display

 $A \diamondsuit 1 \diamondsuit 2 \bullet 3 \diamondsuit 4 \bullet 5 \bullet$ 

Method of Malfunction Detection

A compressor overload is detected through compressor OL.

## Malfunction Decision Conditions

- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 60 minutes without any other error
- \* The operating temperature condition is not specified.

# Supposed Causes

- Defective discharge pipe thermistor
- Defective outdoor electronic expansion valve or coil
- Defective four way valve or coil
- Defective outdoor unit PCB
- Refrigerant shortage
- Water mixed in refrigerant
- Defective stop valve

### **Troubleshooting**



Check No.01 Refer to P.325




Check No.12 Refer to P.329




Check No.13 Refer to P.330



Check No.14 Refer to P.330





## 7.8 Compressor Lock

Remote Controller Display 88

Outdoor Unit LED Display

 $A \diamondsuit 1 \bullet 2 \diamondsuit 3 \diamondsuit 4 \bullet 5 \bullet$ 

Method of Malfunction Detection

A compressor lock is detected by checking the compressor running condition through the position detection circuit.

Malfunction Decision Conditions

- Judging from the current waveform generated when high-frequency voltage is applied to the compressor.
- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 5 minutes without any other error

Supposed Causes

- Compressor locked
- Compressor harness disconnected


## **Troubleshooting**



!\ Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.

(Precaution before turning on the power again)
Make sure the power has been off for at least 30 seconds.



## 7.9 DC Fan Lock

Remote Controller Display Ęſ

Outdoor Unit LED Display

Method of Malfunction Detection

An error is determined with the high-voltage fan motor rotation speed detected by the Hall IC.

Malfunction Decision Conditions


- The fan does not start in 30 seconds even when the fan motor is running.
- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 5 minutes without any other error

Supposed Causes

- Disconnection of the fan motor
- Foreign matter stuck in the fan
- Defective fan motor
- Defective outdoor unit PCB

## **Troubleshooting**





## 7.10 Input Overcurrent Detection

Remote Controller Display 88

Outdoor Unit LED Display

A **♦** 1 **●** 2 **♦** 3 **●** 4 **♦** 5 **●** 

Method of Malfunction Detection

Detected by checking the input current value

Malfunction Decision Conditions

- The input current is at a certain value (depending on the condition) for 2.5 seconds.
- The compressor halts if the error occurs, and restarts automatically after 3-minute standby.

## Supposed Causes

- Outdoor temperature is out of operation range.
- Defective compressor
- Defective power module
- Defective outdoor unit PCB
- Short circuit

#### **Troubleshooting**



Check No.15 Refer to P.331




Check No.17 Refer to P.333



Check No.18 Refer to P.333 Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.

\* An input overcurrent may result from wrong internal wiring. If the system is interrupted by an input overcurrent after the wires have been disconnected and reconnected for part replacement, check the wiring again.



## 7.11 Discharge Pipe Temperature Control

Remote Controller Display 7

Outdoor Unit LED Display

 $A \diamondsuit 1 \diamondsuit 2 \bullet 3 \diamondsuit 4 \bullet 5 \bullet$ 

Method of Malfunction Detection

Detected by the discharge pipe thermistor

## Malfunction Decision Conditions

- If the temperature detected by the discharge pipe thermistor rises above A °C, the compressor stops.
- The error is cleared when the discharge pipe temperature is dropped below **B** °C.

	A (°C)	B (°C)
40/50/52/58 class	110	95
68/75/80/90 class	120	107

- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 60 minutes without any other error

# Supposed Causes

- Defective discharge pipe thermistor
   (Defective outdoor heat exchanger thermistor or outdoor temperature thermistor)
- Defective outdoor electronic expansion valve or coil
- Refrigerant shortage
- Defective four way valve
- Water mixed in refrigerant
- Defective stop valve
- Defective outdoor unit PCB

## **Troubleshooting**




Check No.01 Refer to P.325



Check No.12 Refer to P.329



Check No.14 Refer to P.330 Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



## 7.12 High Pressure Control in Cooling

Remote Controller Display 55

# Outdoor Unit LED Display

Method of Malfunction Detection High-pressure control (operation halt, frequency drop, etc.) is activated in cooling mode if the temperature sensed by the outdoor heat exchanger thermistor exceeds the limit.

## Malfunction Decision Conditions

- The temperature sensed by the outdoor heat exchanger thermistor rises above about 65°C.
- The error is cleared when the temperature drops below about 50°C.

# Supposed Causes

- The installation space is not large enough.
- Dirty outdoor heat exchanger
- Defective outdoor fan motor
- Defective stop valve
- Defective outdoor electronic expansion valve or coil
- Defective outdoor heat exchanger thermistor
- Defective outdoor unit PCB

## **Troubleshooting**



Check No.01 Refer to P.325



Check No.12 Refer to P.329




Check No.17 Refer to P.333



Check No.18 Refer to P.333



Check No.19 Refer to P.334



(R14413)

## 7.13 Compressor Sensor System Abnormality

Remote Controller Display 

# Outdoor Unit LED Display



# Method of Malfunction Detection

- Fault condition is identified by the supply voltage and the DC voltage which is detected before the compressor startup.
- Fault condition is identified by the compressor current which is detected right after the compressor startup.
- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 5 minutes without any other error


## Malfunction Decision Conditions

- The detected value of the supply voltage and the DC voltage is obviously low or high.
- The compressor current does not run when the compressor is started.

# Supposed Causes

- Disconnection of reactor
- Disconnection of compressor harness
- Defective outdoor unit PCB
- Defective compressor

## **Troubleshooting**



# 7.14 Position Sensor Abnormality

Remote Controller Display Outdoor Unit LED Display

A ♦ 1 ♦ 2 ♦ 3 ● 4 ● 5 ●

Method of Malfunction Detection

A compressor startup failure is detected by checking the compressor running condition through the position detection circuit.

Malfunction Decision Conditions

- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 5 minutes without any other error

Supposed Causes

- Disconnection of the compressor relay cable
- Defective compressor
- Defective outdoor unit PCB
- Start-up failure caused by the closed stop valve
- Input voltage is outside the specified range.


#### **Troubleshooting**



Check No.15 Refer to P.331



Check No.18 Refer to P.333



# 7.15 CT or Related Abnormality

Remote Controller Display Outdoor Unit LED Display

A **♦** 1 **♦** 2 **♦** 3 **●** 4 **●** 5 **●** 

Method of Malfunction Detection

A CT or related error is detected by checking the compressor running frequency and CT-detected input current.

Malfunction Decision Conditions ■ The compressor running frequency is more than A Hz and input current is less than B A.

	<b>A</b> (Hz)	<b>B</b> (A)
40/50/52/58/68/75 class	55	0.5
80/90 class	32	0.5

- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 60 minutes without any other error

Supposed Causes

- Defective power module
- Broken or disconnected wiring
- Defective reactor
- Defective outdoor unit PCB


#### **Troubleshooting**



Check No.15 Refer to P.331



Check No.21 Refer to P.334



## 7.16 Thermistor or Related Abnormality (Outdoor Unit)

Remote Controller Display <del>48, 43, 46, 48, 48, 84</del>

# Outdoor Unit LED Display

# Method of Malfunction Detection

This type of error is detected by checking the thermistor input voltage to the microcomputer. A thermistor error is detected by checking the temperature sensed by each thermistor.

#### Malfunction Decision Conditions

- The thermistor input is above 4.96 V or below 0.04 V with the power on.
- 3 error is judged if the discharge pipe temperature is lower than the heat exchanger temperature.
- The system is shut down if all the units are judged as the d8 error.

# Supposed Causes

- Disconnection of the connector for the thermistor
- Defective thermistor corresponding to the error code
- Defective heat exchanger thermistor in the case of 🗗 error (outdoor heat exchanger thermistor in cooling operation, or indoor heat exchanger thermistor in heating operation)
- Defective outdoor unit PCB

#### **Troubleshooting**

#### In case of PY




Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.

Replace the outdoor unit PCB.

৪৭ : Radiation fin thermistor

#### **Troubleshooting**

Check No.01 Refer to P.325 In case of 89, 43, 48, 48, 49



(R17164)

**83**: Outdoor temperature thermistor

এ3 : Discharge pipe thermistor

48 : Liquid pipe thermistor

਼ Gas pipe thermistor

# 7.17 Electrical Box Temperature Rise

Remote Controller Display 13

Outdoor Unit LED Display

 $A \diamondsuit 1 \diamondsuit 2 \diamondsuit 3 \bullet 4 \diamondsuit 5 \bullet$ 

Method of Malfunction Detection

An electrical box temperature rise is detected by checking the radiation fin thermistor with the compressor off.

Malfunction Decision Conditions

- With the compressor off, the radiation fin temperature is above **A** °C.
- The error is cleared when the temperature drops below B °C.
- To cool the electrical components, the outdoor fan starts when the radiation fin temperature rises above **C** °C and stops when it drops below **B** °C.

<b>A</b> (°C)	<b>B</b> (°C)	<b>C</b> (°C)
100	70	85

# Supposed Causes


- Defective outdoor fan motor
- Short circuit
- Defective radiation fin thermistor
- Disconnection of connector
- Defective outdoor unit PCB

#### **Troubleshooting**

Check No.17 Refer to P.333



Check No.19 Refer to P.334



<b>A</b> (°C)	<b>B</b> (°C)	<b>C</b> (°C)
100	70	85

# 7.18 Radiation Fin Temperature Rise

Remote Controller Display 14

# Outdoor Unit LED Display

 $A \diamondsuit 1 \bullet 2 \bullet 3 \bullet 4 \diamondsuit 5 \bullet$ 

Method of Malfunction Detection

A radiation fin temperature rise is detected by checking the radiation fin temperature with the compressor on.

#### Malfunction Decision Conditions

- The radiation fin temperature with the compressor on is above **A** °C.
- The error is cleared when the temperature drops below **B** °C

	<b>A</b> (°C)	<b>B</b> (°C)
40/50/52/58/68/75 class	103	95
80/90 class	105	97

- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 60 minutes without any other error

# Supposed Causes

- Defective outdoor fan motor
- Short circuit
- Defective radiation fin thermistor
- Disconnection of connector
- Defective outdoor unit PCB
- Silicon grease is not applied properly on the radiation fin after replacing the outdoor unit PCB.

#### **Troubleshooting**




Check No.17 Refer to P.333



Check No.19 Refer to P.334



Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



	<b>A</b> (°C)
40/50/52/58/68/75 class	103
80/90 class	105



Refer to "Application of silicon grease to a power transistor and a diode bridge" on page 423 for detail.

# 7.19 Output Overcurrent Detection

Remote Controller Display 15

Outdoor Unit LED Display

 $A \diamondsuit 1 \bullet 2 \bullet 3 \diamondsuit 4 \bullet 5 \bullet$ 

Method of Malfunction Detection

An output overcurrent is detected by checking the current that flows in the inverter DC section.

#### Malfunction Decision Conditions

- A position signal error occurs while the compressor is running.
- A speed error occurs while the compressor is running.
- An output overcurrent signal is fed from the output overcurrent detection circuit to the microcomputer.
- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 5 minutes without any other error

# Supposed Causes

- Poor installation condition
- Closed stop valve
- Defective power module
- Wrong internal wiring
- Abnormal power supply voltage
- Defective outdoor unit PCB
- Defective compressor

#### **Troubleshooting**



Check No.15 Refer to P.331



Check No.17 Refer to P.333



Check No.18 Refer to P.333




Check No.22 Refer to P.335



Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.

\* An output overcurrent may result from wrong internal wiring. If the system is interrupted by an output overcurrent after the wires have been disconnected and reconnected for part replacement, check the wiring again.



SiBE121135 Check

## 8. Check

## 8.1 Thermistor Resistance Check

#### Check No.01


Disconnect the connectors of the thermistors from the PCB, and measure the resistance of each thermistor using tester.

The relationship between normal temperature and resistance is shown in the table and the graphs below.

The data is for reference purpose only.

	Resistance (kΩ)		
Thermistor temperature (°C)	Room temperature thermistor for FTXS-K and CTXS-K series	Other thermistors	
-20	70.3	197.8	
-15	56.1	148.2	
-10	44.1	112.1	
<b>-</b> 5	34.9	85.60	
0	28.2	65.93	
5	22.3	51.14	
10	18.1	39.99	
15	14.8	31.52	
20	12.2	25.02	
25	10.0	20.00	
30	8.3	16.10	
35	6.9	13.04	
40	5.8	10.62	
45	4.9	8.707	
50	4.1	7.176	

 $(R25^{\circ}C=10~k\Omega,~B=3435~K)~~(R25^{\circ}C=20~k\Omega,~B=3950~K)$ 



- The room temperature thermistor is directly mounted on the display PCB. Remove the display PCB from the control PCB to measure the resistance.
- When the indoor heat exchanger thermistor is soldered on the PCB, remove the thermistor and measure the resistance.


Check SiBE121135

#### 8.2 Fan Motor Connector Check

#### Check No.02

#### FTXG, FTXS-J, FTXS-G, FVXG, FVXS Series


- 1. Check the connection of connector.
- 2. Check motor power supply voltage output (pins 4 7).
- 3. Check motor control voltage (pins 4 3).
- 4. Check rotation command voltage output (pins 4 2).
- 5. Check rotation pulse input (pins 4 1).



#### Check No.03

#### FTXS-K, CTXS-K Series

- Fan motor wire breakdown / short circuit check
- 1. Check the connector for connection.
- 2. Turn the power off.
- 3. Check if each resistance at the phases U V and V W is 90  $\Omega$  ~ 100  $\Omega$  (between the pins 12 9, and between 9 6).
- Motor control voltage check
- 1. Check the connector for connection.
- 2. Check the motor control voltage is generated (between the pins 2 3).
- Rotation pulse check
- 1. Check the connector for connection.
- 2. Turn the power on and stop the operation.
- 3. Check if the Hall IC generates the rotation pulse 4 times when the fan motor is manually rotated once (between the pins 1 3).



SiBE121135 Check

#### 8.3 Hall IC Check

#### Check No.04


#### **FLXS, FDXS Series**

- 1. Check the connector connection.
- 2. With the power on, operation off, and the connector connected, check the following.
  - \*Output voltage of about 5 V between pins 1 and 3.
  - \*Generation of 3 pulses between pins 2 and 3 when the fan motor is operating.

If NG in step 1  $\rightarrow$  Defective PCB  $\rightarrow$  Replace the PCB.

If NG in step 2 → Defective Hall IC → Replace the fan motor.

If OK in both steps 1 and 2  $\rightarrow$  Replace the PCB.




# 8.4 Indoor Electronic Expansion Valve Coil Check

#### Check No.06

Conduct the followings to check the indoor electronic expansion valve coil (EV).

- 1. Check to see if the EV connector is correctly connected to the PCB.
- 2. Turn the power off and on again, and check to see if the EV generate latching sound.
- 3. If the EV does not generate latching sound in the above step 2, disconnect the connector and check the continuity using a tester.
- 4. Check the continuity between the pins 1 6, 2 6, 3 6, and 4 6. If there is no continuity between the pins, the EV coil is faulty.



5. If the continuity is confirmed in the above step 3, the PCB is faulty.

Note: Please note that the latching sound varies depending on the valve type.

Check SiBE121135


# 8.5 Power Supply Waveform Check

#### Check No.11

Measure the power supply waveform between No. 1 and No. 2 on the terminal board, and check the waveform disturbance.

- Check to see if the power supply waveform is a sine wave (Fig.1).
- Check to see if there is waveform disturbance near the zero cross (sections circled in Fig.2)

[Fig.1] [Fig.2]



SiBE121135 Check

# 8.6 Outdoor Electronic Expansion Valve Check

#### Check No.12

Conduct the followings to check the outdoor electronic expansion valve (EV).

- 1. Check to see if the EV connector is correctly inserted in the PCB. Match the EV unit number and the connector number.
- 2. Turn the power off and on again, and check to see if all the EVs generate latching sound.
- 3. If any of the EVs does not generate latching sound in the above step 2, disconnect that connector and check the continuity using a tester.
  - Check the continuity between the pins 1 6 and 3 6, and between the pins 2 5 and 4 5. If there is no continuity between the pins, the EV coil is faulty.
- 4. If no EV generates latching sound in the above step 2, the outdoor unit PCB is faulty.
- 5. If the continuity is confirmed in the above step 3, mount a good coil (which generated latching sound) in the EV unit that did not generate latching sound, and check to see if that EV generates latching sound.
  - \*If latching sound is generated, the outdoor unit PCB is faulty.
  - \*If latching sound is not generated, the EV unit is faulty.

Note:

Please note that the latching sound varies depending on the valve type.


If the system keeps operating with a defective outdoor electronic expansion valve, the following problem may occur.


Valve opening position	Possible problem	Check method
Open	Cooling:  Flowing noise of refrigerant in the unit which is not in operation  Water leakage at the unit which is not in operation  Operation half due to anti-icing function	Reset power supply and conduct cooling operation unit by unit.  Check the liquid pipe temperature of no-operation unit.
	Heating:  Flowing noise of refrigerant in the unit which is not in operation  The unit does not heat the room.	Almost the same as the outdoor temperature?  YES  NO  The EV is not defective.  Replace the EV of the room.  (R16019)
Close	Cooling:  The problem unit does not cool the room.  Only the problem unit is in operation, the unit starts pump down.  (The low pressure of the unit becomes vacuum.)  Abnormal discharge pipe temperature	Reset power supply and conduct cooling operation unit by unit.  Check the low pressure.  Does the pressure become into vacuum zone?  NO The EV is not defective.
	Heating:  ■ Refrigerant shortage due to stagnation of liquid refrigerant inside the faulty indoor unit  ■ The unit does not heat the room.  ■ Abnormal discharge pipe temperature	YES Replace the EV of the room. (R16020)

Check SiBE121135

# 8.7 Four Way Valve Performance Check


#### **Check No.13**





# 8.8 Inverter Unit Refrigerant System Check

#### Check No.14



(R15833)

SiBE121135 Check

## 8.9 "Inverter Checker" Check

#### Check No.15

#### **■** Characteristics

If abnormal stop occurs due to compressor startup failure or overcurrent output when using an inverter unit, it is difficult to judge whether the stop is caused by the compressor failure or some other failure (control PCB, power module, etc.). The inverter checker makes it possible to judge the cause of trouble easily and securely. (Connect this checker as a quasi-compressor instead of the compressor and check the output of the inverter.)

#### Operation Method

#### Step 1


Be sure to turn the power off.

#### Step 2

Install the inverter checker instead of a compressor.

#### Note:

Make sure the charged voltage of the built-in smoothing electrolytic capacitor drops to 10 VDC or below before carrying out the service work.



#### Reference:

If the terminals of the compressor are not FASTON terminals (difficult to remove the wire on the terminals), it is possible to connect wires available on site to the outdoor unit from output side of PCB. (Do not connect them to the compressor at the same time, otherwise it may result in incorrect detection.)

#### Step 3

Activate the power transistor test operation from the outdoor unit.

- Press the forced operation [ON/OFF] switch for 5 seconds. (Refer to page 405 for the position.)
  - → Power transistor test operation starts.

Check SiBE121135

#### ■ Diagnose method (Diagnose according to 6 LEDs lighting status.)

- (1) If all the LEDs are lit uniformly, the compressor is defective.
  - → Replace the compressor.
- (2) If the LEDs are not lit uniformly, check the power module.
  - → Refer to Check No.22.
- (3) If NG in Check No.22, replace the power module.

(Replace the main PCB. The power module is united with the main PCB.)


If OK in Check No.22, check if there is any solder cracking on the PCB.

(4) If any solder cracking is found, replace the PCB or repair the soldered section. If there is no solder cracking, replace the PCB.



#### Caution

- (1) When the output frequency is low, the LEDs blink slowly. As the output frequency increases, the LEDs blink quicker. (The LEDs look like they are lit.)
- (2) On completion of the inverter checker diagnosis, be sure to re-crimp the FASTON terminals. Otherwise, the terminals may be burned due to loosening.



#### 8.10 Rotation Pulse Check on the Outdoor Unit PCB

#### Check No.16

<Outdoor fan motor>

Make sure that the voltage of 320  $\pm$  30 V is applied.


- 1. Set operation off and power off. Disconnect the connector S70.
- 2. Check that the voltage between the pins 4 7 is 320 VDC.
- 3. Check that the control voltage between the pins 3 4 is 15 VDC.
- 4. Check that the rotation command voltage between the pins 2 4 is 0 ~ 15 VDC.
- 5. Keep operation off and power off. Connect the connector S70.
- Check whether 2 pulses (0 ~ 15 VDC) are output at the pins 1 4 when the fan motor is rotated 1 turn by hand.

When the fuse is melted, check the outdoor fan motor for proper function.

If NG in step  $2 \rightarrow$  Defective PCB  $\rightarrow$  Replace the PCB.

If NG in step 4  $\rightarrow$  Defective Hall IC  $\rightarrow$  Replace the outdoor fan motor.


If OK in both steps 2 and 4  $\rightarrow$  Replace the PCB.



SiBE121135 Check


# 8.11 Installation Condition Check

#### Check No.17



# 8.12 Discharge Pressure Check

#### Check No.18




(1110700)

Check SiBE121135

# 8.13 Outdoor Fan System Check

#### Check No.19




# 8.14 Capacitor Voltage Check

#### Check No.21

Before this check, be sure to check the main circuit for short circuit.

With the circuit breaker still on, measure the voltage according to the drawing of the model in question. Be careful never to touch any live parts.



SiBE121135 Check

## 8.15 Power Module Check

#### Check No.22




Check to make sure that the voltage between (+) and (-) of the power module (PM1) is approx. 0 V before checking.

■ Disconnect the compressor harness connector from the outdoor unit PCB. To disengage the connector, press the protrusion on the connector.

■ Follow the procedure below to measure resistance between the terminals of the power module and the terminals of the compressor with a multi-tester. Evaluate the measurement results referring to the following table.

Negative (–) terminal of tester (positive terminal (+) for digital tester)	Power module (+)	UVW	Power module (–)	UVW
Positive (+) terminal of tester (negative terminal (–) for digital tester)	UVW	Power module (+)	UVW	Power module (–)
Resistance is OK.	several k $\Omega$ ~ several M $\Omega$			
Resistance is NG.	$0~\Omega$ or $\infty$			

\* The illustration is for 40/50/52/58 class as representative.



(R16074)

# Part 7 Removal Procedure

1.	Outd	loor Unit: -	40-75 Class	337
	1.1	Removal	of Outer Panels	.337
	1.2	Removal	of Electrical Box	.341
	1.3	Removal	of PCBs	.349
	1.4	Removal	of Outdoor Fan / Fan Motor	354
	1.5	Removal	of Sound Blankets	.356
	1.6	Removal	of Coils / Thermistors	360
	1.7	Removal	of Distributor	363
	1.8	Removal	of Four Way Valve	364
	1.9	Removal	of Compressor	.365
2.	Outd	loor Unit:	80/90 Class	367
	2.1		of Outer Panels	
	2.2	Removal	of Electrical Box	.382
	2.3	Removal	of PCBs	388
	2.4	Removal	of Fan Motor	.392
	2.5	Removal	of Coils / Thermistors	393
	2.6	Removal	of Sound Blankets	.399
	2.7	Removal	of Compressor	.402

SiBE121135 Outdoor Unit: 40-75 Class

# 1. Outdoor Unit: 40-75 Class


**Note:** The illustrations are for heat pump models as representative.

## 1.1 Removal of Outer Panels


**Procedure** 

Warning


Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.




Outdoor Unit: 40-75 Class SiBE121135



SiBE121135 Outdoor Unit: 40-75 Class



Outdoor Unit: 40-75 Class SiBE121135




SiBE121135 Outdoor Unit: 40-75 Class

## 1.2 Removal of Electrical Box


#### **Procedure**




Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.




Outdoor Unit: 40-75 Class SiBE121135




SiBE121135 Outdoor Unit: 40-75 Class




Outdoor Unit: 40-75 Class SiBE121135




SiBE121135 Outdoor Unit: 40-75 Class




Outdoor Unit: 40-75 Class SiBE121135



SiBE121135 Outdoor Unit: 40-75 Class



Outdoor Unit: 40-75 Class SiBE121135





# 1.3 Removal of PCBs


#### **Procedure**


**∕** Warning


Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.












# 1.4 Removal of Outdoor Fan / Fan Motor

#### **Procedure**

/ Warnin

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step		Procedure	Points
1	Remove the 2 screws of the fan motor fixing plate.	Fan motor fixing plate (R12908)	Preparation  ■ Remove the outer panels and plates.  ■ Remove the electrical box.
2	Remove the fan motor fixing plate.	(R5561)	■ When reassembling, fit the lower hooks.  ■ Nut size: M6
3	Remove the nut and remove the outdoor fan.	Outdoor fan (R12909)	10 mm (R12236)
		▼ mark Nut (R14592)	■ When reassembling, align the ▼ mark of the outdoor fan with the D-cut section of the motor shaft.




# 1.5 Removal of Sound Blankets


#### **Procedure**


/ Warnin

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step		Procedure	Points
1. R	emove the right side		Preparation
pa	anel.	Right side panel	■ Remove the outer panels
1	Remove the 3 screws of the right side panel.	(R12915)	and plates.  ■ Remove the electrical box.
2	Remove the 2 screws	()	
	on the back.	(R5571)	
3	Remove the protection rubber. There is a hook on the back.	Protection rubber  (R5572)	









# 1.6 Removal of Coils / Thermistors


**Procedure** 

**Warning** 

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.







#### **Removal of Distributor** 1.7

#### **Procedure**

Warning

Be sure to wait for 10 minutes or more after turning off all power

		supplies before disassembling work.
Step		Procedure
1	Remove the putty.	Putty (R5595)
<ul> <li>Before working, make sure that the refrigerant gas is empty in the circuit.</li> <li>Be sure to apply nitrogen replacement when heating up the brazed part.</li> <li>Heat up and disconnect the brazed parts to</li> </ul>		
	remove the distributor.	

#### Note:

- Do not use a metal saw for cutting pipes by all means because the sawdust comes into the circuit.
- When withdrawing the pipes, be careful not to pinch them firmly with pliers. The pipes may get deformed.
- Provide a protective sheet or a steel plate so that the brazing flame cannot influence peripheries.

#### **Cautions for restoration**

sure to collect all the refrigerant gas.

1. Restore the piping by nonoxidation brazing.

**Points** 

Warning Be careful not to get yourself burnt with the pipes and other parts that are heated by the gas brazing machine.

**\** Warning If the refrigerant gas leaks during work, ventilate the room. (If the refrigerant gas is exposed to flames, toxic gas

may be generated.)


Caution

From the viewpoint of global environment protection, do not discharge the refrigerant gas in the atmosphere. Make

2. It is required to prevent the carbonization of the oil inside the four way valve and the deterioration of the gaskets affected by heat. (Keep below 120°C.) For the sake of this, wrap the four way valve with wet cloth and provide water so that the cloth does not dry.

#### In case of difficulty with gas brazing machine

- 1. Disconnect the brazed part where is easy to disconnect and restore.
- 2. Cut pipes on the main unit with a tube cutter in order to make it easy to disconnect.



# 1.8 Removal of Four Way Valve

#### **Procedure**

**Warning** 

**Procedure** 

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.


# ■ Before working, make sure that the refrigerant gas is empty in the circuit. ■ Be sure to apply nitrogen replacement when heating up the brazed


- 1 Remove the screw to remove the four way valve coil.
- 2 Heat up the 4 brazed part of the four way valve. First, disconnect the part (a).


- 3 Disconnect the part (b).
- 4 Disconnect the part (c) and (d) and remove the four way valve.


#### Note:

- Do not use a metal saw for cutting pipes by all means because the sawdust comes into the circuit.
- When withdrawing the pipes, be careful not to pinch them firmly with pliers. The pipes may get deformed.
- Provide a protective sheet or a steel plate so that the brazing flame cannot influence peripheries.









#### **Points**

 Cooling only models have no four way valve coil.

Warning
Be careful not to get yourself burnt with the pipes and other parts that are heated by the gas brazing machine.

Warning
If the refrigerant gas leaks
during work, ventilate the
room. (If the refrigerant gas is
exposed to flames, toxic gas
may be generated.)

Caution

From the viewpoint of global environment protection, do not discharge the refrigerant gas in the atmosphere. Make sure to collect all the refrigerant gas.

#### **Cautions for restoration**

- 1. Restore the piping by non-oxidation brazing.
- 2. It is required to prevent the carbonization of the oil inside the four way valve and the deterioration of the gaskets affected by heat. (Keep below 120°C.) For the sake of this, wrap the four way valve with wet cloth and provide water so that the cloth does not dry.

# In case of difficulty with gas brazing machine


- Disconnect the brazed part where is easy to disconnect and restore.
- Cut pipes on the main unit with a tube cutter in order to make it easy to disconnect.

# 1.9 Removal of Compressor

**Procedure** 

**│** Warning

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.



#### Step **Procedure Points** Warning Be careful not to get yourself burnt with the pipes and other parts that are heated by the gas brazing machine. **∖** Warning If the refrigerant gas leaks during work, ventilate the room. (If the refrigerant gas is (R5605) exposed to flames, toxic gas 4 Remove the putty. may be generated.) Remove the 2 nuts. Warning Since it may happen that the refrigerant oil in the ■ Before working, make compressor catches fire, sure that the refrigerant prepare wet cloth so as to gas is empty in the circuit. extinguish fire immediately. ■ Be sure to apply nitrogen replacement when Caution heating up the brazed From the viewpoint of global part. environment protection, do Heat up the brazed part (R17172) not discharge the refrigerant of the discharge side gas in the atmosphere. Make and disconnect the part sure to collect all the refrigerant gas. 7 Heat up the brazed part of the suction side and Cautions for restoration disconnect the part (b). 1. Restore the piping by non-Remove the oxidation brazing. compressor. 2. It is required to prevent the carbonization of the oil inside the four way valve and the Note: (R14070) deterioration of the gaskets ■ Do not use a metal saw affected by heat. (Keep for cutting pipes by all below 120°C.) For the sake means because the of this, wrap the four way sawdust comes into the valve with wet cloth and circuit. provide water so that the cloth does not dry. ■ When withdrawing the pipes, be careful not to In case of difficulty with gas pinch them firmly with brazing machine pliers. The pipes may get 1. Disconnect the brazed part deformed. where is easy to disconnect and restore. ■ Provide a protective sheet Compresso (R12917) 2. Cut pipes on the main unit or a steel plate so that the with a tube cutter in order to brazing flame cannot make it easy to disconnect. influence peripheries. ■ Be careful so as not to burn the compressor terminals, the name plate,

366 Removal Procedure

the heat exchanger fin.

# 2. Outdoor Unit: 80/90 Class


**Note:** The illustrations are for heat pump models as representative.


# 2.1 Removal of Outer Panels


**Procedure** 


Warning


Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.











































# 2.2 Removal of Electrical Box


**Procedure** 


/ Warning


Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.
















#### 2.3 Removal of PCBs


**Procedure** 


/ Warning

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.










# 2.4 Removal of Fan Motor

**Procedure** 

∕ **!** Warning

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.





## 2.5 Removal of Coils / Thermistors


**Procedure** 


/ Warning


Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.
















#### 2.6 Removal of Sound Blankets

#### **Procedure**

Warning

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.






Step		Procedure	Points
	ve the sound		
7 Remo	ve the sound of (inner).	(R10439)	

# 2.7 Removal of Compressor

#### **Procedure**

/ Warning

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.



# Part 8 Trial Operation and Field Settings

1.	Pum	p Down Operation	404
2.	Forc	ed Operation	405
3.	Wirir	ng Error Check Function	406
4.	Trial	Operation	408
		RA Indoor Unit - FTXG, FTXS, CTXS, FVXG, FVXS, FLXS,	
		FDXS Series	408
	4.2	SA Indoor Unit - FCQG, FFQ, FHQ, FDBQ, FBQ Series	410
5.	Field	I Settings	412
		Outdoor Unit	
	5.2	RA Indoor Unit - FTXG, FTXS, CTXS, FVXG, FVXS, FLXS,	
		FDXS Series	415
	5.3	SA Indoor Unit - FCQG, FFQ, FHQ, FDBQ, FBQ Series	419
6.	Appl	ication of Silicon Grease to a Power Transistor	
		a Diode Bridge	423

Pump Down Operation SiBE121135


# 1. Pump Down Operation

#### **Outline**

In order to protect the environment, be sure to conduct pump down operation when relocating or disposing the unit.

#### Detail

- 1) Remove the valve caps from the liquid stop valve and the gas stop valve.
- 2) Carry out forced cooling operation.
- 3) After 5 to 10 minutes, close the liquid stop valve with a hexagonal wrench.
- 4) After 2 to 3 minutes, close the gas stop valve and stop the forced cooling operation.



(R14566)



Refer to page 405 for forced operation.

SiBE121135 **Forced Operation** 


# 2. Forced Operation

#### **Outline**

Forced operation mode includes forced cooling and forced heating. Operation mode can be selected by the operation mode switch (SW2) on the outdoor unit. Press the forced operation [ON/OFF] switch (SW1) on the outdoor unit to start the operation.

#### Detail

Item	Forced Cooling	Forced Heating
Conditions	1) The indoor unit is not abnormal, but the indoor unit which is not in the freezing prohibiting zone is present in more than 1 room.	1) The indoor unit is not abnormal. The indoor unit which is not in the peak-cut prohibited zone is present in more than 1 room.
	2) The outdoor unit is not abnormal and not in the 3-minute standby mode.	<b>←</b>
	3) The operating mode of the outdoor unit is the stop mode.	<b>←</b>
	4) The operation mode switch (SW2) on the outdoor unit is set to the cooling mode.	4) The operation mode switch (SW2) on the outdoor unit is set to the heating mode.
Start	Press the forced operation [ON/OFF] switch (SW1) on the outdoor unit.	<b>←</b>
Operating room	All rooms: The command is sent to all the rooms where the transmission is normal.	■ Only 1 room: The command is sent to one of the rooms which can be operate and the order of priority is A > B > C > D > E. Other rooms operation must be stopped.
Command frequency	40/50/52/58 class : 52 Hz     68/75 class : 42 Hz     80/90 class : 31 Hz	(Outdoor temperature : 2°C) • 40/50/52/58 class : 42 Hz • 68/75 class : 35 Hz • 80/90 class : 26 Hz
End	1) Press the forced operation [ON/OFF] switch (SW1) on the outdoor unit again.	<b>←</b>
	2) The operation ends automatically after 15 minutes.	2) The operation ends automatically after 60 minutes.
Others	The protection functions are prior to all others in the forced operation.	<b>←</b>



(R12870)

# 3. Wiring Error Check Function

#### **Outline**

The convenient wiring error check function is designed for the microcomputer to correct wiring errors itself.

If local wiring is unclear in the case of buried piping, for example, just press the wiring error check switch that is behind the stop valve cover of the outdoor unit. Even if the connections for Room A and Room B are confused, the system may run without a hassle. Note that this check function does not work in the following cases.

- For about 1 minute after the power is turned on (during initial setup).
- For 3-minute standby period after the compressor has stopped.
- When the outdoor temperature is below 5°C.
- If the indoor unit is in trouble (also in case of all-room transmission failure).

When the piping and wiring are perfect, there is no need to use this function.

#### Operation

- 1. Remove the stop valve cover.
- 2. Press the wiring error check switch (SW3) on the service monitor PCB of the outdoor unit, and the wiring error check function is activated.
- 3. In about 10 ~ 20 minutes, the check finishes automatically.
- 4. When the check is over, the service monitor LED indicators start blinking.


LED	1	2	3	4	5	Judgment
Status	All blinking at once					Self-correction impossible
Status	ВІ	inking o	one afte	r anoth	er	Self-correction complete

- Self-correction complete...The LED indicators 1 ~ 3 (3-room model), 1 ~ 4 (4-room model), or 1~5 (5-room model) blink one after another.
- Self-correction impossible...The LED indicators blink all at the same time.
  - \* Transmission failure occurs at any of the indoor units.
  - \* The indoor unit heat exchanger thermistor is disconnected.
  - \* An indoor unit is in trouble (if a trouble occurs during the wiring error checking).
- Emergency stop...Any of the LED indicators stays on.



- 1. It takes about 10 ~ 20 minutes (after pressing the wiring error check switch) to complete the checking.
- 2. Wrongly connected liquid and gas pipes cannot be self-corrected. Be sure to make the liquid pipe and the gas pipe in pairs.
- 3. To cancel the wiring error check procedure halfway, press the wiring error check switch again.
  - In this case, the memory of the microcomputer returns to its initial status (Room A wiring  $\rightarrow$  Port A piping, Room B wiring  $\rightarrow$  Port B piping).
- 4. When replacing the outdoor unit PCB, be sure to use this function.
- 5. Make the power side setting after doing the wiring error check. (Otherwise, if the wiring is reversed, the air-conditioners being connected are set up in the reverse way.)

Service monitor PCB



#### **Basic Knowledge**

- Refrigerant flows from Port A and on. The temperatures of the indoor heat exchanger thermistors are detected one by one to check up the matching between the piping and wiring.
- With this function on, freezing (crackling) noise may be heard from the indoor unit. This is not a problem. (This is because the heat exchanger temperature is made to drop below 0°C in order to increase the detection accuracy.)
- The indoor fan is made to turn on or off at the same time.

Checking the current setting data on the microcomputer memory

Those data can be checked by looking at the service monitor LED indicators, when the wiring error checking is over, during forced operation, at the stop of the system.

The LED indicators stop blinking when the forced operation is over.


LED1...Room A wiring, LED2...Room B wiring

1st blinking LED...Port A piping, 2nd blinking LED...Port B piping


The 1st blinking LED means the room that is connected with Port A. The 2nd blinking LED means the one connected with Port B.

#### Example

Ex: Suppose the LED indicators are blinking as follows.



The above means that Port A is connected with Port B, and Port B with Room A (or self-corrected this way.)



Trial Operation SiBE121135

# 4. Trial Operation

# 4.1 RA Indoor Unit - FTXG, FTXS, CTXS, FVXG, FVXS, FLXS, FDXS Series

#### **Outline**

- 1. Measure the power supply voltage and make sure that it falls in the specified range.
- 2. Trial operation should be carried out in either cooling or heating operation.
- 3. Carry out the trial operation in accordance with the operation manual to ensure that all functions and parts, such as flap movement, are working properly.
- The air conditioner requires a small amount of power in its standby mode. If the system is not to be used for some time after installation, shut off the circuit breaker to eliminate unnecessary power consumption.
- If the circuit breaker trips to shut off the power to the air conditioner, the system backs up the operation mode. The system then restarts operation with the previous operation mode when the circuit breaker is restored.


In cooling operation, select the lowest programmable temperature; in heating operation, select the highest programmable temperature.

- Trial operation may be disabled in either operation mode depending on the room temperature.
- After trial operation is complete, set the temperature to a normal level. (26°C ~ 28°C in cooling, 20°C ~ 24°C in heating)
- For protection, the system does not start for 3 minutes after it is turned off.

#### Detail

#### **ARC466 Series**


- (1) Press the [On/Off] button to turn on the system.
- (2) Press the center of the [Temp] button and the [Mode] button at the same time.
- (3) Select ? (trial operation) with the [Temp] ▲ or ▼ button.
- (4) Press the [Mode] button to start the trial operation.
- (5) Press the [Mode] button and select operation mode.
- (6) Trial operation terminates in approx. 30 minutes and switches into normal mode. To quit a trial operation, press the [On/Off] button.



SiBE121135 Trial Operation


#### **ARC452 Series**

- (1) Press the [ON/OFF] button to turn on the system.
- (2) Press the both of [TEMP] buttons and the [MODE] button at the same time.
- (3) Press the [MODE] button twice.
  - (? appears on the display to indicate that trial operation is selected.)
- (4) Press the [MODE] button and select the operation mode.
- (5) Trial operation terminates in approx. 30 minutes and switches into normal mode. To quit a trial operation, press the [ON/OFF] button.



#### **ARC433 Series**

- (1) Press the [ON/OFF] button to turn on the system.
- (2) Press the center of the [TEMP] button and the [MODE] button at the same time.
- (3) Press the [MODE] button twice.
  - (? appears on the display to indicate that trial operation is selected.)
- (4) Press the [MODE] button and select the operation mode.
- (5) Trial operation terminates in approx. 30 minutes and switches into normal mode. To quit a trial operation, press the [ON/OFF] button.



Trial Operation SiBE121135

# 4.2 SA Indoor Unit - FCQG, FFQ, FHQ, FDBQ, FBQ Series

#### 4.2.1 Check points

To carry out test operation, check the followings:

■ Check that the temperature setting of the remote controller is at the lowest level in cooling mode.

■ Go through the following checklist:

Checkpoints	Cautions or warnings
Are all units securely installed?	<ul> <li>Dangerous for turning over during storm</li> <li>Possible damage to pipe connections</li> </ul>
Is the earth wire installed according to the applicable local standard?	Dangerous if electric leakage occurs.
Are all air inlets and outlets of the indoor and outdoor units unobstructed?	<ul><li>Poor cooling</li><li>Poor heating</li></ul>
Does the drain flow out smoothly?	Water leakage
Is piping adequately heat-insulated?	Water leakage
Have the connections been checked for refrigerant leakage?	<ul><li>Poor cooling</li><li>Poor heating</li><li>Stop</li></ul>
Is the supply voltage conform to the specifications on the name plate?	Incorrect operation
Are the cable sizes as specified and according to local regulations?	Damage of cables
Are the remote controller signals received by the unit?	No operation

#### 4.2.2 Test operation

#### **BRC1D528**

Step	Action
1	Turn on the power supply more than 6 hours before test operation.
2	Open the gas stop valve.
3	Open the liquid stop valve.
4	Set to cooling operation with the remote controller and start operation by pressing [ON/OFF] button ( ① ).
5	Press the [INSPECTION/TEST OPERATION] button ( *) 4 times (2 times for wireless remote controller) and operate at test operation mode for 3 minutes.
6	Press the [AIRFLOW DIRECTION ADJUST] button ( 🔎 ) to make sure the unit is in operation.
7	Press the [INSPECTION/TEST OPERATION] button ( *) and operate normally.
8	Confirm all the function of unit according to the operation manual.
9	If the decoration panel has not been installed, turn off the power after the test operation.

SiBE121135 Trial Operation

#### BRC1E51A7

Step	Action	Remote controller
Before test		Tiomote controller
1	Turn on the power supply more than 6 hours before test operation.	
2	Open the gas stop valve.	
3	Open the liquid stop valve.	
	ivate test operation	
4	Press and hold the [Cancel] button ( 1 ) for	
_	4 seconds to enter the <b>Field setting</b> menu.	
5	Use the ▼▲ buttons to select <b>Test</b> operation ON/OFF and push the [Menu/ Enter] button ( → J ).	Field setting 1/2  Test operation ON/OFF Register Service Contract Field setting list Group No. setting Indoor unit Airnet No. set Outdoor unit Airnet No. set  Outdoor unit Airnet No. set  (R12872)
6	<b>Test operation</b> is displayed on the bottom of the basic screen.	Cool Test Operation (R12873)
7	Push the [ON/OFF] button ( (1) ) within 10	
	seconds to start the test operation.	
How to che	ck airflow direction	
8	Push the [Menu/Enter] button ( ) to enter the <b>Main Menu</b> .	
9	Use the ▼▲ buttons to select <b>Airflow direction</b> and push the [Menu/Enter] button ( → J ).	MainMenu 1/2  Set temp mode changeover Airflow Direction Quick Cool/Heat On/Off Ventilation Timer setting Service Contact/Model Into Setting  Return Setting   (R12874)
10	Check that the airflow direction is actuated according to the setting and push the [Menu/Enter] button ( ).	Airflow Direction Swing  (R12875)
How to dea	ctivate test operation	
11	Press and hold the [Cancel] button ( the joint of the field setting menu.	
12	Use the ▼▲ buttons to select <b>Test</b> operation <b>ON/OFF</b> in the menu and push the [Menu/Enter] button ( → J ).	Field setting    Test operation ON/OFF

Field Settings SiBE121135

# 5. Field Settings

#### 5.1 Outdoor Unit

#### 5.1.1 Priority Room Setting

Outdoor electronic expansion valves are controlled to provide more capacity to the prioritized room.

Setting method

Turn off the circuit breaker before changing the setting.


Only one room can be set as the priority room (By turning on one of the SW4 on the service monitor PCB of the outdoor unit).

- The control starts when all the following conditions are met.
  - \* Priority room setting is made.
  - \* "POWERFUL" signal from the priority room unit is received.


Note: The operation mode of the priority room unit has precedence.

#### ■ Cancellation of control

The control function is canceled when the "POWERFUL" operation mode is switched off or 20 minutes elapse after "POWERFUL Operation" started.



The prioritized room will be heated/cooled much more quickly



SiBE121135 Field Settings

#### 5.1.2 COOL / HEAT Mode Lock

Use the [S15] connector to set the unit to cooling only or heating only.

Setting to heating only (H): Short-circuit pins 1 and 3 of the connector [S15].


Setting to cooling only (C): Short-circuit pins 3 and 5 of the connector [S15].

The following specifications apply to the connector housing and pins.

JST products Housing: VHR-5N

Pin: SVH-21T-1, 1

Note that forced operation is also possible in cooling / heating mode.




Field Settings SiBE121135

#### 5.1.3 NIGHT QUIET Mode


If NIGHT QUIET mode is to be used, initial settings must be made when the unit is installed. Explain the function of NIGHT QUIET mode, as described below, to the customer, and confirm whether or not the customer wants to use NIGHT QUIET mode.

NIGHT QUIET mode function reduces operating noise of the outdoor unit at nighttime. This function is useful if the customer is worried about the effects of the operating noise on the neighbors. However, if NIGHT QUIET mode is running, cooling capacity is reduced.

- Procedure
- 1. Remove the SW5 jumper switch on the service monitor PCB of the outdoor unit. Once the settings are complete, reset the power.



2. Install the removed jumper switch as described below. This jumper switch is needed later to disable this setting.



#### 5.1.4 ECONO-mode-proof Setting

**Outline** 

When installing in hotels, you can make ECONO mode ineffective on the outdoor unit.

#### Operation

The ECONO mode can be switched over between "effective" and "ineffective" by pressing the forced operation [ON/OFF] switch (SW1) on the outdoor unit and wiring error check switch (SW3) on the outdoor unit at the same time and holding them for 5 seconds while the compressor is stopped. The LEDs are lit in turn for 15 seconds to show the ECONO mode status.

The factory setting is "effective".

LED flashing order	effective  ightarrow ineffective	$ineffective \rightarrow effective$
3 or 4-room model	$4 \rightarrow 3 \rightarrow 2 \rightarrow 1$	$1 \rightarrow 2 \rightarrow 3 \rightarrow 4$
5-room model	$5 \rightarrow 4 \rightarrow 3 \rightarrow 2 \rightarrow 1$	$1 \rightarrow 2 \rightarrow 3 \rightarrow 4 \rightarrow 5$


SiBE121135 Field Settings

# 5.2 RA Indoor Unit - FTXG, FTXS, CTXS, FVXG, FVXS, FLXS, FDXS Series

#### 5.2.1 Model Type Setting

#### ARC452A1, ARC452A3, ARC466A6

- The remote controller is common to the heat pump model and cooling only model. Use the DIP switch on the remote controller to set the model type.
- Set the DIP switch as shown in the illustration. (The factory set is the heat pump side.)
  - Heat pump model: Set the DIP switch to H/P.
  - Cooling only model: Set the DIP switch to C/O.



#### 5.2.2 When 2 Units are Installed in 1 Room

#### **Outline**

When 2 indoor units are installed in 1 room, 1 of the 2 indoor units and the corresponding wireless remote controller can be set for different address.

Both the indoor unit PCB and the wireless remote controller need alteration.


The method of address setting varies depending on the type of indoor unit and the series of wired remote controller. Refer to the following pages for the appropriate indoor unit and wireless remote controller.

#### Wall Mounted Type

- (1) Remove the front grille.
- (2) Remove the electrical box.
- (3) Remove the shield plate of the electrical box.
- (4) Cut the address setting jumper JA on the PCB.

# FTXG Series FTXS-K, CTXS-K Series FTXS-K, CTXS-K Series (Bottom of electrical box) FTXS-K, CTXS-K Series


Field Settings SiBE121135




# Floor Standing Type

#### **FVXG Series**

- (1) Remove the front panel, air filters and front grille.
- (2) Remove the screw, and remove the service cover.



(3)Turn on the DIP switch [S2W-1] on the service PCB.




\* Keep the other switches as factory setting (OFF).

SiBE121135 Field Settings


#### **FVXS Series**

- 1) Remove the front grille.
- 2) Lift the sensor PCB fixing plate and remove the front shield plate.
- 3) Disconnect the connectors [S1] [S41] [S42].
- 4) Remove the electric box (1 screw).
- 5) Pull out the indoor heat exchanger thermistor.
- 6) Remove the shield plate (8 tabs).
- 7) Cut the address setting jumper JA on the indoor unit PCB.




#### Floor / Ceiling Suspended Dual Type

■ Cut the jumper JA on PCB.



# **Duct Connected Type**

■ Cut the jumper JA on PCB.




Field Settings SiBE121135


# Wireless Remote Controller

- (1) Remove the cover and take it off.
- (2) Cut the address setting jumper.


#### **ARC466** series



#### ARC452 series



#### **ARC433** series



#### 5.2.3 Jumper and Switch Settings

Jumper (on indoor unit PCB)	Function	When connected (factory set)	When cut
JB	Fan speed setting when compressor stops for thermostat OFF. (effective only at cooling operation)	Fan speed setting; Remote controller setting	Fan speed setting; "0" (The fan stops.)
JC	Power failure recovery function	Auto-restart	The unit does not resume operation after recovering from a power failure. Timer settings are cleared.

#### <Floor Standing Type: FVXS Series>

Switch (on indoor unit PCB)	Function	OFF (factory set)	ON
SW2-4	Upward airflow limit setting	Exposed or half embedded installation	Set the switch to ON position when you install the indoor unit embedded in the wall to avoid condensation.

#### <Floor / Ceiling Suspended Dual Type>

Switch (on indoor unit PCB)	Function	FLOOR (factory set)	CEILING
SW2		When installed as the floor mounted type	When installed as the ceiling suspended type



For the location of the jumper and the switch, refer to the following pages.

Wall Mounted Type: page 42, 45, 47, 50

Floor Standing Type: page 53, 56 Floor / Ceiling Suspended Dual Type: page 58

Duct Connected Type: page 60

SiBE121135 Field Settings

# 5.3 SA Indoor Unit - FCQG, FFQ, FHQ, FDBQ, FBQ Series


### 5.3.1 How to Change the Field Settings

**Outline** 

If optional accessories are mounted on the indoor unit, the indoor unit setting may have to be changed. Refer to the instruction manual for each optional accessory.

# Wired remote controller

#### **BRC1D528**




To set the field settings, you have to change:

- Mode No.
- First code No.
- Second code No.

Step	Action	
1	Press the [INSPECTION/TEST OPERATION] button for 4 seconds during normal	
	mode to enter the field setting mode.	
2	Press the [TEMPERATURE ADJUST] button to select the desired mode No.	
3	<ul> <li>If the indoor unit is under group control, all settings for all the indoor units are set at the same time. Use the codes 10 to 15 to apply this group control and proceed to the next step.</li> <li>If you want to set the indoor units of one group individually or if you want to read out the last settings, use the codes 20 to 25 which are displayed in brackets. Press the [PROGRAMMING] button to select the indoor unit No. for which you want to adjust the field settings.</li> </ul>	
4	Press the upper part of the [TIME ADJUST] button to select the first code No.	
5	Press the lower part of the [TIME ADJUST] button to select the second code No.	
6	Press the [SCHEDULE TIMER] button to confirm the setting.	
7	Press the [INSPECTION/TEST OPERATION] button to return to normal mode.	

Field Settings SiBE121135

#### **BRC1E52A7, BRC1E52B7**



- a Unit No.
- **b** First code No.
- c Second code No.
- **d** Mode

Step	Action	Remote controller
1	Press and hold the [Cancel] button ( the pressure of the press	
2	Use the ▼▲ buttons to select <b>Field setting list</b> and push the [Menu/Enter] button ( → ).	Field setting 1/2 Test operation ON/OFF Register Service Contract Field setting list Group No, setting Indoor unit Airnet No, set Outdoor unit Airnet No, set Outdoor unit Airnet No, set (R12879)
3	Use the ▼▲ buttons to select the desired Mode.	
4	During group control, when setting by each indoor unit (Mode 20, 21, 22 and 23 have been selected), push the ◀ button to highlight and ▼▲ buttons to select the INDOOR UNIT NO. to be set. This operation is unnecessary when setting by group.	
5	Highlight the second code No. to be changed using the ◀▶ buttons, and use the ▼▲ buttons to select the desired second code No.	When setting by group, all of the second code No. that may be set are displayed as "*".
6	Push the [Menu/Enter] button ( ) to display the confirmation screen.	
7	Use the ◀▶ buttons to select <b>Yes</b> and push the [Menu/Enter] button ( ◢ ).	When multiple setting changes are needed, repeat steps 3 to 7.
8	Push the [Cancel] button (  2 times to return to basic screen.	

SiBE121135 Field Settings

# 5.3.2 Overview of the Field Settings

Mode	Code	Description of setting					Second (	Code No.	
No.	No.	Description o	rsetting		01		02	03	04
	0	Filter cleaning sign		Light	Approx. 10,000 hrs.	Неаvy	Approx. 5,000 hrs.	_	_
10		interval	Longlife filter	Approx. 2,500 hrs. Δ		의 Approx. 1,250 hrs.			
(20)	1	Longlife filter type		Longlife filter		Ultra longlife filter		_	_
	2	Remote controller the	rmistor	Enabled			Disabled	_	_
	3	Filter cleaning sign			Display	١	No display	_	_
	0	Indoor unit number of operation system		Pair		Twin	Triple	Double twin	
11 (21)	1	Simultaneous operation individual setting	on system	Un	ified setting		Individual setting	_	_
(= - )	7	External static pressu	re setting	ad	Airflow ljustment is OFF		mpletion of airflow djustment	Start of airflow adjustment	
12	1	Forced ON/OFF funct	ion	F	orced OFF	ON/OFF			
(22)	2	Thermostat differentia (setting for when using	al changeover g remote sensor)		1°C		0.5°C	_	
	0	High air outlet velocity applications)		≤ 2.7 m	2	.7 ~ 3.0 m	3.0 ~ 3.5 m	_	
13	1	Selection of airflow di for when a blocking p installed)	4	-way flow	3	3-way flow	2-way flow	_	
(23)	3	Selection of airflow fu for when using a deco outlet)	nction (setting pration panel for		Equipped	No	ot equipped	_	_
	4	Airflow direction range	e setting		Upper		Normal	Lower	_
	6	External static pressu	re		Refer to Note 2.			Note 2.	
	2	Dust collection sign interval		Ap	prox. 1,250 hrs.	Ap	prox. 2,500 hrs.	Approx. 5,000 hrs.	_
	3	Filter replacement sig	n	١	lo display	Apı	orox. 32,000 hrs.	Approx. 48,000 hrs.	Approx. 72,000 hrs.
14 (24)	4	Panel indicator (green) ON/OFF			indicator ts up during n air ditioning ration and r auto- aning.	can duri	e indicator light up only ing filter o-cleaning.	The indicator does not light up during both air conditioning operation and filter autocleaning.	_
	8	Selection of the autor operation lock mode	natic control		ON		OFF	_	_
	9	Dust amount setting			Standard		Heavy	_	_
15 (25)	3	Drain pump operation	with humidifying	No	ot equipped		Equipped	_	_

: factory set

Note

1. Any function that is not available on the indoor unit is not displayed.

			External static pressure (Pa)				
Mode	First	First Second		FBQ			
No.	code No.	code No.	35 class	50 class	60 class		
		03	30	30	30		
		04	35	35	40		
		05	40	40	50		
		06	45	45	60		
13 (23)	6	07	50	50	70		
13 (23)	0	08	60	60	80		
		09	70	70	90		
		10	80	80	100		
		11	90	90	_		
		12	100	100	_		

: factory set

Field Settings SiBE121135

# 5.3.3 MAIN / SUB Setting when Using 2 Wired Remote Controllers

### **Outline**

The MAIN / SUB setting is necessary when 1 indoor unit is controlled by 2 remote controllers. When you use 2 remote controllers (control panel and separate remote controller), set one to MAIN and the other to SUB.

### **Detail**

The remote controllers are factory set to MAIN, so you only have to change one remote controller from MAIN to SUB.

### **BRC1D528**

Action Insert a flat screwdriver into the groove between the upper and lower part of the emote controller, as shown in the illustration below. Gently pry off the upper part of the controller, working from the two possible positions.
emote controller, as shown in the illustration below. Gently pry off the upper part of the controller, working from the two possible positions.
Upper part of the remote controller
Lower part of the remote controller  (R11738)
Set the [MAIN / SUB changeover] switch on the PCB to "S".
The switch is set to MAIN (factory setting)  Main (factory setting)  Set the switch to SUB.  (R11739)
6

### **BRC1E52A7, BRC1E52B7**

Step	Action	Remote controller
1	Put on the power for both remote controllers.	
2	Determine which one is the sub/main remote controller.	
3	When Error code: U5 - Connection under check Please wait for a moment is displayed on both remote controllers, push and hold the [Operation mode selector] button (\$\bigs\sim\sim\) of the sub remote controller for 4 seconds.	Error code:U5 Connection under check Please wait for a moment  Main remote contri
4	The sub remote controller now displays <b>Sub</b> remote contrl.	
	Note) The main remote controller still displays <b>Main remote contrl.</b>	Connection under check Please wait for a moment  Sub remote contri
		(R12881)
5	After a few seconds, the basic screen is displayed.	

# 6. Application of Silicon Grease to a Power Transistor and a Diode Bridge

# Applicable Models

All outdoor units using inverter type compressor for room air conditioner.

When the printed circuit board (PCB) of an outdoor unit is replaced, it is required that silicon grease (\*1) is certainly applied to the heat radiation part (the contact point to the radiation fin) of the power transistor and diode bridge.

\*1: Parts number of the silicon grease - 1172698 (Drawing number 3FB03758-1)

#### **Details**


The silicon grease is an essential article for encouraging the heat radiation of the power transistor and the diode bridge. Applying the paste should be implemented in accordance with the following instruction.

Note: There is the possibility of failure with smoke in case of bad heat radiation.

- Wipe off the old silicon grease completely on a radiation fin.
- Apply the silicon grease evenly to the whole.
- Do not leave any foreign object such as solder or paper waste between the power transistor and the radiation fin, and also the diode bridge, and the radiation fin.
- Tighten the screws of the power transistor and the diode bridge, and contact to the radiation fin without any gap.

### <Example>

The shape of electrical box and PCB vary depending on the model.






OK: Evenly applied silicon grease.



NG: Not evenly applied



NG: Foreign object

(R9056)

# Part 9 Appendix


1.	Pipir	ng Diagrams	425
	•	Outdoor Unit	
	1.2	Indoor Unit	430
2.	Wirin	ng Diagrams	437
		Outdoor Unit	
	2.2	Indoor Unit	442

# 1. Piping Diagrams

# 1.1 Outdoor Unit


# 1.1.1 Cooling Only

### 3MKS50E3V1B




3D052056C

### 4MKS58E3V1B




3D052057B

### 4MKS75F2V1B




### 5MKS90E2V3B



3D051938


## 1.1.2 Heat Pump

### 3MXS40K2V1B




3D073394

### 3MXS52E3V1B




3D052055D

#### 3MXS68G2V1B




3D058888

### 4MXS68F2V1B




3D055041

#### 4MXS80E2V3B



3D051937E

### 5MXS90E2V3B




3D051936A


# 1.2 Indoor Unit

# 1.2.1 Wall Mounted Type

### FTXG25/35JV1BW(A)

### FTXG50JV1BW(A)







4D065855B 4D065856C

### FTXS20/25K2V1B, CTXS15/35K2V1B

### FTXS25/35/42J2V1B







4D058926N 4D058897H

### FTXS50J2V1B


### FTXS60GV1B





4D058898F 4D040081Y

### FTXS71GV1B





4D040082W

# 1.2.2 Floor Standing Type

### FVXG25/35K2V1B

### FVXG50K2V1B







4D071597 4D071598

### FVXS25/35FV1B

### FVXS50FV1B





4D056137B 4D056138C


COOLING


--- HEATING

# 1.2.3 Floor / Ceiling Suspended Dual Type

### FLXS25/35BAVMB

### FLXS50/60BAVMB






4D048722B 4D048724B

# 1.2.4 Duct Connected Type

### FDXS25/35E7VMB, FDXS50/60C7VMB




C: 4D045449Q

# 1.2.5 Ceiling Mounted Cassette Type


### FCQG35/50/60FVEB





C: 4D076993

### FFQ25/35/50/60B9V1B




MODEL	Α	В
FFQ25/35B9V1B	6.4	9.5
FFQ50/60B9V1B	6.4	12.7

C: 4D039335B

# 1.2.6 Ceiling Suspended Type

### FHQ35/50/60BWV1B




MODEL	Α	В
FHQ35BWV1B	6.4	9.5
FHQ50, 60BWV1B	6.4	12.7

C: 4D037995L

# 1.2.7 Ceiling Mounted Built-in Type

### FDBQ25B8V1



Refrigerant flow


Cooling ————
Heating ————

Refrigerant pipe connection port diameters

Model	Gas	Liquid
FDBQ25B8V1	φ9.52	φ6.35

C: 3TW20815-1B

### FBQ35/50/60C8VEB



Refrigerant flow

Cooling 

Heating 

→

### Refrigerant pipe connection port diameters

Model	Gas	Liquid
FBQ35C	9.52	6.35
FBQ50C	12.70	6.35
FBQ60C	12.70	6.35


C: 3TW31275-1

# 2. Wiring Diagrams


# 2.1 Outdoor Unit

# 2.1.1 Cooling Only


### 3MKS50E3V1B




### 4MKS58E3V1B



#### 4MKS75F2V1B




### 5MKS90E2V3B




## 2.1.2 Heat Pump


### 3MXS40K2V1B, 3MXS52E3V1B




### 3MXS68G2V1B



#### 4MXS68F2V1B




### 4MXS80E2V3B



2TW27576-1B

### 5MXS90E2V3B




2TW27586-1A

# 2.2 Indoor Unit


# 2.2.1 Wall Mounted Type

### FTXG25/35/50JV1BW(A)




3D065507D


### FTXS20/25K2V1B, CTXS15/35K2V1B



#### FTXS25/35/42/50J2V1B




#### FTXS60/71GV1B




3D064800C

### 2.2.2 Floor Standing Type

### FVXG25/35/50K2V1B




### FVXS25/35/50FV1B



3D055953A

# 2.2.3 Floor / Ceiling Suspended Dual Type


### FLXS25/35/50/60BAVMB



3D033909F

## 2.2.4 Duct Connected Type


### FDXS25/35E7VMB, FDXS50/60C7VMB



3D045012M

### 2.2.5 Ceiling Mounted Cassette Type


### **FCQG35/50/60FVEB**



	INDOOR UNIT	DECENTED	ADICDLAY HAUT (ATTACHED	CONNECT	OR FOR OPTIONAL PARTS
A1P	PRINTED CIRCUIT BOARD		R/DISPLAY UNIT (ATTACHED ESS REMOTE	X2A	CONNECTOR
A2P				AZA	(SENSOR KIT)
		CONTROL		V0.4	
A3P	PRINTED CIRCUIT BOARD		PRINTED CIRCUIT BOARD	X8A	CONNECTOR
	(HUMIDITY SENSOR UNIT)		PRINTED CIRCUIT BOARD		(AUTO CLEAN PANEL)
C21	CAPACITOR	A5P	PUSH BUTTON (ON/OFF)	X24A	CONNECTOR (WIRELESS
C105	CAPACITOR	BS1	LIGHT EMITTING DIODE		REMOTE CONTROLLER)
F1U	FUSE (F, 5A, 250V)	H1P	(ON-RED)	X33A	CONNECTOR (ADAPTOR
HAP	LIGHT EMITTING DIODE		LIGHT EMITTING DIODE		FOR WIRING)
	(SERVICE MONITOR	H2P	(TIMER-GREEN)	X35A	CONNECTOR (GROUP
	GREEN)		LIGHT EMITTING DIODE		CONTROL ADAPTOR)
M1F	MOTOR (INDOOR FAN)	H3P	(FILTER SIGN-RED)	X36A	CONNECTOR (AUTO
M1P	MOTOR (DRAIN PUMP)		LIGHT EMITTING DIODE		CLEAN PANEL)
M1S-M4S	MOTOR (SWING FLAP)	H4P	(DEFROST-ORANGE)		
R1T	THERMISTOR (AIR)		SELECTOR SWITCH		
R2T-R3T	THERMISTOR (COIL)	SS1	(MAIN/SUB)		
S1L	FLOAT SWITCH	SS2	SELECTOR SWITCH		
SS1	SELECTOR SWITCH		(WIRELESS ADDRESS		
	(EMERGENCY)		SET)		
V1R	DIODE BRIDGÉ	AD	APTOR FOR WIRING		
X1M	TERMINAL BLOCK	F1U	FUOE (® 54 050)()		
X2M	TERMINAL BLOCK	F2U	FUSE (B), 5A, 250V)		
Z1C	FERRITE CORE	KCR	MAGNETIC RELAY		
	(NOISE FILTER)	KFR	MAGNETIC RELAY		
(Z1E)	NOISE FILTER	KHuR	MAGNETIC RELAY (Hu)		
(PS)	POWER SUPPLY CIRCUIT			•	
(RC)	SIGNAL RECEIVER				
	CIRCUIT				
TC	SIGNAL TRANSMISSION				
	CIRCUIT				
WIRED	REMOTE CONTROLLER				
R1T	THERMISTOR (AIR)				

3D074344

### FFQ25/35/50/60B9V1B



:TERMINAL

: CONNECTOR

-- : WIRE CLAMP

**≡** : FIELD WIRING

RED: RED BLK: BLACK

WHT: WHITE YLW: YELLOW

GRN: GREEN

- 1. IN CASE OF USING A REMOTE CONTROLLER, CONNECT IT TO THE UNIT IN ACCORDANCE TO THE ATTACHED INSTALLATION MANUAL.
- 2. X24A IS CONNECTED WHEN THE WIRELESS REMOTE CONTROLLER KIT IS BEING USED.
- 3. REMOTE CONTROLLER MODEL VARIES ACCORDING TO THE COMBINATION SYSTEM.
  - SEE TECHNICAL DATA AND CATALOGS, ETC. BEFORE CONNECTING.
- 4. GROUND THE SHIELD OF THE REMOTE CONTROLLER WIRE TO THE INDOOR UNIT.


(IN CASE OF USING SHIELD WIRE)

A1P	PRINTED CIRCUIT BOARD	WIRE	D REMOTE CONTROLLER		LESS REMOTE CONTROLLER	CONN	IECTOR FOR OPTIONAL PARTS
C1	CAPACITOR (M1F)	R1T	THERMISTOR (AIR)	(REC	EIVER/DISPLAY UNIT)	ХЗЗА	CONNECTOR
F1U	FUSE (F5A, 250V)	SS1	SELECTOR SWITCH (MAIN/SUB)	A3P	PRINTED CIRCUIT BOARD	ASSA	(ADAPTOR FOR WIRING)
HAP	LIGHT EMITTING DIODE			A4P	PRINTED CIRCUIT BOARD	X35A	CONNECTOR
	(SERVICE MONITOR GREEN)			BS1	PUSH BUTTON(ON/OFF)	ASSA	(GROU CONTROL ADAPTOR)
	MAGNETIC RELAY (M1P)			H1P	LIGHT EMITTING DIODE	X40A	CONNECTOR
M1F	MOTOR (INDOOR FAN)			піР	(ON-RED)	7407	(ON/OFF INPUT FROM OUTSIDE)
M1P	MOTOR (DRAIN PUMP)			H2P	LIGHT EMITTING DIODE	X60A	CONNECTOR
M1S	MOTOR (SWING FLAP)			паг	(TIMER-GREEN)	X61A	(INTERFACE ADAPTOR FOR SKY-AIR SERIES)
O1M	THERMO SWITCH			НЗР	LIGHT EMITTING DIODE		
	(M1F EMBEDDED)				(FILTER SIGN-RED)		
R1T	THERMISTOR (AIR)			H4P	LIGHT EMITTING DIODE		
R2T	THERMISTOR (COIL-1)				(DEFROST-ORANGE)		
R3T	THERMISTOR (COIL-2)			SS1	SELECTOR SWITCH		
S1L	FLOAT SWITCH				(MAIN/SUB)		
T1R	TRANSFORMER (220-240V/22V)			SS2	SELECTOR SWITCH		
V1TR	PHASE CONTROL CIRCUIT				(WIRELESS ADDRESS SET)	J	
X1M	TERMINAL STRIP						
X2M	TERMINAL STRIP						
RC	SIGNAL RECEIVER CIRCUIT						
TC	SIGNAL TRANSMISSION CIRCUIT						

3TW26476-1

### 2.2.6 Ceiling Suspended Type


### FHQ35/50/60BWV1B



3D074574A

## 2.2.7 Ceiling Mounted Built-in Type


### FDBQ25B8V1




A1P	PRINTED CIRCUIT BOARD	R1T	THERMISTOR (AIR)	ADAPT	OR FOR WIRING	FIELD SUPPLY		
T1R	POWER SUPPLY TRANSFORMER	R2T	THERMISTOR (LIQUID)	RyH	MAGNETIC RELAY	K1R	MAGNETIC RELAY	
	(TRANSFORMER 220-240V/218V)	R3T	THERMISTOR (COIL)	Q1L	THERMAL PROTECTOR	EH	ELECTRICAL HEATER KIT	
C1R	CAPACITOR (FAN)	RyF1-4	MAGNETIC RELAY (FAN)	CONNE	CTOR FOR OPTIONAL PARTS			
F1U	FUSE (5A, 250V)	SS1	SELECTOR SWITCH (EMERGENCY)	X60A, X61A	CONNECTOR (INTERFACE ADAPTOR FOR SKY			
F1T	THERMAL FUSE (152°C) (M1F	X1M	TERMINAL STRIP		AIR/US SERIEŠ)			
	EMBEDDED)	X2M	TERMINAL STRIP	X33A	CONNECTOR (ADAPTOR FOR WIRING)			
HAP	LIGHT EMITTING DIODE	RC	SIGNAL RECEIVER CIRCUIT	X35A	CONNECTOR (GROUP CONTROL ADAPTOR)			
	(SERVICE MONITOR-GREEN)	TC	SIGNAL TRANSMISSION CIRCUIT	X40A	CONNECTOR (REMOTE ON/OFF FORCED OFF)			
M1F	MOTOR (FAN)							

2TW25856-1B

### FBQ35/50C8VEB



### FBQ60C8VEB



Appendix 449

2TW31296-3



- Daikin products are manufactured for export to numerous countries throughout the world. Prior to
  purchase, please confirm with your local authorised importer, distributor and/or retailer whether this
  product conforms to the applicable standards, and is suitable for use, in the region where the product
  will be used. This statement does not purport to exclude, restrict or modify the application of any local
  legislation.
- Ask a qualified installer or contractor to install this product. Do not try to install the product yourself.
   Improper installation can result in water or refrigerant leakage, electrical shock, fire or explosion.
- Use only those parts and accessories supplied or specified by Daikin. Ask a qualified installer or contractor to install those parts and accessories. Use of unauthorised parts and accessories or improper installation of parts and accessories can result in water or refrigerant leakage, electrical shock, fire or explosion.
- Read the User's Manual carefully before using this product. The User's Manual provides important safety instructions and warnings. Be sure to follow these instructions and warnings.

If you have any enquiries, please contact your local importer, distributor and/or retailer.

### **Cautions on product corrosion**

- 1. Air conditioners should not be installed in areas where corrosive gases, such as acid gas or alkaline gas, are produced.
- 2. If the outdoor unit is to be installed close to the sea shore, direct exposure to the sea breeze should be avoided. If you need to install the outdoor unit close to the sea shore, contact your local distributor.

Dealer

### DAIKIN INDUSTRIES, LTD.

Head Office:

Umeda Center Bldg., 2-4-12, Nakazaki-Nishi, Kita-ku, Osaka, 530-8323 Japan

Tokyo Office:

JR Shinagawa East Bldg., 2-18-1, Konan, Minato-ku, Tokyo, 108-0075 Japan

http://www.daikin.com/global\_ac/

©All rights reserved