SPLIT TYPE ROOM AIR CONDITIONER

DUCT type INVERTER

SERVICE INSTRUCTION

Models Indoor unit Outdoor unit

AR*A12LATN AO*A12LACL AR*A14LATN AO*A14LACL AR*A18LATN AO*A18LACL AR*A24LATN AO*A24LACL AR*A36LATN AO*A36LATL AR*A45LATN AO*A45LATL



CONTENTS

1. SPECIFICATIONS	
SPECIFICATIONS	01-01
2. DIMENSIONS	
DIMENSIONS	02-01
3. REFRIGERANT SYSTEM DIAGRAM	
REFRIGERANT CIRCUIT	03-01
4. CIRCUIT DIAGRAM	
CIRCUIT DIAGRAM	04-01
5. DESCRIPTION OF EACH CONTROL OPERATION	
5-1 COOLING OPERATION	05-01
5-1-1 COOLING CAPACITY CONTROL	05-01
5-2 HEATING OPERATION	
5-2-1 HEATING CAPACITY CONTROL	
5-3 DRY OPERATION	
5-3-1 INDOOR UNIT CONTROL	
5-4 AUTO CHANGEOVER OPERATION	
5-5 INDOOR FAN CONTROL	
5-6 OUTDOOR FAN CONTROL	
5-7 COMPRESSOR CONTROL	
5-8 TIMER OPERATION CONTROL	
5-9 ELECTRONIC EXPANSION VALVE CONTROL	
5-10 TEST OPERATION CONTROL	
5-11 PREVENT TO START FOR 3 MINUTES (3 MINUTES ST)	
5-12 4-WAY VALVE EXTENSION SELECT	
5-14 PUMP DOWN (For AR*30/ 36/ 45LUAN/ 45/ 54LUAK)	
5-14 POMP DOWN (FOI AR 30/ 36/ 45LOAN/ 45/ 54LOAK)	
5-16 FRESH AIR CONTROL	
5-17 EXTERNAL ELECTRICAL HEATER CONTROL	
5-18 DEFROST OPERATION CONTROL	
5-19 OFF DEFROST OPERATION CONTROL	
5-20 ECONOMY OPERATION	
5-21 VARIOUS PROTECTIONS	
5-22 FORCED COOLING OPERATION	
5-23 COMPRESSOR STOP CONTROL	05-22

6. REFRIGERANT CAUTION -R410A-	
6-1 R410A TOOLS	06-01
6-2 PRECAUTION FOR INSTALLATION	
6-3 PRECAUTION FOR SERVICING	06-04
6-4 NEW REFRIGERANT R410A	06-05
6-5 DEFFERENCE FROM CONVENTIONAL MODEL (R22) AND PRECAUTIONS	06-08
7. TROUBLE SHOOTING	
7-1 ERROR DISPLAY	07-01
7-1-1 WIRED REMOTE CONTROLLER DISPLAY	07-01
7-1-2 OUTDOOR UNIT DISPLAY	07-03
7-2 TROUBLE SHOOTING WITH ERROR CODE	07-04
7-3 TROUBLE SHOOTING WITH NO ERROR CODE	07-30
7-4 SERVICE PARTS INFORMATION	07-35
8. APPENDING DATA	
8-1 CAPACITY TABLE	08-01
8-2 OPERATION RANGE	08-07
8-3 ELECTRIC CHARACTERISTICS	08-08
8-4 SAFETY DEVICE	08-10
8-5 FUNCTION SETTING	08-10
8-5-1 INDOOR UNIT	08-12
8-5-2 Procedures to change the Function Setting	08-14
8-5-3 WIRED REMOTE CONTROLLER	

9. INSTALLATION MANUAL



DUCT type INVERTER

1. SPECIFICATIONS

1. SPECIFICATIONS FOR INDOOR UNIT

T					DUCTE	D MODEL
Туре					INVERTER	HEATPUMP
Model name					AR * A12LATN	AR * A14LATN
Power source					230V	~ 50Hz
Available voltage	e range				198-264	V ~ 50Hz
European energ	v lahel			Cooling	A	A
Luropean energ	y label			Heating	A	Α
		Rated		kW	3.5	4.3
Co	Cooling	raica		BTU/h	11950	14650
Cooling		MinMax.		kW	0.9 - 4.4	0.9 - 5.4
Capacity		Willia Wida.		BTU/h	3100 - 15000	3100 - 18400
Capacity		Rated		kW	4.1	5.0
	Heating	rated		BTU/h	14000	17050
	ricating	MinMax.		kW	0.9 - 5.7	0.9 - 6.5
		ļ		BTU/h	3100 - 19400	3100 - 22100
	Cooling	Rated			1.05	1.33
Input power		*Max.		kW	1.73	2.07
	Heating	Rated			1.11	1.34
		*Max.			2.30	2.88
	Cooling	Rated			4.6	5.8
Current		*Max.		А	7.5	9.0
	Heating	Rated			4.9	5.9
		*Max.			10.0	12.5
EER		Cooling		kW/kW	3.33	3.21
COP		Heating			3.69	3.71
Moisture remova	al .			I/h (pints/h)	1.3 (2.3)	1.5 (2.6)
			High		720	820
			Med	m³/h	630	720
Airflow rate Fan			Low		560	610
	Airflow		Quiet		480	550
	rate		High		720	820
		Heating	Med		630	720
			Low		560	610
			Quiet		480	550
	Type × Q	-				cco × 2
	Motor out			W	60 0 to 90	
Recommended	static press	sure T	I	Pa		1
			High	- - dB(A)	32	33
		Cooling	Med		30	31
			Low		28	29
Sound pressure	level		Quiet		26 32	27
			High			33
		Heating	Med		30 28	31 29
			Low		28	29
		Quiet Dimensions (H × W × D)			294 × 700 × 26.6	27 294 × 700 × 39.9
		<u> </u>	v ^ U)	mm	1.30	294 × 700 × 39.9
Heat exchanger	type	Fin pitch Rows x Stages			2 × 14	3 × 14
out oxonanger	.,,,,	Pipe type				ppper 3 × 14
		Fin type				ninium
		Material				teel
Enclosure		Colour			-	-
Dimensions	Net	1001001				<u> </u>
(H×W ×D)	Gross			mm		075 × 686
,	Net				23 (51)	23 (51)
Weight	Gross			kg(lb.)	27 (60)	27 (60)
		Liquid			φ 6.35	(φ 1 / 4 in.)
Connection pipe	Size	Gas		mm	φ9.52 (φ3/8 in.)	φ12.70 (φ1/2 in.)
	Method			1	. , , , , , , , , , , , , , , , , , , ,	lare
				°C		to 32
Operation range	:	Cooling		%RH		or less
		Heating		°C		or less
Remote controll	er type	<u> </u>				/ired
	Material					PS
Drain pipe	Size			mm		/ Inner_diameter : 21.5
					,	

Note:
Specifications are based on the following conditions.
Cooling: Indoor temperature of 27 °CDB / 19 °CWB.and outdoor temperature of 35 °CDB/24 °CWB.
Heating: Indoor temperature of 20 °CDB / 15 °CWB.and outdoor temperature of 7 °CDB/6 °CWB.
Standard static pressure: 0 Pa
Pipe length: 7.5 m, Height difference: 0 m.(Outdoor unit - Indoor unit)
Sound pressure level: Install a 2m duct to the outlet port and a 1m duct to the suction port and measure.
*The maximum current and the maximum input value are the maximum values when operated within the operation (temperature) range.

					DUCTED MODEL		
Туре				F	INVERTER HEATPUMP		
Model name					AR * A18LATN		
Power source					230V∼ 50Hz		
Available voltag	ge range				198-264V ~ 50Hz		
1				Cooling	A		
European ener	gy label			Heating	A		
		D. L. J		kW	5.2		
		Rated		BTU/h	17700		
	Cooling			kW	0.9 - 5.9		
		Min-Max		BTU/h	3100 - 20100		
Capacity		Datad		kW	6.0		
	Llooting	Rated		BTU/h	20500		
	Heating	Min-Max		kW	0.9 - 7.5		
		IVIII I-IVIAX		BTU/h	3100 - 25600		
	Cooling	Rated		l L	1.62		
Input power	Cooming	Min-Max		kW	0.09 - 1.80		
input power	Heating	Rated		l "'' L	1.66		
	ricating	Min-Max			0.09 - 2.46		
	Cooling	Rated		ļ L	7.1		
Current	Sooning	Max		A	9.0		
	Heating	Rated		ļ	7.3		
		Max			10.8		
EER		Cooling		kW/kW	3.21		
COP		Heating			3.61		
Moisture remov	val		1	I/h (pints/h)	2.0 (3.5)		
			High		820		
		Cooling	Med	↓	720		
			Low		610		
	Airflow		Quiet	m³/h	550		
Fan	rate	Heating	High	↓ [,]	820		
			Med	↓	720		
			Low	↓	610		
			Quiet		550		
	Type × Q	-			Sirocco × 2		
_	Motor out			W	60		
Recommended	static pres	sure	T	Pa	0 to 90		
			High	∤ ⊢	33		
		Cooling	Med	∤ ⊦	31		
			Low	 	29		
Sound pressure	e level		Quiet	dB(A)	27		
			High Med	┤ ├	33 31		
		Heating	Low	ł - -	29		
			Quiet	<u> </u>	27		
		Dimensions (H × W		+	294 × 700 × 39.9		
		Fin pich	· 5)	mm –	1.30		
Heat exchange	er type	Rows x Stages			3 × 14		
onoriungo	.,,,,	Pipe type		+	Copper		
		Fin type			Aluminium		
		Material		+	Steel		
Enclosure		Colour		+	-		
Dimensions	Net	1			217 × 953 × 595		
(H×W×D)	Gross			mm –	324 × 1075 × 686		
	Net			·	23 (51)		
Weight	Gross			kg(lb.)	27 (60)		
		Liquid			φ 6.35 (φ 1 / 4 in.)		
Connection pip	Size	Gas		mm –	φ12.70 (φ1/2 in.)		
	Method	•		•	Flare		
	•	Caalia		°C	18 to 32		
Operation range		Cooling		%RH	80 or less		
		Heating		°C	30 or less		
Operation rang	Heating			30 OI 1033			
Operation rang Remote contro	ller type	ricating		' 	Wired		
	ller type Material	ricating					

Note:
Specifications are based on the following conditions.
Cooling: Indoor temperature of 27 °CDB / 19 °CWB.and outdoor temperature of 35 °CDB/24 °CWB.
Heating: Indoor temperature of 20 °CDB / 15 °CWB.and outdoor temperature of 7 °CDB/6 °CWB.
Standard static pressure: 0 Pa
Pipe length: 7.5 m, Height difference: 0 m.(Outdoor unit - Indoor unit)
Sound pressure level: Install a 2m duct to the outlet port and a 1m duct to the suction poit and measure.

Torre					DUCTED MODEL
Туре					INVERTER HEATPUMP
Model name					AR * A24LATN
Power source					230V∼ 50Hz
Available voltage	ge range			1	198-264V ~ 50Hz
European ener	gy label			Cooling	A
		1		Heating	A
		Rated		kW	7.1
	Cooling			BTU/h	24200
		Min-Max		kW BTU/h	0.9 - 8.0
Capacity				kW	3100 - 27300 8.0
		Rated		BTU/h	27300
	Heating			kW	0.9 - 9.1
		Min-Max		BTU/h	3100 - 31000
		Rated			2.21
	Cooling	Min-Max		i	0.09 - 2.62
Input power	I I a ation a	Rated		kW	2.21
	Heating	Min-Max			0.09 - 2.77
	Cooling	Rated			9.7
Current	Cooling	Max		A	11.5
Carront	Heating	Rated			9.7
	licating	Max			12.2
EER		Cooling		kW/kW	3.21
COP		Heating			3.61
Moisture remov	val	_	T	I/h (pints/h)	2.5 (4.4)
			High	├	1100
		Cooling	Med	<u> </u>	950
	1		Low	├	800
	Airflow rate		Quiet	m³/h	600
Fan	Tate	Heating	High Med	ł –	1100 950
			Low	ł –	800
			Quiet	l -	600
	Type × Q	l 'tv	Quict		Sirocco × 2
	Motor out	-		W	115
Recommended		•		Pa	30 to 150
			High		31
		0 - 11	Med		29
		Cooling	Low		27
Cound procesur	o loval		Quiet	4D(A)	25
Sound pressur	e ievei		High	dB(A)	31
		Heating	Med		29
		Heating	Low	ļ L	27
			Quiet		25
		Dimensions (H × W	× D)	mm –	294 × 1000 × 39.9
		Fin pich			1.40
Heat exchange	er type	Rows x Stages			3 × 14
		Pipe type			Copper
		Fin type			Aluminium
Enclosure		Material			Steel
	Not	Colour			
Dimensions (H×W×D)	Net Gross			mm –	270 × 1135 × 700
(** ** ** **)	Net				300 × 1300 × 790 38 (84)
Weight	Gross			kg(lb.)	45 (99)
		Liquid			φ 6.35 (φ 1/4 in.)
Connection pip	Size	Gas		mm –	φ 15.88 (φ 5 / 8 in.)
	Method	1		-	Flare
		I		°C	18 to 32
		Cooling		%RH	80 or less
Operation rang		Lla ations		°C	
Operation rang	Heating				30 or less
Operation rang	ller type	Heating		C	Wired
	ller type Material	Heating			

Note:
Specifications are based on the following conditions.
Cooling: Indoor temperature of 27 °CDB / 19 °CWB.and outdoor temperature of 35 °CDB/24 °CWB.
Heating: Indoor temperature of 20 °CDB / 15 °CWB.and outdoor temperature of 7 °CDB/6 °CWB.
Standard static pressure: 30 Pa
Pipe length: 7.5 m, Height difference: 0 m.(Outdoor unit - Indoor unit)
Sound pressure level: Install a 2m duct to the outlet port and a 1m duct to the suction poit and measure.

Capacity Hea Input power Hea Coo Current Hea EER COP Moisture removal Airfl rate			Cooling Heating kW BTU/h kW BTU/h kW BTU/h kW BTU/h kW A	AR * A36LATN 230V~	HEATPUMP AR * A45LATN 50Hz 50Hz A A 12.5 42700 4.0 - 14.0 13700 - 47800 14.0 47800 4.2 - 16.2 14300 - 55300 3.89 4.56 3.77 4.56 17.0
Power source Available voltage rang European energy labe Coo Capacity Hea Input power Hea Coo Current Hea EER COP Moisture removal Airfl rate	Rated MinMax. Rated MinMax. Rated MinMax. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Cooling		Heating kW BTU/h kW BTU/h kW BTU/h kW BTU/h kW KW BTU/h	230V~ 198-264V A A 10.0 34100 3.8 - 11.2 13000 - 38200 11.2 38200 4.0 - 14.0 13700 - 47800 3.11 4.33 3.02 4.33 13.6	A A 12.5 A 2700 A 14.0 A 15.0
Available voltage rang European energy labo Coo Capacity Hea Input power Hea Coo Current Hea EER COP Moisture removal Airfl rate	Rated MinMax. Rated MinMax. Rated MinMax. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Cooling		Heating kW BTU/h kW BTU/h kW BTU/h kW BTU/h kW KW BTU/h	198-264V A A 10.0 34100 3.8 - 11.2 13000 - 38200 11.2 38200 4.0 - 14.0 13700 - 47800 3.11 4.33 3.02 4.33 13.6	~ 50Hz A A 12.5 42700 4.0 - 14.0 13700 - 47800 14.0 47800 4.2 - 16.2 14300 - 55300 3.89 4.56 3.77 4.56
European energy labo Coo Capacity Hea Input power Hea Coo Current Hea EER COP Moisture removal Airfl rate	Rated MinMax. Rated MinMax. Rated MinMax. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Cooling		Heating kW BTU/h kW BTU/h kW BTU/h kW BTU/h kW KW BTU/h	A A 10.0 34100 3.8 - 11.2 13000 - 38200 11.2 38200 4.0 - 14.0 13700 - 47800 3.11 4.33 3.02 4.33 13.6	A A A 12.5 42700 4.0 - 14.0 13700 - 47800 14.0 47800 4.2 - 16.2 14300 - 55300 3.89 4.56 3.77 4.56
Coo Capacity Hea Input power Hea Coo Current Hea EER COP Moisture removal Airfl rate	Rated MinMax. Rated MinMax. Rated MinMax. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Cooling		Heating kW BTU/h kW BTU/h kW BTU/h kW BTU/h kW KW BTU/h	A 10.0 34100 3.8 - 11.2 13000 - 38200 11.2 38200 4.0 - 14.0 13700 - 47800 3.11 4.33 3.02 4.33 13.6	A 12.5 42700 4.0 - 14.0 13700 - 47800 14.0 47800 4.2 - 16.2 14300 - 55300 3.89 4.56 3.77 4.56
Capacity Hea Input power Hea Coo Current Hea EER COP Moisture removal Airfl rate	MinMax. Rated MinMax. Rated *Max. Cooling		kW BTU/h kW BTU/h kW BTU/h kW BTU/h kW KW	10.0 34100 3.8 - 11.2 13000 - 38200 11.2 38200 4.0 - 14.0 13700 - 47800 3.11 4.33 3.02 4.33 13.6	12.5 42700 4.0 - 14.0 13700 - 47800 14.0 47800 4.2 - 16.2 14300 - 55300 3.89 4.56 3.77 4.56
Capacity Hea Input power Hea Coo Current Hea EER COP Moisture removal Airfl rate	MinMax. Rated MinMax. Rated *Max. Cooling		BTU/h kW BTU/h kW BTU/h kW BTU/h kW KW BTU/h	34100 3.8 - 11.2 13000 - 38200 11.2 38200 4.0 - 14.0 13700 - 47800 3.11 4.33 3.02 4.33 13.6	42700 4.0 - 14.0 13700 - 47800 14.0 47800 4.2 - 16.2 14300 - 55300 3.89 4.56 3.77 4.56
Capacity Hea Input power Hea Coo Current Hea EER COP Moisture removal Airfl rate	MinMax. Rated MinMax. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Cooling		kW BTU/h kW BTU/h kW BTU/h kW	3.8 - 11.2 13000 - 38200 11.2 38200 4.0 - 14.0 13700 - 47800 3.11 4.33 3.02 4.33 13.6	4.0 - 14.0 13700 - 47800 14.0 47800 4.2 - 16.2 14300 - 55300 3.89 4.56 3.77 4.56
Capacity Hea Input power Hea Coo Current Hea EER COP Moisture removal Airfl rate	MinMax. Rated MinMax. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Cooling		BTU/h kW BTU/h kW BTU/h	13000 - 38200 11.2 38200 4.0 - 14.0 13700 - 47800 3.11 4.33 3.02 4.33 13.6	13700 - 47800 14.0 47800 4.2 - 16.2 14300 - 55300 3.89 4.56 3.77 4.56
Heal Input power Heal Coo Current Heal EER COP Moisture removal Airfl rate	MinMax. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Cooling		kW BTU/h kW BTU/h	11.2 38200 4.0 - 14.0 13700 - 47800 3.11 4.33 3.02 4.33 13.6	14.0 47800 4.2 - 16.2 14300 - 55300 3.89 4.56 3.77
Heal Input power Heal Coo Current Heal EER COP Moisture removal Airfl rate	MinMax. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Cooling		BTU/h kW BTU/h	38200 4.0 - 14.0 13700 - 47800 3.11 4.33 3.02 4.33 13.6	47800 4.2 - 16.2 14300 - 55300 3.89 4.56 3.77 4.56
Input power Hea Coo Current Hea EER COP Moisture removal Airfl rate	MinMax. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Cooling		kW BTU/h kW	4.0 - 14.0 13700 - 47800 3.11 4.33 3.02 4.33 13.6	4.2 - 16.2 14300 - 55300 3.89 4.56 3.77 4.56
Input power Hea Coo Current Hea EER COP Moisture removal Airfl rate	MinMax. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Cooling		BTU/h	13700 - 47800 3.11 4.33 3.02 4.33 13.6	14300 - 55300 3.89 4.56 3.77 4.56
Input power Hea Coo Current Hea EER COP Moisture removal Airfl rate	Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Rated *Max. Cooling		kW	3.11 4.33 3.02 4.33 13.6	3.89 4.56 3.77 4.56
Input power Hea Coo Current Hea EER COP Moisture removal Airfl rate	*Max. Rated *Max. Rated Rated Rated Rated Rated Rated Rated Rated			4.33 3.02 4.33 13.6	4.56 3.77 4.56
Input power Hea Coo Current Hea EER COP Moisture removal Airfl rate	"Max. Rated "Max. Rated "Max. Rated "Max. Rated "Max. Rated "Max. Cooling			3.02 4.33 13.6	3.77 4.56
Coo Current Hea EER COP Moisture removal Airfl rate	*Max. Rated *Max. Rated *Max. Rated *Max. Cooling			4.33 13.6	4.56
Current Hea EER COP Moisture removal Airfl rate	*Max. Rated *Max. Rated *Max. Rated *Max. Cooling		A	13.6	
Current Hea EER COP Moisture removal Airfl rate	*Max. Rated *Max. Cooling		A		17.0
Current Hea EER COP Moisture removal Airfl rate	*Max. Rated *Max. Cooling		А	19.0	
EER COP Moisture removal Airfl	*Max. Cooling		_ ^		20.0
EER COP Moisture removal Airfl	*Max. Cooling		1	13.2	16.5
COP Moisture removal Airfl				19.0	20.0
Moisture removal Airfl	Heating		14/4///-/4/	3.21	3.21
Airfl rate	·		kW/kW	3.71	3.71
rate			l/h (pints/h)	3.0 (5.3)	3.5 (6.2)
rate		High		2020	2250
rate		Med	1	1710	1710
rate	Cooling	Low	1	1340	1340
rate	low	Quiet	m ³ /h	1020	1020
		High		2020	2250
Fan		Med		1710	1710
	Heating	Low		1340	1340
		Quiet	1	1020	1020
Typ	e × Q'ty	Quiot	l	Sirocco × 2	Sirocco × 2
l	tor output		W	197	197
Recommended static			Pa	30 to 150	30 to 150
recommended static	pressure	High	ıα	42	44
		Med	1	37	38
	Cooling	Low		32	33
		Quiet	1	29	29
Sound pressure level	I -	High	dB(A)	42	44
		Med		37	38
	Heating	Low		32	33
		Quiet		29	29
-	Dimensions (L	Dimensions (H × W × D)		294 × 1000 × 53.2	294 × 1000 × 53.2
	Fin pitch	<u> </u>		1.40	1.40
Heat exchanger type		<u> </u>		4 × 14	4 × 14
i loat oxorianger type	Pipe type			Copper	Copper
	Fin type			Copper Aluminium	Copper
	Material			Steel	Aluminium Steel
Enclosure					
Branco Israel	Colour		1	- 270 × 1125 × 700	- 270 × 4425 × 700
Dimensions Net (H × W × D) Gros			mm	270 × 1135 × 700 300 × 1300 × 790	270 × 1135 × 700
					300 × 1300 × 790
Weight			kg(lb.)	41 (90)	41 (90)
Gro				48 (106)	48 (106)
Size	e Liquid		mm	φ 9.52 (φ 3 / 8 in.)	φ 9.52 (φ 3 / 8 in.)
Connection pipe	Gas		L	φ15.88 (φ5/8 in.)	φ15.88 (φ 5 / 8 in.)
Met	thod			Flare	Flare
	Cooling		°C	18 to 32	18 to 32
Operation range			%RH	80 or less	80 or less
	Heating		°C	30 or less	30 or less
Remote controller typ	oe			Wired	Wired
Mate	terial			Steel	Steel
Drain pipe Material			mm	Outer diameter : 38.0 / Inner diameter : 36.0	Outer diameter : 38.0 / Inner diameter : 36.0

Note:

Note:
Specifications are based on the following conditions.
Cooling: Indoor temperature of 27 °CDB / 19 °CWB.and outdoor temperature of 35 °CDB/24 °CWB.
Heating: Indoor temperature of 20 °CDB / 15 °CWB.and outdoor temperature of 7 °CDB/6 °CWB.
Standard static pressure: 30Pa
Pipe length: 7.5 m, Height difference: 0 m.(Outdoor unit - Indoor unit)
Sound pressure level: Install a 2m duct to the outlet port and a 1m duct to the suction poit and measure.
*The maximum current and the maximum input value are the maximum values when operated within the operation (temperature) range.

2. SPECIFICATIONS FOR OUTDOOR UNIT

Туре	Туре			INVERTER HEATPUMP		
Model name				AO * A12LACL	AO * A14LACL	
Power source				230V~	50Hz	
Available voltage	range			198-264V	~ 50Hz	
Starting current			Α	4.9	5.9	
	Airflow	Cooling	m³/h	1780	1910	
Fon	rate	Heating	m [*] /n	1630	1740	
Fan	Type × Q	ty		Propel	ler × 1	
	Motor out	put	W	54	4	
Sound proceure I	ovol	Cooling	4D(V)	47	49	
Sound pressure I	evei	Heating	dB(A)	48	49	
		Dimensions (H × W × D)	mm	546 × 87 546 × 84		
Heat exchanger t	vpe	Fin pitch		1.30		
	Rows x Stages			2 ×	26	
		Pipe type		Сор	per	
	Fin type			Alumi	nium	
Type × Q'ty			Twin Ro	tary × 1		
Compressor	Motor out	put	W	11	00	
Refrigerant		Туре		R47	10A	
Reingerant		Charge	g	1150	1250	
Refrigerant oil		Туре		PC)E	
Enclosure		Material		Steel	sheet	
Eliciosure		Colour		Beige (10YF	R7.5/1.0NN)	
Dimensions	Net		mm	578 × 790 × 300		
$(H \times W \times D)$	Gross		mm	648 × 91	10 × 380	
Woight	Net		ka(lb.)	40 (88)	40 (88)	
Weight	Gross		kg(lb.)	44 (97)	44 (97)	
	Size	Liquid	mm	φ6.35 (φ 1/4 in.)	
	JIZ6	Gas	mm	φ9.52 (φ3/8 in.)	ϕ 12.70 (ϕ 1/2 in.)	
Connection pipe	Method			Fla	are	
	Max. leng	th	m	25 (charge	eless : 15)	
	Max. heig	ht difference	111	1	5	
Operation range		Cooling	°C	-10 t	o 46	
Operation range		Heating		-15 t	o 24	

Specifications are based on the following conditions.

Cooling: Indoor temperature of 27°CDB/19°CWB. and outdoor temperature of 35°CDB/24°CWB. Heating: Indoor temperature of 20°CDB/15°CWB. and outdoor temperature of 7°CDB/6°CWB. Pipe length: 7.5 m, Height difference: 0 m. (Outdoor unit - Indoor unit)

Туре			INVERTER HEATPUMP			
Model name				AO * A18LACL	AO * A24LACL	
Power source				230V~ 50Hz		
Available voltag	e range			198-264	√~ 50Hz	
Starting current	Э		Α	7.7	10.0	
Airflow		Cooling	m ³ /h	2000	2470	
F	rate	Heating	m ⁻ /n	1910	2470	
Fan	Type × C	Q'ty		Prope	eller × 1	
	Motor ou	tput	W	54	65	
Carrad massacras	laval	Cooling	dD(A)	50	52	
Sound pressure	ievei	Heating	dB(A)	50	53	
		Dimensions (H × W × D)	mm	546 × 876 × 18.2 546 × 842 × 18.2	546 × 866 × 18.2 546 × 832 × 18.2 504 × 589 × 18.2	
Heat exchanger	type	Fin pich	ĺ	1.30	1.40	
	<i>,</i>	Rows x Stages		2 × 26	2 × 26 1 × 24	
Pipe type			Co	pper		
		Fin type		Alum	ninium	
Compressor	Type × C	Q'ty		Twin R	otary × 1	
Compressor	Motor ou	tput	W	1	100	
Dofrigoront		Туре		R410A		
Refrigerant		Charge	g	1250	1700	
Refrigerant oil		Туре		Р	OE	
Enclosure		Material		Stee	l sheet	
Eliciosure		Colour		Beige (10YR7.5/1.0NN)		
Dimensions	Net		mm	578 × 790 × 300	578 × 790 × 315	
(H×W×D)	Gross		111111	648 × 910 × 380		
Weight	Net		kg(lb.)	40 (88)	44 (97)	
Weight	Gross		kg(ib.)	44 (97)	48 (106)	
	Size	Liquid	mm	φ6.35 ((φ1/4 in.)	
	SIZE	Gas	mm	ϕ 12.70 (ϕ 1/2 in.)	φ 15.88(φ 5/8 in.)	
Connection pipe	Method			FI	are	
	Max. len	gth	m	25(chargeless : 15)	30(chargeless : 15)	
	Max. hei	ght difference	m	15	20	
Operation range		Cooling	°C	-10	to 46	
Operation range	;	Heating		-15	to 24	

Specifications are based on the following conditions.

Cooling: Indoor temperature of 27°CDB/19°CWB. and outdoor temperature of 35°CDB/24°CWB. Heating: Indoor temperature of 20°CDB/15°CWB. and outdoor temperature of 7°CDB/6°CWB. Pipe length: 7.5 m, Height difference: 0 m. (Outdoor unit - Indoor unit)

Туре				INVERTER HEATPUMP		
Model name				AO * A36LATL	AO * A45LATL	
Power source			230V~	50Hz		
Available voltage	range			198-264V	~ 50Hz	
Starting current			А	15.0	15.0	
	Airflow	Cooling	m ³ /h	6600	6600	
Fon	rate	Heating	m /n	6600	6600	
Fan	Type × Q'	ty		Propel	ler × 2	
	Motor out	put	W	103 × 2	103 × 2	
Cound procesure	ovol	Cooling	4D(A)	54	55	
Sound pressure I	evei	Heating	dB(A)	55	56	
		Dimensions (H × W × D)	m.m.	1260 × 900 × 36.4	1260 × 900 × 36.4	
l		Fin pitch	mm	1.30	1.30	
Heat exchanger	type	Rows x Stages		2 × 60	2 × 60	
		Pipe type		Copper		
Fin type			Alumi	nium		
Type × Q'ty			Twin Ro	tary × 1		
Compressor	Motor out	put	W	37	50	
Refrigerant		Туре		R41	10A	
Reingerant		Charge	g	33	50	
Refrigerant oil		Туре		PC)E	
Enclosure		Material		Steel	sheet	
Liiciosure		Colour		Beige (10YF	R7.5/1.0NN)	
Dimensions	Net		mm	1290 × 900 × 330		
(H × W × D)	Gross		'''''	1430 × 1050 × 445		
Weight	Net		kg(lb.)	98 (216)		
vveignt	Gross		kg(ib.)	107 (236)		
	Size	Liquid	mm	ϕ 9.52 (<i></i> 3/8 in.)	
	OIZE	Gas	111111	φ 15.88 (φ 5/8 in.)		
Connection pipe				Fla	are	
	Max. leng	th	m	50 (chargeless : 20)	50 (chargeless : 20)	
	Max. heig	ht difference		30	30	
Operation range		Cooling	°C	-15 t	o 46	
		Heating		-15 t	o 24	

Specifications are based on the following conditions.

Cooling: Indoor temperature of 27°CDB/19°CWB. and outdoor temperature of 35°CDB/24°CWB. Heating: Indoor temperature of 20°CDB/15°CWB. and outdoor temperature of 7°CDB/6°CWB. Pipe length: 7.5 m, Height difference: 0 m. (Outdoor unit - Indoor unit)





DUCT type INVERTER

2. DIMENSIONS


2. DIMENSIONS

■ MODEL: AR*A12LATN / AO*A12LACL AR*A14LATN / AO*A14LACL







■ MODEL: AR*A18LATN / AO*A18LACL




(Unit: mm)







- ① Refrigerant piping flare connection (Gas)
- 2 Refrigerant piping flare connection (Liquid)
- ③ Drain piping connection




■ MODEL: AR*A24LATN / AO*A24LACL






02-03

■ MODEL: AR*A36LATN / AO*A36LATL AR*A45LATN / AO*A45LATL








DUCT type INVERTER


3. REFRIGERANT SYSTEM DIAGRAM

3. REFRIGERANT CIRCUIT


■ MODEL: AR*A12LATN / AO*A12LACL




■ MODEL: AR*A14LATN / AO*A14LACL AR*A18LATN / AO*A18LACL



■ MODEL: AR*A24LATN / AO*A24LACL



■ MODEL: AR*30/36LUAN/AO*30/36LMAWL






DUCT type INVERTER


4. CIRCUIT DIAGRAM

4. CIRCUIT DIAGRAM


■ MODEL: AR*A12/ 14/ 18LATN




■ MODEL: AR*A24/36/45LATN



■ MODEL: AO*A12/ 14/ 18/ 24LACL



■ MODEL : AO*A36/45LATL





DUCT type INVERTER

5. DESCRIPTION OF EACH CONTROL OPERATION

5-1-1 COOLING CAPACITY CONTROL


A sensor (room temperature thermistor) built in the indoor unit will usually perceive difference or variation between a set temperature and present room temperature, and controls the operation frequency of the compressor.

- * If the room temperature is 2 degC higher than a set temperature, the compressor operation frequency will attain to maximum performance.
- * If the room temperature is 2.5 degC lower than a set temperature, the compressor will be stopped.
- * When the room temperature is between +2 degC to -2.5 degC of the setting temperature, the compressor frequency is controlled within the range shown in Table1. However, the maximum frequency is limited in the range shown in Figure 1 based on the fan speed mode and the outdoor temperature.

(Table 1 : Compressor Frequency Range)

	minimum frequency	maximum frequency
AR*A12LATN	18Hz	80Hz
AR*A14LATN	18Hz	113Hz
AR*A18LATN	18Hz	113Hz
AR*A24LATN	18Hz	113Hz
AR*A36LATN	18Hz	70Hz
AR*A45LATN	18Hz	77Hz

(Fig. 1: Limit of Maximum Frequency based on Outdoor Temperature)



Fan s	peed mode	Hi	Me	Lo	Quiet
AR*A12LATN	A zone	80Hz	49Hz	42Hz	34Hz
	B zone	80Hz	49Hz	42Hz	34Hz
	C zone	80Hz	49Hz	42Hz	34Hz
	D-F zone	49Hz	38Hz	30Hz	22Hz
AR*A14LATN	A zone	113Hz	66Hz	54Hz	34Hz
	B zone	113Hz	66Hz	54Hz	34Hz
	C zone	80Hz	54Hz	45Hz	34Hz
	D-F zone	54Hz	45Hz	38Hz	24Hz
AR*A18LATN	A zone	113Hz	66Hz	54Hz	34Hz
	B zone	113Hz	66Hz	54Hz	34Hz
	C zone	80Hz	54Hz	45Hz	34Hz
	D-F zone	54Hz	45Hz	38Hz	24Hz
AR*A24LATN	A zone	113Hz	66Hz	54Hz	34Hz
	B zone	113Hz	66Hz	54Hz	34Hz
	C zone	80Hz	54Hz	45Hz	34Hz
	D-F zone	54Hz	45Hz	38Hz	24Hz
AR*A36LATN	A zone	70Hz	43Hz	37Hz	29Hz
	B zone	70Hz	43Hz	37Hz	29Hz
	C zone	48Hz	37Hz	33Hz	29Hz
	D-F zone	37Hz	33Hz	29Hz	23Hz
AR*A45LATN	A zone	77Hz	48Hz	41Hz	31Hz
	B zone	77Hz	48Hz	41Hz	31Hz
	C zone	55Hz	41Hz	37Hz	31Hz
	D-F zone	41Hz	37Hz	33Hz	25Hz

5-2. HEATING OPERATION

5-2-1 HEATING CAPACITY CONTROL


A sensor (room temperature thermistor) built in the indoor unit will usually perceive difference or variation between a set temperature and present room temperature, and controls the operation frequency of the compressor.

- * If the room temperature is lower 3 degC than a set temperature, the compressor operation frequency will attain to maximum performance.
- * If the room temperature is higher 2.5 degC than a set temperature, the compressor will be stopped.
- * When the room temperature is between +2.5 degC to -3 degC of the setting temperature, the compressor frequency is controlled within the range shown in Table2. However, the maximum frequency is limited in the range shown in Figure 2 based on the outdoor temperature.

(Table 2: Compressor Frequency Range)

	minimum frequency	maximum frequency
AR*A12LATN	18Hz	120Hz
AR*A14LATN	18Hz	120Hz
AR*A18LATN	18Hz	120Hz
AR*A24LATN	18Hz	120Hz
AR*A36LATN	18Hz	90Hz
AR*A45LATN	18Hz	90Hz

(Fig.2: Limit of Maximum Frequency based on Outdoor Temperature)



Fan speed mode		Hi Me+	Me	Lo	Quiet
AR*A12LATN	A zone	120Hz	70Hz	60Hz	49Hz
	B zone	120Hz	70Hz	60Hz	49Hz
	C zone	120Hz	70Hz	60Hz	49Hz
AR*A14LATN	A zone	120Hz	101Hz	75Hz	60Hz
	B zone	120Hz	101Hz	75Hz	60Hz
	C zone	120Hz	101Hz	75Hz	60Hz
AR*A18LATN	A zone	120Hz	101Hz	75Hz	60Hz
	B zone	120Hz	101Hz	75Hz	60Hz
	C zone	120Hz	101Hz	75Hz	60Hz
AR*A24LATN	A zone	120Hz	101Hz	75Hz	60Hz
	B zone	120Hz	101Hz	75Hz	60Hz
	C zone	120Hz	101Hz	75Hz	60Hz
AR*A36LATN	A zone	90Hz	66Hz	53Hz	45Hz
	B zone	90Hz	66Hz	53Hz	45Hz
	C zone	90Hz	66Hz	53Hz	45Hz
AR*A45LATN	A zone	90Hz	66Hz	53Hz	45Hz
	B zone	90Hz	66Hz	53Hz	45Hz
	C zone	90Hz	66Hz	53Hz	45Hz

5-3. DRY OPERATION


5-3-1 INDOOR UNIT CONTROL

The compressor rotation frequency shall change according to set temperature and room temperature variation which the room temperature sensor of the indoor unit has detected as shown in the Fig 3.


(Table 3: Compressor frequency)

	Operating frequency
AR*A12LATN	34Hz
AR*A14LATN	34Hz
AR*A18LATN	34Hz
AR*A24LATN	34Hz
AR*A36LATN	31Hz
AR*A45LATN	31Hz

(Fig.3: Compressor Control based on Room Temperature)



(Fig.4: Indoor Fan Control)



5-4. AUTO CHANGEOVER OPERATION

When the air conditioner is set to the AUTO mode by remote control, operation starts in the optimum mode from among the HEATING, COOLING, DRY and MONITORING modes. During operation, the optimum mode is automatically swiched in accordance with temperature changes. The temperature can be set between 18°C and 30°C in 1 degC steps.

① When operation starts, only the indoor and outdoor fans are operated for 1 minute. After 1 minute, the room temperature and outdoor air temperature are sensed and the operation mode is selected in accordance with the table below.

(Fig.5: Outdoor air temperature zone selection)

[For AR*A	A12/ 14/ 18/ 24LATN]	[For AR*A	36/ 45LATN]
32°C -	C zone	32°C —	C zone
0_ 0	B zone	0_ 0	B zone
-10°C -	A zone	-15°C —	A zone

(Table 4 : Operation mode selection table)


Outdoor temperature :To Room temperature :Tb	A zone	B zone	C zone
Tb > Ts +2 degC	Monitoring	Cooling (Automatic Dry)	Cooling (Automatic Dry)
Ts +2 degC ≥ Tb ≥ Ts-2 degC	Monitoring	Monitoring	Monitoring
Ts +2 degC > Tb	Heating	Heating	Monitoring

Ts: Setting temperature

- ② When COOLING was selected at ①, the air conditioner operates as follow:
 - The same operation as COOLING OPERATION of item 5-1 above is performed.

 However, the setting temperature is raised 1degC and the room temperature correct coefficient value is 0°C
 - When the compressor frequency have been below 20Hz for 8 minutes or the room temperature reaches "setting temperature -1.5°C", operation is automatically switched to DRY OPERATION of item 5-3 above is performed.

However, compressor control based on room temperature is as follows.



- If the room temperature reaches "setting temperature +2°C" during DRY operation, operation returns to COOLING operation.
- ③ When HEATING was selected at ⊕, the same operation as HEATING OPERATION of item 5-2 above is performed. However, the room temperature correct coefficient value is 0°C.
- When the compressor was stopped for 6 consecutive minutes by the temperature control function after the COOLING or HEATING operation mode was selected at ① above, operation is switched to MONITORING and the operation mode is selected again.

5-5. INDOOR FAN CONTROL

1. Fan speed

(Table 5: Indoor Fan Speed)

-AR*A12LATN

, u () () = = , u () () ()		
Operation mode	Air flow mode	Speed (rpm)
Cooling	Hi	880
Heating	Me	780
Fan	Lo	720
	Quiet	620
Dry	Auto	620
Monitoring	S- Lo	450

-AR*A18LATN

Operation mode	Air flow mode	Speed (rpm)
Cooling	Hi	1040
Heating	Me	950
Fan	Lo	840
	Quiet	740
Dry	Auto	740
Monitoring	S- Lo	450

-AR*A36LATN

Operation mode	Air flow mode	Speed (rpm)
Cooling	Hi	1200
Heating	Me	1020
Fan	Lo	840
	Quiet	670
Heating	Hi	1220
	Me	1020
	Lo	840
	Quiet	670
Dry	Auto	670
Monitoring	S- Lo	370

-AR*A14LATN

Operation mode	Air flow mode	Speed (rpm)
Cooling	Hi	1040
Heating	Me	950
Fan	Lo	840
	Quiet	740
Dry	Auto	740
Monitoring	S- Lo	450

-AR*A24LATN

Operation mode	Air flow mode	Speed (rpm)
Cooling	Hi	830
Heating	Me	700
Fan	Lo	600
	Quiet	550
Dry	Auto	550
Monitoring	S- Lo	350

-AR*A45LATN

Operation mode	Air flow mode	Speed (rpm)
Cooling	Hi	1310
Heating	Me	1020
Fan	Lo	840
	Quiet	670
Heating	Hi	1300
	Me	1020
	Lo	840
	Quiet	670
Dry	Auto	670
Monitoring	S- Lo	370

2. FAN OPERATION


The airflow can be switched in 5 steps such as AUTO, QUIET, LOW, MED, HIGH, while the indoor fan only runs.


When Fan mode is set at (Auto), it operates on [MED] Fan Speed.

3. COOLING OPERATION

Switch the airflow [AUTO], and the indoor fan motor will run according to a room temperature, as shown in Figure 6.

On the other hand, if switched in [HIGH] \sim [QUIET], the indoor motor will run at a constant airflow of [COOL] operation modes QUIET, LOW, MED, HIGH, as shown in Table 5.






4. HEATING OPERATION

Switch the airflow [AUTO], and the indoor fan motor will run according to a room temperature, as shown in Figure 7.

On the other hand, if switched [HIGH] \sim [QUIET], the indoor motor will run at a constant airflow of [HEAT] operation modes QUIET, LOW, MED, HIGH, as shown in Table 5.

(Fig.7: Airflow change - over (Heating: AUTO))




5. COOL AIR PREVENTION CONTROL (Heating mode)


The maximum value of the indoor fan speed is set as shown in Figure 8, based on the detected temperature by the indoor heat exchanger sensor on heating mode.

(Fig.8: Cool Air Prevention Control)

(1) Fan mode: HIGH



(2) Fan mode: MED, LOW, QUIET



6. DRY OPERATION

Refer to the Figure 4.

During the dry mode operation, the fan speed setting can not be changed.

5-6. OUTDOOR FAN CONTROL

1. Outdoor Fan Motor

1-1. For AR*A12/ 14/ 18/ 24LATN

Following table shows the fan speed of the outdoor unit.

Table 6: Fan speed of the outdoor unit

	Outdoor temperature	Cooling	Dry
AR*A12LATN	Over than 12°C	860/ 820/ 770/ 670/ 500 rpm	500 rpm
AR AIZLAIN	Less than 12°C	400/ 340/ 280/ 250/ 230 rpm	400/ 340/ 280/ 250/ 230 rpm
AR*A14LATN	Over than 12°C	860/ 820/ 670/ 500 rpm	500 rpm
AR*A18LATN	Less than 12°C	400/ 340/ 280/ 250/ 230 rpm	400/ 340/ 280/ 250/ 230 rpm
AR*A24LATN	Over than 12°C	950/ 820/ 670/ 500 rpm	500 rpm
AR AZ4LATN	Less than 12°C	400/ 340/ 280/ 250/ 230 rpm	400/ 340/ 280/ 250/ 230 rpm

	Heating
AR*A12LATN	950/ 820/ 750/ 700/ 550/ 450 rpm
AR*A14LATN AR*A18LATN	950/ 820/ 750/ 670/ 550/ 450 rpm
AR*A24LATN	1050/ 1000/ 730/ 670/ 550/ 450 rpm

• The outdoor fan speed is changed in the range of the speed shown in the above table, based on the frequency of the compressor.

(When the compressor frequency increases, the outdoor fan speed is also changed to higher speed. If the compressor frequency decreases, the outdoor fan speed is changed to the lower speed as well.)

After starting up the outdoor fan, it operates with the following speed for initial 20 seconds.

Table 7: Fan speed when starting up outdoor fan

	Outdoor temperature	Fan speed
AR*A12LATN AR*A14LATN AR*A18LATN AR*A24LATN	Over than 12°C	500 rpm
	Less than 12°C	200 rpm

• After operating the defrost control function on heating mode except economy operation, its speed becomes 950rpm (AR*A12/14/18L) and 1050rpm (AR*A24L) regardless of the compressor frequency.

However, it returns to the normal speed control when the defrosting operation does not function for 240 minutes after releasing the defrost operation or when the outdoor temperature sensor detection value becomes higher than 5°C.

1-2. For AR*A36/ 45LATN

Following table shows the fan speed of the outdoor unit.

Table 8: Fan speed of the outdoor unit

		Cooling	Heating
AR*A36LATN AR*A45LATN	Upper fan	850/ 780/ 520/ 400/ 350/ 300/ 280 rpm	850/ 780/ 350/ 200/ 170/ 150 rpm
	Lower fan	780/ 750/ 520/ 350/ 280/ 0 rpm	780/ 750/ 350/ 200/ 170/ 150 rpm

- · AR*A36/ 45LATN have two fan motors.
- The outdoor fan speed changs in the range mentioned avobe depending on the compressor frequency and outdoor temperature.
- It runs at 500rpm for 20 seconds after starting up the outdoor fan.

 When the outdoor heat exchanger temperature is lower than 2°C,
 the fan speed switches to 850rpm(Upper fan) and 750rpm(Lower fan) on heating mode.

5-7. COMPRESSOR CONTROL

1. OPERATION FREQUENCY RANGE

The operation frequency of the compressor is different based on the operation mode as shown in Table 9.

(Table 9 : Compressor Operation Frequency Range)


	Cooling		Heating		
	Min	Max	Min	Max	Dry
AR*A12LATN	18Hz	80Hz	18Hz	120Hz	34Hz
AR*A14LATN	18Hz	113Hz	18Hz	120Hz	34Hz
AR*A18LATN	18Hz	113Hz	18Hz	120Hz	34Hz
AR*A24LATN	18Hz	113Hz	18Hz	120Hz	34Hz
AR*A36LATN	18Hz	70Hz	18Hz	90Hz	31Hz
AR*A45LATN	18Hz	77Hz	18Hz	90Hz	31Hz

2. OPERATION FREQUENCY CONTROL AT START UP

2-1. For AR*A12/ 14/ 18/ 24LATN

The compressor frequency soon after the start-up is controlled as shown in Figure 9.


(Fig.9: Compressor Control at Start-up)



2-2. For AR*A36/ 45LATN

The compressor frequency soon after the start-up is controlled as shown in Figure 10.

(Fig.10 : Compressor Control at Start-up)



5-8. TIMER OPERATION CONTROL


5-8-1 Wired Remote Controller

AR-6TC1


- ON / TIMER
- OFF / TIMER
- WEEKLY TIMER
- TEMPERATURE SET BACK TIMER

1. ON / OFF TIMER

· OFF timer: When the clock reaches the set time, the air conditioner will be turned off.




• ON timer: When the clock reaches the set time, the air conditioner will be turned on.



2. WEEKLY TIMER

2-1. WEEKLY TIMER


- Use this timer function to set operating time for each day of the week.
- The weekly timer allows up to two ON and OFF time to set up per day.




- The operating time can be set in 30 min increments only.
- The OFF time can be carried over to next day.
- The ON timer and the OFF timer functions cannot be set with using the weekly timer. Both ON and OFF time must be set.

2-2. DAY OFF setting

- The DAY OFF setting is only available for days for which weekly settings already exist.
- If the operating time carries over to the next day (during a next day setting), the effective DAY OFF range will be set as shown below.
- Normal






• The DAY OFF setting can only be set one time. The DAY OFF setting is cancelled automatically after the set day has passed.

3. TEMPERATURE SET BACK TIMER

- The SET BACK timer only changes the set temperature for 7 days, it cannot be used to start or stop air conditioner operation.
- The SET BACK timer can be set to operate up to two times per day but only one temperature setting can be used.
- During the COOL/DRY mode, the air conditioner will operate at a minimum of 18°C even if the SET BACK temperature is set to 17°C or lower.

Case of SET BACK timer on the Cooling operation. (Setting temperature :22°C, SET BACK temperature :26°C)



5-9. ELECTRONIC EXPANSION VALVE CONTROL

The most proper opening of the electronic expansion valve is calculated and controlled under the present operating condition based on the following values.

The compressor frequency, the temperatures detected by the discharge temperature sensor, the indoor heat exchanger sensor, the outdoor heat exchanger sensor, and the outdoor temperature sensor.

(1) Pulse range of EEV

	Operation	Pulse range
AR*A12LATN AR*A14LATN	Cooling/ Dry	60 ~ 480 pulse
AR*A18LATN AR*A24LATN	Heating	
AR*A36LATN	Cooling/ Dry	50~480 pulse
AR*A45LATN	Heating	62~480 pulse

- (2) The EEV is set up at 480 pulses when the compressor is stopped.
- (3) Intialization (Input of 528 pulses toward closing direction) is operated under the following condition.
 - * When the power is turned on.
 - * 4 hours has passed since the last initialization, and 3 minutes has passed after the compressor stop.

(If 12 hours has passed since the last initialization, the compressor is compulsorily stopped.)

5-10. TEST OPERATION CONTROL

Under the condition where the air conditioner stops, press the MASTER CONTROL button and the FAN CONTROL button simultaneously for 2 seconds or more, and the test operation control mode will appear.

During test running, "a{" will display on the remote controller display.

Set the test operation mode, and the compressor will continue to run regardless of whatever the room temperature sensor detects.

The test operation mode is released if 60 minutes have passed after setting up the test operation.

5-11. PREVENT TO RESTART FOR 3 MINUTES (3 MINUTES ST)

The compressor won't enter operation status for 3 minutes after the compressor is stopped, even if any operation is given.

5-12. 4-WAY VALVE EXTENSION SELECT

At the time when the air conditioner is switched from the cooling mode to heating mode. the compressor is stopped, and the 4-way valve is switched in 3 minutes later after the compressor stopped.

5-13. AUTO RESTART

When the power was interrupted by a power failure, etc. during operation, the operation contents at that time are memorized and when power is recovered, operation is automatically resumed with the memorized operation contents.

When the power is interrupted and recovered during timer operation, timer operation is canceled, but only setting time is memorized.

[Operation contents memorized when the power is interrupted]

- Operation mode
- Set temperature
- · Set air flow
- · Timer mode and timer time
- Thermistor detected position (When using the Wired Remote Controller)

5-14. PUMP DOWN (For AR*A36/45LATN)

Perform the following procedures to collect the refrigerant when moving the indoor unit or the outdoor unit.

When the product is stopped:

- 1. Press the PUMP DOWN switch (SW2) on the outdoor unit. (The LED on the outdoor unit circuit board starts flashing (1sec.ON / 1sec.OFF repeated).)
- 2. The pump down operation (cooling operation) begins right away. After operation starts, close the 3-way valve (liquid).
- 3. After 2-3minutes, operation stops. Close the 3-way valve (gas) within 1minute after operations stops.
- 4. The LED will go out 3minutes after it stops. Disconnect the power supply after confirming that the LED has gone out.

When the product is operating:

- 1. Press the PUMP DOWN switch (SW2) on the outdoor unit. The LED on the outdoor unit circuit board starts flashing (1sec.ON / 1sec.OFF repeated), and operation stops. At this point, recovery has not been completed, so do not close the 3-way valves (liquid and gas).
- 2. The pump down operation (cooling operation) begins after 3minutes.
 - Close the 3-way valve (liquid) after operation starts.
- 3. After 2-3minutes, operation stops. Close the 3-way valve (gas) within 1minute after operations stops.
- 4. The LED will go out 3minutes after it stops. Disconnect the power supply after confirming that the LED has gone out.


5-15. COMPRESSOR PREHEATING

When the outdoor heat exchanger temperature is lower than 5°C and the heating operation has been stopped for 30 minutes, power is applied to the compressor and the compressor is heated. (By heating the compressor, warm air is quickly discharged when operation is started.) When operation was started, and when the outdoor temperature rises to 7°C or greater. preheating is ended.

5-16. FRESH AIR CONTROL

The fan motor for Fresh Air is operated in synchronization with the indoor fan operation as shown in Figure 11.


(Fig.11: Fresh air control)



5-17. EXTERNAL ELECTRICAL HEATER CONTROL

The external electrical heater is operated as shown in Figure 12.

(Fig.12: External electrical heater control)



- Ts : Setting temperature
- When the compressor stop, External electrical heater is OFF.

5-18. DEFROST OPERATION CONTROL

1. CONDITION OF STARTING THE DEFROST OPERATION

The defrost operation starts when the outdoor heat exchanger temperature sensor detects the temperature lower than the values shown in Table 11.

(Table 11 : Condition of starting Defrost Operation)

- 1st time defrosting after starting operation

Compressor contiguous operation time	Below 10 min.		Above 10 min.	
Compressor integrating operation time	Less than 17 min.	17 to 62 min.	62 min. to 4 hours	After 4 hours
Operation temperature	Does not operate	- 9°C	- 5°C	- 3°C

- Defrosting after 2nd time upon starting operation

Compressor contiguous operation time	Below 10 min.	Above 10 min.	
Compressor integrating operation time	Less than 35 min.	35 min. to 4 hours	After 4 hours
Operation temperature	Does not operate	- 6°C	- 3°C

2. CONDITION OF THE DEFROST OPERATION COMPLETION


Defrost operation is released when the conditions become as shown in Table 12.

(Table 12 : Defrost Release Condition)

Release Condition
Outdoor heat exchanger temperature sensor value is higher than +10°C or Compressor operation time has passed 15 minutes.

3. Defrost Flow Chart

The defrosting shall proceed by the integrating operation time and outdoor heat exchanger emperature as follows.



5-19. OFF DEFROST OPERATION CONTROL

When operation stops in the [Heating operation] mode, if frost is adhered to the outdoor unit heat exchanger, the defrost operation will proceed automatically. In this time, if indoor unit operation lamp flashes slowly (7 sec ON / 2 sec OFF), the outdoor unit will allow the heat exchanger to defrost, and then stop.

1. OFF DEFROST OPERATION CONDITION


In heating operation, the outdoor heat exchanger temperature is less than - 4 C, and compressor operation integrating time lasts for more than 30 minutes. and compressor operation contiguous time lasts for more than 10 minutes.

2. OFF DEFROST END CONDITION

Release Condition

Outdoor heat exchanger temperature sensor value is higher than +10°C or Compressor operation time has passed 15 minutes.

OFF Defrost Flow Chart



5-20. ECONOMY OPERATION

At the maximum output, ECONOMY OPERATION is approximately 70% of normal air conditioner operation for cooling and heating.

When ECONOMY OPERATION is performed during the cooling mode, dehumidification is improved.

This function is especially convenient when you want to remove the humidity in the room without significantly lowering the room temperature.

During ECONOMY OPERATION, the thermostat setting automatically changes according to the temperature to avoid Unnecessary cooling and heating for the most economical operation.

- If the room is not cooled (or heated) well during economy operation, select normal operation.
- During the monitor period in the AUTO mode, the air conditioner operation will not change to ECONOMY OPERATION even if ECONOMY OPERATION is selected by pressing the ECONOMY button.

5-21. VARIOUS PROTECTIONS

1. DISCHARGE GAS TEMPERATURE OVER RISE PREVENTION CONTROL

1-1. For AR*A12/ 14/ 18/ 24LATN

The discharge gas thermosensor (discharge thermistor : Outdoor side) will detect discharge gas temperature.

When the discharge temperature becomes higher than 104°C, the compressor frequency is decreased 20 Hz, and it continues to decrease the frequency for 20 Hz every 120 seconds until the temperature becomes lower than 101°C.

When the discharge temperature becomes lower than 101°C, the control of the compressor frequency is released.

When the discharge temperature becomes higher than 110°C, the compressor stops

1-2. For AR*A36/ 45LATN

The discharge gas thermosensor (discharge thermistor : Outdoor side) will detect discharge gas temperature.

When the discharge temperature becomes higher than 105°C, the compressor frequency is decreased 10 Hz, and it continues to decrease the frequency for 10 Hz every 120 seconds until the temperature becomes lower than 105°C.

When the discharge temperature becomes lower than 100°C, the control of the compressor frequency is released.

When the discharge temperature becomes higher than 115°C, the compressor stops

2. CURRENT RELEASE CONTROL

2-1. For AR*A12/ 14/ 18/ 24LATN

The compressor frequency is controlled so that the outdoor unit input current does not exceeds the current limit velue that was set up with the outdoor temperature.

The compressor frequency returns to the designated frequency of the indoor unit at the time when the frequency becomes lower than the release value.

(Table 13 : Current Release Operation Value / Release Value)

[Heating]

AR*A12LATN		
OT (C	Control / Release)	
17°C -	6.5A/ 6.0A	
	8.0A/ 7.5A	
12°C ·	8.5A/ 8.0A	
5°C		
	9.5A/ 9.0A	

$\cap T$	Outdoor	Temperatur

AR*A14/ 18LATN
OT (Control / Release)
7.0A/ 6.5A
9.0A/ 8.5A
12°C ————————————————————————————————————
5°C
12.0A/ 11.5A

OT : Outdoor Temperature

AR*A24LATN		
OT (Control / Release)		
7.0A/ 6.5A		
9.0A/ 8.5A		
11.5A/ 11.0A		
5°C 13.0A/ 12.5A		

OT : Outdoor Temperature

[Cooling]

AR*A12LATN		
OT (C	Control / Release)	
46°C	4.5A/ 4.0A	
	6.0A/ 5.5A	
40°C ·	7.0A/ 6.5A	

OT : Outdoor Temperature

AR*	A14/ 18LATN
OT (0	Control / Release)
46°C	4.5A/ 4.0A
"	6.0A/ 5.5A
40°C	8.5A/ 8.0A

OT : Outdoor Temperature

AR*A24LA	ΛTN
OT (Control /	Release)
7.0A/ 6	6.5A
9.5A/ 9	9.0A
40°C ————————————————————————————————————	11.0A

OT : Outdoor Temperature

2-2. For AR*A36/ 45LATN

(Table 13-2 : Current Release Operation Value / Release Value)

[Heating]

	Outdoor unit fan speed (UP / LO)			
	850/ 780 rpm 780/ 780 rpm 350/ 350 rpm	200/ 200 rpm 170/ 170 rpm 150/ 150 rpm		
T0 ≥ 20°C	13.0A / 12.5A	13.0A / 12.5A		
20°C > T0 ≥ 12°C	15.0A / 14.5A			
T0 < 12°C	18.0A / 17.5A	15.0A / 14.5A		

T0: Outdoor temperature

[Cooling]

	Outdoor unit fan speed (UP / LO)					
	850/ 750 rpm 780/ 780 rpm	520/ 520 rpm	350/ 350 rpm	280/ 280 rpm 400/ 0 rpm	350/ 0 rpm	300/ 0 rpm
T0 <u>≥</u> 46°C	11.0A / 10.5A	11.0A / 10.5A	11.0A / 10.5A	11.0A / 10.5A	11.0A / 10.5A	11.0A / 10.5A
46°C > T0 ≥ 40°C	14.5A / 14.0A	14.5A / 14.0A	12.0A / 11.5A	12.0A / 11.5A		
40°C > T0 ≥ 31°C	18.0A / 17.5A	15.0A / 14.5A				
31°C > T0 ≥ 25°C		17.5A / 17.0A	14.0A / 13.5A			
25°C > T0 ≥ 13°C	17.5A / 17.0A					
13°C > T0 ≥ 7°C	14.0A / 13.5A	14.0A / 13.5A				
7°C > T0 ≥ 0°C					12.0A / 11.5A	
T0 < 0°C						11.5A / 11.0A

T0: Outdoor temperature

3. ANTIFREEZING CONTROL (Cooling and Dry mode)

The compressor frequency is decrease on cooling & dry mode when the indoor heat exchanger temperature sensor detects the temperature lower than Temperature I.

Then, the anti-freezing control is released when it becomes higher than Temperature II.

(Table 14 : Anti-freezing Protection Operation / Release Temperature)

Outdoor temperature	Temperature I	Temperature I	
Over than 10°C *1 or 12°C *2	4°C	7°C	
Less than 10°C *1 or 12°C *2	40	13°C	


^{*1.} When the temperature rises.

^{*2.} When the temperature drops.

4. COOLING PRESSURE OVER RISE PROTECTION

On cooling mode, the compressor frequency is controlled as following based on the detection value of the outdoor heat exchanger temperature sensor.

(Fig.13: Cooling Pressure Over Rise Protection Control) Outdoor heat exchange temperature




Release of protection

5. HIGH TEMPERATURE RELEASE CONTROL (HEATING MODE)

On heating mode, the compressor frequency is controlled as following based on the detection value of the indoor heat exchanger temperature sensor.

(Fig.14: Heating Overload Protection Control)

Indoor heat exchange temperature



Over than 18Hz → Frequency down every 60 seconds Less than 18Hz → OFF

5-22. FORCED COOLING OPERATION

The forced cooling operation starts up when MANUAL / AUTO button is pressed more than 10 seconds. During the forced cooling operation, it keeps operation regardless of detection value of room temperature sensor.

Operation LED and Timer LED light up while the unit is on the forced cooling operation.

The forced cooling operation is released after 60 minutes from starting time.

5-23. COMPRESSOR STOP CONTROL

When the detection value of outdoor temperature sensor is lower than temperature I in the table below, the compressor is stopped.

(Table 15 : Operation temperature of compressor stop control)

	Temperature I		
	Cooling	Heating	
Operation temperature	- 20°C		



DUCT type INVERTER

6. REFRIGERANT CAUTION -R410A-

6. REFRIGERANT CAUTION -R410A-

6-1. R410A TOOLS

This air conditioner used R410A.

For installation and servicing, it is necessary to prepare the tools and machines that are different from the previous refrigerant.

Mark shows the exclusive use for R410A.

© Gauge manifold (Fig.4-1)
The specification of the gauge is different due to higher pressure.
The size of connection pipe is also different to

The size of connection pipe is also different to prevent mis-use.

Refrigerant cylinder (Fig.4-3) Confirm the refrigerant type before charging. Always charge liquid-phase refrigerant.

Electronic balance for refrigerant charging (Fig.4-4)

Electronic balance is recommended as in the case of R410A.

Vacuum pump with adapter to prevent reverse flow(Fig.4-5) Conventional pump can be used.

Vacuum holder (Fig.4-6)
Conventional pump can be used if adapter for preventing vacuum pump oil from flowing back is used.

© Gas leakage tester (Fig.4-7) Exclusive for HFC

Refrigerant cleaner (Fig.4-8)

Brown paint as designated by the ARI, USA

⊚ Flare tool(Fig.4-9)

The shape of flare is different for high pressure condition.

Refrigerant recovering

equipment (Collector) (Fig.4-11)

The type which can be used for any refrigerant is available

Nitrogen cylinder (Fig.4-12)
This prevents an oxide film from forming in the pipe silver-

alloy brazing work by turning the air out of the pipe and preventing the inside combustion.

⊚ Safety charger (Fig.4-13)

It is always compulsory to change the liquid, because R410A is a mixed refrigerant and there is some fear that a mixing ratio changes. In order to avoid the refrigerant from returning to the compressor in a liquid state, the refrigerant can be charged instead of giving a load to the compressor with a safety charger.

Control valve (Fig.4-14)

The control valve prevents the refrigerant from spouting when it is removed, as the charging hose side and the service port side are possible to open and close at the same time.


Thermistor vacuum gauge (Fig.4-15)

To remove moisture from the refrigerating cycle completely, it is necessary to perform appropriate vacuum drying. For that reason, vacuum conditions can be confirmed certainly.

Vacuum valve (Fig.4-16)

This valve builts in a check valve, and it is easily possible to vacuum a refrigerating cycle or check for degree of vacuum with it.

TOOLS AND EQUIPMENT (R410A)



* 1 Gauge Manifold

	R410A	R22, R407C
High pressure gauge	-0.1 ~ 5.3 Mpa	-0.1~3.5 Mpa
Compond gauge	-0.1 ~ 3.8 Mpa	-0.1∼1.7 Mpa
Port size	1/2UNF 5/16"	7/16UNF 1/4"

*2 Charge hose

	R410A	R22, R407C
Normal pressure	5.1 Mpa	3.4 Mpa
Breaking pressure	27.4 Mpa	17.2 Mpa
Port size	1/2UNF	7/16UNF

6-2. PRECAUTION FOR INSTALLATION

Precaution for installation

Pipe diameter, recommended material and wall thickness


Nominal diameter (in)	1/4"	3/8"	1/2"	5/8"	3/4"	7/8"	1"	1 1/8"	1 1/4"	1 3/8"	1 1/2"
Outside diameter (mm)	6.35	9.52	12.70	15.88	19.05	22.22	25.40	28.58	31.75	34.92	38.10
Material	JIS H	COPPER JIS H3300-C1220T-O or equivalent 1)				J	IIS H330		PPER)T-H or e	quivalen	t ²⁾
Wall thickness ³⁾ (mm)	0.8	0.8	0.8	1.0	1.2	1.0	1.0	1.0	1.1	1.2	1.3

¹⁾ Allowable tensile stress ≥ 33 (N/mm²); 2) Allowable tensile stress ≥ 61 (N/mm²); 3) Design pressure 4.2MPa.

The pipe must be properly pressure rated for R410A The pipe must be an air-conditioning refrigerant pipe.

Flare and flare nuts

Diameter	1/4"(6.3	35mm)	3/8" (9.5	52mm)	1/2"(12	2.7mm)	3/8"(15.	88mm)	3/4"(19.	05mm)
Refrigerant	R410A	R22 /R407C	R410A	R22 /R407C	R410A	R22 /R407C	R410A	R22 /R407C	R410A	R22 /R407C
Α	9.1	9.0	13.2	13.0	16.6	16.2	19.7	19.4	24	23.7
В	13	12	20	15	13	20	25	23	29	29
С	12	11	16	12.5	19	16	22	20	24	24
Nut width	1	7	2:	2	26	24	29	27	30	6




Always use the flare nut that is packed with the product.

Do not use existing (for R22) pipes


- Be sure to use new pipes when replacing conventional (R22) model with HFC (R407C, R410A) model.
- If you use existing pipes, it may cause resolution of compressor oil by remaining mineral oil.


Be careful not to mix moisture and contamination into the pipe



Moisture and contamination in the pipe is a cause of trouble.

Air purge







Always use a vacuum pump to purge air.

Refrigerant charge







Do it always from the liquid phase side.

Compressor oil is changed

- We developed new synthetic oil, since HFC refrigerant doesn't dissolve in mineral (for R22)oil.
- Be careful to handle synthetic oil, since it resolves easily by moisture and contamination.
- Don't mix new synthetic oil and mineral oil.
 It may cause trouble.

6-3. PRECAUTION FOR SERVICING

Feature 1 Refrigerant oil is different from before.

Refrigerant oil for New Refrigerant

Synthetic oil

Ether

Esther

Previously it was mineral oil.

Different point from previous one

- Absorbent character is high.
- Contamination occurs when mixed withe other kind of oil.

Precaution on Tools

- Use the gauge manifold and charge hose for New Refrigerant(HFC), which shall be segregated from those of R22.
- Attach the stop valve on the vacuum pump and avoid the oil from reverse frow.
- It is necessary to use the vacuum pump which can obtain the high vacuum condition.

R410A R22 Feature 2 New Refrigerant has Approx 1.6 times higher pressure than previous refrigerant.

R410A

High Pressure

Different point from previous one

- Diameter of Service port has been changed from 1/4 Flare to 5/16 Flare.
- JIS standard of flare process It became lager
- To keep thethickness of copper tube.
 (1/4,3/3=more than 0.8mm)


Precaution on Tools

- It requires the gauge manifold and charge hose exclusively for R410A.
- It requires the flare tool and torque wrench that satisfies New JIS standard.
- * Previous flare tool + flare adapter can be used as well.


6-4. NEW REFRIGERANT R410A

*What is HFC?

Phase-out schedule of HCFC according to Montreal protocol



Ozone Layer depleting mechanism



What is CFC and HCFC?

CFC: Chloro-Fluoro-Carbon

High ODP(ozone depletion potential) chemical compound, including chlorine. (ODP:0.6-1.0) For example: R12 (for refrigerator and car air-conditioner)

HCFC: Hydro-Chloro-Fluoro-Carbon

Low ODP chemical compound, including chlorine and hydrogen. (ODP:0.02-01)

For example: R22 (for air-conditioner)

HFC₃: Hydro-Fluoro-Carbon

R134a (for Car air conditioner) R407C (for air conditioner)

Refrigerant characteristics

	R410A	R407C	R22
Composition (wt%)	R32/R125 (50/50)	R32/R125/R134a (23/25/52)	R22 (100)
Boiling Point	- 51.4	- 43.6	- 40.8
Behavior	near azeotrope	zeotrope	
Pressure at 54.5 °C (kPa)	3,406	2,262	2,151
Temperature Glide (deg)	0.11	5.4	0
ODP	0	0	0.055

Summary of R407C and R410A characteristics

	R410A	R407C
Advantage	higher system performanceNear-Azeotropic refrigerant	similar pressure as R22 (possible to design large equipment)
Disadvantage	1.6 times higher pressure than R22 (difficult to design against pressure resistance)	Zeotropic refrigerant (handle with care)
Suitable for	Small Air-Conditioners	Large Air-Conditioners

* Desighed pressure of R410A refrigerant

Relation between R410A condensing temperature and saturated pressure.

< Pressure →Temp >

Pressure (Mpa) Temp (°C)

j 000a. 0 (pa)	1 · Op (O)
2.20	37.9
2.25	38.7
2.30	39.6
2.35	40.5
2.40	41.3
2.45	42.1
2.55	43.8
2.60	44.6
2.65	45.3
2.70	46.1
2.75	46.8
2.80	47.6
2.85	48.3
2.90	49.0
2.95	49.8
3.00	50.5
3.05	51.2
3.10	51.9
3.15	52.6
3.20	53.2
3.25	53.9
3.30	54.6
3.35	55.3
3.40	55.9
3.45	56.5
3.50	57.1
2.55	57.8
3.60	58.4
3.65	59.0
3.70	59.6
3.75	60.2
3.80	60.8
3.85	61.4
3.90	52.0
3.95	62.5
4.00	63.1
4.05	63.6
1 4 4 6	040

4.10

4.15

64.2

64.8

< Temp → Pressure >

Temp (°C)	Pressure (Mpa)
39	2.27
40	2.32
41	2.38
42	2.44
44	2.57
45	2.63
46	2.69
47	2.76
48	2.83
49	2.90
51	3.04
52	3.11
53	3.18
54	3.26
56	3.41
57	3.49
58	3.57
59	3.65
61	3.82
62	3.90
63	3.99
64	4.08

6-5. DEFFERENCE FROM CONVENTIONAL MODEL (R22) AND PRECAUTIONS

OIL

- Use new synthetic oils such as ester because HFC series refrigerant has less solubility with mineral oils conventionally used for R22.
- As these new synthetic oils are easily influenced by moisture and dusts, they must be treated more carefully than the conventional lubricating oils.

CAUTION

For installation/servicing, take more precautions than the case of conventional refrigerants to avoid moisture and dusts entering the refrigerant circuit. Also, for storing parts, more precautions must be taken.

COMPRESSOR

- Use better grade of material for sliding parts for securing good lubrication of sliding part as HFC refrigerant does not contain chloride.
- · Review insulating materials
- · Increase pressure resistance strength

CAUTION

Check if the compressor is suitable for the refrigerant (model) when replacing. Complete welding within 15minutes after opening the cap when replacing.

HEAT EXCHANGER

- · Review the water, contaminants controlling level
- Use thinner tube to increase pressure Increase capacity for resistance strength (only outdoor unit) improving performance

CAUTION

During storage, due care must be taken so that foreign matters such as dust and water do not enter.

4-WAY VALVE

· Review materials

CAUTION

Check if the valve is suitable for the refrigerant (model) when replacing.

2, 3-WAY VALVE

· Review material O-ring, valve core seal for securing suitability with oil.

CALITION

Check if the valve is suitable for the refrigerant (model) when replacing.

Check Valve

- Review materials
- Change shape of pipe ends to increase pressure resistance strength.

CAUTION

Check if the valve is suitable for the refrigerant (model) when replacing.

Other Piping

- · Review the water, contaminants controlling level.
- Review thickness of pipes.

CAUTION

During storage, due care must be taken so that foreign matters such as dust and water do not enter.



DUCT type INVERTER

7. TROUBLE SHOOTING

7. TROUBLESHOOTING

7-1 ERROR DISPLAY

7-1-1 WIRED REMOTE CONTROLLER DISPLAY

1. SELF - DIAGNOSIS

When "EE" in Temperature Display is displayed, inspection of the air conditioning system is necessary. Please consult authoilzed servise personnel.

Unit number (usually 0)

Error code

SU MO TU WE TU FR SA

ex. Self-diagnosis check

Error code	Error contents							
88	Communication error (indoor unit ← remote control)							
[] {	Communication error (Serial reverse transfer error)	2						
82	Room temperature sensor error	3						
ΩH	Indoor heat exchanger temperature sensor error	4						
85	Outdoor heat exchanger temperature sensor(outlet) error	5						
83	Water drain abnormal	*(6)						
<u>O</u> A	Outdoor temperature sensor error	7						
	Outdoor discharge pipe temperature sensor error	8						
<u> </u>	Discharge temperature error	9						
{ {	Indoor EEPROM abnormal (Model No.)	10						
PI	Indoor fan motor abnormal	11						
(3	Outdoor communication signal error (Forward transfer signal error)	12						
15	Compressor temperature sensor error	13						
15	Pressure switch error	14						
97	IPM error	15						
[3	CT error	16						
(5	Active filter module (AFM) error	17						
Æ	Compressor rotor location cannot detect (permanent stop)	18						
1 5	Outdoor unit fan motor error	19						
15	Outdoor unit computer communication error	20						
20	Indoor manual auto switch error	21						
1	Exessive high pressure protection on cooling	22						
25	PFC circuit error	23						
26	Communication error (Main PCB → Display PCB)	*(24)						
27	Communication error (Main PCB ← Display PCB)	*(25)						
29	Outdoor heat exchanger temperature sensor(middle) error	26						
Zb	Compressor temperature error	27						
Zc	4-way valve error	28						

If "CO" appears in the unit number display, there is a remote controller error.
 Refer to the installation instruction sheet included with the remote controller.


[•] Trouble shooting No.6,24,and 25 have no application in this models.


2. ERROR CODE HISTORY DISPLAY

Up to 16 memorized error codes may be displayed for the indoor unit connected to the remote controller.


1. Stop the air conditioner operation.

2. Press the SET TEMPERATURE buttons ♥, ▲ simultaneously for 3 seconds or more to start the self-diagnosis.





3. Press the SET TEMPERATURE button to select the error history number.



4. Press the SET TEMPERATURE buttons ♥, ▲ simultaneously for 3 seconds or more or there is no key input for 60 seconds to stop the display.

7-1-2 OUTDOOR UNIT DISPLAY

1. ERROR DISPLAY

1-1. For AR*A12L/ 14L/ 18L/ 24L (AO*A12L/ 14L/ 18L/ 24L)


Error contents	LED Flashing Pattern	Trouble shooting
Discharge temperature error	Continuously lighting	9
IPM error	0.5sec ON / 0.5sec OFF	15
CT error	2sec ON / 2sec OFF	16
Compressor rotor location cannot detect	0.1sec ON / 2sec OFF	18,30
Outdoor unit sensor error (Discharge or Outdoor or Heat EX(In)(Out))	0.1sec ON / 0.1sec OFF	5,7,8,26
Outdoor unit fan motor error	5sec ON / 5sec OFF	19
Compressor temperature error	2sec ON / 5sec OFF	27
PFC circuit error	5sec ON / 2sec OFF	23

1-2. For AR*A36L/ 45L (AO*A36L/ 45L)

Error contents	LED Flashing Pattern	Display priority	Trouble shooting
Outdoor communication signal error (Forward transfer signal error)	1 time flash	1	12
Outdoor discharge pipe temperature sensor error	2 times blink	2	8
Outdoor heat exchanger temperature(outlet) sensor error	3 times blink	3	5
Outdoor temperature sensor error	4 times blink	4	7
Outdoor heat exchanger temperature(middle) sensor error	5 times blink	5	26
Discharge temperature error	6 times blink	6	9
Compressor temperature sensor error	7 times blink	7	13
Heat sink temperature sensor error	8 times blink	8	29
Pressure switch abnormal	9 times blink	9	14
Compressor temperature error	10 times blink	10	27
IPM error	12 times blink	11	15
Compressor rotor location cannot detect	13 times blink	12	18
Compressor Start-up error	14 times blink	13	30
Outdoor unit fan motor error (upper fan)	15 times blink	14	19
Outdoor unit fan motor error (lower fan)	16 times blink	15	19

1-2-1. ERROR DISPLAY METHOD

Outdoor LED Blink (1 to 16 times) 0.5sec ON / 0.5sec OFF blinking



1-2-2. NORMAL OPERATION DISPLAY

Operation	LED Blinking Pattern				
Normal operation	OFF				
Protected operation	5sec ON / 1sec OFF				
Pump down operation	1sec ON / 1sec OFF				

7-2 TROUBLE SHOOTING WITH ERROR CODE

Trouble shooting 1 INDOOR UNIT Error Method:

Communication Error

(Indoor unit ← Remote control)

Indicate or Display:

Outdoor Unit : No indication

ERROR CODE: E:00

Detective Actuators:

Indoor unit controller PCB circuit Wired Remote Control

Detective details:

When the indoor unit cannot receive the signal from Wired Remote more than 10seconds after power ON, or the indoor unit cannot receive the signal more than 1minute during normal operation.

Forecast of Cause:

1. Terminal connection abnormal 2. Wired Remote Control failure 3. Controller PCB failure

Check Point 1: Check the connection of terminal

After turning off the power, check & correct the followings.

• Check the connection of terminal between remote control and Indoor unit, and check if there is a disconnection of the cable.



Check Point 2: Check Remote Control and Controller PCB

 Check Voltage at CN14 (terminal 1-3) of Controller PCB. (Power supply to Remote Control)



>> If it is DC 0V, Controller PCB is failure. (Check Remote Control once again) >> Replace Controller PCB

▶ Upon correcting the removed connector or mis-wiring, reset the power.



Trouble shooting 2 **OUTDOOR UNIT Error Method:**

Communication Error

(Serial Reverse Transfer Error)

Indicate or Display:

Outdoor Unit : No indication

ERROR CODE: E:01

Detective Actuators:

Outdoor Unit Main PCB Circuit Active Filter Module

Detective details:

When the indoor unit cannot receive the serial signal from Outdoor unit more than 10seconds,

then permanent stop after 20seconds.

Forecast of Cause:

1. Connection failure 2. External cause 3. Main PCB failure 4. Active Filter Module failure

NO

Check Point 1-1: Reset the power and operate

Does Error indication show again?

YES

Check Point 2: Check Connection

- Check any loose or removed connection line of Indoor unit and Outdoor unit.
- >> If there is an abnormal condition, correct it by referring to Installation Manual or Data & Technical Manual.
- Check connection between Outdoor Unit Main PCB and Filter PCB.

(If there is loose connector or open cable)

Check Point 1-2:

Check external cause such as noise


- · Check the complete insulation of the grounding.
- Check if there is any equipment that causes harmonic wave near the power cable (Neon light bulb or any electronic equipment which causes harmonic wave).



Check Point 3: Check the voltage of power supply

Check the voltage of power supply

>> Check if AC198 - 264V appears at Outdoor Unit Terminal L - N.






Check Point 4: Check Serial Signal (Reverse Transfer Signal)

Check Serial Signal (Reverse Transfer Signal)

- >> Check if Indicated value swings between AC70V and AC130V at Outdoor Unit Terminal 1 3.
- >> If it is abnormal, Check Active Filter Module. (PARTS INFORMATION 3)
- >>If Active Filter Module is abnormal, replace it.
- >>If Active Filter Module is normal, replace Main PCB.



Trouble shooting 3

INDOOR UNIT Error Method:

Room Temperature Sensor Error

Indicate or Display:

Outdoor Unit : No indication

ERROR CODE : E:02

Detective Actuators:

Indoor Unit Controller PCB Circuit Room Temperature Thermistor

Detective details:

When Room Temperature Thermistor open or short-circuit is detected at power ON.

Forecast of Cause:

1. Connector connection failure 2. Thermistor failure 3. Controller PCB failure

Check Point 1: Check connection of Connector

- Check if connector is removed.
- Check erroneous connection.
- Check if thermistor cable is open.
- >><u>Upon correcting the removed connector or mis-wiring, reset the power.</u>



Check Point 2: Remove connector and check Thermistor resistance value

Thermistor Characteristics (Approx. value)

	75	l
$\rceil \mid$	<u> </u>	

Temperature	0°C	5°C	10°C	15°C	20°C	25°C	30°C	35°C
Resistance Value (kΩ)	33.6	25.9	20.2	15.8	12.5	10.0	8.04	6.51
Temperature	40°C	45°C	50°C					

3.59

▶ If Thermistor is either open or shorted, replace it and reset the power.

4.35

5.30




Resistance Value ($k\Omega$)

Check Point 3: Check voltage of Controller PCB (DC5.0V)

Make sure circuit diagram of indoor unit and check terminal voltage at Thermistor (DC5.0V)





▶ If the voltage does not appear, replace Controller PCB.

Trouble shooting 4

INDOOR UNIT Error Method:

Indoor Heat Exchanger Temperature

Sensor Error

Indicate or Display:

Outdoor Unit : No indication

ERROR CODE : E:04

Detective Actuators:

Indoor Unit Controller PCB Circuit Heat Exchanger Temperature Thermistor

Detective details:

When Heat Exchanger Temperature Thermistor open or short-circuit is detected at power ON.

Forecast of Cause:

Temperature

1. Connector connection failure 2. Thermistor failure 3. Controller PCB failure

Check Point 1: Check connection of Connector

- Check if connector is removed.
- · Check erroneous connection.
- Check if thermistor cable is open.
- >>Upon correcting the removed connector or mis-wiring, reset the power.



Check Point 2: Remove connector and check Thermistor resistance value

5°C

10°C

15°C

80.3

20°C

62.9

25°C

49.7

Thermistor Characteristics (Approx. value)

30°C	35°C	
39.6	31.7	

Resistance Value (k Ω)	176	134	103
Temperature	40°C	45°C	50°C
Resistance Value (kΩ)	25.6	20.8	17.1

0°C


▶ If Thermistor is either open or shorted, replace it and reset the power.



Check Point 3: Check voltage of Controller PCB (DC5.0V)

Make sure circuit diagram of indoor unit and check terminal voltage at Thermistor (DC5.0V)





▶ If the voltage does not appear, replace Controller PCB.

Trouble shooting 5

OUTDOOR UNIT Error Method:

Outdoor Heat Exchanger Temperature

Sensor (Outlet) Error

Indicate or Display:

Outdoor Unit (AR*A12L- 24L) : LED 0.1sec ON/ 0.1sec OFF

(AR*A36L/45L): LED 3 times blink

ERROR CODE: E:06

Detective Actuators:

Outdoor Unit Main PCB Circuit Heat Exchanger Temperature Thermistor (Outlet)

Detective details:

When Heat Exchanger Temperature Thermistor (Outlet) open or short-circuit is detected at power ON or while running the compressor.

Forecast of Cause:

1. Connector connection failure 2. Thermistor failure 3. Main PCB failure

Check Point 1: Check connection of Connector

- Check if connector is removed.
- Check erroneous connection.
- Check if thermistor cable is open.
- >>Upon correcting the removed connector or mis-wiring, reset the power.



Check Point 2: Remove connector and check Thermistor resistance value

Thermistor Characteristics (Approx. value)

Thermistor Characteristics (Approx. Value)										
Temperature	-10°C	-5°C	0°C	5°C	10°C	15°C	20°C	25°C	30°C	
Resistance Value ($k\Omega$)	27.8	21.0	16.1	12.4	9.63	7.56	5.98	4.77	3.84	
Temperature	35°C	40°C	45°C	50°C	60°C	70°C	80°C	90°C	100°C	
Resistance Value (kΩ)	3.11	2.53	2.08	1.71	1.19	0.840	0.606	0.446	0.333	


▶ If Thermistor is either open or shorted, replace it and reset the power.




Check Point 3: Check voltage of Main PCB (DC5.0V)

Make sure circuit diagram of outdoor unit and check terminal voltage at Thermistor (DC5.0V)

For AR*A12L-24L



For AR*A36L/ 45L



▶ If the voltage does not appear, replace Main PCB.

Trouble shooting 7 OUTDOOR UNIT Error Method:

Outdoor Temperature Sensor Error

Indicate or Display:

Outdoor Unit (AR*A12L-24L) : <u>LED 0.1sec ON/ 0.1sec OFF</u>

(AR*A36L/45L): LED 4 times blink

ERROR CODE : E: 0A

Detective Actuators:

Outdoor Unit Main PCB Circuit Outdoor Temperature Thermistor

Detective details:

When Outdoor Temperature Thermistor open or short-circuit is detected at power ON or while running the compressor.

Forecast of Cause:

1. Connector connection failure 2. Thermistor failure 3. Main PCB failure

Check Point 1: Check connection of Connector

- Check if connector is removed.
- Check erroneous connection.
- Check if thermistor cable is open.
- >>Upon correcting the removed connector or mis-wiring, reset the power.



Check Point 2: Remove connector and check Thermistor resistance value

Thermistor Characteristics (Approx. value)

Temperature	-20°C	-10°C	-5°C	0°C	5°C	10°C	15°C	20°C
Resistance Value (kΩ)	115	62.3	46.6	35.2	26.9	20.7	16.1	12.6
Temperature	30°C	40°C	50°C	60°C	70°C			
Resistance Value (kΩ)	7.97	5.18	3.45	2.36	1.65			

▶ If Thermistor is either open or shorted, replace it and reset the power.




Check Point 3: Check voltage of Main PCB (DC5.0V)

Make sure circuit diagram of outdoor unit and check terminal voltage at Thermistor (DC5.0V)




For AR*A12L-24L



▶ If the voltage does not appear, replace Main PCB.

For AR*A36L/ 45L



Trouble shooting 8 OUTDOOR UNIT Error Method: Outdoor Discharge Pipe Temperature Sensor Error

Indicate or Display:

Outdoor Unit (AR*A12L-24L): LED 0.1sec ON/ 0.1sec OFF

(AR*A36L/ 45L) : LED 2 times blink

ERROR CODE : E: 0C

Detective Actuators:

Outdoor Unit Main PCB Circuit
Discharge Pipe Temperature Thermistor

Detective details:

When Discharge Pipe Temperature Thermistor open or short-circuit is detected at power ON or while running the compressor.

Forecast of Cause:

1. Connector connection failure 2. Thermistor failure 3. Main PCB failure

Check Point 1: Check connection of Connector

- Check if connector is removed.
- · Check erroneous connection.
- Check if thermistor cable is open.
- >>Upon correcting the removed connector or mis-wiring, reset the power.

ок

Check Point 2: Remove connector and check Thermistor resistance value

Thermistor Characteristics (Approx. value)

Thermistor characteristics (Approx. value)									
Temperature	0°C	5°C	10°C	15°C	20°C	30°C	40°C	50°C	60°C
Resistance Value (kΩ)	169	130	101	79.1	62.6	40.0	26.3	17.8	12.3
Temperature	7000	0000	0000	40000	40000	44000			

Temperature	70°C	80°C	90°C	100°C	120°C	140°C
Resistance Value (kΩ)	8.70	6.27	4.60	3.43	2.00	1.22


▶ If Thermistor is either open or shorted, replace it and reset the power.

ОК

Check Point 3: Check voltage of Main PCB (DC5.0V)

Make sure circuit diagram of outdoor unit and check terminal voltage at Thermistor (DC5.0V)

For AR*A36L/ 45L



THERMISTOR (PIPE MID) THERMISTOR (PIPE OUT) **THERMISTOR** HERMISTOR BBROWN BROWN BLACK BLACK BLACK BLUE 1 2 1 2 1 2 1 2 1 2 1 2 1 2 1 2 1 2 1 2 1 2 1 2 **CN24 CN21** CN22 **CN23 CN26 CN25**

► If the voltage does not appear, replace Main PCB.

Trouble shooting 9 **OUTDOOR UNIT Error Method:** Discharge temperature error

Indicate or Display:

Outdoor Unit (AR*A12L-24L): LED continuously lighting

(AR*A36L/45L): LED 6 times blink

ERROR CODE: E: 0F

Detective Actuators:

Outdoor Unit Main PCB Circuit Discharge Pipe Temperature Thermistor

Detective details:

- ① When the discharge temperature becomes higher than 110°C (AR*A36L and 45L is 115°C), the compressor stops.
- 2) After the compressor restarts, if the same operation is repeated, the compressor stops permanently.

Forecast of Cause:

- 1. Valve is close 2. EEV failure 3. Gas Leak, less 4. Discharge Thermistor failure
- 5. Outdoor Fan Operation failure 6. Outdoor Heat Exchanger clogged

< Cooling mode > < Heating mode > Check Point 1: Check if Gas Valve is open Check Point 1: Check if Liquid Valve is open • If it is not open, open it and check the operation. • If it is not open, open it and check the operation. OK OK Check Point 2: Check EEV and Strainer Check Point 2: Check EEV and Strainer Are EEV and Strainer open? Are EEV and Strainer open? (Refer to PARTS INFORMATION 4) (Refer to PARTS INFORMATION 4) >>If EEV or Strainer is defective, replace it. >>If EEV or Strainer is defective, replace it. OK OK Check Point 3: Check if gas leak or less gas Measure Gas pressure, if there is a leak, correct it.

- - >>If recharging refrigerant, make sure to perform vacuuming and recharge the specified amount.



Check Point 4: Check Discharge Thermistor

- · Isn't it fallen off the holder?
- Is there a cable pinched?
- >> Check characteristics of thermistor (Refer to Trouble shooting 8), If defective, replace the thermistor



Check Point 5: Check Outdoor FAN, Heat Exchanger

- Is there anything obstructing the air distribution circuit?
- Is there any clogging of Outdoor Heat Exchanger?
- Is the Fan rotating? (Check by hand and if it is locked, replace the motor)
- Check Outdoor Fan Motor.
 - >>If the Fan Motor is defective, replace it.

Trouble shooting 10 INDOOR UNIT Error Method: Indoor EEPROM abnormal (Model No.)

Indicate or Display:

Outdoor Unit : No indication

ERROR CODE: E:11

Detective Actuators:

Detective details:

Indoor Unit Controller PCB circuit

When the model information being read from EEPROM has an apparent error.

Forecast of Cause:

1. External cause 2. Defective connection of electric components 3. Controller PCB failure

Check Point 1-1 : Reset Power Supply and operate Does Error indication show again?

NO

Check Point 2:

Check Indoor Unit electric components

Check all connectors.
 (loose connector or incorrect wiring)

YES

Check any shortage or corrosion on PCB.

Check Point 1-2:

Check external cause at Indoor and Outdoor (Voltage drop or Noise)

- Instant drop: Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure: Check if there is a defective contact or leak current in the power supply circuit.
- Noise: Check if there is any equipment causing harmonic wave near electric line. (Neon bulb or electric equipment that may cause harmonic wave) Check the complete insulation of grounding.

Check Point 3: Replace Controller PCB

► Change Controller PCB.

Note: EEPROM

EEPROM(Electronically Erasable and Programmable Read Only Memory) is a non-volatile memory which keeps memorized information even if power is turned off. It can change the contents electronically. To change the contents, it uses higher voltage than normal, and it can not change a partial contents. (Rewriting shall be done upon erasing the all contents.)

There is a limit in a number of rewriting.

Trouble shooting 11 INDOOR UNIT Error Method:

Indoor Fan Motor abnormal

Indicate or Display:

Outdoor Unit : No indication

ERROR CODE : E : 12

Detective Actuators:

Indoor Unit Controller PCB Circuit Indoor Fan Motor

Detective details:

When the condition that actual frequency of Indoor Fan is below 1/3 of target frequency is continued more than 56 seconds.

Forecast of Cause:

- 1. Fan rotation failure 2. Fan motor winding open 3. Motor protection by surrounding temperature rise
- 4. Control PCB failure

Check Point 1: Check rotation of Fan

- Rotate the fan by hand when operation is off.
 (Check if fan is caught, dropped off or locked motor)
- >><u>If Fan or Bearing is abnormal, replace it.</u>



Check Point 2: Check ambient temp. around motor

- Check excessively high temperature around the motor.
 (If there is any surrounding equipment that causes heat)
- >>Upon the temperature coming down, restart operation.



Check Point 3: Replace Controller PCB

▶ If Check Point 1-2 do not improve the symptom, replace Controller PCB.

Trouble shooting 12 INDOOR UNIT Error Method: Outdoor Communication Signal F

Outdoor Communication Signal Error (Forward Transfer Signal Error)

Indicate or Display:

Outdoor Unit (AR*A12L- 24L) : No indication (AR*A36L/ 45L) : <u>LED 4 times blink</u>

ERROR CODE: E:13

Detective Actuators:


Indoor Unit Controller PCB Circuit

Detective details:

When the outdoor unit cannot receive the serial signal from Indoor unit more than 10seconds.

Forecast of Cause:

1. Connection failure 2. External cause 3. Controller PCB failure



Check Point 2: Check Connection

- Check any loose or removed connection line of Indoor unit and Outdoor unit.
- >> If there is an abnormal condition, correct it by referring to Installation Manual or Data & Technical Manual.
- Check connection between Indoor Unit Controller PCB and Filter PCB.

(If there is loose connector or open cable)

Check Point 1-2:


Check external cause such as noise

- Check the complete insulation of the grounding.
- Check if there is any equipment that causes harmonic wave near the power cable (Neon light bulb or any electronic equipment which causes harmonic wave).



Check Point 3: Check the voltage of power supply

- Check the voltage of power supply
- >> Check if AC198 264V appears at Outdoor Unit Terminal L N.




OK

Check Point 4: Check Serial Signal (Forward Transfer Signal)

Check Serial Signal (Forward Transfer Signal)

- >> Check if Indicated value swings between AC70V and AC130V at Outdoor Unit Terminal 2 3.
- >> If it is abnormal, Controller PCB is failure. >> Replace Controller PCB



Trouble shooting 13 OUTDOOR UNIT Error Method:

Compressor Temperature Sensor Error

Indicate or Display:

Outdoor Unit (AR*A12L- 24L) : <u>LED 0.1sec ON/ 0.1sec OFF</u>

(AR*A36L/ 45L): LED 7 times blink

ERROR CODE : E : 15

Detective Actuators:

Outdoor Unit Main PCB Circuit Compressor Temperature Thermistor

Detective details:

When Compressor Temperature Thermistor open or short-circuit is detected at power ON or while running the compressor.

Forecast of Cause:

1. Connector connection failure 2. Thermistor failure 3. Main PCB failure

Check Point 1: Check connection of Connector

- Check if connector is removed.
- Check erroneous connection.
- Check if thermistor cable is open.
- >>Upon correcting the removed connector or mis-wiring, reset the power.



Check Point 2: Remove connector and check Thermistor resistance value

Thermistor Characteristics (Rough value)

I hermistor Characteristics	(Rougn	value)							
Temperature	0°C	5°C	10°C	15°C	20°C	30°C	40°C	50°C	60°C
Resistance Value (kΩ)	169	130	101	79.1	62.6	40.0	26.3	17.8	12.3
Temperature	70°C	80°C	90°C	100°C	120°C	140°C			

4.60

3.43

2.00

▶ If Thermistor is either open or shorted, replace it and reset the power.

6.27

8.70




Resistance Value ($k\Omega$)

Check Point 3: Check voltage of Main PCB (DC5.0V)

Make sure circuit diagram of outdoor unit and check terminal voltage at Thermistor (DC5.0V)


For AR*A12L-24L



▶ If the voltage does not appear, replace Main PCB.

For AR*A36L/ 45L

1.22



(For AR*A36L/ 45L)

Trouble shooting 14 OUTDOOR UNIT Error Method:

Pressure Switch Error

Indicate or Display:

Outdoor Unit : <u>LED 9 times blink</u>

ERROR CODE: E: 16

Detective Actuators:

Outdoor Unit Main PCB Circuit Pressure Switch


Detective details:

When pressure switch open is detected in 10 seconds

after the power is turned on.

Forecast of Cause:

1. Connector connection failure 2. Pressure Switch failure 3. Main PCB failure



Check Point 4: Check High Pressure Protection on cooling

* Check Excessive high pressure protection on cooling. (Refer to Trouble shooting 22)

Trouble shooting 15	Indicate or Display:
OUTDOOR UNIT Error Method:	Outdoor Unit (AR*A12L- 24L): LED 0.5sec ON/ 0.5sec OFF
IPM error (Permanent Stop)	(AR*A36L/ 45L) : <u>LED 12 times blink</u> ERROR CODE : <u>E : 17</u>
Detective Actuators:	Detective details:
Outdoor Unit Main PCB Circuit Compressor	 When more than normal operating current to IPM in Main PCB flows, the compressor stops. After the compressor restarts, if the same operation is repeated within 40sec, the compressor stops again. If ① and ② repeats 5 times, the compressor stops permanently.

Forecast of Cause:

- 1. Defective connection of electric components 2. Outdoor Fan Operation failure
- 3. Outdoor Heat Exchanger clogged
- 4. Compressor failure
- 5. Main PCB failure

Check Point 1: Check connections of Outdoor Unit Electrical Components

- Check if the terminal connection is loose.
- Check if connector is removed.
- Check erroneous connection.
- Check if cable is open.
- >>Upon correcting the removed connector or mis-wiring, reset the power.



Check Point 2: Check Outdoor Fan, Heat Exchanger

- Is there anything obstructing the air distribution circuit?
- Is there any clogging of Outdoor Heat Exchanger?
- Is the Fan rotating by hand when operation is off?
 - >> If the Fan Motor is locked, replace it.



Check Point 3: Check Outdoor Fan

- Check Outdoor Fan Motor. (Refer to Trouble shooting 19)
- >> If the Fan Motor is failure, replace it.



Check Point 4: Check Compressor

- Check Compressor. (PARTS INFORMATION 2)



Check Point 5: Replace Main PCB

► If Check Point 1 ~ 4 do not improve the symptom, change Main PCB.

Trouble shooting 16 Indicate or Display: Outdoor Unit (AR*A12L-24L) : <u>LED 2sec ON/ 2sec OFF</u> **OUTDOOR UNIT Error Method:** (AR*A36L/ 45L) : No indication **CT error ERROR CODE: E:18 Detective details: Detective Actuators:** When Input Current Sensor has detected 0A, while Inverter Compressor is Outdoor Unit Main PCB Circuit operating at higher than 56Hz(for AR*A12L-24L) or 50Hz(for AR*A36L/45L), Outdoor Unit Filter PCB Circuit after 1minute upon starting the Compressor. (Input current sensor unit) (Except during the defrost operation) Forecast of Cause: 1. Defective connection of electric components 2. External cause 3. Filter PCB failure 4. Main PCB failure Check Point 1-1: Reset Power Supply and operate NO Does Error indication show again? YES Check Point 2: Check Point 1-2: Check connections of Outdoor Unit Electrical Components Check external cause at Indoor and Outdoor (Voltage drop or Noise) Check if the terminal connection is loose. - Check if connector is removed. Instant drop : Check if there is a large load electric Check erroneous connection. apparatus in the same circuit. - Check if cable is open. • Momentary power failure : Check if there is a defective >>Upon correcting the removed connector or mis-wiring, contact or leak current in the reset the power. power supply circuit. • Noise : Check if there is any equipment causing harmonic OK wave near electric line.(Neon bulb or electric equipment that may cause harmonic wave) AR*A12L- 24L Check the complete insulation of grounding. Check Point 3: Check Filter PCB and Main PCB • Check DC voltage of CN1 (between 2 (Brown) and 3 (Red)) on Filter PCB. >> After 40seconds upon starting the Compressor. If it is higher than 0.2V, Main PCB is failure. (Filter PCB is normal) >> Replace Main PCB >> If it is lower than 0.2V, Filter PCB is failure. >> Replace Filter PCB ▶ If it does not improve the symptom, change Main PCB.

Check Point 4: Replace Main PCB

► If Check Point 1, 2 do not improve the symptom, change Main PCB.

(For AR*A36L/45L)

Trouble shooting 17 OUTDOOR UNIT Error Method: Active Filter Module (AFM) error	Indicate or Display: Outdoor Unit : No indication ERROR CODE : E : 19
<u>Detective Actuators:</u>	Detective details:
Outdoor Unit Main PCB Circuit Active Filter Module	When inverter input DC voltage is higher than 467V or lower than 237V. When a momentary power cut off occurred on low voltage.

Forecast of Cause:

1. External cause 2. Connector connection failure 3. Active Filter Module failure 4. Main PCB failure

Check Point 1: Check external cause at Indoor and Outdoor (Voltage drop or Noise)

- Instant drop : Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure : Check if there is a defective contact or leak current in the power supply circuit.
- Noise: Check if there is any equipment causing harmonic wave near electric line. (Neon bulb or electric equipment that may cause harmonic wave)
 Check the complete insulation of grounding.



Check Point 2: Check connection of Connector

- Check if connector is removed.
- · Check erroneous connection.
- Check if cable is open.
- >>Upon correcting the removed connector or mis-wiring, reset the power.



Check Point 3: Check Active Filter Module

- Check Active Filter Module. (PARTS INFORMATION 3)
- >>If Active Filter Module is abnormal, replace it.



Check Point 4: Replace Main PCB

► If Check Point 1 ~ 3 do not improve the symptom, change Main PCB.

OUTDOOR UNIT Error Method:

Compressor rotor location cannot detect

(Permanent Stop)

Indicate or Display:

Outdoor Unit (AR*A12L-24L) : LED 0.1sec ON/ 2sec OFF

(AR*A36L/45L): LED 13 times blink

ERROR CODE : E : 1A

Detective Actuators:

Outdoor Unit Main PCB Circuit Compressor

Detective details:

- ① While running the compressor, if the detected rotor location is out of phase with actual rotor location more than 90 degrees, the compressor stops.
- ② After the compressor restarts, if the same operation is repeated within 40sec, the compressor stops again.
- (3) If (1) and (2) repeats 5 times, the compressor stops permanently.

Forecast of Cause:

1. Defective connection of electric components 2. Main PCB failure 3. Compressor failure

Check Point 1: Check Noise from Compressor

- Turn on Power and check operation noise.
- If an abnormal noise show, replace Compressor.



Check Point 2: Check connection of around the Compressor components

For Compressor Terminal, Main PCB

- Check if connector is removed.
- Check erroneous connection.
- Check if cable is open.
 (Refer to PARTS INFORMATION 2)
 - >>Upon correcting the removed connector or mis-wiring, reset the power.



Check Point 3: Replace Main PCB

► If Check Point 1,2 do not improve the symptom, change Main PCB.

Trouble shooting 19 OUTDOOR UNIT Error Method:

Outdoor Unit Fan Motor Error

Indicate or Display:

Outdoor Unit (AR*A12L- 24L) : <u>LED 5sec ON/ 5sec OFF</u>

(AR*A36L/ 45L) : LED 15 times blink (Upper fan)

LED 16 times blink (Lower fan)

ERROR CODE : E : 1b

Detective Actuators:

Outdoor Unit Main PCB Circuit
Outdoor Fan Motor

Detective details:

- ① When outdoor fan rotation speed is less than 100rpm in 20 seconds after fan motor starts, fan motor stops.
- ② After fan motor restarts, if the same operation within 60sec is repeated 3 times in a row, compressor and fan motor stops.
- ③ If ① and ② repeats 5 times in a row, compressor and fan motor stops permanently.

Forecast of Cause:

1. Fan rotation failure 2. Motor protection by surrounding temperature rise 3. Main PCB failure

Check Point 1: Check rotation of Fan

- Rotate the fan by hand when operation is off.
 (Check if fan is caught, dropped off or locked motor)
- >>If Fan or Bearing is abnormal, replace it.




Check Point 2: Check ambient temp. around motor

- Check excessively high temperature around the motor.
 (If there is any surrounding equipment that causes heat)
- >>Upon the temperature coming down, restart operation.




Check Point 3: Check Output Voltage of Main PCB

• Check outdoor unit circuit diagram and the voltage. (Measure at Main PCB side connector)



Read wire	DC voltage					
Red - Black	150~390V					
White - Black	15±1.5V					

AR*A36L/ 45L



Read wire	DC voltage
Red - Black	300~400V
White - Black	15±1.5V

▶ If the voltage is not correct, replace Main PCB.

Trouble shooting 20 OUTDOOR UNIT Error Method:

Outdoor unit computer communication error

Indicate or Display:

Outdoor Unit : No indication

ERROR CODE: E:1c

Detective Actuators:

Outdoor Unit Main PCB Circuit

Detective details:

When it cannot receive an effective signal for 10sec between the Main CPU and Sub CPU in outdoor unit.

Forecast of Cause:

1. Main PCB failure

Check Point 1: Replace Main PCB

► Change Main PCB.

Trouble shooting 21 INDOOR UNIT Error Method:

Indoor manual auto switch error

Indicate or Display:

Outdoor Unit : No indication

ERROR CODE: E: 20

Detective Actuators:

Indoor Unit Controller PCB Circuit Forced auto switch

Detective details:

When the Forced auto switch becomes ON for 30 consecutive seconds.

Forecast of Cause:

1. Forced auto switch failure 2. Controller PCB failure

Check Point 1: Check the Forced auto switch

- Check if Forced auto switch is kept pressed.
- Check ON/OFF switching operation by using a meter.
- >>If Forced auto switch is detective, replace it.





Check Point 2: Replace Controller PCB

► If Check Point 1 do not improve the symptom, change Controller PCB.

OUTDOOR UNIT Error Method:

Excessive high pressure protection on cooling

Indicate or Display:

Outdoor Unit : No indication

ERROR CODE: E: 24

Detective Actuators:

Outdoor Unit Main PCB Circuit
Outdoor Fan Motor
Heat Exchanger Temp. Thermistor (Middle)
Outdoor unit Electronic Expansion Valve

Detective details:

Excessive high pressure protection on cooling mode has been

activated.

Forecast of Cause:

- 1. Defective connection of electric components 2. Outdoor Fan Operation failure
- 3. Outdoor Heat Exchanger clogged
- 4. Thermistor failure
- 5. EEV failure

6. Main PCB failure

Check Point 1: Check connections of Outdoor Unit Electrical Components

- Check if the terminal connection is loose.
- · Check if connector is removed.
- · Check erroneous connection.
- · Check if cable is open.
- >><u>Upon correcting the removed connector or mis-wiring, reset the power.</u>



Check Point 2: Check Outdoor Fan, Heat Exchanger

- Is there anything obstructing the air distribution circuit?
- Is there any clogging of Outdoor Heat Exchanger?
- Is the Fan rotating by hand when operation is off?
 - >> If the Fan Motor is locked, replace it.



Check Point 3: Check Outdoor Fan

- Check Outdoor Fan Motor. (Refer to Trouble shooting 19)
 - >> If the Fan Motor is failure, replace it.



Check Point 4: Check Thermistor (middle)

- Check Thermistor (middle). (Refer to Trouble shooting 26)
 - >> If the Thermistor (middle) is failure, replace it.



Check Point 5 : Check Electronic Expansion Valve

- Check EEV. (PARTS INFORMATION 4)



Check Point 6: Replace Main PCB

► If Check Point 1 ~ 5 do not improve the symptom, change Main PCB.

(For AR*A12L - 24L)

Trouble shooting 23 OUTDOOR UNIT Error Method: PFC circuit error	Indicate or Display: Outdoor Unit : No indication ERROR CODE : E : 25
<u>Detective Actuators:</u>	Detective details:
Outdoor Unit Main PCB Circuit	When inverter output DC voltage is higher than 415V for over 3 seconds, the compressor stops. If the same operation is repeated 5 times, the compressor stops permanently.

Forecast of Cause:

1. External cause 2. Connector connection failure 3. Main PCB failure

Check Point 1: Check external cause at Indoor and Outdoor (Voltage drop or Noise)

- Instant drop : Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure : Check if there is a defective contact or leak current in the power supply circuit.
- Noise: Check if there is any equipment causing harmonic wave near electric line. (Neon bulb or electric equipment that may cause harmonic wave)
 Check the complete insulation of grounding.



Check Point 2: Check connection of Connector

- Check if connector is removed.
- · Check erroneous connection.
- Check if cable is open.
- >>Upon correcting the removed connector or mis-wiring, reset the power.



Check Point 3: Replace Main PCB

▶ If Check Point 1, 2 do not improve the symptom, change Main PCB.

OUTDOOR UNIT Error Method:

Outdoor Heat Exchanger Temperature Sensor (Middle) Error

Indicate or Display:

Outdoor Unit (AR*A12L- 24L) : LED 0.1sec ON/ 0.1sec OFF

(AR*A36L/45L): LED 5 times blink

ERROR CODE : **E** : **29**

Detective Actuators:

Outdoor Unit Main PCB Circuit Heat Exchanger Temperature Thermistor (Middle)

Detective details:

When Heat Exchanger Temperature Thermistor (Middle) open or short-circuit is detected at power ON or while running the compressor.

Forecast of Cause:

1. Connector connection failure 2. Thermistor failure 3. Main PCB failure


Check Point 1: Check connection of Connector

- Check if connector is removed.
- Check erroneous connection.
- Check if thermistor cable is open.
- >>Upon correcting the removed connector or mis-wiring, reset the power.

ок

Check Point 2: Remove connector and check Thermistor resistance value

Thermistor Characteristics (Approx. value)




▶ If Thermistor is either open or shorted, replace it and reset the power.




Check Point 3: Check voltage of Main PCB (DC5.0V)

Make sure circuit diagram of outdoor unit and check terminal voltage at Thermistor (DC5.0V)

For AR*A12L-24L



For AR*A36L/ 45L



▶ If the voltage does not appear, replace Main PCB.

Trouble shooting 27 OUTDOOR UNIT Error Method: Compressor temperature error

Indicate or Display:

Outdoor Unit (AR*A12L- 24L) : <u>LED 2sec ON/ 5sec OFF</u>

(AR*A36L/ 45L) : LED 10 times blink

ERROR CODE : E : 2b

Detective Actuators:


Outdoor Unit Main PCB Circuit Compressor Temperature Thermistor

Detective details:

- ① When the compressor temperature becomes higher than 110°C, the compressor stops.
- ② After the compressor restarts, if the same operation is repeated, the compressor stops permanently.

Forecast of Cause:

- 1. Valve is close 2. EEV failure 3. Gas Leak, less 4. Compressor Thermistor failure
- 5. Outdoor Fan Operation failure 6. Outdoor Heat Exchanger clogged



Check Point 4: Check Compressor Thermistor

OK

- · Isn't it fallen off the holder?
- Is there a cable pinched?
 - >> Check characteristics of thermistor (Refer to Trouble shooting 13),

 If defective, replace the thermistor



Check Point 5: Check Outdoor FAN, Heat Exchanger

- Is there anything obstructing the air distribution circuit?
- Is there any clogging of Outdoor Heat Exchanger?
- Is the Fan rotating? (Check by hand and if it is locked, replace the motor)
- Check Outdoor Fan Motor.
 - >>If the Fan Motor is defective, replace it.

INDOOR UNIT Error Method:

4-way valve error

Indicate or Display:

Outdoor Unit : No indication

ERROR CODE : E : 2c

Detective Actuators:

Indoor Unit Controller PCB Circuit Heat Exchanger Temperature Thermistor Room Temperature Thermistor 4-way valve

Detective details:

When the indoor heat exchanger temperature is compared with the room temperature, and either following condition is detected continuously two times, the compressor stops.

- Cooling or Dry operation [Indoor heat exchanger temp.] - [Room temp.] > 10degC
- Heating operation
 [indoor heat exchanger temp.] [room temp.] < -10degC

If the same operation is repeated 5 times, the compressor stops permanently.

Forecast of Cause:

- 1. Connector connection failure 2. Thermistor failure 3. Coil failure 4. 4-way valve failure
- 5. Controller PCB failure

Check Point 1: Check connection of Connector

- Check if connector is removed.
- Check erroneous connection.
- Check if thermistor cable is open.
- >>Upon correcting the removed connector or mis-wiring, reset the power.



Check Point 2: Check Heat exchanger temp. thermistor and Room temp. thermistor

- Isn't it fallen off the holder?
- Is there a cable pinched?
- >> Check characteristics of thermistor (Refer to Trouble shooting 3, 4),

 If defective, replace the thermistor



Check Point 3: Check the solenoid coil and 4-way valve

[Solenoid coil]

- Remove CN30 from PCB and check the resistance value of coil. Resistance value is about $1.4 k\Omega$
 - >> If it is Open or abnormal resistance value, replace Solenoid Coil.

[4-way valve]

- Check each piping temperature,
 and the location of the valve by the temperature difference.
 - >>If the value location is not proper, replace 4-way valve.



Check Point 4: Replace Controller PCB

▶ If Check Point 1-3 do not improve the symptom, replace Controller PCB.

(For AR*A36L/45L)

Trouble shooting 29

OUTDOOR UNIT Error Method:

Heat Sink Temperature Sensor Error

Indicate or Display:

Outdoor Unit : <u>LED 8 times blink</u>

ERROR CODE: No indication

Detective Actuators:

Outdoor Unit Main PCB Circuit Heat Sink Temperature Thermistor **Detective details:**

When Heat Sink Temperature Thermistor open or short-circuit is detected at power ON or while running the compressor.

0.446

0.333

0.606

Forecast of Cause:

1. Connector connection failure 2. Thermistor failure 3. Main PCB failure


Check Point 1: Check connection of Connector

- Check if connector is removed.
- · Check erroneous connection.
- Check if thermistor cable is open.
- >>Upon correcting the removed connector or mis-wiring, reset the power.

ок

Check Point 2: Remove connector and check Thermistor resistance value

Thermistor Characteristics (Approx. value)



2.08

1.71

1.19

0.840

▶ If Thermistor is either open or shorted, replace it and reset the power.

2.53

3.11




Resistance Value ($k\Omega$)

Check Point 3: Check voltage of Main PCB (DC5.0V)

Make sure circuit diagram of outdoor unit and check terminal voltage at Thermistor (DC5.0V)





▶ If the voltage does not appear, replace Main PCB.



Trouble shooting 30
OUTDOOR UNIT Error Method:
Compressor Start-up error
(Permanent Stop)

Indicate or Display:

Outdoor Unit (AR*A12L- 24L) : <u>LED 0.1sec ON/ 2sec OFF</u> (AR*A36L/ 45L) : <u>LED 14 times blink</u>

ERROR CODE : E : 1A

Detective Actuators:

Outdoor Unit Main PCB Circuit Compressor

Detective details:

- ① On start-up the compressor, when detected rotor position is out of phase with actual rotor position more than 90 degrees, the compressor stops.
- ② After the compressor restarts, if the same operation is repeated within 40sec, the compressor stops again.
- (3) If (1) and (2) repeats 5 times, the compressor stops permanently.

Forecast of Cause:

1. Defective connection of electric components 2. Main PCB failure 3. Compressor failure

Check Point 1: Check Noise from Compressor

- Turn on Power and check operation noise.
- If an abnormal noise show, replace Compressor.



Check Point 2: Check connection of around the Compressor components

For Compressor Terminal, Main PCB

- Check if connector is removed.
- Check erroneous connection.
- Check if cable is open.
 (Refer to PARTS INFORMATION 2)
 - >>Upon correcting the removed connector or mis-wiring, reset the power.



Check Point 3: Replace Main PCB

▶ If Check Point 1,2 do not improve the symptom, replace Main PCB.


7-3 TROUBLE SHOOTING WITH NO ERROR CODE

Trouble shooting 31

Indoor Unit - No Power

Forecast of Cause:


- 1. Power Supply failure 2. External cause
- 3. Electrical Components defective



Outdoor Unit - No Power

Forecast of Cause:

- 1. Power Supply failure 2. External cause
- 3. Electrical Components defective



No Operation (Power is ON)

Forecast of Cause:

- 1. Setting/ Connection failure 2. External cause
- 3. Electrical Component defective

Check Point 1: Check indoor and outdoor installation condition

- Indoor Unit Check incorrect wiring between Indoor Unit Remote Control, or terminals between Indoor Units. Or, check if there is an open cable connection.
- · Are these Indoor Unit, Outdoor Unit, and Remote Control suitable model numbers to connect?
- >> If there is some abnormal condition, correct it by referring to Installation manual and _Data & Technical Manual._



Turn off Power and check/ correct followings.

Is there loose or removed communication line of Indoor Unit and Outdoor Unit?


OK

Check Point 2: Check external cause at Indoor and Outdoor (Voltage drop or Noise)

- Instant drop ----- Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
- Noise ---- Check if there is any equipment causing harmonic wave near electric line. (Neon bulb or electric equipment that may cause harmonic wave)
 Check the complete insulation of grounding.

OK

Check Point 3: Check Electrical Components at Indoor and Outdoor



- >> If it is DC12V, Remote Control is failure. (Controller PCB is normal) >> Replace Remote Control
- >> If it is DC 0V, Controller PCB is failure. (Check Remote Control once again) >> Replace Controller PCB
- >> If the symptom does not change by above Check 1, 2, 3, replace Main PCB of Outdoor unit.

No Cooling / No Heating

Forecast of Cause:

- 1. Indoor Unit error 2. Outdoor Unit error
- 3. Effect by Surrounding environment
- 4. Connection Pipe / Connection Wire failure 5. Refrigeration cycle failure

Check Point 1: Check Indoor Unit

- Does Indoor Unit FAN run on HIGH FAN?
- Is Air Filter dirty?
- Is Heat Exchanger clogged?
- Check if Energy save function is operated.



Check Point 2: Check Outdoor Unit Operation

- Check if Outdoor Unit is operating (If not, refer to Trouble shooting 32)
- Check any objects that obstruct the air flow route.
- Check clogged Heat Exchanger.
- Is the Valve open?



Check Point 3: Check Site Condition

- Is capacity of Indoor Unit fitted to Room size?
- Any windows open? Or direct sunlight?



Check Point 4:

Check Indoor/ Outdoor Installation Condition

- Check connection pipe (specified pipe length & Pipe diameter?)
- Check any loose or removed communication line.
- >> If there is an abnormal condition, correct it by referring to Installation Manual or Data & Technical Manual.





Check Point 5: Check Refrigeration Cycle

- Check if Strainer is clogged (Refer to the figure at right).
- Measure Gas Pressure and if there is a leakage, correct it.
- >> When recharging the refrigerant, make sure to perform vacuuming, and recharge the specified amount.
- Check EEV (PARTS INFORMATION 4)
- Check Compressor (PARTS INFORMATION 1,2)

Attention

Strainer normally does not have temperature difference between inlet and outlet as shown in 1, but if there is a difference like shown in 2, there is a possibility of inside clogged. In this case, replace Strainer.





Abnormal Noise

Forecast of Cause:

- 1. Abnormal installation (Indoor/ Outdoor) 2. Fan failure(Indoor/ Outdoor)
- 3. Compressor failure (Outdoor)

Diagnosis method when Abnormal Noise is occurred

- Abnormal noise is coming from Indoor Unit. (Check and correct followings)
- Is Main Unit installed in stable condition?
- Is the installation of Air suction grille and front panel normal?



- Is Fan broken or deformed?
- Is the screw of Fan loose?
- Is there any object which obstruct the Fan rotation?

- Abnormal noise is coming from Outdoor Unit. (Check and correct followings)
- Is Main Unit installed in stable condition?
- Is Fan Guard installed normally?



- Is Fan broken or deformed?
- Is the screw of Fan loose?
- Is there any object which obstruct the Fan rotation?



 Check if vibration noise by loose bolt or contact noise of piping is happening.



- Is Compressor locked?
- >> Check Compressor (PARTS INFORMATION 1,2)

Trouble shooting 36

Water Leaking

Forecast of Cause:

1. Erroneous installation 2. Drain hose failure

Diagnosis method when water leak occurs

- Is Main Unit installed in stable condition?
- Is Main Unit broken or deformed at the time of transportation or maintenance?



- Is Drain Hose connection loose?
- Is there a trap in Drain Hose?
- Is Drain Hose clogged?



Is Fan rotating?

Diagnosis method when water is spitting out.

Is the filter clogged?



 Check Gas Pressure and correct it if there was a gas leak.





7-4 SERVICE PARTS INFORMATION

SERVICE PARTS INFORMATION 1 Compressor Diagnosis method of Compressor (If Outdoor Unit LED displays Error, refer to Trouble shooting) Abnormal noise Stops soon after starting up Does not start up Check if vibration noise by - Is there open or loose connection • Is there open or loose connection cable? cable? loose bolt or contact noise of piping is happening. Is Gas Pipe Valve open? - Check Filter PCB, Main PCB, ► Defective Compressor (Low Pressure is too low) connection of Compressor, and winding can be considered. resistance. (Refer to the next page). (due to inside dirt clogging >> If there is no failure, the defect of (MPa) (MPa or broken component) Compressor is considered (Locked Check if Refrigerant is leaking. \bigcirc 0 compressor due to clogged dirt or (Recharge Refrigerant) less oil) Replace Compressor · Check if Strainer is clogged. (PARTS INFORMATION 4) Replace Compressor · Check Filter PCB, Main PCB, connection of Compressor, and winding resistance. (Refer to the next page). >> If there is no failure, the defect of Compressor can be considered. (Compression part broken or valve defective.) Replace Compressor

SERVICE PARTS INFORMATION 2

Inverter Compressor





Check Point 3: Replace Main PCB

▶If the symptom does not change with above Check 1, 2, replace Main PCB.

(For AR*A36L/45L)


SERVICE PARTS INFORMATION 3

Active Filter Module

Check Point 1: Check Open or Short-circuit and Diode (D1)

•Remove connector, check the open or short-circuit and the diode in the module





Check the open or short-circuit

Tern	ninal	Resistance value		
Tester(+)	Tester(-)	Resistance value		
(+)	(-)	360k Ω		
(–)	N1	0Ω		
Р	(+)	720k Ω		
L1	L2	5.4M Ω (approx.)		
Р	N1	360k Ω		
L1,L2	Control Box	∞ Ω		
L2	N2	5.8M Ω(approx.)		


Check the diode

Tern	ninal	Desistance value
Tester(+)	Tester(-)	Resistance value
L2	Р	5.3M Ω (approx.)
Р	L2	5.4M Ω (approx.)

▶ If it is abnormal,replace ACTIVE FILTER MODULE

Check Point 2: Check the Output DC voltage (between P and N1)

- Check the Output DC voltage (between P and N1) of compressor stopping and operating.






SERVICE PARTS INFORMATION 4

Outdoor unit Electronic Expansion Valve (EEV)

Check Point 1: Check Connections

Check connection of connector (CN27 or CN40)
 (Loose connector or open cable)

CN40 (For AR*A12L-24L) CN27 (For AR*A36L/ 45L)




Check Point 2: Check Coil of EEV

 Remove connector, check each winding resistance of Coil.

Read wire	Resistance value					
White - Red						
Yellow - Brown	46 Ω ± 4 Ω					
Orange - Red	at 20°C	75				
Blue - Brown		8				

▶ If Resistance value is abnormal, replace EEV.

Check Point 3: Check Voltage from Main PCB.




► If it does not appear, replace Main PCB.




Check Point 4: Check Noise at start up

- Turn on Power and check operation noise.
- ► If an abnormal noise does not show, replace Main PCB.




When Valve is closed,

it has a temp. difference between Inlet and Outlet.




If it is open,


it has no temp. difference between Inlet and Outlet.



Check Point 6: Check Strainer

Strainer normally does not have temperature difference between inlet and outlet as shown in ①, but if there is a difference as shown in ②, there is a possibility of inside clogged. In this case, replace Strainer.







DUCT type INVERTER

8. APPENDING DATA

8. APPENDING DATA

8-1. CAPACITY TABLE

■ MODEL: AR*A12LATN / AO*A12LACL

COOLING

AFR 12.2

			Indoor temperature																			
	°CDB		18 21 23 25				27			29		32										
	°CWB		12			15			16			18			19			21			23	
	°CDB	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
	-10	3.52	3.13	0.31	3.92	3.15	0.31	4.05	3.42	0.32	4.32	3.43	0.32	4.46	3.70	0.32	4.72	3.69	0.32	4.99	3.93	0.33
	0	3.33	3.00	0.51	3.71	3.02	0.52	3.84	3.28	0.52	4.09	3.29	0.53	4.22	3.55	0.53	4.47	3.54	0.54	4.73	3.77	0.54
an	5	3.33	3.00	0.49	3.71	3.02	0.50	3.84	3.28	0.50	4.09	3.29	0.51	4.22	3.55	0.51	4.47	3.54	0.52	4.73	3.77	0.52
erat	10	3.33	2.99	0.45	3.71	3.01	0.46	3.84	3.27	0.46	4.09	3.29	0.46	4.21	3.55	0.47	4.47	3.53	0.47	4.72	3.76	0.48
ď	15	3.22	2.92	0.55	3.59	2.94	0.56	3.71	3.19	0.56	3.95	3.20	0.57	4.08	3.46	0.57	4.32	3.44	0.58	4.57	3.67	0.58
or te	20	4.20	3.60	1.29	4.68	3.63	1.31	4.84	3.94	1.32	5.16	3.95	1.33	5.32	4.27	1.34	5.64	4.25	1.35	5.95	4.53	1.36
utdoc	25	4.03	3.49	1.44	4.49	3.51	1.46	4.64	3.81	1.47	4.95	3.83	1.48	5.10	4.13	1.49	5.41	4.11	1.51	5.71	4.38	1.52
ō	30	3.80	3.32	1.53	4.23	3.34	1.56	4.37	3.63	1.56	4.66	3.64	1.58	4.81	3.93	1.59	5.09	3.92	1.60	5.38	4.17	1.62
	35	3.48	3.10	1.54	3.88	3.12	1.57	4.01	3.39	1.57	4.27	3.40	1.59	4.40	3.67	1.60	4.67	3.65	1.61	4.93	3.89	1.63
	40	2.93	2.72	1.31	3.26	2.74	1.33	3.37	2.98	1.33	3.59	2.99	1.35	3.70	3.22	1.35	3.93	3.21	1.37	4.15	3.42	1.38
	46	2.16	2.20	1.01	2.40	2.21	1.03	2.48	2.40	1.03	2.65	2.41	1.04	2.73	2.60	1.05	2.89	2.59	1.06	3.06	2.76	1.07

AFR : Air flow rate (m³/min)
TC : Total capacity (kW)
SHC : Sensible Heat capacity (kW)

PI : Power Input (kW)

HEATING

AFR 12.2

				Indoor temperature												
		°CDB	1	6	18		2	:0	2	2	24					
	°CDB	°CWB	TC	PI	TC	PI	TC PI		TC	PI	TC	PI				
	-15	-16	3.41	1.87	3.32	1.91	3.24	1.95	3.16	1.99	3.08	2.03				
ø	-10	-11	4.16	1.87	4.06	1.91	3.96	1.95	3.86	1.99	3.76	2.03				
temperature	-5	-7	4.76	2.15	4.65	2.19	4.53	2.24	4.42	2.28	4.26	2.30				
per	0	-2	5.43	2.22	5.30	2.27	5.17	2.30	4.92	2.30	4.70	2.30				
tem	5	3	5.91	2.21	5.77	2.26	5.63	2.30	5.37	2.30	5.14	2.30				
00r	7	6	5.99	2.06	5.84	2.10	5.70	2.15	5.56	2.19	5.42	2.23				
Outdoor	10	8	6.20	2.04	6.06	2.08	5.91	2.12	5.76	2.16	5.61	2.21				
	15	10	6.39	2.01	6.24	2.05	6.09	2.09	5.93	2.14	5.78	2.18				
	20	15	6.42	1.78	6.27	1.81	6.12	1.85	5.96	1.89	5.81	1.92				
	24	18	6.46	1.76	6.31	1.79	6.15	1.83	6.00	1.87	5.84	1.90				

AFR : Air flow rate (m³/min) TC : Total capacity (kW) PI : Power Input (kW)

■ MODEL: AR*A14LATN / AO*A14LACL

COOLING

AFR 13.7

											Indoo	r tempe	rature									
	°CDB		18			21			23			25			27			29			32	
	°CWB		12			15			16			18			19			21			23	
	°CDB	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
	-10	4.06	3.64	0.36	4.52	3.67	0.36	4.68	3.98	0.36	4.99	4.00	0.37	5.14	4.32	0.37	5.45	4.30	0.37	5.76	4.58	0.38
	0	3.97	3.58	0.42	4.42	3.60	0.43	4.57	3.91	0.43	4.87	3.92	0.43	5.03	4.24	0.44	5.33	4.22	0.44	5.63	4.50	0.44
rature	5	3.84	3.49	0.53	4.28	3.51	0.54	4.43	3.81	0.54	4.72	3.82	0.54	4.87	4.13	0.55	5.16	4.11	0.55	5.45	4.38	0.56
erat	10	3.70	3.38	0.63	4.12	3.40	0.64	4.26	3.70	0.64	4.54	3.71	0.65	4.68	4.01	0.65	4.96	3.99	0.66	5.24	4.25	0.67
temper	15	3.75	3.42	0.55	4.18	3.44	0.56	4.32	3.74	0.56	4.60	3.75	0.57	4.75	4.05	0.57	5.03	4.03	0.58	5.32	4.30	0.58
	20	4.78	4.17	1.20	5.32	4.19	1.22	5.51	4.56	1.22	5.87	4.57	1.24	6.05	4.94	1.24	6.41	4.92	1.26	6.78	5.24	1.27
Outdoo	25	4.56	4.01	1.35	5.08	4.03	1.37	5.25	4.38	1.38	5.60	4.40	1.39	5.77	4.75	1.40	6.12	4.73	1.41	6.47	5.04	1.43
O	30	4.33	3.84	1.50	4.82	3.86	1.52	4.98	4.20	1.53	5.31	4.21	1.55	5.48	4.55	1.55	5.81	4.53	1.57	6.13	4.82	1.59
	35	4.27	3.79	1.78	4.75	3.81	1.81	4.91	4.15	1.82	5.24	4.16	1.84	5.40	4.49	1.85	5.72	4.47	1.87	6.05	4.77	1.88
	40	3.12	2.97	1.27	3.47	2.99	1.29	3.59	3.25	1.29	3.83	3.26	1.31	3.95	3.52	1.31	4.18	3.50	1.33	4.42	3.73	1.34
	46	2.22	2.34	0.96	2.47	2.35	0.98	2.56	2.56	0.98	2.73	2.56	0.99	2.81	2.77	1.00	2.98	2.76	1.01	3.15	2.94	1.02

AFR: Air flow rate (m³/min)
TC: Total capacity (kW)
SHC: Sensible Heat capacity (kW)

PI : Power Input (kW)

HEATING

AFR 13.7

						In	door tei	mperatu	ire			
		°CDB	1	6	1	8	2	20	2	2	2	.4
	°CDB	°CWB	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
	-15	-16	4.35	2.16	4.25	2.21	4.14	2.25	4.04	2.30	3.94	2.34
ىۋ	-10	-11	4.92	2.16	4.80	2.21	4.68	2.25	4.56	2.30	4.45	2.34
Outdoor temperature	-5	-7	5.48	2.39	5.35	2.44	5.22	2.49	5.09	2.54	4.96	2.59
per	0	-2	6.29	2.56	6.14	2.61	5.99	2.67	5.84	2.72	5.69	2.77
tem	5	3	7.04	2.74	6.88	2.80	6.71	2.85	6.46	2.87	6.17	2.87
00r	7	6	6.83	2.35	6.66	2.40	6.50	2.45	6.34	2.49	6.18	2.54
outd	10	8	7.08	2.40	6.91	2.45	6.74	2.50	6.57	2.55	6.40	2.60
	15	10	6.71	2.06	6.55	2.10	6.39	2.14	6.23	2.19	6.07	2.23
	20	15	6.28	1.64	6.13	1.67	5.98	1.71	5.83	1.74	5.68	1.78
	24	18	6.47	1.64	6.32	1.68	6.16	1.71	6.01	1.75	5.85	1.78

AFR : Air flow rate (m³/min) TC : Total capacity (kW) PI : Power Input (kW)

■ MODEL: AR*A18LATN / AO*A18LACL

COOLING

AFR 13.7

		ī										Indoo	r tempe	roturo									$\overline{}$
	- ⊢											IIIuuu		ialuie									-
	Ľ	°CDB		18			21			23			25			27			29			32	
	۰	°CWB		12			15			16			18			19			21			23	
	°CD	В	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
	-10)	4.44	3.44	0.35	4.94	3.46	0.35	5.11	3.77	0.35	5.45	3.78	0.36	5.62	4.08	0.36	5.96	4.06	0.36	6.29	4.33	0.37
	0		4.34	3.40	0.41	4.83	3.42	0.42	5.00	3.71	0.42	5.33	3.72	0.42	5.49	4.02	0.42	5.82	4.01	0.43	6.15	4.27	0.43
ture	5		4.20	3.33	0.51	4.68	3.35	0.52	4.84	3.64	0.52	5.16	3.65	0.53	5.32	3.94	0.53	5.64	3.93	0.54	5.96	4.19	0.54
erat	10)	4.04	3.25	0.62	4.50	3.27	0.63	4.66	3.56	0.63	4.96	3.57	0.63	5.12	3.86	0.64	5.42	3.84	0.64	5.73	4.09	0.65
g.	15	,	4.10	3.28	0.54	4.56	3.30	0.54	4.72	3.59	0.55	5.03	3.60	0.55	5.19	3.89	0.56	5.50	3.87	0.56	5.81	4.12	0.57
r te	20)	5.22	3.83	1.17	5.82	3.85	1.19	6.02	4.19	1.19	6.41	4.20	1.21	6.61	4.54	1.21	7.01	4.52	1.22	7.40	4.81	1.24
utdoc	25	i	4.98	3.71	1.31	5.55	3.73	1.33	5.74	4.06	1.34	6.12	4.07	1.35	6.31	4.40	1.36	6.69	4.38	1.38	7.06	4.66	1.39
Ont	30)	4.73	3.58	1.46	5.27	3.60	1.48	5.45	3.92	1.49	5.81	3.93	1.51	5.98	4.25	1.51	6.34	4.23	1.53	6.70	4.50	1.55
ľ	35	,	4.66	3.55	1.74	5.19	3.57	1.76	5.37	3.88	1.77	5.72	3.90	1.79	5.90	4.21	1.80	6.25	4.19	1.82	6.61	4.46	1.84
	40	1	3.41	2.96	1.24	3.80	2.98	1.25	3.92	3.24	1.26	4.18	3.25	1.27	4.31	3.51	1.28	4.57	3.50	1.29	4.83	3.72	1.31
	46	i	2.43	2.53	0.94	2.70	2.54	0.95	2.79	2.76	0.96	2.98	2.77	0.97	3.07	2.99	0.97	3.25	2.98	0.98	3.44	3.18	0.99

AFR : Air flow rate (m³/min)

TC : Total capacity (kW)

SHC : Sensible Heat capacity (kW)

PI : Power Input (kW)

HEATING

AFR 13.7

						I	ndoor te	emperatu	re			
		°CDB	1	6	_	18	2	20	2	22	2	24
	°CDB	°CWB	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
	-15	-16	5.06	2.18	4.94	2.22	4.81	2.27	4.69	2.31	4.57	2.36
ē	-10	-11	5.71	2.29	5.58	2.33	5.44	2.38	5.30	2.43	5.17	2.48
temperature	-5	-7	6.37	2.41	6.22	2.46	6.06	2.51	5.91	2.56	5.76	2.61
ber	0	-2	7.25	2.58	7.08	2.63	6.91	2.68	6.73	2.74	6.56	2.79
ten	5	3	8.13	2.75	7.93	2.81	7.74	2.87	7.55	2.93	7.35	2.98
00r	7	6	7.87	2.36	7.69	2.41	7.50	2.46	7.31	2.51	7.12	2.56
Outdoor	10	8	8.16	2.41	7.97	2.46	7.77	2.51	7.58	2.57	7.39	2.62
Ō	15	10	7.75	2.07	7.56	2.11	7.38	2.16	7.19	2.20	7.01	2.24
	20	15	7.24	1.65	7.07	1.68	6.90	1.72	6.73	1.75	6.55	1.79
	24	18	7.46	1.65	7.29	1.69	7.11	1.72	6.93	1.76	6.75	1.79

AFR: Air flow rate (m³/min)

TC : Total capacity (kW)

PI : Power Input (kW)

■ MODEL: AR*A24LATN / AO*A24LACL

COOLING

AFR 18.3

												Indoo	r tempe	rature									
	[°CDB		18			21			23			25			27			29			32	
		°CWB		12			15			16			18			19			21			23	
	°CI	DВ	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
	-1	0	5.62	4.62	0.60	6.26	4.65	0.61	6.47	5.05	0.62	6.90	5.07	0.62	7.11	5.48	0.62	7.54	5.45	0.63	7.97	5.81	0.64
	C)	5.53	4.58	0.65	6.16	4.60	0.66	6.37	5.00	0.66	6.79	5.02	0.67	7.00	5.42	0.67	7.42	5.40	0.68	7.83	5.75	0.68
temperature	5	5	5.34	4.49	0.79	5.94	4.51	0.80	6.15	4.91	0.80	6.55	4.92	0.81	6.75	5.32	0.82	7.16	5.29	0.82	7.57	5.64	0.83
era	1	0	5.13	4.38	0.92	5.71	4.40	0.93	5.90	4.79	0.94	6.29	4.80	0.95	6.49	5.19	0.95	6.88	5.17	0.96	7.27	5.50	0.97
l du	1:	5	5.25	4.44	0.76	5.85	4.47	0.78	6.05	4.86	0.78	6.45	4.87	0.79	6.65	5.26	0.79	7.05	5.24	0.80	7.45	5.58	0.81
or te	2	0	6.78	5.21	1.61	7.55	5.24	1.64	7.81	5.70	1.65	8.32	5.72	1.66	8.58	6.18	1.67	9.09	6.15	1.69	9.61	6.55	1.70
0	2	5	6.45	5.04	1.81	7.18	5.07	1.84	7.43	5.51	1.85	7.92	5.53	1.87	8.16	5.97	1.88	8.65	5.95	1.90	9.14	6.34	1.91
Outd	3	0	6.10	4.87	2.01	6.80	4.90	2.04	7.03	5.32	2.05	7.50	5.34	2.07	7.73	5.77	2.08	8.19	5.74	2.10	8.65	6.12	2.12
1	3	5	6.32	4.98	2.53	7.04	5.01	2.57	7.28	5.45	2.58	7.76	5.46	2.61	8.00	5.90	2.62	8.48	5.88	2.65	8.96	6.26	2.67
	4	0	5.13	4.38	2.05	5.71	4.41	2.08	5.91	4.79	2.09	6.30	4.80	2.11	6.49	5.19	2.12	6.88	5.17	2.14	7.27	5.51	2.16
	4	6	3.66	3.68	1.56	4.08	3.70	1.58	4.22	4.02	1.59	4.50	4.03	1.60	4.64	4.36	1.61	4.91	4.34	1.63	5.19	4.62	1.64

AFR : Air flow rate (m³/min)

TC : Total capacity (kW)

SHC : Sensible Heat capacity (kW)

PI : Power Input (kW)

HEATING

AFR 18.3

						I	ndoor te	mperatu	re			
		°CDB	1	6		18	2	20	2	22	2	24
	°CDB	°CWB	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
	-15	-16	6.27	2.75	6.12	2.81	5.97	2.87	5.82	2.93	5.67	2.98
<u>e</u>	-10	-11	7.10	2.97	6.93	3.04	6.76	3.10	6.60	3.16	6.43	3.22
temperature	-5	-7	7.94	3.12	7.75	3.18	7.56	3.25	7.37	3.31	7.18	3.38
be	0	-2	8.80	3.05	8.59	3.12	8.38	3.18	8.17	3.25	7.96	3.31
tem	5	3	9.72	3.08	9.49	3.14	9.26	3.21	9.03	3.27	8.80	3.34
	7	6	9.56	2.66	9.33	2.71	9.10	2.77	8.87	2.83	8.65	2.88
Outdoor	10	8	9.85	2.66	9.62	2.72	9.38	2.78	9.15	2.83	8.91	2.89
Ō	15	10	9.03	2.13	8.82	2.17	8.60	2.22	8.39	2.26	8.17	2.31
	20	15	8.29	1.65	8.09	1.69	7.90	1.72	7.70	1.76	7.50	1.79
	24	18	8.58	1.65	8.38	1.68	8.17	1.72	7.97	1.75	7.77	1.79

AFR : Air flow rate (m³/min)

TC : Total capacity (kW) PI : Power Input (kW)

■ MODEL: AR*A36LATN / AO*A36LATL

COOLING

AFR 32.2

											Indooi	r tempe	rature									
	°CDB		18			21			23			25			27			29			32	
	°CWB		12			15			16			18			19			21			23	
	°CDB	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
	-15	8.68	6.29	1.21	9.67	6.33	1.23	10.00	6.88	1.24	10.66	6.91	1.25	10.99	7.46	1.26	11.65	7.43	1.27	12.31	7.91	1.28
	-10	8.37	6.18	1.44	9.33	6.21	1.47	9.65	6.75	1.47	10.28	6.78	1.49	10.60	7.32	1.50	11.24	7.29	1.51	11.87	7.76	1.53
<u>ല</u>	0	8.53	6.24	1.30	9.50	6.28	1.32	9.82	6.83	1.32	10.47	6.85	1.34	10.79	7.40	1.34	11.44	7.37	1.36	12.09	7.85	1.37
atn	5	8.21	6.11	1.52	9.14	6.15	1.54	9.45	6.68	1.55	10.08	6.70	1.56	10.39	7.24	1.57	11.01	7.21	1.59	11.63	7.68	1.60
mper	10	8.23	6.12	1.47	9.17	6.16	1.49	9.48	6.69	1.50	10.11	6.72	1.52	10.42	7.25	1.52	11.05	7.22	1.54	11.67	7.69	1.55
tem	15	7.89	5.99	1.69	8.79	6.03	1.72	9.09	6.55	1.73	9.68	6.57	1.75	9.98	7.10	1.76	10.58	7.07	1.77	11.18	7.53	1.79
90 r	20	9.72	6.71	2.51	10.82	6.75	2.55	11.19	7.33	2.56	11.93	7.36	2.59	12.30	7.94	2.60	13.04	7.91	2.63	13.77	8.43	2.66
tp	25	9.58	6.66	2.60	10.67	6.70	2.64	11.03	7.28	2.66	11.76	7.30	2.68	12.13	7.89	2.70	12.85	7.85	2.72	13.58	8.37	2.75
Ō	30	9.12	6.48	2.91	10.16	6.52	2.95	10.51	7.09	2.97	11.20	7.11	3.00	11.54	7.68	3.01	12.24	7.65	3.04	12.93	8.15	3.08
	35	8.85	6.37	3.37	9.86	6.40	3.42	10.19	6.96	3.44	10.86	6.98	3.47	11.20	7.54	3.49	11.87	7.51	3.52	12.54	8.00	3.56
	40	7.05	5.68	2.81	7.85	5.72	2.85	8.12	6.22	2.87	8.65	6.24	2.89	8.92	6.73	2.91	9.46	6.71	2.94	9.99	7.15	2.97
	46	4.98	4.95	2.24	5.54	4.98	2.27	5.73	5.42	2.28	6.11	5.43	2.31	6.30	5.87	2.32	6.68	5.85	2.34	7.05	6.23	2.37

AFR : Air flow rate (m³/min)
TC : Total capacity (kW)

SHC : Sensible Heat capacity (kW)

PI : Power Input (kW)

HEATING

AFR 32.2

						I.	ndoor ter	mperatur	e			
		°CDB	1	6	1	8	2	0	2	2	2	4
	°CDB	°CWB	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
	-15	-16	10.17	3.61	9.93	3.68	9.68	3.76	9.44	3.83	9.20	3.91
ē	-10	-11	10.91	3.63	10.65	3.71	10.39	3.78	10.13	3.86	9.87	3.93
temperature	-5	-7	11.69	3.62	11.41	3.70	11.13	3.78	10.86	3.85	10.58	3.93
beı	0	-2	12.75	3.62	12.44	3.69	12.14	3.77	11.84	3.84	11.53	3.92
ten	5	3	13.68	3.59	13.36	3.67	13.03	3.74	12.70	3.82	12.38	3.89
oc	7	6	14.70	3.62	14.35	3.69	14.00	3.77	13.65	3.85	13.30	3.92
Outdoor	10	8	15.44	3.59	15.07	3.67	14.70	3.74	14.34	3.82	13.97	3.89
Ō	15	10	14.72	3.17	14.37	3.24	14.02	3.30	13.67	3.37	13.32	3.44
	20	15	14.15	2.78	13.81	2.83	13.48	2.89	13.14	2.95	12.80	2.99
	24	18	14.92	2.75	14.57	2.81	14.21	2.86	13.86	2.92	13.50	2.97

AFR : Air flow rate (m³/min) TC : Total capacity (kW) PI : Power Input (kW)

■ MODEL: AR*A45LATN / AO*A45LATL

COOLING

AFR 35.3

												Indoo	r tempe	rature									
		°CDB		18			21			23			25			27			29			32	
		°CWB		12			15			16			18			19			21			23	
	°C	DB	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
	-1	5	10.59	8.61	1.51	11.80	8.66	1.54	12.20	9.42	1.55	13.00	9.45	1.56	13.41	10.20	1.57	14.21	10.16	1.58	15.02	10.82	1.60
	-1	0	10.20	8.42	1.79	11.37	8.47	1.81	11.75	9.21	1.82	12.53	9.24	1.84	12.92	9.98	1.85	13.69	9.94	1.87	14.47	10.58	1.89
ē	()	10.42	8.52	1.59	11.60	8.57	1.62	12.00	9.32	1.63	12.79	9.35	1.64	13.19	10.10	1.65	13.98	10.06	1.67	14.77	10.71	1.68
rature	ţ	5	10.01	8.33	1.86	11.15	8.37	1.89	11.53	9.10	1.90	12.29	9.13	1.92	12.68	9.86	1.93	13.44	9.83	1.95	14.20	10.47	1.97
- De	1	0	10.06	8.35	1.80	11.21	8.40	1.83	11.59	9.13	1.84	12.35	9.16	1.86	12.73	9.89	1.87	13.50	9.85	1.89	14.26	10.49	1.90
tem	1	5	9.63	8.14	2.07	10.72	8.19	2.10	11.09	8.90	2.12	11.82	8.93	2.14	12.18	9.64	2.15	12.92	9.60	2.17	13.65	10.23	2.19
ŏ	2	0	11.94	9.29	3.05	13.31	9.34	3.10	13.76	10.16	3.12	14.67	10.19	3.15	15.12	11.00	3.17	16.03	10.96	3.20	16.93	11.67	3.23
utdoor	2	5	11.79	9.22	3.16	13.14	9.28	3.21	13.58	10.09	3.22	14.48	10.12	3.26	14.93	10.93	3.27	15.82	10.88	3.31	16.72	11.59	3.34
Ō	3	0	11.21	8.93	3.52	12.49	8.98	3.58	12.91	9.76	3.60	13.76	9.80	3.63	14.19	10.58	3.65	15.04	10.54	3.69	15.89	11.22	3.72
	3	5	11.06	8.84	4.21	12.32	8.89	4.27	12.74	9.67	4.29	13.58	9.70	4.34	14.00	10.48	4.36	14.84	10.44	4.40	15.68	11.12	4.45
	4	0	8.53	7.62	3.36	9.50	7.66	3.41	9.83	8.33	3.43	10.47	8.36	3.46	10.80	9.02	3.48	11.45	8.99	3.51	12.09	9.57	3.55
	4	6	6.03	6.44	2.72	6.71	6.48	2.76	6.94	7.04	2.77	7.40	7.06	2.80	7.63	7.63	2.82	8.09	7.60	2.84	8.54	8.09	2.84

AFR : Air flow rate (m³/min) TC : Total capacity (kW)

SHC : Sensible Heat capacity (kW)

PI : Power Input (kW)

HEATING

AFR 35.3

						l	ndoor ter	nperatur	е			
		°CDB	1	6	1	8	2	0	2	2	2	4
	°CDB	°CWB	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
	-15	-16	11.58	4.19	11.31	4.28	11.03	4.37	10.75	4.46	10.48	4.54
ല	-10	-11	12.51	4.19	12.22	4.28	11.92	4.36	11.62	4.45	11.32	4.54
temperature	-5	-7	13.43	4.20	13.11	4.29	12.79	4.37	12.47	4.46	12.15	4.55
ber	0	-2	14.50	4.20	14.15	4.29	13.81	4.37	13.46	4.46	13.12	4.55
ten	5	3	15.93	4.21	15.55	4.30	15.17	4.39	14.79	4.47	14.41	4.56
)OC	7	6	17.01	4.19	16.60	4.28	16.20	4.37	15.79	4.46	15.39	4.54
Outdoor	10	8	17.74	4.19	17.32	4.28	16.90	4.37	16.47	4.45	16.05	4.54
Ō	15	10	16.63	3.51	16.23	3.58	15.84	3.66	15.44	3.73	15.04	3.80
	20	15	15.75	3.05	15.37	3.11	15.00	3.17	14.62	3.24	14.25	3.29
	24	18	16.76	3.05	16.36	3.11	15.96	3.17	15.56	3.24	15.16	3.29

AFR : Air flow rate (m³/min) TC : Total capacity (kW) PI : Power Input (kW)

8-2. OPERATION RANGE

■ MODEL: AR*A12/14/18/24LATN/AO*A12/14/18/24LACL

Mode		Operation Range	
Mode	Indoor temperature	Indoor humidity	Outdoor temperature
Cooling Dry	18 to 32°C	About 80% or less	-10 to 46°C
Heating	30°C or less	_	-15 to 24°C

■ MODEL: AR*A36/45LATN/AO*A36/45LATL

Mode		Operation Range	
Mode	Indoor temperature	Indoor humidity	Outdoor temperature
Cooling Dry	18 to 32°C	About 80% or less	-15 to 46°C
Heating	30°C or less	_	-15 to 24°C

8-3. ELECTRIC CHARACTERISTICS

Model Name			AR*A12LATN	AR*A14LATN
Dower Cumply	Voltage	V	230 ~	
Power Supply	Frequency	Hz	50	
Max Operating Current		Α	0.3	0.3
Wiring Spec.	Connection cable	mm ²	1.5 - 2.5	
(Indoor unit to outdoor unit)	Limited wiring length	m	26	

Model Name		AO*A12LACL	AO*A14LACL	
Dawar Cumhi	Voltage	V	230 ~	
Power Supply	Frequency	Hz	50	
Max Operating Current		Α	10.0	12.5
Starting Current		Α	4.9	5.9
*1) Wiring Spec.	Main Fuse (Circuit breaker) Curren	А	25	25
1) Willing Opco.	Power Cable	mm ²	3.5 - 4.0	
*2) Limited wiring length		m	36	28

Model Name			AR*A18LATN AR*A24LATI	
Dawar Cumhu	Voltage	V	230 ~	
Power Supply	Frequency	Hz	50	
Max Operating Current		Α	0.5	0.7
	Circuit breaker	Α	0.6	0.9
*1) Wiring Spec.	Connection cable	mm ²	1.5 - 2.5	
	Limited wiring length	m	26	31

Model Name		AO*A18LACL	AO*A24LACL	
Dawar Cumhi	Voltage	V	230 ~	
Power Supply	Frequency	Hz	50	
Max Operating Current		Α	15.0	16.2
Starting Current		Α	7.7	10.0
*1) Wiring Spec.	Main Fuse (Circuit breaker) Curren	А	20	20
Ty Willing Opco.	Power Cable	mm ²	3.5 - 4.5	
*2) Limited wiring length		m	24	22

^{*1)} Wiring Spec.

Selected Sample

(Selected based on Japan Electrotechnical Standard and Code Committee E0005)

*2) Limited Wiring length

This is the wiring length in case voltage descent is less than 2%.

When the wiring length becomes long, please select the wiring of more larger diameter.

Model Name			AR*A36LATN	AR*A45LATN
Dower Cumby	Voltage	V	230 ~	
Power Supply	Frequency	Hz	50	
Max Operating Current		Α	2.0	2.1
Wiring Spec.	Connection cable	mm ²	1.5 - 2.5	
(Indoor unit to outdoor unit)	Limited wiring length	m	51	

Model Name		AO*A36LATL	AO*A45LATL	
Dawar Cumhi	Voltage	V	230 ~	
Power Supply	Frequency	Hz	50	
Max Operating Current		Α	19.0	20.5
Starting Current		Α	15.0	
*1) Wiring Spec. Main Fuse (Circuit breaker) Curren		А	30	
1) Willing Opec.	Power Cable	mm ²	5.3 - 6.0	
*2) Limited wiring length		m	1	7

^{*1)} Wiring Spec.

Selected Sample

(Selected based on Japan Electrotechnical Standard and Code Committee E0005)

*2) Limited Wiring length

This is the wiring length in case voltage descent is less than 2%. When the wiring length becomes long, please select the wiring of more larger diameter.

8-4. SAFETY DEVICE

■OUTDOOR UNIT

		Model			
		AO*A12LACL AO*A14LACL			
	Current fuse	20A 250V			
Circuit	(NEAR THE TERMINAL)	5A	250V		
protection	Current fuse	15A	250V		
	(MAIN PRINTED CIRCUIT BOARD)		3.15A 250V		
Fan motor	Thermal protection program	OFF: 100 ⁺¹⁵ °C			
protection	Thermal protection program	ON : 95 ⁺¹⁵ °C			
	Thermal protection program	OFF : 110°C			
Compressor	(COMPRESSOR TEMP.)	ON : After 40 minutes			
protection Thermal protection program (DISCHARGE TEMP.)		OFF : 110°C ON : After 7 minutes			

		Model		
		AO*A18LACL	AO*A24LACL	
	Current fuse	20A 250V		
Circuit	(NEAR THE TERMINAL)	5A 250V		
protection	Current fuse	15A	250V	
	(MAIN PRINTED CIRCUIT BOARD)		250V	
Fan motor	Thermal protection program	OFF : 100 ⁺¹⁵ °C	OFF: 110 ⁺¹⁵ °C	
protection	Thermal protection program	ON : 95 ⁺¹⁵ ₋₁₀ °C	ON : 105 ⁺¹⁵ °C	
	Thermal protection program	OFF : 110	°C	
Compressor	(COMPRESSOR TEMP.)	ON : After 40 minutes		
protection Thermal protection program		OFF: 110°C		
(DISCHARGE TEMP.)		ON : After 7 minutes		

		Model		
		AO*A36LATL	AO*A45LATL	
Current fuse		25A 250V		
Circuit	(NEAR THE TERMINAL)	10A 250V		
protection	Current fuse	5A :	250V	
(MAIN PRINTED CIRCUIT BOARD)		3.15A 250V		
Fan motor protection	Thermal protection program	OFF: 130±20°C ON: 100±20°C		
High Pressure protection	High Pressure Switch	OFF: 4.2 ±0.1MPa ON: 3.2 ±0.15MPa		
Compressor	Thermal protection program (COMPRESSOR TEMP.)	OFF : 110°C ON : 80°C		
protection	Thermal protection program (DISCHARGE TEMP.)	OFF : 115°C ON : After 7 minutes		

■INDOOR UNIT

		Мо	del
		AR*A12LATN	AR*A14LATN
Circuit protection	Current fuse (PCB)	3.15A	250V
Fan motor protection	Thermal protection program	OFF : 140 ON : 110	

		Mc	odel
		AR*A18LATN	AR*A24LATN
Circuit protection	Current fuse (PCB)	3.15A	250V
Fan motor protection	Thermal protection program	OFF : 140 ON : 110	

		Mo	del
		AR*A18LATN	AR*A24LATN
Circuit protection	Current fuse (PCB)	3.15A 250V	
Fan motor	Over current protection	1.90 ±0.24A	
protection	Thermal protection program	OFF: 115±10°C ON: 90±10°C	

8-5. FUNCTION SETTING

8-5-1 INDOOR UNIT

- Follow the instructions in the Local Setup Procedure, which is supplied with the remote control, in accordance with the installed condition.
 - After the power is turned on, perform the Function Setting on the remote control.
- The settings may be selected between the following two: Function Number or Setting Value.
- Settings will not be changed if invalid numbers or setting values are selected.

1-1. Setting the Static Pressure

(♠ Factory setting)

	Setting Description	Function Number	Setting Value
•	Normal		00
	High static pressure 1	21	01
	High static pressure 2	21	02
	High static pressure 3		03

Determine the wind volume in each mode i.e., applicable range of static pressure, refering to TECHNICAL MANUAL.

1-2. Setting the Cooler Room Temperature Correction

Depending on the installed environment, the room temperature sensor may require a correction. The settings may be selected as shown in the table below.

	Setting Description	Function Number	Setting Value
◆ Standard		30	00
	Lower control	30	01

1-3. Setting the Heater Room Temperature Correction

Depending on the installed environment, the room temperature sensor may require a correction. The settings may be changed as shown in the table below.

	Setting Description	Function Number	Setting Value
•	Standard		00
	Lower control	31	01
	Slightly warmer control		02
	Warmer control		03

1-4. Setting Other Functions

The following settings are also possible, depending on the operating conditions.

Auto Restart

(♦ Factory setting)

	Setting Description	Function Number	Setting Value
◆ Yes		40	00
	No	70	01

Indoor Room Temperature Sensor Switching Function (Only for Wired remote controller)

(Factory setting)

	Setting Description	Function Number	Setting Value
•	No	42	00
	Yes	42	01


- If setting value is "00", room temperature is controlled by the indoor unit temperature sensor.
- If setting value is "01", room temperature is controlled by either indoor unit temperature sensor or remote control unit sensor.

8-5-2 Procedures to change the Function Setting


- This procedure changes the function settings used to control the indoor unit according to the installation conditions.
- Incorrect settings can cause the indoor unit to malfunction.

This procedure should be performed by authorized installation or service personnel only.


- Perform the "FUNCTION SETTING" according to the installation conditions using the remote controller.
- (1) Press the set temperature buttons (∨) (∧) and fan control button simultaneously for more than 5 seconds to enter the function setting mode.



(2) Press the SET BACK button to select the indoor unit number.




(3) Press the set time buttons to select the function number.



- (4) Press set temperature buttons (\lor) (\land) to select the setting value. The display flashes as shown to the right during setting value selection.
- (5) Press the SET button to confirm the setting. Press the SET button for a few seconds until the setting value stops flashing. If the setting value display changes or if "- -" is displayed when the flashing stops, the setting value has not been set correctly. (An invalid setting value may have been selected for

the indoor unit.)




- (6) Repeat steps 2 to 5 to perform additional settings. Press the set temperature buttons (∨) (∧) and fan control button simultaneously again for more than 5 secondsto cancel the function setting mode. In addition, the function setting mode will be automatically canceled after 1 minute if no operation is performed.
- (7) After completing the FUNCTION SETTING, be sure to turn off the power and turn it on again.

8-5-3 WIRED REMOTE CONTROLLER

Wired remote controller		
	1	Can be used. (Do not change.)
	2	Dual remote controller setting
DIP SW	3	Filter reset operation and filter display (Duct model is nonfunctional.)
	4	Can be used. (Do not change.)
	5	Can be used. (Do not change.)
	6	Memory backup setting

■ SWITCH POSITION

Wired remote controller



■ DIP SWITCH SETTING

1. SW setting

1-1 Dual remote controller setting

Set the remote controller DIP switch 1 No.2 according to the following table.

Number of remote controller

Number of remote controller

DIP-SW 1 DIP-SW 1 No.2

1 (Normal)

OFF

ON

(♦ - - Factory setting)

1-2 Memory backup setting

Set to ON to use batteries for the memory backup.if batteries are not used, all of the settings stored in memory will be deleted if there is a power failure.

X This function is wired remotecontroll only.

(♦ - Factory setting)

	DIP-SW No.6	Memory backup
•	OFF	Invalidity
	ON	Validity



DUCT type INVERTER

9. INSTALLATION MANUAL

Duct Type SPLIT TYPE AIR CONDITIONER INSTALLATION **INSTRUCTION SHEET**

A CAUTION REFRIGERANT IIS PRODUCT MUST ONLY BE INSTALLED OR SERVICED

gulations, codes, installation & operation manuals, before a installation, maintenance and /or service of this product.

(PART NO. 9374815043)

Indoor unit is an appliance not accessible to the general public.

For authorized service personnel only.

⚠ DANGER	This mark indicates procedures which, if improperly performed, are most likely to result in the death of or serious injury to the user or service personnel.
⚠ WARNING	This mark indicates procedures which, if improperly performed, might lead to the death or serious injury of the user.
⚠ CAUTION	This mark indicates procedures which, if improperly performed, might possibly result in personal harm to the user, or damage to property.

⚠ DANGER

Never touch electrical components immediately after the power supply has been turned off. Electrical shock may occur. After turning off the power, always wait 5 minutes or more before touching electrical components.

This air conditioner uses new refrigerant HFC (R410A).

The basic installation work procedures are the same as conventional refrigerant models. However, pay careful attention to the following points:

- Since the working pressure is 1.6 times higher than that of conventional refrigerant models, some of the piping and installation and service tools are special. (See the table below.) Especially, when replacing a conventional refrigerant model with a new refrigerant R410A model, always replace the conventional piping and flare nuts with the R410A piping and flare nuts.
- Models that use refrigerant R410A have a different charging port thread diameter to prevent erroneous charging with conventional refrigerant and for safety. Therefore, check beforehand. The charging port thread diameter for R410A is 1/2 UNF 20 threads per inch.]
- Be more careful that foreign matter (oil, water, etc.) does not enter the piping than with refrigerant models. Also, when storing the piping, securely seal the openings by pinching, taping, etc.
- ④ When charging the refrigerant, take into account the slight change in the composition of the gas and liquid phases, and always charge from the liquid phase side whose composition is stable.

Special tools for R410A

•	
Tool name	Contents of change
Gauge manifold	Pressure is high and cannot be measured with a conventional gauge. To prevent erroneous mixing of other refrigerants, the diameter of each port has been changed. It is recommended the gauge with seals –0.1 to 5.3 MPa (–76 cmHg to 53 kgf/cm²) for high pressure. –0.1 to 3.8 MPa (–76 cmHg to 38 kgf/cm²) for low pressure.
Charge hose	To increase pressure resistance, the hose material and base size were changed.
Vacuum pump	A conventional vacuum pump can be used by installing a vacuum pump adapter.
Gas leakage detector	Special gas leakage detector for HFC refrigerant R410A.
Conner nines	Thicknesses of Annealed Conner Pines (R410A)

Copper pipesIt is necessary to use seamless copper pipes and it is desirable that the amount of residual oil is less than 40 mg/10m. Do not use copper pipes

having a collapsed, deformed or discolored portion (especially on the interior surface). Otherwise, the expansion valve or capillary tube may become blocked with contaminants.

As an air conditioner using R410A incurs pressure higher than when using conventional refrigerant, it is necessary to choose adequate materials. Thicknesses of copper pipes used with R410A are as shown in the table. Never use copper pipes thinner than that in the table even when it is available on the market

Thicknesses of Annealed Copper Pipes (R410A)

Thickness
0.80 mm
0.80 mm
0.80 mm
1.00 mm

Strong and durable ceiling

For authorized service personnel only.

<u></u> WARNING
1 For the room air conditioner to operate satisfactorily, install it as outlined in this installation instruction sheet.

- ② Connect the indoor unit and outdoor unit with the room air conditioner piping and cords available standards parts. This installation instruction sheet describes the correct connections using the installation set available from our standard parts.
- ③ Installation work must be performed in accordance with national wiring standards by authorized personne
- (4) If refrigerant leaks while work is being carried out, ventilate the area. If the refrigerant comes in contact with a flame, it produces a toxic gas.
- 5 Do not use an extension cord.
- 6 Do not turn on the power until all installation work is complete.

CAUTION

This installation instruction sheet describes how to install the indoor unit only. To install the outdoor unit, refer to the installation instruction sheet included with the outdoor unit.

- · Be careful not to scratch the room air conditioner when handling it.
- · After installation, explain correct operation to the customer, using the operating manual.
- · Let the customer keep this installation instruction sheet because it is used when the air conditioner is serviced or

SELECTING THE MOUNTING POSITION

↑ WARNING

Install at a place that can withstand the weight of the indoor and outdoor units and install positively so that the units will not topple or fall.

⚠ CAUT

Do not install where there is the danger of combustible gas leakage

② Do not install near heat sources.

③ If children under 10 years old may approach the unit, take preventive measures so that they cannot reach the unit.

4 Take precautions to prevent the unit from falling.

Decide the mounting position with the customer as follows:

(1) Install the indoor unit level on a strong wall, floor, ceiling which is

- not subject to vibration. (2) The inlet and outlet ports should not be obstructed: the air should
- (3) Install the unit near an electric outlet or special branch circuit.
- (4) Install the unit where connection to the outdoor unit is easy.
- (7) Install the indoor unit where vibrations and noise are not ampli-
- (8) When installing the unit on the floor, provide an opening that will
- be able to blow all over the room. (5) Install the unit where the drain pipe can be easily installed. 10 cm (4") or more (6) Take servicing, etc. into consideration and leave the spaces shown on the right. Also install the unit where the filter can be allow sufficient air to reach the air inlet panel. Strong and durable floor 10 cm (4") or more 30 cm (1') or more

STANDARD PARTS

INDOOR UNIT ACCESSORIES

Special nut B

(small flange)

Name and Shape	Q'ty	Application
Installation template	1	For positioning the indoor unit
Hanger	4	For suspending the indoor unit from ceiling
Tapping screw (ø4 × 10)	8	For installing the hanger
Special nut A (large flange)	4	For suspending the indoor unit from ceiling

· ·		
Coupler heat insulation (large)	1	For indoor side pipe joint (large pipe)
Coupler heat insulation (small)	1	For indoor side pipe joint (small pipe)
Binder	(Large)	For fixing the coupler heat insulation
Filter	2	9000 BTU/h model
	3	12000 - 22000 BTU/h models
Drain hose insulation	1	Insulates the drain hose and vinyl hose connection

Name and Shape Q'ty Application

CONNECTING PIPE REQUIREMENT

A CAUTION

Refer to the installation instruction sheet of the outdoor unit for description of the length of connecting pipe or for difference of its elevation

MODEL		12000 BTU/h model	14000/18000 BTU/h model
Diameter	Small	6.35 mm (1/4 in.)	6.35 mm (1/4 in.)
Diameter	Large	9.52 mm (3/8 in.)	12.70 mm (1/2 in.)

· Use pipe with water-resistant heat insulation.

CAUTION

Install heat insulation around both the gas and liquid pipes. Failure to do so may cause water leaks.

Use heat insulation with heat resistance above 120 °C. (Reverse cycle model only)

In addition, if the humidity level at the installation location of the refrigerant piping is expected to exceed 70%, install heat insulation around the refrigerant piping. If the expected humidity level is 70-80%, use heat insulation that is 15 mm or thicker and if the expected humidity exceeds 80%, use heat insulation that is 20 mm or thicker. If heat insulation is used that is not as thick as specified, condensation may form on the surface of the insulation. In addition, use heat insulation with heat conductivity of 0.045 W/(m·K) or less (at 20 °C).

ELECTRICAL REQUIREMENT

Connection cord (mm²)		
MAX.	MIN.	
2.5	1.5	

- · Use conformed cord with Type 245 IEC57.
- Install all electrical works in accordance to the standard.
- · Install the disconnect device with a contact gap of at least 3 mm in all poles nearby the units. (Both indoor unit and outdoor unit)

INSTALLATION PROCEDURE

INDOOR UNIT


№ WARNING amplify sound or vibration. If the installation location is not strong enough, the indoor unit may fall and cause injuries. ② If the job is done with the panel frame only, there

⚠ CAUTION

A. CEILING CONCEALED TYPE

· Install the filters to the unit.

take care.




This unit may also be installed with the air inlet facing down.

INSTALLATION

Install the air conditioner in a location which can withstand a load of at least five times the weight of the main unit and which will not


For installation, refer to the technical data.



See also 1 - B - 1 for such cases.

is a risk that the unit will come loose. Please

1. INSTALL THE FILTERS




Remove the 4 tapping screws, and then remove cover. Install the cover with the 4 tapping screws as shown in the

B. FLOOR STANDING CONCEALED


TYPE

1. INSTALL THE FILTERS


Install the filters to the unit referring to 1 - A -1




2. INSTALLING THE HANGERS Install the hangers to the unit (4 places).



3. DRILLING HOLES FOR BOLTS AND IN-STALLING THE BOLTS Drilling position for bolts.



CAUTION Secure with an M10 anchor bolts. If securing the unit to the floor is difficult, first build a stand or



↑ CAUTION

Fasten the unit securely with special nuts A and B

2. DRILLING HOLES FOR BOLTS AND IN-

Using the installation template, drill holes for bolts (4 holes).

Installation template

Fasten the hanging bolts to the ceiling and install special nuts

M10 Hanging bolt


Special nut A

STALLING THE BOLTS


3. INSTALLING THE HANGERS

Install the hangers to the unit (4 places).

4. INSTALL THE UNIT Fix the unit.



5. LEVELING Base horizontal and vertical direction leveling on top of the unit.



A CAUTION

X Bad

In order to prevent water from leaking around the outlet port, make sure to insulate it (on both the CEILING CONCEALED type and the FLOOR STANDING CONCEALED type).

NOTE: INSTALLING DRAIN HOSE

O Good

CAUTION Install the drain hose in accordance with the in-

structions in this installation instruction sheet and keep the area warm enough to prevent condensation. Problems with the piping may lead to water

INSTALL THE DRAIN HOSE

4. LEVELING

O Good

O Good

5. SERVICE HOLE DIMENSIONS

Open a service hole with the dimensions shown

6. INTAKE DUCT CONNECTION Follow the procedure in the following figure to the ducts.

× Bad

Control box


Base horizontal direction leveling on top of the unit.

 Install the drain hose with downward gradient (1/50 to 2/50) and so there are no rises or traps in the hose. · Use general hard polyvinyl chloride pipe and connect it with


The air inlet duct can be changed by replacing the intake cover.

- adhesive (polyvinyl chloride) so that there is no leakage.
- When the hose is long, install supporters. · Do not perform air bleeding.
- Always heat insulate the indoor side of the drain hose.

A. CEILING CONCEALED TYPE



1.5 to 2 m (5 to 6.5 ft)




⚠ CAUTION

cover can be removed for servicing In order to prevent water from leaking into the control box, make sure that the drain hose is well insulated.

Install the drain hose so that the control box

After the wiring is connected and installation of the piping and drain hose is complete, make a seal around the opening in the wall.

The outside diameter of drain port is 26 mm, use a suitable drain hose.



CONNECTING THE

PIPE

⚠ CAUTION

Do not use mineral oil on flared part. Prevent mineral oil from getting into the system as this would reduce the lifetime of the units.

↑ CAUTION

When air is taken in from the bottom side, the

operating sound of the product will easily enter

Install the product and intake grilles where the

A CAUTION

1) If an intake duct is installed, take care not to

2 Be sure to install the air inlet grille and the

▼ Air Outlet Grille Air Inlet Grille

3 Grills must be fixed so that man cannot touch

4) Be sure to install the air filter in the air inlet. If the air filter is not installed, the heat exchanger

may be clogged and its performance may

hand operation without tool.

decrease.

indoor unit fan, and cannot be removed by only

air outlet grille for air circulation. The correct

affect of the operating sound is small.

damage the temperature sensor.

temperature cannot be detected.

While welding the pipes, be sure to blow dry nitrogen gas through them.

1. FLARING

(1) Cut the connection pipe to the necessary length with a pipe


(2) Hold the pipe downward so that cuttings will not enter the pipe and remove the burrs. (3) Insert the flare nut (always use the flare nut attached to the

indoor and outdoor units respectively) onto the pipe and perform the flare processing with a flare tool. Use the special R410A flare tool, or the conventional flare

9.52 mm (3/8 in.)

12.70 mm (1/2 in.)

12.70 mm (1/2 in.)



0 to 0.5

Dimension B $_{-0.4}^{0}$ (mm)
9.1
13.2

When using conventional flare tools to flare R410A pipes, the dimension A should be approximately 0.5 mm more than indicated in the table (for flaring with R410A flare tools) to achieve the specified flaring. Use a thickness gauge to measure the

Pipe outside


Width across flats

diameter of Flare nut 6.35 mm (1/4 in) 17 mm 9.52 mm (3/8 in.) 22 mm 12.70 mm (1/2 in.) 26 mm

Width across flats

(Continued to the next page.)

9374815043_B2.indd 1 1/11/07 2:16:49 PM



Do not bend the pipes in an angle more than 90° When pipes are repeatedly bent or stretched, the material will harden, making it difficult to bend or stretch them any more. Do not bend or stretch the pipes more than three times.

When bending the pipe, do not bend it as is. The pipe will be Heat insulating collapsed. In this case, cut the Pipe heat insulating pipe with a sharp Cutter ___ cutter as shown on the right, and bend it after exposing the pipe. After bending the pipe as you want, be sure to put the heat insulating pipe back on the pipe, and secure it with tape.

⚠ CAUTION

1 To prevent breaking of the pipe, avoid sharp bends Bend the pipe with a radius of curvature of 150 mm or over.

If the pipe is bent repeatedly at the same place, it will break.

3. CONNECTION PIPES

Indoor unit (1) Detach the caps and plugs from the pipes.

⚠ CAUTION


Be sure to apply the pipe against the port on the indoor unit correctly. If the centering is improper, the flare nut cannot be tightened smoothly. If the flare nut is forced to turn, the threads will be damaged.

2 Do not remove the flare nut from the indoor unit pipe until immediately before connecting the connection pipe.

(2) Centering the pipe against port on the indoor unit, turn the flare nut with your hand.



(3) When the flare nut is tightened properly by your hand, use a torque wrench to finally tighten it.



⚠ CAUTION Hold the torque wrench at its grip, keeping it in the right angle with the pipe, in order to tighten the flare nut correctly.

Tightening torque
14 to 18 N·m (140 to 180 kgf·cm)
33 to 42 N·m (330 to 420 kgf·cm)
50 to 62 N·m (500 to 620 kgf·cm)


A CAUTION


Be sure to connect the large pipe after connecting the small pipe completely.

· Lay the piping.

A. CEILING CONCEALED TYPE

Control box cover






↑ CAUTION Install the piping so that the control box cover can be removed for servicing.

2 In order to prevent water from leaking into the control box, make sure that the piping is well

INSTALLING THE 3 **COUPLER HEAT INSULATION**

After checking for gas leaks, insulate by wrapping insulation around the two parts (gas and liquid) of the indoor unit coupling, using the coupler heat insulation After installing the coupler heat insulation, wrap both ends with



⚠ CAUTION

Must fit tightly against body without any gap.

ELECTRICAL WIRING

HOW TO CONNECT WIRING TO THE TERMINALS

A. For solid core wiring

Cut the wire end with a wire cutter or wire-cutting pliers. then strip the insulation to about 25 mm (15/16") of expose the solid wire. 2) Using a screwdriver, remove the terminal screw(s) on the


terminal board. Using pliers, bend the solid wire to form a loop suitable for the terminal screw. Shape the loop wire properly, place it on the terminal board and tighten securely with the terminal screw using

a screwdriver. B. For strand wiring


Cut the wire end with a wire cutter or wire-cutting pliers, then strip the insulation to about 10 mm (3/8") of expose the strand wiring.

2) Using a screwdriver, remove the terminal screw(s) on the terminal board. Using a round terminal fastener or pliers, securely clamp


a round terminal to each stripped wire end. Position the round terminal wire, and replace and tighten the terminal screw using a screwdriver.



1. CONNECTION DIAGRAMS



2. CONNECTION CORD PREPARATION Keep the earth wire longer than the other wires.



3. CONNECTION OF WIRING

⚠ WARNING Before starting work, check that power is not being supplied to the indoor unit and outdoor

2 Match the terminal board numbers and connection cord colors with those of the outdoor Erroneous wiring may cause burning of the

3 Connect the connection cords firmly to the terminal board. Imperfect installation may cause


4 Always fasten the outside covering of the connection cord with the cord clamp. (If the insulator is chafed, electric leakage may occur.)

5 Always connect the ground wire.


electric parts.

6 Install the remote controller wires so as not to be direct touched with your hand.

(1) Remove the control box cover and install each connection



(2) After wiring is complete, secure the remote controller cord connection cord, and power cord with the cord clamps.



A CAUTION

Tighten the indoor unit connection cord (to the outdoor unit) and power supply indoor and outdoor unit terminal board connections firmly with the terminal board screws. Faulty connection may cause a fire.

If the indoor unit connection cord (to the outdoor unit) and power supply are wired incorrectly, the air conditioner may be damaged.

Wire the indoor unit connection cord (to the outdoor unit) by matching the numbers of the outdoor and indoor units terminal board numbers as shown in terminal label.

Ground both the indoor and outdoor units by attaching a ground wire.

Unit shall be grounded in compliance with the applicable local and national codes.

FUNCTION SETTING

Follow the instructions in the Local Setup Procedure, which is supplied with the remote control, in accordance with the installed condition. After the power is turned on, perform the Function

Setting on the remote control. The settings may be selected between the following two: Func-

tion Number or Setting Value. Settings will not be changed if invalid numbers or setting values

Setting the Static Pressure

are selected.

Setting Description	Function Number	Setting Value
Normal	21	00
High static pressure 1		01
High static pressure 2		02
High static pressure 3		03

Determine the wind volume in each mode i.e., applicable range of static pressure, refering to [7] STATIC PRESSURE CHARACTERISTICS. (The unit is factory-set to "00".)

Setting the Cooler Room Temperature Correction Depending on the installed environment, the room temperature

sensor may require a correction. The settings may be selected as shown in the table below. (The unit is factory-set to "00".)

Setting Description	Function Number	Setting Valu
Standard	30	00
Lower control		01

Setting the Heater Room Temperature Correction Depending on the installed environment, the room temperature

sensor may require a correction. The settings may be changed as shown in the table below. (The unit is factory-set to "00".)

Setting Description	Function Number	Setting Value	
Standard		00	
Lower control	31	01	
Slightly warmer control		02	
Warmer control		03	

Setting Other Functions

The following settings are also possible, depending on the operating conditions. (The unit is factory-set to "00".)

Auto Restart

tting Description	Function Number	Setting Value	
Yes	40	00	
No	40	01	

Indoor Room Temperature Sensor Switching Function (Wired remote controller only)

etting Description	Function Number	Setting Value
No	42	00
Yes	42	01

· If setting value is "00", room temperature is controlled by the

indoor unit temperature sensor.

If setting value is "01", room temperature is controlled by either

[When using the wireless remote controller]

SWITCHING REMOTE CONTROL UNIT

Confirm the setting of the remote control unit signal code and

used to operate for the air conditioner.

Jumper wire		Remote control unit
JM1	JM2	signal code
Connect	Connect	A (Primary setting)
Disconnect	Connect	b
Connect	Disconnect	С
Disconnect	Disconnect	d

Setting	Setting Value
Static pressure	
Cooler room temperature correction	
Heater room temperature correction	
Auto restart	
Indoor room temperature sensor switching function	

the power and turn it on again.

TEST RUN

CHECK ITEMS

(1) Is operation of each button on the remote control unit nor-

(2) Does each lamp light normally?

(3) Do not air flow direction louvers operate normally? (4) Is the drain normal?

(5) Is there any abnormal noise and vibration during operation? • Do not operate the air conditioner in the running state for a

[Using the wireless remote control]

For the operation method, refer to the operating manual. The outdoor unit may not operate, depending on the room temperature. In this case, press the test run button on the remote control unit while the air conditioner is running. (the transmitter section of the remote control unit towar air conditioner and press the test run button with the ti ball-point pen, etc.)



STOP button.

(2) Press the master control button and the fan control button

simultaneously for 2 seconds or more to start the test run.


9374815043_B2.indd 2



(3) Press the start/stop button to stop the test run.

[Troubleshooting at the remote control LCD]

("EE" will appear in the set room temperature display.)



(Point ard the	26 27	indoor signal error
ip of a	00	Wired remote conf
	02	Indoor room tempe
	04	Indoor heat excha (middle) error
	28	Indoor heat excha (inlet) error
	09	Float switch opera
	0C	Outdoor discharge error
	06	Outdoor heat exch (outlet) error
TART/	0A	Outdoor temperate

2c

16

2b


To end test operation, press the remote control unit START/ (When the air conditioner is run by pressing the test run button, the OPERATION indicator lamp and TIMER indicator lamp will simultaneously flash slowly.) [Using the wired remote control]

For the operation method, refer to the operating manual. (1) Stop the air conditioner operation.



PFC circuit error


If an error occurs, the following display will be shown.



13 26 27	Indoor signal error
00	Wired remote controller abnormal
02	Indoor room temperature sensor error
04	Indoor heat exchanger temperature sensor (middle) error
28	Indoor heat exchanger temperature sensor (inlet) error
09	Float switch operated
0C	Outdoor discharge pipe temperature sensor error
06	Outdoor heat exchanger temperature sensor (outlet) error
0A	Outdoor temperature sensor error
15	Compressor temperature sensor error
1d	2-way valve temperature sensor error
1E	3-way valve temperature sensor error
29	Outdoor heat exchanger temperature sensor (middle) error
20	Indoor manual auto switch abnormal
2A	Power supply frequency detection error
17	IPM protection
18	CT error
1A	Compressor location error
1b	Outdoor fan error
1F	Connected indoor unit abnormal
1c	Outdoor unit computer communication error
12	Indoor fan abnormal
0F	Discharge temperature error

This is possible only on the wired remote control.

[SELF-DIAGNOSIS]



Error contents

Exessive high pressure protection on cooling

If "CO" appears in the unit number display, there is a remote controller error. Refer to the installation instruction sheet included with the remote controller.

4-way valve abnormal

Active filter abnormal

Pressure switch abnormal

Compressor temperature error

STATIC PRESSURE CHARACTERISTIC

A CAUTION

If the applicable static pressure does not match the static pressure mode, the static pressure mode may be changed to another mode automatically.

RECOMMENDED RANGE OF EXTERNAL STATIC PRESSURE

0Pa to 90Pa

. STATIC PRESSURE MODE It is necessary to set up a static pressure mode for each usage of static pressure. Determine the applicable range of static pressure in each mode

and wind volume, referring to the TECHNICAL MANUAL.

2. MODE SETTING It is possible to change the setting of static pressure mode. Refer to [5] FUNCTION SETTING and to the INSTALLATION INSTRUC-TION SHEET of remote controller for a setting method.

SPECIAL INSTALLATION METHODS

⚠ CAUTION When setting DIP switches, do not touch any other parts on the circuit board directly with

② Be sure to turn off the main power.

GROUP CONTROL SYSTEM

your bare hands.

A number of indoor units can be operated at the same time using a single remote controller. (1) Wiring method (indoor unit to remote controller)

123 Remote

Remote controller wire (2) DIP switch setting (Indoor unit) Set the unit number of each indoor unit using DIP switch on the indoor unit circuit board. (See following table and figure.)

DIP switch is normally set to make unit number No. 0.

Indoor unit Unit number OFF OFF OFF ON OFF OFF OFF ON OFF ON OFF OFF OFF ON OFF OFF ON OFF ON OFF ON ON OFF OFF ON ON ON OFF OFF OFF ON OFF OFF ON ON OFF OFF ON ON ON OFF ON ON 12 OFF OFF ON ON 13 ON OFF ON ON 14 OFF ON ON ON 15 ON ON ON ON

Example: No. 3

CUSTOMER GUIDANCE

Explain the following to the customer in accordance with the

(1) Starting and stopping method, operation switching, temperature adjustment, timer, air flow switching, and other remote

operating manual:

(3) Give the operating and installation manuals to the customer.

(2) Air filter removal and cleaning, and how to use the air

in the remote control unit are replaced). *(4) is applicable to using wireless remote control.

control unit operations.

change (the system returns to signal code A when the batteries

PART NO. 9374815043

indoor unit temperature sensor or remote control unit sensor.

SIGNAL CODES

the printed circuit board setting. If these are not confirmed, the remote control unit cannot be

r wire	Remote control unit
JM2	signal code
Connect	A (Primary setting)
Connect	b
Disconnect	С
Disconnect	d
	JM2 Connect Connect Disconnect

Record any changes to the settings in the following table.

Setting	Setting Value
Static pressure	
Cooler room temperature correction	
Heater room temperature correction	
Auto restart	
Indoor room temperature sensor switching function	

After completing the FUNCTION SETTING, be sure to turn off

1/11/07 2:17:00 PM

Duct Type SPLIT TYPE AIR CONDITIONER INSTALLATION **INSTRUCTION SHEET**

A CAUTION REFRIGERANT IIS PRODUCT MUST ONLY BE INSTALLED OR SERVICED

gulations, codes, installation & operation manuals, before a installation, maintenance and /or service of this product.

(PART NO. 9374815036)

Indoor unit is an appliance not accessible to the general public.

For authorized service personnel only.

⚠ DANGER	This mark indicates procedures which, if improperly performed, are most likely to result in the death of or serious injury to the user or service personnel.
⚠ WARNING	This mark indicates procedures which, if improperly performed, might lead to the death or serious injury of the user.
⚠ CAUTION	This mark indicates procedures which, if improperly performed, might possibly result in personal harm to the user, or damage to property.

⚠ DANGER

Never touch electrical components immediately after the power supply has been turned off. Electrical shock may occur. After turning off the power, always wait 5 minutes or more before touching electrical components.

This air conditioner uses new refrigerant HFC (R410A).

The basic installation work procedures are the same as conventional refrigerant models. However, pay careful attention to the following points:

Since the working pressure is 1.6 times higher than that of conventional refrigerant models, some of the piping and installation and service tools are special. (See the table below.) Especially, when replacing a conventional refrigerant model with a new refrigerant R410A model, always replace the conventional piping and flare nuts with the R410A piping and flare nuts.

Models that use refrigerant R410A have a different charging port thread diameter to prevent erroneous charging with conventional refrigerant and for safety. Therefore, check beforehand. The charging port thread diameter for R410A is 1/2 UNF 20 threads per inch.]

Be more careful that foreign matter (oil, water, etc.) does not enter the piping than with refrigerant models. Also, when storing the piping, securely seal the openings by pinching, taping, etc.

④ When charging the refrigerant, take into account the slight change in the composition of the gas and liquid phases, and always charge from the liquid phase side whose composition is stable.

Special tools for R410A

Tool name	Contents of change	
Gauge manifold	Pressure is high and cannot be measured with a conventional gauge. To prevent erroneous mixing of other refrigerants, the diameter of each port has been changed. It is recommended the gauge with seals –0.1 to 5.3 MPa (–76 cmHg to 53 kgf/cm²) for high pressure. –0.1 to 3.8 MPa (–76 cmHg to 38 kgf/cm²) for low pressure.	
Charge hose	To increase pressure resistance, the hose material and base size were changed.	
Vacuum pump	A conventional vacuum pump can be used by installing a vacuum pump adapter.	
Gas leakage detector	Special gas leakage detector for HFC refrigerant R410A.	

It is necessary to use seamless copper pipes and it is desirable that the amount of residual oil is less than 40 mg/10m. Do not use coppe having a collapsed, deformed or discolored portion (especially on the surface). Otherwise, the expansion valve or capillary tube may blocked with contaminants.

As an air conditioner using R410A incurs pressure higher than whe conventional refrigerant, it is necessary to choose adequate mater Thicknesses of copper pipes used with R410A are as shown in th Never use copper pipes thinner than that in the table even when it is available on the market

tnat tne er pipes	Pipe outside diameter
e interior become	6.35 mm (1/4 in.)
Decome	9.52 mm (3/8 in)
en using erials.	12.70 mm (1/2 in.)
ne table.	15.88 mm (5/8 in)

Thicknesses of Annealed Copper Pipes (R410A)

Thickness
0.80 mm
0.80 mm
0.80 mm
1.00 mm

For authorized service personnel only.

! WARNING

For the room air conditioner to operate satisfactorily, install it as outlined in this installation instruction

2 Connect the indoor unit and outdoor unit with the room air conditioner piping and cords available standards parts. This installation instruction sheet describes the correct connections using the installation set available from our standard parts.

3) Installation work must be performed in accordance with national wiring standards by authorized personne

4 If refrigerant leaks while work is being carried out, ventilate the area. If the refrigerant comes in contact with a flame, it produces a toxic gas.

5 Do not use an extension cord.

6 Do not turn on the power until all installation work is complete.

CAUTION

This installation instruction sheet describes how to install the indoor unit only. To install the outdoor unit, refer to the installation instruction sheet included with the outdoor unit.

· Be careful not to scratch the room air conditioner when handling it. · After installation, explain correct operation to the customer, using the operating manual.

• Let the customer keep this installation instruction sheet because it is used when the air conditioner is serviced or

SELECTING THE MOUNTING POSITION

↑ WARNING

Install at a place that can withstand the weight of the indoor and outdoor units and install positively so that the units will not topple or fall.

CAUTION

1) Do not install where there is the danger of combustible gas leakage

② Do not install near heat sources.

③ If children under 10 years old may approach the unit, take preventive measures so that they cannot reach the unit.

4 Take precautions to prevent the unit from falling.

Decide the mounting position with the customer as follows:

(1) Install the indoor unit level on a strong wall, floor, ceiling which is not subject to vibration.

(2) The inlet and outlet ports should not be obstructed: the air should be able to blow all over the room.

(3) Install the unit near an electric outlet or special branch circuit.

(4) Install the unit where connection to the outdoor unit is easy.

(5) Install the unit where the drain pipe can be easily installed.

shown on the right. Also install the unit where the filter can be

(7) Install the indoor unit where vibrations and noise are not ampli-

(6) Take servicing, etc. into consideration and leave the spaces

(8) When installing the unit on the floor, provide an opening that will allow sufficient air to reach the air inlet panel.

Strong and durable ceiling 10 cm (4") or more Strong and durable floor 10 cm (4") or more 30 cm (1') or more

STANDARD PARTS

INDOOR UNIT ACCESSORIES

Special nut B

(small flange)

Name and Shape	Q'ty	Application
Installation template	1	For positioning the indoor unit
Hanger	4	For suspending the indoor unit from ceiling
Tapping screw (ø4 × 10)	8	For installing the hanger
Special nut A (large flange)	4	For suspending the indoor unit from ceiling

Name and Shape Q'ty Application For indoor side pipe joint heat insulation (large pipe) (large) For indoor side pipe joint Coupler heat insulation (small pipe) (small) For fixing the coupler heat Binder 9000 BTU/h model 12000 - 22000 BTU/h Drain hose insulation Insulates the drain hose and vinyl hose connection

CONNECTING PIPE REQUIREMENT

A CAUTION

Refer to the installation instruction sheet of the outdoor unit for description of the length of connecting pipe or for difference of its elevation

Diameter	Small	6.35 mm (1/4 in.)
	Large	12.70 mm (1/2 in.)

· Use pipe with water-resistant heat insulation.

CAUTION

Install heat insulation around both the gas and liquid pipes. Failure to do so may cause water leaks.

Use heat insulation with heat resistance above 120 °C. (Reverse cycle model only) In addition, if the humidity level at the installation location of the refrigerant piping is expected to exceed 70%,

install heat insulation around the refrigerant piping. If the expected humidity level is 70-80%, use heat insulation that is 15 mm or thicker and if the expected humidity exceeds 80%, use heat insulation that is 20 mm or thicker. If heat insulation is used that is not as thick as specified, condensation may form on the surface of the insulation. In addition, use heat insulation with heat conductivity of 0.045 W/(m·K) or less (at 20 °C).

ELECTRICAL REQUIREMENT

Connection	cord (mm²)
MAX.	MIN.
2.5	1.5

· Use conformed cord with Type 245 IEC57.

Install all electrical works in accordance to the standard

· Install the disconnect device with a contact gap of at least 3 mm in all poles nearby the units. (Both indoor unit and outdoor unit)


INSTALLATION PROCEDURE


INDOOR UNIT

№ WARNING Install the air conditioner in a location which can withstand a load of at least five times the weight of the main unit and which will not amplify sound or vibration. If the installation location is not strong enough, the indoor unit may fall and cause injuries.

take care. **⚠** CAUTION

1. INSTALL THE FILTERS





See also 1 - B - 1 for such cases.

INSTALLATION


If the job is done with the panel frame only, there


is a risk that the unit will come loose. Please

For installation, refer to the technical data.

A. CEILING CONCEALED TYPE


· Install the filters to the unit.






This unit may also be installed with the air inlet facing down.


2. DRILLING HOLES FOR BOLTS AND IN-**STALLING THE BOLTS** Using the installation template, drill holes for bolts (4 holes).



3. INSTALLING THE HANGERS Fasten the hanging bolts to the ceiling and install special nuts




Install the hangers to the unit (4 places).




4. LEVELING

Base horizontal direction leveling on top of the unit.




5. SERVICE HOLE DIMENSIONS Open a service hole with the dimensions shown


O OK



6. INTAKE DUCT CONNECTION Follow the procedure in the following figure to the ducts.



and flange.



For the bottom air intake, follow the procedure of \bigcirc \rightarrow \bigcirc for (The factory setting is back air intake.)



CAUTION


When air is taken in from the bottom side, the operating sound of the product will easily enter the room. Install the product and intake grilles where the

affect of the operating sound is small.

↑ CAUTION

1) If an intake duct is installed, take care not to damage the temperature sensor (the temperature sensor is attached to the intake port

2 Be sure to install the air inlet grille and the air outlet grille for air circulation. The correct temperature cannot be detected.



3 Grills must be fixed so that man cannot touch indoor unit fan, and cannot be removed by only hand operation without tool

4) Be sure to install the air filter in the air inlet. If the air filter is not installed, the heat exchanger may be clogged and its performance may

CONNECTING THE PIPE

A CAUTION

Do not use mineral oil on flared part. Prevent mineral oil from getting into the system as this would reduce the lifetime of the units.

While welding the pipes, be sure to blow dry nitrogen gas through them.

1. FLARING

(1) Cut the connection pipe to the necessary length with a pipe

(2) Hold the pipe downward so that cuttings will not enter the pipe and remove the burrs.

(3) Insert the flare nut (always use the flare nut attached to the indoor and outdoor units respectively) onto the pipe and perform the flare processing with a flare tool. Use the special R410A flare tool, or the conventional flare



Dimension A (mm) Flare tool for R410A, clutch 6.35 mm (1/4 in.) 9.52 mm (3/8 in.) 0 to 0.5 12.70 mm (1/2 in.)

Pipe outside diameter	Dimension B $_{-0.4}^{0}$ (mm)
6.35 mm (1/4 in.)	9.1
9.52 mm (3/8 in.)	13.2
12.70 mm (1/2 in.)	16.6

When using conventional flare tools to flare R410A pipes, the dimension A should be approximately 0.5 mm more than indicated in the table (for flaring with R410A flare tools) to achieve the specified flaring. Use a thickness gauge to measure the

Pipe outside


Width across flats

diameter of Flare nut 6.35 mm (1/4 in) 17 mm 9.52 mm (3/8 in.) 22 mm 12.70 mm (1/2 in.) 26 mm


(Continued to the next page.)

B. FLOOR STANDING CONCEALED TYPE


1. INSTALL THE FILTERS Remove the 4 tapping screws, and then remove cover.




Install the filters to the unit referring to 1 - A -1




2. INSTALLING THE HANGERS



3. DRILLING HOLES FOR BOLTS AND IN-STALLING THE BOLTS Drilling position for bolts.




CAUTION Secure with an M10 anchor bolts. If securing the unit to the floor is difficult, first build a stand or




↑ CAUTION

Fasten the unit securely with special nuts A and B

4. INSTALL THE UNIT Fix the unit. Install the unit and fasten with special nut B.




5. LEVELING Base horizontal and vertical direction leveling on top of the unit.




In order to prevent water from leaking around

NOTE: INSTALLING DRAIN HOSE

INSTALL THE DRAIN HOSE







CAUTION

Install the drain hose with downward gradient (1/50 to 2/50)


and so there are no rises or traps in the hose. · Use general hard polyvinyl chloride pipe and connect it with adhesive (polyvinyl chloride) so that there is no leakage.


 When the hose is long, install supporters. · Do not perform air bleeding. • Always heat insulate the indoor side of the drain hose.





Install the drain hose in accordance with the instructions in this installation instruction sheet and keep the area warm enough to prevent condensation. Problems with the piping may lead to water






the outlet port, make sure to insulate it (on both the CEILING CONCEALED type and the FLOOR STANDING CONCEALED type).

CAUTION

 \times NO

1.5 to 2 m (5 to 6.5 ft)

B. FLOOR STANDING CONCEALED TYPE



Install the drain hose so that the control box cover can be removed for servicing In order to prevent water from leaking into the

well insulated.

drain hose.

⚠ CAUTION

control box, make sure that the drain hose is

After the wiring is connected and installation of the piping and drain hose is complete, make a seal around the opening in the wall.


The outside diameter of drain port is 26 mm, use a suitable

Drain hose insulatio

8/22/06 9:27:32 AM


Width across flats

9374815036_B2front.indd 1



Do not bend the pipes in an angle more than 90°. When pipes are repeatedly bent or stretched, the material will harden, making it difficult to bend or stretch them any more. Do not bend or stretch the pipes more than three times.

When bending the pipe, do not bend it as is. The pipe will be Heat insulating collapsed. In this case, cut the Pipe heat insulating pipe with a sharp Cutter cutter as shown on the right, and bend it after exposing the pipe. After bending the pipe as you want, be sure to put the heat insulating pipe back on the pipe, and secure it with tape



CAUTION

1 To prevent breaking of the pipe, avoid sharp Bend the pipe with a radius of curvature of 150 mm or over.

2) If the pipe is bent repeatedly at the same place, it will break.

3. CONNECTION PIPES

Indoor unit (1) Detach the caps and plugs from the pipes.

A CAUTION


Be sure to apply the pipe against the port on the indoor unit correctly. If the centering is improper, the flare nut cannot be tightened smoothly. If the flare nut is forced to turn, the threads will be damaged.

2 Do not remove the flare nut from the indoor unit pipe until immediately before connecting the connection pipe.

(2) Centering the pipe against port on the indoor unit, turn the flare nut with your hand.



(3) When the flare nut is tightened properly by your hand, use a torque wrench to finally tighten it.



A CAUTION Hold the torque wrench at its grip, keeping it in the right angle with the pipe, in order to tighten the flare nut correctly.


Flare nut	Tightening torque
6.35 mm (1/4 in.) dia.	14 to 18 N·m (140 to 180 kgf·cm)
12.70 mm (1/2 in.) dia.	50 to 62 N·m (500 to 620 kgf·cm)

A CAUTION

Be sure to connect the large pipe after connecting the small pipe completely.

· Lay the piping.

A. CEILING CONCEALED TYPE




⚠ CAUTION

Install the piping so that the control box cover can be removed for servicing.

2 In order to prevent water from leaking into the control box, make sure that the piping is well

3 **INSTALLING THE COUPLER HEAT INSULATION**

After checking for gas leaks, insulate by wrapping insulation around the two parts (gas and liquid) of the indoor unit coupling, using the coupler heat insulation After installing the coupler heat insulation, wrap both ends with vinyl tape so that there is no gap.



⚠ CAUTION

Must fit tightly against body without any gap.

ELECTRICAL WIRING

HOW TO CONNECT WIRING TO THE TERMINALS

A. For solid core wiring

- Cut the wire end with a wire cutter or wire-cutting pliers. then strip the insulation to about 25 mm (15/16") of expose the solid wire. 2) Using a screwdriver, remove the terminal screw(s) on the
- terminal board. Using pliers, bend the solid wire to form a loop suitable for the terminal screw.
- Shape the loop wire properly, place it on the terminal board and tighten securely with the terminal screw using


B. For strand wiring

a screwdriver.


Cut the wire end with a wire cutter or wire-cutting pliers, then strip the insulation to about 10 mm (3/8") of expose the strand wiring.

2) Using a screwdriver, remove the terminal screw(s) on the terminal board.


Using a round terminal fastener or pliers, securely clamp a round terminal to each stripped wire end. Position the round terminal wire, and replace and tighten the terminal screw using a screwdriver.



1. CONNECTION DIAGRAMS



2. CONNECTION CORD PREPARATION Keep the earth wire longer than the other wires.





3. CONNECTION OF WIRING

⚠ WARNING Before starting work, check that power is not being supplied to the indoor unit and outdoor

- 2 Match the terminal board numbers and connection cord colors with those of the outdoor Erroneous wiring may cause burning of the
- electric parts. 3 Connect the connection cords firmly to the terminal board. Imperfect installation may cause
- 4 Always fasten the outside covering of the con-
- nection cord with the cord clamp. (If the insulator is chafed, electric leakage may occur.)
- 5 Always connect the ground wire.
- 6 Install the remote controller wires so as not to be direct touched with your hand.

(1) Remove the control box cover and install each connection





CAUTION

Tighten the indoor unit connection cord (to the outdoor unit) and power supply indoor and outdoor unit terminal board connections firmly with the terminal board screws. Faulty connection may cause a fire.

- If the indoor unit connection cord (to the outdoor unit) and power supply are wired incorrectly, the air conditioner may be damaged.
- Wire the indoor unit connection cord (to the outdoor unit) by matching the numbers of the outdoor and indoor units terminal board numbers as shown in terminal label.
- Ground both the indoor and outdoor units by attaching a ground wire.
- Unit shall be grounded in compliance with the applicable local and national codes.

FUNCTION SETTING

- Follow the instructions in the Local Setup Procedure, which is supplied with the remote control, in accordance with the installed condition. After the power is turned on, perform the Function
- Setting on the remote control.
- Settings will not be changed if invalid numbers or setting values are selected.

Setting Description	Function Number	Setting Value
Normal		00
High static pressure 1	21	01
High static pressure 2	21	02
High static pressure 3		03

Determine the wind volume in each mode i.e., applicable range of static pressure, refering to [7] STATIC PRESSURE CHARACTERISTICS. (The unit is factory-set to "00")

Setting the Cooler Room Temperature Correction as shown in the table below. (The unit is factory-set to "00".)

Setting Description	Function Number	Setting Valu
Standard	30	00
Lower control	30	01

sensor may require a correction. The settings may be changed as shown in the table below. (The unit is factory-set to "00".)

Setting Description	Function Number	Setting Value
Standard		00
Lower control	31	01
Slightly warmer control	31	02
Warmer control		03

tting Description	Function Number	Setting Value	
Yes	40	00	
No	40	01	

Indoor Room Temperature Sensor Switching Function (Wired

Setting Description	Function Number	Setting Value
No	42	00
Yes	42	01

- perature is controlled by either indoor unit temperature sensor or remote control unit sensor.

[When using the wireless remote controller]

SIGNAL CODES

If these are not confirmed, the remote control unit cannot be used to operate for the air conditioner.

Jumper wire		Remote control unit	
JM1	JM2	signal code	
Connect	Connect	A (Primary setting)	
Disconnect	Connect	b	
Connect	Disconnect	С	
Disconnect	Disconnect	Ь	

· Record any changes to the settings in the following table.

Setting	Setting Value
Static pressure	
Cooler room temperature correction	
Heater room temperature correction	
Auto restart	
Indoor room temperature sensor switching function	

the power and turn it on again.

TEST RUN

CHECK ITEMS

(1) Is operation of each button on the remote control unit nor-

(2) Does each lamp light normally?

(3) Do not air flow direction louvers operate normally? (4) Is the drain normal?

(5) Is there any abnormal noise and vibration during operation? • Do not operate the air conditioner in the running state for a

[Using the wireless remote control]

For the operation method, refer to the operating manual. The outdoor unit may not operate, depending on the room temperature. In this case, press the test run button on the remote control unit while the air conditioner is running. (Point the transmitter section of the remote control unit toward the air conditioner and press the test run button with the tip of a ball-point pen, etc.)



To end test operation, press the remote control unit START/ STOP button. (When the air conditioner is run by pressing the test run button, the OPERATION indicator lamp and TIMER indicator lamp will

(2) Press the master control button and the fan control button

[Using the wired remote control]

For the operation method, refer to the operating manual. (1) Stop the air conditioner operation.

simultaneously flash slowly.)

simultaneously for 2 seconds or more to start the test run.

9374815036_B2back.indd 1




(3) Press the start/stop button to stop the test run.

[Troubleshooting at the remote control LCD]

Error code

If an error occurs, the following display will be shown.



	Ellol code	Endicontents	
	01 13 26 27	Indoor signal error	
	00	Wired remote controller abnormal	
	02	Indoor room temperature sensor error	
04 Indoor heat exc (middle) error		Indoor heat exchanger temperature sensor (middle) error	
	28	Indoor heat exchanger temperature sensor (inlet) error	
	09	Float switch operated	
	0C	Outdoor discharge pipe temperature sensor error	
	06	Outdoor heat exchanger temperature sensor (outlet) error	
	0A	Outdoor temperature sensor error	
15 1d		Compressor temperature sensor error	
		2-way valve temperature sensor error	
	1E	3-way valve temperature sensor error	
	29	Outdoor heat exchanger temperature sensor (middle) error	
	20	Indoor manual auto switch abnormal	
2A		Power supply frequency detection error	
	17	IPM protection	
	18	CT error	
	1A	Compressor location error	
	1b	Outdoor fan error	
	1F	Connected indoor unit abnormal	
	1c	Outdoor unit computer communication error	
	12	Indoor fan abnormal	
	0F	Discharge temperature error	
	24	Exessive high pressure protection on cooling	
	2c	4-way valve abnormal	
	16	Pressure switch abnormal	
I	-	_	

This is possible only on the wired remote control.

[SELF-DIAGNOSIS]

("EE" will appear in the set room temperature display.)

EE THER SA
EX. Self-diagnosis
Error contents
nal error
ote controller abnormal
m temperature sensor error
t exchanger temperature sensor ror
t exchanger temperature sensor

PFC circuit error If "CO" appears in the unit number display, there is a remote controller error. Refer to the installation instruction sheet included with the remote controller.

Compressor temperature error


Active filter abnormal

STATIC PRESSURE CHARACTERISTIC

⚠ CAUTION If the applicable static pressure does not match the static pressure mode, the static pressure mode may be changed to another mode automatically.

RECOMMENDED RANGE OF EXTERNAL STATIC PRESSURE 0Pa to 90Pa

1. FAN PERFORMANCE AND AIR FLOW **EXTERNAL STATIC PRESSURE**



2. AIR FLOW SETTING The air flow is set according to the FUNCTION settings in the following tables.

Mode	Setting condition	Static pressure range
1	Normal	0 ≦ P ≦ 8
2	High static pressure 1	13 ≦ P ≦ 31
3	High static pressure 2	44 ≦ P ≦ 62
4	High static pressure 3	76 ≦ P ≦ 90


SPECIAL INSTALLATION METHODS

⚠ CAUTION When setting DIP switches, do not touch any other parts on the circuit board directly with

your bare hands. 2 Be sure to turn off the main power.

GROUP CONTROL SYSTEM

A number of indoor units can be operated at the same time using a single remote controller.




Remote controller wire (2) DIP switch setting (Indoor unit) Set the unit number of each indoor unit using DIP switch on the indoor unit circuit board. (See following table and figure.) DIP switch is normally set to make unit number No. 0.

Indoor unit Unit number 1 2 3 4

0	OFF	OFF	OFF	OFF
1	ON	OFF	OFF	OFF
2	OFF	ON	OFF	OFF
3	ON	ON	OFF	OFF
4	OFF	OFF	ON	OFF
5	ON	OFF	ON	OFF
6	OFF	ON	ON	OFF
7	ON	ON	ON	OFF
8	OFF	OFF	OFF	ON
9	ON	OFF	OFF	ON
10	OFF	ON	OFF	ON
11	ON	ON	OFF	ON
12	OFF	OFF	ON	ON
13	ON	OFF	ON	ON
14	OFF	ON	ON	ON
15	ON	ON	ON	ON

Example: No. 3



CUSTOMER GUIDANCE

Explain the following to the customer in accordance with the

(1) Starting and stopping method, operation switching, temperature adjustment, timer, air flow switching, and other remote

(3) Give the operating and installation manuals to the customer.

(2) Air filter removal and cleaning, and how to use the air

operating manual:


control unit operations.


in the remote control unit are replaced).

change (the system returns to signal code A when the batteries

*(4) is applicable to using wireless remote control.

PART NO. 9374815036





(2) After wiring is complete, secure the remote controller cord connection cord, and power cord with the cord clamps.

The settings may be selected between the following two: Function Number or Setting Value.

Setting the Static Pressure

ting Description	Function Number	Setting Value			No Yes	4
nal		00		ı	 If setting value is "00", room te indoor unit temperature sensor If setting value is "01", room tem 	
static pressure 1	21	01		•		
static pressure 2		02				
	1		1 1		in country value to or , is	oom tompe

Depending on the installed environment, the room temperature sensor may require a correction. The settings may be selected

Setting Description	Function Number	Setting Value
Standard	30	00
Lower control	30	01

Setting the Heater Room Temperature Correction Depending on the installed environment, the room temperature

Setting Description	Function Number	Setting Value
Standard		00
Lower control	31	01
Slightly warmer control	ال	02
\\/		00

Setting Other Functions

· The following settings are also possible, depending on the operating conditions. (The unit is factory-set to "00".)

	Auto Restart		
	Setting Description	Function Number	Setting Value
1			22

emote controller only)				
Setting Description	Function Number	Setting Value		
No	40	00		
Voo	42	01		

- mperature is controlled by the

SWITCHING REMOTE CONTROL UNIT

Confirm the setting of the remote control unit signal code and the printed circuit board setting.

Jumper wire		Remote control unit
JM1	JM2	signal code
Connect	Connect	A (Primary setting)
Disconnect	Connect	b
Connect	Disconnect	С

Setting Record

Setting	Setting Value
Static pressure	
Cooler room temperature correction	
Heater room temperature correction	
Auto restart	
Indoor room temperature sensor switching function	
<u> </u>	

After completing the FUNCTION SETTING, be sure to turn off

8/23/06 4:41:10 PM

Duct Type SPLIT TYPE AIR CONDITIONER INSTALLATION **INSTRUCTION SHEET**

ACAUTION R410A REFRIGERANT IIS PRODUCT MUST ONLY BE INSTALLED OR SERVICED

gulations, codes, installation & operation manuals, before a installation, maintenance and /or service of this product. (PART NO. 9374318148)

Indoor unit is an appliance not accessible to the general public.

For authorized service personnel only.

⚠ DANGER	This mark indicates procedures which, if improperly performed, are most likely to result in the death of or serious injury to the user or service personnel.
⚠ WARNING	This mark indicates procedures which, if improperly performed, might lead to the death or serious injury of the user.
⚠ CAUTION	This mark indicates procedures which, if improperly performed, might possibly result in personal harm to the user, or damage to property.

⚠ DANGER

Never touch electrical components immediately after the power supply has been turned off. Electrical shock may occur. After turning off the power, always wait 5 minutes or more before touching electrical components.

This air conditioner uses new refrigerant HFC (R410A). The basic installation work procedures are the same as conventional refrigerant models.

However, pay careful attention to the following points:

- Since the working pressure is 1.6 times higher than that of conventional refrigerant models, some of the piping and installation and service tools are special. (See the table below.) Especially, when replacing a conventional refrigerant model with a new refrigerant R410A model, always replace the conventional piping and flare nuts with the R410A piping and flare nuts.
- Models that use refrigerant R410A have a different charging port thread diameter to prevent erroneous charging with conventional refrigerant and for safety. Therefore, check beforehand. The charging port thread diameter for R410A is 1/2 UNF 20 threads per inch.]
- Also, when storing the piping, securely seal the openings by pinching, taping, etc. 4) When charging the refrigerant, take into account the slight change in the composition of the gas and liquid

Be more careful that foreign matter (oil, water, etc.) does not enter the piping than with refrigerant models.

phases, and always charge from the liquid phase side whose composition is stable.

Special tools for R410A

Tool name	Contents of change
Gauge manifold	Pressure is high and cannot be measured with a conventional gauge. To prevent erroneous mixing of other refrigerants, the diameter of each port has been changed. It is recommended the gauge with seals –0.1 to 5.3 MPa (–76 cmHg to 53 kgf/cm²) for high pressure. –0.1 to 3.8 MPa (–76 cmHg to 38 kgf/cm²) for low pressure.
Charge hose	To increase pressure resistance, the hose material and base size were changed.
Vacuum pump A conventional vacuum pump can be used by installing a vacuum pump adapter.	
Gas leakage detector	Special gas leakage detector for HFC refrigerant R410A.

It is necessary to use seamless copper pipes and it is desirable that the amount of residual oil is less than 40 mg/10m. Do not use copper pipes having a collapsed, deformed or discolored portion (especially on the interior surface). Otherwise, the expansion valve or capillary tube may become blocked with contaminants.

As an air conditioner using R410A incurs pressure higher than when using conventional refrigerant, it is necessary to choose adequate materials. Thicknesses of copper pipes used with R410A are as shown in the table. Never use copper pipes thinner than that in the table even when it is available on the market

Thicknesses of Annealed Copper Pipes (R410A)

	11 1 (/
Pipe outside diameter	Thickness
6.35 mm (1/4 in.)	0.80 mm
9.52 mm (3/8 in)	0.80 mm
12.70 mm (1/2 in.)	0.80 mm
15.88 mm (5/8 in)	1.00 mm

Thickness
0.80 mm
0.80 mm
0.80 mm
1.00 mm

STANDARD PARTS

INDOOR UNIT ACCESSORIES


Name and Shape	Q'ty	Application
Hanger	4	For suspending the indoor unit from ceiling
Drain hose insulation	1	Insulates the drain hose and vinyl hose

Name and Shape Coupler heat insulation (large) Coupler heat insulation (small) Coupler heat insulation (small) Binder 1 For indoor side pipe joint (large pipe) For indoor side pipe joint (small pipe) For fixing the drain hose Special nut A (large flange) For suspending the indoor unit from ceiling			
insulation (large) Coupler heat insulation (small) Binder I For indoor side pipe joint (small pipe) For fixing the drain hose Special nut A (large flange) For suspending the indoor unit from ceiling	Name and Shape	Q'ty	Application
Binder 1	'	1	
Special nut A (large flance) (large flance) (large flance)	1 ·	1	
(large flange) (a) indoor unit from ceiling	Binder	1 (large)	_
	l ' (5)	4	
Special nut B (small flange) 4	1 . (8)	4	

OPTIONAL PARTS

When connecting the square duct and round duct, use the optional square flange or round flange and flexible duct.


Square flange Model name: UTD-SF045T (P/N 9098180007)








Model name: UTD-RF204 (P/N 9093160004)



Long-life filter Model name: UTD-LF25NA (P/N9079892004)



For authorized service personnel only.

↑ WARNING For the air conditioner to operate satisfactorily, install it as outlined in this installation instruction sheet.

- Connect the indoor unit and outdoor unit with the air conditioner piping and cords available standards parts. This installation instruction sheet describes the correct connections using the installation set available from
- Installation work must be performed in accordance with national wiring standards by authorized personnel
- If refrigerant leaks while work is being carried out, ventilate the area. If the refrigerant comes in contact with a flame, it produces a toxic gas.
- Do not use an extension cord.
- 6 Do not turn on the power until all installation work is complete

↑ CAUTION

This installation instruction sheet describes how to install the indoor unit only. To install the outdoor unit, refer to the installation instruction sheet included with the outdoor unit.

- Be careful not to scratch the air conditioner when handling it.
- · After installation, explain correct operation to the customer, using the operating manual. Let the customer keep this installation instruction sheet because it is used when the air conditioner is serv-

SELECTING THE MOUNTING POSITION

WARNING

Install at a place that can withstand the weight of the indoor and outdoor units and install positively so that the units will not topple or fall.

⚠ CAUTION


- Do not install where there is the danger of combustible gas leakage.
- Do not install the unit near heat source of heat, steam, or flammable gas.
- ③ If children under 10 years old may approach the unit, take preventive measures so that they cannot reach
- Take precautions to prevent the unit from falling.
- Decide the mounting position with the customer as follows:

INDOOR UNIT

- (1) Install the indoor unit on a place having a sufficient strength so that it withstand against
- (2) The inlet and outlet ports should not be obstructed; the air should be able to blow all
- (3) Leave the space required to service the air conditioner.
- 4) Install the unit where the drain pipe can be easily installed.
- 5) Providing as much space as possible between the indoor unit and the ceiling will make
- (6) If installing in a place where its humidity exceeds 80%, use heat insulation to prevent

Maintenance hole dimension

It shall be possible to install and remove the control box.



or more or more It shall be possible to install and remove the control box, fan units and filter Control box

150 mm

300 mm

CONNECTING PIPE REQUIREMENT

⚠ CAUTION

Refer to the installation instruction sheet of the outdoor unit for description of the length of connecting pipe or for difference of its elevation.

Diameter	Small	6.35 mm (1/4 in.)	
Diameter	Large	15.88 mm (5/8 in.)	

Use pipe with water-resistant heat insulation.

!\ CAUTION

Use heat insulation with heat resistance above 120 °C. (Reverse cycle model only) In addition, if the humidity level at the installation location of the refrigerant piping is expected to exceed 70%, install heat insulation around the refrigerant piping. If the expected humidity level is 70-80%, use heat insulation that is 15 mm or thicker and if the expected humidity exceeds 80%, use heat insulation that is 20 mm or

Install heat insulation around both the gas and liquid pipes. Failure to do so may cause water leaks.

If heat insulation is used that is not as thick as specified, condensation may form on the surface of the insulation. In addition, use heat insulation with heat conductivity of 0.045 W/(m·K) or less (at 20 °C).

ELECTRICAL REQUIREMENT

Connection	cord (mm²)
MAX.	MIN.
0.5	4.5

- Use conformed cord with Type 245 IEC57
- Install the disconnect device with a contact gap of at least 3 mm nearby the units.
- (Both indoor unit and outdoor unit) Install all electrical works in accordance to the standard.

INSTALLATION PROCEDURE

INDOOR UNIT INSTALLATION

↑ WARNING

- Install the air conditioner in a location which can withstand a load of at least five times the weight of the main unit and which will not amplify sound or vibration. If the installation location is not strong enough,
- the indoor unit may fall and cause injuries. 2) If the job is done with the panel frame only, there is a risk that the unit will come loose. Please take

CAUTION

For installation, refer to the technical data.

1. INSTALLING THE HANGERS

↑ WARNING When fastening the hangers, make the bolt positions uniform.

Hanging bolt installation diagram.

hanging bolts.

and flange.

(MAX: 550 mm, MIN: 410 mm)

4. INTAKE DUCT CONNECTION


Follow the procedure in the following figure to the ducts.

1015 mm

The air inlet duct can be changed by replacing the intake grille

For the bottom air intake, follow the procedure of \bigcirc \rightarrow \bigcirc for

(The factory setting is back air intake.)



Bolt Strength 9.81 to 14.71 N·m (100 to 150 kgf·cm) **⚠** WARNING Fasten the unit securely with special nuts A and B. Base vertical direction leveling on the unit (right and left). Base horizontal direction leveling on top of the unit. Give a slight tilt to the side to which the drain hose is connected The tilt should be in the range of 0 mm to 5 mm. 3. INSTALLING DRAIN HOSE Install the drain hose according to the measurements given in the following figure. (Right side)

Drain pipe

⚠ CAUTION

When air is taken in from the bottom side, the operat-

ing sound of the product will easily enter the room.

of the operating sound is small.

perature cannot be detected.

hand operation without tool.

Install the product and intake grilles where the affect

CAUTION

1) If an intake duct is installed, take care not to

sensor is attached to the intake port flange).

2 Be sure to install the air inlet grille and the air outlet grille for air circulation. The correct tem-

▼ Air Outlet Grille Air Inlet Grille

3 Grills must be fixed so that man cannot touch indoor unit fan, and cannot be removed by only

4) Be sure to install the air filter in the air inlet. If the

air filter is not installed, the heat exchanger may

be clogged and its performance may decrease.

damage the temperature sensor (the temperature

ø 38 mm (O.D.)

The drain cap is attached

at the factory setting.

Slide the unit in the arrow direction and fasten it.

(Obtained locally)


Hanging bolt M10


(Obtained locally)

↑ CAUTION Install the drain hose in accordance with the instructions in this installation instruction sheet and keep the area warm enough to prevent condensation. Problems with the piping may lead to water leaks. **NOTE: INSTALL THE DRAIN HOSE** • Install the drain hose with downward gradient (1/50 to


1/100) and so there are no rises or traps in the hose. · Use general hard polyvinyl chloride pipe (VP25) [outside diam-

eter 38mm] and connect it with adhesive (polyvinyl chloride) so that there is no leakage. When the hose is long, install supporters.





When the unit is shipped from the factory, the drain port is on the left side (control box side).





Always check that the drain cap is installed to the unused drain port and is fastened with the nylon


from the end with cutters, etc. Stick the large drain hose insulation at the drain hose installation


· Stick the small drain hose insulation at the drain cap side.

• Cut the drain hose insulation at a position approximately 30mm









↑ CAUTION

If the drain cap is not installed, or is not sufficiently fastened by the nylon fastener, water may drip during the cooling operation.


6. FRESH AIR INTAKE

(1) Square duct


5. OUTLET DUCT CONNECTION

Duct installation pattern (CUT PART)

(2) Round duct outlet ×4 (This is the factory setting.




(2) Turn up the insulation around the points to be cut according to the outlet port shape working points so that the insulation does not stick out at the 1////// part.




(3) Cut with nippers and remove the sheet metal.

(4) Since there is a slit in the insulation, use radio pliers, tweezers, etc. to stretch the screw hole part used when installing the round flange and square flange when connecting the duct.




(Processing before use) (1) When taking in fresh air, cut a slit shaped cabinet in the left

side of the outer case with nippers.




CAUTION 1) When removing the cabinet (iron plate), be careful not to damage the indoor unit internal parts and surrounding area (outer case).

2 When processing the cabinet (iron plate), be careful not to injure yourself with burrs, etc.



(3) Connect the duct to the round flange (4) Seal with a band and vinyl tape, etc. so that air does not leak from the connection.



(Continued to the next page.)


8/22/06 1:26:44 PM

9374318148_B2front.indd 1

. FLARING

- 1) Cut the connection pipe to the necessary length with a pipe
- (2) Hold the pipe downward so that cuttings will not enter the pipe and remove the burrs.
- 3) Insert the flare nut (always use the flare nut attached to the indoor and outdoor units respectively) onto the pipe and perform the flare processing with a flare tool. Use the special R410A flare tool, or the conventional flare

Check if [L] is flared uniformly and is not cracked or scratched



Dina autaida diamatar	Dimension A (mm)	
Pipe outside diameter	Flare tool for R410A, clutch typ	
6.35 mm (1/4 in.)		
9.52 mm (3/8 in.)	0 +0 0 5	
12.70 mm (1/2 in.)	0 to 0.5	
15.88 mm (5/8 in.)		

Pipe outside diameter	Dimension B $^0_{-0.4}$ (mm)
6.35 mm (1/4 in.)	9.1
9.52 mm (3/8 in.)	13.2
12.70 mm (1/2 in.)	16.6
15.88 mm (5/8 in.)	24.0

When using conventional flare tools to flare R410A pipes, the dimension A should be approximately 0.5 mm more than indicated in the table (for flaring with R410A flare tools) to achieve the specified flaring. Use a thickness gauge to measure the dimension A.

Pipe outside

diameter

6.35 mm (1/4 in.)

Width across flats

of Flare nut

17 mm


Width across flats



9.52 mm (3/8 in.)	22 mm
12.70 mm (1/2 in.)	26 mm
15.88 mm (5/8 in.)	29 mm


2. BENDING PIPES

The pipes are shaped by your hands. Be careful not to collapse



Do not bend the pipes in an angle more than 90°. When pipes are repeatedly bent or stretched, the material will harden, making it difficult to bend or stretch them any more. Do not bend or stretch the pipes more than three times.

When bending the pipe, do not bend it as is. The pipe will be collapsed. In this case, cut the heat insulating pipe with a sharp Pipe cutter as shown on the right, and bend it after exposing the pipe. After bending the pipe as you want, be sure to put the heat insulating pipe back on the pipe, and secure it with tape.



↑ CAUTION


- To prevent breaking of the pipe, avoid sharp Bend the pipe with a radius of curvature of 150
- 2) If the pipe is bent repeatedly at the same place, it will break.

3. CONNECTION PIPES

Indoor unit (1) Detach the caps and plugs from the pipes.

CAUTION

- 1) Be sure to apply the pipe against the port on the indoor unit correctly. If the centering is improper, the flare nut cannot be tightened smoothly. If the flare nut is forced to turn, the threads will be damaged.
- 2 Do not remove the flare nut from the indoor unit pipe until immediately before connecting the connection pipe.
- (2) Centering the pipe against port on the indoor unit, turn the flare nut with your hand.




To prevent gas leakage, coat the flare surface with alkylbenzene oil (HAB).

↑ CAUTION

Hold the torque wrench at its grip, keeping it in the right angle with the pipe, in order to tighten the flare nut correctly.

When the flare nut is tightened properly by your hand, use a torque wrench to finally tighten it.



Flare nut tightening torque

Flare nut	Tightening torque
6.35 mm (1/4 in.) dia.	14 to 18 N·m (140 to 180 kgf·cm)
15.88 mm (5/8 in.) dia.	63 to 77 N·m (630 to 770 kgf·cm)

↑ CAUTION


Be sure to connect the gas pipe after connecting

the liquid pipe completely.

INSTALLING THE

COUPLER HEAT INSULATION

After checking for gas leaks, insulate by wrapping insulation around the two parts (gas and liquid) of the indoor unit coupling, using the coupler heat insulation. After installing the coupler heat insulation, wrap both ends with



Must fit tightly against body without any gap.

ELECTRICAL WIRING

CAUTION

Do not bundle the remote controller cord, or wire the remote controller cord in parallel, with the indoor unit connection wire (to the outdoor unit) and the power supply cord. It may cause erroneous operation.


HOW TO CONNECT WIRING TO THE TERMINALS

A. For solid core wiring


- (1) Cut the wire end with a wire cutter or wire-cutting pliers,
- then strip the insulation to about 25 mm (15/16") to expose the solid wire.
- (2) Using a screwdriver, remove the terminal screw(s) on the terminal board.
- (3) Using pliers, bend the solid wire to form a loop suitable for the terminal screw.
- (4) Shape the loop wire properly, place it on the terminal board and tighten securely with the terminal screw using a screwdriver.

B. For strand wiring


- (1) Cut the wire end with a wire cutter or wire-cutting pliers, then strip the insulation to about 10 mm (3/8") to expose the strand wiring.
- (2) Using a screwdriver, remove the terminal screw(s) on the terminal board. (3) Using a round terminal fastener or pliers, securely clamp
- a round terminal to each stripped wire end. (4) Position the round terminal wire, and replace and tighten



1. CONNECTION DIAGRAMS



2. CONNECTION CORD PREPARATION Keep the earth wire longer than the other wires.




3. CONNECTION OF WIRING


⚠ WARNING

- Before starting work, check that power is not being supplied to the indoor unit and outdoor
- Match the terminal board numbers and connection cord colors with those of the outdoor Erroneous wiring may cause burning of the electric parts.
- Connect the connection cords firmly to the terminal board. Imperfect installation may
- Always fasten the outside covering of the connection cord with the cord clamp. (If the insulator is chafed, electric leakage may occur.)
- Always connect the ground wire.
- Install the remote controller wires so as not to be direct touched with your hand.

(1) Remove the control box cover and install each connection



(2) After wiring is complete, secure the remote controller cord, connection cord, and power cord with the cord clamps.



FUNCTION SETTING

- Follow the instructions in the Local Setup Procedure, which is supplied with the remote control, in accordance with the installed condition. After the power is turned on, perform the Function Setting on the remote control.
- The settings may be selected between the following two: Function Number or Setting Value.
- Settings will not be changed if invalid numbers or setting values

Setting the Static Pressure

Setting Description	Function Number	Setting Value
Normal	21	00
High static pressure 1		01
High static pressure 2		02
High static pressure 3		03

Determine the wind volume in each mode i.e., applicable range of static pressure, refering to [7] STATIC PRESSURE CHARACTERISTICS. (The unit is factory-set to "00")

Setting the Cooler Room Temperature Correction

Depending on the installed environment, the room temperature sensor may require a correction. The settings may be selected as shown in the table below. (The unit is factory-set to "00".)

Setting Description	Function Number	Setting Value
Standard	20	00
Lower control	30	01

Setting the Heater Room Temperature Correction Depending on the installed environment, the room temperature sensor may require a correction. The settings may be changed

as shown in the table below. (The unit is factory-set to "00".)

Setting Description	Function Number	Setting Value
Standard		00
Lower control	31	01
Slightly warmer control	31	02
Warmer control		03

Setting Other Functions

The following settings are also possible, depending on the operating conditions. (The unit is factory-set to "00".)

Auto Hestart				
Setting Description	Function Number	Setting Value		
Yes	40	00		
Na	40	01		

remote controller only)

- If setting value is "00", room temperature is controlled by the indoor unit temperature sensor.
- indoor unit temperature sensor or remote control unit sensor.

SWITCHING REMOTE CONTROL UNIT SIGNAL CODES

the printed circuit board setting. If these are not confirmed, the remote control unit cannot be used to operate for the air conditioner.

Jumper wire		Remote control unit		
JM1	JM2	signal code		
Connect	Connect	A (Primary setting)		
Disconnect	Connect	b		
Connect	Disconnect	С		
Disconnect	Disconnect	d		

Setting	Setting Value		
Static pressure			
Cooler room temperature correction			
Heater room temperature correction			
Auto restart			
Indoor room temperature sensor switching function			

After completing the FUNCTION SETTING, be sure to turn off the power and turn it on again.

Auto Hestart				
Setting Description	Function Number	Setting Value		
Yes	40	00		
NI-	40	0.4		

Indoor Room Temperature Sensor Switching Function (Wired

Setting Description	Function Number	Setting Value
No	42	00
Yes	42	01

- If setting value is "01", room temperature is controlled by either

[When using the wireless remote controller]

· Confirm the setting of the remote control unit signal code and

Jumper wire JM1 JM2		Remote control unit
		signal code
Connect Connect		A (Primary setting)
Disconnect	Connect	b
Connect	Disconnect	С

Setting Record

· Record any changes to the settings in the following table.


Setting	Setting Value
Static pressure	
Cooler room temperature correction	
Heater room temperature correction	
Auto restart	
Indoor room temperature sensor switching function	

TEST RUN

- (1) Is operation of each button on the remote control unit nor-
- (2) Does each lamp light normally?
- (3) Do not air flow direction louvers operate normally? (4) Is the drain normal?
- (5) Is there any abnormal noise and vibration during operation? · Do not operate the air conditioner in the running state for a

[Using the wireless remote control]

For the operation method, refer to the operating manual. The outdoor unit may not operate depending on the room temperature. In this case, press the test run button on the remote control unit while the air conditioner is running. (Point the transmitter section of the remote control unit toward the air conditioner and press the test run button with the tip of a ball-point pen, etc.)



To end test operation, press the remote control unit START/ STOP button.

(When the air conditioner is run by pressing the test run button,


the OPERATION indicator lamp and TIMER indicator lamp will

simultaneously flash slowly.) [Using the wired remote control]

For the operation method, refer to the operating manual. Stop the air conditioner operation.

(2) Press the master control button and the fan control button

simultaneously for 2 seconds or more to start the test run.






(3) Press the start/stop button to stop the test run.

[Troubleshooting at the remote control LCD]

This is possible only on the wired remote control.

[SELF-DIAGNOSIS]



EX. Self-diagnosis

Error code Error contents Indoor signal error 00 Wired remote controller abnormal Indoor room temperature sensor error 02 ndoor heat exchanger temperature sensor 04 middle) error ndoor heat exchanger temperature sensor 28 nlet) error

Float switch operated Outdoor discharge pipe temperature sensor 0C Outdoor heat exchanger temperature sensor 06 outlet) error Outdoor temperature sensor error 15 Compressor temperature sensor error 1d 2-way valve temperature sensor error 1E 3-way valve temperature sensor error 29

Outdoor heat exchanger temperature sensor Indoor manual auto switch abnormal **2A** Power supply frequency detection error IPM protection CT error 1**A** Compressor location error 1b Outdoor fan error Connected indoor unit abnormal Outdoor unit computer communication error Indoor fan abnormal Discharge temperature error Exessive high pressure protection on cooling 24 2c 4-way valve abnormal 16 Pressure switch abnormal 2b Compressor temperature error

If "CO" appears in the unit number display, there is a remote controller error. Refer to the installation instruction sheet included with the remote controller.

Active filter abnormal PFC circuit error

STATIC PRESSURE **CHARACTERISTIC**


⚠ CAUTION If the applicable static pressure does not match the

be changed to another mode automatically. **RECOMMENDED RANGE OF** EXTERNAL STATIC PRESSURE

30Pa to 150Pa

static pressure mode, the static pressure mode may

1. FAN PERFORMANCE AND AIR FLOW



2. AIR FLOW SETTING The air flow is set according to the DIP switch settings in the

following	tables.	
Mode	Setting condition	Static pressure range
1	Normal	30 ≦ P ≦ 40
2	High static pressure 1	56 ≦ P ≦ 65
3	High static pressure 2	95 ≦ P ≦ 105
4	High static pressure 3	142 ≦ P ≦ 150

SPECIAL INSTALLATION METHODS


other parts on the circuit board directly with

CAUTION When setting DIP switches, do not touch any

② Be sure to turn off the main power.

your bare hands.

GROUP CONTROL SYSTEM A number of indoor units can be operated at the same time using a single remote controller.




Remote controller wire

(2) DIP switch setting (Indoor unit) Set the unit number of each indoor unit using DIP switch on the indoor unit circuit board. (See following table and figure.) DIP switch is normally set to make unit number No. 0.

Unit number	DIP SWITCH No.			
	1	2	3	4
0	OFF	OFF	OFF	OFF
1	ON	OFF	OFF	OFF
2	OFF	ON	OFF	OFF
3	ON	ON	OFF	OFF
4	OFF	OFF	ON	OFF
5	ON	OFF	ON	OFF
6	OFF	ON	ON	OFF
7	ON	ON	ON	OFF
8	OFF	OFF	OFF	ON
9	ON	OFF	OFF	ON
10	OFF	ON	OFF	ON
11	ON	ON	OFF	ON
12	OFF	OFF	ON	ON
13	ON	OFF	ON	ON
14	OFF	ON	ON	ON

Example: No. 3



CUSTOMER GUIDANCE

Explain the following to the customer in accordance with the operating manual:

ture adjustment, timer, air flow switching, and other remote control unit operations.

(4) If the signal code is changed, explain to the of

(1) Starting and stopping method, operation switching, tempera-

(3) Give the operating and installation manuals to the customer.


(2) Air filter removal and cleaning, and how to use the air

changed (the system returns to signal code A when the batteries in the remote control unit are replaced).

*(4) is applicable to using wireless remote control.

Indoor unit

aooi aint					
Init number	DIP SWITCH No.				
	1	2	3	4	
0	OFF	OFF	OFF	OFF	
1	ON	OFF	OFF	OFF	
2	OFF	ON	OFF	OFF	
3	ON	ON	OFF	OFF	
4	OFF	OFF	ON	OFF	
5	ON	OFF	ON	OFF	
6	OFF	ON	ON	OFF	
7	ON	ON	ON	OFF	
8	OFF	OFF	OFF	ON	
9	ON	OFF	OFF	ON	
10	OFF	ON	OFF	ON	
11	ON	ON	OFF	ON	
12	OFF	OFF	ON	ON	
13	ON	OFF	ON	ON	
14	OFF	ON	ON	ON	
15	ON	ON	ON	ON	



PART NO. 9374318148

- **A** CAUTION Tighten the indoor unit connection cord (to the outdoor unit) and power supply indoor and
- outdoor unit terminal board connections firmly with the terminal board screws. Faulty connection may cause a fire. 2) If the indoor unit connection cord (to the outdoor
- air conditioner may be damaged. 3 Wire the indoor unit connection cord (to the outdoor unit) by matching the numbers of

the outdoor and indoor units terminal board


unit) and power supply are wired incorrectly, the

4) Ground both the indoor and outdoor units by attaching a ground wire.

numbers as shown in terminal label.

5 Unit shall be grounded in compliance with the applicable local and national codes.

(3) Install control box cover



to the installation.

9374318148_B2back.indd 1

8/23/06 4:43:04 PM

Duct Type SPLIT TYPE AIR CONDITIONER INSTALLATION **INSTRUCTION SHEET**

A CAUTION REFRIGERANT IIS PRODUCT MUST ONLY BE INSTALLED OR SERVICED

(PART NO. 9374318193)

Indoor unit is an appliance not accessible to the general public.

For authorized service personnel only.

<u> </u>	This mark indicates procedures which, if improperly performed, are most likely to resul in the death of or serious injury to the user or service personnel.
⚠ WARNING	This mark indicates procedures which, if improperly performed, might lead to the death or serious injury of the user.
⚠ CAUTION	This mark indicates procedures which, if improperly performed, might possibly result in personal harm to the user, or damage to property.

⚠ DANGER

Never touch electrical components immediately after the power supply has been turned off. Electrical shock may occur. After turning off the power, always wait 5 minutes or more before touching electrical components.

This air conditioner uses new refrigerant HFC (R410A).

The basic installation work procedures are the same as conventional refrigerant models. However, pay careful attention to the following points:

- Since the working pressure is 1.6 times higher than that of conventional refrigerant models, some of the piping and installation and service tools are special. (See the table below.) Especially, when replacing a conventional refrigerant model with a new refrigerant R410A model, always replace the conventional piping and flare nuts with the R410A piping and flare nuts.
- Models that use refrigerant R410A have a different charging port thread diameter to prevent erroneous charging with conventional refrigerant and for safety. Therefore, check beforehand. The charging port thread diameter for R410A is 1/2 UNF 20 threads per inch.]
- Also, when storing the piping, securely seal the openings by pinching, taping, etc. 4) When charging the refrigerant, take into account the slight change in the composition of the gas and liquid

Be more careful that foreign matter (oil, water, etc.) does not enter the piping than with refrigerant models.

phases, and always charge from the liquid phase side whose composition is stable.

Special tools for R410A

Tool name	Contents of change
Gauge manifold	Pressure is high and cannot be measured with a conventional gauge. To prevent erroneous mixing of other refrigerants, the diameter of each port has been changed. It is recommended the gauge with seals –0.1 to 5.3 MPa (–76 cmHg to 53 kgf/cm²) for high pressure. –0.1 to 3.8 MPa (–76 cmHg to 38 kgf/cm²) for low pressure.
Charge hose	To increase pressure resistance, the hose material and base size were changed.
Vacuum pump	A conventional vacuum pump can be used by installing a vacuum pump adapter.
Gas leakage detector	Special gas leakage detector for HFC refrigerant R410A.
Copper pipes	Thicknesses of Annealed Copper Pipes (R410A)

It is necessary to use seamless copper pipes and it is desirable that the having a collapsed, deformed or discolored portion (especially on the interior surface). Otherwise, the expansion valve or capillary tube may become blocked with contaminants.

conventional refrigerant, it is necessary to choose adequate materials. Thicknesses of copper pipes used with R410A are as shown in the table. Never use copper pipes thinner than that in the table even when it is

amount of residual oil is less than 40 mg/10m. Do not use copper pipes As an air conditioner using R410A incurs pressure higher than when using

available on the market

gulations, codes, installation & operation manuals, before a installation, maintenance and /or service of this product.

Installation work must be performed in accordance with national wiring standards by authorized personnel

If refrigerant leaks while work is being carried out, ventilate the area. If the refrigerant comes in contact with a flame, it produces a toxic gas.

↑ WARNING

For the air conditioner to operate satisfactorily, install it as outlined in this installation instruction sheet.

Connect the indoor unit and outdoor unit with the air conditioner piping and cords available standards parts.

This installation instruction sheet describes the correct connections using the installation set available from

Do not use an extension cord.

For authorized service personnel only.

6 Do not turn on the power until all installation work is complete

↑ CAUTION

This installation instruction sheet describes how to install the indoor unit only. To install the outdoor unit, refer to the installation instruction sheet included with the outdoor unit.

- Be careful not to scratch the air conditioner when handling it. · After installation, explain correct operation to the customer, using the operating manual.
- · Let the customer keep this installation instruction sheet because it is used when the air conditioner is serv-

SELECTING THE MOUNTING POSITION

WARNING

Install at a place that can withstand the weight of the indoor and outdoor units and install positively so that the units will not topple or fall.

⚠ CAUTION

- Do not install where there is the danger of combustible gas leakage.
- Do not install the unit near heat source of heat, steam, or flammable gas.
- ③ If children under 10 years old may approach the unit, take preventive measures so that they cannot reach
- 4) Take precautions to prevent the unit from falling.
- Decide the mounting position with the customer as follows:

INDOOR UNIT

- (1) Install the indoor unit on a place having a sufficient strength so that it withstand against
- (2) The inlet and outlet ports should not be obstructed; the air should be able to blow all
- (3) Leave the space required to service the air conditioner.
- 4) Install the unit where the drain pipe can be easily installed.
- 5) Providing as much space as possible between the indoor unit and the ceiling will make
- (6) If installing in a place where its humidity exceeds 80%, use heat insulation to prevent

300 mm 150 mm or more or more

Maintenance hole dimension It shall be possible to install and remove the control box.


Thickness


0.80 mm

0.80 mm

0.80 mm

1.00 mm





STANDARD PARTS

INDOOR UNIT ACCESSORIES

Name and Shape	Q'ty	Application
Hanger	4	For suspending the indoor unit from ceiling
Drain hose insulation	1	Insulates the drain hose and vinyl hose

Name and Shape	Q'ty	Application
Coupler heat insulation (large)	1	For indoor side pipe joint (large pipe)
Coupler heat insulation (small)	1	For indoor side pipe joint (small pipe)
Binder	1 (large)	For fixing the drain hose
Special nut A (large flange)	4	For suspending the indoor unit from ceiling
Special nut B (small flange)	4	

Pipe outside diameter

6.35 mm (1/4 in.)

9.52 mm (3/8 in)


12.70 mm (1/2 in.)

15.88 mm (5/8 in)

OPTIONAL PARTS When connecting the square duct and round duct, use the optional square flange or round flange and flexible duct.

Square flange


Model name: UTD-SF045T (P/N 9098180007)




Flexible duct Model name: UTD-RD202 (P/N 9074165004)



Model name: UTD-RF204 (P/N 9093160004)



Long-life filter Model name: UTD-LF25NA (P/N9079892004)



CONNECTING PIPE REQUIREMENT

⚠ CAUTION

Refer to the installation instruction sheet of the outdoor unit for description of the length of connecting pipe or for difference of its elevation.

MODEL		24000 BTU/h model	36000/45000 BTU/h model
Diameter	Small	6.35 mm (1/4 in.)	9.52 mm (3/8 in.)
Diameter Large	Large	15.88 mm (5/8 in.)	15.88 mm (5/8 in.)

Use pipe with water-resistant heat insulation.

! CAUTION

Install heat insulation around both the gas and liquid pipes. Failure to do so may cause water leaks. Use heat insulation with heat resistance above 120 °C. (Reverse cycle model only)

In addition, if the humidity level at the installation location of the refrigerant piping is expected to exceed 70%, install heat insulation around the refrigerant piping. If the expected humidity level is 70-80%, use heat insulation that is 15 mm or thicker and if the expected humidity exceeds 80%, use heat insulation that is 20 mm or

If heat insulation is used that is not as thick as specified, condensation may form on the surface of the insulation. In addition, use heat insulation with heat conductivity of 0.045 W/(m·K) or less (at 20 °C).

ELECTRICAL REQUIREMENT

Connection	cord (mm²)
MAX.	MIN.
2.5	1.5

- Use conformed cord with Type 245 IEC57
- Install the disconnect device with a contact gap of at least 3 mm nearby the units.
- (Both indoor unit and outdoor unit)
- Install all electrical works in accordance to the standard.

INSTALLATION PROCEDURE

INDOOR UNIT INSTALLATION

↑ WARNING

- Install the air conditioner in a location which can withstand a load of at least five times the weight of the main unit and which will not amplify sound or vibration. If the installation location is not strong enough,
- the indoor unit may fall and cause injuries. 2) If the job is done with the panel frame only, there is a risk that the unit will come loose. Please take

CAUTION For installation, refer to the technical data.

×477 mm

The distance of $\overset{*}{\times}$ is adjustable according to the place of the

1. INSTALLING THE HANGERS

(Example)

(Top side)

hanging bolts.

and flange.

(MAX: 550 mm, MIN: 410 mm)

4. INTAKE DUCT CONNECTION


Follow the procedure in the following figure to the ducts.

1015 mm

The air inlet duct can be changed by replacing the intake grille


For the bottom air intake, follow the procedure of \bigcirc \rightarrow \bigcirc for

(The factory setting is back air intake.)



Give a slight tilt to the side to which the drain hose is connected

following figure.



↑ CAUTION Install the drain hose in accordance with the instructions in this installation instruction sheet and keep the area warm enough to prevent condensation. Problems with the piping may lead to water leaks. **NOTE: INSTALL THE DRAIN HOSE** • Install the drain hose with downward gradient (1/50 to 1/100) and so there are no rises or traps in the hose. · Use general hard polyvinyl chloride pipe (VP25) [outside diam-

that there is no leakage.

· Do not perform air bleeding.

left side (control box side).

When the hose is long, install supporters.

Bolt Strength 9.81 to 14.71 N·m (100 to 150 kgf·cm)


(Obtained locally)


Slide the unit in the arrow direction and fasten it.


Hanging bolt M10

(Obtained locally)

⚠ WARNING Fasten the unit securely with special nuts A and B.








The tilt should be in the range of 0 mm to 5 mm.

3. INSTALLING DRAIN HOSE





⚠ CAUTION

When air is taken in from the bottom side, the operat-

ing sound of the product will easily enter the room.

of the operating sound is small.

damage the temperature sensor.

perature cannot be detected.

hand operation without tool.

(Room)

Install the product and intake grilles where the affect

CAUTION

1) If an intake duct is installed, take care not to

Be sure to install the air inlet grille and the air outlet grille for air circulation. The correct tem-

▼ Air Outlet Grille Air Inlet Grille

3 Grills must be fixed so that man cannot touch

Be sure to install the air filter in the air inlet. If the

air filter is not installed, the heat exchanger may

be clogged and its performance may decrease.

indoor unit fan, and cannot be removed by only

Unit

at the factory setting.


the drain cap to the left side drain port.


Always check that the drain cap is installed to the


If the drain cap is not installed, or is not sufficiently

· Cut the drain hose insulation at a position approximately 60 mm from the end with cutters, etc. • Stick the large drain hose insulation at the drain hose installation


· Stick the small drain hose insulation at the drain cap side.







· Cover the drain cap with the drain hose insulation.



When the unit is shipped from the factory, the drain port is on the

eter 38mm] and connect it with adhesive (polyvinyl chloride) so

Always heat insulate the indoor side of the drain hose.

↑ CAUTION

unused drain port and is fastened with the nylon


fastened by the nylon fastener, water may drip during the cooling operation.

5. OUTLET DUCT CONNECTION Duct installation pattern (CUT PART)


(1) Square duct



When using as a square duct




(2) Turn up the insulation around the points to be cut according to the outlet port shape working points so that the insulation does not stick out at the 1////// part.




(3) Cut with nippers and remove the sheet metal.

(4) Since there is a slit in the insulation, use radio pliers, tweezers, etc. to stretch the screw hole part used when installing the round flange and square flange when connecting the duct.



6. FRESH AIR INTAKE (Processing before use)

(1) When taking in fresh air, cut a slit shaped cabinet in the left side of the outer case with nippers.




1) When removing the cabinet (iron plate), be careful not to damage the indoor unit internal parts and surrounding area (outer case).

CAUTION


2 When processing the cabinet (iron plate), be careful not to injure yourself with burrs, etc.

(2) Install the round flange (option parts) to the fresh air intake.



(3) Connect the duct to the round flange

(4) Seal with a band and vinyl tape, etc. so that air does not leak from the connection



(Continued to the next page.)

9374318193_B2.indd 1 1/15/07 2:46:55 PM

CONNECTING THE PIPE

⚠ CAUTION 1) Do not use mineral oil on flared part. Prevent

mineral oil from getting into the system as this would reduce the lifetime of the units. While welding the pipes, be sure to blow dry nitrogen gas through them.


. FLARING

1) Cut the connection pipe to the necessary length with a pipe

(2) Hold the pipe downward so that cuttings will not enter the pipe and remove the burrs. B) Insert the flare nut (always use the flare nut attached to the

indoor and outdoor units respectively) onto the pipe and perform the flare processing with a flare tool. Use the special R410A flare tool, or the conventional flare

Check if [L] is flared uniformly and is not cracked or scratched



	Dine outeide diemeter	Dimension A (mm)	
	Pipe outside diameter	Flare tool for R410A, clutch ty	
	6.35 mm (1/4 in.)		
	9.52 mm (3/8 in.)	0 to 0 E	
	12.70 mm (1/2 in.)	0 to 0.5	
	15.88 mm (5/8 in.)		

Pipe outside diameter	Dimension B $_{-0.4}^{0}$ (mm)
6.35 mm (1/4 in.)	9.1
9.52 mm (3/8 in.)	13.2
12.70 mm (1/2 in.)	16.6
15.88 mm (5/8 in.)	24.0

When using conventional flare tools to flare R410A pipes, the dimension A should be approximately 0.5 mm more than indicated in the table (for flaring with R410A flare tools) to achieve the specified flaring. Use a thickness gauge to measure the dimension A.

Width across flats




diameter	of Flare nut
6.35 mm (1/4 in.)	17 mm
9.52 mm (3/8 in.)	22 mm
12.70 mm (1/2 in.)	26 mm
15.88 mm (5/8 in.)	29 mm

Pipe outside Width across flats


2. BENDING PIPES

The pipes are shaped by your hands. Be careful not to collapse



Do not bend the pipes in an angle more than 90°. When pipes are repeatedly bent or stretched, the material will harden, making it difficult to bend or stretch them any more. Do not bend or stretch the pipes more than three times.

When bending the pipe, do not bend it as is. The pipe will be collapsed. In this case, cut the heat insulating pipe with a sharp Pipe cutter as shown on the right, and bend it after exposing the pipe. After bending the pipe as you want, be sure to put the heat insulating pipe back on the pipe, and secure it with tape.



⚠ CAUTION

To prevent breaking of the pipe, avoid sharp Bend the pipe with a radius of curvature of 150

2) If the pipe is bent repeatedly at the same place, it will break.

3. CONNECTION PIPES


Indoor unit (1) Detach the caps and plugs from the pipes.

CAUTION

1) Be sure to apply the pipe against the port on the indoor unit correctly. If the centering is improper, the flare nut cannot be tightened smoothly. If the flare nut is forced to turn, the threads will be damaged.

Do not remove the flare nut from the indoor unit pipe until immediately before connecting the connection pipe.

(2) Centering the pipe against port on the indoor unit, turn the flare nut with your hand.




To prevent gas leakage, coat the flare surface with alkylbenzene oil (HAB).

↑ CAUTION

Hold the torque wrench at its grip, keeping it in the right angle with the pipe, in order to tighten the flare nut correctly.

When the flare nut is tightened properly by your hand, use a torque wrench to finally tighten it.



Flare nut tightening torque

Flare nut	Tightening torque
6.35 mm (1/4 in.) dia.	14 to 18 N·m (140 to 180 kgf·cm)
9.52 mm (3/8 in.) dia.	33 to 42 N·m (330 to 420 kgf·cm)
15.88 mm (5/8 in.) dia.	63 to 77 N·m (630 to 770 kgf·cm)

↑ CAUTION Be sure to connect the gas pipe after connecting

the liquid pipe completely.

⚠ CAUTION Must fit tightly against body without any gap.

insulation

using the coupler heat insulation.

vinyl tape so that there is no gap.

Coupler heat insulation

Be sure to overlap the

INSTALLING THE

COUPLER HEAT

After checking for gas leaks, insulate by wrapping insulation

around the two parts (gas and liquid) of the indoor unit coupling,

After installing the coupler heat insulation, wrap both ends with

INSULATION

ELECTRICAL WIRING

CAUTION

Do not bundle the remote controller cord, or wire the remote controller cord in parallel, with the indoor unit connection wire (to the outdoor unit) and the power supply cord. It may cause erroneous operation.

HOW TO CONNECT WIRING TO THE TERMINALS

A. For solid core wiring

B. For strand wiring

(1) Cut the wire end with a wire cutter or wire-cutting pliers, then strip the insulation to about 25 mm (15/16") to expose

the solid wire. (2) Using a screwdriver, remove the terminal screw(s) on the terminal board.


(3) Using pliers, bend the solid wire to form a loop suitable for the terminal screw. (4) Shape the loop wire properly, place it on the terminal

board and tighten securely with the terminal screw using a screwdriver.


(1) Cut the wire end with a wire cutter or wire-cutting pliers, then strip the insulation to about 10 mm (3/8") to expose the strand wiring.

(2) Using a screwdriver, remove the terminal screw(s) on the terminal board.


(3) Using a round terminal fastener or pliers, securely clamp a round terminal to each stripped wire end. (4) Position the round terminal wire, and replace and tighten



1. CONNECTION DIAGRAMS



2. CONNECTION CORD PREPARATION Keep the earth wire longer than the other wires.



3. CONNECTION OF WIRING

⚠ WARNING

- Before starting work, check that power is not being supplied to the indoor unit and outdoor
- Match the terminal board numbers and connection cord colors with those of the outdoor Erroneous wiring may cause burning of the electric parts.
- Connect the connection cords firmly to the terminal board. Imperfect installation may
- Always fasten the outside covering of the connection cord with the cord clamp. (If the insulator is chafed, electric leakage may occur.)
- Always connect the ground wire.
- Install the remote controller wires so as not to be direct touched with your hand.

Screw Control box cover

Cord clamp

(1) Remove the control box cover and install each connection

(2) After wiring is complete, secure the remote controller cord,

connection cord, and power cord with the cord clamps.

Connection cord

outdoor unit terminal board connections firmly with the terminal board screws. Faulty connection may cause a fire. ② If the indoor unit connection cord (to the outdoor

A CAUTION

Tighten the indoor unit connection cord (to the

outdoor unit) and power supply indoor and

unit) and power supply are wired incorrectly, the air conditioner may be damaged.


3 Wire the indoor unit connection cord (to the

the outdoor and indoor units terminal board numbers as shown in terminal label. 4) Ground both the indoor and outdoor units by

outdoor unit) by matching the numbers of

attaching a ground wire. 5 Unit shall be grounded in compliance with the applicable local and national codes.

(3) Install control box cover



Adjust the position of the screws for control box cover according to the installation.

FUNCTION SETTING

- Follow the instructions in the Local Setup Procedure, which is supplied with the remote control, in accordance with the installed condition. After the power is turned on, perform the Function Setting on the remote control.
- The settings may be selected between the following two: Function Number or Setting Value.
- Settings will not be changed if invalid numbers or setting values

Setting the Static Pressure

Setting Description	Function Number	Setting Value
Normal		00
High static pressure 1	21	01
High static pressure 2		02
High static pressure 3		03

Determine the wind volume in each mode i.e., applicable range of static pressure, refering to [7] STATIC PRESSURE CHARACTERISTICS. (The unit is factory-set to "00".)

Setting the Cooler Room Temperature Correction

Depending on the installed environment, the room temperature sensor may require a correction. The settings may be selected as shown in the table below. (The unit is factory-set to "00".)

Setting Description	Function Number	Setting Value
Standard	00	00
Lower control	30	01

Setting the Heater Room Temperature Correction Depending on the installed environment, the room temperature sensor may require a correction. The settings may be changed

as shown in the table below. (The unit is factory-set to "00".)

Setting Description	Function Number	Setting Value
Standard		00
Lower control	31	01
Slightly warmer control	31	02
Warmer control		03

Setting Other Functions

The following settings are also possible, depending on the

Setting Description	Function Number	Setting Value
Yes	40	00
No	40	01

Setting Description	Function Number	Setting Value
No	42	00
Yes	42	01

SWITCHING REMOTE CONTROL UNIT SIGNAL CODES

the printed circuit board setting.

Jumper wire		Remote control unit	
JM1	JM2	signal code	
Connect	Connect	A (Primary setting)	
Disconnect	Connect	b	
Connect	Disconnect	С	
D: .	- ·		

 Record any changes to the settings 	in the following table.
Setting	Setting Value
Static pressure	
Cooler room temperature correction	
Heater room temperature correction	
Auto restart	
Indoor room temperature sensor switching function	

After completing the FUNCTION SETTING, be sure to turn off the power and turn it on again.

uto Restart			
Setting Description	Function Number	Setting Value	
Yes	40	00	
No	40	01	

Indoor Room Temperature Sensor Switching Function (Wired remote controller only)

Setting Description	Function Number	Setting Value
No	42	00
Yes	42	01

used to operate for the air conditioner.

Jumper wire		Remote control unit	
JM1	JM2	signal code	
Connect	Connect	A (Primary setting)	
Disconnect	Connect	b	
Connect	Disconnect	С	
Disconnect	Disconnect	d	

TEST RUN

operating conditions. (The unit is factory-set to "00".)

Setting Description	Function Number	Setting Value	
Yes	40	00	

Setting Description	Function Number	Setting Value
No	42	00
Yes	42	01

- If setting value is "00", room temperature is controlled by the indoor unit temperature sensor.
- If setting value is "01", room temperature is controlled by either indoor unit temperature sensor or remote control unit sensor.

[When using the wireless remote controller]

Confirm the setting of the remote control unit signal code and If these are not confirmed, the remote control unit cannot be

Jumper wire		Remote control unit	
JM1	JM2	signal code	
Connect	Connect	A (Primary setting)	
Disconnect	Connect	b	
Connect	Disconnect	С	

Setting Record

Setting	Setting Value
Static pressure	
Cooler room temperature correction	
Heater room temperature correction	
Auto restart	
Indoor room temperature sensor switching function	

(1) Is operation of each button on the remote control unit nor-

(2) Does each lamp light normally?

(3) Do not air flow direction louvers operate normally? (4) Is the drain normal? (5) Is there any abnormal noise and vibration during operation?

[Using the wireless remote control]

For the operation method, refer to the operating manual. The outdoor unit may not operate depending on the room temperature. In this case, press the test run button on the remote control unit while the air conditioner is running. (Point the transmitter section of the remote control unit toward the air conditioner and press the test run button with the tip of a ball-point pen, etc.)

· Do not operate the air conditioner in the running state for a



To end test operation, press the remote control unit START/ STOP button. (When the air conditioner is run by pressing the test run button,

the OPERATION indicator lamp and TIMER indicator lamp will

simultaneously flash slowly.) [Using the wired remote control]

For the operation method, refer to the operating manual. (1) Stop the air conditioner operation. (2) Press the master control button and the fan control button

simultaneously for 2 seconds or more to start the test run.






(3) Press the start/stop button to stop the test run.

[Troubleshooting at the remote control LCD]

[SELF-DIAGNOSIS]

This is possible only on the wired remote control.



Error contents

O0 Wired remote controller abnormal O2 Indoor room temperature sensor error O4 Indoor heat exchanger temperature sensor (middle) error D8 Indoor heat exchanger temperature sensor (inlet) error O9 Float switch operated OC Outdoor discharge pipe temperature sensor error OA Outdoor heat exchanger temperature sensor (outlet) error OA Outdoor temperature sensor error D6 Compressor temperature sensor error D7 Compressor temperature sensor error D8 S-way valve temperature sensor error D9 Coutdoor heat exchanger temperature sensor error D9 Coutdoor heat exchanger temperature sensor error D9 Coutdoor heat exchanger temperature sensor (middle) error D9 Coutdoor manual auto switch abnormal D9 CT error D9	
Indoor heat exchanger temperature sensor (middle) error 28	
(middle) error Indoor heat exchanger temperature sensor (inlet) error Op Float switch operated OC Outdoor discharge pipe temperature sensor error OA Outdoor heat exchanger temperature sensor (outlet) error OA Outdoor temperature sensor error 15 Compressor temperature sensor error 16 2-way valve temperature sensor error 17 Sensor error Outdoor heat exchanger temperature sensor error Outdoor heat exchanger temperature sensor error Dutdoor heat exchanger temperature sensor (middle) error Outdoor manual auto switch abnormal Outdoor manual auto switch abnormal Outdoor fan error Outdoor fan error Outdoor fan error Connected indoor unit abnormal Outdoor unit computer communication error	
(inlet) error O9 Float switch operated OC Outdoor discharge pipe temperature sensor error O4 Outdoor heat exchanger temperature sensor (outlet) error OA Outdoor temperature sensor error 15 Compressor temperature sensor error 16 2-way valve temperature sensor error 17 Outdoor heat exchanger temperature sensor (middle) error OUtdoor manual auto switch abnormal OFFICE POWER SUPPLY SENSOR (PROPERSOR) OUTDOOR (PROPERSOR) OUTDOOR	
OC Outdoor discharge pipe temperature sensor error OA Outdoor heat exchanger temperature sensor (outlet) error OA Outdoor temperature sensor error 15 Compressor temperature sensor error 16 2-way valve temperature sensor error 17 Outdoor heat exchanger temperature sensor (middle) error Outdoor manual auto switch abnormal OH Power supply frequency detection error 18 CT error 1A Compressor location error 1B Outdoor fan error Connected indoor unit abnormal Coutdoor unit computer communication error	
of Outdoor heat exchanger temperature sensor (outlet) error OA Outdoor temperature sensor error 15 Compressor temperature sensor error 16 2-way valve temperature sensor error 18 3-way valve temperature sensor error Outdoor heat exchanger temperature sensor (middle) error Outdoor manual auto switch abnormal Power supply frequency detection error IPM protection RCT error A Compressor location error Dutdoor fan error Connected indoor unit abnormal C Outdoor unit computer communication error	
(outlet) error OA Outdoor temperature sensor error 15 Compressor temperature sensor error 1d 2-way valve temperature sensor error 1E 3-way valve temperature sensor error Outdoor heat exchanger temperature sensor (middle) error 20 Indoor manual auto switch abnormal 2A Power supply frequency detection error 17 IPM protection 18 CT error 1A Compressor location error 1b Outdoor fan error 1r Connected indoor unit abnormal Outdoor unit computer communication error	
15 Compressor temperature sensor error 1d 2-way valve temperature sensor error 1E 3-way valve temperature sensor error 29 Outdoor heat exchanger temperature sensor (middle) error 20 Indoor manual auto switch abnormal 2A Power supply frequency detection error 17 IPM protection 18 CT error 1A Compressor location error 1b Outdoor fan error 1F Connected indoor unit abnormal 1c Outdoor unit computer communication error	
1d 2-way valve temperature sensor error 1E 3-way valve temperature sensor error 29 Outdoor heat exchanger temperature sensor (middle) error 20 Indoor manual auto switch abnormal 2A Power supply frequency detection error 17 IPM protection 18 CT error 1A Compressor location error 1b Outdoor fan error 1F Connected indoor unit abnormal 1c Outdoor unit computer communication error	
1E 3-way valve temperature sensor error 29 Outdoor heat exchanger temperature sensor (middle) error 20 Indoor manual auto switch abnormal 2A Power supply frequency detection error 17 IPM protection 18 CT error 1A Compressor location error 1b Outdoor fan error 1F Connected indoor unit abnormal 1c Outdoor unit computer communication error	
29 Outdoor heat exchanger temperature sensor (middle) error 20 Indoor manual auto switch abnormal 2A Power supply frequency detection error 17 IPM protection 18 CT error 1A Compressor location error 1b Outdoor fan error 1F Connected indoor unit abnormal 1c Outdoor unit computer communication error	
20 Indoor manual auto switch abnormal 2A Power supply frequency detection error 17 IPM protection 18 CT error 1A Compressor location error 1b Outdoor fan error 1F Connected indoor unit abnormal 1c Outdoor unit computer communication error	
Power supply frequency detection error 17 IPM protection 18 CT error 1A Compressor location error 1b Outdoor fan error 1F Connected indoor unit abnormal 1c Outdoor unit computer communication error	
17 IPM protection 18 CT error 1A Compressor location error 1b Outdoor fan error 1F Connected indoor unit abnormal 1c Outdoor unit computer communication error	
18 CT error 1A Compressor location error 1b Outdoor fan error 1F Connected indoor unit abnormal 1c Outdoor unit computer communication error	
1A Compressor location error 1b Outdoor fan error 1F Connected indoor unit abnormal 1c Outdoor unit computer communication error	
1b Outdoor fan error 1F Connected indoor unit abnormal 1c Outdoor unit computer communication error	
1F Connected indoor unit abnormal 1c Outdoor unit computer communication error	
1c Outdoor unit computer communication error	
10 Indeer for chrormal	
12 Indoor fan abnormal	
0F Discharge temperature error	
24 Exessive high pressure protection on cooling	
2c 4-way valve abnormal	
16 Pressure switch abnormal	
2b Compressor temperature error	
19 Active filter abnormal	
25 PFC circuit error	

If "CO" appears in the unit number display, there is a remote controller error. Refer to the installation instruction sheet included with the remote controller.

STATIC PRESSURE **CHARACTERISTIC**

A CAUTION

static pressure mode, the static pressure mode may be changed to another mode automatically.

If the applicable static pressure does not match the

RECOMMENDED RANGE OF EXTERNAL STATIC PRESSURE 30Pa to 150Pa

1. STATIC PRESSURE MODE

It is necessary to set up a static pressure mode for each usage of static pressure. Determine the applicable range of static pressure in each mode

and wind volume, referring to the TECHNICAL MANUAL.

2. MODE SETTING It is possible to change the setting of static pressure mode. Refer to [5] FUNCTION SETTING and to the INSTALLATION INSTRUC-TION SHEET of remote controller for a setting method.

SPECIAL INSTALLATION METHODS

CAUTION When setting DIP switches, do not touch any other parts on the circuit board directly with

2 Be sure to turn off the main power. GROUP CONTROL SYSTEM

your bare hands.

A number of indoor units can be operated at the same time using a single remote controller.

(1) Wiring method (indoor unit to remote controller)


Remote controller wire (2) DIP switch setting (Indoor unit) Set the unit number of each indoor unit using DIP switch on the

indoor unit circuit board. (See following table and figure.)

DIP switch is normally set to make unit number No. 0.

Unit number	DIP SWITCH No.			
	1	2	3	4
0	OFF	OFF	OFF	OFF
1	ON	OFF	OFF	OFF
2	OFF	ON	OFF	OFF
3	ON	ON	OFF	OFF
4	OFF	OFF	ON	OFF
5	ON	OFF	ON	OFF
6	OFF	ON	ON	OFF
7	ON	ON	ON	OFF
8	OFF	OFF	OFF	ON
9	ON	OFF	OFF	ON
10	OFF	ON	OFF	ON
11	ON	ON	OFF	ON
12	OFF	OFF	ON	ON
13	ON	OFF	ON	ON
14	OFF	ON	ON	ON
15	ON	ON	ON	ON

Example: No. 3



control unit operations.

(2) Air filter removal and cleaning, and how to use the air (3) Give the operating and installation manuals to the customer.

CUSTOMER GUIDANCE

Explain the following to the customer in accordance with the operating manual:

ture adjustment, timer, air flow switching, and other remote

(1) Starting and stopping method, operation switching, tempera-

changed (the system returns to signal code A when the batteries in the remote control unit are replaced).

*(4) is applicable to using wireless remote control.

PART NO. 9374318193

1/15/07 2:47:01 PM

9374318193_B2.indd 2

For authorized service personnel only.

refer to the installation instruction sheet included with the indoor unit.

REFRIGERANT

HIS PRODUCT MUST ONLY BE INSTALLED OR SERVICED BY QUALIFIED PERSONNEL. This installation instruction sheet describes how to install the outdoor unit only. To install the indoor unit,

⚠ DANGER	This mark indicates procedures which, if improperly performed, are most likely to result in the death of or serious injury to the user or service personnel.
⚠ WARNING	This mark indicates procedures which, if improperly performed, might lead to the death or serious injury of the user.
⚠ CAUTION	This mark indicates procedures which, if improperly performed, might possibly result in personal harm to the user, or damage to property.

↑ DANGER

Never touch electrical components immediately after the power supply has been turned off. Electrical shock may occur. After turning off the power, always wait 5 minutes or more before touching electrical components

This air conditioner uses new refrigerant HFC (R410A).

The basic installation work procedures are the same as conventional refrigerant models However, pay careful attention to the following points:

) Since the working pressure is 1.6 times higher than that of conventional refrigerant models, some of the piping and installation and service tools are special. (See the table below.) Especially, when replacing a conventional refrigerant model with a new refrigerant R410A model, always replace the conventional piping and flare nuts with the R410A piping and flare nuts.

Models that use refrigerant R410A have a different charging port thread diameter to prevent erroneous charging with conventional refrigerant and for safety. Therefore, check beforehand. [The charging port thread diameter for R410A is 1/2 UNF 20 threads per inch.

3 Be more careful that foreign matter (oil, water, etc.) does not enter the piping than with refrigerant models. Also, when storing the piping, securely seal the openings by pinching, taping, etc.

When charging the refrigerant, take into account the slight change in the composition of the gas and liquid phases, and always charge from the liquid phase side whose composition is stable.

Special tools for R410A

Tool name	Contents of change		
	Pressure is high and cannot be measured with a conventional gauge. To prevent erroneous mixing of other		
Cause manifold	refrigerants, the diameter of each port has been changed.		
Gauge manifold	It is recommended the gauge with seals -0.1 to 5.3 MPa (-76 cmHg to 53 kgf/cm²) for high pressure0.1 to		
	3.8 MPa (-76 cmHg to 38 kgf/cm²) for low pressure.		
Charge hose	To increase pressure resistance, the hose material and base size were changed.		
Vacuum pump	A conventional vacuum pump can be used by installing a vacuum pump adapter.		
Gas leakage detector	Special gas leakage detector for HFC refrigerant R410A.		

↑ DANGER

Never touch electrical components immediately after the power supply has been turned off. Electrical shock may occur. After

⚠ WARNING

Connect the indoor unit and outdoor unit with the room air conditioner piping and cords available standards parts. This

installation instruction sheet describes the correct connections using the installation set available from our standard

For the room air conditioner to operate satisfactorily, install it as outlined in this installation instruction sheet

Installation work must be performed in accordance with national wiring standards by authorized personnel only.

turning off the power, always wait 5 minutes or more before touching electrical components

Do not purge the air with refrigerants but use a vacuum pump to vacuum the installation

· After installation, explain correct operation to the customer, using the operating manual.

Using the same vacuum pump for different refrigerants may damage the vacuum pump or the unit.

It is necessary to use seamless copper pipes and it is desirable that the amount of residual oil is less than 40 mg/10 m. Do not use copper pipes having a collapsed, deformed or discolored portion (especially on the interior surface). Otherwise, the expansion valve or capillary tube may become blocked with contaminants. As an air conditioner using R410A incurs pressure higher than when using conventional refrigerant, it is necessary to choose adequate materials. Thicknesses of copper pipes used with R410A are as shown in the table. Never

Do not turn on the power until all installation work is complete.

There is not extra refrigerant in the outdoor unit for air purging.

(1) Use a clean gauge manifold and charging hose for R410A exclusively.

Be careful not to scratch the room air conditioner when handling it.

Thicknesses of Annealed Copper Pipes (R410A)

Pipe outside diameter	Thickness
6.35 mm (1/4 in.)	0.80 mm
9.52 mm (3/8 in.)	0.80 mm
12.70 mm (1/2 in.)	0.80 mm
15.88 mm (5/8 in.)	1.00 mm
19.05 mm (3/4 in.)	1.20 mm

1. LIMITATION OF REFRIGERANT PIPING LENGTH

↑ CAUTION

The total maximum pipe lengths and height difference of this product are shown in the table If the units are further apart than this, correct operation cannot be guaranteed.

Model Type	Pipe length		Maximum height (between indoor
	MAX.	MIN.	and outdoor)
12,000, 14,000 18,000 BTU/h class	25 m	5 m	15 m
24,000 BTU/h class	30 m	5 III	20 m

2. SELECTING PIPE SIZES

The diameters of the connection pipes differ according to the capacity of Refer to the following table for the proper diameters of the connection

Capacity of indoor unit	Gas pipe size (thickness) [mm]	Liquid pipe size (thickness) [mm]
12	ø9.52 (0.8)	ø6.35 (0.8)
14, 18	ø12.7 (0.8)	ø6.35 (0.8)
24	ø15.88 (1.0)	ø6.35 (0.8)

Operation cannot be guaranteed if the correct combina tion of pipes, valves, etc., is not used to connect the in door and outdoor units.

3. HEAT INSULATION AROUND CONNECTION PIPES REQUIREMENTS

⚠ CAUTION

Install heat insulation around both the gas and liquid pipes

Failure to do so may cause water leaks. Use heat insulation with heat resistance above 120 °C. (Re verse cycle model only) In addition, if the humidity level at the installation location of the refrigerant piping is expected to exceed 70%, install heat insulation around the refrigerant piping. If the expected humidity level is 70-80%, use heat insulation that

is 15 mm or thicker and if the expected humidity exceeds 80%, use heat insulation that is 20 mm or thicker. If heat insulation is used that is not as thick as specified condensation may form on the surface of the insulation In addition, use heat insulation with heat conductivity of 0.045 W/(m·K) or less (at 20 °C).

Connect the connection pipes according to "2 CONNECTING THE PIP-ING" in this installation instruction sheet.

4. ELECTRICAL REQUIREMENT

 Use conformed cord with Type 245 IEC57 Electric wire size and fuse capacity:


Danier annulu aand (mm²)	MAX.	4.0
Power supply cord (mm²)	MIN.	3.5
Connection cord (mm²)	MAX.	2.5
Connection cord (mm-)	MIN.	1.5
Fuse capacity (A) OUTDOOR UNIT 25		

poles nearby the units. (both indoor unit and outdoor unit) Always make the air conditioner power supply a special branch circuit and provide a special breaker.

INSTALLATION PROCEDURE


OUTDOOR UNIT INSTALLATION

1. OUTDOOR UNIT PROCESSING (1) Outdoor unit to be fasten with bolts at the four places indicated by the arrows without fail.



available M10 bolt, nut and washer.)


(3) Since the drain water flows out of the outdoor unit during heating operation, install the drain pipe and connect it to a commercial 16 mn hose. (Reverse cycle model only) (4) When installing the drain pipe, plug all the holes other than the drain



⚠ CAUTION

When the outdoor temperature is 0 °C or less, do not use the accessory drain pipe and drain cap. If the drain pipe and drain cap are used, the drain water in the pipe may freeze in extremely cold weather. (Reverse cycle

In the area with heavy snowfall, if the intake and outlet of outdoor unit is blocked with snow, it might become difficult to get warm and it is likely to cause of the breakdown. Please construct a canopy and a pedestal or place the unit on a high stand (local configured).



 Set the unit on a strong stand, such as one made of concrete blocks to minimize shock and vibration. Do not set the unit directly on the ground because it will cause trouble

When there are obstacles at the back and front sides.


· When there are obstacles at the back side with the installation of

Connector cover removal

Installing the connector cover (1) After inserting the two front hooks, then insert the rear hook. (2) Tighten the tapping screws.

1 Install the unit where it will not be tilted by more than 5°. When installing the outdoor unit where it may exposed to strong wind, fasten it securely.

⚠ WARNING



CONNECTING THE PIPE

⚠ CAUTION


Do not use mineral oil on flared part. Prevent mineral oil from getting into the system as this would reduce the lifetime of the units.

While welding the pipes, be sure to blow dry nitrogen gas through them.

(1) Cut the connection pipe to the necessary length with a pipe cutter. (2) Hold the pipe downward so that cuttings will not enter the pipe and remove the burrs.

(3) Insert the flare nut (always use the flare nut attached to the indoor and outdoor units respectively) onto the pipe and perform the flare processing with a flare tool. Use the special R410A flare tool, or the conventional flare tool

Check if [L] is flared uniformly and is not cracked or scratched



Flare tool for R410A, clutch tv

6.35 mm (1/4 in.)	
9.52 mm (3/8 in.)	
12.70 mm (1/2 in.)	0 to 0.5
15.88 mm (5/8 in.)	
19.05 mm (3/4 in.)	
Pipe outside diameter	Dimension B -0.4 (mm)
6.35 mm (1/4 in.)	9.1

9.52 mm (3/8 in.)	13.2

Dimension B -0.4 (mm)
9.1
13.2
16.6
19.7
24.0

A should be approximately 0.5 mm more than indicated in the table (for flaring with R410A flare tools) to achieve the specified flaring. Use a thick-

ss gauge to measure the dimension A.				
h across flats	Pipe outside diameter	Width across flats of Flare nut		
	6.35 mm (1/4 in.)	17 mm		
	9.52 mm (3/8 in.)	22 mm		
	12.70 mm (1/2 in.)	26 mm		
~	15.88 mm (5/8 in.)	29 mm		
	19.05 mm (3/4 in.)	36 mm		

2. BENDING PIPES

Do not bend the pipes in an angle more than 90°. When pipes are repeatedly bend or stretched, the material will harden. making it difficult to bend or stretch them any more. Do not bend or stretch the pines more than three times

⚠ CAUTION

To prevent breaking of the pipe, avoid sharp bends. Bend the pipe with a radius of curvature of 150 mm or over

If the pipe is bent repeatedly at the same place, it will


3. CONNECTION PIPES


(1) Detach the caps and plugs from the pipes.

Z. CAUTION
Be sure to apply the pipe against the port on the indo unit and outdoor unit correctly. If the centering is imprope the flare nut cannot be tightened smoothly. If the flare n is forced to turn, the threads will be damaged.

Do not remove the flare nut from the indoor unit pipe until immediately before connecting the connection pipe.

(2) Centering the pipe against port on the indoor unit, turn the flare nut





⚠ CAUTION Hold the torque wrench at its grip, keeping it in the right

angle with the pipe, in order to tighten the flare nut correctly.	
Flare nut Tightening torque	
6.35 mm (1/4 in.) dia.	16 to 18 N·m (160 to 180 kgf·cm)
9.52 mm (3/8 in.) dia.	30 to 42 N·m (300 to 420 kgf·cm)
12.70 mm (1/2 in.) dia.	49 to 61 N·m (490 to 610 kgf·cm)
15.88 mm (5/8 in.) dia.	63 to 75 N·m (630 to 750 kgf·cm)
19.05 mm (3/4 in.) dia.	90 to 110 N·m (900 to 1100 kgf·cm)

4. HOW TO USE ADAPTER (Connection ports of outdoor unit) X 12000BTU model only

 When using the ADAPTER, be careful not to overtighten the nut, or the smaller pipe may be damaged.

Use appropriate wrenches to avoid damaging the connection thread by

Apply wrenches on both of flare nut (local part), and ADAPTER to tighten

ø12.7 mm → ø9.52 mm 50 to 62 [N·m] (500 to 620 kgf·cm)

⚠ CAUTION

② Refrigerant for purging the air is not charged in the

3 Refrigerant must not be discharged into atmosphere

Use a vacuum pump, gauge manifold and charge hose

for R410A exclusively. Using the same vacuum for different refrigerants may damage the vacuum pump or

After connecting the piping, check the joints for gas

Gas leak checks are performed using either vacuum or nitrogen gas, so

(2) Remove the cap of 3-way valve, and connect the gauge manifold

(5) Check that the compound pressure gauge reads -0.1 MPa (76 cmHg),

(6) At the end of pump down, close the valve of the gauge manifold fully

(7) Disconnect the charge hose from the 3-way valve charging port.

(8) Remove the blank caps, and fully open the spindles of the 2-way and

(9) Tighten the blank caps and charging port cap of the 2-way valve and

(2) Remove the cap of 3-way valve, and connect the gauge manifold charge hoses to the charging port of the 3-way valve.

(3) Pressurize with nitrogen gas using the 3-way valve charging port.

(4) Do not pressurize up to the specified pressure all at once but do so

five minutes and then check for any decrease in pressure. ② Increase the pressure up to 1.5 Mpa (15 kgf/cm²), let it sit for

1) Increase the pressure up to 0.5 Mpa (5 kgf/cm²), let it sit for about

about five minutes and then check for any decrease in pressure.

③ Increase the pressure up to the specified pressure (the pressure

sure then it is satisfactory. If a pressure decrease is confirmed, there

is a leak, so it is necessary to specify the leak location and make

designed for the product) and then make a note of it.

(5) Let it sit at the specified pressure and if there is no decrease in pres

(It checks that leave as it is for about 10 minutes, and a needle does

charge hoses to the charging port of the 3-way valve.

leakage with gas leak detector or soapy water.

CHECKING GAS LEAKAGE AND PURGING AIR

select the proper one depending on the situation.

(1) Check if the piping connections are secure.

(3) Open the valve of the gauge manifold fully.

3-way valves with a hexagon wrench.

3-way valve to the specified torque.

(1) Check if the piping connections are secure.

Checking gas leaks with nitrogen gas:

[torque: 6 to 7 N·m (60 to 70 kgf·cm)].

(4) Operate the vacuum pump and start pump down.

operate the vacuum pump for at least 1 hour.

Checking gas leaks with vacuum

① Always use a vacuum pump to purge the air.

outdoor unit at the factory.

overtightening the flare nut.

5. VACUUM

- (9) Check that the compound pressure gauge reads -0.1 MPa (76 cmHg), Apply a coat of refrigeration oil to the threaded connection port of the outdoor unit where the flare nut comes in.
 - and stop the vacuum pump.

3-way valves with a hexagon wrench.

(8) Operate the vacuum pump and start pump down.

Open the valve of the gauge manifold fully.


operate the vacuum pump for at least 1 hour. (10) At the end of pump down, close the valve of the gauge manifold fully

(6) Discharge the nitrogen gas and starting removing the gas with a

- (11) Disconnect the charge hose from the 3-way valve charging port. 12) Remove the blank caps, and fully open the spindles of the 2-way and
- [torque: 6 to 7 N·m (60 to 70 kgf·cm)]. (13) Tighten the blank caps and charging port cap of the 2-way valve and 3-way valve to the specified torque.

Tightening torque 6.35 mm (1/4 in.) 20 to 25 N·m (200 to 250 kgf·cm) 9.52 mm (3/8 in.) 20 to 25 N·m (200 to 250 kgf·cm 12.70 mm (1/2 in.) 28 to 32 N·m (280 to 320 kgf·cm) 15.88 mm (5/8 in.) 30 to 35 N·m (300 to 350 kgf·cm) 19.05 mm (3/4 in.) 35 to 40 N·m (350 to 400 kgf·cm)

Charging port cap 12.5 to 16 N·m (125 to 160 kgf·cm)



6. ADDITIONAL CHARGE

For the additional amount, see the table below.

Refrigerant suitable for a piping length of 15 m is charged in the outdoor unit at the factory. When the piping is longer than 15 m, additional charging is necessary.

15 m 20 m 25 m 30 m None 100 g 200 g **24,000 BTU/h class** None 100 g 200 g 300 g

⚠ CAUTION

When moving and installing the air conditioner, do not mix gas other than the specified refrigerant (R410A) inside the refrigerant cycle.

When charging the refrigerant R410A, always use an electronic balance for refrigerant charging (to measure the refrigerant by weight).

When charging the refrigerant, take into account the slight change in the composition of the gas and liquid phases, and always charge from the liquid phase side whose composi-

Add refrigerant from the charging valve after the com pletion of the work.

) If the units are further apart than the maximum pipe length, correct operation can not be guaranteed.

TEST RUNNING

1. Make a TEST RUN in accordance with the

(1) Is operation of each button on the remote control unit normal?

(5) Is there any abnormal noise and vibration during operation?

(1) Is there any abnormal noise and vibration during operation?

(2) Will noise, wind, or drain water from the unit disturb the neighbors?

Do not operate the air conditioner in the test running state for a long

· For the operation method, refer to the operating manual and perform

When a malfunction occurs in the outdoor unit, the LED on the circuit

board lights to indicate the error. Refer to the following table for the

LED

on 0.1 sec/off 0.1 se

on 0.5 sec/off 0.5 sec

on 2.0 sec/off 2.0 sec

on 0.1 sec/off 2.0 sec

on 5.0 sec/off 5.0 sec

on 5.0 sec/off 0.1 sec

on 1.0 sec/off 1.0 sec

(2) Does each lamp light normally?

(4) Is the drain normal?

(2) OUTDOOR UNIT

(3) Is there any gas leakage?

Thermistor malfunction

Current surge protection

AM voltage abnormality

CT abnormality

an malfunction

2. OUTDOOR UNIT LEDS

description of each error according to the LED.

Error contents

(3) Do the air flow-direction louver operate normally?

installation instruction sheet for the indoor unit

Select installation locations that can properly support the weight of the indoor and outdoor units. Install the units securely s that they do not topple or fall.

3 If children under 10 years old may approach the unit, take preventive measures so that they cannot reach the unit.


When installing the outdoor unit where it may exposed to strong wind, fasten it securely.

Decide the mounting position with the customer as follows (1) Install the outdoor unit in a location which can withstand the weight of the unit and vibration, and which can install horizontally.


(If necessary, install a blind that does not interfere with the airflow.)

herefore, install the outdoor unit in a place where the drain water flow will not be obstructed. (Reverse cycle model only) (6) Do not install the unit where strong wind blows or where it is very dusty.

(7) Do not install the unit where people pass.) Install the outdoor unit in a place where it will be free from being dirty or getting wet by rain as much as possible.



• When there are obstacles at the back, side(s), and top.



* If the space is larger than that is stated, the condition will be the

↑ WARNING

Before turning on, verify that the voltage is within the

cial receptacle to supply power to the air conditioner Use a special branch circuit breaker and receptacl

so that the air conditioner can be operated safely and

accordance with the related laws and regulations and electric company standards. The circuit breaker is installed in the permanent wir-


ing. Always use a circuit that can trip all the poles of

the wiring and has an isolation distance of at least

insufficient, change the contracted capacity.

When the voltage is low and the air conditioner is difficult to start, contact the power company the voltage raised.

ELECTRICAL WIRING




Always connect the ground wire.


electric leakage may occur.)

HOW TO CONNECT WIRING TO THE

1) Cut the wire end with a wire cutter or wire-cutting pliers, then strip the insulation to about 10 mm to expose the strand wiring.

1. CONNECTION DIAGRAMS







(1) Remove the outdoor unit connector cover. (2) Bend the end of the cord as shown in the figure. (3) Connect the end of the connection cord fully into the terminal block.

minor adjustments.


3. OUTDOOR UNIT

(4) Fasten the sheath with a cord clamp. (5) Install the connector cover





Connection cord wiring Run the connection cord to the rear of the outdoor unit within the (A) range of the arrows shown in the figure.



⚠ CAUTION

1) Match the terminal block numbers and connection cord colors with those of the indoor unit. Erroneous wiring may cause burning of the electric

② Connect the connection cords firmly to the termina block. Imperfect installation may cause a fire.

electric leakage may occur.) 4 Securely earth the power cord plug.

3 Always fasten the outside covering of the connection cord with the cord clamp. (If the insulator is chafed,

⑤ Do not use the earth screw for an external connector

Only use for interconnection between two units.

(1) Starting and stopping method, operation switching, temperature

(2) Air filter removal and cleaning.

CUSTOMER GUIDANCE

Explain the following to the customer in accordance with the operating

Compressor temperature protection (permanent stop) on 2.0 sec/off 5.0 sec

PFC surge protection (permanent stop) on 5.0 sec/off 2.0 sec

(3) Give the operating manual and installation instruction sheet to the

① If refrigerant leaks while work is being carried out, ventilate the area. If the refrigerant comes in contact with a flame, it

· Let the customer keep this installation instruction sheet because it is used when the room air conditioner is serviced or moved.

STANDARD PARTS The following installation parts are furnished.

Also, do not use an extension cord.

Use a vacuum pump for R410A exclusively.

Name and Shape Adapter assy 1 12.7 mm → 9.52 mm

Q'ty Application For outdoor unit drain For use when connecting

SELECTING THE MOUNTING POSITION

Do not install where there is the danger of combustible gas leakage.


Do not install the unit near heat source of heat, steam, or flammable gas

MARNING

2) Provide the indicated space to ensure good airflow. (3) If possible, do not install the unit where it will be exposed to direct sunlight.

(4) Do not install the unit near a source of heat, steam, or flammable gas. (5) During heating operation, drain water flows from the outdoor unit.

(9) Install the unit where connection to the indoor unit is easy. When there are obstacles at the back side.



same as that there are no obstacles

The rated voltage of this product is 220-240 V a.c.

POWER

198 V to 264 V range. Always use a special branch circuit and install a spe-

matched to the capacity of the air conditioner. (Install in accordance with standard.) Perform wiring work in accordance with standards

Install a leakage special branch circuit breaker in

3 mm between the contacts of each pole.


⚠ CAUTION The power source capacity must be the sum of the air conditioner current and the current of other electrical appliances. When the current contracted capacity is


⚠ WARNING Before starting work, check that power is not being Match the terminal board numbers and connection Erroneous wiring may cause burning of the electric

Always fasten the outside covering of the connection

cord with the cord clamp. (If the insulator is chafed.

 Using a screwdriver, remove the terminal screw(s) on the termina (3) Using a round terminal fastener or pliers, securely clamp a round terminal to each stripped wire end. (4) Position the round terminal wire, and replace and tighten the





Keep the earth wire longer than the other wires

adjustment, timer, air flow adjustment, and other remote control unit

06M413 9377863034

INSTALLATION INSTRUCTION **SHEET**

⚠ CAUTION **R410A**

REFRIGERANT HIS PRODUCT MUST ONLY BE INSTALLED OR SERVICED BY QUALIFIED PERSONNEL.

(PART NO. 9377863010)

For authorized service personnel only.

This installation instruction sheet describes how to install the outdoor unit only. To install the indoor unit, refer to the installation instruction sheet included with the indoor unit.

⚠ DANGER	This mark indicates procedures which, if improperly performed, are most likely to result in the death of or serious injury to the user or service personnel.
⚠ WARNING	This mark indicates procedures which, if improperly performed, might lead to the death or serious injury of the user.
⚠ CAUTION	This mark indicates procedures which, if improperly performed, might possibly result in personal harm to the user, or damage to property.

This air conditioner uses new refrigerant HFC (R410A).

The basic installation work procedures are the same as conventional refrigerant models. lowever, pay careful attention to the following points:

- Since the working pressure is 1.6 times higher than that of conventional refrigerant models, some of the piping and installation and service tools are special. (See the table below.) Especially, when replacing a conventional refrigerant model with a new refrigerant R410A model, always replace the conventional piping and flare nuts with the R410A piping and flare nuts.
- Models that use refrigerant R410A have a different charging port thread diameter to prevent erroneous charging with conventional refrigerant and for safety. Therefore, check beforehand. [The charging port thread diameter for R410A is
- Be more careful that foreign matter (oil, water, etc.) does not enter the piping than with refrigerant models. Also, when storing the piping, securely seal the openings by pinching, taping, etc.
-) When charging the refrigerant, take into account the slight change in the composition of the gas and liquid phases, and always charge from the liquid phase side whose composition is stable.

Special tools for R410A

Tool name	Contents of change	
	Pressure is high and cannot be measured with a conventional gauge. To prevent erroneous mixing of other	
Gauge manifold	refrigerants, the diameter of each port has been changed.	
	It is recommended the gauge with seals –0.1 to 5.3 MPa (–76 cmHg to 53 kgf/cm²) for high pressure. –0.1 to	
	3.8 MPa (-76 cmHg to 38 kgf/cm²) for low pressure.	
Charge hose To increase pressure resistance, the hose material and base size were changed.		
Vacuum pump A conventional vacuum pump can be used by installing a vacuum pump adapter.		
Gas leakage detector	Special gas leakage detector for HFC refrigerant R410A.	

⚠ DANGER

Never touch electrical components immediately after the power supply has been turned off. Electrical shock may occur. After

⚠ WARNING

Connect the indoor unit and outdoor unit with the room air conditioner piping and cords available standards parts. This

installation instruction sheet describes the correct connections using the installation set available from our standard

For the room air conditioner to operate satisfactorily, install it as outlined in this installation instruction sheet.

Installation work must be performed in accordance with national wiring standards by authorized personnel only.

① If refrigerant leaks while work is being carried out, ventilate the area. If the refrigerant comes in contact with a flame, it

• Let the customer keep this installation instruction sheet because it is used when the room air conditioner is serviced or moved.

turning off the power, always wait 5 minutes or more before touching electrical components

Do not purge the air with refrigerants but use a vacuum pump to vacuum the installation.

· After installation, explain correct operation to the customer, using the operating manual.

Application

For outdoor unit drain piping work

⑤ Using the same vacuum pump for different refrigerants may damage the vacuum pump or the unit.

It is necessary to use seamless copper pipes and it is desirable that the amount of residual oil is less than 40 mg/10 m. Do not use copper pipes having a collapsed, deformed or discolored portion (especially on the interior surface). Otherwise, the expansion valve or capillary tube may become blocked with contaminants. As an air conditioner using R410A incurs pressure higher than when using conventional refrigerant, it is necessary to choose adequate materials. Thicknesses of copper pipes used with R410A are as shown in the table. Never

Do not turn on the power until all installation work is complete.

There is not extra refrigerant in the outdoor unit for air purging.

(1) Use a clean gauge manifold and charging hose for R410A exclusively.

Be careful not to scratch the room air conditioner when handling it.

Also, do not use an extension cord.

8 Use a vacuum pump for R410A exclusively.

STANDARD PARTS

The following installation parts are furnished.

Drain pipe

9377863010 IM.p65

Name and Shape Q'ty

Thicknesses of Annealed Copper Pipes (R410A)

Pipe outside diameter	Thickness
6.35 mm (1/4 in.)	0.80 mm
9.52 mm (3/8 in.)	0.80 mm
12.70 mm (1/2 in.)	0.80 mm
15.88 mm (5/8 in.)	1.00 mm
19.05 mm (3/4 in.)	1.20 mm

1. LIMITATION OF REFRIGERANT PIPING LENGTH

↑ CAUTION The total maximum pipe lengths and height difference of this product are shown in the table. If the units are further apart than this, correct operation

Maximum heigh Pipe length and outdoor) 18,000 BTU/h class 25 m 24,000 BTU/h class 30 m

2. SELECTING PIPE SIZES

cannot be guaranteed.

The diameters of the connection pipes differ according to the capacity of the indoor unit. Refer to the following table for the proper diameters of the connection

Capacity of indoor unit	Gas pipe size (thickness) [mm]	Liquid pipe size (thickness) [mm]
18	ø12.7 (0.8)	ø6.35 (0.8)
24	ø15.88 (1.0)	ø6.35 (0.8)

Operation cannot be guaranteed if the correct combina tion of pipes, valves, etc., is not used to connect the in door and outdoor units.

3. HEAT INSULATION AROUND CONNECTION PIPES REQUIREMENTS

⚠ CAUTION

Install heat insulation around both the gas and liquid pipes

Failure to do so may cause water leaks. Use heat insulation with heat resistance above 120 °C. (Reverse cycle model only) In addition, if the humidity level at the installation location of the refrigerant piping is expected to exceed 70%, install heat insulation around the refrigerant piping. If the expected humidity level is 70-80%, use heat insulation that is 15 mm or thicker and if the expected humidity exceeds 80%, use heat insulation that is 20 mm or thicker. If heat insulation is used that is not as thick as specified condensation may form on the surface of the insulation In addition, use heat insulation with heat conductivity o

Connect the connection pipes according to "2 CONNECTING THE PIP-ING" in this installation instruction sheet

4. ELECTRICAL REQUIREMENT

0.045 W/(m·K) or less (at 20 °C).

 Use conformed cord with Type 245 IEC57. Electric wire size and fuse capacity:

Power supply cord (mm²)	MAX.	4.0
	MIN.	3.5
Connection cord (mm²)	MAX.	2.5
	MIN.	1.5
Fuse capacity (A)	OUTDOOR UNIT	25


- Install the disconnect device with a contact gap of at least 3 mm nearby
- Always make the air conditioner power supply a special branch circuit and provide a special breaker.

INSTALLATION PROCEDURE


OUTDOOR UNIT

INSTALLATION 1. OUTDOOR UNIT PROCESSING

(2) Fix securely with bolts on a solid block. (Use 4 sets of commercially available M10 bolt, nut and washer.)




(3) Since the drain water flows out of the outdoor unit during heating operation, install the drain pipe and connect it to a commercial 16 mm hose. (Reverse cycle model only) (4) When installing the drain pipe, plug all the holes other than the drain



When the outdoor temperature is 0 °C or less, do not

use the accessory drain pipe and drain cap. If the drain pipe and drain cap are used, the drain water in the pipe may freeze in extremely cold weather. (Reverse cycle

In the area with heavy snowfall, if the intake and outlet of outdoor unit is blocked with snow, it might become difficult to get warm and it is likely to cause of the breakdown. Please construct a canopy and a pedestal or place the unit on a high stand (local configured).



 Set the unit on a strong stand, such as one made of concrete blocks to minimize shock and vibration.

Do not set the unit directly on the ground because it will cause trouble

When there are obstacles at the back and front sides.

When there are obstacles at the back side with the installation of


Connector cover removal

Installing the connector cover

(1) After inserting the two front hooks, then insert the rear hook. (2) Tighten the tapping screws.

⚠ WARNING

1 Install the unit where it will not be tilted by more than 5° When installing the outdoor unit where it may exposed to strong wind, fasten it securely.



CONNECTING THE PIPE

⚠ CAUTION


Do not use mineral oil on flared part. Prevent mineral oil from getting into the system as this would reduce the lifetime of the units.

While welding the pipes, be sure to blow dry nitrogen gas through them.

(1) Cut the connection pipe to the necessary length with a pipe cutter. (2) Hold the pipe downward so that cuttings will not enter the pipe and remove the burrs. (3) Insert the flare nut (always use the flare nut attached to the indoor

and outdoor units respectively) onto the pipe and perform the flare processing with a flare tool. Use the special R410A flare tool, or the conventional flare tool

Check if [L] is flared uniformly and is not cracked or scratched



Pipe outside diameter	Flare tool for R410A, clutch type
6.35 mm (1/4 in.)	
9.52 mm (3/8 in.)	
12.70 mm (1/2 in.)	0 to 0.5
15.88 mm (5/8 in.)	
10.05 (0/4 !)	
19.05 mm (3/4 in.)	
Pipe outside diameter	Dimension B -0.4 (mm)
, ,	Dimension B ⁰ _{-0.4} (mm) 9.1
Pipe outside diameter	
Pipe outside diameter 6.35 mm (1/4 in.)	9.1

19.7

When using conventional flare tools to flare R410A pipes, the dimension A should be approximately 0.5 mm more than indicated in the table (for flaring with R410A flare tools) to achieve the specified flaring. Use a thickness gauge to measure the dimension A

Width across flats of Flare nut 6.35 mm (1/4 in.) 17 mm 9.52 mm (3/8 in.) 22 mm 12.70 mm (1/2 in.) 26 mm 15.88 mm (5/8 in.) 29 mm 19.05 mm (3/4 in.)

2. BENDING PIPES

The pipes are shaped by your hands. Be careful not to collapse them. Do not bend the pipes in an angle more than 90°. When pipes are repeatedly bend or stretched, the material will harden. making it difficult to bend or stretch them any more. Do not bend or stretch the pipes more than three times.

To prevent breaking of the pipe, avoid sharp bends. Bend the pipe with a radius of curvature of 150 mm or

If the pipe is bent repeatedly at the same place, it will

3. CONNECTION PIPES

Outdoor unit (1) Detach the caps and plugs from the pipes

⚠ CAUTION


Be sure to apply the pipe against the port on the indoor unit and outdoor unit correctly. If the centering is improper, the flare nut cannot be tightened smoothly. If the flare nut is forced to turn, the threads will be dam-

Do not remove the flare nut from the indoor unit pipe until immediately before connecting the connection

(2) Centering the pipe against port on the indoor unit, turn the flare nut with your hand.



(3) When the flare nut is tightened properly by your hand, use a torque wrench to finally tighten it.



↑ CAUTION Hold the torque wrench at its grip, keeping it in the right angle with the pipe, in order to tighten the flare nu correctly.

Flare nut	Tightening torque
6.35 mm (1/4 in.) dia.	16 to 18 N·m (160 to 180 kgf·cm)
9.52 mm (3/8 in.) dia.	30 to 42 N·m (300 to 420 kgf·cm)
12.70 mm (1/2 in.) dia.	49 to 61 N·m (490 to 610 kgf·cm)
15.88 mm (5/8 in.) dia.	63 to 75 N·m (630 to 750 kgf·cm)
19.05 mm (3/4 in.) dia.	90 to 110 N·m (900 to 1100 kgf·cm)

⚠ CAUTION

4. VACUUM

(1) Always use a vacuum pump to purge the air. ② Refrigerant for purging the air is not charged in the

outdoor unit at the factory. ③ Refrigerant must not be discharged into atmosphere

Use a vacuum pump, gauge manifold and charge hose for R410A exclusively. Using the same vacuum for different refrigerants may damage the vacuum pump or

After connecting the piping, check the joints for gas

leakage with gas leak detector or soapy water.

CHECKING GAS LEAKAGE AND PURGING AIR

Gas leak checks are performed using either vacuum or nitrogen gas, so select the proper one depending on the situation.

Checking gas leaks with vacuum (1) Check if the piping connections are secure

(2) Remove the cap of 3-way valve, and connect the gauge manifold charge hoses to the charging port of the 3-way valve. (3) Open the valve of the gauge manifold fully.

(4) Operate the vacuum pump and start pump down.

(5) Check that the compound pressure gauge reads -0.1 MPa (76 cmHg), operate the vacuum pump for at least 1 hour. (6) At the end of pump down, close the valve of the gauge manifold fully

and stop the vacuum pump. (It checks that leave as it is for about 10 minutes, and a needle does not return.) (7) Disconnect the charge hose from the 3-way valve charging port.

(8) Remove the blank caps, and fully open the spindles of the 2-way and 3-way valves with a hexagon wrench [torque: 6 to 7 N·m (60 to 70 kgf·cm)] Tighten the blank caps and charging port cap of the 2-way valve and

3-way valve to the specified torque. Checking gas leaks with nitrogen gas:

(1) Check if the piping connections are secure.

(2) Remove the cap of 3-way valve, and connect the gauge manifold

charge hoses to the charging port of the 3-way valve. (3) Pressurize with nitrogen gas using the 3-way valve charging port. (4) Do not pressurize up to the specified pressure all at once but do so

① Increase the pressure up to 0.5 Mpa (5 kgf/cm²), let it sit for about five minutes and then check for any decrease in pressure. ② Increase the pressure up to 1.5 Mpa (15 kgf/cm²), let it sit for about five minutes and then check for any decrease in pressure

designed for the product) and then make a note of it. (5) Let it sit at the specified pressure and if there is no decrease in pressure then it is satisfactory. If a pressure decrease is confirmed, there is a leak, so it is necessary to specify the leak location and make

③ Increase the pressure up to the specified pressure (the pressure

(6) Discharge the nitrogen gas and starting removing the gas with a

7) Open the valve of the gauge manifold fully.


(8) Operate the vacuum pump and start pump down. (9) Check that the compound pressure gauge reads -0.1 MPa (76 cmHg), operate the vacuum pump for at least 1 hour.

(10) At the end of pump down, close the valve of the gauge manifold fully and stop the vacuum pump. (11) Disconnect the charge hose from the 3-way valve charging port

12) Remove the blank caps, and fully open the spindles of the 2-way and 3-way valves with a hexagon wrench. [torque: 6 to 7 N·m (60 to 70 kgf·cm)].

(13) Tighten the blank caps and charging port cap of the 2-way valve and 3-way valve to the specified torque.





5. ADDITIONAL CHARGE

Refrigerant suitable for a piping length of 15 m is charged in the outdoor unit at the factory. When the piping is longer than 15 m, additional charging is necessary. For the additional amount, see the table below

 Pipe length
 15 m
 20 m
 25 m
 30 m
 18,000 BTU/h class None 100 g 200 g

24,000 BTU/h class None 100 g 200 g 300 g

⚠ CAUTION

When moving and installing the air conditioner, do not mix gas other than the specified refrigerant (R410A) inside the refrigerant cycle.

When charging the refrigerant R410A, always use an electronic balance for refrigerant charging (to measure the refrigerant by weight).

When charging the refrigerant, take into account the slight change in the composition of the gas and liquid phases, and always charge from the liquid phase side whose composi-

Add refrigerant from the charging valve after the com pletion of the work.

) If the units are further apart than the maximum pipe length, correct operation can not be guaranteed.

SELECTING THE MOUNTING POSITION

Select installation locations that can properly support the weight of the indoor and outdoor units. Install the units securely so that they do not topple or fall.

⚠ CAUTION

Do not install where there is the danger of combustible gas leakage.


When installing the outdoor unit where it may exposed to strong wind, fasten it securely.

(1) Install the outdoor unit in a location which can withstand the weight of the unit and vibration, and which can install horizontally.


(3) If possible, do not install the unit where it will be exposed to direct sunlight. (If necessary, install a blind that does not interfere with the airflow.)

(5) During heating operation, drain water flows from the outdoor unit.

(9) Install the unit where connection to the indoor unit is easy.



• When there are obstacles at the back, side(s), and top.



* If the space is larger than that is stated, the condition will be the same as that there are no obstacles.

⚠ WARNING

Do not install the unit near heat source of heat, steam, or flammable gas

3 If children under 10 years old may approach the unit, take preventive measures so that they cannot reach the unit.

MARNING


) Install the outdoor unit in a place where it will be free from being dirty or getting wet by rain as much as possible.


Decide the mounting position with the customer as follows:

2) Provide the indicated space to ensure good airflow.

(4) Do not install the unit near a source of heat, steam, or flammable gas.

herefore, install the outdoor unit in a place where the drain water flow will not be obstructed. (Reverse cycle model only) (6) Do not install the unit where strong wind blows or where it is very dusty. (7) Do not install the unit where people pass.





15.88 mm (5/8 in.)

19.05 mm (3/4 in.)

↑ WARNING The rated voltage of this product is 220-240 V a.c. Before turning on, verify that the voltage is within the

POWER

198 V to 264 V range. Always use a special branch circuit and install a special receptacle to supply power to the air conditioner

matched to the capacity of the air conditioner. (Install in accordance with standard.) Perform wiring work in accordance with standards so that the air conditioner can be operated safely and

Use a special branch circuit breaker and receptacl

accordance with the related laws and regulations and electric company standards. The circuit breaker is installed in the permanent wiring. Always use a circuit that can trip all the poles of

the wiring and has an isolation distance of at least


Install a leakage special branch circuit breaker in

∴ CAUTION

3 mm between the contacts of each pole.

) The power source capacity must be the sum of the air conditioner current and the current of other electrical appliances. When the current contracted capacity is insufficient, change the contracted capacity.

When the voltage is low and the air conditioner is difficult to start, contact the power company the voltage raised.



⚠ WARNING Before starting work, check that power is not being supplied to the indoor unit and outdoor unit.

cord colors with those of the outdoor unit.

Always connect the ground wire.

28/7/06, 15:26

Connect the connection cords firmly to the terminal board. Imperfect installation may cause a fire. Always fasten the outside covering of the connection cord with the cord clamp. (If the insulator is chafed. electric leakage may occur.)


Match the terminal board numbers and connection

Erroneous wiring may cause burning of the electric


HOW TO CONNECT WIRING TO THE TERMINALS

1) Cut the wire end with a wire cutter or wire-cutting pliers, then strip the insulation to about 10 mm to expose the strand wiring.

2) Using a screwdriver, remove the terminal screw(s) on the termina (3) Using a round terminal fastener or pliers, securely clamp a round terminal to each stripped wire end.



1. CONNECTION DIAGRAMS




2. CORD PREPARATION


Keep the earth wire longer than the other wires.

3. OUTDOOR UNIT


(1) Remove the outdoor unit connector cover.

(2) Bend the end of the cord as shown in the figure. (3) Connect the end of the connection cord fully into the terminal block. (4) Fasten the sheath with a cord clamp.





Connection cord wiring Run the connection cord to the rear of the outdoor unit within the (A) range of the arrows shown in the figure.



⚠ CAUTION

Match the terminal block numbers and connection cord colors with those of the indoor unit. Erroneous wiring may cause burning of the electric

block. Imperfect installation may cause a fire.

4 Securely earth the power cord plug.

② Connect the connection cords firmly to the termina

3 Always fasten the outside covering of the connection cord with the cord clamp. (If the insulator is chafed, electric leakage may occur.)

(5) Do not use the earth screw for an external connector Only use for interconnection between two units.

TEST RUNNING

1. Make a TEST RUN in accordance with the installation instruction sheet for the indoor unit

(1) Is operation of each button on the remote control unit normal? (2) Does each lamp light normally?

(3) Do the air flow-direction louver operate normally? (4) Is the drain normal? (5) Is there any abnormal noise and vibration during operation? (2) OUTDOOR UNIT

(1) Is there any abnormal noise and vibration during operation? (2) Will noise, wind, or drain water from the unit disturb the neighbors? (3) Is there any gas leakage? Do not operate the air conditioner in the test running state for a long

• For the operation method, refer to the operating manual and perform

description of each error according to the LED.

2. OUTDOOR UNIT LEDS When a malfunction occurs in the outdoor unit, the LED on the circuit board lights to indicate the error. Refer to the following table for the

Error contents	LED
Thermistor malfunction	on 0.1 sec/off 0.1 sec
Abnormal discharge temperature	on
Current surge protection	on 0.5 sec/off 0.5 sec
CT abnormality	on 2.0 sec/off 2.0 sec
Compressor position detection malfunction	on 0.1 sec/off 2.0 sec
Fan malfunction	on 5.0 sec/off 5.0 sec
PAM voltage abnormality	on 5.0 sec/off 0.1 sec
Timer short	on 1.0 sec/off 1.0 sec
Compressor temperature protection (permanent stop)	on 2.0 sec/off 5.0 sec
PFC surge protection (permanent stop)	on 5.0 sec/off 2.0 sec

CUSTOMER GUIDANCE

Explain the following to the customer in accordance with the operating

(1) Starting and stopping method, operation switching, temperature

adjustment, timer, air flow adjustment, and other remote control unit (2) Air filter removal and cleaning.

(3) Give the operating manual and installation instruction sheet to the

⚠ CAUTION

R410A REFRIGERANT

THIS PRODUCT MUST ONLY BE INSTALLED OR SERVICED BY QUALIFIED PERSONNEL.

(PART NO. 9374995066)

For authorized service personnel only.

This installation instruction sheet describes how to install the outdoor unit only. To install the indoor unit, refer to the installation instruction sheet included with

⚠ DANGER	This mark indicates procedures which, if improperly performed, are most likely to result in the death of o serious injury to the user or service personnel.
⚠ WARNING	This mark indicates procedures which, if improperly performed, might lead to the death or serious injury o the user.
⚠ CAUTION	This mark indicates procedures which, if improperly performed, might possibly result in personal harm to the user, or damage to property.

⚠ DANGER

Never touch electrical components immediately after the power supply has been turned off. Electrical shock may occur. After turning off the power, always wait 5 minutes or more before touching electrical components.

This air conditioner uses new refrigerant HFC (R410A).

The basic installation work procedures are the same as conventional refrigerant models. However, pay careful attention to the following points:

- Since the working pressure is 1.6 times higher than that of conventional refrigerant models, some of the piping and installation and service tools are special. (See the table below.) Especially, when replacing a conventional refrigerant model with a new refrigerant R410A model, always replace the conventional piping and flare nuts with the R410A piping and flare nuts.
- Models that use refrigerant R410A have a different charging port thread diameter to prevent erroneous charging with conventional refrigerant and for safety. Therefore, check beforehand. [The charging port thread diameter for R410A is
- Be more careful that foreign matter (oil, water, etc.) does not enter the piping than with refrigerant models. Also, when storing the piping, securely seal the openings by pinching, taping, etc.
- When charging the refrigerant, take into account the slight change in the composition of the gas and liquid phases, and always charge from the liquid phase side whose composition is stable.

Special tools for R410A

Tool name	Contents of change	
	Pressure is high and cannot be measured with a conventional gauge. To prevent erroneous mixing of other	
Gauge manifold	refrigerants, the diameter of each port has been changed.	
Gauge manifold	It is recommended the gauge with seals -0.1 to 5.3 MPa (-76 cmHg to 53 kgf/cm²) for high pressure0.1 to	
	3.8 MPa (-76 cmHg to 38 kgf/cm²) for low pressure.	
Charge hose	To increase pressure resistance, the hose material and base size were changed.	
Vacuum pump	A conventional vacuum pump can be used by installing a vacuum pump adapter.	
Gas leakage detector	Special gas leakage detector for HFC refrigerant R410A.	

It is necessary to use seamless copper pipes and it is desirable that the amount of residual oil is less than 40 mg/10 m. Do not use copper pipes having a collapsed, deformed or discolored portion (especially on the interior surface). Otherwise, the expansion valve or capillary tube may become blocked with contaminants As an air conditioner using R410A incurs pressure higher than when using conventional refrigerant, it is necessary to choose adequate materials. Thicknesses of copper pipes used with R410A are as shown in the table. Never use copper pipes thinner than that in the table even when it is available on the

Thicknesses of Annealed Copper Pipes (R410A)

Pipe outside diameter	Thickness
6.35 mm (1/4 in.)	0.80 mm
9.52 mm (3/8 in.)	0.80 mm
12.70 mm (1/2 in.)	0.80 mm
15.88 mm (5/8 in.)	1.00 mm
19.05 mm (3/4 in.)	1.20 mm

⚠ WARNING

- ① For the air conditioner to operate satisfactorily, install it as outlined in this installation instruction sheet.
- Connect the indoor unit and outdoor unit with the room air conditioner piping and cords available standards parts. This installation instruction sheet describes the correct connections using the installation set available from our standard parts.
- Installation work must be performed in accordance with national wiring standards by authorized personnel only.
- Also, do not use an extension cord
- ⑤ Do not turn on the power until all installation work is complete
- 6 Do not purge the air with refrigerants but use a vacuum pump to vacuum the installation
- There is not extra refrigerant in the outdoor unit for air purging.
- 8 Use a vacuum pump for R410A exclusively.
- Using the same vacuum pump for different refrigerants may damage the vacuum pump or the unit.
- (1) Use a clean gauge manifold and charging hose for R410A exclusively.
- ① If refrigerant leaks while work is being carried out, ventilate the area. If the refrigerant comes in contact with a flame, it produces a toxic gas.
- Be careful not to scratch the air conditioner when handling it.
- After installation, explain correct operation to the customer, using the operating manual.
- Let the customer keep this installation instruction sheet because it is used when the air conditioner is serviced or moved.

STANDARD PARTS

The following installation parts are furnished.

ose mem as req	uireu.		
Name and Shape		Q'ty	Application
Drain pipe		1	For outdoor unit drain piping work (May not be supplied, depending on
Drain cap		2	the model.)
Insulation (sea		1	For filling in a gap at the entrance of connection cords

CONNECTION PIPE REQUIREMENT

The maximum lengths of this product are shown in the following table. If the units are further apart than this, correct operation can not be guaranteed

Diameter		Pipe	Maximum height (between indoor and	
Liquid	Gas	MAX.	MIN.	outdoor)
9.52 mm (3/8 in.)	15.88 mm (5/8 in.)	50 m	5 m	30 m

• Use pipe with water-resistant heat insulation.

9374995066 IM front.p65

↑ CAUTION

- Install heat insulation around both the gas and liquid pipes. Failure to do so may cause water leaks.
- Use heat insulation with heat resistance above 120 °C. (Reverse cycle model only) In addition, if the humidity level at the installation location of the refrigerant piping is expected to exceed 70%, install heat
- insulation around the refrigerant piping. If the expected humidity level is 70-80%, use heat insulation that is 15 mm or thicker and if the expected humidity exceeds 80%, use heat insulation that is 20 mm or thicker
- If heat insulation is used that is not as thick as specified, condensation may form on the surface of the insulation.
- In addition, use heat insulation with heat conductivity of 0.045 W/(m·K) or less (at 20 °C).

ELECTRICAL REQUIREMENT

• Electric wire size and breaker capacity:

Po	ower supply co	rd	(Breaker		
Conductor size (mm²)		Maximum	Conductor size (mm²)		Conductor size (mm²) Maximum	
MAX.	MIN.	length (m)	MAX. MIN.		length (m)	capacity (A)
6.0	5.3	17	2.5	1.5	51	30

- Use conformed cord with Type 245 IEC57.
- Install all electrical works in accordance to the standard.

Decide the mounting position with the customer as follows:

• Install the disconnect device with a contact gap of at least 3 mm in all poles nearby the units. (Both indoor unit and outdoor unit)

SELECTING THE MOUNTING POSITION


Select installation locations that can properly support the weight of the indoor and outdoor units. Install the units securely so

↑ CAUTION


- ① Do not install where there is the danger of combustible gas leakage.
- 2 Do not install the unit near heat source of heat, steam, or flammable gas
- ③ If children under 10 years old may approach the unit, take preventive measures so that they cannot reach the unit.

-) Install the unit where it will not be tilted by more than 3°. However, do not install the unit with it tilted towards the side
- When installing the outdoor unit where it may exposed to strong wind, fasten it securely.
- (1) Install the outdoor unit in a location which can withstand the weight of the unit and vibration, and which can install horizontally. (2) Provide the indicated space to ensure good airflow.
- (3) If possible, do not install the unit where it will be exposed to direct sunlight. (If necessary, install a blind that does not interfere with the airflow.)
- (4) Do not install the unit near a source of heat, steam, or flammable gas (5) During heating operation, drain water flows from the outdoor unit.
- Therefore, install the outdoor unit in a place where the drain water flow will not be obstructed. (Reverse cycle model only) (6) Do not install the unit where strong wind blows or where it is very dusty.
- (7) Do not install the unit where people pass. (8) Install the outdoor unit in a place where it will be free from being dirty or getting wet by rain as much as possible
- (9) Install the unit where connection to the indoor unit is easy.


When there are obstacles at the back side




When there are obstacles at the back and front sides



When there are obstacles at the back, side(s), and top.



When there are obstacles at the back side with the installation of more than one unit.




* If the space is larger than that is stated, the condition will be the same as that there are no obstacles.

INSTALLATION PROCEDURE


OUTDOOR UNIT

INSTALLATION

1. OUTDOOR UNIT PROCESSING (1) Outdoor unit to be fasten with bolts at the four places indicated by the arrows without fail.




(2) Fix securely with bolts on a solid block. (Use 4 sets of commercially available M10 bolt, nut and washer.)



- (3) Since the drain water flows out of the outdoor unit during heating operation, install the drain pipe and connect it to a commercial 16 mm
- hose (Reverse cycle model only) (4) When installing the drain pipe, plug all the holes other than the drain pipe mounting hole in the bottom of the outdoor unit with putty so there is no water leakage. (Reverse cycle model only)

E erierien
When the outdoor temperature is 0 °C or less, do not ue the accessory drain pipe and drain cap. If the drain pand drain cap are used, the drain water in the pipe not freeze in extremely cold weather. (Reverse cycle moonly)



CONNECTING THE PIPE

↑ CAUTION Do not use mineral oil on flared part. Prevent mineral

- oil from getting into the system as this would reduce the lifetime of the units. While welding the pipes, be sure to blow dry nitrogen
- The maximum lengths of this product are shown in the table. If the units are further apart than this, correct

operation can not be guaranteed


(1) Cut the connection pipe to the necessary length with a pipe cutter. (2) Hold the pipe downward so that cuttings will not enter the pipe and

(3) Insert the flare nut (always use the flare nut attached to the indoor

and outdoor units respectively) onto the pipe and perform the flare processing with a flare tool. Use the special R410A flare tool, or the conventional flare tool.

Check if [L] is flared uniformly

gas through them.



Dimension A (mm)		
Flare tool for R410A, clutch type		
0 to 0.5		

Pipe outside diameter	Dimension B _{-0.4} (mm)
6.35 mm (1/4 in.)	9.1
9.52 mm (3/8 in.)	13.2
12.70 mm (1/2 in.)	16.6
15.88 mm (5/8 in.)	19.7
19.05 mm (3/4 in.)	24.0

When using conventional flare tools to flare R410A pipes, the dimension A should be approximately 0.5 mm more than indicated in the table (for flaring with R410A flare tools) to achieve the specified flaring. Use a thick-

Width across flats	Pipe outside diameter	Width across flats of Flare nut
	6.35 mm (1/4 in.)	17 mm
$((\bigcirc))$	9.52 mm (3/8 in.)	22 mm
	12.70 mm (1/2 in.)	26 mm
~	15.88 mm (5/8 in.)	29 mm
	19.05 mm (3/4 in.)	36 mm

2. BENDING PIPES

The pipes are shaped by your hands. Be careful not to collapse them. Do not bend the pipes in an angle more than 90°.

When pipes are repeatedly bend or stretched, the material will harden, making it difficult to bend or stretch them any more. Do not bend or

stretch the pipes more than three times.


To prevent breaking of the pipe, avoid sharp bends. Bend the pipe with a radius of curvature of 150 mm or ② If the pipe is bent repeatedly at the same place, it will

3. CONNECTION PIPES

Outdoor unit (1) Detach the caps and plugs from the pipes

⚠ CAUTION D Be sure to apply the pipe against the port on the indoor unit and the outdoor unit correctly. If the centering is improper, the flare nut cannot be tightened smoothly. If the flare nut is forced to turn, the threads will be


- Do not remove the flare nut from the indoor unit pipe until immediately before connecting the connection
- (2) Centering the pipe against port on the outdoor unit, turn the flare nut




with your hand.

Do not use mineral oil.

(3) Tighten the flare nut of the connection pipe at the outdoor unit valve



(4) When the flare nut is tightened properly by your hand, use a torque wrench to finally tighten it.



Hold the torque wrench at its grip, keeping it in the right angle with the pipe, in order to tighten the flare nut


Flare nut	Tightening torque
6.35 mm (1/4 in.) dia.	14 to 18 N·m (140 to 180 kgf·cm)
9.52 mm (3/8 in.) dia.	33 to 42 N·m (330 to 420 kgf·cm)
12.70 mm (1/2 in.) dia.	50 to 62 N·m (500 to 620 kgf·cm)
15.88 mm (5/8 in.) dia.	63 to 77 N⋅m (630 to 770 kgf⋅cm)
19.05 mm (3/4 in.) dia.	100 to 110 N·m (1000 to 1100 kgf·cm)

- (1) Remove the cap, and connect the gauge manifold and the vacuum
- pump to the charging valve by the service hoses. (2) Vacuum the indoor unit and the connecting pipes until the pressure gauge indicates -0.1 MPa (-76 cmHg). (3) When -0.1 MPa (-76 cmHg) is reached, operate the vacuum pump
- for at least 60 minutes. (4) Disconnect the service hoses and fit the cap to the charging valve to

4. VACUUM

- the specified torque. (5) Remove the blank caps, and fully open the spindles of the 2-way and 3-way valves with a hexagon wrench [Torque: 6~7 N·m (60 to
- Tighten the blank caps of the 2-way valve and 3-way valve to the

	6.35 mm (1/4 in.)	20 to 25 N·m (200 to 250 kgf·cm)			
Blank	9.52 mm (3/8 in.)	20 to 25 N·m (200 to 250 kgf·cm)			
cap	12.70 mm (1/2 in.)	25 to 30 N·m (250 to 300 kgf·cm)			
Сар	15.88 mm (5/8 in.)	30 to 35 N·m (300 to 350 kgf·cm)			
	19.05 mm (3/4 in.)	35 to 40 N·m (350 to 400 kgf·cm)			
Charging port cap		10 to 12 N·m (100 to 120 kgf·cm)			
Connecting pipe Blank cap					



- **⚠** CAUTION Do not purge the air with refrigerants, but use a vacuum pump to vacuum the installation! There is no extra refrigerant in the outdoor unit for air purging!
- Use a vacuum pump and gauge manifold and charging hose for R410A exclusively. Using the same vacuum for different refrigerants may damage the vacuum pump

5. ADDITIONAL CHARGE

Refrigerant suitable for a piping length of 20 m is charged in the outdoor unit at the factory. When the piping is longer than 20 m, additional charging is necessary.

F	For the additional amount, see the table below.					
	Pipe length	20 m	30 m	40 m	50 m	g/m
	Additional refrigerant	None	500 g	1000 g	1500 g	50 g/m

↑ CAUTION

- When moving and installing the air conditioner, do not mix gas other than the specified refrigerant R410A inside the refrigerant cycle. When charging the refrigerant R410A, always use
- an electronic balance for refrigerant charging (to measure the refrigerant by weight). ③ When charging the refrigerant, take into account the slight change in the composition of the gas and liquid phases, and always charge

from the liquid phase side whose

- composition is stable. Add refrigerant from the charging valve after the
- completion of the work. (5) If the units are further apart than the maximum pipe length, correct operation can not be guaranteed.

6. GAS LEAKAGE INSPECTION

A CAUTION
After connecting the piping, check the all joints for
leakage with gas leak detector.

pump for pressure. Do not use nitrogen gas.

② When inspecting gas leakage, always use the vacuum

POWER

↑ WARNING

The rated voltage of this product is 220-240 V a.c.

Before turning on, verify that the voltage is within the

- 198 V to 264 V range. Always use a special branch circuit and install a special receptacle to supply power to the air conditioner.
- Use a special branch circuit breaker and receptacle matched to the capacity of the air conditione (Install in accordance with standard.) Perform wiring work in accordance with standards
- so that the air conditioner can be operated safely and Install a leakage special branch circuit breaker in accordance with the related laws and regulations
- The circuit breaker is installed in the permanent wiring. Always use a circuit that can trip all the poles of the wiring and has an isolation distance of at least 3 mm between the contacts of each pole.

↑ CAUTION

and electric company standards.

The power source capacity must be the sum of the air conditioner current and the current of other electrical appliances. When the current contracted capacity is insufficient, change the contracted capacity.

When the voltage is low and the air conditioner is difficult to start, contact the power company the voltage raised.

(Continued to the next page)

1/11/07, 10:01 AM

4 ELECTRICAL WIRING

⚠ WARNING

Before starting work, check that power is not being supplied to all poles of the indoor unit and outdoor unit.
 Match the terminal board numbers and connection cord colors with those of the outdoor unit.
 Erroneous wiring may cause burning of the electric


Connect the connection cords firmly to the terminal board. Imperfect installation may cause a fire.

- Always fasten the outside covering of the connection cord with the cord clamp. (If the insulator is chafed, electric leakage may occur.)
- S Always connect the ground wire.


HOW TO CONNECT WIRING TO THE TERMINALS

For strand wiring

- (1) Cut the wire end with a wire cutter or wire-cutting pliers, then strip the insulation to about 10 mm to expose the strand wiring.
 (2) Using a screwdriver, remove the terminal screw(s) on the terminal board.
- board.(3) Using a round terminal fastener or pliers, securely clamp a round terminal to each stripped wire end.
- (4) Position the round terminal wire, and replace and tighten the terminal screw using a screwdriver.




1. CONNECTION DIAGRAMS



2. CONNECTION CORD PREPARATION

Keep the earth wire longer than the other wires.





3. OUTDOOR UNIT

⚠ CAUTION

When connecting the power supply cord, make sure that the phase of the power supply matches with the phase of the terminal board. If the phases do not match, the compressor will rotate in reverse and will not be able to compress.

- (1) Service cover removal
- Remove the two mounting screws.Remove the service cover by pushing downwards.






(3) Connect the power supply cord and the connection cord to terminal.


(4) Fasten the power supply cord and connection cord with cord clamp.


Remove the one mounting screw.

connection cord)

Remove the valve cover by sliding upward.







(6) Put the service cover and valve cover back after completion of the work.

5

TEST RUN

Make a TEST RUN in accordance with the installation instruction sheet for the indoor unit.

2. OUTDOOR UNIT LEDS

When a malfunction occurs in the outdoor unit, the LED on the circuit board lights to indicate the error. Refer to the following table for the description of each error according to the LED.

LED	Error contents
1 flash	Communication error
Hasn	(Indoor unit – Outdoor unit)
2 flash	Discharge pipe temperature sensor
3 flash	Outdoor heat exchanger temperature (OUTLET) senso
4 flash	Outdoor temperature sensor
5 flash	Outdoor heat exchanger temperature (MID) sensor
6 flash	Discharge pipe temperature abnormal
7 flash	Compressor temperature sensor
8 flash	Heat sink temperature sensor
9 flash	Pressure switch abnormal
10 flash	Compressor temperature abnormal
12 flash	IPM error
13 flash	Compressor rotor position cannot detect
14 flash	Compressor cannot operate
15 flash	Outdoor fan abnormal (upper fan)
16 flash	Outdoor fan abnormal (lower fan)
5 sec. ON/ 1 sec. OFF repeated	Protect operation
1 sec. ON/ 1 sec. OFF repeated	PUMP DOWN operation
OFF	No error

6

SPECIAL INSTALLATION SETTING

PUMP DOWN (Refrigerant collecting operation)

Perform the following procedures to collect the refrigerant when moving the indoor unit or the outdoor unit.

1. When the product is stopped:

- Press the PUMP DOWN switch on the outdoor unit.
 (The LED on the outdoor unit circuit board starts
- flashing (1 sec. ON / 1 sec. OFF repeated).)

 The pump down operation (cooling operation) begins right away. After operation starts, close the
- three-way valve (liquid).

 3 After 2 3 minutes, operation stops. Close the three-way valve (gas) within one minute after operations
- The LED will go out three minutes after it stops.
 Disconnect the power supply after confirming that the LED has gone out.


2. When the product is operating:


- Press the PUMP DOWN switch on the outdoor unit.
 The LED on the outdoor unit circuit board starts flashing (1 sec. ON / 1 sec. OFF repeated), and operation stops. At this point, recovery has not been completed, so do not close the three-way valves (liquid and gas).
- ② The pump down operation (cooling operation) begins after three minutes. Close the three-way valve (liquid) after operation starts.
- 3 After 2 3 minutes, operation stops. Close the threeway valve (gas) within one minute after operations stops.
- The LED will go out three minutes after it stops. Disconnect the power supply after confirming that the LED has gone out.

*When the pump down operation is repeated, temporarily disconnect the power supply after opening the closed valves (both liquid and gas). Reconnect the power supply after 2 - 3 minutes and perform the pump down operation.

*When the start of the operation after pump down operation has been completed, temporarily disconnect the power supply after opening the closed valves (both liquid and gas).

Reconnect the power supply after 2 - 3 minutes and be sure to perform a





⚠ DANGER

This part (Choke coil) generates high voltages.

Never touch this part.

PART NO. 9374995066

9374995066_IM_back.p65 1/11/07, 2:21 PM

Remote Controller (Wired Type)

INSTALLATION INSTRUCTION SHEET

(PART NO. 9373328063-02)

For authorized service personnel only.

! WARNING!

This mark indicates procedures which, if improperly performed, might lead to the death or serious injury of

- For the air conditioner to operate satisfactorily, install it as outlined in this installation instruction sheet.
- Installation work must be performed in accordance with national wiring standards by authorized personnel only.
- Do not turn on the power until all installation work is complete.
- Let the customer keep this installation instruction sheet because it is needed when the air conditioner or remote controller is serviced or moved.

CAUTION!

This mark indicates procedures which, if improperly performed, might possibly result in personal harm to the user, or damage to property.

- In order to detect the room temperature correctly when using the temperature sensor of the remote controller, do not install the remote controller in a place where it will be exposed to direct sunlight or directly below the air outlet of the indoor unit. Temperature sensor
- Do not touch the remote controller PC board and PC board parts directly with your hands.
- Do not wire the remote controller cord and the bus wire together with or parallel to the connection cables, transmission cords, and power supply cords of the indoor and outdoor units. It may cause erroneous operation.
- When installing the bus wire near a source of electromagnetic waves, use shielded wire.
- Do not set the DIP switches, either on the air conditioner or the remote controller, in any way other than indicated in this sheet or the manual that is supplied with the air conditioner. Doing so may result in an accident.

1

STANDARD PARTS

The following installation parts are supplied. Use them as required.

Name and Shape	Q'ty	Application
Remote controller	1	For air conditioner operation
Remote controller cord (*1)	1	For connecting the remote controller
Connecting cord (*2)	1	For connecting the remote controller cord to the indoor unit

Name and Shape	Q'ty	Application
Tapping screw (M4 × 16)	2	For installing the remote controller
Binder	1	For remote controller and remote controller cord binding
Tapping screw (M4 × 14) (*2)	1	For installing the remote controller cord to the indoor unit
Cord clamper (*2)	1	For installing the remote controller cord to the indoor unit

(*2) Use only if the remote controller cord must be modified for the indoor unit model.

REMOTE CONTROLLER SETTING


1. INSTALLING THE REMOTE CONTROLLER

Open the operation panel on the front of the remote controller, remove the two screws indicated in the following figure, and then remove the front case of the remote controller.

When installing the remote controller, remove the connector from the front case. The wires may break if the connector is not removed and the front case hangs down.

Fig. 1






When installing the front case, connect the connector to the front case.


^(*1) UTB-YU/GU/XU only


When remote controller cord is embedded

- (1) Embed the remote controller cord and box.
- (2) Pass the remote controller cord through the hole in the rear case and connect the remote controller cord to the remote controller terminal board specified in Fig. 2.
- (3) Clamp the remote controller cord sheath with the binder as shown in Fig. 2.
- (4) Cut off the excess binder.
- (5) Install the rear case to the wall, box, etc., with two screws (Fig. 3).



Ground the remote controller if it has a ground wire.






⚠ CAUTION

- ① Install the remote controller wires so as not to be direct touched with your hand.
- ② Do not touch the remote controller PC board and PC board parts directly with your hands.

2. SETTING THE DIP SWITCHES

Set the remote controller DIP switches.



	NO.	SW state		Detail	
	NO.	OFF	ON	Detail	
1	1	*		Cannot be used. (Do not change)	
DIP switch 1 2 * 3 Follow the selection in FUNCTION SETTING 4 *	2	*		Dual remote controller setting *Refer to 2. DUAL REMOTE CONTROLLERS in 3 SPECIAL INSTALLATION METHODS.	
	3		Invalidity	Filter reset operation and filter display	
		Cannot be used. (Do not change)			
	5	*		Cannot be used. (Do not change)	
	6	★ Invalidity	Validity	Memory backup setting *Set to ON to use batteries for the memory backup. If batteries are not used, all of the settings stored in memory will be deleted if there is a power failure.	

(★ Factory setting)


REMOTE CONTROLLER CORD MODIFICATION

When the installation instruction sheet for the indoor unit contains information that the remote controller cord must be modified, perform the following work.

The remote controller cord must be modified when connecting it to some indoor unit models.

- (1) Use a tool to cut off the terminal on the end of the remote controller cord, and then remove the insulation from the cut end of the cord as shown in Fig. 4.
- (2) Connect the remote controller cord and connecting cord as shown in Fig. 5.

Important: Be sure to insulate the connection between the cords.




4

SPECIAL INSTALLATION METHODS

1. GROUP CONTROL

- A number of indoor units can be operated at the same time using a single remote controller.
- Depending on the model, some indoor units cannot be connected for group control.
- Some functions may become unusable, depending on the combination of the indoor units that are connected in a group.
- (1) Wiring method (indoor unit to remote controller)



When ground wire is necessary


(2) Indoor unit address setting

Set each indoor unit address using the DIP switch of each indoor unit.

(Refer to the installation instruction sheet for the indoor unit.)

2. DUAL REMOTE CONTROLLERS

- Two separate remote controllers can be used to operate the indoor units.
- The timer and self-diagnosis functions cannot be used on the slave units.
- (1) Wiring method (indoor unit to remote controller)




(2) Remote controller DIP switch 1 setting Set the remote controller DIP switch 1 No. 2 according to the following table.

Number of remote	Master unit	Slave unit	
controllers	DIP SW 1 No. 2	DIP SW 1 No. 2	
1 (Normal)	OFF	-	
2 (Dual)	OFF	ON	

TURNING ON THE POWER


- 1. Check the remote controller wiring and DIP switch settings.
- 2. Install the front case.
- * When installing the front case, connect the connector to the front case (in 2 REMOTE CONTROLLER SETTING).
- 3. Check the indoor and outdoor unit wiring and circuit board switch settings, and then turn on the indoor and outdoor units. After " #[" has flashed on the set temperature display for several seconds, the clock display will appear in the center of the remote controller display. The clock display will appear in the center of the remote controller display.



6

TEST OPERATION

- 1. If the operation lamp is on, press the Start/Stop button to turn it off.
- * Perform the test operation for 60 minutes.
- * Pressing the Start/Stop button will stop the test operation.






Test operation display

SELF-DIAGNOSIS

If an error occurs, the following display will be shown. ("EE" will appear in the set room temperature display.)

Unit number	Error code	Content
CO	1d	Incompatible indoor unit is connected
C0	1c	Indoor unit ↔ remote controller communication error



SETTING THE ROOM TEMPERATURE DETECTION LOCATION


The detection location of the room temperature can be selected from the following two examples. Choose the detection location that is best for the installation location.

A. Indoor unit setting (factory setting)

The room temperature is detected by the indoor unit temperature sensor.

(1) When the THERMO SENSOR button is pressed, the lock display flashes because the function is locked at the factory.






B. Indoor unit/remote controller setting (room temperature sensor selection)

The temperature sensor of the indoor unit or the remote controller can be used to detect the room temperature.

- (1) Enable the room temperature sensor selection in FUNCTION SETTING, which will be described later.
- (2) Press the THERMO SENSOR button for 5 seconds or more to select the temperature sensor of the indoor unit or the remote controller.





NOTES


If the function to change the temperature sensor is used as shown in examples A (other than example B), be sure to lock the detection location. If the function is locked, the lock display will flash when the THERMO SENSOR button is pressed.

FUNCTION SETTING


This procedure changes the function settings used to control the indoor unit according to the installation conditions. Incorrect settings can cause the indoor unit to malfunction. This procedure should be performed by authorized installation or service personnel only.

Perform the "FUNCTION SETTING" according to the installation conditions using the remote controller. (Refer to the indoor unit installation instruction sheet for details on the function numbers and setting values.)


(1) Press the set temperature buttons (∨) (∧) and fan control button simultaneously for more than 5 seconds to enter the function setting mode.




(2) Press the SET BACK button to select the indoor unit number.



(3) Press the set time buttons to select the function number.



- (4) Press the set temperature buttons (\vee) (\wedge) to select the setting value. The display flashes as shown to the right during setting value selection.
- (5) Press the SET button to confirm the setting. Press the SET button for a few seconds until the setting value stops flashing. If the setting value display changes or if "- -" is displayed when the flashing stops, the setting value has not been set correctly. (An invalid setting value may have been selected for the indoor unit.)
- (6) Repeat steps 2 to 5 to perform additional settings. Press the set temperature buttons (\(\vec \) (\(\Lambda \)) and fan control button simultaneously again for more than 5 seconds to cancel the function setting mode. In addition, the function setting mode will be automatically canceled after 1 minute if no operation is performed.
- (7) After completing the FUNCTION SETTING, be sure to turn off the power and turn it on again.





FUJITSU GENERAL LIMITED

1116,Suenaga,Takatsu-ku,Kawasaki 213-8502,Japan