

UTOPIA DC INVERTER RASC SERIES RASC-H(V)RNE






Service manual

• RASC-(3/5)HVRNE • RASC-10HRNE



Specifications in this manual are subject to change without note in order that HITACHI may bring the latest innovations to their customers.

Whilst every effort is made to ensure that all specifications are correct, printing errors are beyond Hitachi's control; Hitachi cannot be held responsible for these errors.





Electrical wiring



Available optional functions

Test run

Troubleshooting

Spare parts

8

11

3

5

6

Servicing

Main parts 10

Field work instruction

General Index

1. Ur	nits Installation	19
1.1. F	RASC-(3~10)H(V)RNE	22
1.1.1.	Transportation	22
1.1.2.	Center of gravity	
1.1.3.	Installation space (Initial check)	
1.1.4.	Place provision	
1.1.5.	Available configurations	
1.1.6.	Duct connection	
2. Pip	ping installation	27
2.1. 0	General notes	
2.2. P	Piping work connection considerations	
2.2.1.	Piping materials	
2.2.2.	Three principles on refrigerant piping work	
2.2.3.	Suspension of refrigerant piping	
2.2.4.	Brazing work	
2.2.5.	Caution of the pressure by check joint	
2.2.6.	Refrigerant charge quantity	
2.2.7.	Pump down refrigerant	
2.3. S	Suspension of refrigerant piping	
2.4. P	Piping connection	37
2.4.1.	Tightening torque	
2.4.2.	Flange piping connection (only for RASC-10HRNE)	
2.5. P	Piping and refrigerant charge	40
2.5.1.	General process	40
2.5.2.	Refrigerant piping range	
2.5.3.	Refrigerant piping length	
2.5.4.	Refrigerant piping selection	
2.6. T	win and quad system installation	45
2.6.1.	Height difference between indoor units and distributor	
2.6.2.	Installing distributor	45
2.7. F	Rasc unit factory refrigerant charge (wo kg)	47
2.8. A	dditional refrigerant charge calculation	47

3. E	Electrical wiring	51
3.1.	General check	52
3.2.	Electrical wiring for outdoor units	53
3.2.	1 Electrical wiring connection for outdoor units	53
3.2.2		
3.3.	Electrical wiring between indoor unit and outdoor unit	57
3.4.	Wire size	58
3.5.	Electrical wiring diagrams	60
3.5.	1. Electrical wiring diagram for RASC-(3/5)HVRNE	60
3.5.2	2. Electrical wiring diagram for RASC-10HRNE	61
4. (Control system	63
4.1.	Device control system	64
4.2.	RASC-(3~10)H(V)RNE PCB	66
4.3.	Protection and safety control	67
4.4.	Standard operation sequence	68
4.4.	1. Cooling operation	68
4.4.2		
4.4.3	3. Heating operation	72
4.4.4	4. Defrost operation control	74
4.5.	Standard control functions	75
4.5.	1. Freezing protection during cooling process or dry operation	75
4.5.		
4.5.3		
4.5.4	4. Activation of protection device control	78
4.5.	5 5 1	
4.5.0		
4.5.	5	
4.5.8	3. Prevention control for high pressure increase	81
5. A		
	Available optional functions	83
5.1.	Available optional functions RASC-(3~10)H(V)RNE Units	
	RASC-(3~10)H(V)RNE Units	84
5.1.	RASC-(3~10)H(V)RNE Units 1. Available ports 2. Configuration	84 84 86
5.1. 5.1. 5.1. 5.1.	RASC-(3~10)H(V)RNE Units 1. Available ports 2. Configuration 3. Description of optional input signals	84 84 86 88
5.1. 5.1. 5.1. 5.1. 5.1.	RASC-(3~10)H(V)RNE Units Available ports Configuration Description of optional input signals Description of optional output signals	84 84 86 88 89
5.1. 5.1. 5.1. 5.1.	RASC-(3~10)H(V)RNE Units	84 86 88 89 89

8

 $\left(\right)$

5.2.	Av	vailable optional functions through the remote control switch (PC-ART)	95
5.2 5.2		Optional function setting Optional functions of the remote control switch	
5.3.	Av	vailable optional functions through the remote control switch (PC-ARH)	108
5.3	.1.	Alarm indication	.109
5.4.	Av	vailable optional functions through wireless remote control switch (PC-LH3A + receiver)	110
6.	Tes	t run	111
6.1.	Ch	necking procedure before the test run	112
6.2.	Те	st run procedure using the remote control switch	114
6.3.	Те	st run procedure using the wireless remote control switch	115
6.4.	Те	st run procedure from the outdoor unit side	117
6.5.	Nc	ormal operation pressure	118
6.6.	Ch	neck list	120
7.	Tro	ubleshooting	123
7.1.	Ini	tial troubleshooting	124
7.1 7.1 7.1 7.1	.2. .3.	Checking using the 7-segment display Failure of the power supply to the indoor unit and the remote control switch Abnormal transmission between the remote control switch and the indoor unit Abnormal operation of the devices	.125 .126
7.2.	Tro	oubleshooting procedure	135
7.2 7.2 7.2 7.2 7.2	.2. .3. .4.	Alarm code Troubleshooting by alarm code Troubleshooting in check mode Troubleshooting using the 7 segment display Cause of inverter stoppage	.137 .176 .182
7.3.	Pr	ocedure for checking each main part	187
7.3 7.3 7.3	.2.	Self-checking procedure of PCB using the remote control switch Self-checking procedure of the Remote Control Switch Checking procedure of other main parts	.189
8.	Spa	are parts	201
8.1.	RA	ASC-(3/5)HVRNE	202
8.1 8.1 8.1	.2.	Cabinet and Fan Refrigerant Cycle Electrical equipament	204

8.2.	RASC-10HRNE	208
8.2.1	Cabinet and Fan	208
8.2.2		
8.2.3		
0.2.0		
9. S	ervicing	215
9.1.	RASC-(3/5)HVRNE	217
9.1.1	Removing piping service cover	217
9.1.2	Removing fan service cover	217
9.1.3	Removing electrical box service cover	217
9.1.4	Removing the outdoor unit fan motor	218
9.1.5	Removing the compressor	
9.1.6	Removing the high pressure switch (PSH) and pressure switch for control (PSC)	
9.1.7	Removing reversing valve coil	
9.1.8	Removing expansion valve coil	
9.1.9	Removing expansion valve	
9.1.1	0. Removing reversing valve	
9.1.1	1. Removing solenoid valve	
9.1.1	2. Removing the PCB	
	3. Removing electrical components	
9.2.	RASC-10HRNE	228
0.2.4		229
9.2.1		
9.2.2		
9.2.3		
9.2.4	5	
9.2.5		
9.2.6		
9.2.7		
9.2.8		
9.2.9		
9.2.1		
	1. Removing solenoid valve	
	2. Removing the PCB	
9.2.1	3. Removing electrical components	237
9.3.	Collecting refrigerant for replacing indoor unit	238
10. M	ain parts	239
10.1.	nverter	240
40.4		0.10
	1. Specifications of inverter	
	2. Inverter time chart	
	3. Protective function	
10.1.	4. Overload control	244
10.2	Thermistor	

 \cap

10.3. Electronic expansion valve24	47
10.3.1. Electronic expansion valve for outdoor unit	47
10.4. High pressure protection device24	48
10.5. Noise filters (NF)24	49
10.6. Capacitor (CB1, CB2)	52
10.7. Reactor (DCL)	52
10.8. Scroll compressor	54
10.8.1. Reliable mechanism for low vibrating and low sound	
11. Field work instruction25	55
11.1. Checking the power source and the wiring connection25	56
11.2. Burnt-out compressor due to an insufficient refrigerant charge	56
11.3. Insufficient cooling performance when a long piping is applied	57
11.4. Abnormally high operation sound (in-the-ceiling type indoor unit)	57
11.5. Alarm code "31"	58
11.6. Not well cooling due to insufficient installation space for outdoor unit or inlet/outlet air bypass 25	58
11.7. Caution in case of refrigerant leakage25	58
11.7.1. Maximum permitted concentration of HFCs 24 11.7.2. Calculation of refrigerant concentration 24 11.7.3. Countermeasure for refrigerant leakage 24	59
11.8. Maintenance work	30
11.9. Service and maintenance record	51
11.10. Service and maintenance record using the 7-segment display	32
11.11. Service and maintenance record by remote control switch	63
11.12. Pump-down method for replacing the compressor	34


12

O. Model codes and Description

• Unit code list

		NOTE	
-	- All references of the "Buil abbreviated as "RASC" u	in horitzontal" units contained into this Service Manual document, have been t.	





ACCESSORY CODE LIST

Accessory	Name	Code	Figure
PC-ART	Wall-mounted remote control switch with timer	70510000	HURCH CONTRACTOR
PC-P2HTE	Remote control switch with timer	7E899954	
PSC-A64S	Central control	60291479	
PSC-A1T	Programmable timer	60291482	
PC-LH3A	Wireless remote control switch	60291056	
PC-ARH	Optional remote controller	60291486	
PC-ALH	Receiver kit (for RCI-FSN2E -on the panel-)	60291464	Statistics
PC-ALHD	Receiver kit (for RCD-FSN2· -on the panel-)	60291467	- Terre
PC-ALHZ	Receiver kit (for RCI, RCD, RPC, RPI, RPK, RPF(I) - (FSN2E) -on the wall-)	60291473	
PC-ALHC	Receiver kit (for RCIM-FSN2E -on the panel-)	60291476	Image not available

Accessory	Name	Code	Figure	
PSC-5HR	H-LINK relay	60291105		0
PCC-1A	Optional function connector	60199286		
PRC-10E1	2-pin extension cord	7E790211	×.	
PRC-15E1	2-pin extension cord	7E790212		
PRC-20E1	2-pin extension cord	7E790213		
PRC-30E1	2-pin extension cord	7E790214	-	
THM-R2AE	Remote sensor (THM4)	7E799907	9	
HARC-BXE (A)	Lonwork BMS Interface (7 inputs up to 6 units)	60290874		
HARC-BXE (B)	Lonwork BMS Interface (4 inputs up to 32 units)	60290875		
HARC MOD BUS	Integration with installations with intelligent control (Building Management System) Gateway Interface to LON-WORKS BMS systems.	70513200		
HC-A64BNP	Integration with installations with intelligent control (Building Management System) Gateway Interface to BAC NET BMS systems.	60xxxx11	Frank	
CSNET-WEB (V3)	Control System	7E891938		
TS001 WEB SCREEN	15-inch touch-screen display	7E891935		
PCA-1IO	Integration of teams into H-Link	70519000		

SMGB0043 rev.1 - 04/2010

Accessory	Name	Code	Figure
HC-A160 SMS	SMS alarm warning device	70519100	
P-N23WA	Air panel for RCI-FSN2E	70530000	
P-N23WAM	Air panel for RCIM-FSN2E	60197160	
P-N23DWA	Air panel for RCD-FSN2E	60291574	
P-N46DWA	Air panel for RCD-FSN2E	60291575	
B-23H4	Adapter for deodorant filter	60199790	
F-23L4-K	Antibacteria filter	60199791	
F-23L4-D	Deodorant filter	60199793	
F-46L4-D	Deodorant filter	60199794	
PDF-23C3	Duct connection flange	60199795	
PDF-46C3	Duct connection flange	60199796	
OACI-232	Fresh-air intake kit	60199797	
PD-75	Fresh-air intake kit	60199798	

Accessory	Name	Code	Figure	0
PI-23LS5	3-way outlet parts	60199799		0
TKCI-232	T-duct connecting kit	60199801		
TE-03N	Branch pipe	70800007		
TE-56N	Branch pipe	70800009		
TE-10N	Branch pipe	70800004		
QE-810N	Branch pipe	70800006		

1. Units Installation

This chapter provides information concerning the installation of outdoor units.

Contents

1.	Uni	ts Installation	
1.1.	RA	ASC-(3~10)H(V)RNE	
1	.1.1.	Transportation	
		Center of gravity	
1	.1.3.	Installation space (Initial check)	
1	.1.4.	Place provision	
1	.1.5.	Available configurations	
1	.1.6.	Duct connection	

DANGER

Electrical hazard. Risk of death.

Before gaining access to terminals or performing any maintenance operation, turn OFF all power switches and disconnect all supply circuits.

Check that the LED201 (red) located on the DIP-IPM is OFF.

Do not touch the electrical components when LED201 (Red) is ON in order to avoid an electrical shock.

Do not touch the electrical components of the PCB directly.



WARNING

Damage by water. Electrical hazard.

Install the unit indoors to prevent water contact. The water proof class is IPX0.

Install the unit where no high level of oil mist, salty air or sulphurous atmosphere exists.

Attach a water proof cover in order to prevent water getting into the unit when installing.

Risk of explosion. A fire may occur. Use of inflammable agent may cause explosion or fire. For cleaning operation, use non-inflammable and nontoxic cleaning liquid.

Oxygen deficiency. Toxic gases may be produced. Work with sufficient ventilation. Working in an enclosed space is dangerous. Toxic gas may be produced when cleaning agent is heated to high temperature by, e.g., being exposed to fire.

Electric shock. Electrical hazard. In order to avoid electric shock or fire, pay attention not to clamp cables when attaching the service cover.

Electrical hazard. Electrical discharge. This unit contains condensers that might remain charged once the unit is switched off. Wait at least five minutes after the stop of the unit before to start any cleaning or maintenance operation, allowing the discharge of the condensers.



CAUTION

Malfunction. Unit failure. When installing more than one unit together, keep clearance of more than 50 mm between units and avoid obstacles that could hamper air intake.


Malfunction. Short circuit. Keep cleareance of more than 3000 mm between the wall (without vent holes) and air inlet/outlet.

Electromagnetic contamination. Equipment failures. Install the unit as far as possible (being at least 3 meters) from electromagnetic wave radiator, such as medical equipment.

Overheat of the unit. Malfunction. Install the unit in the shade or not exposed to direct sunshine or direct radiation from high temperature heat source.

Sharp fins. Risk of injury. Aluminium fins have very sharp edges. Pay attention to the fins in order to avoid injury. Use gloves.

Mount suspension bolts using M10 (W3/8) as size, as shown below:



i	Ì
---	---

NOTE

This appliance is not intended to be used by people (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision and instruction concerning the use of the appliance by a person responsible for their safety.

For easy operation and maintenance, install the unit with sufficient clearance around it as shown in the next pages.

Transport the package as close as possible to the intallation location before unpacking.

Make sure that the foundation is flat, levelled and strong enough.

Install the unit in a place where no seasonal wind might directly blow into the outdoor fan.


Install the unit in a restricted area not accessible by the general public.

Cleaning liquid shall be collected after cleaning operation.

Hitachi indoor units are designed for free air discharge (Static Pressure, Pst=0), except ducted indoor units as RPIM, which require to be connected to discharge air ducts. For these units see flow-static pressure chart.


1.1.<u>RASC-(3~10)H(V)RNE</u>

1.1.1. Transportation



• Hanging method

When hanging the unit, ensure its balance and lift it up smoothly and safely. Do not remove any packing materials until the unit is positioned. Hang the unit under packing condition with two ropes, as shown in the figure below.






NOTE

Make sure that the exterior of the unit is adequately protected with cloth or paper.


Do not hold the unit with the handles or the air outlet parts. Steel plates may be deformed. Use gloves.


1.1.2. Center of gravity

When the unit is lifted manually (using the handles), do not remove the wooden base from the unit to prevent its overturning. Pay attention to the center of gravity shown in the figures below.




1.1.3. Installation space (Initial check)





1.1.4. Place provision

- Concrete foundation. Installation on the floor.
- 1. Foundation shall be on levelled surface and it is recommended to be 100-300mm higher than ground level.
- 2. Install a drainage around foundation for smooth drain.
- 3. When installing the unit, fix it by M10 anchor bolts.
- 4. Use vibration-proof rubber (approx. 60 degree) between the unit and foundation.
- 5. Drain water might turn into ice on cold weather areas. Therefore, when installing the unit on a roof or a veranda, avoid to drain on a public area, since it may become slippery.
- 6. Check to ensure that the foundation is water-proof. In other case, apply water-proofing measures.
- 7. Install the unit so that the drain outlet parts are slightly (approx. 20 mm) lower than the other side, in order to avoid incorrect drain discharge.



N٥	Description
0	Unit
0	Cut this portion of the bolt. Otherwise, it will be an obstacle to remove the service cover
3	Mortar hole (Ø100 x Depth 150)
4	Anchor bolt M10
6	Drainage (Wide 100 x Depth 150)
6	Drainage
0	Vibration-proof rubber
U	

- Suspended unit. Installation in the ceiling.
- 1. Suspend the unit as the drawing indicates.
- 2. Ensure that ceiling can resist the unit weight, which is indicated in the specification label.
- 3. Install the unit so that the drain outlet parts are slightly (approx. 20 mm) lower than the other side, in order to avoid incorrect drain discharge.

Mark	Sling bolt pitch	
Model	3-5HP	10HP
A(mm)	1250	1770
B(mm)	1300	1113

	WARNING
	lown. Can cause serious injury or death. If the unit is suspended in the ceiling, ensure that the place for n is strong enough. If not, reinforce the place with beams, etc., (more than 150 kg for one sling bolt).


1.1.5. Available configurations

Different configurations are available for RASC unit only changing the inlet/outlet air panels (and fan position for the case of RASC-10HRNE).

• Air inlet modification (optional)


Changing air inlet is only necessary to interchange the indicated panels position. Both panels use screws to be fixed to unit chasis.

View from top




• Air outlet modification (option only for RASC-10HRNE)

Changing air outlet is necessary to interchange panels too. Fan outlet panel is attached to fan structure, which must be mounted as follow:



1.1.6. Duct connection

Install the duct with down slope to prevent entry of rain water. Also, provide insulation for duct and connection in order to prevent dew formation.



2. Piping Installation


This chapter provides information about the procedures to perform water piping work connections for outdoor units.

Contents

2.	Pip	ing installation	27
2.1.	G	eneral notes	
2.2.	Pi	iping work connection considerations	
2.2	.1.	Piping materials	
2.2	.2.	Three principles on refrigerant piping work	
2.2	.3.	Suspension of refrigerant piping	
2.2		Brazing work	
2.2		Caution of the pressure by check joint	
2.2		Refrigerant charge quantity	
2.2	.7.	Pump down refrigerant	35
2.3.	S	uspension of refrigerant piping	
2.4.	Pi	iping connection	37
2.4	.1.	Tightening torque	
2.4	.2.	Flange piping connection (only for RASC-10HRNE)	
2.5.	Pi	iping and refrigerant charge	40
2.5	.1.	General process	40
2.5	.2.	Refrigerant piping range	41
2.5	.3.	Refrigerant piping length	
2.5	.4.	Refrigerant piping selection	44
2.6.	T۱	win and quad system installation	45
2.6	1	Height difference between indoor units and distributor	45
2.6		Installing distributor	
2.7.	R	asc unit factory refrigerant charge (wo kg)	47
2.8.	A	dditional refrigerant charge calculation	47
2.9.	D	rain piping	48

2.1. General notes

- 1. Connect all pipes as close as possible to the unit, so that disconnection can be easily performed when required.
- 2. Install the drainage in accordance with national and local codes.
- 3. Do not install the drain-pipe in an up-slope position. Installing it like this, the drain water cannot be evacuated and will flow back to the unit, causing a possible leakage when the operation is stopped. Always install the unit higher than the exit of the pipe. Making this so, the water will flow easily to the outside.



- 4. It is recommended to use flexible joints for the piping of water inlet and outlet, so vibration will not be transmited.
- 5. Do not connect the drain pipe with the sanitary piping, the sewage piping or any other drainage piping.
- 6. The drain pipe will require insulation if it is installed in a location where the ambient humidity may condensate on the drain pipe outer surface. This condensation could drop and cause damage. The insulation for the drain pipe must be selected in order to ensure that the vapor is sealed and in order to prevent the condensation forming.


2.2. Piping work connection considerations

2.2.1. Piping materials

1. In order to avoid supply problems in terms of local regulations and quality, prepare locally-supplied copper pipes.

i	NOTE
	e of using copper pipes for piping sections bigger than Ø 19.05 mm (3/4 inches), flaring work cannot be ned. If necessary, use a joint adapter.


- 2. Select clean copper pipes. Make sure there is not dust and moisture inside. Blow the inside of the pipes with oxygen free nitrogen to remove any dust and foreign materials before connecting the pipes.
- 3. After connecting the refrigerant piping, seal the open space between Knockout hole and refrigerant pipes by using insulation material as shown below:




- CAUTION
- Several hazards due to contamination or impacts. Can cause serious injury.
 Do not use a sew and a grindstone or other tools which cause conner nowd.
- Do not use a saw and a grindstone or other tools which cause copper powder.
- When cutting pipes, secure the part for brazing in accordance with both national and local regulations.
- Use security glasses and gloves for cutting or welding works.

• Piping Connection

When connecting liquid piping for units with piping longer than 15 meters, apply a piping size of Ø9.53 mm (3/8 inches). Fix the connecting pipe as shown in the following figure using the insulation attached to the Indoor Unit.




NOTE - A system with no moisture or oil contamination will give maximum performance and lifecycle compared to a poorly prepared system. Take particular care to ensure that all copper piping is clean and dry internally. - To ensure this, blow oxygen-free nitrogen through the pipes. - When inserting a pipe through any hole protect the end with a cap. - Do not put pipes on the ground directly without a cap or vinyl tape at the end of the pipe




- If the piping installation is not completed until the next day or even over a longer period of time, braze off the ends of the piping and charge the pipe with oxygen-free nitrogen through a Schrader-valve-type access-fitting, to prevent moisture and particle contamination entering.
- Do not use insulation material that contents NH3. NH3 can damage the cooper pipe material and can be a source of future leakages

Insulation

Attach the pipe insulation to each branch using vinyl tape. Attach also insulation to field supplied pipes in order to prevent the capacity decrease according to the ambient air conditions and dewing on the low pressure pipe surface.





2.2.2. Three principles on refrigerant piping work

In case of using refrigerant R410A in the refrigeration cycle, the refrigeration oil should be of a synthetic type one.


In order to avoid oxidation, pay much careful attention to basic piping work control to avoid infiltration of moisture or dust during the refrigerant piping work.

Three principles	Cause of failure	Presumable failure	Preventive action	
1. Dry Keep good dryness	 Water infiltration due to insufficient protection at pipe ends Dewing inside of pipes Insufficient vacuum pumping time 	Icing inside tube at ex. valve (Water choking) + Generation of hydration and oxidation of oil ↓ Clogged strainer, etc., insulation failure and compressor failure	Pipe protection 1 Pinching 2 Taping ↓ Flushing ↓ Vacuum Drying - One gram of water turns into gas (approx. 1000 lrs) at 1 Torr - Therefore, it takes long time to vacuum-pump by a small vacuum pump	
2. Clean No dust inside of pipes	 Infiltration of dust or other through the pipe ends Oxidation film during brazing without blowing nitrogen Insufficient flushing by nitrogen after brazing 	Clogging of expansion valve, capillary tube and filter Oxidation of oil Compressor failure ↓ Insufficient cooling or heating compressor failure	Pipe Protection 1 Mounting Caps 2 Taping 3 Pinching ↓ Flushing	
 3. No leakage No leakage shall exist Failed flaring work and insufficient torque of squeezing flare Insufficient torque of squeezing flanges 		Refrigerant shortage Performance decrease Oxidation of oil	Careful Basic Brazing Work ↓ Basic Flaring Work ↓ Basic Flange Connecting Work ↓ Air Tight Test ↓ Holding of Vacuum	

(Comes from page 2-5)


2.2.3. Suspension of refrigerant piping

Suspend the refrigerant piping at certain points and prevent the refrigerant piping from touching weak parts of the building such as walls, ceiling, etc. (If touched, abnormal noises may occur due to the vibration of the piping. Pay special attention in case of short piping length).



In order to fix the piping to wall or ceilings use suspension and clamping systems as shown in the following figure.

31



2.2.4. Brazing work

The most important work in the refrigerant piping installation work is the brazing of the pipes. If it accidentally occurs a leakage due to a careless brazing process, it will cause clogged capillary pipes or serious compressor failure.


It is important to control the clearance of the pipe fitting portion as shown below. In the case that a cooper tube expansion jig is used, following dimensions should be secured.

In order to guarantee a proper brazing neck between different pipes surfaces, accurate pipe dimensions after the expansion process (see the following table):

Copper pipe size	Ød1	Gap	а	Copper pipe size	Ød1	Gap	а
+0.08 Ø6.35	+0.1 Ø6.5	0.33	6	+0.09 Ø22.22	+0.1 Ø22.42	0.39	10
-0.08	0	0.07		-0.09	0	0.11	
+0.08 Ø9.53	+0.1 Ø9.7	0.35	8	+0.12 Ø25.4	+0.1 Ø25.6	0.42	12
-0.08	0	0.09		-0.12	0	0.08	
+0.08	+0.1	0.38		+0.12	+0.1	0.42	
Ø12.7	Ø12.9		8	Ø28.58	Ø28.78		12
-0.08	0	0.19		-0.12	0	0.08	
+0.09	+0.1	0.41		+0.12	+0.1	0.47	
Ø15.88	Ø16.1		8	Ø31.75	Ø32.0		12
-0.09	0	0.13		-0.12	0	0.13	
+0.09	+0.1	0.44		+0.12	+0.1	0.52	
Ø19.05	Ø19.3		10	Ø38.1	Ø38.3		14
-0.09	0	0.16		-0.12	0	0.18	

A basic brazing method is shown below.

- Pre-heat the outer tube for better flowing of the filler metal
- Heat inner side tube evenly
- 8 Rubber plug
- Packless valve
- High pressure hose
- **6** 0.03 to 0.05 MPa (0.3 to 0.5 Kg/cm² G)
- Reducer valve: open this valve only when the gas is needed
- In Nitrogen gas flow 0.05m³/h or smaller



2

	CAUTION
Risk o	f explosion. Can cause serious injuries and generate poisonous gases.
Use ni	trogen gas for blowing during pipe brazing. Do not use oxygen, acetylene or fluorocarbon gas.
	reducer valve when nitrogen gas blowing is performed during brazing. The gas pressure should be ined within 0.03 to 0.05 MPa.
an exp	charge OXYGEN, ACETYLENE, or other flammable and poisonous gases into the refrigerant because losion will occur. It is recommended that oxygen free nitrogen be charged for these types of tests cycle performing a leakage test or an airtight test. These types of gases are extremely dangerous.
Insulat	e the unions and flare-nuts at the piping connection part completely.
	e the liquid piping completely to avoid a decrease of performance; if not, it will cause sweating on the e of the pipe.
Charge	e refrigerant correctly. Overcharging or insufficient charging could cause a compressor failure.
	for refrigerant leakage in detail. If a large refrigerant leakage occurred, it would cause difficulty with ing or harmful gases would occur if a fire were being used in the room.
If the f	are nut is tigthened too hard, the flare nut may crack after a long time and cause refrigerant leakage.
\boldsymbol{i}	NOTE
During	the brazing work, a lot of oxidation film will be generated inside of the pipes if no oxygen-free nitrogen

2.2.5. Caution of the pressure by check joint

When the pressure is measured, use the check joint of gas stop valve (**①**), and use the check joint of liquid piping (**②**) in the figure below.

gas is blown through the pipes. This film will be flecked off after operation and will circulate in the refrigeration

cycle, resulting in clogged expansion valves, etc. This coud origin problems in the compressor.

At that time, connect the pressure gauge according to the following table because of high pressure side and low pressure side changes by operation mode.


	Cooling Operation	Heating Operation
Check joint for gas stop valve "	Low pressure	High pressure
Check joint for piping "2"	High pressure	Low pressure
Check joint for liquid stop valve "I	Exclussive for vacuum pump a refrigerant charge	

i

NOTE

- Be careful that refrigerant and oil do not splash to the electrical parts when removing the charge hoses.

The below figures show examples of 3/5 HP and 10HP



RASC-(3/5)HVRNE case



RASC-10HRNE case


2.2.6. Refrigerant charge quantity



- Some types of gases are extremely dangerous and can cause an explosion. It is recommended that compressed air, nitrogen or refrigerant be used for these types of tests.
- Check to ensure that no pressure exists inside the stop valve before removing the flange.
- Use refrigerant R410A in the refrigerant cycle. Do not charge oxygen, acetylene or other flammable and poisonous gases into the refrigerant cycle when performing a leakage test or an air-tight test.

Evacuation and refrigerant charge

- Evacuation and refrigerant charging procedure should be performed according to the following instructions.
- The stop valve has been closed before shipment. However, make sure that the stop valves are closed completely. Connect the indoor unit and the outdoor unit with field-supplied refrigerant piping.
- Connect the gauge manifold using charging hoses with a vacuum pump or a nitrogen cylinder to the check joints of the liquid line and the gas line stop valve.
- Check for any gas leakage at the flare nut connection, by using nitrogen gas to increase the pressure at 4.15 MPa inside of the field-supplied piping.
- Operate the vacuum pump for 1 to 2 hours until the pressure decreases lower than a pressure of 756 mm Hg in vacuum.
- For charging refrigerant, connect the gauge manifold using charging hoses with a refrigerant charging cylinder to the check joint of the liquid line stop valve.
- Charge the proper quantity of refrigerant according to the piping length (Calculate the quantity of the refrigerant charge).
- Fully open the gas line stop valve, and slightly open the liquid line stop valve. _
- Charge refrigerant by opening the gauge manifold valve.
- Charge the required refrigerant within the difference range of ±0.5kg by operating the system in cooling.
- Fully open the liquid line stop valve after completing refrigerant charge.
- Continue cooling operation for more than 10 minutes to circulate the refrigerant.
- Remove the "close" plate from the stop valve and hook the attached "open" plate at the stop valve.




Example of evacuation and refrigerant charge for RASC-H(V)RNE

	i	NOTE
-		to ensure that there is no gas leakage. When large amount of the refrigerant leaks, the troubles as s may occur:

- Oxygen deficiency.
- Generation of Harmful gas Due to Chemical Reaction with fire.
- Use thick gloves to protect your hands from liquid refrigerant injuries when handling refrigerant.
- Charge the refrigerant correctly after calculation. Overcharge or insufficient charge of the refrigerant may cause the compressor failure. Insulate the liquid pipe for prevention of the capacity decrease according to the ambient air conditions and the dewing on the pipe surface by the low pressure.

Outdoor units has been charged with refrigerant for 20 m (RASC-3HVRNE) or 30 m (RASC-5HVRNE) of pipe length. It is required that additional refrigerant be charged according the piping length if it is longer than 20 m (RASC-3HVRNE) or 30 m (RASC-5HVRNE).



2.2.7. Pump down refrigerant

When the refrigerant should be collected into the RASC unit due to indoor/outdoor unit relocation, collect the refrigerant as follows:

- 1. Attach the manifold gauge to the gas stop valve and the liquid stop valve
- 2. Turn ON the power source
- 3. Set the DSW1-1 pin of the RASC unit PCB at the "ON" side for cooling operation. Close the liquid stop valve and collect the refrigerant.
- When the pressure at lower pressure side (gas stop valve) indicates -0.01 MPa (-100 mmHg), perform the following procedures immediately. Close the gas stop valve.

Set the DSW1-1 pin at the "OFF" side (To stop the unit operation).

5. Turn OFF the power source.


35



CAUTION
- Incorrect pressure. Compressor failure. Measure the low pressure by the pressure gauge and keep it in a
measurement higher than -0.01 MPa.

2.3. Suspension of refrigerant piping

Suspend the refrigerant piping at certain points and prevent the refrigerant piping from touching weak parts of the building such as walls, ceiling, etc. If touched, abnormal noises may occur due to the vibration of the piping. Pay special attention in case of short piping length.



Do not fix the refrigerant piping directly with the metal fittings (The refrigerant piping may expand and contract). In order to fix the piping to wall or ceilings, use suspension and clamping systems as shown in the following figure.



Heavy piping suspension




Piping along the wall

Instant installation work

2.4. Piping connection

- 1. Stop valve is located on rear cover side of unit. Before connecting refrigerant piping, the stop valve protection cover shall be removed.
- 2. It is recommended to use a tube bender for pipe bending work.
- 3. For gas pipe connection, use the factory supplied flange pipe (Only for RASC-10HRNE).




2.4.1. Tightening torque

See tighten torque in the next table:

		Size		Tightening torque (N.m)				
	Valve		Pipe size	Allen wrench size	A	в	с	D
Liquid	RASC-(3/5) HVRNE	Fig. a	9.53 (3/8")	4 mm	8	16.5	40	14~18
Liq	RASC-10HRNE	Fig. a	12.7 (1/2")	5 mm	8	38	40	9.8
Gas	RASC-(3/5) HVRNE	Fig. a	15.88 (5/8")	5 mm	10	30	80	14~18
Ű	RASC-10HRNE	Fig. b	25.4 (1")	10 mm	25	49	55~75(*)	9.8

(*) Flange connection, check specific instruction on flange piping connection paragraph.



	CAUTION	
- Damage to devices. Unit failure. At the test run, fully open the spindle valve.		


NOTE

Do not apply force to the spindle valve at the end of opening (5 N.m or smaller). The back seat construction is not provided.

i


2.4.2. Flange piping connection (only for RASC-10HRNE)

Confirm that the valve is closed. Prepare a field-supplied bend pipe for liquid line. Connect it to the liquid valve by flare nut through the square hole of bottom base.



Factory supplied accesory


Prepare a field-supplied pipe for gas line. Solder it and the factory-supplied pipe flange at the outside of the unit. Connect the pipe flange to gas valve with the factory-supplied gasket through the square hole of Bottom Base. Do not use the gasket that had been attached to the unit.



2.5. Piping and refrigerant charge

2.5.1. General process


- 1. Prepare locally-supplied copper pipes.
- 2. Select the piping size with the correct thickness and correct material, which must have sufficient pressure strength.
- 3. Select clean copper pipes. Make sure there is no dust and moisture inside. Blow the inside of the pipes with oxygen free nitrogen to remove any dust and foreign materials before connecting pipes.
- 4. After connecting the refrigerant piping, seal the open space between knockout hole and refrigerant pipes by using insulation material as shown below:





NOTE


- A system with no moisture or oil contamination will give maximum performance and life cycle compared to a poorly prepared system. Take particular care to ensure all copper piping is clean and dry internally.
- There is no refrigerant in the cycle of the indoor unit.



2.5.2. Refrigerant piping range

The piping selection and the distribution must be designed according to the following specifications:


Example of single and twin systems



Iter	n	Applicable range		
		RASC-3HVRNE	RASC-5/10H(V)RNE	
Actual length between	Single: L	30	50	
O.U. and the farthest I.U.	Twin: C + (A or B)	50	50	
Equivalent length between	Single: Leq	45	70	
O.U. and the farthest I.U.	Twin: (C + (A or B))eq	40	70	
Total pipin	g length			
Piping length from e	each I.U.: A,B (m)			
Lift between I.U. and	O.U. is higher: +H (m)	3	0	
O.U.: H (m)	O.U. is lower: -H (m)	2	20	
Lift between I.U. (m)		0.5		
			I.U.: indoor unit	

2.5.3. Refrigerant piping length

The refrigerant piping length between indoor units and outdoor units must be designed using the following chart. Maintain the design point within the dark area of the chart, which shows the height difference according to the piping length.



• Maximum piping length according to the unit:


		Maximum piping length		
Mark	Unit	Actual piping length	Equivalent piping length	
	RASC-3HVRNE	≤ 30 m	≤ 45 m	
	RASC-(5/10)H(V)RNE	≤ 50 m	≤ 70 m	

L = Piping length.

Í	NOTE
Howe	the branch pipe at the location from where the piping length to the indoor units is of equal distance. /er, when different piping lengths from the branch pipe to the indoor units, due to building construction are ed, the difference between the two pipes should be less than 8 m.

• Single combination example based on RASC-3HVRNE and RPI models:





_>			_>>	-#	
Cooling Refrigerant	Heating Refrigerant	Installation	Flare Nut		
Flow	Flow	Refrigerant Piping	Connectiion	Flange Connection	Brazing Connection
		Line			

N°	Name of Item
1	Compressor
2	Heat exchanger
3	Liquid tank
4	Strainer
5	Distributor
6	Revercing valve
7	Capilary tube
8	Electronic expansion valve
9	Solenoid valve
10	Check joint
11	Stop valve for liquid line

N٥	Name of Item
12	Stop valve for gas line
13	High pressure switch for protection
14	Pressure switch for control
15	Ambient thermistor
16	Condenser pipe thermistor
17	Discharge gas thermistor
18	Indoor exchanger
19	Strainer
20	Electronic expansion valve
21	Distributor

2.5.4. Refrigerant piping selection

Select the piping connection sizes according to the following procedures:

Between outdoor unit and branch pipe: Select the same pipe connection size as the pipe size of the Outdoor unit

Between branch pipe and indoor unit: Select the same pipe connection size as the pipe size of the indoor unit


Unit	Gas piping	Liquid	Distributor	
Onit	size	piping size	Twin	Quad
RASC-3HVRNE	15.88 (5/8")	9.53 (3/8")	TE-03N	-
RASC-5HVRNE	15.88 (5/8")	9.53 (3/8")	TE-56N	-
RASC-10HRNE	25.4 (1")	12.7 (1/2")	TE-10N	QE-810N

For RASC-10HRNE units, use a reducer pipe in the following installations:

Installation		Pipe			
type	Distributor	Type	Dimensions		
type		Type	а	b	
Single	-	Gas	Ø 25.4 (1")	Ø 22.2 (7/8")	
Single		Liquid	Ø 12.7 (1/2")	Ø 9.53 (3/8")	
Twin	TE-56N	Liquid	Ø 9.53 (3/8")	Ø 6.35 (1/4")	
Quad	QE-810N	Liquid	Ø 12.7 (1/2")	Ø 9.53 (3/8")	

Piping size for indoor unit.

The piping size for indoor unit are as follows:




2.6. Twin and quad system installation

2.6.1. Height difference between indoor units and distributor

Install all indoor units at the same height. When the height difference between the indoor units due to building construction is necessary, this should be less than 0,5 meters. Install the branch pipe at the same height of indoor units or lower, but never higher.

Sample: Twin system




2.6.2. Installing distributor

- 1. Install the distributor supplied by Hitachi on request A tee can not be installed instead of a branch pipe.
- Sample: Twin system



2. Installing the distributor. Fix the branch pipe horizontally to the pillar, wall or ceiling. Piping must not be fixed rigidly to the wall as thermal expansion and contraction can cause pipe fracture.


Sample: Twin system




- Fix the piping from outside of insulation or inserting absorber between the pipe and a fixing metal.

3. Correct position of twin distributor


This is the correct position of twin branch pipe:




This is wrong position.



4. Correct position of quad distributor. Install the header horizontally.



Liquid piping



• Tightening flare nuts

Pipe size	Tightening torque (N.m)
Ø6.35 mm	20
Ø9.53 mm	40
Ø12.70 mm	60
Ø15.88 mm	80
Ø19.05 mm	100

Brazing work

	WARNING			
- Use - Use	 Explosion risk. Can cause serious injury. Use nitrogen gas for blowing during pipe brazing. Do not use oxygen, acetylene or fluorocarbon gas. Use a reducer valve when nitrogen gas blowing is performed during brazing. The gas pressure should be maintained within 0.03 to 0.05 Mpa. Do not apply excessively high pressure to a pipe. 			
j	NOTE			
film w	f oxidation film will occur inside of tubes if no nitrogen gas blowing is performed during brazing work. This ill be flecked off after operation and will circulate in the cycle, resulting in clogged expansion valves, etc. vill cause bad influence to the compressor.			

2.7. Rasc unit factory refrigerant charge (wo kg)

Rasc unit factory refrigerant charge (wo kg) is the next:

O/U MODEL	Wo Factory Charge (Kg)
RASC-3HVRNE	2.8
RASC-5HVRNE	4.0
RASC-10HRNE	9.0

i

NOTE

In case of the actual piping length is less than 5 m, total refrigerant quantity should be according to the table below.

2

O/U MODEL	Refrigerant quantity (Kg)
RASC-3HVRNE	2.3
RASC-5HVRNE	3.3
RASC-10HRNE	7.4

2.8. Additional refrigerant charge calculation

• See the following table:


O/U MODEL	Wo: Factory Charge (Kg)	ℓ Charge-less Length (m)	p Compensating Rate (kg/m)
RASC-3HVRNE	2.8	20	0.06
RASC-5HVRNE	4.0	30	0.06
RASC-10HRNE	9.0	30	0.12

• Single system


Calculate piping length AL(m)

RASC-5/10H(V)RNE

AL: Piping Length
ℓ: Charge-less piping length
(a): No additional charge is required AL≤ ℓ
(b): Additional charge is required AL≥ ℓ
W (additional charge quantity) = (AL- ℓ) x p



Example:




W (additional charge quantity) = (45-30) x 0.06 = 0.9 kg

• Twin system


Calculate piping length AL(m) AL= A + B + C

AL: A+B+C ℓ: Charge-less piping length W (additional charge quantity) = (AL-ℓ) x p




2.9. Drain piping


1. Drain pipe location is indicated in the below figures.



RASC-10HRNE



2. Connect a siphon as shown in the figure below. Pay special attention when connecting it to the unit (proper installation work is needed in order to guarrantee connection pipes matching).



- 3. Fasten the siphon to the drain hose with an adhessive and a field-supplied clamp.
- 4. Prepare a draining pipe of 25 OD (outer diameter) for the draining line which shall be performed by a down slope of 2 %.
- 5. Check to ensure that the water drains smoothly by pouring some water into the drain pan.
- 6. Check to ensure that the water do not remain in the drain pan.
- 7. Check the drain connections periodically (once a year) in order to detect water leakage.

j	NOTE
	unit is installed in a cold area, the drain water may freeze. Install an electric heater (field- lied) at the drain connection.

3. Electrical Wiring

This chapter describes the procedures to carry out the electrical wiring connections for outdoor units.


Contents

3.	El	lectrical wiring	51
3.1	. (General check	52
3.2	. E	Electrical wiring for outdoor units	53
-	.2.1 .2.2.	···· · · · · · · · · · · · · · · · · ·	53 54
3.3	. E	Electrical wiring between indoor unit and outdoor unit	57
34			
0	. \	Wire size	58
		Wire size	

3.1. General check

DANGER

- Electrical hazard. Can cause serious injuries or death.
- Do not connect or adjust any wiring or connections unless the main power switch is OFF.
- Check that the earth wire is securely connected, tagged and locked in accordance with national and local codes.
- Check and test to ensure that if there is more than one source of power supply, that all are turned OFF.
- Check to ensure that the indoor fan and the outdoor unit have stopped before electrical wiring work or periodical check is performed.
- Check to ensure that the screws of the terminal block are tightly tightened.



- Ensure that the field-supplied electrical components (mains power switches, circuit breakers, wires, connectors and wire terminals) have been properly selected according to the electrical data indicated. Make sure that they comply with national and regional electrical codes.
- Following the Council Directive 2004/108/EC(89/336/EEC), relating to electromagnetic compatibility, as the next table indicates. Maximum permissible system impedance Zmax at the interface point of the user's supply, in accordance with EN61000-3-11:

MODEL	Zmax (Ω)
RASC-3HVRNE	0.26
RASC-5HVRNE	0.19
RASC-10HRNE	0.20

3. Harmonics situation of each model regarding IEC 61000-3-2 and IEC 61000-3-12 is as follows:

MODELS SITUATION REGARDING IEC 61000-3-2 AND IEC 61000-3-12 Ssc "xx"	MODELS(*)	Ssc "xx" (KVA)
Equipment complying with IEC 61000-3-12	RASC-3HVRNE RASC-5HVRNE	-
This equipment complies with IEC 61000-3-12 provided that the short-circuit power Ssc is greater than or equal to xx (see Ssc column) at the interface point between the user's supply and the public system. It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with a short-circuit power Ssc greater than or equal to xx (see Ssc column)		
Installation restrictions may be applied by supply authorities in relation to harmonics	RASC-10HRNE	-
This(ese) unit(s) is(are) out of scope of IEC 61000-3-12	-	-


- 4. Check to ensure that the power supply voltage is within +/-10% of the rated voltage.
- 5. Check to ensure that power supply has an impedance low enough to warranty not reduce the starting voltage more than 85% of the rated voltage.
- 6. Check to ensure that the ground wire is connected.
- 7. Connect a fuse of specified capacity.

3.2. Electrical wiring for outdoor units


3.2.1 Electrical wiring connection for outdoor units

The electrical wiring connection for the outdoor unit is as shown below:

• RASC-(3/5)HVRNE




RASC-10HRNE




3.2.2. Setting of DIP switches for outdoor unit

• Quantity and location of DIP switches

The PCB in the outdoor unit is operating with 5 types of DIP switches, 1 slide switch and 3 push switches. The location is as follows:





• DSW1: Test run

Function	Setting position	Remarks
Setting before shipment	ON 1234	
Test run for cooling	ON 1234	Continuous operation during 2 hours is performed without thermo OFF. The 3 minutes guard
Test run for heating	ON 1 2 3 4	for compressor protection is not effective during the test run operation.
Forced stop of compressor (1)	ON 1234	The compressor is OFF during this operation

i

NOTE

- It is possible to select the cancellation of the outdoor hot start control by pushing both PSW1 & PSW3 simultaneously during 3 seconds.
- This operation is reset once the compressor is in Thermo-ON mode.
- The cancellation of the outdoor hot start control configuration could damage the compressor if it is usually used. In that case the unit warranty will be void.

• DSW2: Piping length/selection function

Function	Setting position	Remarks
Setting before shipment	ON 123456	
Function selection setting	ON 123456	Function selection is set by PSW
External input/output selection	ON 123456	External input/output selection is set by PSW

• DSW3: Capacity setting

Unit	Setting position	Remarks
RASC-3HVRNE	ON 123456	
RASC-5HVRNE	ON 123456	No setting is required
RASC-10HRNE	ON 123456	

• DSW4 / RSW1: Refrigerant cycle setting

In case of using an H-Link II net it is required to set the refrigerant cycle number.

	Setting position (DSW4)		Setting position (RSW1)
Setting for tens (second digit)	ON 123456	Setting for units (first digit)	$\begin{pmatrix} 0 & 0 & 0 \\ 0 & 0 $
Example for 16	ON 123456	and	

Rotary switches' positions (RSW1) are set by inserting a screw driver into the groove.

DSW5: Transmission setting of end terminal resistance

Function	Setting position	Remarks
Setting before shipment	ON 12	Setting before shipment: pin # 1 setted ON. In case of having 2 or more RASC
Cancellation	ON 12	units connected to the same H-Link, set for the second unit, pin #1 OFF. If only one RASC unit is used, no setting is required.

DSW6: Power source setting

Function	Setting position	Remarks
RASC-(3/5)HVRNE 220~240V (setting before shipment)	ON 12	
RASC-10HRNE 380~415V (setting before shipment)	ON 12	No setting is required

• Jumper setting


Jumper	Function	Remarks
JP1	Cut: Anual cooling mode	
JP5	Cut: Simultaneous defrost prevention	-

3.3. Electrical wiring between indoor unit and outdoor unit

Connect the electrical wires between the indoor unit and the outdoor unit, as shown below.

Check to ensure that the terminal for power source wiring (terminals "L1" to "L1" and "N" to "N" of each terminal board: AC230V), and intermediate wires (Operating line: terminals "1" to "1" and "2" to "2" of each terminal board: DC5V) between the indoor unit and the outdoor unit are connected correctly. If not, some component will be damaged.

- Follow local codes and regulations when performing electrical wiring.
- Connect the operation wiring to the units in the same refrigerant cycle (The refrigerant piping and the control wiring should be connected to the same indoor units). If the refrigerant piping and the control wiring are connected to the units in the different refrigerant cycle, it may cause a abnormal operation. Use twist pair wire (more than 0.75 mm²) for operation wiring between outdoor unit and indoor unit, and operation wiring between indoor units (H-Link connection). It can be also used shielded pair wiring. Shield shall be connected to earth only in one cable side.
- Use shielded wires for intermediate wiring to protect the units from noise obstacle at length of less than 300 m and size complied with local code.
- Do not use more than 3 cores for operation wiring (H-Link). Core sizes must be selected according to the national regulations.
- Open a hole near the connection hole of power source wiring when multiple outdoor units are connected from one power source line.
- The recommended breaker sizes are shown in Table of electrical data and recommended Wiring, Breaker Size/1 O.U.
- In the case that a conduit tube for field-wiring is not used, fix rubber bushes with adhesive on the panel.
- All the field wiring and equipment must comply with local and international codes.






NOTE


Incorrect wiring. Possible failure of PCB. Pay attention to the connection of the operating line.

RASC-(3/5)HVRNE •



- Optional acce

RASC-10HRNE •



3.4. Wire size

Recomended minimum sizes for field provided wires: •

				Power source cable size		Transmitting cable size	
Model	Power source	Max. Current	EN60 335-1	MLFC O	EN60 335-1	MLFC 2	
All indoor units(*)	1~ 230V 50Hz	5 A	0.75 mm²	0.5 mm²			
RPI-8/10		10 A	1.5 mm ²				
RASC-3HVRNE	1~ 230V 50Hz	28 A	6 mm²	3.5 mm²	0.75 mm ²	0.5 mm²	
RASC-5HVRNE	1~ 230V 50Hz	37 A	10 mm²	5.5 mm²			
RASC-10HRNE	3N~ 400V 50Hz	33 A	10 mm²	5.5 mm²			
(*) Except RPI-8/10							

The wire sizes marked in the table with 1 are selected by 125% of the maximum current of the unit according to the European Standard, EN60 335-1.

٠

- The wire sizes marked in the table with ② are selected by 125% of the maximum current of the unit according to the wire, MLFC (Flame Retardant Polyflex Wire) manufactured by HITACHI Cable Ltd. Japan.
- In case that the power wires are connected in series, add each unit maximum current and select the wire size according to the next table:

Selection according to EN60 335-1		Selection according to MLFC (at cable Temp. Of 60 °C)	
Current i (A)	Wire Size (mm ²)	Current i (A)	Wire Size (mm ²)
l ≤ 6	0.75	l ≤ 15	0.5
6 < i ≤ 10	1	15 < i ≤ 18	0.75
10 < i ≤ 16	1.5	18 < i ≤ 24	1.25
16 < i ≤ 25	2.5	24 < i ≤ 34	2
25 < i ≤ 32	4	34 < i ≤ 47	3.5
32 < i ≤ 40	6	47 < i ≤ 62	5.5
40 < i ≤ 63	10	62 < i ≤ 78	8
63 < i	8	78 < i ≤ 112	14
		112 < i ≤ 147	22

3

3 In case that current exceeds 63 A do not connect cables in series

İ


NOTE


- Follow local codes and regulations when selecting field wires, circuit breakers and earth leakage breakers.
- Use the wires which are not lighter than the ordinary polychloroprene sheathed flexible cord (code designation H05RN-F).
- Use shielded wires for transmission between indoor and outdoor units, and connect the shielded part to the earth screw in the electrical box of the indoor unit as shown below.

Select the main switches in according to the next table:

Model	Power source	Max. Current	СВ	ELB (no. poles/A/mA)
All Indoor Units (*)	1~ 230V 50Hz	5A	6A	
RPI-8/10	1~ 230V 50Hz	10A	10A	2/40/30
RASC-3HVRNE	1~ 230V 50Hz	28A	40A	
RASC-5HVRNE	1~ 230V 50HZ	37A	50A	2/63/30
RASC-10HRNE	3N~ 400V 50Hz	33A	40A	(informed later)

ELB: Earth switch; CB: Switch; (*) Except RPI-8/10HP





┉

ł

AIR

Å.

L+0

Disposal of Electric Parts in RASC Unit

1

OUTLET

_____ ⊜5 8

I.F. Connector

CH FS DS1,DS2

Docition

the DIP Switch

indicates


<u>tar</u>

_____ ⊧•≘ ⊒≪

Me Cano

1N~ 230V 50Hz





SMGB0043 rev.1 - 04/2010

Δ

4. Control System

This chapter presents the control system flowcharts for the H(V)RNE RASC series and the complete range of the Hitachi indoor units.

Contents

4.	Cor	ntrol system	63
4.1.	De	evice control system	64
4.2.	RA	ASC-(3~10)H(V)RNE PCB	66
4.3.	Pr	otection and safety control	67
4.4.	St	andard operation sequence	68
4.4	.1.	Cooling operation	.68
4.4	.2.	Dry operation	
4.4	.3.	Heating operation	.72
4.4	.4.	Defrost operation control	74
4.5.	St	andard control functions	75
4.5	.1.	Freezing protection during cooling process or dry operation	.75
4.5	.2.	Prevention control for excessively high discharge gas temperature	
4.5	.3.	Outdoor unit electrical expansion valve control	
4.5	.4.	Activation of protection device control	
4.5		Outdoor Unit fan control during cooling operation	
4.5		Outdoor unit fan control during heating operation	
4.5		Preheating control of compressor	
4.5	.8.	Prevention control for high pressure increase	.81

4.1. Device control system

O an track and the st	Purpose					
Control subject	Cooling operation	Heating operation	Defrost operation			
Control frequency of inverter compressor	 The frequency control is determined with the next parameters: Ratio (I.U. capacity/RASC capacity) Temperature difference between air inlet temperature and setting air temperature. 	 The frequency control is determined with the next parameters: Ratio (I.U. capacity/RASC capacity) Temperature difference between air inlet temperature and setting air temperature. 	Fixed frequency (stop compressor during 30 sec. After defrosting condition was completed.			
Opening degree expansion valve of RASC	Fully open	 Control range of expansion valve opening degree is determined to optimize temperature. on the top of compressor. When number of I.U. is decreased, determined with I.U. capacity. Ratio of (before/after decrease or with above condition). 	Fully open			
Opening degree expansion valve of indoor unit	 Control range of expansion valve opening degree is determined to optimize I.U. gas pipe temp. (Tg) - I.U. liquid pipe temp. (TI) difference. The expansion valve opening degree is controlled according to the number of connected I.U. 	 Specified opening degree at normal control starting. Afterward, controlled to optimize I.U. liquid pipe temp. (TI) The expansion valve opening degree is controlled according to the number of connected I.U 	Specified opening degrees controlled by temp. on the top of compressor. (Td).			
Outdoor unit fan	 Fan step is operated for RASC liquid pipe temp. (Te) stabilization control- increased number of I.U.: step-up decreased number of I.U.: step-down 	 Fan Step is controlled according to RASC liquid pipe temp. and temp. on the top of compressor. Increased number of I.U.: step-up decreased number of I.U.: step-down (limited the lowest by outdoor temp.) 	Fan stop.			
4-Way valve (RVR)	OFF	ON	OFF			
Solenoid valve (SVA) (By-Pass valve)	 Turn ON for 1 min. at starting and after compressor thermo-ON. Turn ON at pressure control switch activation. (RASC-(3~10)H(V)RNE) 	 Turn ON for 1 min. at starting and after compressor thermo-ON. Turn ON at pressure control switch activation. (RASC-(3~10)H(V)RNE) 	Turn OFF at defrosting			
Solenoid Valve (SVF) (Oil return)	Turn ON at compressor operation (RASC-10HRNE)	Turn ON at compressor operation (RASC-10HRNE)	-			

I.U.: Indoor unit

Tc / Te: Condensing temperature / Evaporating temperature

Td: Discharge temperature


TI: Liquid temperature

Tg: Gas temperature

Cap: Capacity

Temp.: Temperature

The figure below shows the outline of the control system




Symbol	Name	
MC	Motor (for compressor)	
MIF	Motor (for indoor fan)	
MOF	Motor (for outdoor fan)	
MS	Motor (for auto-louver)	
MV	Electronic expansion valve	
CMC	Compressor magnetic contactor	

Symbol	Name	
СН	Crankcase heater	
СТ	Current transformer	
RVR	4-Way valve	
SVA	Solenoid valve	
PSC	Pressure switch for control	
SSR	Solid state relay (Thyristor control)	

4.2. RASC-(3~10)H(V)RNE PCB

PCB drawing

The PCB in the outdoor unit is operating with 6 types of DIP switches, 1 rotary switch and 3 push switches. The location is as follows:



	Switch indication		
DSW1	Test run		
DSW2	Piping length and selection function		
DSW3	Capacity setting		
DSW4 & RSW1	Ref. cycle number setting		
DSW5	End terminal resistace setting		
DSW6	Power source setting		

	LED and jumper indication		
LED1	Red	This LED indicates the transmission status between the indoor unit and the RCS	
LED2	Yellow	This LED indicates the transmission status between the indoor unit and the outdoor unit	
LED3	Green	Power source for the PCB	
JP1	Annual cooling		
JP2	Release phase detection		
JP3	Self-diagnosis		
JP4	Fix cooling mode		
JP5	Alternative defrosting mode		
JP6	Control for existing piping		

i

NOTE

- The mark "■" indicates position of dips switches. Figures show setting before shipment or after selection.
- Not mark "■" indicates pin position is not affecting.
- Before setting dips switches, firstly turn off power source and set the position of the dips switches. If the switches are set without turning off the power source, the contents of the setting are invalid.

4.3. Protection and safety control

Compressor and fan motor protections

The following devices and their combinations protect the compressor and fan motor.

High-pressure switch	This switch cuts out the operation of the compressor when the discharge pressure exceeds the setting.
Oil heater	This band heater protects against the oil carry-over during the cold starting, as the band heater is energized while the compressor is stopped.
Fan motor protection	Internal thermostat that is embedded in the fan motor winding: this internal thermostat cuts out the operation of the fan motor when the temperature of the fan motor winding exceeds the setting.


RASC Safety and control device setting


Model			RASC-3HVRNE	RASC-5HVRNE	RASC-10HRNE
High pressure switch for compressor	Cut-out	MPa	-0.05 4.15 -0.15	-0.05 4.15 -0.15	-0.05 4.15 -0.15
	Cut-in	MPa	±0.15 3.20	±0.15 3.20	±0.15 3.20
Pressure switch for by-pass	Cut-out	MPa	+0.01 2.85 -0.01	+0.01 2.85 -0.01	+0.01 2.85 -0.01
	Cut-in	MPa	0 3.60 -0.15	0 3.60 -0.15	0 3.60 -0.15
Fuse	1~ 230V 50Hz	А	40	50	-
	3N~ 400V 50Hz	А	-	-	40x2
Cranckcase heater	Output	W	40x2	40x2	40x1
CCP timer		-	Non-adjustable		
Setting time		min.	3	3	3
Fan motor fuse		А	10	10	12 (MCB)
Internal thermostat	Cut-out	°C	130	130	145
	Cut-in	°C	60~110	60~110	70

MCB: Magnetic Circuit Breaker


4.4. Standard operation sequence


4.4.1. Cooling operation







4.4.2. Dry operation






4.4.3. Heating operation






SMGB0043 rev.1 - 04/2010

4.4.4. Defrost operation control




4.5. Standard control functions

4.5.1. Freezing protection during cooling process or dry operation



4.5.2. Prevention control for excessively high discharge gas temperature



Δ

4.5.3. Outdoor unit electrical expansion valve control

- 1. After supplying power source, the electronic expansion valve is completely opened.
- 2. When the compressor is stopped, the electronic expansion valve is completely closed to adjust its opening.
- 3. At starting operation (compressor is operated), opening of the electronic expansion valve is set at a specified opening.a) Specified opening during heating operation: 1 minute
- 4. During the cooling and the defrosting operations, the electronic expansion valve is set at the specified opening.
- 5. Normal opening of the electronic expansion valve.


Coling operation

• 480 pulse (100%)


Heating operation


- 1. Set of target temperature TdSH = 20~25 °C
- 2. Simulation PI control for the electronic expansion valve. The electronic expansion valve opening is controlled so that the thermistor temperatures for the compressor can reach the target temperature.

4.5.4. Activation of protection device control




4.5.5. Outdoor Unit fan control during cooling operation





4.5.6. Outdoor unit fan control during heating operation

4.5.7. Preheating control of compressor



4.5.8. Prevention control for high pressure increase

This function is performed to prevent the abnormal condition (Alarm: 02) when the outdoor air flow is decreased by a seasonal wind against air outlet.

When the **CMC** is ON during cooling operation, **PSC** is ON and (Te) is \geq than Te1+4°C, forced thermo-off operation will be performed.

(Te): Outdoor liquid pipe temperature

Te1: i/o liquid pipe temperature when PSC is ON

PSC ON: 3.60 MPa

However, if it occurs more than 6 times during operation, forced thermo-off operation will not be performed. Cause of stoppage will be 13(d1-13).

5. Available Optional Functions

Contents

5. Ava	illable optional functions	83
5.1. RA	ASC-(3~10)H(V)RNE Units	84
5.1.1.	Available ports	
5.1.2.	Configuration	86
5.1.3.	Description of optional input signals	
5.1.4.	Description of optional output signals	
5.1.5.	Optional functions	
5.1.6.	Outdoor units available optional functions	94
5.2. Av	vailable optional functions through the remote control switch (PC-ART)	95
5.2.1.	Optional function setting	
5.2.2.	Optional functions of the remote control switch	
5.3. Av	vailable optional functions through the remote control switch (PC-ARH)	108
5.3.1.	Alarm indication	
5.4. Av	vailable optional functions through wireless remote control switch (PC-LH3A + receive	er) 110

5.1. RASC-(3~10)H(V)RNE Units

The system has eight input and five output signals that are programmed in the PCB of the outdoor unit using connectors CN1 and CN2 for the input signals and CN7 for the output signal.

Connectors CN1 and CN2 have two and one ports respectively to configure three input options out of the eight options the system has.

Input connector CN1 has two ports to configure two input options out of the five options the system has. The system has ten optional functions that are programmed in the PCB of the outdoor unit.


5.1.1. Available ports

The system has the following input and output ports.

Con	tent	Setting of the port in the PCB of the indoor unit	Remarks	Outlet
	, 1	1-2 of CN1	1 0 0 0 2 00 3 0	Contact
Inputs	ų	2-3 of CN1		Contact
	Ē	1-2 of CN2	1 0 0 2 00	Contact
outs	۱ م	1-2 of CN7	1 0 X 2 0 3 0	DC 12V
Outputs	0Z	1-3 of CN7	1 0 X 2 0 3 0	DC 12V

Connection:

The system has the following connections.



	Output connections							
Indication	Connections							
בב	CN7 000 X3							

Specification of the components for a correct installation

Component		Manufacturer or specifications	Remarks	
Auxiliary relay (X3)		OMRON mini power relay model: MY1F or equivalent	Voltage between relay terminals 12 Vdc - 75 mA	
(SS1) (x1), (x2) contact example		SS1) (x1), (x2) contact example Manual type		
3P connector cable		Optional part PCC-1A (capable of connecting the JST XHP –3 connector)	Five wires with connectors as one set	
Wire (control Voltage: 12V DC.		0.5 mm²		
Wire (power)	Voltage 230V	2.0 mm ²		

[1]

NOTE

- The connection of the input signal is only an example.

- Keep the CN1 and CN2 wires as short as possible.

- Do not run the wires along 230 V/400 V CA power cables separately install them at a distance of more than 30cm. (The cables may intersect.)

- If you install the wires along a power supply wire, insert the wires in a metal conduit tube and ground one end of the tube.

- The maximum wiring length is 70 m. If you use this function, it is recommended that you use safety devices such as an electrical leakage breaker or a smoke detector.

5.1.2. Configuration

Available optional signals

H(V)RNE units have the following signals that are described in the following table. These signals are set up through the PCB of the outdoor unit.

• Input signals

Ind.	Input signal	Application	Port		
۵	N° setting application	N° setting			
1	Fixing the heating mode	This signal allows to pre-fix the operation mode, in this case the heating mode, independently of what the indoor unit requests. If the indoor units request the oposite mode than the outdoor unit, the compressor will not start. This is very useful to set up a unique operation mode.	CN1 and CN2		
2	Fixing the cooling mode This signal allows to pre-fix the operation mode, in this case the cooling mode, independentlyof what the indoor unit requests. If the indoor units request the oposite mode than the outdoor unit, the compressor will not start. This is very useful for computer rooms where the cooling mode is fixed throughout the year.				
з	Demand thermo OFF This signal allows to stop the compressor if it reaches a certain power as well as to put the indoor unit in Thermo-OFF. This is very useful for installations with high power consumption.				
ч	Forced stoppage This signal allows to control the stoppage of the compressor and the fans of the indoor as well as outdoor units. This is very useful when used with the alarm signals of the fire prevention systems.				
5	Current control demand 50%	This signal allows to regulate current consumption and establish an average consumption of 50% of the rate point. This is very useful for installations that run 24 hours a day.	CN1 and CN2		
Б	Current control demand 75% This signal allows to regulate current consumption and establish an average consumption of 75% of the rate point. This is very useful for installations that run 24 hours a day.		CN1 and CN2		
ר	Current control demand 100%This signal allows to regulate current consumption and establish an average consumption of 100% of the rate point. This is very useful for installations that run 24 hours a day.		CN1 and CN2		

Output signals

Ind.	Output signal Application			
۵	N° setting application	N° setting		
01	Operation signal Allows to pick up the machine's operation signal. This is very useful to start up additional systems such as humidifiers, fans and other additional air-conditioning systems.			
02	Alarm signal This signal picks up the machine's alarm. This is very useful to warn that an alarm has been tripped.		CN7	
03	Compressor ON signalThis single allows to pick up the compressor's operation signal. It is very useful for checking signals during remote-control operation and for the interlock of the outdoor unit.		CN7	
<u>0</u> 4	Defrost operation signal	This signal allows to pick up the defrosting of the unit. This is very useful to know how the indoor unit is operating if there is an abnormal situation.	CN7	

	NOTE
- Do not set same function (01	04) to multiple input port.

Programming

The optional signals are programmed through the PCB of the outdoor unit.


Setting of the optional signals

The optional signals of the outdoor unit are set up from the PCB of the outdoor unit and push switches PSW1, PSW2 and PSW3

Selection of the input signal


If the below setting change is required on-site, perform the following instructions:

 While the outdoor unit is ON, set the following DIP switches on the printed circuit board of the outdoor unit as follows: set pin 6 of DSW2 to ON. Because of these settings, the function selection mode becomes available and the following indication appears on the 7-segment display.



This indicates that function No.1 (set heating mode) is set at input 1.

- 2. By pressing the push switches PSW1, PSW2 and PSW3, you change the input/output terminal name. The flowchart shown on the side reflects the changes on the 7-segment display when you press PSW2 and PSW3.
- After selecting the input/output terminal name, select your required function by pushing the PSW1.
- 4. After setting the pin 6 of DSW2 to OFF, the selected contents are memorized in the PCB of the outdoor unit, and, immediately afterwards, the function selection mode is set to OFF. The memorized data is maintained even when the power supply wires are disconnected. The connection details of each function, as well as the required parts, are described in the first section.



5.1.3. Description of optional input signals.

• Fixing operation mode (heating / cooling) (ℓ / ਟ)


This input function is fixed in terminals CN1 or CN2 of the PCB of the outdoor unit, to use it as a cooling and heating mode. CN1 must be set up as follows.

Short circuit between the terminals 1 and 2 of CN1: set heating mode.

Short circuit between the terminals 2 and 3 of CN1: set cooling mode.

After having pre-fixed the established mode, the remote control can only be used to adjust the temperatures. Stoppage code "d1" "20" will be displayed if an attempt is made to change the operation mode of any of the indoor units with the remote control.

Example of wiring diagram of fixing the operation mode. Outdoor unit PCB:



SS1:Fixing operation mode switch SS2:Changeover switch X2:Cooling X1:Heating

Demand thermo OFF (∃)

This is an input function to control the maximum power that the compressor can consume. When this option is turned on, the outdoor units are stopped completely, and the indoor units go into THERMO-OFF. Alarm "10" is displayed on the remote control. If the switch of this function is disconnected it becomes available again.

Connect the cabling and use the materials as shown in section "Avaliable ports"

• Forced stoppage (^L)

This is an input function that turns on when the switch receives a signal that causes the compressor and the fan motor of the indoor unit to stop; alarm "10" displays on a remote-controlled when this option turns on. If the switch of this function is disconnected it becomes available again.

Connect the cabling and use the materials as shown in section "Avaliable ports"

• Current control demand (5/5/7)

This is an input function that turns on when it detects that the frequency of the compressor reaches 50%, 75% or 100%. The frequency of the compressor is determined when the maximum current reaches the established limit.

Connect the cabling and use the materials as shown in section "Avaliable ports"

If the running current of the outdoor unit exceeds the maximum limit, the unit changes to the thermo-OFF condition. Stoppage cause code "10" will appear. When the input terminal is opened during the demand current control, the control of the input terminal is reset.

5.1.4. Description of optional output signals

• Operation signal (2 1)

This optional signal is used to pick up the operation signal. It can be used to turn on or off complementary units of the airconditioning system, such as fans, humidifiers, etc.

Connect the cabling and use the materials as shown in section "Avaliable ports". Note that the contact of auxiliary relay X3 is closed when an operation signal is issued.

• Alarm signal (□□)

This optional signal is used to pick up the activation of safety devices.

Connect the cabling and use the materials as shown in section "Avaliable ports".

Note that the contact of auxiliary relay X3 is closed when an operation signal is issued.

Compressor on signal (□ ∃)

This optional signal is used to pick up the signal when the compressor is ON. It can be used to check how the compressor is running at all times. It is very useful for locking the compressor when the fans are locked.

Connect the cabling and use the materials as shown in section "Avaliable ports"

Note that the contact of auxiliary relay X3 is closed when an operation signal is issued.

• Defrost operation signal (24)

This optional signal is used to pick up when defrosting turns on. It is very useful to check if the indoor unit is in thermo-OFF.

Connect the cabling and use the materials as shown in section "Avaliable ports".

Note that the contact of auxiliary relay X3 is closed when an operation signal is issued.

5.1.5. Optional functions

Programming


The optional signals are programmed through the PCB of the outdoor unit.

Setting of the optional signals

The optional signals of the outdoor unit are set up from the PCB of the outdoor unit and push switches PSW1, PSW2 and PSW3


Selecting the optional function


 While the outdoor unit is ON, set the following DIP switches on the printed circuit board of the indoor unit as follows: set pin 5 of DSW2 to ON. Because of these settings, the function selection mode becomes available and the following indication appears on the 7-segment display.



This indicates that the "fixing of demand" function is available.

- By pressing push switches PSW2 and PSW3, you change the input/output terminal name. The flowcharts shown on the next page reflects the changes on the 7-segment display when you press PSW2 and PSW3. (See the flowcharts on the next page)
- 3. After selecting the terminal of the function setting, select the availability function by pressing the PSW1.
- 4. After setting the pin 5 of DSW2 to OFF, the selected contents are memorized in the PCB of the outdoor unit, and, immediately afterwards, the function selection mode is set to OFF. The memorized data is maintained even when the power supply wires are disconnected.





Available optional functions Service Manual


• Fixing of demand function

This function regulates the running current of the outdoor unit. If the demanded current is above the set current, the indoor unit capacity is reduced. The running current can be regulated both from internal signal. The capacity regulation is 50%, 75%, 100%.

This function can be activated when the demand is selected at one of input terminal indications i, i, i and i. In case that multiple demand functions are set the input terminal indications, i, i, i and i. The demand running current is selected with 5, δ , η . PSW1.

Wave function setting

This function regulates the power consumption of the outdoor unit. While this function is activated, the maximum limit of running is changed as shown bellow:




This function can be activated when the demand is selected at one of input terminal indications c_1^2 , c_2^2 and c_3^2 . The minimum limit of running current control is according to the set value of the demand function. If the demand function is not set at the input terminal indication, this function can not be activated.

Indoor temperature setting for energy saving

This function can be activated when the customer wants to reduce the system power consumption. The setting temperature will be increased or decreased depends if it is in cooling or heating mode.

Setting defrosting at low-speed

Using this option, you can select the speed of the indoor unit fan during the defrost period.




Low noise setting

This function can be activated and then the compressor frequency is set lower than the normal setting. This function can activate in cooling or heating mode.

Night-shift (low noise)

When you set the operation mode to night mode (low noise), which is used especially during the nighttime, the cooling capacity is decreased to 60%. You should use the night shift operation only when the remaining cooling capacity can supply the requested temperature.


Outdoor fan




NOTE
 Note
 The maximum rotation (rotating speed) is always 100% for the standard unit. (No limitation of the outdoor temperature).

Change of defrost operation conditions

This function allows to change the operation conditions in defrosting mode. The change is shown in the following illustrations:





• Fixing of frequency

No setting for this function is available.

Cool draft protection 1

This function can be activated, when the minimum discharge Air temperature falls down to 8 °C in cooling operation. Outdoor fan stop and compressor frequency forcibly declines to prevent discharge air temperature from dropping.

Cool draft protection 2

This function can be activated, when the minimum discharge Air temperature falls down to 10° C in cooling operation. Compressor stop. In this case stoppage code N° 24 is given.

• Optional functions (jumper)

- Fixing cooling mode

When this function is activated, the operation mode is fixed in cooling mode. Thermo ON is only available for COOL or DRY mode at indoor unit. The minimum temperature is -5 °C. To activate this option the jumper JP4 of the outdoor unit PCB1 must be cut.

- Alternative defrost mode

When one outdoor unit is connected with one H-LINK system with other outdoor units, is under defrosting, the other outdoor units defrosting is cancelled.

After one outdoor unit defrosting is completed, another outdoor unit starts defrosting operation. To activate this option the jumper JP5 of the outdoor unit PCB1 must be cut.

- R407C piping

If you are using conventional R410A refrigerant instead of R407C refrigerant pressure will be increased. To avoid pressure increase will activate this function.

To activate this option the jumper JP6 of the outdoor unit PCB1 must be cut.

5.1.6. Outdoor units available optional functions

Optional functions						
Optional function	Explanation					
Fixing the energy saving request function.	This function regulates the outdoor unit consumption to 50%, 70% or 100%. If the required power is above the set value, the capacity of the indoor unit will be reduced proportionally to the power consumption of the outdoor unit. It can even come to a thermostatic stop if necessary. This function can be configured using an external or internal signal, depending on the needs of the installation. Configuration by external signal is very useful for setting up groups of outdoor units. The internal signal is useful for setting up a single outdoor unit.					
Thermostatic stoppage order	When this function is activated the compressor is stopped and the indoor units are on thermo OFF.					
Low speed defrost adjustment.	When this function is activated the indoor fan speed at defrost mode changes to slow instead of stopping the fan.					
Low noise setting	This function decreases the sound levels of the outdoor units by reducing the maximum working frequency of the compressor (Cooling/Heating).					
Night mode (low noise) operation	This function reduces the sound level of the outdoor units by decreasing the maximum working frequency of the compressor and the fan airflow according to the outside temperature (only for cooling mode).					
Change of defrost operation conditions	This function changes the defrosting operation conditions. It is especially useful in cold areas.					
Protection against cold air discharge (1)	When the air discharge temperature of the indoor unit is less than or equal to 10 °C in cooling mode, the fans stop and the frequency of the outdoor unit is reduced, thereby preventing any discomfort to the occupants of the room.					
Protection against cold air discharge (2)	When the discharge temperature of the air in the indoor unit is less than or equal to 10 °C in cooling mode, the compressor stops and alarm no. 24 appears.					
	This function controls the outdoor unit consumption in the following way:					
Wave function setting	It allows a consumption of 100% for 20 minutes. The following 10 minutes it goes down to 70% and then alternates between 100% and 70%.					
Indoor unit energy-saving temperature setting	This function reduces the power consumption of the indoor unit according to the temperature.					
Piping for the R407C	If you use conventional R407C piping instead of the R410A, the piping pressure will increase. This function is activated in order to avoid this pressure increase.					
Alternation in defrost mode activation	This function is useful in an installation consisting of various outdoor units placed in the same H-LINK. The defrost mode is activated alternately in each outdoor unit.					
Fixing the cooling mode	This function sets the cooling mode: the indoor unit will only start when the system is on COOL or DRY.					
Fixing the heating mode	This function sets the heating mode: the indoor unit will only start when the system is on HEAT or DRY/FAN.					
Signal capture	This function provides information on the units operation, (operation, alarm, compressor ON, defrosting signals) so the necessary devices can be activated.					

5.2. Available optional functions through the remote control switch (PC-ART)

5.2.1. Optional function setting

The remote control switch is changed to the optional setting mode by the following procedures.

Programming with the PC-ART

The optional signals are programmed using the remote control switch.

• Programming and setting mode

Make sure the unit is stopped. Press the " \rightarrow OK" and the "RESET" switches on the remote control switch simultaneously more than 3 seconds, and the remote control switch is changed to the field setting mode. The "SERVICE" indication is displayed, and " \square I" flickers below it.




• Selecting SERVICE [] {

When in the programming and setting mode, press the "TEMP O" or the "TEMP O" switch, and the number that flickers below the "SERVICE" indication will change ($\square \downarrow \rightarrow \square \square$). Set the flickering number to " $\square \downarrow$ ", maintain it during 7 seconds or press the " \dashv OK" switch, and the remote control switch will change to optional setting mode.

• Selection of indoor unit

a. In SERVICE 01 selection mode, the indication of the remote control switch will change as shown in the figure below.



• The " \square *l*" indication is activated.


• The address of the indoor unit for which the optional function is to be set is indicated in the segments for timer setting time indication and "ADDS" is indicated below.

- The refrigerant cycle number of the outdoor unit for which the optional function is to be set is indicated in the segments for timer setting time indication and "RN" is indicated below.
- The indication of the setting temperature is turned OFF.
- b. In previous point (a), press the "TEMP " switch ⊗ or the "TEMP " switch ⊗ of the remote control switch and the indoor unit for which the optional function is to be set, can be changed.


į	ΝΟΤΕ
- T	The indoor unit can be selected among the indoor units connected to the remote control switch.
	f both the indication of the address and the refrigerant cycle number is "AA", the settings of all the indoor units are the same.

c. After selecting the indoor unit, leave the condition for 7 seconds or press the "OK" switch, the remote control switch is changed to the optional setting mode.


- Changing the optional signals and setting conditions
- a. At the optional setting mode, the indication on the remote control switch is changed as shown below.



- The indications of "ADDS" and "RN" are turned OFF.
- O The setting condition of the optional function is indicated in the segments of the time indication of the timer setting.
- **3** The item number of the optional function is indicated in the segment for the set temperature indication.
- b. Press the DAY ▼switch or the SCHEDULE ▲ switch. Then, the port indication at the segments for time indication of the timer setting changes as shown below. Select the port for allocating the input signal and the output signal.




c. Press the ",JOK" switch. Then, the input signal code and the output signal code at the segments for the setting temperature indication changes as shown below. Select the input signal and the output signal that you need to allocate to the port.



- **Return to normal mode from the optional functions setting mode** Press the "RESET" switch to memorize the optional functions settings and return to normal mode.
- Selection of other indoor unit

When in optional settings mode, press the "TEMP O" switch or the "TEMP O" switch, the condition of the remote control switch is changed so that the Indoor Unit can be selected to set the optional function described above.

Setting items of the optional functions



 Individual: This function can be selected individually for each indoor unit controlled by the same RCS.

 "RR RR" Not individual (all units): This function can be selected for all indoor units controlled by the same RCS. It is necessary to select "RR RR" before set.

- Items marked with "-----" are not used. Do not change its setting condition "00".

	Item.	Optional functions	Setting	Contents of parts	Content
	ы	Removal of heating temperature	00	Not available	This function is used to eliminate the 4
	01	calibration	01	Available	°C shift.
	62	Circulator function at heating	00	Not available	This function is to avoid the stratification
		thermo-OFF	01	Available	of air.
		Enforced 3 minutes minimum	00	Not available	This function is used to guard the
	63	operation time of compressor	01	Available	compressor when it frequently starts and stops
			00	Std.	
			01	100 hours	With this function is possible to change the time when the remote controller
	64	Change of filter cleaning time	02	1200 hours	- advise about when is necessary to
			03	2500 hours	change the air filter.
			04	No indication	
			00	Not available	This function eliminates the possibility of
- 88 88	65	Fixing the operation mode	01	Available	changing operation mode from RCS or central control
			00	Not available	This function eliminates the possibility of
- 88 88	65	Fixing the setting temperature	01	Available	changing setting temperature from RCS or central control
- 88 88	67	Fixing of operation as exclusive	00	Not available	This function eliminates heating mode
- ,01 ,01	<u> </u>	cooling unit	01	Available	from RCS or central control
- 88 88	68	Automatic COOL/HEAT operation	00	Not available	This function changes automatically from
- ,01 ,01			01	Available	cool to heat.
			00	Not available	This function eliminates the possibility of
- 88 88	69	Fixing the air volume	01	Available	changing fan speed from RCS or central control
	ЬЯ	Not prepared			
		Cooling to manufacture	00	Not available	Standard (no compensation)
	66	Cooling temperature compensation	01	Available	Compensation in -1°C
			02	Available	Compensation in -2°C
	ЬΕ	Network	00	Net used (standard 00)	
		Not prepared	01	Not used (standard 00)	
		Not proported	00	– Not used (standard 00)	
	bd	Not prepared	01		
			00		
	ЬΕ	Not prepared	01	Not used (standard 00)	
	E 1	Not prepared			
	52	Not prepared			
	E 3	Not prepared			
		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		I	

	ltem.	Optional functions	Setting	Contents of parts	Content
	Eч	Drain pump in heating	00	Not available	This function is used to activate the drain
	<u> </u>		01	Available	pump in heating mode.
		Statio procesure coloction	00	Medium static pressure (factory setting)	This function is used to change the
-		Static pressure selection	01	High static pressure	static pressure levels from the remote controller on the RPI units.
	65		02	Low static pressure	
-		Increasing fan speed (RCD)	00	Normal.	This function is used to change the fan
		(RCI)	01	Increasing speed 1	speed due to the high ceiling.
			02	Increasing speed 2	
	65	Hi speed at heating thermo-OFF	00	Not available	This function is used to increase the fan
			01	Available	speed when Thermo-OFF
	בח	Cancelling of enforced 3 minutes minimum operation time of	00	Not available	This function is used to cancel the "enforced 3 minutes minimum operation
	L 1	compressor	01	Available	time of compressor".
			00	Control by indoor suction thermistor	
		Thermistor of remote control	01	Control by thermistor of remote control switch	This function is used to control the unit
	68	switch		Control by average	with the thermistor of remote control.
			02	value of indoor suction thermistor and thermistor of remote control switch	
	[9]	Not prepared			
	ER	Not prepared			
		Selection of forced stoppage logic	00	Forced stoppage input A contact	With this function we select the forced
- 88 88			01	Forced stoppage input B contact	stoppage logic.
	55	Not prepared			
			00		
	Ed	Not prepared	01	Not used (standard 00)	
			00		
	EE	Not prepared	01	Not used (standard 00)	
			00	Standard (7 steps)	
	EF	Change of louver swing angle	01	Draft prevention (5 steps)	For draft prevention option, the two last louver position will be not available
			02	High ceiling (5 steps)	For high celing option, the two first louver position will be not available
			00	Not available	This function retains the settings of the
	d	ON/OFF 1 unit power supply	01	Available	unit if power supply is interrupted. The unit will start when power is restored.
	d2	Not prepared			
			00	Not available	This function retains the settings of the
٩	БP	Restart function after power failure	01	Available	unit if power supply is interrupted. The unit will restart when power is restored if the unit was ON before the power failure
		Prevention cooling for discharge	00	Not available	
	dЧ	air temperature decrease	01	Available	
	_07	Prevention heating for discharge	00	Not available	
	d5	air temperature decrease	01	Available	
	dБ	Room temperature control for energy saving	00 01	Not available Available	
	dП	Not prepared	00–07	Not used (standard 00)	
	E5				
	C 3	Not prepared	00	Not available	
	Indoor fan operation timer after	60 minutes	This function delays the indoor fan start		
	L U	cooling operation stopage			
			02 120 minutes		
	EП	Not prepared		Not used (standard 00)	1

	Item.	Optional functions	Setting	Contents of parts	Content	
	c 0	Fan operation control at heating	00	Netweed (stendard 00)		
	thermo OFF	01	Not used (standard 00)			
	E9	Netpropored	00	Net used (standard 00)		
	27	Not prepared	01	Not used (standard 00)		
			00	Netwood (Standard 00)		
	ER	Not prepared	01	Not used (Standard 00)		
			02			
			00	Available		
	ЕЬ	Fan operation control at cooling thermo OFF	01	Low		
			02	Slow		
	EE	Forced thermo-ON stoppage at	00	Available		
	E L	cooling	01	Not available		
	Ed	Not prepared	00	Not used (standard 00)		
			01			
	EE	Automatic fan speed control	00	Available		
	L L		01	Not available		
			00	No function		
	F I	Automatic setting for OFF timer (only available for PC-P1HE)	01	OFF timer by 1 hour	This function is used to set the OFF timer	
- 88 88			02	OFF timer by 2 hours	function automatically when the unit is	
			~		started by the remote control switch.	
			23	OFF timer by 23 hours	-	
			24	OFF timer by 24 hours		
- 88 88	FZ	Remote control main-sub setting	00	Main	This function is used when to remote	
			01	Sub	control are installed in one system.	
	Fヨ to Fワ	Not prepared	-	Not prepared	-	
- 88 88	FB	Mada laak	00	Not available		
- ^^ ^^	10	Mode lock	01	Available	This function eliminates the possibility of	
- 88 88	Fq	Tomp look	00	Not available	changing operation mode from RCS, but it is possible from central control.	
- ^^ ^^	ר ק	F9 Temp lock		Available		
- 88 88	FR	Fan lock	00	Not available		
- חח חח	гл		01	Available	This function eliminates the possibility of changing fan speed from RCS or central	
- 88 88	Fb Louver lock	00	Not available			
- ,,,,,,,,,	· -		01	Available		
- 88 88	Fc	Cooling temperature range limit	00~10	Standard 00	+1 ~ +10°C	
- RA RA	Fd	Heating temperature range limit	00~10	Standard 00	-1 ~ -10°C	
		lite after a subserved in the	00	5°C		
	FE	Heating automatic operation	01	10°C		
-	temp.		02	15°C		

5.2.2. Optional functions of the remote control switch

This function is used when the temperature settings of the remote control switch and the suction air temperature of the indoor unit are required to be equal.

In standard heating operation, the suction air temperature is higher than the room temperature, therefore the suction air temperature is calibrated at -4 °C.

(Indicated setting temperature = suction air temperature –4 °C return to 0 °C)

This is useful when the thermistor at the suction side of an Indoor Unit is removed and installed into another place.

Circulator function at heating thermo-OFF ($b\vec{\mathcal{Z}})$

If fan speed LOW is selected at heating thermo-OFF, the air of the room might become stratified because warm air stagnates near the ceiling. In this case, it is recommended that the circulator function explained below be used. <Circulator function>

The function keeps the fan speed at thermo-OFF at the same level as thermo-ON. In this case, air movement in the room

will be kept on the same level as thermo-ON, ensuring a homogenous air distribution. In the case that an auto louver is equipped, this operation will be also held on when the heating is turned thermo-OFF.

\boldsymbol{i}	NOTE
,	olness, heat and air flow are subject to personal preferences and behaviours. mmended to discuss this with customers thoroughly and then, set the unit accordingly.

Enforced 3 minutes minimum operation time of compressor ($b \vec{z}$)

When a compressor frequently starts and stops in short intervals, this function should be used to guard the compressor. By setting this function, the mode of a minimum 3 minutes operation will be added. (The mode of a minimum 3 minutes stoppage is standard.)

In case of SET-FREE, this function is standard even when setting is not available.

i	NOTE	
- When	the safety device is activated or the "ON/OFF" switch is pressed, the compressor is stopped immediately.	

Change of filter cleaning time $(b \lor)$

The period for filter sign indication is set for each indoor unit model when shipping. The filter sign is indicated according to the filter cleaning time (factory-setting). However, this filter cleaning time can be changed depending on the condition of the filter as shown in the next table.

	Period for filter sign indication			
	Approx. 100 hours	Approx. 1200 hours	Approx. 2500 hours	No indication
In case of 4-way cassette type	Changed period	Changed period	Factory setting	Changed period
Liquid crystal display on remote control switch	ОТ БЧ	02 by	03 ЬЧ or 00 ЬЧ (*)	04 64

(*) For the RPK model, the factory setting is 200 hours

Fixing the operation mode (b5)

This function is used when changes in operation modes are not required. When this function is valid, the operation mode that has been set cannot be changed.

Fixing of setting temperature ($b\overline{b}$)

This function is used when changes in setting temperature are not required. When this function is valid, the setting temperature that has been set cannot be changed.

Fixing of operation as exclusive cooling unit (b^{\prime})

This function is used when exclusive cooling operation is required. This function invalidates the heating operation and the automatic COOL/HEAT operation, as the operation of exclusive cooling unit.

Automatic COOL/HEAT operation (bB)

This function is used to operate the unit with changing cooling and heating operation automatically. This function is invalid when the outdoor unit is cooling only model or the function of "fixing operation as exclusive cooling unit" is valid.

Fixing of fan speed (2^{-1})

This function is used to fix the fan speed. When this function is valid, the fan speed is not changes by the remote control switch.

Not prepared (bR)

Cooling Setting Temperature Compensation (bb)

This function is used to provide the longer cooling operation time. When this function is valid, Thermo-ON/OFF is controlled under the lower temperature conditions than the setting temperature (indicated value) of the remote control switch.

Setting Temperature for Room Temperature Control at Cooling

Setting Condition	Actual Control Temperature		
00 (Standard)	Remote Control Switch Setting Temperature (Indicated Value)		
01	Remote Control Switch Setting Temperature (Indicated Value) -1°C		
02	Remote Control Switch Setting Temperature (Indicated Value) -2°C		
NOTE			
- The setting temperature lower limit after compensation is 19°C.			

Not prepared (b)

- Not prepared (bd)
- Not prepared (bE)
- Not prepared (*L* 1)
- Not prepared (∠ 2)
- Not prepared ($\square \exists$)

Drain pump in heating (when the humidifier is installed) (L^{-1})

This function is used to operate the drain pump in heating operation.

High speed (25)

This function is used to increase the fan speed due to the high ceiling. (Only available for RCI and RCD Units). In case of RPI units, this setting is used to select the static pressure.

High speed at heating thermo-OFF ($\mathcal{L}\mathcal{L}$)

This function is used to increase the fan speed with function (L5) when thermo-OFF in heating operation. (The fan speed is not increased when thermo-OFF in heating operation at the function (L5) setting). (Only available for RCD units).

Canceling the enforced 3 minutes minimum operation time of compressor ($\mathcal{L}^{\prime \gamma}$)

SMGB0043 rev.1 - 04/2010

In case of SET-FREE, the "enforced 3 minutes minimim operation time of compressor" described in item (3) is the standard function.

This function is used to cancel the "enforced 3 minutes minimum operation time of compressor" function.

Remote control switch thermistor (\mathcal{LB})

This function is used to control the unit by the built-in thermistor of the remote control switch (remote control thermistor) instead of the thermistor for suction air.

Set it at " \square l" or " \square a" when you use it.

However, even when this function is set at " \square l" or " \square 2" if the temperature detected is abnormal due to the failure of the remote control thermistor. etc., the indoor unit suction air thermistor is used automatically.

Not prepared (도약)

Not prepared (27)

Selection of forced stoppage logic (*L*b)

This function is used to select the logic of the contact for forced stoppage signal input. The setting condition and the logic of the contact are as shown below.

	Setting condition				
	Logic of		Activation contact		
Ļ	contact	Sequence	"Open"	"Close"	
00	Contact A		Normal.	Enforced stoppage	
01	Contact B		Enforced stoppage	Normal.	


Not prepared (にd)

Not prepared (ΣE)

Change of Louver Swing Angle (\mathcal{LF})

This function is used to change the Louver swing angle

Setting	Louver Swing Angle	Purpose	
condition	(Air Discharge Angle)		A :
00	Approx. 30° to 60°	Standard Operation	Air Discharge
01	Approx. 30° to 50°	Draft Prevention	Angle
02	Approx. 40° to 60°	For High Ceiling	ר



Power supply ON/OFF 1 (d 1)

This function is used to start and stop the unit according to the power supply ON/OFF. When this function is used in the condition that there is no person to operate the unit, make the system with monitoring for disaster prevention.

	<i>NOTE</i>
-	The unit is started and stopped according to the power supply ON/OFF due to the power failure. When the power failure is occurred during stoppage by the remote control switch operation, the unit is started again automatically after the power supply is recovered.

Not prepared $(\vec{a} \cdot \vec{c})$

Restart function after power failure ($rac{J}$

This function is used to start the unit operation again automatically when the power supply is recovered after the power failure over 2 seconds.

The standard unit is started operation again automatically with all the same operating conditions such as operation mode, etc. in case of the power failure within 2 seconds.

(The compressor unit is started operation again after three minutes guard in addition to 2 seconds power failure as a maximum.)

(i)

NOTE

- In case of power failure during the unit stoppage, the unit is stopped after recovering the power supply.

Prevention for Cooling Discharge Air temperature decrease (a'-4)

This function is used to change Thermo-ON/OFF conditions at cooling operation and prevent discharge air temperature decrease. In the result, the perception of cold draft is eliminated.

<Thermo-OFF Conditions>

(a) Cooling Operation (including Dry Operation) and

(b) Indoor air discharge temp. <11°C has been kept for 3 minutes.

(Thermo-OFF when discharge air temperature is low.)

<Thermo-ON Conditions>

(a) Indoor discharge air temp. >13°C and

(b) Thermo-ON depends on indoor discharge air temperature.

(Not Thermo-ON when discharge air temperature is low.)

Prevention for Heating Discharge Air temperature decrease (d'5)

This function is used to prevent discharge air temperature decrease by lowering actual fan speed than the indications on the remote control switch.

Indications on Remote Control Switch	Actual Fan Speed
HIGH	MEDIUM
MEDIUM	LOW
LOW	LOW

Room Temperature Control for Energy Saving (d5)

When outdoor temperature air thermistor is detecting that the air-conditioning load is low from the outdoor temperature. This function is used to automatically save energy.

Nor prepared (

For the following optional functions, please refer to Econofresh or KPI proper service manual.

- Ventilation mode (KPI) (E 1)
- All fresh operation (econofresh) (E 1)
- Increasing supply air volume (KPI) (EZ)
- Enthalpy sensor (econofresh) $(\mathcal{E}\mathcal{Z})$
- With humidifier (indication only) (KPI) ($\mathcal{E} \mathcal{I}$)
- Precooling/preheating period (KPI) ($\mathcal{E}^{\mathcal{H}}$)
- Gas sensor (econofresh) $(E \lor)$

Not prepared ($\mathcal{E}5$)

Indoor fan operation timer after cooling operation sttopage ($\mathcal{E}\mathcal{E}$)

This function is used to prevent dew condensation "SLOW" indoor fan operation (for 60 minutes or 120 minutes depending on the setting) while cooling operation is stopped. Additionally, it is effective to prevent fangs or abnormal odor.

Not prepared (\mathcal{E}^{-1})

Fan operation control at heating thermo OFF (*EB*)

This function is used to prevent the perception of cold draft by reducing indoor fan speed at heating thermo-OFF.

Setting Condition	Fan Operation at Thermo-OFF	
00	LOW	
01	SLOW (*)	
(*): If THM4 (remote sensor) is connected, the fan speed will be stop during heating thermo OFF.		

Not prepared (\mathcal{E} ?)

Not prepared ($\mathcal{E}\mathcal{R}$)

Fan operation control at cooling thermo OFF (Eb)

This function is used to control odor diffusion and humidity level indoor fan speed at cooling thermo-OFF.

Setting Condition	Fan Operation at Thermo-OFF
00	Operation at Setting Fan Speed
01	LOW
02	SLOW

Forced thermo-on stoppage at cooling ($\mathcal{E}_{\mathcal{L}}$)

This function is used to stop operation by forced thermo-ON when cooling operation is stopped.

It is effective to prevent abnormal odor because the heat exchanger is kept in the clean condition such as the heat exchanger is rinsed with drain water.

Automatic fan speed control ($\mathcal{E}\mathcal{E}$)

This function is used to economize the operation. The fan speed is automatically controlled when the room temperature is near the setting temperature. Available for PC-ART and all indoor units except RPI-(8.0/10.0)FSN2E.

Fan speed setting	Fan speed
"High"	"High"→"Mid"→"Low"
"Mid"	"Mid"→"Low"
"Low"	"Low" (No charge)

Automatic setting for OFF timer (F l)

This function is used to turn on the OFF timer of the indoor units.

Setting condition		Contents of parts
00	Not available	OFF timer not set
01	Available	Turns OFF after running for 1 hour
~ 24		Turns OFF after running for 24 hour

Remote control main-sub setting $(F\vec{c})$

This function is used to set two remote-control switches in a same installation; one in main mode and the other one in sub mode.

Setting condition		Contents of parts
00	Main	The remote control switch is set as main
01	Sub	The remote control switch is set as sub

Mode lock (FB)

This function is used to lock the operation mode. The setting condition is showing below

S	Setting condition	Contents of parts
00	Not available	-
01	Available	-

Temperature lock (F 9)

This function is used to lock the temperature. The setting condition is showing below

Setting condition		Contents of parts
00	Not available	-
01	Available	-

Fan lock (F무)

This function is used to lock the fan.

The setting condition is showing below

Ś	Setting condition	Contents of parts
00	Not available	-
01	Available	-

Louver lock (Fb)

This function is used to lock the louver.

The setting condition is showing below

Setting condition		Contents of parts
00	Not available	-
01	Available	-


Cooling temperature range limit (Fc)

This function is used to set the temperature range in cooling mode. This function allows reducing the cooling range, to configurate trough the remote control switch.

The setting condition is showing below

Setting condition		Contents of parts
00	Not available	-
01	Available	Working range is reduced in 1°C, increased the lower limit in 1°C
~ 10		Working range is reduced in 10°C, increased the lower limit in 10°C

Example:



Available optional functions Service Manual

Heating temperature range limit (F d)

This function is used to set the temperature range in heating mode. This function allows reducing the Heating range, to configurate trough the remote control switch.

The setting condition is showing below

Setting condition		Contents of parts
00	Not available	-
01	Available	Working range is reduced in 1°C, decreased the upper limit in 1°C
10	Available	Working range is reduced in 10°C, decreased the upper limit in 10°C
		Example: 19°C 30°C
Temp	range at heating (standard)	19~30°C
Min. a	at heating + 1°C	19~29°C −1°C
	at heating + 10°C	19~20°Cl -10°C
		 possible to set temperature by remote controller SW
		← → impossible to set temperature by remote controller SW

Heating automatic temperature range limit (FE)

This function is used to avoid anti-froze water pipe protection. The unit will be activated from setting temperature until 19 °C

The setting condition is showing below

Setting condition		Contents of parts
00	Not available	-
01 02 03	Available	Setting temperature 5°C Setting temperature 10°C Setting temperature 15°C

5.3. Available optional functions through the remote control switch (PC-ARH)

1. Switching to optional setting mode:

Press the "MODE" and "FAN SPEED" buttons at the same time for at least 3 seconds when the air conditioning unit is off.

The screen will change, as shown in the diagram, when optional setting mode is activated.


2. Changing options and setting elements:

Press "V TEMP" to change certain setting elements when shown.

To change setting options, press the "TEMP " button. Consult the following table for setting elements and options.

3. Cancelling the function selection mode:

To return to normal mode from 2., press the "MODE" and "FAN SPEED" buttons at the same time.



Optional setting elements

Code	Element	Setting	
ы	Cancelling heating temperature setting	00: Normal (temperature setting +4 °C) 01: Cancelled (temperature setting) 02: Temperature setting +2 °C *1	
ь8	Automatic cooling/heating mode	00: Off 01: On	
٢5	Indoor fan increase	00: Off 01: High 1 02: High 2	
C8	Remote control thermostat *2	 00: Off 01: Switch from indoor inlet thermistor to remote control thermostat 02: Unit control using the average value of the indoor inlet thermistor and the remote control thermostat 	
F2	Setting primary and secondary remote controls	00: Primary 00: Secondary	
FE	Minimum setting for cooling temperature *3	00: Normal temperature margin 01-10: Minimum cooling limit +1 °C - +10 °C	
Fd	Maximum setting for heating temperature *4	00: Normal temperature margin 01-10: Maximum heating limit -1 °C - 10 °C	
н	Maintenance alarm	00: Show 01: Hide	
HZ	No automatic control indication	00: Show 01: Hide	
НЭ	Operation mode change restriction *5	00: Operation mode change off (hide operation mode) (factory setting)01: Operation mode set by the central control unit + "FAN" mode02: Unlimited operation	
нч	Ventilation changeover (total heat exchanger only)	00: Air conditioning only 01: Ventilation only 02: Air conditioning + ventilation	
HS	Central control available after forced stoppage.	00: Off 01: On	
*1. Certain	*1. Certain indoor units do not accept the setting "02".		

*2. If installed on a bedside table, use the setting "00".*3. Applies to "FAN", "COOL" and "DRY" modes.*4. Applies to "HEAT" mode.*5.

"01" is only available when using a remote control. Do not use this setting when using two remote controls (primary/secondary).

i

NOTE

- When connecting several indoor units, the same settings are applied to all units.
- To change the settings, wait at least three minutes after switching the power on.
- Some indoor and outdoor units do not accept certain settings or do not have the functions that relate to the activated settings. Check the available settings beforehand.
- Note down the option selected in the "settings" column on the table.

5.3.1. Alarm indication

The run LED (green) will flash. The LCD screen will show the following information:

- No. of indoor unit affected by the alarm.
- Alarm code.
- Unit model.
- No. of indoor units connected to the system.

Í

NOTE

- For more information on alarm indications, check the installation and operation manual for the outdoor unit.

5.4. Available optional functions through wireless remote control switch (PC-LH3A + receiver)

You can adjust the following optional functions with the DIP switches of the receiver.

PC-RLH8/9/11

DIP switch					
	2	3	4		
)	-	-	-		
	O(1)				
,		2 - O(1)	O(1)		

(1) Only for PC-ALHD, 11, 13

i	NOTICE
- Turn (DFF all the power sources before setting the DIP switches.

Setting of sub-receiver part


For this optional function set pin marked with **1** to ON.

PC-RLH8/9/11/13

Open the lid of case by removing two screws so that the following functions are available.

PC-ALH

PC-ALHD Remove two screws Remove two screws Switch (COOL) Switch (COOL) and open the case and open the case Switch (HEAT) Switch (HEAT) DIP switch (SW3) DIP switch (SW3) (factory supplied) (factory supplied) 6001 (HEAT) 6 Þ 며 며 NUN DEF FILTER TIMER ß 0 Hole for cable Hole for cable ſ PCB Case Cover Cover **PCB** Case



110

6

6. Test Run

Contents

6.	Test run	111
6.1.	Checking procedure before the test run	. 112
6.2.	Test run procedure using the remote control switch	. 114
6.3.	Test run procedure using the wireless remote control switch	. 115
6.4.	Test run procedure from the outdoor unit side	. 117
6.5.	Normal operation pressure	. 118
6.6.	Check list	.120

6.1. Checking procedure before the test run


When the installation is finished, perform the test run according to the following procedure. After performing the test run, hand over the system to the customer.

Perform the test run of the indoor units one by one in order.

Make sure that the electrical wiring and the refrigerant piping are correctly connected.

Start the indoor units one by one in order to make sure that the indoor units are correctly numbered.

You should perform the test run according to the "7.2 Test Run Procedure" on the next page.



- Electrical discharge. Can cause serious injuries. Do not touch any electrical components for more than three minutes after turning OFF the main switch.

Checking procedure

- 1. Make sure that the stop valve of the gas line and the stop valve of the liquid line are fully open.
- 2. Make sure that there is no refrigerant leakage. The flare nuts sometimes loosen because of the vibration during the transportation.
- 3. Make sure that the refrigerant piping and the electrical wiring belong to the same system Make sure that the setting of the unit number of DSW1, DSW6 and RSW1 of indoor units correspond to the system.
- 4. Make sure that the setting of the DIP switches on the printed circuit board of the indoor units and the outdoor units are correct. Especially, pay attention to the setting of the lift between the indoor units and the outdoor units. Refer to chapter 3 "Electrical Wiring" for details.
- 5. Make sure that the switch on the main power source has been ON for more than twelve hours in order to warm the compressor oil by means of the oil heater.
- Check whether or not the electrical wiring of the indoor units and the outdoor units are connected as shown in chapter 3 "Electrical Wiring".
- 7. Make sure that each wire terminal (L1, L2, L3 and N, or L1 and N for single phase) is correctly connected at the power source.


6

	ΝΟΤΕ
-	Make sure that the field-supplied electrical components (main switch fuse, fuse-free breaker, earth leakage breaker, wires, conduit connectors and wire terminals) have been properly selected according to the electrical data in the technical catalog of the unit. Also, make sure that the field-supplied electrical components comply with the national codes and the local codes.
-	Use the shielded cables for the field wiring in order to avoid the electrical noise. (The length of the shielded cable should be less than 1,000 m. The size of shielded cable should comply with the local codes.)
-	Make sure that the terminals for the power supply wiring ("L1" to "L1" and "N" to "N" of each terminal board for AC380-415V. "R" to "R" and "T" to "T" of each terminal board for AC220V) and the terminals for the intermediate wires between the indoor unit and the outdoor unit (Operating Line: terminals of each terminal board for DC12V) coincide correctly. Otherwise, you may damage some components.
-	Check to ensure that the crankcase heater is turned ON for more than 4 hours. The operation is not available within 4 hours after turning ON the power supply.
-	Check to ensure that the main source has been ON for more than 12 hours to warm the compressor oil by the oil heater.
-	Check to ensure the operating temperature:
	- Cooling operation:
	 Indoor DB21.5 °C and above, Indoor WB16 °C and above, Outdoor DB0 °C and above.
-	Heating operation: Indoor DB27 °C and below.
-	The compressor is NOT available within 4 hours after turning ON the power supply.
-	(Stoppage code: d1-22) If the compressor should be within 4 hours, turn ON the power and wait for more than 30 seconds. Press PSW1 and PSW3 on the outdoor PCB simultaneously for more than 3 seconds. The forced thermo-OFF function (d1-22) is canceled and the compressor operation is available.

6.2. Test run procedure using the remote control switch

1	Turn ON the power s	source of the indoor uni	ts and the outdoor units	Operation		
0	Press the MODE sw seconds. a) If the TEST RUN i to the remote com control switch, the b) If no indication or	indication and the coun trol switch (for example connection of remote "DD" appears or if the r	emote control switch. simultaneously for more than three ting number of the connected units " ¹⁷ / ₂ 5") are displayed on the remote control cable is correct. Go to 1 . number of the units that is displayed units, there is some abnormal		Counting number of the connected units	
	RCS indication	Fault		Inspection poir	nts after the power source is OFF	
	No indication		s not turned ON. he remote control cable is incorrect. of the power supply line are incorrect	 Connecting The contact 	tion between the remote control and the unit is correct. points of the remote control cable. of the connectors of the remote control cable. astening of each terminal board.	
3	The counting number of the connected units is incorrect	 The setting of the u The connection of the indoor unit is incorrected. 	of outdoor unit in not turned ON. nit number is incorrect. he control cables between each ect. (When multiple units are rmote control switch).	 Setting of the DIP switches on the printed circuit board. Wire connection order of the bridge cable. Connecting points of the bridge cable. The contact of the connectors of the bridge cable. 		
	Back to 1 after the o	checking				
4			e MODE switch (COOL OR HEAT).			
	operation by pres		TEST RUN operation will be finish af /itch again).	ter two hours. Y	ou can also finish the TEST RUN	
	\boldsymbol{i}		NOTE			
5	continuous op operation is pe time switch in	eration, but the protecti erformed in high ambier the Remote control.	perature limitation and ambient tempe ons are alive. Therefore, the protection t temperature. TEST RUN operation t LED on the remote control switch is flic	n may activate w ime can be mod	then the heating TEST RUN	
	RCS indication	Unit condition	Fault		tion points after the power source is OFF	
				1. The connec	tion order of each terminal board. The fuse on the PCB lown out due to an incorrect wiring.	
	The operation LED			\boldsymbol{i}	NOTE	
	flickers. (1 time / 1 sec.) and the unit number and the alarm code "03" flicker.		(FUSE4 on Indoor Unit PCB1, EF1 on Outdoor unit PCB1) to pro			
6				 The screw fastening of each terminal board. The connection order of the power supply wire between the indoor units and the outdoor units. 		
	The operation LED flickers. (1 time / 2 sec.)	The unit does not start	The connection of the remote control cable is incorrect.	This is the sam	ne as the item 1, 2, and 3	
	The flickering indicator is different from the one above	The unit does not start. The unit starts once and then the unit stops.	The connection of the thermistor or other connectors is incorrect. There is tripping of the protector.		m code table in the service manual. nnel should do the checking).	
	The operation lamp Flickers. (1 Time/1s) Unit No. IIILU, Alarm Code IIILU, Alarm Code IIILU flicker	The unit does not start.	The connection of the remote control cable between Indoor Units is incorrect.	Check by the at service people).	pnormality mode table in the Technical Catalog (Do it by	
<u> </u>	Back to 1 after the c	· · · · ·	, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,			
0	 Correct the wiring Set the 1st pin of Only for RPK-1.0/ 	to the terminal board. DSW7 on the indoor ur		t:	Except Only RPK 1.0/1.5 RPK-1.0/1.5 ON 12	

6.3. Test run procedure using the wireless remote control switch



- 1. Perform the test run after completing the installation.
 - a) Set the batteries for the remote control switch.
 - b) Turn ON the power source of the indoor units and the outdoor units.
 - c) The yellow 'on' LED on the receiver of the indoor unit flickers (0.25 seconds ON \leftrightarrow 0.25 seconds OFF). Then, the yellow LED turns OFF. While the LED is flickering, the unit will not operate because the unit is initializing.
- 2. Set the TEST RUN mode by pressing the SET switch and the OFF TIME switch simultaneously for more than three seconds. The LCD should look like the LCD on the right figure.

The TEST RUN mode is not operating


- 3. Set the operation mode by pressing the MODE switch. The TEST RUN mode is operating.
- 4. Operate the test run by pointing the transmitter towards the receiver of the indoor unit. Then, press the RUN/STOP switch. When the indoor unit receives the commands, the yellow 'on' LED of the receiver will turn on briefly.


Make sure that the commands are received well and the selected mode 3) is set correctly. In the TEST RUN mode, the red RUN LED of the receiver is turned ON and the green TIMER LED flickers (0.5 seconds ON \leftrightarrow 0.5 seconds OFF) (*2). Then, the timer switches off for two hours.


i	NOTE
the i	e yellow 'ా' LED does not turn ON, the commands from remote control switch may not have reached the receiver. d the commands again.

(*2) In the case of the RPK model, the TIMER LED is turned OFF

- 5. Adjust the angle of the air grille as follows. The air louver has a mechanism for the auto-swing function. Do not move the louver by hand forcefully.
 - a) Select the FAN mode by pressing the MODE switch.
 - b) Set the louver angle by pressing the LOUVER switch.








- 6. Stop the test run (normal)
 - a) The test run stops automatically after two hours.
 - b) You stop the test run by pressing the RUN/STOP switch again.
 After the test run has finished, check that the red RUN LED and the green TIMER LED turn OFF.
- 7. Stop the test run (abnormal) for the PC-RLH 9/11.

If you cannot use the PC-LH3A because of battery shortage or any other reason, perform the emergency operation as follows.


- a) COOL switch: Press the COOL switch in order to start the cooling process. Press the COOL switch again in order to stop the cooling process.
- b) HEAT switch: Press the HEAT switch in order to start the heating process. Press the HEAT switch again in order to stop the heating process.



- c) Alarm code display
 - If some malfunction occurs because of the activation of a safety device or any other reason, the red RUN LED blinks (0.5 seconds ON / 0.5 seconds OFF).
 - Refer to the chapter 7.2.1 for the alarm code table.
 - The alarm code displays the number of blinks of the green DEF LED and the yellow FILTER LED as shown bellow:

Green DEF LED: Digit 2 of the alarm code blinks.

Yellow FILTER LED: Digit 1 of the alarm code blinks. (Alphabet code: A=10 blinks, B=11 blinks, C=12 blinks, etc.).



- The red RUN LED (1 second ON / 1 second OFF) means that there is an abnormal transmission between the indoor units and the outdoor unit.

6

6.4. Test run procedure from the outdoor unit side

The test run procedure from the outdoor unit side is shown below. You can set this DIP switch while the power source is ON.

• Setting of dip switch (before shipment)

		DSW1
	1	Cooling: Pin 1 ON
	2	Heating: Pin 1, 2 ON
	3	Cooling intermediate season: Pin 1, 3 ON
1234	4	Heating intermediate season: Pin 1, 2, 3 ON
	5	Manual compressor OFF: Pin 1~4 ON



WARNING

- Electrical hazard. Can cause serious injuries. Do not touch any other electrical components while you are setting the switches on the PCB.

i

NOTE

- Set all the DIP switches of DSW1 to OFF after completing the test run.

	Dip switch setin	g	Operation	Remarks
Test run	 Setting operation mode (a) Cooling: Set DSW1-1 ON (b) Heating SET DSW1-1 and 2 ON (c) Cooling intermediate season: Set DSW1-1 and 3 ON (d) Heating intermediate season: Set DSW1-1, 2 and 3 ON 	ON 1 2 3 4 ON 1 2 3 4 ON 1 2 3 4 ON 1 2 3 4 ON 1 2 3 4	 The indoor unit automatically starts to operate when the test run of the outdoor unit is set. You can perform the ON/ OFF operation from the remote control switch or the DSW1-1 of the outdoor unit. Continuous operation during 2 hours is performed without the Thermo-OFF condition. 	 Make sure that the indoor units start to operate in accord with the test run of the outdoor unit. If you start the test run from the outdoor unit and you stop the test run from the remote control switch, the test run function of the remote control switch is cancelled. However, the test run function of the outdoor unit is not cancelled. If the more than one indoor unit is connected with one remote control switch, all the units start the test run at the same time. Therefore, turn OFF the power source so that the indoor units do not perform the test run. If this is the case, the TEST RUN indication of the remote control switch may flicker. This is not abnormal. The setting of DSW1 is not required for the test run from the remote control switch.
Manual OFF of compressor	2. Forced stoppage of comp Set DSW1-4 ON	ON 1 2 3 4	 When DSW1-4 is ON during the compressor operation, the compressor stops operating immediately and the indoor unit is under the Thermo-OFF condition. When DSW1-4 is OFF, the compressor starts to operate after the cancellation of the 3-minute guard. 	 Do not turn ON and OFF the compressor frequently.


6.5. Normal operation pressure

You can check the excess or the deficiency of the refrigerant in comparision with the following charts and actual pressure measurement.


The following checking procedure is useful during test run and maintenance work.

Nomina	I value (I	MPa)	RCI	RCD	RPI	RPC	RPK
Cooling		Pd	2.82	2.85	2.82	2.81	2.78
Cooling	3 HP	Ps	0.93	0.95	0.91	0.90	0.88
Lippting	3 112	Pd	2.67	2.96	2.80	2.97	3.12
Heating		Ps	0.67	0.68	0.67	0.67	0.69
Cooling		Pd	2.75	2.75	2.77	2.74	-
Cooling	ELID	Ps	0.80	0.80	0.79	0.79	-
Lipsting	5 HP	Pd	2.59	2.71	2.60	2.49	-
Heating		Ps	0.61	0.62	0.60	0.59	-

• Heating operation pressure correction values for models RASC-(3/5)H(V)RNE



• Cooling operation pressure correction values for models RASC-(3/5)H(V)RNE



Ø

NOTE

- The above curves indicate pressures under the following conditions:
- Indoor Fan Speed: HIGH
- Indoor total capacity: 100% compared with the capacity of the outdoor unit. (Connected 1 indoor unit)
- Piping length: 7.5m (main piping: 5m, branch piping: 2.5m x 4)
- Do not use the above data for the refrigerant charge procedure.
- These data should be used as a reference for the checking of operating conditions.
- Nominal Pd and Ps Indoor unit combination:

6.6. Check list

Check list on test run

MODEL:	SERIAL No.	COMPRESSOR MFG. No.
CUSTOMER'S NAME AND ADDRESS:		DATE:
 Is the rotating direction of the indoor coil fan of Is the rotating direction of the outdoor coil fan of Is there any abnormal compressor sound? Has the unit been operating for at least twenty Check the room temperature: 	correct? / (20) minutes?	_
Inlet: <u>No.1 DB /WB °C, No.2</u> Outlet: <u>DB /WB °C,</u> Inlet: <u>No.5 DB /WB °C, No.6</u>	<u>DB /WB °C</u> ,	<u>DB /WB °C</u> , <u>No.4 DB /WB °C</u> <u>DB /WB °C</u> , <u>DB /WB °C</u> <u>DB /WB °C, No.8 DB /WB °C</u>
Inlet: <u>No.5 DB /WB °C, No.6</u> Outlet: <u>DB /WB °C,</u> 6. Check the outdoor temperature: Inlet: <u>DB °C, WB °C</u> Outlet: <u>DB °C, WB °C</u>	<u>DB /WB °C</u> ,	<u>DB /WB °C,</u> <u>No.8 DB /WB °C</u> <u>DB /WB °C</u> , <u>DB /WB °C</u>
 Check the refrigerant temperature: Operation Discharge gas temperature: <u>Td=</u> Liquid pipe temperature: <u>Te=</u> 	mode (cool or heat) <u>°C</u> °C	
8. Check the pressure: Pd= Discharge pressure: Ps=	<u>kg/cm²G</u> kg/cm²G	
9. Check the voltage: Rated voltage <u>V</u> Operating voltage: <u>L1-L2 V</u> , Starting voltage: <u>V</u>	<u>L1-L3 V</u> , <u>L2-L3</u>	V
Phase imbalance: 1- —— = Vm		
10. Check the compressor input running current	ectly?	
21. Does the drain water flow smoothly from the c	Irain pipe?	

6

Check list on compressor

CLIENT: MODEL:	DATE
Serial No.: Production	n date: Checker:

No.	Check item	Check method	Result	Remarks
1	Is THM9 correctly connected? THM9: Discharge gas thermistor	 (1) Is wire of thermistor correctly connected by viewing? (2) Check to ensure the 7-segment indication of Td when comp. is operating. Td: Temperature of THM9 		
2	Is thermistor THM9 disconnected?	 (1) Check to ensure that thermistor on the top of comp. is correctly mounted by viewing? (2) Check to ensure that actually measured temp. is the same as the indication during check mode. 		
3	Is current sensor faulty?	(1) Check to ensure that indication A1 and A2		
4	Is current sensing part on PCB2 faulty?	are 0 during compressor stopping. (2) Check to ensure that indication A1 and A2 are not 0 during compressor running.		
5	Is the direction of current sensor (CTU, CTV) reverse?	Check the direction => by viewing.		
6	Are power source wires, U and V inserted correctly into current sensor?	Check to ensure that wires are correctly inserted.		
7	Is exp. valve (MV1) correctly connected?	Check to ensure that MV1 to CN5A is correctly connected.		
8	Is exp. valve (MV1) coil correctly connected?	Check to ensure that each coil is correctly mounted on the valve.		
9	Are the refrigeration cycle and electrical wiring system incorrectly connected?	Check to ensure that refrigerant is flowing into indoor units by operating one refrigerating cycle only from the outdoor unit.		
10	Is opening of exp. valve completely closed (locked)?	Check the following by the check mode of outdoor units. (1) Liquid pipe temp. (TL) < air intake temp. (Ti) during cooling operation (2) Liquid pipe temp. (TL) > air intake temp. (Ti) during heating operation		
11	Is opening of exp. valve fully opened (locked)?	Check to ensure that liquid pipe temp. is lower than air intake temp. of stopping indoor unit when other indoor units are operating under cooling operation.		
12	Are the contacts for comp. magnetic switch CMC1 faulty?	Check the surface of each contact (L1, L2 and L3) by viewing.		
13	Is there any voltage abnormality among L1-L2, L2-L3 and L3- L1?	Check to ensure that voltage imbalance is smaller than 3%. Please note that power source voltage must be within 380V or 220V+10%.		
14	Is the comp. oil acidified during compressor motor burning?	Check to ensure that the oil color is not black.		

Additional information for "Check list on compressor"

Check item	Additional information (mechanism of compressor failure)
1 & 2	The liquid refrigerant return volume to the compressor is controlled by the discharge gas temperature Td when compressor is operating. If Td thermistor is disconnected, the liquid refrigerant return volume will become small by detecting the temperature even if the actual discharge gas temperature is high. Therefore, this abnormal overheating by detecting the temperature operation will result in insulation failure of the motor winding.
3 & 4	Overcurrent control (operating frequency control) is performed by detecting current by the PCB2. In this case, winding insulation failure will occur, since control is not available in spite of actually high current.
5&6	The current sensor checks phase and adjusts output electrical wave in addition to the above mentioned items. If fault occurs, the output electrical wave becomes unstable giving stress to the motor winding, resulting in winding insulation failure.
7 & 8	During a cooling operation, SH is controlled by MV of each indoor units. During a heating operation, Td is controlled by MV1. If expansion valves are incorrectly connected, correct control is not available, resulting in compressor seizure depending on liquid refrigerant returning conditions or motor winding insulation failure depending on overheating conditions.
9	If the refrigeration cycle and electrical system are incorrectly connected, abnormally low suction pressure operation is maintained or abnormally high discharge pressure operation is maintained, resulting in giving stress to the compressor, since their correct control is not available.
10	If the expansion valve and electrical system are incorrectly connected, abnormally low suction pressure operation is maintained or abnormally high discharge pressure operation is maintained, resulting in giving stress to the compressor, since their correct control is not available.
11	The compressor may be locked due to the liquid return operation during the cooling operation.
12	In the case that the contacting resistance becomes big, voltage imbalance among each phase will cause abnormal overcurrent.
13	In this case, overcurrent will occur, efficiency will decrease or the motor winding will be excessively heated.
14	In the case, it will result in motor burning or compressor failure.

7. Troubleshooting

Contents

7. Tro	oubleshooting	123
7.1. Ir	nitial troubleshooting	124
7.1.1.	Checking using the 7-segment display	124
7.1.2.	Failure of the power supply to the indoor unit and the remote control switch	
7.1.3.	Abnormal transmission between the remote control switch and the indoor unit	
7.1.4.	Abnormal operation of the devices	127
7.2. T	roubleshooting procedure	135
7.2.1.	Alarm code	135
7.2.2.	Troubleshooting by alarm code	
7.2.3.	Troubleshooting in check mode	
7.2.4.	Troubleshooting using the 7 segment display	
7.2.5.	Cause of inverter stoppage	
7.3. P	Procedure for checking each main part	187
7.3.1.	Self-checking procedure of PCB using the remote control switch	
7.3.2.	Self-checking procedure of the Remote Control Switch	
7.3.3.	Checking procedure of other main parts	

7

7.1. Initial troubleshooting

7.1.1. Checking using the 7-segment display

• Simple checking procedure using the 7-segment display

- 1. Turn on all the indoor units which are connected to the outdoor unit.
- 2. Turn on the outdoor unit
- 3. Auto-addressing starts. (outdoor unit printed circuit board PCB 1)
 - During the auto-addressing, you can check the following items using the 7-segment display of the outdoor unit.
 - a) Disconnection of the power supply to the indoor unit.
 - b) Duplication of the indoor unit number.

Normal case:

The 7-segment display of the outdoor unit is not indicated.

Abnormal case:

If there is something wrong, the 7-segment display of the outdoor unit displays the following indications:

	Cause	Indication	Remarks
a.	The indoor units are not supplied with power.	EI	continues to flash after 30 seconds.
b.	Disconnection of the operating line between the outdoor units and the indoor units.	EI	continues to flash after 30 seconds.
C.	Duplicated settings of the indoor unit number on the rotary switch RSW (Refer to the section 7.2.2, "Troubleshooting using the alarm code" for the description of the alarm code "35").		

7.1.2. Failure of the power supply to the indoor unit and the remote control switch

• The LED and the LCD are not indicated.

• Not operated

If the fuses are blown out or a breaker is activated, investigate the cause of the overcurrent and take the necessary action.

Phenomenon	Cause	Check item	Action (Turn OFF the main switch)
Power failure or	power is not ON	Measure the voltage using the voltmeter	Supply the power
Blown out fuse or activation of	Short circuit supplied between the wires	Check for any uncovered part of the wires	Remove the cause of the short circuit and replace the fuse
the breaker at the power source	Short circuit of the wires to earth	Measure the insulation resistance	Remove the cause of the short circuit and replace the fuse
Blown out fuse at the control	Short circuit supplied between the wires	Check for any uncovered part of the wires	Remove the cause of the short circuit and replace the fuse
circuit	Short circuit of the control circuit to earth	Measure the insulation resistance	Remove the cause of the short circuit and replace the fuse
Failure of the transform	er at the indoor unit side	Measure the voltage at the secondary side	Replace the transformer
Disconnected cable of the	ne remote control switch	Connect the cable	Replace the cable or repair the cable
Insufficient contacting at the	Insufficient connection or incorrect connection of the indoor unit PCB		
connectors of the remote control switch	Insufficient connection or incorrect connection of the indoor unit PCB in the remote control switch	Check the connectors	Correctly connect the connector
Failure of the remote control switch		Check the remote control switch using the self-check mode *1)	Replace the remote control switch if it failed
Failure of PCB	Unconnected wires to PCB	Check the connectors	Correctly connect the wires
	Failure of PCB	Check PCB using the self-check mode *2)	Replace PCB if it failed
Incorrect wirin	ng connection	Take action according to the p "TEST	

*1):Refer to section 7.3.2.

*2):Refer to section 7.3.1.

125

7.1.3. Abnormal transmission between the remote control switch and the indoor unit

• **RUN LED on the remote control switch:** Flickering every 2 seconds.

Phenomenon	Cause	Check item	Action (Turn OFF the main switch)
Disconnection or insufficient contacting of the remote control cable		Check the cable and the connections	Repair the cable or connect the cable
Failure of the remote control switch		Check the remote control switch using the self-check mode *1)	Replace the remote control switch if the remote control switch is faulty
Failure of PCB (in the indoor unit	Disconnected wire to PCB	Check the connectors	Correctly connect the wires
and the remote control switch)	Failure of PCB	Check PCB using the self-check mode *2)	Replace PCB if it failed

*1):Refer to section 7.3.2.

*2):Refer to section 7.3.1.

7

7.1.4. Abnormal operation of the devices

Phenomenon	Cat	JSe	Check item	Action (Turn OFF the main switch)
	Failure of the indoor unit fan motor	Disconnected coil	Measure the coil resistance using the tester	Replace the indoor unit
		Burnt-out coil	Measure the insulation resistance	fan motor
	Failure of the Outdoor unit	Disconnected coil	Measure the coil resistance using the tester	Replace the Outdoor
	fan motor	Burnt-out coil	Measure the insulation resistance	unit fan motor
RUN LED is ON and the LCD is indicated However, the system does not operate	Failure of the magnetic switch for the Outdoor unit fan motor	Insufficient contacting	Measure the voltage between the contacting parts	Replace PCB for the Outdoor unit
(For example, the indoor fan, the outdoor fan or the compressor does not operate)	Failure of the comp. motor		Measure the resistance between two wires	De slave the commence
opolatoj	Failure of the comp.		Check for an abnormal sound from the comp.	Replace the compressor
	Failure of the magnetic switch for comp.	Insufficient contacting	Check that the magnetic switch activates correctly or not	Replace the magnetic switch
		Disconnected wiring to PCB	Check the connections	Correctly connect the wiring
	Failure of one of PCBs	Failure of PCB	Check PCB using the self- check mode *1)	Replace PCB if it failed
	Failure of air inlet	Failure of thermistor		Penlace or correctly
The comp. does not stop or start even if the setting	thermistor	Disconnection of thermistor	Check it by self-checking *2)	Replace or correctly connect the wires if abnormal operation exists
temperature on the LCD changes to *3)	Abnormal operation of the remote control switch cord			
	Failure of the ir	ndoor unit PCB	Check PCB using the self- check mode *1)	Replace PCB if it failed

Phenomenon	Cause	Check item	Action (Turn OFF the main switch)
The comp. does not stop or start even if the setting temperature on LCD changes to *3)	Incorrect optional setting	Check the setting condition of "remote control thermostat" using the optional setting Setting and control: "00": Control using the indoor thermistor for the suction air "01": Control using the thermostat of the remote control switch "02": Control using the average value of the indoor thermistor for the suction air and the thermostat of the remote control switch	If the thermostat of the remote control switch is not used, set at "00"
	Incorrect input/output setting	Check setting condition of "i1" and "i2" by input/output setting. * Setting and ontrol: "01": Room thermostat (cooling) "02": Room thermostat (heating)	In case that room thermostat is not used, set for input signal actuallt used. If no signal is used, set at "00"

*1):Refer to section 7.3.2.

*2):Refer to section 7.3.1.

*3): Even if the remote control switches are normal, the compressor does not operate under the following conditions:

1. Indoor temp. is lower than 21°C or Outdoor temp. Is lower than -5°C during the cooling process (DB).

- 2. Indoor temp. is higher than 27°C (DB) or Outdoor temp. is higher than 15°C (WB) during the heating process.
- 3. When a cooling (or heating) process signal is given to the Outdoor unit and a different mode as heating (or cooling) process signal is given to the indoor units.
- 4. When an emergency stop signal is given to Outdoor unit.

Phenomenon	Cause		Check item	Action (Turn OFF the main switch)
	Failure of the discharge	Failure of the thermistor	Check the thermistor using the self-check mode *2)	Replace or correctly connect the wiring when it is abnormal
Indoor fan speed does not	air temp. thermistor	Disconnected wire of the thermistor		
change	Failure of the rem	ote control switch	Check it using the self-	Replace if it failed
	Failure of PCB fo	or the indoor unit	check mode *1)	Replace if PCB fails
	Failure of thermistor for outdoor evaporating temp.	Failure of thermistor	Poplace or correctly conr	poet when it is obnormal
	during heating	Disconnected wire of thermistor	Replace or correctly connect when it is abnorm	
	Failure of 4-way valve	Disconnected 4-way valve coil	Measure the resistance of coil	Danlage the 4 way walks
No defrost operation		Incorrect activation of 4-way valve	Enforced power supply	Replace the 4-way valve
mode is available during the heating process or the defrost operation	Disconnected control wires between indoor unit and outdoor unit		Check the connectors	Correctly connect the wiring
continues	s Failure of the outdoor units of PCB	Disconnected wiring to PCB	Check the connectors	Correctly connect the wiring
		Failure of PCB	Check PCB using the self- check mode *1)	Replace PCB when the check mode is not available
	Failure of the indoor unit	Disconnected wiring to PCB	Check the connectors	Correctly connect the wiring
	of PCB Failure of PCB			
The LED and the LCD on the remote control switch remain ON	Failure of PCB in the indoor unit or the remote control switch		Check PCB using the self- check mode *1)	Replace if PCB fails

*1):Refer to section 7.3.2.

*2):Refer to section 7.3.1.

Phenomenon	Ca	use	Check item	Action (Turn OFF the main switch)
	Indoor cool load is greate	r than the cooling capacity	Calculate the cool load	Use a bigger unit
		Gas leakage or shortage of refrigerant	Measure superheat	Correctly charge the refrigerant after repairing the gas leakage
		Excessively small diameter tube or long piping	Measure and check the field-supplied pipes	Use the correct pipes
		Incorrect activation of the check valve of the outdoor unit	Check whether or not the temp. difference exists before/after the check valve	Replace the check valve for the outdoor unit
			Check for clogging	Remove the clogging
	g Excessively low suction pressure	Failure or malfunction of the expansion valve	Check the connection cord and the connector	Replace the connector
			Is there an operation sound from the coil?	Replace the coil
Insufficient cooling process			Is the thermistor on the compressor normal?	Replace the thermistor
			Is the thermistor installed correctly on compressor?	Correctly install the thermistor
		Clogged strainer in the indoor unit; clogging at the low pressure piping	Check the temp. difference at the inlet and the outlet of the strainer	Replace the strainer in the indoor unit
		Clogging at the low pressure piping	Check the temp. difference	Remove the clogging
		Insufficient air flow to the indoor unit heat exchanger	Check for clogged air filter	Clean the air filter
			Check for an obstacle at the inlet or the outlet	Remove the obstacles
		Excessively low air temp. to the indoor unit heat exchanger	Insufficient speed of the indoor unit fan motor?	Replace the fan motor
			Short-circuited indoor unit air?	Remove the cause of the short-circuited air

Phenomenon	Ca	use	Check item	Action (Turn OFF the main switch)
		Insufficient air flow to the outdoor unit heat	Clogging of the outdoor unit heat exchanger?	Remove the clogging
			Obstacles at the inlet or the outlet of the outdoor unit heat exchanger	Remove the obstacles
		exchanger	Is the service area for the outdoor unit sufficient?	Secure the service area
			Correct fan speed?	Replace the fan motor
		Excessively high air temp. to the outdoor unit heat	Short-circuited air to the outdoor unit?	Remove the cause of the short-circuited air
		exchanger	Any other heat load near the outdoor unit?	Remove the Rasc Unit
	Excessively high	Excessively charged refrigerant	Expansion valve opening	Correctly charge the refrigerant
	discharge pressure	Non-condensate gas in cycle	Check each temp. and each pressure	Charge the refrigerant after the vacuum pumping
		Clogging of the discharge piping	Check for clogging	Remove the clogging
		Failure or malfunction of the expansion valve	Check for clogging	Remove the clogging
Insufficient cooling process			Check the connection cord and the connector	Replace the connector
			Is there an operation sound from the coil?	Replace the coil
			Is the thermistor on the compressor normal?	Replace the thermistor
			Is the thermistor installed correctly on the compressor?	Correctly install the thermistor
	Malfunction or internal leakage of the 4-way valv		Check the temp. difference at the inlet and the outlet of the 4-way valve	Replace the 4-way valve
	Excessively low suction pressure	Malfunction or internal leakage of the 4-way valve	Check the Temp. Difference between the Inlet and the Outlet of 4-Way Valve	Replace the 4-way valve
		Failure of solenoid valve for bypass	Check refrigerant leakage of solenoid valve	Replace solenoid valve
	Discharge temp. of the	e indoor unit is unstable	Check the expansion valve of the indoor unit in the same system	Replace the failed expansion valve of the indoor unit

Phenomenon	Cause		Check item	Action (Turn OFF the main switch)
	Indoor heat load is grea capad		Calculate the heat load	Replace the unit with a bigger unit
		Gas leakage or insufficient refrigerant charge	Measure superheat	Correctly charge the refrigerant after the gas leakage check and repairing
		Excessively small diameter or long piping	Measure the field- supplied piping	Use the specified pipes
			Check for clogging	Remove the clogging
			Check the connection cord and the connector	Replace the connector
		Failure or malfunction of the expansion valve	Is there an operation sound from the coil?	Replace the coil
	Excessively low suction pressure		Is the thermistor on the compressor normal?	Replace the thermistor
			Is the thermistor installed correctly on compressor?	Correctly install the thermistor
Insufficient heating process		Clogging of I.U./O.U. strainer	Check the temp. difference between the inlet and the outlet of strainer	Replace the strainer for the outdoor unit or the indoor unit
		Clogging of suction piping	Check the temp. difference of each part	Remove the clogging
		Insufficient air flow through the outdoor	Is the outdoor unit heat exchanger clogged?	Remove the clogging
			Are there any obstacles at the inlet or the outlet of outdoor unit?	Remove the obstacles
		unit heat exchanger	Is the service area for the outdoor unit sufficient?	Secure a sufficient service area
			Check the speed of the outdoor unit fan	Replace the fan motor
		Excessively low air temp. through the outdoor unit heat exchanger	Check for any short- circuited air to the outdoor unit	Remove the cause of the short-circuited air
		Defrosting is insufficiently completed	Check the thermistor for the defrost operation	Replace the thermistor for the defrost operation

Phenomenon	Ca	use	Check item	Action (Turn OFF the main switch)
		Insufficient air flow to the indoor unit heat exchanger	Check the filter for a clogging	Remove the clogging
			Check for any obstacles at the inlet or the outlet of the indoor unit	Remove the obstacles
			Check the indoor fan speed	Replace the fan motor
	Excessively high discharge pressure	Excessively high air temp. to the indoor unit heat exchanger	Check whether or not the short-circuited air exists	Remove the cause of the short-circuited air
		Excessively charged refrigerant	Check the refrigerant quantity *1)	Correctly charge the refrigerant
Incufficient booting	ient heating rocess	Non-condensate gas in ref. cycle	Check the refrigerant quantity *1)	Recharge the refrigerant after the vacuum pumping
process		Clogging of the discharge pr. piping	Check for clogging	Remove the clogging
	Malfunction or internal le	akage of the 4-way valve	Check the temp. difference at the inlet and the outlet of the 4-way valve	Replace the 4-way valve
	Malfunction of the check	valve of the outdoor unit	Check the temp. difference at the inlet and the outlet of the check valve	Replace the check valve
Excessively high suction pressure	Malfunction or internal leakage of 4-way valve	Check the temp. difference at the inlet and the outlet of the 4-way valve	Replace the 4-way valve	
	Discharge temp. of the	indoor unit is unstable	Check the expansion valve of the indoor unit in the same system	Replace the failed expansion valve of the indoor unit

*1):Refer to chapter 7 of TC.

Phenomenon	Ca	Cause		Action (Turn OFF the main switch)
	Foreign particles inside of the fan casing		Visually inspect it	Remove the foreign particles
	Indoor unit fan runne	r is hitting the casing	Visually inspect it	Adjust the position of the fan runner
	Outdoor unit fan runn	er is hitting the casing	Visually inspect it	Adjust the position of the fan runner
		Faulty Installation	Check that each part is tightly fixed	Tightly fix each part
Cooling or heating process with an abnormal sound	Abnormal sound from the	Liquid ref. compression	Adjust the suction gas temp. and pressure	Ensure superheat
Sound	compressor	Wear or breakage of the internal comp. parts	Abnormal sound from the inside of the compressor	Replace the compressor
		No heating by the oil heater	Check the resistance (oil heater, fuse)	Replace the oil heater or the fuse
	Humming sound from the magnetic conductor		Check the surface of the contacts	Replace the magnetic switch
	Abnormal vibration of th	on of the cabinets	Check each fixing screw	Tightly fix each screw
Outdoor fan does not	Obstacle at th	e Outdoor fan	Check the obstacles	Remove the obstacles
operate when the compressor operates	Watching condition for	or the heating process	Wait for the switching of the 4-Way valve (1 ~ 3 minutes)	If the 4-Way valve does not switch, check for insufficient refrigerant
Indoor fan does not operate when the		5	Check the operation pressure *1)	Add the refrigerant
compressor operates	Disconnected wirin	Faulty installation Liquid ref. compression Wear or breakage of the internal comp. parts No heating by the oil heater the magnetic conductor on of the cabinets the Outdoor fan	Check the wiring	Connect the wiring correctly

*1):Refer to chapter 10 of TC.

7.2. Troubleshooting procedure

7.2.1. Alarm code


If the RUN LED flickers for 2 seconds, there is a failure in the transmission between the indoor unit and the remote control switch.

Possible causes are:

- Broken remote cable
- Contact failure in the remote control cable
- Defective IC or defective microcomputer

In any case, ask your retailer for service

If the RUN LED flickers 5 times (5 seconds) with the unit number and the alarm code displayed, make a note of the alarm code (refer to the table below) and ask your retailer for service.



Alarm code table

Code No.	Category	Type of Abnormality	Main Cause
01	Indoor unit	Activation of protection device	Float switch activated.
02	Rasc Unit	Activation of protection device	Activation of PSH, locked motor, abnormal operation in the power supply phase, Float Switch Activation in Rasc Unit.
03	Transmission	Abnormality between indoor (or Rasc Unit) and Rasc Unit (or indoor) units	Incorrect wiring. Failure of PCB. Tripping of fuse. Power supply OFF.
04	Transmission	Abnormal operation between inverter and control PCB	Transmission failure between inverter PCBs.
05	Power source	Abnormality of power source wiring	Incorrect Wiring.
06	Voltage drop	Voltage drop due to excessively low or high voltage in Rasc Unit	Voltage drop in power supply. Incorrect wiring or insufficient capacity of power supply wiring.
07	Quela	Drop in discharge gas overheating	Excessive refrigerant charge. Expansion valve lock open.
08	Cycle	Increase in discharge gas temperature	Insufficient refrigerant charge, refrigerant leakage. Expansion valve closed or clogged.
11		Inlet air thermistor	
12]	Outlet air thermistor	
13	Sensor in	Anti-freeze thermistor	Failure of thermistor, sensor, connection
14	indoor unit	Gas pipe thermistor	
19		Protection device for fan motor is triggered	Failure of fan motor.
20		Compressor thermistor	
22	Sensor of Rasc Unit.	Outside air thermistor	Failure of thermistor, sensor, connection.
24		Evaporation thermistor	
31		Incorrect setting of Rasc Unit and indoor unit	Incorrect setting of capacity code
35	System	Incorrect setting of indoor unit number	Duplication of indoor unit number.
38		RASC Unit circuit protection abnormality	Failure of indoor unit PCB; incorrect wiring; connection to indoor unit PCB.

HITACHI Inspire the Next

Code No.	Catamami		Main Causa
Code No.	Category	Type of Abnormality	Main Cause
41		Overload cooling (possible activation of high pressure device)	RASC unit pipe thermistor temp. is higher than 55°C and the compressor top temp. is higher than 95°C, outdoor unit protection device is activated.
42	Pressure	Heating overload (high-pressure device may be activated)	If I.U. freeze protection thermistor temp. is higher than 55°C and compressor top temp. is higher than 95°C, outdoor unit protection device is activated.
47		Enabling of protection device for low pressure drop	Stoppage due to excessive decrease of evaporating temperature (Tem < -35°C) is activated 3 times in one hour, motor locked in heating operation.
48		Activation of overcurrent protection	Clogging of heat exchanger. Locked compressor. Excessive refrigerant charge, Failure of Inverter PCB.
51		Abnormality in inverter current sensor	Failure of Control PCB or Inverter PCB.
53	Inverter	Activation for protection of Inverter	Inverter PCB Abnormality Compressor failure, heat exchanger clogged.
54		Increase in inverter fin temperature	Abnormal inverter fin thermistor Heat exchanger clogged. Abnormal Rasc Unit fan. Failure of Fan Motor.
55		Inverter Abnormality	Failure of Inverter PCB.
59	Inverter	Abnormal inverter fin thermistor (for the temperature of inverter fin)	Loose connector, short-circuit in disconnected cable
b1	Indoor unit No. setting	Incorrect unit No. setting	Over 64 indoor units, setting by refrigerant cycle No. or indoor unit address.
EE	Compressor	Compressor protection alarm	Compressor failure.

7.2.2. Troubleshooting by alarm code

Alarm code	Description	
Activation of the safety device in the indoor unit		
 The unit number, The unit number –This alarm code 	ckers and "ALARM" is displayed on the remote control switch. the alarm code and the unit code are alternately displayed on the set temperature section. and the alarm code are displayed on the display of the RASC unit PCB. is displayed when the contact between #1 and #2 of CN14 is not closed over 120 seconds during cess, the heating process or the fan operation.	

No RCI, RCIM, RCD, RPC, RPI, RPF(I) : Activation of the safety Is DC24V applied to both ends of R24? device (such as float switch FS) or incorrect wiring Yes ТНМ1ТНМ2 ТНМ3ТНМ4ТНМ5 ТНМ6 LED1 O LED2 O CN CN12 Faulty PCB CN9 N10 LED4 CN10 R2

Phenomenon	Cause		Check item	Action (Turn OFF the main switch)
	High drain level	Clogging of the drainage	Check the drain pump and drain discharge boss	Remove the clogged foreign particles
Activation of the float	pat	Fault	Check the continuity when the drain level is low	Replace the float switch if faulty
switch	Faulty float switch	Faulty contacting	Measure the resistance using the tester	Fix the looseness and Replace the connector
	Faulty connection	Check the connections	Repair the connection	
	Faulty indoor unit PCB		Check PCB using the self-check mode *1)	Replace PCB if faulty


*1):Refer to section 7.3.1 and 7.3.3.

Alarm code "01" is not displayed at the RPK series.

HITACHI Inspire the Next

Alarm code	Description
	Activation of the safety device in the RASC unit

- The RUN LED flickers and "ALARM" is displayed on the remote control switch.
- The unit number, the alarm code and the unit code are alternately displayed on the set temperature section. The unit number and the alarm code are displayed on the display of the outdoor unit PCB.
 - This alarm is indicated when one of safety devices is activated during compressor running.



Service Manual


Phenomenon	Cause	9	Check item	Action (Turn OFF the main switch)
			Check the heat exchanger for dust or for clogging	Remove the dust or the clogging
			Check the air filter for dust	Remove the dust
	Insufficient air flow to th (Outdoor heat exchange process or indoor heat ex heating pro	r during the cooling xchanger during the	Check for any obstacles at the inlet or the outlet of the heat exchanger	Remove the obstacles
	01	,	Check the service area	Secure service area
			Check the speed (Outdoor fan: cooling / indoor fan: heating)	Replace the fan motor if faulty
	Malfunction of the expansion valve		Disconnected of the connector	Fix the looseness or reconnect the connector
Activation of the high-			Fully closed and locked	Replace the expansion valve
pressure switch due to the excessively high discharge pressure			Calculate the heat load	Reduce the heat load or use a bigger unit
	Evenenively high terms	Excessively high temp. air to the indoor unit		Provide good circulation
	Excessively high temp. a			Remove the short-circuited air
			Check for other Rasc Unit	Remove the Rasc Unit
	Factorial	Faulty pressure switch	Measure the discharge pressure. Check the continuity after the decrease of the pressure	Replace the pressure switch if faulty
	Faulty high-pressure – switch	Insufficient contacting	Measure the resistance using the tester	Fix the looseness. Replace the connector
		Incorrect connection	Check the connections	Repair the connections

HITACHI	
Inspire the Next	

Phenomenon	Cause	Check item	Action (Turn OFF the main switch)
		Check for clogging	Remove the clogging
		Check the connect wiring and the connectors	Replace the connector
	Faulty or malfunction of the expansion valve	Check the operation sound from the coil	Replace the coil
		Check the discharge gas thermistor	Replace the thermistor
		Check the attaching state of the discharge gas thermistor	Reattach the thermistor
Activation of the high-pressure switch due to the excessively high discharge pressure	Faulty gas bypass solenoid valve	Check for clogging	Replace the gas bypass solenoid valve
	Overcharged refrigerant	Check the cycle operation temp.	Charge the refrigerant correctly
	Mixture of the non-condensate gas in the refrigerant cycle	Check the air temp. and the pressure	Recharge the refrigerant after the vacuum pumping
	Clogging of the discharge piping	Check for clogging	Remove the clogging
	Liquid line stop valve or gas line stop valve is not in operation	Check the stop valves	Fully open the stop valves
	Clogging of the check valve	Check for clogging	Replace the check valve


Troubleshooting Service Manual	HITAC Inspire the	
Alarm code	Description	
	Abnormal operation of picking up phase signal	
The unit number	flickers and "ALARM" is displayed on the remote control switch. er, the alarm code and the unit code are alternately displayed on the set temperature section. The unit e alarm code are displayed on the display of the RASC unit PCB.	

- This alarm is displayed when the main power source phase is reversely connected or one phase is not connected.




• RASC-(3/5)HVRNE

RASC-10HRNE



Phenomenon	Cause	Check item	Action (Turn OFF the main switch)
Activation of reverse phase	Reverse or single phase	Check it according to the electrical wiring	Replacing wires, repair, tightening screws or correct wiring
sensor in the RASC unit	Faulty RASC unit PCB	_	Replace PCB if faulty

Alarm code	Description				
EI	Abnormal transmiss	ssion between the indoor units and the outdoor unit			
 The unit number, the unit number a This alarm is diabetween the inmicro-compute The alarm is diabetweor unit. Investigate the 	he alarm code and the unit cod nd the alarm code are displayed isplayed when an abnormal op door units and the outdoor unit r is automatically reset. splayed when the abnormal tra	d on the remote control switch. de are alternately displayed on the set ed on the display of the outdoor unit PC peration is maintained for three minutes t. Also, an abnormal operation is mainta ansmission is maintained for 30 second take the necessary action when the fus	CB. s after the normal transmission ained for 30 seconds after the ds from the starting of the		
(Refer to the next page)					
 Note from next page: *1) In case that terminal resistance (DSW5-1P) is OFF when H-Link connection is performed. Set the terminal resistance to ON when CN8 is removed. Set the terminal resistance to OFF when CN8 is reconnected. * Check item 					
	Power supply	Faston terminal			
	380-415V/50Hz	between 1 and 3 of PCN1 on PCB			



HITACHI
Inspire the Next


Phenomenon	Cause	Check item	Action (Turn OFF the main switch)
Power failure or	no power supply	Measure the voltage using the tester	Supply the power
	Short circuit between wires	Check the insulation material for breaks	Remove the short circuit and replace the fuse
Blown out fuse for the power	Short-circuited wire to ground	Measure the insulation resistance	Remove the short circuit to ground and replace the fuse
source or activation of the outdoor unit breaker	Faulty comp. motor	Measure the resistance between the wires and the insulation resistance	Replace the comp. and the fuse
	Faulty outdoor unit fan motor	Measure the resistance between the wires and the insulation resistance	Replace the outdoor unit fan motor and the fuse
Blown out fuse for control circuit or activation of outdoor unit breaker	Short circuit between wires	Check the insulation material for breaks	Remove the short circuit and replace the fuse
	Short circuit of the control circuit (to ground)	Measure the insulation resistance	Remove the short circuit and replace the fuse
	Faulty solenoid coil for the magnetic switch for the comp. motor	Measure the resistance of coil	Replace the magnetic switch and the fuse
	Failure of the outdoor unit fan motor	Measure the resistance between the wires and the insulation resistance	Replace the outdoor unit fan motor and fuse
Faulty tra	nsformer	Measure input voltage	Replace transformer
Disconnected wires insufficient	Between outdoor unit and indoor unit	Check the continuity of the wires. Check for looseness of the	Replacing wires repairing and tightening the screws and the correct wiring
contacting or incorrect connection	Power source wiring for the outdoor unit	connection screws. Check the terminal nos.	
Faulty PCB (Outdoor unit,	Disconnected wires to PCB	Check the connections	Correctly connect the wires
indoor unit)	Faulty PCB	-	Replace PCB if faulty
Incorrect wiring	Disconnected wire; insufficient contacting	Check the continuity and the looseness of connection screws	Replacing wires, repairing and tightening the screws
Incorrect wiring	Incorrect wiring	Check the terminal Nos.	Correctly connect the wires

*1)

PCB1 output voltage	Voltage
Vcc 12 - GND2	12VDC
Vcc 05 - GND1	5 VDC
Vcc 15 - GND1	15 VDC
Vcc 24 - GND1	24 VDC
Vcc 12T - GND1	12 VDC

Troubleshooting Service Manual	HITACHI Inspire the Nex
Alarm code	Description
	Abnormal transmission between Inverter PCB and RASC unit PCB1

- The RUN LED flickers and "ALARM" is displayed on the remote control switch.
- The unit number, the alarm code and the unit code are alternately displayed on the set temperature section. The unit number and the alarm code are displayed on the display of the RASC unit PCB.
 - This alarm is displayed when the abnormal operation is maintained for 30 seconds after the normal transmission between the RASC unit PCB1 and inverter PCB. Also, the abnormal operation is maintained for 30 seconds after the micro-computer is automatically reset. The alarm is displayed when the abnormal transmission is maintained for 30 seconds from the starting of the RASC unit.




PCB1: Control PCB in RASC unit Inverter dipIPM RASC-(3/5)HVRNE Inverter IPM RASC-10HRNE

Phenomenon	Cause	Check item	Action (Turn OFF the main switch)
Disconnected wires, insufficient contacting or incorrect	Between control PCB, inverter PCB and FANM	Check the continuity of wires. Check for looseness of the	Replacing wires, repairing,
connection	Power source wiring for the RASC unit	connection screws. Check the connection No.	0
Faulty PCB (PCB1 for the	Disconnected wires to PCB	Check the connections	Repair the wiring connections
control, PCB for the inverter)	Faulty PCB		Replace PCB if faulty
Incorrect wiring	Disconnected wires; insufficient contacting	Check the continuity. Check for looseness of connection screws	Replacing wires, repairing, tightening screws
	Incorrect wiring	Check the connection nos.	Correctly connect the wires

Froubleshooting Service Manual		HITA Inspire ti
Alarm code	Description	
<u>8</u>	Excessively low voltage or excessively high voltage f (RASC-(3/5)HVRNE)	or the inverter
The unit number The unit number – This alarm c alarm has th	ckers and "ALARM" is displayed on the remote control switch. the alarm code and the unit code are alternately displayed on the set temper and the alarm code are displayed on the display of the RASC unit PCB. de is displayed when the voltage between terminal "P" and "N" of Dip IPM is see occurrences in 30 minutes. If the number of occurrences is smaller than tw he alarm code "06" means fan controller Abnormal Operation.	insufficient and the
Restart the op	ration	
Is the power supp 230V ±10		Check the wiring and the cable capacity
Is the voltage over	87V during No	
operatior ↓ Ye		
Does the voltage the operation beca operation of other	use of the	
No ▼	Frequency can increase higher than 60 Hz	
Does LED201 on F ON after compres electromagnetic sw (CMC) turn ON	or's compressor operation?	Faulty PCB2. Replace it
No	Compressor stops when frequency increases (Approx. 20 Hz to 60 Hz)	
Is connection of between DipIPM an (CB1 and CB2), DO	L or CMC?	Connect correctly
v Yes	Be extremely carefull because of the high voltage Yes Faulty	[
Is the DC voltage	ver 240V? ► Check capacitors (CB1, 2)	Replace the capacitors
N	Normal	Capacitors have high voltage. Be extremely carefull *1)
		Faulty PCB2. Replace it
		Check the wiring PCB2 and capacitors CB. In case the wiring is correct

Refer to section 7.3.4. *2): Checking procedures of the diode module are displayed in item 7.3.4.



*1): If the capacitor has a high voltage, perform the high-voltage discharge procedure. Refer to section 7.3.4.

*2): Checking procedures of the diode module are displayed in item 7.3.4.

148

HITACHI

Inspire the Next

Troubleshooting Service Manual			 זו	HITA
Alarm code	Description			
	Decrease of discharg	e gas su	perheat	
The unit numbe number and the This alarm code – The tempera under 300pls – The tempera under 70pls	ickers and "ALARM" is displayed on the remote control s t, the alarm code and the unit code are alternately displa alarm code are displayed on the display of the RASC un- is indicated as follows: ture on the top of the compressor is less than the target at cooling operation for 30 minutes. ture on the top of compressor is less than the target and at heating operation for 30 minutes. ssor is stopped and then the retry operation is performed	yed on the hit PCB. and also th d also the R	ne I.U. expansion valve ope ASC expansion valve oper	ening is
	No No Pressor normal?		Faulty thermistor	
Is the t	Yes Ves No			
correctly	on the compressor?	▶	Install it correctly	
	ling or heating mode alarm has occurred?		Heating operation	
	Cooling ling operation		Yes	
	Yes]
			expansion valve opening and top of the compressor by the R unit PCB.	
Ye	s v	/	Yes ▼]
	J. expansion opening <300pls		RASC expansion valve opening <70pls	ightarrow
Ye	/		Yes	
	mperature on the top of compressor an estimated condensation temp.?		e on the top of compressor les ated condensation temp.?	ss >
Ye	is		Yes	
	· · · · · · · · · · · · · · · · · · ·			
Plug the connecto properly	- Connector on I.U. PCB for ex. valve	onnected prope	erly?	
I.U.: Indoor Unit	Sthe RASC fan normal? Yes	No	Replace fan motor	
	Is the refrigerant corectly charged? Yes	No	Charge correct refrigerant volume.	
	Is gas leaking? ✓ Yes ✓ Repair leaks of gas.	No	 Check the ex. valve. Or remove the cause of discharge air short-circuit at indoor and RASC units. 	
	Correctly charge refrigerant.			


Alarm code	Description	
<u>80</u>	Excessively High Discharge Gas Temperature at the Top of Compressor Chamber	
 The RUN LED flickers and "ALARM" is displayed on the remote control switch. The unit number, the alarm code and the unit code are alternately displayed on the set temperature section. The unit 		


- number and the alarm code are displayed on the display of the Outdoor unit PCB.
 - This alarm is indicated when the temperature of the thermistor on the top of the compressor is maintained higher _ than 127°C for 10 minutes or higher than 140°C for 5 seconds under cooling operation (1).
 - This alarm is indicated when the temperature of the thermistor on the top of the compressor is maintained higher _ than 120°C for 10 minutes or higher than 140°C for 5 seconds under heating operation (1)


(1) For RASC-3HVRNE the temperature is 115 °C and 125 °C in cooling and heating mode


HITACHI

Inspire the Next











Thermistor resistance characteristics

Troubleshooting Service Manual	HITAC Inspire the T	
Alarm code	Description	
11	Abnormal operation of thermistor for the indoor unit air inlet temperature (air inlet thermistor)	
	flickers and "ALARM" is displayed on the remote control switch. er, the alarm code and the unit code are alternately displayed on the set temperature section.	


- The unit number and the alarm code are displayed on the display of the Outdoor unit PCB.
 - This alarm code is displayed when the thermistor is short-circuited (less than 0.24 kΩ) or cut (greater than 840 kΩ) during the cooling process or the heating process. The system is automatically restarted when the fault is removed.





Phenomenon	Cause	Check item	Action (Turn OFF the main switch)
Foulty or inlat thermister	Fault	Check the resistance	Replace the thermistor if faulty
Faulty air inlet thermistor	Incorrect connection	Check the connection	Repair the wiring and the connections
Faulty	/ РСВ	Replace PCB and check the operation	Replace PCB if faulty

Thermistor resistance (KΩ)



	i	NOTE
		s data is applicable to the following mistors:
-	1. lı	ndoor unit discharge air temperature,
-	2. lı	ndoor unit liquid refrigerant temperature
-	3. lı	ndoor unit air inlet temperature
-		Dutdoor temperature (Outdoor unit inlet air emperature)

- 5. Outdoor unit evaporating temperature
- 6. Indoor unit gas piping

Inspire the Next		
Alarm code		


HITACHI


I

Abnormal operation of the thermistor for the indoor discharge air temperature (air outlet thermistor)

Description

- The RUN LED flickers and "ALARM" is displayed on the remote control switch.
- The unit number, the alarm code and the unit code are alternately displayed on the set temperature section. The unit number and the alarm code are displayed on the display of the Outdoor unit PCB.
 - This alarm code is displayed when the thermistor is short-circuited (less than 0.24 kΩ) or cut (greater than 840 kΩ) during the cooling process or the heating process. The system is automatically restarted when the fault is removed.






Phenomenon	Cause	Check item	Action (Turn OFF the main switch)
	Fault	Check the resistance	Replace the thermistor if faulty
Faulty air outlet thermistor	Incorrect connection	Check the connection	Repair the wiring and connections
Faulty	/ PCB	Replace PCB and check the operation	Replace PCB if faulty

Troubleshooting Service Manual	HITACHI Inspire the Nex
Alarm code	Description
E	Abnormal operation of the thermistor for the indoor unit heat exchanger liquid pipe temperature (freeze protection thermistor)

• The RUN LED flickers and "ALARM" is displayed on the remote control switch.

• The unit number, the alarm code and the unit code are alternately displayed on the set temperature section. The unit number and the alarm code are displayed on the display of the Outdoor unit PCB.


 This alarm code is displayed when the thermistor is short-circuited (less than 0.24 kΩ) or cut (greater than 840 kΩ) during the cooling process or the heating process. The system is automatically restarted when the fault is removed.



Phenomenon	Cause	Check item	Action (Turn OFF the main switch)
Faulty freeze protection	Fault	Check the resistance	Replace the thermistor if faulty
thermistor	Incorrect connection	Check the connection	Repair the wiring and connections
Faulty PCB		Replace PCB and check the operation	Replace PCB if faulty

Alarm code	Description
;;	Abnormal operation of the thermistor for the indoor unit heat exchanger gas pipe temperature (gas piping thermistor)

- The RUN LED flickers and "ALARM" is displayed on the remote control switch.
- The unit number, the alarm code and the unit code are alternately displayed on the set temperature section. The unit number and the alarm code are displayed on the display of the Outdoor unit PCB.
 - This alarm code is displayed when the thermistor is short-circuited (less than 0.24 kΩ) or cut (greater than 840 kΩ) during the cooling process or the heating process. The system is automatically restarted when the fault is removed.




Phenomenon	Cause	Check item	Action (Turn OFF the main switch)
	Fault	Check the resistance	Replace the thermistor if faulty
Faulty gas piping thermistor	Incorrect connection	Check the connection	Repair the wiring and connections
Faulty PCB		Replace PCB and check the operation	Replace PCB if faulty

7

Alarm code	Description		
17	Activation of the protection device for the indoor fan motor (except RCI, RCIM and RPK)		
The unit number The unit number	ckers and "ALARM" is displayed on the remote control switch. the alarm code and the unit code are alternately displayed on the set temperatur and the alarm code are displayed on the display of the Outdoor unit PCB. de is displayed when the temperature of the internal thermostat for the indoor fan		
Does the indoor fan run? Yes	No Is the continuity present at the internal thermostat of the indoor fan motor? Yes Is the connection bad at the connector? Yes	Replace the motor	
	Is the coil resistance of the fan motor normal?	Replace the motor	
	Yes Check the indoor temperature. If the indoor temperature is unusual, take a suitable action to reduce the indoor temperature		

Phenomenon	Cause		Check item	Action (Turn OFF the main switch)
	Faulty indoor u	Faulty indoor unit fan motor		Replace the motor if faulty
Activation of the internal thermostat for the indoor unit fan motor		Fault	Check the continuity after the fan motor temperature decreases to room temp	Replace the fan motor if there is no continuity
	Faulty internal thermostat	Insufficient contacting	Measure the resistance using the tester	Correct looseness. Replace the connectors
		Incorrect connection	Check the connections	Repair the connections



HITACHI


Troubleshooting
Service Manual

Alarm code	Description
17	Activation of the protection device for the indoor fan motor (RPK)

• The RUN LED flickers and "ALARM" is displayed on the remote control switch.


• The unit number, the alarm code and the unit code are alternately displayed on the set temperature section. The unit number and the alarm code are displayed on the display of the outdoor unit PCB1.

- This alarm code is displayed when the following conditions occurs three times in 30 minutes. Indoor fan rotates less than 70rpm for 5 seconds during operation.
- Set air flow volume "Hi" before starting this check.



Alarm code	Description
	Abnormality of thermistor for discharge gas temperature (compressor thermistor)

- The RUN LED flickers and "ALARM" is displayed on the remote control switch.
- The unit number, the alarm code and the unit code are alternately displayed on the set temperature section. The unit number and the alarm code are displayed on the display of the Outdoor unit PCB.
 - This alarm code is indicated when the thermistor is short-circuited (less than 1 k Ω) or cut (greater than 6 M Ω) during the cooling or heating operation.




Thermistor resistance characteristics


Phenomenon	Cause	Check item	Action (Turn OFF main switch)
Faulty top of compressor	Fault	Check resistance	Replace thermistor if faulty
thermistor	Incorrect connection	Check wiring to PCB1	Repair wiring and connections
Faulty PCB1		Replace PCB1 and check operation	Replace PCB1 if faulty

Alarm code	Description
Abnormal operation of the inlet air temperature thermistor (RASC unit outdoor ambient thermistor)	
	ckers and "ALARM" is displayed on the remote control switch. the alarm code and the unit code are alternately displayed on the set temperature section.

- The unit number and the alarm code are displayed on the display of the RASC unit PCB.
 - This alarm code is displayed when the thermistor is short-circuited (less than 0.2 kΩ) or cut (greater than 500 kΩ) during the operation. However, this alarm occurs during the test run mode only. In the case that the thermistor is abnormal during the operation, the operation continues based on the assumption that the outdoor temperature is 35 °C (cooling) / 6 °C (heating).




Thermistor characteristics



Phenomenon	Cause	Check item	Action (Turn OFF main switch)
Faulty of the inlet air temperature	Fault	Check resistance	Replace thermistor if faulty
thermistor (RASC unit outdoor ambient thermistor)	Incorrect connection	Check wiring to PCB	Repair wiring and connections
Faulty PCB1		Replace PCB1 and check operation	Replace PCB if faulty

Alarm code	Description
24	Abnormal operation of the thermistor for the evaporating temperature during the heating process (outdoor unit)


- The RUN LED flickers and "ALARM" is displayed on the remote control switch.
- The unit number, the alarm code and the unit code are alternately displayed on the set temperature section. The unit number and the alarm code are displayed on the display of the outdoor unit PCB. (*1)
 - If you find an abnormal operation of the thermistor, check all the thermistors as shown below.
 - The evaporating thermistor during the heating process is attached to the heat exchanger as shown in the figure below. If the thermistor is faulty, such as short-circuit (less than 0,2kΩ) or cut (more than 840kΩ) during eight minutes continuously, this alarm is displayed. The position is indicated below.




RASC-10HRNE

Replace PCB and


check the operation



Faulty PCB



Replace PCB if faulty




0	Thermistor for discharge gas temperature
0	Thermistor for outdoor ambient temperature
8	Thermistor for evaporating temperature

Alarm code	Description		
1 E	Incorrect capacity setting or combined capacity between indoor units and outdoor unit		
The RUN LED flickers and "ALARM" is displayed on the remote control switch.			

• The unit number, the alarm code and the unit code are alternately displayed on the set temperature section. The unit number and the alarm code are displayed on the display of the outdoor unit PCB.

This alarm code is indicated when the total indoor unit capacity is not equal to the combined outdoor unit capacity.
 Outdoor unit capacity setting is not correct.



Phenomenon Cause		Check item	Action (Turn OFF main switch)
Incorrect capacity s	etting of indoor unit	Check combination of indoor units and capacity setting on PCB.	Correctly set dip switch, DSW3.
Incorrect capacity se	etting of outdoor unit	Check capacity setting on outdoor unit PCB.	Correctly set dip switch, DSW3.
Total indoor unit capacity connect permissil	eted to the outdoor unit is beyond ble range	Check outdoor unit model by calculating total indoor units capacity.	Ensure that total indoor unit capacity is from 80% to 120%.

 NOTE

 - In case of H-LINK system, this alarm code is indicated when DSW4, RSW1 (for refrigerant system setting) on the outdoor unit PCB and DSW5, RSW2 (for refrigerant system setting) on the indoor unit PCB are incorrectly set.

 - In this case, set correctly DSW4, RSW1, DSW5 and RSW2 after turning OFF main switch.

- (DSW2 is not equipped with some models.)


	Alarm code	Description	
	35	Incorrect indoor number setting	
•	The unit number, number and the – This alarm co connected to	ckers and "ALARM" is displayed on the remote control switch. , the alarm code and the unit code are alternately displayed on the set temperature section. The alarm code are displayed on the display of the outdoor unit PCB. ode is indicated 3 minutes after power is supplied to the outdoor unit when the indoor unit no. the outdoor unit is duplicated by setting of RSW. ode is indicated when 5 or more indoor units are connected to one outdoor unit.	unit
		NOTE	
	outdoor un	H-LINK system, this alarm code is indicated when DSW4, RSW1 (for refrigerant system setting) on the it PCB and DSW5, RSW2 (for refrigerant system setting) on the indoor unit PCB are incorrectly set.	

- (DSW2 is not equipped with some models.)

Troubleshooting
Service Manual

Alarm code	Description
38	Abnormality of protective circuit for protection (outdoor unit)


- The RUN LED flickers and "ALARM" is displayed on the remote control switch.
- The unit number, the alarm code and the unit code are alternately displayed on the set temperature section. The unit number and the alarm code are displayed on the display of the outdoor unit PCB.
- This alarm code is indicated when AC 220V or 240V is supplied to voltage PCN9#1 and #3 on PCB1 in the outdoor unit during CMC is opened.



Phenomenon Cause		Check item	Action (Turn OFF main switch)
Faulty	PCB1	Check PCB1 by seft-checking	Replace PCB1

Alarm code	Description
41	Cooling overload (high pressure switch will be activated)

- The RUN LED flickers and "ALARM" is displayed on the remote control switch.
- The unit number, the alarm code and the unit code are alternately displayed on the set temperature section. The unit number and the alarm code are displayed on the display of the outdoor unit PCB.
 - This alarm code is indicated when the protection device is activated at following condition. Evaporation temperature of outdoor unit is more than 55 degree and top of compressor temperature is more than 95 degree.



Ambient temperature (°C)

7

Phenomenon	Cause		Check item	Action (Turn OFF main switch)
	Insufficient air flow to heat exchanger of outdoor unit		Clogging of heat exchanger?	Remover clogging
			Check for dust on air filter	Remove dust
			Check the service space	Secure service space
			Check fan speed: Outdoor fan: cooling Indoor fan: heating	Replace fan motor if faulty
	Excessively high temp. air to outdoor unit heat exchanger		Check for hot air near the ceiling.	Make good circulation.
			Check for short circuited air.	Remove short-circuited air.
			Check for other Rasc Unit.	Remove Rasc Unit.
	Faulty high pressure switch	Faulty pressure switch	Measure discharge pressure. Check continuity after decreasing of pressure.	Replace it if faulty.
Activation of high pressure switch due to excessively high discharge pressure during cooling operation		Insufficient contacting	Measure resistance by tester.	Repair looseness. Replace connector.
		Incorrect connection	Check connections.	Repair connections.
	Overcharged refrigerant		Check cycle operating temp.	Charge refrigerant correctly.
	Mixture of non-condensable gas in refrigerant cycle		Check ambient temp. and pressure.	Recharge refrigerant after vacuum pumping.
	Clogging of discharge piping		Check for clogging.	Remove clogging.
	Faulty or malfunction of expansion valve		Check for clogging.	Remove clogging.
			Check connecting wiring and connectors.	Replace connector.
			Check operating sound from coil.	Replace coil.
			Check discharge gas thermistor.	Replace thermistor.
			Check attaching state of discharge gas thermistor.	Reattach thermistor.
	Liquid line stop valve or gas line stop valve are not in operation		Check stop valves.	Fully open stop valve.
	Locking up outdoor unit expansion valve closure		Check expansion valve actuation.	Replace outdoor unit expansion valve.


Ì

NOTE

- This alarm code is indicated when the outdoor unit protective device is activated by high discharge pressure during cooling operation. Accordingly, when this alarm code is indicated, there is high possibility of high pressure switch actuation and the above troubleshooting actions are based on such cases.

Heating overload (high pressure switch will be activate)	

- The RUN LED flickers and "ALARM" is displayed on the remote control switch.
- The unit number, the alarm code and the unit code are alternately displayed on the set temperature section. The unit number and the alarm code are displayed on the display of the outdoor unit PCB.
 - This alarm code is indicated when the protection device is activated at following condition. Liquid refrigerant piping temperature of indoor unit is more than 55 °C and top of compressor temperature is more than 95 °C.



Phenomenon	Cause	Check item	Action (Turn OFF main switch)
		Clogging of Heat exchanger	
Activation of high pressure switch due to excessively high discharge pressure during heating operation	Insufficient air flow to heat exchanger of indoor unit	Check for dust on air filter	Remove it
		Check for any obstacle at inlet or outlet of heat exchanger.	
		Check the service space.	Secure service space.
		Check fan speed. (Outdoor fan: cooling Indoor fan: heating)	Replace fan motor if faulty.

Phenomenon	Cause		Check item	Action (Turn OFF main switch)
	Excessively high temp. air to indoor unit heat exchanger		Calculate heat load.	Reduce heat load or use a bigger unit.
			Check for hot air near the ceiling.	Make good circulation.
			Check for short circuited air.	Remove short-circuited air.
			Check for other RASC Unit.	Remove RASC Unit.
		Faulty pressure switch	Measure discharge pressure. Check continuity after decreasing of pressure.	Replace it if faulty.
	Faulty high pressure switch	Insufficient contacting	Measure resistance by tester.	Repair looseness. Replace connector.
		Incorrect connection	Check connections.	Repair connections.
Activation of high pressure switch due to excessively high discharge pressure during heating operation	Faulty of outdoor fan control		Check decreasing air flow volume at pressure switch for control activative.	Replace thermistor for evaporating temp. if faulty.
	Faulty of pressure switch for control		Check activated pressure and connecting wire.	Replace it if pressure switch for control is faulty.
	Overcharged refrigerant		Check cycle operating temp.	Charge refrigerant correctly.
	Mixture of non-condensable gas in refrigerant cycle		Check ambient temp. and pressure.	Recharge refrigerant after vacuum pumping.
	Clogging of discharge piping		Check for clogging.	Remove clogging.
	Faulty or malfunction of expansion valve		Check for clogging.	Remove clogging.
			Check connecting wiring and connectors.	Replace connector.
			Check operating sound from coil.	Replace coil.
			Check discharge gas thermistor.	Replace thermistor.
			Check attaching state of discharge gas thermistor.	Reattach thermistor.
	Liquid line stop valve or gas line stop valve are not in operation		Check stop valves.	Fully open stop valve.


i

NOTE


This alarm code is indicated when the outdoor unit protective device is activated by high discharge pressure during heating operation. Accordingly, when this alarm code is indicated, there is high possibility of high pressure switch actuation and the above troubleshooting actions are based on such cases.


Alarm code		Description		
1_1 Г	71 1	Activation to protect system from excessively low suction pressure (protection from vacuum operation)		
The RUN	I LED fl	ickers and "ALARM" is displayed on the remote control switch.		
• The unit number, the alarm code and the unit code are alternately displayed on the set temperature section. The unit number and the alarm code are displayed on the display of the outdoor unit PCB.				
		nat the evaporating temperature (Cooling: liquid refrigerant piping temp. of indoor unit, heating:		

evaporating temp. of outdoor unit) is lower than -37 °C ($250 \sim 350 \text{ k}\Omega$) and the thermistor on top of compressor is higher than 90 °C. for 3 minutes, retry operation is performed 3 minutes after compressor stoppage. However, when the state occurs more than 3 times including 3 in one hour, this alarm code is indicated.




Phenomenon	Cause	Check item	Action (Turn OFF main switch)
 Faulty freeze protection Thermistor of indoor unit Evaporating thermistor of 	Fault	Check resistance.	Replace thermistor if faulty.
outdoor unit	Incorrect connection	Check wiring to PCB.	Repair wiring and connections.
Faulty (Outdoor unit		Replace PCB and check operation.	Replace PCB if faulty.
	Liquid line stop valve is not open before operation	Check stop valve.	Fully open stop valve.
		Check for clogging.	Remove clogging.
	Faulty or malfunction of expansion valve	Check connecting wiring and connectors.	Replace connector.
Excessively low suction pressure (in vacuum)		Check operating sound from coil.	Replace coil.
		Check discharge gas thermistor.	Replace thermistor.
		Check attaching state of discharge gas thermistor.	Reattach thermistor.
	Refrigerant leakage	Check each temp. and pressure.	Charge refrigerant after vacuum pumping.
	Kongerant leakage	Check gas leakage part.	Correctly charge refrigerant after repairing gas leakage.
Faulty RASC fan at heating operation	Faulty RASC fan motor	Measure coil resistance and insulating resistance.	Replace RASC fan motor if faulty.





*1): P7 is shown at 7-segment on the Outdoor unit PCB.

*2): Perform the high voltage discharge work by referring to the item 7.3.4 before checking and replacing the inverter parts.



*1) Perform the high voltage discharge work by referring to the item 7.3.4 before checking and replacing the inverter components.

- *2) Regarding replacing or checking method for inverter components, refer to the item 7.3.4.
- *3) Turn ON the No.1 switch of the dip switch DSW1 on PCB2 when restarting with disconnecting the terminals of the compressor. After troubleshooting, turn OFF the No.1 switch of the dip switch DSW1 on PCB2.
- *4) Use the silicon grease provided as accessory (Service parts No. P22760).

Alarm code	Description				
54	Temperature increase in the inverter fin				
 The unit number, number and the a If the alarm continue is display Conditions: When the term 	the alarm code and the unit alarm code are displayed on ode "51" or "54" occurs three yed. The retry operation is p	ayed on the remote control so t code are alternately display the display of the outdoor un e times within 30 minutes, the erformed twice. or inverter fin excess 100 °C ted and the operation is stop	ed on the set ten hit PCB. e alarm code whi (RASC-10HRNE	ch occurred for the third	
	retry is performed.		ped. In the case		
Restart the op Does it trip		Is thermistor short circuit or faulty?	No	Replace the dipIPM, ISPM, IPM. *1	
	No	Yes		Replace the thermistor	
Is the heat excha outdoor unit c	Anger of the logged?			Remove the clogging	
	No			Faulty PCB2 or thermistor. Replace it.	

1*): Perform the high voltage discharge work by referring to the item 7.3.4 before checking and replacing the inverter components.

Alarm code	Description
55	IPM or PCB2 abnormality
The RUN LED flickers and "ALARM" is displayed on the remote control switch	

- The RUN LED flickers and "ALARM" is displayed on the remote control switch.
 The unit number, the alarm code and the unit code are alternately displayed on the set temperature section. The unit
- number and the alarm code are displayed on the display of the outdoor unit PCB.
 - In case that the abnormality of alarm code 55 occurs four times within 30 minutes, the alarm code of abnormality
 occurred for the fourth time is indicated. Retry operation is performed up to third time of abnormality occurrence.

Conditions:

When the transmitting abnormality occurs between dipIPM (or IPM) and PCB2), this alarm is indicated and the operation is stopped.

Troubleshooting: Replace the PCB2.

Alarm code	Description
EE	Compressor protection

• This alarm code is displayed when one of the following alarms occurs three times within six hours. If the outdoor unit operates continuously without removing the cause of the alarm, the compressor may be seriously damaged.


Alarm code	Content of abnormality
02	Tripping of protection device in outdoor unit
07	Decrease in discharge gas superheat
08	Increase in discharge gas temperature
41	Cooling overload
42	Heating overload
47	Low pressure decrease protection activating


You can check these alarms using the check mode 1. Follow the action that is indicated in each alarm chart. You can clear these alarms only by turning OFF the main switch to the system. **However, you must pay careful attention before starting, because there is a possibility of causing serious damages to the compressors.**

7.2.3. Troubleshooting in check mode

Use the "OK" switch of the remote control in the following cases:

- 1. When the RUN LED is flickering.
- 2. To trace back the cause of the malfunction after restarting from the stoppage while the RUN LED is flickering.
- 3. To check during the normal operation or during the stoppage.
- 4. To monitor the inlet air temperature and the discharge air temperature.





Although the wireless controller is used for the wall type indoor unit with the built-in receiver part, you can check the alarm code by connecting the PC-P2HTE.





Image: Note

- The unit does not operate by pressing the operation switch.
- The above function is available only when the alarm occurs.
- The PCB check using the remote control switch is not available.
- The indication is the data when you are connecting PC-P2HTE. The indication is not the data before the alarm occurs.

Contents of the check mode 1

The next indication is shown if you press the part "
]"
"
of the TEMP switch.


If you press the part " \bigtriangledown " of the TEMP switch, the previous indication is shown.



	ation of micro-comp	iter inp		μιραι]		Y52C		relay	Part name
~	Micro-computer input/	F					Y2	21	Y21	Relay for 4-way valve
2	output in indoor unit		i	ר'					Y52C	Relay for compressor
			`					FAN1	Y20A1	Relay for selonoid valve (SVA)
	·							FANT	FAN1	Relay for RASC fan.
									YCH	Relay for cranckcase heater
2	Micro-computer input/		1							
13	output in outdoor unit		[]	-			Y20A1	YCH	63H2	Relay for PSH
dica	ation of unit stoppag	e cause	•			00 0 (Operation OFF, pov Thermo - OFF (note			
						02 03	Alarm (note 2) Freeze protection, o	overheating prot	tection	
14	Cause of stoppage		!			05	Instantaneous pow			eset (note 3)
	11 0	/	•		٩	05	Instantaneous pow			. ,
	I I					00				loor air temperature (<= -5°C
							Stoppage of heating indoor air temperature temperature (<= -20	g operation due ure, stoppage o 0°C)	to high out	idoor air temperature (2 - 3 c idoor air temperature, and hig peration due to low outdoor a
						10	Demand, enforced			
						13	Retry due to high p			
						15		mai high temper	ature of dis	scharge gas, excessive low
						15	suction pressure Retry due to decrea	se of discharge		heat
						10	Retry due to inverte		, gas super	nout
						18	Retry due to voltage			
						19	Expansion valve op		rotection	
						20	Operation mode ch			ote 5)
						21	Enforced thermo-of	-		
						22	Hot start after 4 hou			
						24	Cold draft protectio			
						i			NOTE	
						- Ev	hermo-OFF: A con comp ven if stoppage is the transmission b	ressor to open caused by "Al petween the in	an indoor rate. Iarm", "02 nverter pri	unit is not requesting the " is not always displayed. nted circuit board and the d during 30 seconds, the
ono	Abnormal operation	rrence E	cou 1	nter	1	sti - If	oppage cause is c the transmission b	11-05 and the between the in	alarm coo ndoor unit	de "04" may be displayed and the outdoor unit is no ' Units are stopped.
	occurrence counter				•	<i>m</i>	ay be displayed.			nd the alarm code "03" liference between indoor
16	Instantaneous power failure occurrence counter in indoor unit	Ez	1		7		table up to 99.			
	Transmission error						99 times, "99" is a	always displav	/ed.	
	LICODEMICCION OFFOR	1			_ _			,,,		
			1						NOTE	
17	occurrence counter between remote control switch and indoor unit	E	}			- If	a transmission eri e occurrence coui		NOTE	ninutes, one is added to
	occurrence counter between remote control switch and	E				- If th - Th ex	e occurrence cou he memorized dat	nter. a can be canc 1 7.3.1 "self-ch	for three r	he method which is
17 18 dica	occurrence counter between remote control switch and indoor unit Abnormal operation occurrence counter on	E	{			- If th - TH ex re	e occurrence cou he memorized dat plained in section	nter. a can be canc 1 7.3.1 "self-ch	for three r	

Service Manual


Compressor pressure/frequency indication



control switch. This does not have any specific meaning

The total frequency is displayed when several compressors are

Indoor unit capacity indication



Expansion opening indication

28	Indoor unit expansion valve opening (%)		
----	---	--	--

Capacity	code of indoor unit	t	


This is an indication for frequency inverter

Indication code	Equivalent capacity (HP)
06	0.8
08	1.0
10	1.3
13	1.5
14	1.8
16	2.0
18	2.3
20	2.5
22	2.8
26	3.0/3.5
32	4.0
40	5.0
48	6.0
64	8.0
80	10.0

" σ " indicates the total number of Indoor Units: $l \sim 4$

J3: 01 ~ 64 (01: when shipment (DSW5+RSW2), decimal indication

J4: 00 ~ 40 (00: when shipment (DSW5+RSW2), indication with 16 numbers



Estimated electric current indication



The total current is displayed when several compressors are running. In case of the inverter compressor, the running current of the primary side of the inverter is displayed.

returns to temperature indication

179

• Contents of the check mode 2


When more than three indoor units are connected to one remote control switch, the latest data of only the first three indoor units that are connected serially are displayed.

If you press the part " \bigcirc " of the TEMP switch, the next display appears. If you press the part " \bigcirc " of the TEMP switch, the previous display appears.

			 Indication of the category code Indication of the temperature, etc
Tem	perature indication		
1	Indoor unit air inlet temp. at thermistor (°C)	E5 1 P	- Corresponds to check mode 1 "b₽"
2	Indoor unit discharge air temp. at thermistor (°C)	92 50	- Corresponds to check mode 1 "占∃"
3	Indoor unit heat exchanger liquid pipe temp. (freeze protection) (°C)	93 25	- Corresponds to check mode 1 "占 4"
4	Outdoor temperature (°C)	94 12	 Corresponds to check mode 1 "bb"
5	Indoor unit heat exchanger gas pipe temp. (°C)	95 25	- Corresponds to check mode 1 "占ワ"
6	Evaporating temp. at heating (°C)	95 <u>0</u> 3	 Corresponds to check mode 1 "b8"
7	Control information	97	 Corresponds to check mode 1 "b^q"
8	Discharge gas temp. at the top of comp. chamber (°C)	98 45	 Corresponds to check mode 1 "b^R"

Com	pressor pressure/fre	quency indication	———— Corresponds to check mode 1 "H I"
9	Discharge pressure (high) (x 0.1 MPa)	99 (8	
			Corresponds to check mode 1 "Hz"
10	Suction pressure (low) (x 0.01 MPa)	98 <u>0</u> 4	
			———— Corresponds to check mode 1 "H∃"
11	Control information	7 6 44	
			Corresponds to check mode 1 "H4"
12	Operating frequency (Hz)	95 44	

Expansion opening indication



← Returns to temperature indication

7.2.4. Troubleshooting using the 7 segment display

• Simple checking by 7-segment display

1	Turn ON all indoor inits connected to the outdoor unit
2	Turn ON the outdoor unit
3	Auto-addressing starts


Outdoor unit, circuit board, PCB1

Checking method by 7-segment display

During auto-addressing, the following items can be checked using the outdoor unit's on-board 7-segment LED display:

- 1. Disconnection of power supply to the indoor unit.
- 2. Reverse connection of the operating line between the outdoor and indoor units.
- 3. Duplication of indoor unit number.

Operating conditions and each part of refrigeration cycle can be checked by 7-segment and push switches (PSW) on the PCB in the outdoor unit. During checking data, do not touch the electric parts except for the indicated switches because 220-240V is applied to them. Pay attention not to contact the tools with electrical parts. If contacted, electrical parts will be damaged



- To start checking, press PSW2 switch for more than three seconds.
- To proceed checking, press the PSW2 switch.
- To back to the previous item, press the PSW3 switch.
- To cancel this checking, press the PSW2 switch for more than 3 seconds.

ltem	Item		Indication data			
item	Check No.	Indic.	Indic.		Contents	
Total capacity of indoor unit connected	01	EP	22	00~96		
Input/output state of outdoor micro-computer	02	5E	ā	Indicates only for the segments corresponding to the equipment in the figure. (See figure above)		
Alarm code for abnormal stoppage of compressor	03	RE	08	Alarm code on compressor		
Inverter order frequency to compressor	04	HI	74	30~115 (Hz) In case that frequency is higher t	than 100Hz, the last two digits flicker	
Indoor order frequency to compressor	05	HZ	74	30~115 (Hz) In case that frequency is higher t	than 100Hz, last two digits flicker	
Air flow ratio	06	Fo	80	00~100 (%) In case that air flow ratio is 100%	6, "00" flashes	
Outdoor unit expansion valve opening	07	Ea	30	00~100 (%) In case that expansion valve ope	ening is 100%, "00" flashes	
Temperature at the top of compressor	08	Гd	02	00~142 (°C) In case that temperature is highe	er than 100°C, the last two digits flash	
Evaporating temperature at heating	09	ΓЕ	-12	-19~80°C		
Ambient air temperature	10	Γa		-19~80°C		
Cause of stoppage at inverter	11	ெ	1	(See table at the next page)		
Control information	12	ΓF	20	Internal information of outdoor ur	nit PCB	
Control information	13	R (12	Internal information of outdoor ur	nit PCB	
Inverter secondary current	14	RZ	20	00~199 (A)		
Outdoor unit address	15	лЯ	00	00~15		
Indoor unit expansion valve opening	16	ER	20	00~100 (%) In case that opening is 100%. "00" flashes	In case of twin/triple/quad-type unit, the information of 2nd to the 4th indoor units is indicated repeatedly.	
Liquid pipe temperature of indoor unit (freeze protection)	17	LĦ	85	-19~127 (°C)	The right character of the indication represents the indoor unit setting No.	
Indoor unit intake air temperature	18	R,	28	-19~127 (°C)	Single: A Twin: A, b	
Indoor unit discharge air temperature	19	ρĦ	20	Image: Triple: A, b, c Description Descrinteracingreacing and		
Cause of indoor unit stoppage	20	dЯ	85	(See table at the next page)		

Cause of inverter stoppage (11)

Indication	Contents
1	IPM, ISPM, dipIPM error
2	Instantaneous over current
Ξ	Inverter fin thermistor protection activation
4	Electronic thermal activation
5	Inverter voltage decrease
5	Over voltage
7	Abnormal transmission
8	Abnormal current detection
9	Instantaneous power failure detection
Reset of micro-computer for inverter	
Earth fault detection from compressor	
(3) Open phase detection	
14	Inverter malfunction
15	Inverter malfunction
15	Inverter malfunction
17	Transmission error
18	Abnormal current detection
19	Abnormal protective device

NOTE To finish checking: press the PSW2 switch for more than 3 seconds.

Cause of indoor unit stoppage (20)

Indication	Contents
00	Operation OFF, Power OFF
D (Thermo-OFF
92	Alarm
ED	Freeze protection overheating protection
<i>0</i> 5	Instantaneous power failure at outdoor unit
05	Instantaneous power failure at indoor unit
רים	Stoppage of cooling operation due to low outdoor air temperature Stoppage of heating operation due to high outdoor air temperature
10	Demand thermo OFF
EI	Retry for Pd increase prevention
15	Vacuum/discharge gas temperature increase retry
15	Retry due to discharge gas SUPERHEAT decrease
ריו	IPM error retry, instantaneous over current of inverter retry, electronic thermal activation of inverter retry, abnormal current sensor of inverter retry
18	Retry due to inverter voltage decrease Retry due to Inverter Overvoltage
19	Other retry
20	Different operation mode between indoor/ outdoor units (Only for individual twin/triple/quad types)
21	Forced thermo-OFF (Only for simultaneous twin/triple/quad types)
22	Forced thermo-OFF (During compressor pre-heating)
군식	Thermo-OFF during energy saving operation mode

Cancelation of Forced Thermo OFF

Turn ON the power source and wait for more than 30 seconds. Then press PSW1 and PSW3 simultaneously for more than 3 seconds.

Forced thermo-OFF (indoor unit error code 22) will be cancelled.

However, this function may damage the compressor, use only on inevitable occasion.

In case of using the remote control switch (PC-P1HE), the cancellation is also available with it.

When "operation is limited" indication flashes on the remote control LCD, press FAN SPEED and LOUVER switches simultaneously for more than 3 seconds.

"Operation is limited" indication is disappeared and operation is available.

7.2.5. Cause of inverter stoppage

		Course of stormore for	Remark		
Code	Cause	Cause of stoppage for corresponding unit	Indication during retry	Alarm code	
1	Automatic stoppage of transistor module (IPM, ISPM, dipIPM Error) (Over current, decrease voltage, short circuit protection)	17	P7	53	
2	Instantaneous over current	רין	P7	48	
Ξ	Abnormal inverter fin thermistor	ריו	P7	54	
Ч	Electronic thermal activation	ריו	P7	48	
5	Inverter voltage decrease	(8	PB	06	
5	Over voltage	(8	P8	05	
7	Abnormal inverter transmission	(8	-	-	
8	Abnormal current detection	17	P7	51	
9	Instantaneous power failure detection	18	-	-	
11	Reset of micro-computer for inverter	(8	-	-	
12	Earth fault detection from compressor (Only starting)	ויז	P7	53	
EI	Abnormal power source phase (Open phase)	(8	-	-	
15	Inverter PCB abnormality	18	P8	55	
ריו	Abnormal transmission	18	P8	55	
18	Abnormal current detection	-	-	88	
19	Abnormal protective device	-	-	38	
20 ~ 63	Other factors	18	-	-	

Protection control code on 7-segment display

- 1. Protection control code is displayed on 7-segment when a protection control is activated.
- 2. Protection control code is displayed while function is working, and goes out when released.
- 3. When several protection control are activated, code number with higher priority will be indicated (see below for the priority order).
 - a) Higher priority is given to protection control related to frequency control than the other.
 - <Priority order>
 - * High-pressure increase protection
 - * Over current protection
 - * Cold draft protection
 - * Low-pressure ratio control at cooling operation
 - b) In relation to retry control, the latest retrial will be indicated unless a protection control related to frequency control is indicated.

Co	de	Protection control	
P	Π	Low-pressure ratio control at cooling operation	
P	1	High-pressure ratio control at heating operation	
P	2	High-pressure increase protection	
P	Ξ	Over current protection	
P	Ч	IPM fin temperature increase protection	
P	5	Discharge gas temperature increase protection	

Code		Protection control	
P 5 Frost formation protection			
P	P P Unbalance power source detecting		
P	R	Current demand control	
P	Ь	Low-pressure decrease protection	
P	Ľ	Cold draft protection	

- Retry indication continues for 30 minutes unless a protection control is indicated.
- Retry indication disappears if the stop signal comes from all rooms.

Code		Protection control	
P	7	Inverter retry	
P	8		



NOTE

The protection control code being indicated on 7-segment display is changed to an alarm code when the abnormal operation occurs. Also, the same alarm code is indicated on the remote control switch.

Activating condition of protection control code

For following the conditions as the temperature change, etc., the control of frequency, etc. is performed to prevent the abnormal conditions by the protection control. The activating conditions of protection control are shown in the table below.

Code	Protection control	Activating condition	Remarks
PO	Low-pressure ratio control at cooling operation	Compression ratio ε < 2.2 => frequency increase	ε = (Pd+0.1)/(Ps+0.1)
P (High-pressure ratio control at heating operation	Compression ratio ε > 7.5 => frequency decrease	ε = (Pd+0.1)/(Ps+0.1)
P2	High-pressure increase protection	High pressure switch for control is activated => frequency decrease	
PB	Over current protection	Inverter output current > (*1)A => frequency decrease	
РЧ	dipIPM, ISPM or IPM temperature increase protection	Inverter fin temperature RASC-(3/5)HVRNE > 80 °C RASC-10HRNE > 100 °C => Frequency decrease	
PS	Discharge gas temperature increase protection	Temperature at the top of compressor is high => frequency decrease Temperature at the top of compressor > 107oC => indicate P5	
P6	Frost formation protection	TL ≤ 2°C Over 3 minutes => Frequency decrease	TL: liquid piping, temperature of indoor unit
Pq	Unbalance power source detecting	Inverter output current > 13A (380A) => frequency decrease	
PR	Current demand control	Inverter output current > (*2)A => frequency decrease	In case of demand control setting
Pb	Low-pressure decrease protection	Low pressure switch for control is activated. => frequency decrease	
PE	Cold draft protection	TO \leq 10°C and $\varepsilon \geq$ 2.6 => frequency decrease	ε = (Pd+0.1)/(Ps+0.1) TO: outlet temperature of indoor unit
P7	Inverter retry	Automatic stoppage of transistor module, activation of electronic thermal or abnormal current sensor	When activating 3 times in 30 minutes, "48", "51", "53" or "54" alarm is indicated.
PB	Inverter retry	Insufficient/excessive voltage at inverter Circuit or PCB connector part	When activating 3 times in 30 minutes, "06" or "55" alarm is indicated.

i

- NOTE
- During protection control (except during alarm stoppage), the protection control code is indicated.
- The protection control code is indicated during protection control and turns off when canceling the protection control.
- After retry control, the condition of monitoring is continued for 30 minutes.
- The maximum value (*1) and (*2) are as follows:

- (*1)

Main power	220-2	40V	380-415V	
HP	3	5	10	
Current (A)	16.0	24.0	20.0	


- (*2)


	HP	220 – 240V	220 –	240V
	Demand setting	10	3	5
Current (A)	100%	11.0	13	17.0
	75%	8.0	10	13.0
	50%	5.0	6.5	8.5

7.3. Procedure for checking each main part

7.3.1. Self-checking procedure of PCB using the remote control switch

Use the following troubleshooting procedure for testing the PCB in the indoor unit and the outdoor unit:





Indi- cation	Contents	
00	Normal	
Abnorm	ality (open-circuit, short-circuit, etc.) in circuit for:	
	Air inlet temp. thermistor	
02	Discharge air. temp. thermistor	
ΠЭ	Liquid pipe temp. thermistor	
ДЧ	Remote thermistor abnormality	_ m
05	Gas pipe temp. thermistor	Indoor unit PCB
05	Remote sensor	
80	Transmission of central station	Inde
0A	EEPROM	
06	Zero cross input failure	
EE	Transmission of indoor units during this checking operation	
רם	Transmission of outdoor unit	
FЧ	Internal thermostat fan input failure	
F5	PSW input failure	
F5	PSH protection signal detection circuit	1
F٦	Phase detection	t PCE
F8	Transmission of inverter	or uni
FR	High-pressure sensor	Outdoor unit PCB
FЬ	Comp. discharge gas temp. thermistor	
FE	Low-pressure sensor	
- /	Heat exchanger evaporation temp. thermistor	1
Fd	riedt exchanger evaporation temp. thermistor	


SMGB0043 rev.1 - 04/2010

HITACHI Inspire the Next

If you are using a wireless remote control switch with the built-in receiver part of the wall-type indoor unit and you need to perform the above checking, perform the following procedure:

- 1. Turn OFF the power supply.
- 2. Disconnect the connector (CN25) on PWB(M).
- 3. Connect the PC-ART.
- 4. Turn ON the power supply.


After finishing the checking, turn OFF the power supply again and reconnect the connectors according to the previous situation before the checking.





7.3.2. Self-checking procedure of the Remote Control Switch

Cases where the CHECK switch is used:

- 1. If the remote control switch displays a malfunction.
- 2. For the regular maintenance check.







7.3.3. Checking procedure of other main parts

• RASC-(3/5)HVRNE. Procedure for checking the DIP-IPM.

High voltage discharge is an imperative work for replacing parts.

		WARNING
 Electrical hazard. Can cause serious injuries. Perform t high voltage discharge procedure as described. 		,

- Turn OFF the main switches and wait for three minutes. Make sure that no high voltage exists. If LED201 is ON after start-up and LED201 is OFF after turning OFF power source, the voltage will decrease lower than DC50V.
- 2. Connect connecting wires to an electrical soldering iron
- Connect the wires to terminals, P and N on DIP-IPM.
 => Discharging is started, resulting in hot soldering iron. Pay attention not to short-circuit between terminal P(+) and N(-)
- 4. Wait for 2 or 3 minutes and measure the voltage once again. Check to ensure that no voltage is charged.
- Inverter module checking procedure

Internal circuit of rectified part of DIP-IPM


Non-faulty if [1] – [8] are checked and satisfied. (Measure with 1 k Ω range of a tester.)


i	NOTE
- DO NO	DT use a digital tester.


- Touch [+] of the tester to DIP-IPM 52C terminal, and [-] to DIP-IPM R, S terminals to measure the resistance. Normal if all three terminals have 1 kΩ or greater.
- 2. Contrary to [1], touch [-] of the tester to DIP-IPM 52C terminal, and [+] to DIP-IPM R, S terminals to measure the resistance.

Normal if all three terminals have 100 $k\Omega$ or greater.

- Touch [-] of the tester to [-] of DIP-IPM DMI (soldered part), and [+] of the tester to DIP-IPM R, S terminals to measure the resistance.
 Normal if all three terminals have 1 kΩ or greater
- 4. Contrary to [3], touch [+] of the tester to [-] of DIP-IPM DMI, and [-] of the tester to DIP-IPM R, S terminals to measure the resistance. Normal if all three terminals have 100 k Ω or greater.







- Touch [+] of the tester to [P] of DIP-IPM (soldered part), and [-] to DIP-IPM U, V, W terminals to measure the resistance. Normal if all three terminals have 1 kΩ or greater.
- 6. Contrary to [5], touch [-] of the tester to [P] of DIP-IPM (soldered part), and [+] to DIP-IPM U, V, W terminals to measure the resistance. Normal if all three terminals have 30 k Ω or greater. (Resistance gradually increases during measurement.)
- Touch [-] of the tester to [N] of ISPM (soldered part), and [+] to ISPM U, V, W terminals to measure the resistance.

Normal if all three terminals have 1 $k\Omega$ or greater.

 Contrary to [7], touch [+] of the tester to [N] ofDIP-IPM (soldered part), and [-] to DIP-IPM U, V, W terminals to measure the resistance.

Normal if all three terminals have 30 k Ω or greater. (Resistance gradually increases during measurement.)

Internal circuit of ACT part of inverter module

Non-faulty if [9] – [13] are checked and satisfied.

(Measure with 1 k Ω range of a tester.)

i	NOTE
- DO NO	DT use a digital tester

- 9. Check items [1] [8].
- 10. Touch [+] of the tester to DIP-IPM DCL2 terminal, and [-] to [P] of ISPM/DIP-IPM (soldered part) to measure the resistance.


Normal if all three terminals have 100 $k\Omega$ or greater


- 11. Contrary to [10], touch [-] of the tester to DIP-IPM DCL2 terminal, and [+] to [P] of DIP-IPM (soldered part) to measure the resistance. Normal if all three terminals have 1 k Ω or greater.
- 12. Touch [+] of the tester to DIP-IPM DCL2 terminal, and [-] to [N] of DIP-IPM (soldered part) to measure the resistance.


Normal if all three terminals have 100 k Ω or greater.


 Contrary to [12], touch [-] of the tester to DIP-IPM DCL2 terminal, and [+] to [N] of DIP-IPM (soldered part) to measure the resistance. Normal if all three terminals have 10 kΩ or greater.

(Resistance gradually increases during measurement.)










• RASC-10HRNE. Procedure for checking the ISPM.

Remove all the terminals of the ISPM before check. If items (a) to (h) are performed and the results are satisfactory, ISPM is normal. Measure it under 1 k Ω range of a tester.





Procedure using an analog tester:


Checking the diode module:


- 1. By touching the + side of the tester to the P1 terminal of ISPM and the side of the tester to R and S of ISPM, measure the resistance. If all the resistances are more than 1 k Ω , it is normal.
- 2. By touching the side of the tester to the P1 terminal of ISPM and the + side of the tester to R and S of ISPM, measure the resistance. If all the resistances are more than 100 k Ω , it is normal.
- 3. By touching the side of the tester to the N terminal of ISPM and the + side of the tester to R and S of ISPM, measure the resistance. If all the resistances are more than 1 k Ω , it is normal.
- 4. By touching the + side of the tester to the N terminal of ISPM and the side of the tester to R and S of ISPM, measure the resistance. If all the resistances are more than 100 k Ω , it is normal.













Checking the transistor module:


- By touching the + side of the tester to the P terminal of ISPM and the - side of the tester to U, V and W of ISPM, measure the resistance. If all the resistances are more than 1 kΩ, it is normal.
- 2. By touching the side of the tester to the P terminal of ISPM and the + side of the tester to U, V and W of ISPM, measure the resistance. If all the resistances are more than 100 k Ω , it is normal.
- 3. By touching the side of the tester to the N terminal of ISPM and the + side of the tester to U, V and W of ISPM, measure the resistance. If all the resistances are more than 100 k Ω , it is normal.
- By touching the + side of the tester to the N terminal of ISPM and the - side of the tester to U, V and W of ISPM, measure the resistance. If all the resistances are more than 1 kΩ, it is normal.



• Procedure using a digital tester:



Based on the following scheme of ISPM with the contactor, the reactor, capacitors and the resistance, follow the next procedures.




- Checking the diode module
- 1. By placing a jumper from +P1 to -RST or -N to +RST, no continuity and no variation on voltage drop should appear.
- 2. By placing a jumper from P1 to +RST or +N to RST: continuity and variation on voltage drop (nearly 0,365) should be displayed, and the same value in all cases. Not the same value means that the diode module is damaged.

• Checking the transistor module


- 1. By bonding +P to -UVW or -N to +UVW, no continuity and no variation on voltage drop should appear.
- 2. By bonding -P to +UVW or +N to -UVW: continuity and variation on voltage drop (nearly 0,405) should be displayed, and the same value in all cases. Not the same value means that the diode module is damaged.

• Checking capacitors CB1 & CB2.



If it's possible, check the capacitance of each capacitor : 4700μ F ± 20% (between 3760μ F to 5640μ F).

A visual check of the pressure valve of capacitors must be done to ensure it's integrity:



It is not recommended to check tension.

PN = Power source x $\sqrt{2}$, PC=CN is nearly equal to PN/2.

R1 & R2:

1) If the value is different:

- Capacitor could be damaged by overload.
- 04 alarm could be displayed if low supply voltage (CN) for ISPM control part is present.

2) R1 = 9.5Ω & R2 = 14.0 Ω . If these values are different, the capacitors will be not properly charged.

Resistance between P1 & TB3 = $2k\Omega$ (white resistance in the ISPM).

In case that Mg. SW 52C (CMC1) is not ON, the compressor current will travel through these resistances, and they will be broken. Mg. SW 52C (CMC1) should be checked. Check the resistance between the primary and secondary terminal where the contact point is melted for Mg. SW 42C. If there is continuity, the contact is melted and 52C is broken (NG).

Reactor resistance can be messured between TB3 and RB = $0,2\Omega$. Checking this component is not necessary.

NOTE	
affect ISPM directly, so is not necessary to check it when ISPM fail testers are valid to check the values.	ls.

Checking procedure for the electronic expansion valve

	Indoor unit electronic expansion valve	Outdoor unit electronic expansion valve
Locked with fully closed	Check the liquid pipe temperature during the heating process. It is abnormal if the temperature does not increase.	It is abnormal if the liquid pipe pressure does not increase during the cooling process.
Locked with slightly open	It is abnormal under the following condition: the temperature of the freeze protection thermistor becomes lower than the suction air temperature when the unit which is under chechink stops and the other units are under the	It is abnormal if the liquid pipe pressure does not increase and the outlet temperature of the expansion valve decreases after the cooling process starts.
Locked with fully open	cooling process.	It is abnormal under the following conditions: after the heating process for more than 30 minutes, the discharge gas temperature of the compressor is not 10°C higher than the condensing temperature and there is no other faults, such as an excessive charge of refrigerant and others.

Checking procedure for the electrical coil parts

Abbreviations used for colors:

Black	Brown	Red	Yellow	Green	Blue	Grey	Orange	White
BLK	BRN	RED	YEL	GRN	BLU	GRY	ORN	WHT

Fan motor of the outdoor units

Outdoor units	Power consumption	Electrical wiring diagram	Wiring No.	Resistance (Ω)
RASC-3HVRNE	350 W		BLU 0- ❷ BLK BLU 0- ❸ BRN	8,67 ± 7% 10,50 ± 7%
RASC-5HVRNE	950 W		BLU ❶-❷ BLK BLU ❶-❸ BRN	3,47 ± 7% 5,99 ± 7%
RASC-10HRNE	1500 W		BLK Û- ØWHT BLK Û- ØRED	2,26 ± 7% 7,20 ± 7%

• Other parts

Part name	Unit models	Model code	Resistance (Ω)
Selencid value of reach image (2/0)		105-52-52 (50Hz)	1540.00 at 20 °C
Solenoid valve of gas bypass (3/8)		105-52-51 (60Hz)	1250.00 at 20 °C
Solonoid value of gas bypass (1/4)		VPV-MOAJ502B1 (50Hz)	1435.00 at 20°C
Solenoid valve of gas bypass (1/4)	RASC-(3/5)HVRNE	VPV-MOAG579A1 (60Hz)	952.00 at 20°C
Deversing velve		STF-01AJ502D1 (50Hz)	1435.00 at 20ºC
Reversing valve		STF-01AI511A1 (60Hz)	1358.00 at 20ºC
Comprospor motor		E655DHD-65D2 (380-415V)	0.839 at 20°C
Compressor motor		E655DHD-65A2 (220V)	0.199 at 20ºC

Part name	Unit models	Model code	Resistance (Ω)
Selencid value of gas hypass (2/9)		105-52-52 (50Hz)	1540.00 at 20 °C
Solenoid valve of gas bypass (3/8)		105-52-51 (60Hz)	1250.00 at 20 °C
Selencid value of gas hypass (1/4)		VPV-MOAJ502B1 (50Hz)	1435.00 at 20°C
Solenoid valve of gas bypass (1/4)	- RASC-10HRNE	VPV-MOAG579A1 (60Hz)	952.00 at 20°C
Bovereing velve		STF-01AJ502D1 (50Hz)	1435.00 at 20ºC
Reversing valve		STF-01AI511A1 (60Hz)	1358.00 at 20ºC
Comprosper meter		E655DHD-65D2 (380-415V)	0.839 at 20ºC
Compressor motor		E655DHD-65A2 (220V)	0.199 at 20ºC

Checking procedure for the compressor

CHECK LIST ON COMPRESSOR

Client:	Model:	Date:
Serial No.	Production date:	Checker:

No.	Check item	Check method	Result	Remarks
1	Is THM9 correctly connected? THM9: discharge gas thermistor	 Is wire of thermistor correctly connected by viewing? Check to ensure the 7-segment indication of Td when comp. is operating. Td: temperature of THM9 		
2	Is thermistor THM9 disconnected?	 Check to ensure that thermistor on the top of comp. is correctly mounted by viewing? Check to ensure that actually measured temp. is the same as the indication during check mode. 		
3	Is current sensor faulty?	1. Check to ensure that indication A1 and A2 are		
4	Is current sensing part on PCB2 faulty?	 0 during compressor stopping. Check to ensure that indication A1 and A2 are not 0 during compressor running. 		
5	Is the direction of current sensor CTU, CTV) reverse?	Check the direction => by viewing.		
6	Are power source wires, U and V inserted correctly into current sensor? .	Check to ensure that wires are correctly inserted		
7	Is exp. valve (MV1) correctly connected?	Check to ensure that MV1 to CN5A is correctly connected		
8	Is exp. valve coil (MV1) correctly connected?	Check to ensure that each coil is correctly mounted on the valve.		
9	Are the refrigeration cycle and electrical wiring system incorrectly connected?	Check to ensure that refrigerant is flowing into indoor units by operating one refrigerating cycle only from the outdoor unit.		
10	Is opening of exp. valve completely closed (locked)?	 Check the following by the check mode of outdoor units. 1. Liquid pipe temp. (TL) < air intake temp. (Ti) during cooling operation 2. Liquid pipe temp. (TL) > air intake temp. (Ti) during heating operation 		
11	Is opening of exp. valve fully opened locked)?	Check to ensure that liquid pipe temp. is lower than air intake temp. of stopping indoor unit when other indoor units are operating under cooling operation.		
12	Are the contacts for comp. magnetic switch CMC1 faulty?	Check the surface of each contact (L1, L2 and L3) by viewing.		
13	Is there any voltage abnormality among L1-L2, L2-L3 and L3-L1?	Check to ensure that voltage imbalance is smaller than 3%. Please note that power source voltage must be within 380V or 220V+10%.		
14	Is the comp. oil acidified during compressor motor burning?	Check to ensure that the oil color is not black.		

Additional Information for "CHECK LIST ON COMPRESSOR"

Check item	Additional information (mechanism of the compressor failure)
1 & 2	The liquid refrigerant return volume to the compressor is controlled by the discharge gas temperature Td when compressor is operating. If Td thermistor is disconnected, the liquid refrigerant return volume will become small by detecting the temperature even if the actual discharge gas temperature is high. Therefore, this abnormal overheating by detecting the temperature operation will result in insulation failure of the motor winding.
3 & 4	Overcurrent control (operating frequency control) is performed by detecting current by the PCB2. In this case, winding insulation failure will occur, since control is not available in spite of actually high current.
5&6	The current sensor checks phase and adjusts output electrical wave in addition to the above mentioned items. If fault occurs, the output electrical wave becomes unstable giving stress to the motor winding, resulting in winding insulation failure.
7 &8	During a cooling operation, SH is controlled by MV of each indoor units. During a heating operation, Td is controlled by MV1. If expansion valves are incorrectly connected, correct control is not available, resulting in compressor seizure depending on liquid refrigerant returning conditions or motor winding insulation failure depending on overheating conditions.
9	If the refrigeration cycle and electrical system are incorrectly connected, abnormally low suction pressure operation is maintained or abnormally high discharge pressure operation is maintained, resulting in giving stress to the compressor, since their correct control is not available.
10	If the expansion valve and electrical system are incorrectly connected, abnormally low suction pressure operation is maintained or abnormally high discharge pressure operation is maintained, resulting in giving stress to the compressor, since their correct control is not available.
11	The compressor may be locked due to the liquid return operation during the cooling operation.
12	In the case that the contacting resistance becomes big, voltage imbalance among each phase will cause abnormal overcurrent.
13	In this case, overcurrent will occur, efficiency will decrease or the motor winding will be excessively heated.
14	In the case, it will result in motor burning or compressor seizure.


8. Spare Parts

Contents

Spa	are parts	201
RA	ASC-(3/5)HVRNE	
.1.	Cabinet and Fan	
.3.	Electrical equipament	
RA	ASC-10HRNE	
	Cabinet and Fan	
2.2.	Refrigerant Cycle	210
2.3.	Electrical equipment	212
	R/ .1. .2. .3. R/	Refrigerant Cycle Electrical equipament RASC-10HRNE Cabinet and Fan Refrigerant Cycle

8.1. RASC-(3/5)HVRNE


8.1.1. Cabinet and Fan





SMGB0043 rev.1 - 04/2010

		PRODUCT CODE	7E340005	7E340008	
		MODEL NAME	RASC-3HVRNE, 1N~ 230V 50Hz	RASC-5HVRNE, 1N~ 230V 50Hz	
No.	Description	PART No.	Qty	Qty	Remarks
1	Terminal Board	E01818	1	1	
2	Harness PS	E01958	1	1	PSH (Pressure Switch High)
3	Harness PSC	E01959	1	1	PSC (Pressure Switch Control)
4	Fuse	P24776	1		40A
5	Fuse	P24728		1	50A
6	Fuse	E01960	1	1	10A
7	Electrical Wiring Diagram	E01961		1	Assembly (Components + Harness + Steel Plates)
8	Electrical Wiring Diagram	E01962	1		Assembly (Components + Harness + Steel Plates)
9	Capacitor	P20444	1		18µF
10	Capacitor	P22531		1	30µF
11	Thermistor	P22520	1	1	ТА
12	Thermistor	P23507	1	1	ТЕ
13	Thermistor	P22573	1	1	ТD
14	Noise Filter	P26446	1	1	
15	EVO Assy	E01963	1	1	
15-1	Expansion Valve	P24691	1	1	
15-2	EXPV Coil	P24655	1	1	
15-3	Strainer	P25037	2	2	
16	S Valve 5/8	E01964	1	1	Gas Line
17	S Valve 3/8	E01525	1	1	Liquid Line
18	Check JA	P25044	1	1	
19	Strainer	P24398	1	1	
20	V-P-Rubber 1	P17308	4	4	
21	V-P-Rubber 2	P13109	4	4	
22	Protector Net 1	E01965	1	1	Inlet
23	Protector Net 2	E01966	1	1	Outlet
24	Fan Assy. L	E01846	1	1	Fan Casing + Runner (left)
25	Fan Assy. R	E01843	1	1	Fan Casing + Runner (right)
26	Fan Unit	E01967		1	Assembly
27	Fan Unit	E01968	1		Assembly
28	Condenser	E01969		1	Assembly
29	Condenser	E01970	1		Assembly
30	L Tank	E01971	1	1	Assembly
31	Compressor	E01972	1		E305ALD-27A2
32	Compressor	E01973		1	E405ALD-36A2
33	Fan Motor	E01974		1	DC 950W, 4P
34	Fan Motor	E01975	1		DC 350W, 4P
35	MG SW	P24721	1	1	
36	SV Assy	E01976	1	1	
36-1	Body	P25246	1	1	Solenoid Valve
36-2	Coil Harness 20	E02017	1	1	SVA (Solenoid Valve Coil)
37	C-Heater	E01977	2	2	
38	4 Way Valve	P26337	1	1	Reversing Valve

8.1.2. Refrigerant Cycle









Drawing Nº: EPN200809


SMGB0043 rev.1 - 04/2010

No.	Description	Remarks
39	Coil Harness 21	RVR (Reversing Valve Coil)
40	Transformer	TF
41	Reactor	DCL
42	Reactor	DCL
43	Printed Circuit Board	Main (PO052 Assy)
44	Inv. Fin Assy	DIP IPM 25A (PV051 Assy)
45	Inv. Fin Assy	DIP IPM 17A (PV051 Assy)
46	SSR	
47	Radiation Fin	
48	Float Switch	
49	Drain Pan Unit	
50	Side Cover 1 Assy	Assembly
51	Side Cover 3 Assy	Assembly
52	Side Cover 2 Assy	Assembly
53	E-Box Cover Assy	Assembly
54	U Cover 2 Unit	Assembly
55	Fan Cover Unit	Assembly
56	Side Stay Cover Assy	Assembly
57	Valve Cover 1 Assy	Assembly
58	Valve Cover 2 Assy	Assembly
59	Wiring Cover	
60	Corner Cover Assy	Assembly
61	B-Base Assy	Assembly
62	U Cover 1 Assy	Assembly
63	Suction Cover 1 Assy	Assembly
64	D-Cover Assy	Assembly
65	Comp Base	
66	Thermistor	For Inverter
67	Fuse Holder	
68	Handle	
69	Rubber Bushing	
70	Special Nut	
71	Spacer KGPS	
72	Fan Partition Plate	
73	Holder	
74	Capillary Assy	
75	SV Stay	
76	Side Partition Plate	
77	FS Stay	
78	Fuse Holder	
79	Pipe Assy	
80	Casings Stay	


8.1.3. Electrical equipament







𝔍 Surface




Drawing Nº: EPN200809

No.	Description	Remarks
82	Fan Partition Assy	
83	Motor Base	
84	Clamp	
85	Spacer	
86	Push Spacer	
87	Bracket	
88	Acoustical Cover 2	
89	Fan Stay Assy	Assembly
90	L Base	
91	Suspension Base	


8.2. RASC-10HRNE

8.2.1. Cabinet and Fan




No.	Description	Remarks
1	Terminal Board	
2	Cord PS	PSH (Pressure Switch High)
3	Harness PS	PSC (Pressure Switch Control)
4	Fuse	40A
5	Electrical Wiring Diagram	Assembly (Components + Harness + Steel Plates)
6	Capacitor	4700µF
7	Thermistor	ТА
8	Thermistor	TD
9	Thermistor	TE
10	Noise Filter	
11	Noise Filter	
12	Transistor M	For Inverter
13	Diode M	For Inverter
14	Exp. Valve Unit	
14-1	EXPV Coil	
14-2	Exp. Valve	
14-3	Strainer	
14-4	Exp. Valve Cord	
15	S Valve 1/1	Gas Line
16	S Valve 1/2	Liquid Line
17	Check JA	
18	Dist. Strainer	
19	Strainer	
20	Strainer	
21	V-P-Rubber 2	
22	V-P-Rubber 1	
23	Inlet Protector Net	Inlet
24	Outlet Protector Net	Oulet
25	Fan Motor Unit	Assembly
26	Fan Unit Feet	
27	Fan Motor	DC 1500W - 6P (Fan Casing + Runner)
28	Capillary Unit	
29	Flange Assy	
30	Capillary	
31	Condenser Assembly	
32	Check Valve	
33	Oil Separator	
34	L-Tank	Assembly
35	Compressor	E656DHD-65D2
36	MG SW	
37	Resistor	
38	Resistor	
39	Resister	
	1	

8.2.2. Refrigerant Cycle



No.	Description	Remarks
40	SVB Assy.	
40-1	Body 20	Solenoid Valve
40-2	Harness SVA2	SVA2 (Solenoid Valve Coil)
41	SVF Assy.	
41-1	Body	Solenoid Valve
41-2	Harness SVF	SVF (Solenoid Valve Coil)
42	4 Way Valve	Reversing Valve
43	Harness RVR	RVR (Reversing Valve Coil)
44	Reactor	DCL
45	Transformer	TF
46	Circuit Breaker	
47	End Clamp	
48	PV041 Assy	For Inverter
49	Printed Circuit Board	Main (PO052 Assy)
50	RPP Relay	
51	Inverter Fin	For Inverter
52	SSR	
53	Heat Sink	
54	Drain Pan Assembly	Assembly
55	B-Base Assy	Assembly
56	Back Cover Assy.	Assembly
57	E-Box Cover Assy.	Assembly
58	Front Cover Assy.	Assembly
59	L-Back Corner Assy.	Assembly
60	L-Corner Assy.	Assembly
61	L-Cover Assy.	Assembly
62	Inlet Air Frame Assy.	Assembly
63	Outlet Air Frame Assy.	Assembly
64	R-Corner Assy.	Assembly
65	R-Cover Assy.	Assembly
66	Upper Cover Assy.	Assembly
67	RAIL	
68	Spacer	
69	Holder	
70	Clamp	
71	Fuse Holder	
72	Spacer	
73	Push Spacer	
74	Push Spacer	
75	Push Spacer	
76	Band	
77	Rubber Bush	
78	Bush	
79	Collar	
	1	1

8.2.3. Electrical equipment



No.	Description	Remarks
80	Thermistor	For Inverter
81	R-Back Cover Assy.	Assembly
82	Special Nut	
83	Condenser Stay 1	
84	Condenser Stay 2	
85	Handle	
86	S-Valve Protection Stay	
87	Foot Assy	Assembly
88	Fan Duct Connection	
89	FS Stay	
90	Float Switch	
91	C-Heater	
92	Pipe SC1 Unit	
93	Pipe SC2 Unit	
94	G Valve Assy	
95	L Valve Assy	
96	4 Way Valve Assy.	
97	Pipe C Assy.	
98	Pipe D Assy.	
99	Pipe S Assy.	
100	Pipe E	
101	L-Pipe 3	
102	Rubber Cap	
103	RC Cover	
104	Cover	

SMGB0043 rev.1 - 04/2010

9. Servicing

Contents

9. S	Servicing	215
9.1.	RASC-(3/5)HVRNE	217
9.1.1	Removing piping service cover	
9.1.2	2. Removing fan service cover	217
9.1.3	3. Removing electrical box service cover	217
9.1.4	Removing the outdoor unit fan motor	218
9.1.5	5. Removing the compressor	
9.1.6	8. Removing the high pressure switch (PSH) and pressure switch for control (PSC)	
9.1.7	 Removing reversing valve coil 	
9.1.8	3. Removing expansion valve coil	
9.1.9	9. Removing expansion valve	
9.1.1	0. Removing reversing valve	
9.1.1	1. Removing solenoid valve	
9.1.1	2. Removing the PCB	
9.1.1	3. Removing electrical components	227
9.2.	RASC-10HRNE	228
9.2.1	Removing piping service cover	
9.2.2		
9.2.3	 Removing electrical box service cover 	
9.2.4	Removing the outdoor unit fan motor	
9.2.5	5. Removing the compressor	231
9.2.6	8. Removing the high pressure switch (PSH) and pressure switch for control (PSC)	
9.2.7	 Removing reversing valve coil 	
9.2.8	3. Removing expansion valve coil	234
9.2.9	9. Removing expansion valve	234
9.2.1	0. Removing reversing valve	
9.2.1	1. Removing solenoid valve	235
9.2.1	2. Removing the PCB	
9.2.1	3. Removing electrical components	237
9.3.	Collecting refrigerant for replacing indoor unit	

DANGER

- Electrical hazard. Risk of death.

- Before performing any of the service operations described in this chapter, turn all the main switches off and place security lockers or convenient warning indicators in order to prevent them from turning on accidentally.
- Check and be sure that the LED201 (Red) on the inverter PCB is OFF for all electrical maintenance.
- Do NOT touch the electrical components when the LED201 (Red) on the inverter PCB is ON to avoid electrical shock.



4

WARNING

- Crush hazards. Can cause serious injuries.
- In case of sharped edged parts, as covers, use security gloves to avoid getting injured.
- In case of blocked or stucked parts, use appropriated tools and eventually lubricants to release them.
- When performing brazing work, besides security gloves it is a must to wear convenient eye protection.

İ


NOTE

- All compressors are connected by brazing. Check to ensure whether there are flammable things around or not when using a burner for pipe connections, if not, oil existing pipe inside may ignite.
- Do not expose the refrigerant cycle to the atmosphere for a long period in order to avoid mixing the water and foreign particles into the refrigerant cycle. After removing compressor, replace it quickly. If exposed for a long period, seal the suction pipe and discharge pipe.
- Remove the cap for the compressor just before replacing the compressor. Before mounting the compressor, seal the suction pipe and discharge pipe with a tape to protect the compressor from foreign particles. Remove the tape at pipe connection.

9.1. RASC-(3/5)HVRNE

9.1.1. Removing piping service cover

Remove the main parts according to the following procedures.



- If necessary, seal pipe ends using caps or tape.
- 1. Remove the eleven (11) fixing screws.
- 2. Slide the service cover downward and remove it.
- 3. Pay attention while handling the cover and do not fall it off.

9.1.2. Removing fan service cover

- 1. Remove the nine (9) fixing screws.
- 2. Slide the service cover downward and remove it using the handle.
- 3. Pay attention while handling the cover and do not fall it off.




Fan service

cover

Piping service cover

Electrical box service cover






- 9.1.3. Removing electrical box service cover
- 1. Remove the nine (9) fixing screws.
- 2. Slide the service cover downward and remove it using the handle.
- 3. Pay attention while handling the cover and do not fall it off.



- 9.1.4. Removing the outdoor unit fan motor
- 1. Remove the electrical box service cover.
- 2. Remove the PCB plate by removing it's screw. Turn the PCB plate towards the front side.
- 3. Disconect all the wires to the DIP-IPM, according to the dotted marks in the photo.

A	DANGER	
	- Electrical hazard. Risk of death.	
- Check that the LED201 (red) located on the DIP-IPM is OFF.		

- Do not touch the electrical components when LED201 (Red) is ON in order to avoid an electrical shock.
- Do not touch the electrical components of the PCB directly.




PCB plate DIP-IPM


- 4. Remove the four (4) screws fixing the DIP-IPM. Draw the DIP-IPM towards the front side and leave it in a clear and safe place to prevent any damage.
- Through the hole left by the DIP-IPM, remove the three (3) M5 screws, located inside the unit, in the middle of the fan stay.

i	NOTE
remov	pecial attention to the edges of the plates when ing these screws. Always wear gloves when ming mechanical works.

6. Remove float switch assembly from the drain pan by removing the two (2) screws.



2 Screws



M5 Screws




7. Remove the three (3) screws fixing the fan stay and slowly, begin to draw it towards by paying attention to the wiring and the drain pan.


When half of the fan unit is out, disconnect the connector for the fan motor and pull out the fan motor unit completely.

	CAUTION
 Lifting hazard. Single person operation could cause in Fan unit weight is approx. 30Kg. Use two-man lift. 	


- 8. Once with the fan unit on the floor, remove the four (4) screws at the back side of the casing and remove the stay.
- 9. Turn the casing so the screws fixing each fan motor are visible, and remove the screws (4 per fan). Also remove the bolt fixing each motor shaft.
- 10. Remove the fan motor by removing the fixing bolts and fixing brackets.
- 11. Reassemble the parts in the reverse order of removing order.



- Always wear gloves when performing mechanical works.









Connector








9.1.5. Removing the compressor




- Revome half of the upper cover by removing the fifteen (15) fixing screws. Also remove the piping service cover by removing the eleven (11) fixing screws.
- 2. Open the sound insulation cover wrapped around the compressor and remove the terminal box cover at the compressor fixed by one (1) screw. Disconnect the compressor wires in the terminal box.

i	NOTE
norma termin	sure that the fasten terminals for the compressor are I. Any lack of grip should lead to a change of the old als for new ones. It is recommended to clamp the terminals to improve the contact.
indica	and take Note of each terminal number and tions for its correct connection at the reasembling s. If wires are connected in incorrect order, it will


lead to a compressor failure.





4. Remove the two (2) crankcase heaters by releasing the springs.



- 5. Cut the pipe at the compressor side of the brazing part.
- 6. Remove the cut pipe by using a burner, after cutting.







Í	NOTE
- Compl	etely clean the oil in case it has spread to other parts

- of the unit, such as bottom base, pipes and others.
 Make sure that the pipes are cut before working with a
- burner.
 Do not expose the refrigerant cycle to the atmosphere for a long period in order to avoid water and foreign particles entering into the refrigerant cycle. After removing the compressor, replace it quickly. If it is exposed to the ambiance for a long period, seal both suction and
- discharge pipes.
 Remove the cap for the compressor just before replacing the compressor. Before assembling the compressor, seal the suction pipe and discharge pipe with tape to protect the compressor interior from foreign particles. Remove the tape when connecting the pipes.
- Remove the four (4) nuts fixing the compressor and remove the compressor. When doing this, pay special attention not to touch or deform the sorrounding pipes.
- 8. Isolate the wires and electrical components to protect them from the burner flame when brazing the connection pipes.
- For brazing the compressor connection pipes, first cool down the compresor piping side covering it with wet clooth. Then brazing material will not enter into the compressor. If the brazing material enters the compressor, it will cause compressor failures.
- 10. Reassemble the parts in the reverse order of the indicated removing procedures.
 - Tighten the screws (U, V and W) for compressor wires with 2.5N.m.
 - Fix the lead wire firmly.


i	NOTE
 Fix the lead wire for the compressor firmly using a cable to aviod contacting the metal sheet sharp edges and the high temperature piping. 	




WARNING


 Risk of fire. Smokes and other damages may occur. All compressor pipes must be brazed to be connected to the refrigerant circuit. Ensure that all the sourrounding is free of flammable objects and liquids when performing piping brazing work.

Details for compressor terminals



- 9.1.6. Removing the high pressure switch (PSH) and pressure switch for control (PSC)
- 1. Remove the six (6) screws of the side cover. Slide the cover downward.
- 2. Remove the electrical service cover by unscrewing the nine (9) fixing screws. Slide the service cover downward and remove it using the handle.
- 3. Collect the refrigerant from the check joint.
- 4. Disconnect the connector in the electrical box:
 - PCN13: PSC
 - PCN8: PSH and disconnect Float Switch _ connector, RPR Relay board and Magnetic Switch terminals.
- 5. Cut the high pressure switch and control pressure switch from the brazing neck using a burner.






9.1.7. Removing reversing valve coil

A	DANGER
- Elec	strical hazard. Risk of death.
- Che OFf	ck that the LED201 (red) located on the DIP-IPM is
	not touch the electrical components when LED201 d) is ON in order to avoid an electrical shock.
- Do l dire	not touch the electrical components of the PCB ctly.

- 1. Remove the six (6) screws of the side cover. Slide the cover downward.
- 2. Remove the electrical service cover by unscrewing the nine (9) fixing screws. Slide the service cover downward and remove it using the handle.
- 3. Disconnect the PCN6 connector on the PCB in the electrical box.
- 4. Remove the reversing valve coil by removing the screw fixing the coil.



Reversing valve coil

9.1.8. Removing expansion valve coil

DANGER
 ctrical hazard. Risk of death. ck that the LED201 (red) located on the DIP-IPM is


- Do not touch the electrical components when LED201 (Red) is ON in order to avoid an electrical shock.
- Do not touch the electrical components of the PCB directly.
- 1. Remove the piping service cover by removing the eleven (11) fixing screws.
- 2. Remove the electrical box service cover by removing the nine (9) fixing screws.
- 3. Remove the CN5A connector on the PCB in the electrical box.
- 4. Hold the expansion valve coil and slightly rotate, then pull it up. Refer to the figure below to replace the electrical valve. The lock mechanism is equipped with the expansion valve coil. Check to ensure that the expansion valve coil is locked.
- 9.1.9. Removing expansion valve
- 1. Revome the piping service cover by removing the three (3) fixing screws. Pull up and remove the cover using the handle.
- 2. Collect the refrigerant from the check joint according to the section "Removing Compressor".
- 3. Remove the coils according to the section "Removing Expansion Valve Coil".
- 4. Remove the brazing as shown in the figure below.

Electronic Expansion Valve (EV0): 2 brazing parts.


Perform the brazing to remove and reassemble the electronic expansion valve by cooling with wet cloth.


Protect the connecting wires and pipe insulation from brazing flame.

5. Reassemble the parts in the reverse order of removing procedures.



Electronic expansion valve coil






SMGB0043 rev.1 - 04/2010

9.1.10. Removing reversing valve


- 1. Remove the six (6) screws of the side cover. Slide the cover downward.
- 2. Remove the electrical service cover by unscrewing the nine (9) fixing screws. Slide the service cover downward and remove it using the handle.
- 3. Collect the refrigerant from the check joint according to the section "Removing compressor".
- 4. Remove the reversing valve coil according to the section "Removing reversing valve coil".
- 5. Remove one (1) fixing screw for the valve-mounting plate.
- 6. Remove the stop valve at the gas side from the valvemounting plate by removing the two (2) screws.
- 7. Remove the reversing valve assemblies from the 4 brazed parts where it is fixed. Remove the brazing of the reversing valve and the stop valve at the gas using a blowtorch. Cool down the piping side covering it with wet cloth, in order to avoid brazing material entering the reversing valve. Protect the connecting wires and pipe insulation from the brazing frame.
- Remove the reversing valves from its assemblies 4 brazed parts *×*.

Perform the brazing with a blowtorchto remove and reassemble the reversing valve by cooling the pipes first with wet cloth in order to avoid brazing material entering the reversing valve.

 Reassemble the parts in the reverse order of removing procedures contained in this chapter. When SFV is removed, fix it according to the section "Removing the Reversing Valve and the Solenoid Valve" contained in this chapter.



Reversing valve



9.1.11. Removing solenoid valve

- 1. Remove the six (6) screws of the side cover. Slide the cover downward.
- 2. Remove the electrical service cover by unscrewing the nine (9) fixing screws. Slide the service cover downward and remove it using the handle.
- 3. Collect the refrigerant from the check joint according to the section "Removing compressor" in this chapter.
- 4. Remove the solenoid valve coil by unscrewing the fixing screw.
- 5. Remove the brazing and flare nuts. Using a blowtorch and previously cooling the pipe side with wet cloth in order to avoid brazing material entering the reversing valve.
- 6. Perform the brazing to remove and reassemble the solenoid valve.
- 7. Protect the connecting wires and pipe insulation from the brazing flame.
- 8. Remove the flare nuts with two spanners to avoid twisting.
- 9. Reassemble the parts in the reverse order of removing order of removing procedures.

9.1.12. Removing the PCB

	DANGER
- E	lectrical hazard. Risk of death.
	heck that the LED201 (red) located on the DIP-IPM is FF.
	o not touch the electrical components when LED201 Red) is ON in order to avoid an electrical shock.
	o not touch the electrical components of the PCB rectly.


NOTE

- When handling the PCB, take care of components. Do not apply excesive force to them, in order to avoid damaging the motherboard and failures.



Screw

- 1. Remove the electrical box service cover by removing the nine (9) fixing screws.
 - Disconnect all the connectors in the PCB.
 - Remove the PCB by unlocking the four (4) plastic holders.
 - Pull out the PCB from the PCB plate.



Location of plastic holders

9.1.13. Removing electrical components

4	DANGER
- Elec	strical hazard Risk of death

- Check that the LED201 (red) located on the DIP-IPM is OFF.
- Do not touch the electrical components when LED201 (Red) is ON in order to avoid an electrical shock.
- Do not touch the electrical components of the PCB directly.


	NOTE	
Do	en handling the PCB, take care of components. not apply excesive force to them, in order to avoid naging the motherboard and failures.	

NOTE

- 1. Remove the electrical box service cover by removing the nine (9) fixing screws.
- 2. Remove the screw fixing the PCB plate and turn it towards the front side.
- 3. To remove the electrical components:
 - Remove the reactor by removing the four (4) screws.
 - Disconnect the wiring connected to the magnet contactor and remove the magnet contactor by unscrewing the two (2) screws.
 - Disconnect the wiring connected to the SSR and remove the SSR by unscrewing the two (2) screws.
 - Disconnect the fasten connection to the capacitor and remove the capacitor by unscrewing the two (2) screws.
 - Disconnect the wiring connected to the noise filter.
 Remove the noise filter by holding the expanded part of the holders (6 pieces) with long-nose pliers.

	i	NOTE
-		nnect all the wires connected with the smoothing tor (CB, CB1, CB2, CA).
-	The w	ire has polar characters. Identify the wire mark band

- The wire has polar characters. Identify the wire mark band and the indication on the smoothing capacitor when wire connecting.
- Identify the terminal numbers with mark band. When reassembling, the terminals have to be connected to the correct numbers. If incorrectly connected, malfunctions or damages will occur.




Number	Identification
0	Reactor
2	Magnet contactor
8	SSR
4	Capacitor
6	Noise filter


9.2. RASC-10HRNE

9.2.1. Removing piping service cover

Remove the main parts according to the following procedures.



- 1. Remove the three (3) fixing screws.
- 2. Slide the service cover upward. Then, pull up and remove it using the handle.
- 3. Pay attention while handling the cover and do not fall it off.
- 9.2.2. Removing fan service cover
- 1. Remove the three (3) fixing screws.
- 2. Slide the service cover upward. Then, pull up and remove it using the handle.
- 3. Pay attention while handling the cover and do not fall it off.





9.2.3. Removing electrical box service cover

- 1. Remove the three (3) fixing screws.
- 2. Slide the service cover upward. Then, pull up and remove it using the handle.
- 3. Pay attention while handling the cover and do not fall it off.



9.2.4. Removing the outdoor unit fan motor


	DANGER
- Elec	trical hazard. Risk of death.
0.	ale that the LEDOOT (work) leasted are the DID IDM is

- Check that the LED201 (red) located on the DIP-IPM is OFF.
- Do not touch the electrical components when LED201 (Red) is ON in order to avoid an electrical shock.
- Do not touch the electrical components of the PCB directly.


i	NOTE
remov	pecial attention to the edges of the plates when ing the screws. Always wear gloves when performing anical works.

- 1. Remove the fan outlet air frame by removing the twelve (12) screws and the three (3) screws fixing the upper cover. Remove the outlet air frame cover.
- 2. Remove the fan service cover by removing the three (3) fixing screws.






- 3. Remove the two (2) screws at one side of the fan unit feet from the side of the fan service cover.
- 4. Remove the side cover by removing the eight (8) screws.
- 5. Open the fan motor electrical wiring cover by removing the four (4) screws using a screwdriver.




6. Unscrew the power wires and clearly identify them.

- 7. Remove the other two (2) screws at the other side of the fan unit feet. Now the fan motor unit is free.
- 8. Proceed to release the fan unit from the bottom base of the Outdoor unit. Then, begin to turn and pull out the fan unit as shown in the photos.



9. Reassemble the parts in the reverse order of removing order.




Electrical box







9.2.5. Removing the compressor




- 1. Revome the piping service cover by removing the three (3) fixing screws. Pull up and remove the cover using the handle.
- 2. Open the sound insulation cover wrapped around the compressor and remove the terminal box cover at the compressor fixed by one (1) screw. Disconnect the compressor wires in the terminal box.

	i	NOTE
-	norma termin	sure that the fasten terminals for the compressor are I. Any lack of grip should lead to a change of the old als for new ones. It is recommended to clamp the terminals to improve the contact.
-		and take Note of each terminal number and ions for its correct connection at the reasembling


- process. If wires are connected in incorrect order, it will lead to a compressor failure.
- 3. Remove the rubber cap and the thermistor on the top of the compressor.
- 4. Remove the two (2) crankcase heaters by releasing the springs.

A	CAUTION
	ion risk. Can cause injuries. Make sure that there is sitive pressure inside the pipes.



Sound-proof Compressor cover

Piping service cover



Cut here


- 5. Cut the pipe at the compressor side of the brazing part.
- 6. Remove the cut pipe by using a burner, after cutting.

Ì	NOTE
 Completely clean the oil in case it has spread to other pa of the unit, such as bottom base, pipes and others. 	
- Make burne	sure that the pipes are cut before working with a r.
for a lo particl the co the an	t expose the refrigerant cycle to the atmosphere ong period in order to avoid water and foreign es entering into the refrigerant cycle. After removing mpressor, replace it quickly. If it is exposed to nbiance for a long period, seal both suction and arge pipes.
the co the su	ve the cap for the compressor just before replacing mpressor. Before assembling the compressor, seal ction pipe and discharge pipe with tape to protect mpressor interior from foreign particles. Remove the

 Remove the four (4) nuts fixing the compressor and remove the compressor. When doing this, pay special attention not to touch or deform the sorrounding pipes.


tape when connecting the pipes.

- 8. Isolate the wires and electrical components to protect them from the burner flame when brazing the connection pipes.
- For brazing the compressor connection pipes, first cool down the compresor piping side covering it with wet clooth. Then brazing material will not enter into the compressor. If the brazing material enters the compressor, it will cause compressor failures.
- 10. Reassemble the parts in the reverse order of the indicated removing procedures.
 - Tighten the screws (U, V and W) for compressor wires with 2.5N.m.
 - Fix the lead wire firmly




	WARNING
compr refrige of flan	f fire. Smokes and other damages may occur. All essor pipes must be brazed to be connected to the rant circuit. Ensure that all the sourrounding is free nmable objects and liquids when performing piping g work.

SMGB0043 rev.1 - 04/2010




Oil heater Terminal box






- 9.2.6. Removing the high pressure switch (PSH) and pressure switch for control (PSC)
- 1. Remove the eight (8) fixing screws of the inlet protector net.
- 2. Remove the electrical service cover by unscrewing the three (3) fixing screws. Pull up and remove the cover using the handle.
- 3. Collect the refrigerant from the check joint.
- 4. Disconnect the connector in the electrical box:
 - PCN13: PSC
 - PCN8: PSH and disconnect Float Switch connector, RPR Relay board and Magnetic Switch terminals.
- 5. Disconnect the terminals from the pressure switches.
- 6. Cut the high pressure switch and control pressure switch from the brazing neck using a burner.






PSH




9.2.7. Removing reversing valve coil

A	DANGER
- Elec	strical hazard. Risk of death.
- Che OFf	ck that the LED201 (red) located on the DIP-IPM is
	not touch the electrical components when LED201 d) is ON in order to avoid an electrical shock.
- Do l dire	not touch the electrical components of the PCB ctly.

- 1. Revome the piping service cover by removing the three (3) fixing screws. Pull up and remove the cover using the handle.
- 2. Disconnect the PCN6 connector on the PCB in the electrical box.
- 3. Remove the reversing valve coil by removing the screw fixing the coil.



9.2.8. Removing expansion valve coil



- directly.
- Revome the piping service cover by removing the three (3) fixing screws. Pull up and remove the cover using the handle.
- 2. Remove the CN5A connector on the PCB in the electrical box.
- 3. Hold the expansion valve coil and slightly rotate, then pull it up. Refer to the figure below to replace the electrical valve. The lock mechanism is equipped with the expansion valve coil. Check to ensure that the expansion valve coil is locked.

9.2.9. Removing expansion valve

- 1. Revome the piping service cover by removing the three (3) fixing screws. Pull up and remove the cover using the handle.
- 2. Collect the refrigerant from the check joint according to the section "Removing Compressor".
- 3. Remove the coils according to the section "Removing Expansion Valve Coil".
- 4. Remove the brazing as shown in the figure below.

Electronic Expansion Valve (EV0): 2 brazing parts.

Perform the brazing to remove and reassemble the electronic expansion valve by cooling with wet cloth.

Protect the connecting wires and pipe insulation from brazing flame.


5. Reassemble the parts in the reverse order of removing procedures.



Electronic expansion valve coil



Expansion valve



9.2.10. Removing reversing valve


- 1. Revome the piping service cover by removing the three (3) fixing screws. Pull up and remove the cover using the handle.
- 2. Collect the refrigerant from the check joint according to the section "Removing compressor".
- 3. Remove the reversing valve coil according to the section "Removing reversing valve coil".
- 4. Remove one (1) fixing screw for the valve-mounting plate.
- 5. Remove the stop valve at the gas side from the valvemounting plate by removing the two (2) screws.
- 6. Remove the reversing valve assemblies from the 4 brazed parts where it is fixed. Remove the brazing of the reversing valve and the stop valve at the gas using a blowtorch. Cool down the piping side covering it with wet cloth, in order to avoid brazing material entering the reversing valve. Protect the connecting wires and pipe insulation from the brazing frame.
- Remove the reversing valves from its assemblies 4 brazed parts X.

Perform the brazing with a blowtorchto remove and reassemble the reversing valve by cooling the pipes first with wet cloth in order to avoid brazing material entering the reversing valve.

8. Reassemble the parts in the reverse order of removing procedures contained in this chapter. When SFV is removed, fix it according to the section "Removing the Reversing Valve and the Solenoid Valve" contained in this chapter.


9.2.11. Removing solenoid valve

- 1. Revome the piping service cover by removing the three (3) fixing screws. Pull up and remove the cover using the handle.
- 2. Collect the refrigerant from the check joint according to the section "Removing compressor" in this chapter.
- 3. Remove the solenoid valve coil according to the section "Removing coils for reversing valve and solenoid valve" in this chapter.
- 4. Remove the brazing and flare nuts. Using a blowtorch and previously cooling the pipe side with wet cloth in order to avoid brazing material entering the reversing valve.



Compressor

Reversing valve



- 5. Perform the brazing to remove and reassemble the solenoid valve.
- 6. Protect the connecting wires and pipe insulation from the brazing flame.
- 7. Remove the flare nuts with two spanners to avoid twisting.
- 8. Reassemble the parts in the reverse order of removing order of removing procedures.

SMGB0043 rev.1 - 04/2010


9.2.12. Removing the PCB

	DANGER
- Elec	ctrical hazard. Risk of death.
- Che OFF	eck that the LED201 (red) located on the DIP-IPM is =
	not touch the electrical components when LED201 d) is ON in order to avoid an electrical shock.
- Do i dire	not touch the electrical components of the PCB ctlv.


 NOTE


 - When handling the PCB, take care of components.

- Do not apply excesive force to them, in order to avoid damaging the motherboard and failures.
- 1. Revome the electrical box service cover by removing the three (3) fixing screws. Pull up and remove the cover using the handle.
 - Disconnect all the connectors in the PCB.
 - Remove the PCB by pressing the expanded parte of the four (4) plastic holders, using long-nose pliers., as shown in the picture below.
 - Pull out the PCB from the PCB plate.



Screws





Location of plastic holders

9.2.13. Removing electrical components

	DANGER
- Elec	trical hazard. Risk of death.

- Check that the LED201 (red) located on the DIP-IPM is OFF.
- Do not touch the electrical components when LED201 (Red) is ON in order to avoid an electrical shock.
- Do not touch the electrical components of the PCB directly.


	NOTE	
Do n	n handling the PCB, take care of components. not apply excesive force to them, in order to avoid aging the motherboard and failures.	

NOTE

- 1. Revome the piping service cover by removing the three (3) fixing screws. Pull up and remove the cover using the handle.
- 2. Remove the two (2) screws fixing the PCB plate and turn it towards the front side.
- 3. To remove the electrical components:
 - Remove the reactor by removing the four (4) screws.
 - Disconnect the wiring connected to the magnet contactor and remove the magnet contactor by unscrewing the two (2) screws.
 - Disconnect the wiring connected to the SSR and remove the SSR by unscrewing the two (2) screws.
 - Disconnect the fasten connection to the capacitor and remove the capacitor by unscrewing the two (2) screws.
 - Disconnect the wiring connected to the noise filter. Remove the noise filter by by unlocking the four (4) plastic holders.

İ	NOTE
	nnect all the wires connected with the smoothing tor (CB, CB1, CB2, CA).
	ire has polar characters. Identify the wire mark band e indication on the smoothing capacitor when wire cting.

 Identify the terminal numbers with mark band. When reassembling, the terminals have to be connected to the correct numbers. If incorrectly connected, malfunctions or damages will occur.




Number	Identification		
0	Reactor		
0	Magnet contactor		
8	SSR		
4	Capacitors		
6	Noise filter-s		

9.3. Collecting refrigerant for replacing indoor unit

When the refrigerant should be collected into the outdoor unit due to indoor/outdoor unit relocation, collect the refrigerant as follows.

- 1. Attach the manifold gauge to the gas stop valve and the liquid stop valve.
- 2. Turn ON the power source.
- 3. Set the DSW1-1 pin of the outdoor unit PCB at the "ON" side for cooling operation. Close the liquid stop valve and collect the refrigerant.
- 4. When the pressure at lower pressure side (gas stop valve) indicates -0.01MPa (-100mmHg), perform the following procedures immediately.
 - Close the gas stop valve.
 - Set the DSW1-1 pin at the "OFF" side. (To stop the unit operation.)
- 5. Turn OFF the power source.



10. Main Parts


Contents

10. Main parts	
10.1. Inverter	240
10.1.1. Specifications of inverter	
10.1.2. Inverter time chart 10.1.3. Protective function	
10.1.4. Overload control	
10.2. Thermistor	245
10.3. Electronic expansion valve	247
10.3.1. Electronic expansion valve for outdoor unit	
10.4. High pressure protection device	248
10.5. Noise filters (NF)	249
10.6. Capacitor (CB1, CB2)	252
10.7. Reactor (DCL)	252
10.8. Scroll compressor	254
10.8.1. Reliable mechanism for low vibrating and low sound	
10.8.2. Principle of compression	


10.1. Inverter

10.1.1. Specifications of inverter

Aplicable model	RASC-(3/5)HVRNE	RASC-10HRNE		
Aplicable power source	1~ 230V 50 Hz	3N~ 400V 50 Hz		
Input current	17A (RASC-3HVRNE), 25A (RASC-5HVRNE)	25A		
Control Method	Vector control			
Range output frequency	20~115 Hz			
Accuracy of frequency	0,01 Hz at applicable frequency range			
Output / characteristics	Conditions 1. Power source voltage AC220/240V 2. Non-loading (free output) 3 Ammeter type volt-meter (X1.1) $ \int_{220}^{V_{1}} \int_{f[Hz]}^{f[Hz]} \int_{115 Hz}^{f[Hz]} f[Hz] $	Conditions: 1. Power source voltage AC380/415V 2. Non-loading (free output) 3. Ammeter type volt-meter (X1.1) $\binom{V}{400}{380}{300}{400}{200}{60}{60}{60}{60}{60}{75}{100}{115}{115}{115}{115}{115}{115}{11$		
Soft start stop	0.125, 0.5, 1.2 Hz/s (4 steps)	0.125~3.00 Hz/s		
Protection function				
Excessive high or low voltage for inverter	Excessive low voltage at a voltage is lower than 194V DC Excessive high voltage at a voltage is higher than 420V DC Excessive high voltage at a voltage is higher than 750V DC			
Abnormality of current sensor (0A detection)	Stoppage at a current of compressor smaller than 1.5A. When the frequency is 15 to 18Hz after starting. Cause of abnormality: Failure of current sensor Failure of IPM/DIP-IPM/ ISPM Failure of compressor / fan motor Disconnected wiring			



10.1.2. Inverter time chart



10.1.3. Protective function

- 1. Excessive high or low voltage for inverter
 - a) Level of detection
 - When the voltage of direct current is greater than (A) V, abnormalities are detected.
 - When the voltage of direct current is smaller than (B) V, abnormalities are detected.

Power supply	400V, 50Hz 50Hz	230V, 50Hz
(A)	750	440
(B)	350	194

b) Function

When abnormalities are detected, the inverter compressor is stopped and transmit the signal code of stoppage cause to PCB1.

c) Cancellation of protection function

Transmission for signal code of stoppage cause is cancelled when a stopping order is given or main power source is cut off.

2. Abnormality of current sensor

a) Level of detection

When current of the inverter compressor decreases lower than 0.5A during the inverter compressor frequency between 15Hz and 18Hz, an abnormality is detected.

b) Function

When abnormalities are detected, the inverter compressor is stopped, and transmit the signal code of stoppage cause to PCB1.

c) Cancellation of Protection Function

Transmission for signal code of stoppage cause is cancelled when a stopping order is issued or main power source is cut off.

- 3. Overcurrent protection for inverter
 - a) Level of detection

When the current detected by current sensor reaches 150% of the rated current, overcurrent is detected. (Instantaneous overcurrent)

When the current detected by current sensor exceeds 105% of the rated current continuously for 30 seconds or for 3.5 minutes in total during a 10 minutes period, overcurrent is detected. (Electric thermal relay)

b) Function

When abnormalities are detected, the inverter compressor is stopped and transmit the signal code of stoppage cause to PCB1.

c) Cancellation of protection function

Transmission for signal code of stoppage cause is canceled by stopping order is issued or main power source is cut off.

4. Protection of IPM/DIP-IPM/ISPM

a) Level of detection

When some of the output terminals between "U" and "V", "V" and "W", "W" and "U" of IPM/dip IPM/ISPM are shortcircuited, an abnormality is detected.

When the running current of IPM/DIP-IPM/ISPM reaches (maximum rated current x 105%), an abnormality is detected.

When an internal temperature is measured by internal thermistor of IPM, an abnormality is detected. When the control voltage of IPM/DIP-IPM/ISPM decreases, an abnormality is detected.

b) Function

When abnormalities are detected, the inverter compressor is stopped and the signal code of stoppage cause is transmitted to PCB1.

c) Cancellation of protection function

Transmission for signal code of stoppage cause is canceled when a stopping order is issued or main power source is cut off.

5. Fin temperature increase

a) Level of detection

When the temperature of internal thermistor exceeds more than 100 °C, an abnormality is detected.

b) Function

HITACHI

Inspire the Next

When abnormalities are detected, the inverter compressor is stopped and the signal code of stoppage cause is transmitted to PCB1.

- c) Cancellation of protection function
 Transmission for signal code of stoppage cause is canceled when a stopping order is issued or main power source is cut off.
- 6. Earth detection
 - a) Level of detection

When the starting current of the compressor reaches 80% of the overcurrent protection value, an abnormality is detected.

b) Function

When abnormalities are detected, the inverter compressor is stopped and the signal code of stoppage cause is transmitted to PCB1.

 c) Cancellation of protection function Transmission for signal code of stoppage cause is canceled when a stopping order is issued or main power source is cut off.

10.1.4. Overload control

a) Level of detection

When the output current exceeds 105% of the maximum output current, an abnormality is detected.

b) Function

An overload signal is issued when output current exceeds 105% of the maximum output current, and the frequency decreases.

For 10 seconds after the output current decreases lower than 88% of the rated current, the operation is performed with the compressor frequency limited to the upper level frequency when the output current decreases lower than 88% of the rated one.

However, if the frequency order is smaller than the maximum value, the operation is performed according to the order.


c) Cancellation of protection function

After the operation described in the above item b. is performed for 10 seconds, this control is canceled.


10.2. Thermistor

• Thermistors for the outdoor unit


RASC-10HRNE



RASC-(3/5)HVRNE



1		•		9		•			
⊢									
⊢									
⊢	_	_			_	-			-
⊢							9	L.	
									L
<u> </u>	 			6		-		÷	



Number	Identification	
0	Thermistor for discharge gas temperature	
2 Thermistor for outdoor ambient temperat		
3	Thermistor for evaporating temperature	


Thermistor for upper part temperature of compressor

(For prevention of discharge gas overheating)

 a) A thermistor for the upper part temperature of the compressor is installed to prevent discharge gas from overheating.

If discharge gas temperature increases excessively lubricating oil deterioration occurs and lubricating properties deteriorate, resulting in short compressor life.

- b) If discharge gas temperature increases excessively, compressor temperature increases. At the worst, compressor motor winding will be burnt out.
- c) When the upper part temperature of compressor increases during heating operation, the unit is controlled according to the following method
- An electronic expansion valve of outdoor units is (are) opened to return the liquid refrigerant to the compressor through the accumulator, decreasing compressor temperature.
- If the compressor upper part temperature increases exceeding 132°C even if an electronic expansion valve opens, the compressor is stopped, in order to protect the compressor.



Resistance characteristics of thermistor for discharge gas overheating protection

In cooling operation, the above function is also available.


 d) If compressor upper part temperature increases excessively, the protection control is activated and the compressor is stopped according to the following method.

Operation	Upper part temperature of compressor	Defecting period
Cooling	Over 132°C	10 minutes (continuously)
	Over 140°C	5 seconds (continuously)
Heating	Over 132°C	10 minutes (continuously)
	Over 140°C	5 seconds (continuously)
Defrosting	Over 132°C	5 seconds (continuously)

• Thermistor for outdoor ambient temperature

The thermistor resistance characteristics are shown in the figure below.


• Thermistor for evaporating temperature of outdoor unit in heating operation (for defrosting) The characteristics for the thermistor is the same with the value of outdoor ambient temperature thermistor as shown in the figure below.




Thermistor characteristics

10.3. Electronic expansion valve

10.3.1. Electronic expansion valve for outdoor unit







Items	Specifications			
Applicable to the models	For the main cycle of: RASC-(3~10)H(V)RNE			
Туре	UKV(10.0 USRT) series/UKV (5.0USRT) series for MVB			
Refrigerant	R410A			
Working temperature range	$-30^\circ C \sim 65^\circ C$ (operation time of the coil: less than 50%)			
Mounting direction	Drive shaft in vertical direction within an angle of 45° as maximum			
Flow direction	Reversible			
Drive method	4-Phase canned motor method			
Rated voltage	DC12V±1.8V			
Drive condition	83PPS (pulse width at ON: 36mm sec, OFF: 60mm sec) 1,2 phase excitation			
Coil resistance (each phase)	$46\Omega \pm 10\%$ (at 20°C)			
Wiring diagram, drive circuit and activation mode	ON OFF Drive circuit Unive circuit Unive circuit Unive circuit Unive Circuit Circuit Circuit Circuit Circuit Circuit			

10.4. High pressure protection device

If the discharge pressure is excessively high, the compressor and the component parts of the refrigeration cycle can be damaged. Therefore, in case that the discharge pressure is higher than 4.15MPa (R410A), the protection control is activated and the compressor is stopped.



- 1. For controlling the high pressure not to increase excessively during heating operation, the gas by-pass circuit and the air volume of the outdoor fan is controlled automatically.
- 2. The gas by-pass circuit, which is composed of the solenoid valve and the capillary tube for flow adjustment, control the high pressure not to increase excessively by leading the high pressure gas to the low pressure side.




(The dotted zone marks the gas by-pass circuit)




10.5. Noise filters (NF)

The noise filter decreases the leakage of noise made by the inverter to the power supply side. Terminals indicated with "LOAD" are connected to the inverter side and terminals indicated with "LINE" to the power supply side.


RASC-(3/5)HVRNE (1~ 230V 50Hz)



RASC-10HRNE (3N~ 400V 50Hz)



RASC-10HRNE (3N~ 400V 50Hz)




10.6. Capacitor (CB1, CB2)

This part is used for changing the alternative current to the direct current for the inverter. Connect two capacitor in line and used.

RASC-10HRNE (3N~ 400V 50Hz)

Items	Specifications
Models	LNX2G472MSEAHE
Capacity of static electricity	4700 μF
Rated voltage	400 VDC
Permissible temperature range	-25°C to 95°C




10.7. Reactor (DCL)

This part is used for changing the alternative current to the direct current for the inverter.


RASC-(3/5)HVRNE (1~ 230V 50Hz)


Items	Specifications
Characteristics	0.68 mH+15% (at 1kHz)
Rated current	25 A
Direct resistance	31 mΩ
Permissible temperature range	-20°C to 60°C



RASC-10HRNE (3N~ 400V 50Hz)

Items	Specifications				
Characteristics	1.0 mH+10% (at 1 kHz)				
Rated current	30 A				
Direct resistance	22.8 mΩ+20% (at 20°C)				
Permissible temperature range	-20°C to 65°C				






10


10.8. Scroll compressor

10.8.1. Reliable mechanism for low vibrating and low sound

- 1. The rotating direction is definite.
- 2. The pressure inside of the chamber is high pressure, and the surface temperature of the chamber is 60 °C to 110 °C.

10.8.2. Principle of compression





11. Field Work Instruction

Contents

11. Field work instruction	255
11.1. Checking the power source and the wiring connection	256
11.2. Burnt-out compressor due to an insufficient refrigerant charge	256
11.3. Insufficient cooling performance when a long piping is applied	257
11.4. Abnormally high operation sound (in-the-ceiling type indoor unit)	257
11.5. Alarm code "31"	258
11.6. Not well cooling due to insufficient installation space for outdoor unit or inlet/outlet air bypas	s258
11.7. Caution in case of refrigerant leakage	258
11.7.1. Maximum permitted concentration of HFCs11.7.2. Calculation of refrigerant concentration11.7.3. Countermeasure for refrigerant leakage	259
11.8. Maintenance work	260
11.9. Service and maintenance record	261
11.10. Service and maintenance record using the 7-segment display	262
11.11. Service and maintenance record by remote control switch	263
11.12. Pump-down method for replacing the compressor	264

11

HITACHI Inspire the Next

11.1. Checking the power source and the wiring connection

Check the following items in the case of abnormal operation:

No.	Check item	Procedure						
1	Is the breaker of the fuse cut out?	eck the secondary voltage of the breaker and the fuse by means of a tester.						
2	Is the secondary power source on the transformer correct?	Disconnect the sedcondary side of the transformer and check the voltage by means of a tester.						
		Primary side 220, 230 or 240 V V V V V V V V V V V V V V V V V V V						
3	Is the wiring loosened or incorrectly connected?	 Check the wiring connection on the PCB. Thermistor connectors Connector of the remote control cable Connector of the transformer Each connector in a high-voltage circuit Check the connectors according to the electrical wiring diagram. 						

11.2. Burnt-out compressor due to an insufficient refrigerant charge

• Question and answer for the field work

I	Example 1: Burnt-out compressor due to an insufficient refrigerant charge				
Phenomenon	After commissioning, the alarm code "08" sometimes occurred and the compressors were burnt out after operating for two months.				
CauseThe refrigerant piping work was performed during the summer season. The additional refrig was not sufficiently charged from the discharge gas side. This insufficient refrigerant charge resulted in the overheating of the discharge gas and the deterioration, which was finally due to the separated operation despite the alarm code "08"					
Countermeasure 1. The compressor was replaced with a new compressor. 2. The correct refrigerant amount was charged according to the refrigerant piping lengt connected indoor units.					
Remarks	Additional refrigerant charge: Open the liquid stop valves slightly when you charge the additional refrigerant from the check joint of the liquid stop valves (the discharge gas side) during the cooling process. If the liquid stop valve is fully open, it is difficult to charge the additional refrigerant. Do not charge the refrigerant from the gas stop valve.				

11.3. Insufficient cooling performance when a long piping is applied

• Question and answer for the field work

	Example 2: Insufficient cooling performance when a long piping is applied						
Phenomenon	ufficient cooling was not available for an indoor unit that was located at the farthest position.						
Cause	f the location of an outdoor unit is 20 meters lower than the location of the indoor units, resetting of he DIP switch DSW3 is required. However, no setting was performed. Therefore, the largest discharge pressure was not increased. This resulted in an insufficient cooling performance for the indoor unit.						
	Indoor units						
	Outdoor unit						
Countermeasure	The setting of the DSW2 was changed.						
Remarks	Pay special attention to the size of liquid pipe. Refer to "piping work in TC" for details						

11.4. Abnormally high operation sound (in-the-ceiling type indoor unit)

Example 3: Abnormally high operation sound (in-the-ceiling type indoor unit) Phenomenon The operation sound at the "HIGH" speed was abnormally high. The indoor units were installed without the ducts. Since there scarcely was any external static Cause pressure, an abnormally big air volume was supplied. This resulted in a higher air speed through the heat exchanger Indoor unit Damper A. Filter Countermeasure In order to reduce the airflow rate, a plate that is used as a damper at the discharge gas side was added. Remarks Note that the running current is increased when no external pressure is given to the indoor unit. This results in an overheating.

• Question and answer for the field work

11.5. Alarm code "31"

Example 4: Alarm code "31" Phenomenon Alarm code "31" sometimes occurred and the system stopped. Cause The combination of the indoor units and the outdoor unit was the following. Power source ON OFF ON OFF ON ON ON This system was used in a tenant building. One of tenant's customers turned off the main switch for the indoor unit while other indoor units are running. This results in a different setting of the total indoor unit capacity in the same refrigerant cycle. Countermeasure All the main switches for the indoor units were always ON.

• Question and answer for the field work

11.6. Not well cooling due to insufficient installation space for outdoor unit or inlet/outlet air bypass

Example 5: Not co	oling well due to insufficient installation space for outdoor unit or inlet/outlet air bypass
Phenomenon	Cooling operation was well performed through the intermediate season. However, the cooling operation was not well available when the outdoor temperature was higher than 35°C.
Cause	Hot discharge air re-circulation. In this case, though the outdoor temperature was 35°C, the actual suction air temperature was nearly 50°C and protection system from excessively high suction pressure was activated, the frequency of the compressor was decreased and the cooling capacity was also decreased accordingly.
Countermeasure	Ensure that inlet and outlet is not bypassed (use grilles in opposite directions if necessary). Ensure that intlet and outlet air in opened spaces (never near walls).

Question and answer for the field work

11.7. Caution in case of refrigerant leakage

The installers and those responsible for drafting the specifications are obliged to comply with local safety codes and regulations in the case of refrigerant leakage.

11.7.1. Maximum permitted concentration of HFCs

The refrigerant R410A, charged in the RASC series system, is an incombustible and non-toxic gas. However, if leakage occurs and gas fills a room, it may cause suffocation.

Field work instruction Service Manual

The maximum permissible concentration of HFC gas, R410A in air is 0.44 kg/m³, according to EN378-1.

Therefore, some effective measure must be taken to lower the R410A concentration in air below 0.44 kg/ m³, in case of leakage.

11.7.2. Calculation of refrigerant concentration

- 1. Calculate the total quantity of refrigerant R (kg) charged in the system by connecting all the indoor units in the rooms to be air-conditioned.
- 2. Calculate the room volume V (m³) of each room.
- 3. Calculate the refrigerant concentration C (kg/m³) of the room according to the following equation:

R	R: Total quantity of refrigerant charged (kg)
— = C	V: Room volume (m ³)
V	C: Refrigerant concentration (=0.44* kg/m ³ for R410A)

11.7.3. Countermeasure for refrigerant leakage


The facility must have the following features in case of a refrigerant leakage occurs:

- 1. Provide a shutterless opening which will allow fresh air to circulate into the room.
- 2. Provide a doorless opening of 0.15% or more size to the floor area.
- There must be a ventilator fan connected to a gas leak detector, with a ventilator capacity of 0.4 m³/min or higher per Japanese refrigeration ton (= compressor displacement volume/5.7m³/h) of the air conditioning system using the refrigerant.

Model	Tonnes
RASC-3HVRNE	1.67
RASC-5HVRNE	2.27
RASC-10HRNE	4.11

4. Pay a special attention to the place, such as a basement, etc., where refrigerant can stay, since refrigerant is heavier than air.

General example of application



SMGB0043 rev.1 - 04/2010

Room	R (kg)	V (m³)	C (kg/m³)	Countermeasure			
A	50	300	0.17	-			
В	110	1,000	0.11	-			
С	60	125	0.48	0.075 m ² opening			
D	60	125	0.48	0.075 m ² opening			
C + D	60	350	0.17	-			
E	60	100	0.6	2 m ³ /min. fan linked with gas leak detector			

11.8. Maintenance work

• For the indoor unit and outdoor unit

- 1. Fan and fan motor
 - Lubrication: All the fan motors are prelubricated and sealed at the factory. Therefore, no lubrication maintenance is required.
 - Sound and vibration: Check for abnormal sounds and vibrations.
 - Rotation: Check the clockwise rotation and the rotating speed.
 - Insulation: Check the electrical insulation resistance.
- 2. Heat exchanger
 - Clog: Inspect the heat exchanger at regular intervals and remove any accumulated dirt and any accumulated dust from the heat exchanger. You should also remove from the outdoor units other obstacles, such as the growing grass and the pieces of paper, which might restrict the airflow.
- 3. Piping connection
 - Leakage: Check for the refrigerant leakage at the piping connection.
- 4. Cabinet
 - Stain and lubrication: Check for any stain and any lubrication. Remove the stain and the lubrication.
 - Fixing screw: Check for any loosened screw or any lost screw. Fix the loosened screws and the lost screws. Insulation material: Check for any peeled thermal insulator on the cabinet. Repair the thermal insulator.
- 5. Electrical equipment
 - Activation: Check for an abnormal activation of the magnetic contactor, the auxiliary relay, the PCB and others.
 - Line condition: Pay attention to the working voltage, the working amperage and the working phase balance.
 Check for any faulty contact that is caused by the loosened terminal connections, the oxidized contacts, the foreign matter, and other items. Check the electrical insulation resistance.
- 6. Control device and protection device
 - Setting: Do not readjust the setting in the field unless the setting is maintained at a point that is different from the point listed in the section 4: Safety and control device of "SM"

• For Outdoor unit

- 1. Compressor
 - Sound and vibration: Check for abnormal sounds and vibrations.
 - Activation: Check that the voltage drop of the power supply line is within 15% at the start and within 2% during the operation.
- 2. Reverse valve
- Activation: Check for any abnormal activation sound.
- 3. Strainer
 - Clog: Check that there is no temperature difference between both ends.
- 4. Ground wire
 - Ground line: Check for the continuity to earth.
- 5. Oil heater
 - Activation: You should activate the oil heater at least twelve hours before the start-up by turning ON the main switch.

11.9. Service and maintenance record

No.	Check item	Action	Judgement		
1	Is the service area sufficient?		Yes	No	
2	Is there a short circuit of the discharged air?		Yes	No	
3	Any heat influence?		Yes	No	
4	Is the ground wire connected?		Yes	No	
5	Refrigerant piping		Good	Not good	
6	Fixing the units		Good	Not good	
7	Is there any damage on the outer surface or the internal surface?		Yes	No	
8	Checking the screw and the bolts	Tighten if loosened.	Tightened	Not tightened	
9	Dightening the terminal screws Tighten all the terminal screws with a Phillips screwdriver.		Tightened	Not tightened	
10	Are the compressor terminals tightly fixed?	Push all the terminals.	Pushed	Not pushed	
11	Insulation resistance	$\begin{array}{llllllllllllllllllllllllllllllllllll$	Good	Not good	
12	Does the drain water flow smoothly?	Check the smooth flow by pouring some water.	Good	Not good	
13	Check for a leakage in the compressor	Check for any leakage.	Good	Not good	
14	Check for a leakage in the outdoor heat exchanger	ditto	Good	Not good	
15			Good	Not good	
16	Check for a leakage in the 4-way valve.	ditto	Good	Not good	
17	Check for a leakage in the check valve.	ditto	Good	Not good	
18	Check for a leakage in the accumulator	ditto	Good	Not good	
19	Check for a leakage in the strainer	ditto	Good	Not good	
20	Check for a leakage in the electronic expansion valve	ditto	Good	Not good	
21	Check for a leakage in the piping	ditto	Good	Not good	
22	Check the direction of the fans	By viewing the airflow volume	Good	Not good	
23	Voltage among each phase	Higher than AC220V	Good	Not good	
24	Vibration and sound	Check the fan, the compressor, the piping, and others.	Good	Not good	
25	Activation of each operation mode	Check the activation of the COOL switch, the HEAT switch, the STOP switch and the TEMP switch.	Good	Not good	
26	High-pressure cut-out switch	Check the actual activation value.	Good	Not good	
27	Check the activation of the drain-up mechanism.	Check the activation during the cooling process.	Good	Not good	
28	Air inlet temperature of the indoor unit DB/WB		(°C)DB	(°C)WB	
29	Air outlet temperature of the indoor unit DB/WB		(°C)DB	(°C)WB	
30	Air inlet temperature of the outdoor unit DB/WB		(°C)DB	(°C)WB	
31	Air outlet temperature of the outdoor unit DB/WB		(°C)DB	(°C)WB	
32	High-pressure switch		kg/e	cm²G	
33	Low-pressure switch		kg/e	cm²G	
34	Operating voltage			V	
35	Operating current			A	
36	Instructions to the client for cleaning the air filter		Done	Not yet	
37	Instructions to the client about the cleaning method		Done	Not yet	
38	Instructions to the client about the operation		Done	Not yet	

11.10. Service and maintenance record using the 7-segment display

Data sheet for checking by 7-segment display

Customer's name:				Da	te:				-	
	Outdoor unit model (serial no.)	RA	SC- (Ser	ial no.)	RA	SC- (Ser	ial no.)	
(1)	Operation mode			-						
(2)	Test run start time									
(3)	Data collect start time									
(4)	Read out data from 7-segment in Outdoor unit									
	Protection control code									
	Total capacity of I.U connected	CP								
	Input/output state of Outdoor micro-computer	SC	52C	FAN1	FAN2	20A	52C	FAN1	FAN2	20A
			20F	21	СН	PSH	20F	21	СН	PSH
	Alarm code for abnormal stoppage of compressor	AC								
	Inverter order frequency to compressor	H1								
	Indoor order frequency to compressor	H2								
	Air flow ratio	Fo								
	O.U. expansion valve opening	Eo		-						
	Temp. at the top of compressor	Td								
	Evaporating temp. at heating	TE								
	Ambient air temp.	To		-						
	Cause of stoppage at inverter	iT								
	Inverter secondary current	A2								
	O.U. address	nA								
	Indoor unit (unit no. 1)	EA								
	I.U. expansion valve opening									
	Liquid pipe temp. of I.U. (Freeze protection)	LA								
	I.U. intake air temp. I.U. discharge air temp.	iA oA								
	Cause of I.U. stoppage	dA								
	Indoor unit (unit no. 2)	UA								
	I.U. expansion valve opening	EA								
	Liquid pipe temp of I.U. (Freeze protection)	LA								
	I.U. intake air temp.	iA								
	I.U. discharge air temp.	oA								
	Cause of I.U. stoppage	dA								
	Indoor unit (unit no. 3)	u A								
	I.U. expansion valve opening	EA			-					
	Liquid pipe temp. of I.U. (Freeze protection)	LA								
	I.U. intake air temp.	iA								
	I.U. discharge air temp.	oA								
	Cause of I.U. stoppage	dA		-						
	Indoor unit (unit no. 4)									
	I.U. expansion valve opening	EA								
	Liquid pipe temp. of I.U. (Freeze protection)	LA								
	I.U. intake air temp.	iA								
	I.U. discharge air temp.	oA								
	Cause of I.U. stoppage	dA		-						
	Sudde of i.e. stoppage	un					1			

O.U.: Outdoor unit, I.U: Indoor unit

FAN1, FAN2: Constant speed fan, 52C: CMC, PSH: High pressure switch

20A: Solenoid valve (SVA), 20F: Solenoid valve (SVF), 21: Reversing valve (RVR), CH: Oil heater

*: Multiply 1/8 by the code on the 7-segment.

11.11. Service and maintenance record by remote control switch

Data sheet for checking by remote control switch

Time			:	:	:	:	:
I.U. model							
I.U. serial no.							
I.U. no. / alarm code							
	Check mode 1	Check mode 2	1 · 2	1 · 2	1 · 2	1 · 2	1 · 2
B Temp. indication	1						
Set temp.	b1						
Inlet air temp.	b2	91					
Discharge air temp.	b3	92					
Liquid pipe temp.	b4	93					
Remote thermistor temp.	b5						
Outdoor air temp.	b6	94					
Gas pipe temp.	b7	95					
Evaporating temp.at heating	b8	96					
Control information	b9	97					
Comp. top temp.	bA	98					
Thermo temp. of remote control switch	bb						
C Micro-computer state indication							
I.U. micro-computer	C1						
O.U. micro-computer	C2						
D Stopping cause state indication	1			1			1
Stopping cause state indication	d1						
E Alarm occurrence	1			1	1		1
Times of abnormality	E1						
Times of power failure	E2						1
Times of abnormal transmitting E3							
Times of inverter tripping	E4						
F Automatic louver state	1			1	1	1	1
Louver sensor state	F1						
H Pressure, frequency state indication					1		
Discharge pressure	H1	99					
Suction pressure	H2	9A					
Control information	H3	9b					
Operating frequency	H4	9C					
J I.U. capacity Indication				I	1		1
I.U. capacity (1/8HP)	J1						
O.U. code	J2						
Refrigerant cycle number	J3				1		
Refrigerant cycle number	J4						
L Opening of ex. valve	I	1		1	1	1	1
I.U. ex. valve	L1	9d					
O.U. ex. valve 1	L2	9E					
O.U. ex. valve 2	L3						
O.U. ex. valve B	L4						
P Running current indication (reference)				I	1	1	1
Comp. current	P1	9F					

11.12. Pump-down method for replacing the compressor

No.	Procedure	Remarks
1	Turn off the main switch of the outdoor unit.	
2	Remove the covers, the thermistor, the crankcase heater, the power wirings, and other items according to the chapter "removing the parts of the oudoor unit".	Make sure that the terminal part of the detached power supply wires is not exposed by the winding insulation tape and other items.
3	Attach the manifold to the check joint of the high- pressure side and the low-pressure side of the outdoor unit.	
4	Turn on the main switch of the outdoor unit.	
5	Set the exclusion of the compressor by setting the DSW so that a broken compressor will not work. You can set the exclusion of the compressor by setting the DSW1-4 in ON position.	
6	 The compressor replacing mode is performed: The DSW1-4 on the outdoor unit PCB→ ON (The cooling is run). 	 This operation is performed for up to a maximum of ten minutes. If the inverter compressor is excluded, the operation starts after three minutes.
7	 The operation finishes when one of the following conditions occurs: 1) Ten minutes have passed and STP is displayed in seven segments. 2) "08" is displayed in seven segments. 3) When Ps< 0.1MPa is continued for one minute, in ten minutes STP is displayed in seven seconds and the operation finishes. 	 The operation may finished when any of the conditions 1) to 3) occurs.
8	Close the liquid stop valve completely.	To avoid the spillage of all the refrigerant if the check valve is broken.
9	 Check for a leakage of the check valve on the discharge gas side: DSW4-4 (enforced stoppage of the compressor) → ON, so that the compressor will not run although the running command is sent from the remote control switch. Check that variation of Ps on the outdoor unit PCB is 17 seconds. Make sure that the Ps increase is within 0.03 Mpa in two minutes after the Ps increase at the stoppage (during approximately five minutes). Also make sure that Pd>Ps. Ps 0.03 MPa or smaller Time 	 When you stop the compressor for replacing: You can check the leakage of the check valve by means of the Ps variation because the SVA opens so that the discharge gas side of the inverter compressor can connect to the low-pressure side. 0.03 Mpa / 2 minutes is within the permissible limits for the check valve on the discharge gas side. The leakage of the check valve may cause an incorrect brazing, due to the gas pressure at the brazing of the discharge piping. If the compressor-replacing mode is performed again, set the DSW4-4 to OFF and keep the DSW4-4 at the OFF side during ten minutes. Then, start according to the procedure No. 6.
10	 Collect the refrigerant by means of the refrigerant collection: Perform either A or B, depending on the process 10. A: The leak rate at the process 10 is within the specification → Collect the refrigerant only at the low-pressure side. B: The leak rate at the process 10 is greater than the specification → Collect all the refrigerant of the outdoor unit side by means of the machine. 	 The discharge of the refrigerant in the atmosphere is strictly forbidden. Make sure that the refrigerant is collected by the collector. Keep a note of the quantity of the collected refrigerant.

Service Manual

No.	Procedure	Remarks
11	After collecting the refrigerant, remove the change hose (collector side) of the low-pressure side, so that the low-pressure side of the refrigerant cycle will be the atmosphere pressure.	 Make sure that there is no pressure increase of the low-pressure sides after collecting the refrigerant. Make sure that the refrigerant cycle is the atmosphere pressure. Otherwise, problems such as the blowing of gas and the suction of the cutting material) may occur when you are removing the compressors.
12	Turn OFF the main switch of the outdoor unit.	
13	Perform the replacement of the compressor and the change of the refrigerant oil according to the section "replacing the compressor".	Make sure that you follow the instructions.
14	Perform the vacuum from the check joint of the low-pressure side.	If you collect the refrigerant only on the low-pressure side (A in 11). You cannot perform the vacuum of the refrigerant from the check joint of the high-pressure side.
15	Open the liquid stop valve and the gas stop valve completely when you finish the vacuum.	
16	Make sure that the power is turned OFF and attach the following items: the power supply wire, the thermistor, the crankcase heater, the 63H wiring, the panel and the nut).	
17	Set the DSW back to the original setting. Make sure that all the wirings to the compressor are connected correctly.	
18	Recharge the refrigerant that is collected in the process by the stop valve of the liquid side during the cooling at the TEST RUN mode.	If the replacement of the compressor takes more than two hours, an additional change of the refrigerant is necessary. Additional change = (replacing time $- 2$ hours) x 0.5kg.

Hitachi Air Conditioning Products Europe, S.A. Ronda Shimizu,1 - Políg. Ind. Can Torrella 08233 Vacarisses (Barcelona) España



Hitachi units certifies that our product have fulfilled EU consumer safety, health and environmental requirements.



Hitachi Air Conditioning Products Europe, S.A. is certified with: ISO 9001 by AENOR; Spain for its Quality Management accordance with the standard ISO 14001 by AENOR, Spain for its Environmental Management systems accordance with the standard.



Hitachi participates in the Eurovent Certification Program for (designation of the relevant family products); the certified data of certified models are listed in the Eurovent Certification Online Directory (www.eurovent-certification.com).

HITACHI Inspire the Next