

SET FREE SERIES FSN2



Service manual

Outdoor Units: RAS-(8~48)FSN2

Contents

Model codes and descriptions	0
Units installation	1
Piping installation	2
Electrical wiring	3
Control system	4
Available optional functions	5
Test run	6
Troubleshooting	7
Spare parts	8
Servicing	9
Main parts	10
Field work instruction	11

0.	Model codes and descriptions	V
1.	Units installation	1
1.1	General installation notes	2
1.2	Transportation and handling	4
1.2.1	Hanging method	4
1.2.1	Center of gravity	7
1.3.	Outdoor units installation	8
1.3.1	Before installation	8
1.3.2	Installation location	9
1.3.3	Serial units installation	10
1.3.4	Multiple installation space	11
1.3.5.	Foundations	15
2.	Piping installation	17
2.1.	Piping work considerations	18
2.1.1	Copper pipes and sizes	18
2.1.2	Three principles on refrigerant piping work	21
2.1.3	Suspension of refrigerant piping	21
2.1.4.	Tightening torque	22
2.1.5.	Brazing work	23
2.2.	Outdoor units piping installation	24
2.2.1.	Factory supplied accessories	24
2.2.2.	Position of piping connections	25
2.2.3.	Flange piping connection	26
2.2.4.	Piping connection	27
2.2.5	Vacuum and refrigerant charge	28
2.2.6.	Drain discharging boss	30
3.	Electrical wiring	31
3.1.	General check	32
3.2.	Electrical wiring for the outdoor unit	33
3.2.1.	Electrical wiring connection for outdoor unit	33
3.2.2.	Setting the DIP switches for the outdoor unit	34
3.3.	Common wiring	38
3.3.1.	Electrical wiring between the indoor unit and the outdoor unit	38
3.4.	Wire size	40
3.5.	Electrical wiring diagrams	42
4.	Control system	47
4.1.	Device control system	48
4.1.1.	RAS-8~48FSN2 refrigerant cycle control	48
4.2.	Outdoor Units PCB	51
4.2.1.	RAS-8~48FSN2	51
4.3.	Protection and safety control	52
4.4.	Standard operation sequence	53
4.4.1.	Cooling process	53
4.4.2.	Dry operation	55
4.4.3.	Heating process	57
4.4.4.	Defrost operation control	59
4.5.	Standard control functions	60
4.5.1.	Freezing protection during cooling process or dry operation	60
4.5.2.	Protection control (in cooling and dry operation)	61
4.5.3.	Compressor operation control	62
4.5.4.	Outdoor fan control during cooling operation	64
4.6.	Restricted control for Outdoor Units	65

5.	Available optional functions	67
5.1.	Outdoor units	68
5.1.1.	Setting of external input and output functions	68
5.1.2.	Description of external input signals	70
5.1.3.	Description of external output signals	73
5.1.4.	Optional functions	75
6.	Test run	83
6.1.	Checking procedure before the test run	84
6.2.	Test run procedure from the outdoor unit side	86
6.3.	Check list	87
6.4.	Judgement systems for refrigerant amount	90
6.4.1.	Automatic judgement system for refrigerant amount	90
6.4.2.	Simple judgement system for refrigerant amount	91
7.	Troubleshooting	93
7.1.2.	Emergency operation	95
7.1.3.	Failure of the power supply to the indoor unit and the remote control switch	101
7.1.4.	Abnormal transmission between the remote control switch and the indoor unit	102
7.1.5.	Abnormal operation of the devices	103
7.2.	Troubleshooting procedure	111
7.2.1.	Alarm code indication of remote control switch	111
7.2.2.	Troubleshooting by alarm code	113
7.2.3.	Troubleshooting in check mode	158
7.2.4.	Troubleshooting by means of the 7 segment display	164
7.2.5.	Running current of the compressor	170
7.2.6.	Protection control code on the 7-segment display	172
7.2.7.	Activating condition of the protection control code	173
7.3.	Procedure for checking each main part	175
7.3.1.	Self-checking procedure of PCB by means of the Remote Control Switch	175
7.3.2.	Self-Checking procedure of the Remote Control Switch	177
7.3.3.	Self-Checking procedure of the Indoor Unit PCB (only for RPK)	179
7.3.4.	Procedure of checking other main parts	180
8.	Spare parts	189
8.1.	RAS-8~12FSN2 - Cabinet and fan	190
8.2.	RAS-8~12FSN2 - Refrigerant cycle	191
8.3.	RAS-8~12FSN2 - Eelectrical equipment	192
8.4.	RAS-14~24FSN2 - Cabinet and fan	193
8.5.	RAS-14~24FSN2 - Refrigerant cycle	194
8.6.	RAS-14~48FSN2 - Electrical equipment	195
8.7.	RAS-14~48FSN2 - Electrical equipment	196
9.	Servicing	201
9.1.1	Outdoor units FSN2	202
9.1.1.1.	Removing air intake grille	202
9.1.1.2.	Removing front service panel	203
9.1.1.3.	Removing fan guard net	204
9.1.1.4.	Removing outdoor fan	205
9.1.1.5.	Removing compressor	207
9.1.1.6.	Replacing return oil circuit (Strainer)	217
9.1.1.7.	Removing high pressure switch, high pressure sensor and low pressure sensor	219
9.1.1.8.	Removing reversing valve and removing reversing valve coil	222
9.1.1.9.	Removing solenoid valve and solenoid valve coil	225
9.1.1.10.	Replacing oil separator, liquid tank and accumulator	229
9.1.1.11.	Removing stop valve	233
9.1.1.12.	Removing expansion valve coil	235
9.1.1.13.	Removing thermistor for liquid pipe	237
9.1.1.14.	Removing thermistor for ambient temperature	239
9.1.1.15.	Removing electrical control box	240
9.1.1.16.	Removing other electrical components	242

0

1

2

3

4

5

6

7

8

9

10

11

10.	Main parts	251
10.1.	Inverter	252
10.1.1.	Specifications of inverter	252
10.1.2.	Inverter time chart	254
10.1.3.	Protective Function	255
10.1.4.	Overload Control	256
10.2.	Thermistor	257
10.2.1.	Position of thermistor	257
10.2.2.	Resistance value of the thermistor	257
10.3.	Electronic expansion valve	260
10.3.1.	Electronic expansion valve for the outdoor unit	260
10.4.	Pressure sensor	261
10.5.	Scroll compressor	262
10.5.1.	Reliable mechanism for low vibrating and low sound	262
10.5.2.	Principle of compression	262
11.	Field work instruction	263
11.1.	Checking the power source and the wiring connection	264
11.2.	Burnt-out compressor due to an insufficient refrigerant charge	264
11.3.	Insufficient cooling performance when a long piping is applied	265
11.4.	Alarm Code "31"	265
11.5.	Not cooling well due to insufficient installation space for the outdoor unit	266
11.6.	Caution with the refrigerant leakage	267
11.6.1.	Maximum permissible concentration of the HFC Gas	267
11.6.2.	Calculation of the refrigerant concentration	267
11.6.3.	Countermeasure for the refrigerant leakage according to the KHK standard	267
11.7.	Maintenance work	269
11.7.1.	Pump-down method for replacing the compressor	270

0. Model codes and descriptions

0

◆ Unit code list

MODEL CODIFICATION

Please check by model name your air conditioner type, its abbreviation and reference number in this service manual.

FSN(2)(E) INDOOR UNITS							
4-Way Cassette		4-Way Mini Cassette		2-Way Cassette		Ceiling	
Unit	Code	Unit	Code	Unit	Code	Unit	Code
RCI-1.0FSN2E	7E400001	RCIM-1.0FSN2	60278011	RCD-1.0FSN2	60278029		
RCI-1.5FSN2E	7E400002	RCIM-1.5FSN2	60278013	RCD-1.5FSN2	60278030		
RCI-2.0FSN2E	7E400003	RCIM-2.0FSN2	60278014	RCD-2.0FSN2	60278031	RPC-2.0FSNE	7E440003
RCI-2.5FSN2E	7E400004			RCD-2.5FSN2	60278032	RPC-2.5FSN2E	7E440004
RCI-3.0FSN2E	7E400005			RCD-3.0FSN2	60278033	RPC-3.0FSN2E	7E440005
RCI-4.0FSN2E	7E400007			RCD-4.0FSN2	60278034	RPC-4.0FSN2E	7E440007
RCI-5.0FSN2E	7E400008			RCD-5.0FSN2	60278035	RPC-5.0FSN2E	7E440008
RCI-6.0FSN2E	7E400009					RPC-6.0FSN2E	7E440009

			
RCI	RCIM	RCD	RPC

☀ ☁ 1~

Meaning of model codification:

RPI 3.0 FS N 2 E

Unit Type (Indoor Unit RCI(M), RCD, RPC, RPI, RPK, RPF(I))

Compressor power (HP) 1.0 ~ 6.0

H-Link Set Free / System Free

R410 A refrigerant

Series

E: Made in Europe

- Made in Malaysia

FSN(2)(E) INDOOR UNITS

Duct		Wall		Floor Enclosure		Floor Concealed Enclosure			
Unit	Code	Unit	Code	Unit	Code	Unit	Code		
				RPK-1.0FSNH2M	60277942				
RPI-0.8FSN2E	7E420000	RPIM-0.8FSN2E	7E430000	RPK-1.5FSNH2M	60277942				
RPI-1.0FSN2E	7E420001	RPIM-1.0FSN2E	7E430001	RPK-1.0FSN2M	60277941	RPF-1.0FSN2E	7E450001	RPFI-1.0FSN2E	7E460001
RPI-1.5FSN2E	7E420002	RPIM-1.5FSN2E	7E430002	RPK-1.5FSN2M	60277942	RPF-1.5FSN2E	7E450002	RPFI-1.5FSN2E	7E460002
RPI-2.0FSN2E	7E420003			RPK-2.0FSN2M	60277943	RPF-2.0FSN2E	7E450003	RPFI-2.0FSN2E	7E460003
RPI-2.5FSN2E	7E420004			RPK-2.5FSN2M	60277944	RPF-2.5FSN2E	7E450004	RPFI-2.5FSN2E	7E460004
RPI-3.0FSN2E	7E420005			RPK-3.0FSN2M	60277945	-	-	-	-
RPI-4.0FSN2E	7E420007			RPK-4.0FSN2M	60277946				
RPI-5.0FSN2E	7E420008								
RPI-6.0FSN2E	7E420009								
RPI-8.0FSN2E	7E420010								
RPI-10.0FSN2E	7E420011								



Meaning of model codification:

RPF 2.0 FS N 2 E

Unit Type (Indoor Unit RCI(M), RCD, RPC, RPI, RPK, RPF(I))

Compressor power (HP) 1.0 ~ 6.0

H-Link Set Free / System Free

R410 A refrigerant

Series

E: Made in Europe

- Made in Malaysia

FSN2 OUTDOOR UNITS

Unit	Code	Unit	Code	Unit	Code	Unit	Code
RAS-8FSN2	60288134						
RAS-10FSN2	60288135						
RAS-12FSN2	60288136						
		RAS-14FSN2	60288137				
		RAS-16FSN2	60288138				
		RAS-18FSN2	60288139				
		RAS-20FSN2	60288140				
		RAS-22FSN2	60288141				
		RAS-24FSN2	60288142				
				RAS-26FSN2	60288143		
				RAS-28FSN2	60288144		
				RAS-30FSN2	60288145		
				RAS-32FSN2	60288146		
				RAS-34FSN2	60288147		
				RAS-36FSN2	60288148		
				RAS-38FSN2	60288149		
				RAS-40FSN2	60288150		
				RAS-42FSN2	60288151		
						RAS-44FSN2	60288152
						RAS-46FSN2	60288153
						RAS-48FSN2	60288154



Meaning of model codification: **RAS** **14** **FS** **N** **2**


- Unit Type (Outdoor Unit)
- Compressor power (HP) 8 ~ 48
- Set-Free System
- R410 A refrigerant
- Series




◆ Complementary systems


Name	Description	Code	Figure
KPI-502E1E	Energy recovery ventilation units	70600001	
KPI-802E1E		70600002	
KPI-1002E1E		70600003	
KPI-1502E1E		70600004	
KPI-2002E1E		70600005	
KPI-3002H1E		70600107	
EF-5NE	Econofresh kit	7E774148	

◆ List of accessories

Name	Description	Code	Figure
PC-ART	Remote control switch with timer	70510000	
PSC-A64S	Central control	60291479	
PSC-A16RS	Centralized ON/OFF controller	60291484	
PSC-A1T	Programmable timer	60291482	

Name	Description	Code	Figure
PC-LH3A	Wireless remote control switch	60291056	
PC-ARH	Optional remote controller	60291486	
PC-ALH	Receiver kit (for RCI-FSN2E -on the panel-)	60291464	
PC-ALHD	Receiver kit (for RCD-FSN2- -on the panel-)	60291467	
PC-ALHZ	Receiver kit (for RCI, RCD, RPC, RPI, RPK, RPF(I) - (FSN2(E)) -on the wall-)	60291473	
PC-ALHC	Receiver kit (for RCIM-FSN2 -on the panel-)	60291476	Image not available
PSC-5HR	H-LINK relay	60291105	
PCC-1A	Optional function connector	60199286	
PRC-10E1	2-pin extension cord	7E790211	
PRC-15E1	2-pin extension cord	7E790212	
PRC-20E1	2-pin extension cord	7E790213	
PRC-30E1	2-pin extension cord	7E790214	
THM-R2AE	Remote temperature sensor (THM4)	7E299907	
HC-A32MB	Building Management System Gateway to MODBUS systems.	7E513200 	
HC-A16KNX	Building Management System Gateway to KNX systems.	7E513300 	

Name	Description	Code	Figure
HARC-BXE (A) HARC-BXE (B)	Building Management System Gateway to LONWORKS systems. (max. 64 IU, 8 parameters) Building Management System Gateway to LONWORKS systems. (max. 32 IU, 16 parameters)	60290874 60290875	
HC-A64BNP	Building Management System Gateway to BAC Net system.	60291569	
CSNET-WEB (v3)	Control System	7E891938	
TS001 WEB SCREEN	15-inch touch-screen display	7E891935	
PC-A-110	Integration of teams into H-LINK	7E519000	
HC-A160SMS	SMS alarm warning device	7E519100	
DBS-26	Drain discharge connection	60299192	
P-N23WA	Air panel for RCI-FSN2E	70530000	
P-N23WAM	Air panel for RCIM-FSN2E	60197160	
P-N23DWA	Air panel for RCD-FSN2E	60291574	
P-N46DWA	Air panel for RCD-FSN2E	60291575	

Name	Description	Code	Figure
B-23H4	Adapter for deodorant filter	60199790	
F-23L4-K	Antibacteria filter	60199791	
F-23L4-D	Deodorant filter	60199793	
F-46L4-D	Deodorant filter	60199794	
PDF-23C3	Duct connection flange	60199795	
PDF-46C3	Duct connection flange	60199796	
OACI-232	Fresh-air intake kit	60199797	
PD-75	Fresh-air intake kit	60199798	
PI-23LS5	3-way outlet parts	60199799	
TKCI-232	T-duct connecting kit	60199801	
MW-102AN	Branch pipe	70522001	
MW-162AN		70522002	
MW-242AN		70522004	
MW-302AN		70522005	
MH-84AN	Header	70522007	
MH-108AN		70522008	

Name	Description	Code	Figure
HR-500	Energy exchanger for KPI (heat recovery)	70550101	
HR-800		70550102	
HR-1000		70550103	
HR-1500		70550104	
HR-2000		70550105	
STL-30-200-L600	Sound attenuator (Heat/energy recovery)	70550200	
STL-30-250-L600		70550201	
STL-30-300-L600		70550202	
STL-30-355-L600		70550203	
STL-30-450-L600		70550204	

1. Units installation

This chapter provides information about the procedures you must follow to install the Set-Free FSN2 outdoor units.

Contents

1

1. Units installation	1
1.1 General installation notes	2
1.2 Transportation and handling	4
1.2.1 Hanging method	4
1.2.1 Center of gravity	7
1.3. Outdoor units installation	8
1.3.1 Before installation	8
1.3.2 Installation location	9
1.3.3 Serial units installation	10
1.3.4 Multiple installation space	11
1.3.5. Foundations	15

1.1 General installation notes

	warning
<p>Install the outdoor unit with sufficient clearance around it for operation and maintenance as shown in the next pages.</p> <p>Install the outdoor unit where good ventilation is available.</p> <p>Do not install the outdoor unit where exists a high level of oil mist, salty air or sulphurous atmosphere.</p> <p>Install the outdoor unit as far as practical (being at least 3 meters) from electromagnetic wave radiator, such as medical equipment.</p> <p>Keep clearance between units of more than 50 mm, and avoid obstacles that could hamper air intake, when installing more than one unit together.</p> <p>Install the outdoor unit in the shade or not exposed to direct sunshine or direct radiation from high temperature heat source.</p> <p>Do not install the outdoor unit in a place where a seasonal wind directly blows into the outdoor fan.</p> <p>For cleaning, use non-inflammable and nontoxic cleaning liquid. Use of inflammable agent may cause explosion or fire.</p> <p>Work with sufficient ventilation, for working in an enclosed space could cause oxygen deficiency. Toxic gas may be produced when cleaning agent is heated to high temperature by, e.g., being exposed to fire.</p> <p>Cleaning liquid shall be collected after cleaning.</p> <p>Pay attention not to clamp cables when attaching the service cover to avoid electric shock or fire.</p>	

	caution
<p>Check the foundation to be flat, leveled and strongly enough.</p> <p>Install the unit in a restricted area not accessible by the general public.</p> <p>Aluminium fins have very sharp edges. Pay attention to the fins in order to avoid injury.</p> <p>Do not install the indoor units in a flammable environment to avoid a fire or an explosion.</p> <p>Check to ensure that the ceiling slab is strong enough. If not strong enough, the indoor unit may fall down on you.</p> <p>Do not install the indoor units, outdoor unit, remote control switch and cable within approximately 3 meters from strong electromagnetic wave radiators, such as medical equipment.</p> <p>Do not install the indoor units in a machinery shop or kitchen, where vapor from oil or mist flows to the indoor units. The oil will deposit on the heat exchanger, thereby reducing the indoor unit performance, and may deform. In the worst case, the oil damages the plastic parts of the indoor unit.</p> <p>To avoid any corrosive action to the heat exchangers, do not install the indoor units in an acid or alkaline environment.</p> <p>When lifting or moving the indoor unit, use appropriate slings to avoid damage and be careful not to damage the insulation material on units surface.</p> <p>This appliances are not intended for use by people (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision and instruction concerning the use of the appliance by a person responsible for their safety.</p> <p>Turn OFF all power switches before maintenance is performed.</p> <p>Do not start the cleaning procedures before 5 minutes of the stop of the unit.</p>	

	warning
<p>Check and ensure that the accessories are packed with the indoor unit.</p> <p>Do not install the indoor units outdoors. If installed outdoors, an electric hazard or electric leakage will occur.</p> <p>Consider the air distribution from each indoor unit to the space of the room, and select a suitable location so that uniform air temperature in the room can be obtained. It is recommended that the indoor units be installed 2.3 to 3 meters from the floor level. If the unit is installed higher than 3 meters, it is also recommended to use a fan in order to obtain an uniform air temperature in the room.</p> <p>Avoid obstacles which may hamper the air intake or the air discharge flow.</p> <p>Children must be supervised to ensure that they do not play with the electrical appliances.</p> <p>Before obtaining access to terminals, all supply circuits must be disconnected.</p>	


warning

Pay attention to the following points when the indoor units are installed in a hospital or other places where there are electronic waves from medical equipment and similar.

Do not install the indoor units where electromagnetic wave is directly radiated to the electrical box, remote control cable or remote control switch.




Install the indoor units and components as far as practical or at least 3 meters from the electromagnetic wave radiator.

Prepare a steel box and install the remote control switch in it. Prepare a steel conduit tube and wire the remote control cable in it. Then connect the ground wire with the box and tube.

Install a noise filter when the power supply emits harmful noises.

This unit is exclusive non electrical heater type indoor unit. It is prohibited to install a electrical heater in the field.

Mount suspension bolts using M10 (W3/8) as size, as shown below:


Concrete Beam

Steel Beam

Wooden Beam

Do not put any foreign material into the indoor unit and check to ensure that none exist in the indoor unit before the installation and test running. Otherwise a fire or failure may occur.


Note

Hitachi indoor units are designed for free air discharge (Static Pressure, $P_{st}=0$), except ducted indoor units as RPIM, which require to be connected to discharge air ducts. For these units see flow-static pressure chart.

1

1.2 Transportation and handling

Transport the product as close to installation location as practical before unpacking.

	caution
- Do not put any material on the product.	


1.2.1 Hanging method

When hanging the unit, ensure a balance of the unit, check safety and lift up smoothly.

■ **For transportation**


- Do not remove any packing materials.
- Hang the unit without removing the packaging with ropes through each square hole and apply the splints or corrugated paper for unit protection

	DANGER
- Do not tie ropes at the wooden base..	




■ For installation RAS-(8~12)FSN2


- Remove the wooden base.
- Apply two (2) ropes on the splints or corrugated paper to protect the unit, and hang the unit as shown below



(Rope position)



■ For installation RAS-(14~24)FSN2

- Hang the unit without removing the packaging with four (4) ropes. Push through the wire ropes into the hang hole and clamp the wires by using shackle as shown below.




■ **For installation RAS-(26~42)FSN2**

- Hang the unit without removing the packaging with four (4) ropes. Push through the wire ropes into the hang hole and clamp the wires by using shackle as shown below.



■ **For installation RAS(44~48)FSN2**

- Hang the unit without removing the packaging with four (4) ropes. Push through the wire ropes into the hang hole and clamp the wires by using shackle as shown below.



 NOTES
<ul style="list-style-type: none"> - In case of transportation after removing wooden base, hang the unit as shown in figures above. - In case of transportation after unpacking, protect the unit with the splints or cloth.

 WARNING
<ul style="list-style-type: none"> - Do not put any foreign material into the outdoor unit and check to ensure that none exists in the outdoor unit before the installation and test run. Otherwise a fire or failure etc. may occur.


1.2.1 Center of gravity

■ **When using handles**


When manually lifting the unit using the handles, pay attention to the following: do not remove the wooden base from outdoor unit to prevent it from overturning, paying attention to the center of gravity as shown in the below figure. Two persons are needed to move this unit.

■ **FSN2**

Model: RAS-8-12FSN2




Model: RAS-14-24FSN2




Model	Dimension		
	X	Y	Z
RAS-14/16FSN2	850	630	365
RAS-18/20FSN2	780	605	345
RAS-22/24FSN2	755	600	335

Model: RAS-26-42FSN2



Model	Dimension		
	X	Y	Z
RAS-26/28FSN2	1635	630	345
RAS-30/36FSN2	1575	615	340
RAS-38/42FSN2	1465	600	325

Model: RAS-44-48FSN2



1.3. Outdoor units installation

	WARNING
<ul style="list-style-type: none"> – Install the outdoor unit with sufficient clearance around it for operation and maintenance as shown in the next figures. – Install the outdoor unit where good ventilation is available – Do not install the outdoor unit where is a high level of oil mist, salty air or sulphurous atmosphere. – Install the outdoor unit as far as practical (being at least 3 meters) from electromagnetic wave radiator (such as medical equipment). – Keep clearance between the units of more than 50 mm, and avoid obstacles that may hamper air intake, when installing more than one units together. – Install the outdoor unit in the shade or not exposed to direct sunshine or direct radiation from high temperature heat source. 	

	CAUTION
<ul style="list-style-type: none"> – Check to ensure that the foundation is flat, level and sufficiently strong. – Install the unit in a restricted area not accessible by the general public – Aluminum fins have very sharp edges. Pay attention to the fins to avoid injury. 	

	CAUTION
<p>Pay attention to the followings to run through the cables under the unit using conduit for piping and wiring works. (The pipe cover is required to remove before performing piping and wiring works.)</p> <ol style="list-style-type: none"> 1. Attach the pipe cover to avoid entering rats or other small animals into the unit. 2. Completely seal the conduit inlet with sealing materials. 3. Make a drain hole at the lowest part of the conduit. 	

1.3.1 Before installation


Before installation work, check the availability of the following parts that are packed inside the outdoor unit

Accessory	Quantity	Purpose
Flange gasket	1	Connection for refrigerant gas piping with RAS-10FSN2 to RAS-48FSN2
Pipe flange of refrigerant gas piping	1	
Pipe with flare nut for refrigerant gas piping (Ø19.05)	1	Connection for refrigerant gas piping with RAS-8FSN2
Pipe with flare nut for refrigerant liquid piping (Ø19.05)	1	Connection for refrigerant liquid piping with RAS-26FSN2 to RAS-48FSN2
Rubber Bush	2	For connection hole of operation wiring
	1	For connection hole of power source wiring
Screw	3	Spare

1.3.2 Installation location

■ Installation place

- Install the outdoor unit with a sufficient space around the outdoor unit for operation and maintenance as shown



- In case of no walls at the front and the rear side of the unit, the space of 500mm for the front side and 300mm for the rear side is required .
- When the front wall height is Min. 1,500mm, extend the distance to the wall more than $(500 + h2/2)$.
When the rear wall height is Min. 500mm, extend the distance to the wall more than $(300 + h1/2)$.
- When the distance to the obstacle above the unit is Max. 1,500mm or the space above the unit is closed, set up the duct at the air outlet to prevent the short-circuit .
- When there are walls around the unit, make the vent hole on the wall .
- When there are obstacles above the unit, the four (front, rear, right and left) sides of the unit shall be open in principle .
- Install the outdoor unit in a dry well ventilated environment .
- Install the outdoor unit where the sound or the discharge air from the outdoor unit does not affect neighbors or surrounding ventilation. The operating sound at the rear or right/left sides is 3 to 6dB(A) higher than the value in the catalog at the front side .
- Check to ensure that the foundation is flat, level and sufficiently strong .
- Do not install the outdoor unit where there is a high level of oil mist, flammable gases, salty air or harmful gases such as sulphur and an acid or alkaline environment .
- Do not install the outdoor unit where the electromagnetic wave is directly radiated to the electrical control box .
- Install the outdoor unit as far as possible, being at least 3 meters from the electromagnetic wave radiator .
- When installing the outdoor unit in snow-covered areas, mount the field-supplied hoods on the top of the outdoor unit and the inlet side of the heat exchanger.
- Install the outdoor unit where it is in the shade or it will


not be exposed to direct sunshine or direct radiation from high temperature heat source .

- Do not install the outdoor unit where dust or other contamination could block the outdoor heat exchanger .
- Install the outdoor unit in a space with limited access to general public .
- Do not install the outdoor unit in a space where a seasonal wind directly blows to the outdoor heat exchanger or a wind from a building space directly blows to the outdoor fan .


	CAUTION
<i>Aluminum fins have very sharp edges. Pay attention to the fins in order to avoid any injury.</i>	
	NOTE
<i>Install the outdoor unit on a roof or in an area where people, except service engineers, cannot touch the outdoor unit</i>	

Installation space for single unit

- Front side wall height: < 1500 mm
Rear side wall height: < 500 mm
- Front side wall height: > 1500 mm



Rear side wall height: > 500 mm





*1): $h1$ = Rear side wall height - 500 mm


*2): $h2$ = Front side wall height - 500 mm

1.3.3 Serial units installation

In case that the front and either of the sides are open.




In case that there is a surrounding wall.




1.3.4 Multiple installation space

Keep the upper side open to prevent air short-circuiting.

- In case that the front and either of the sides are open.
- Installation in the same direction




- Rear to rear installation




■ In case that there is a surrounding wall.


- Installation in the same direction




– Rear to rear installation (case 1)




– Rear to rear installation (case 2)



– Rear to rear installation (case3)





i Note:

- In case that the rear space is less than 1600 mm and the side space is less than 400 mm, apply a field-supplied fence for each unit.

1

Other models:


Model	Number of cabinets
RAS-8~12FSN2	1
RAS-14~24FSN2	2
RAS-26~42FSN2	3
RAS-44~48FSN2	3

i Note:

- For other models, the service space is the same as for 1 cabinet. See the table for the number of cabinets according to the Outdoor Unit model.


■ **Consideration to Seasonal Wind**

Avoid the installation that the air intake side (Rear) of the unit is faced directly against a seasonal strong wind.




■ **Consideration to Snow**

Apply an air discharge hood, an air intake hood and a higher foundation to prevent accumulation of snow on the air outlet and air inlet.



■ **Prevention of Short-circuiting**

For prevention of short-circuiting between suction air and discharge air, apply a field-supplied air discharge hood




NOTE:

Install the unit on a sunny place such as east or southside of the building rather than north side.


1.3.5. Foundations

■ Concrete foundations

- 1 The height of the foundation should be 100 to 300mm higher than the ground level.
- 2 Install a drainage around foundation for smooth drain.




1



- 3 Install the outdoor unit in the front-rear and right-left direction horizontally.

Check to ensure that the gradient in four directions (front, rear, right and left) is within 10mm.

- 4 Provide a strong and correct foundation so that;
 - a The outdoor unit is not on an incline.
 - b Abnormal sound does not occur.
 - c The outdoor unit will not fall down due to a strong wind or earthquake.





■ Drain water treatment

While heating or defrosting operation, drain water is discharged. Provide adequate drainage around the foundation. If installing the unit on a roof or a veranda, avoid draining in or over walkways to prevent water dripping on people or the formation of ice in winter. In case of installing such a place, provide the additional drainage around the foundation.



■ Position of anchor bolts

When installing the outdoor unit, fix the unit by anchor bolts. Refer to figure below regarding the location of fixing holes.



Model: RAS-8~12FSN2





Model: RAS-14~24FSN2



Model: RAS-26~42FSN2



Model: RAS-44~48FSN2



①	Power source connection
②	Control circuit connection
③	Refrigerant piping connection
④	Drain hole (Drain boss position (option))

⑤	Hole of anchor bolt (M12)
*	The dimensions marked with * indicates the mounting pitch dimension for anchor bolts.

2. Piping installation

Contents

2. Piping installation	17
2.1. Piping work considerations	18
2.1.1 Copper pipes and sizes	18
2.1.2 Three principles on refrigerant piping work	21
2.1.3 Suspension of refrigerant piping	21
2.1.4 Tightening torque	22
2.1.5 Brazing work	23
2.2. Outdoor units piping installation	24
2.2.1. Factory supplied accessories	24
2.2.2. Position of piping connections	25
2.2.3. Flange piping connection	26
2.2.4. Piping connection	27
2.2.5. Vacuum and refrigerant charge	28
2.2.6. Drain discharging boss	30

2

2.1. Piping work considerations

2.1.1 Copper pipes and sizes

1. Prepare locally-supplied copper pipes.
2. Select the piping size with the correct thickness and correct material which can have sufficient pressure strength. Use the table below to select the required pipe.


Nominal Diameter		Thickness (mm)	Copper type
(mm)	(in)		
6.35	1/4	0.80	Roll
9.53	3/8	0.80	Roll
12.70	1/2	0.80	Roll
15.88	5/8	1.00	Roll
19.05	3/4	1.00	Pipe
22.23	7/8	1.00	Pipe
25.40	1	1.00	Pipe
28.60	1 1/8	1.00	Pipe
31.75	1 1/4	1.10	Pipe
34.93	1 3/8	1.25	Pipe
38.10	1 1/2	1.35	Pipe
41.28	1 5/8	1.20	Pipe
44.45	1 3/4	1.55	Pipe



Note

- In case of using copper pipes for piping sections bigger than Ø 19.05 mm (3/4 inches), flaring work cannot be performed. If necessary, use a joint adapter.

3. Select clean copper pipes. Make sure there is not dust and moisture inside. Blow the inside of the pipes with oxygen free nitrogen to remove any dust and foreign materials before connecting the pipes.
4. After connecting the refrigerant piping, seal the open space between Knockout hole and refrigerant pipes by using insulation material as shown below:




caution

- Do not use a saw and a grindstone or other tools which cause copper powder.
- When cutting pipes, secure the part for brazing in accordance with both national and local regulations.
- Use security glasses and gloves for cutting or welding works.

■ Piping Connection


When connecting liquid piping for units with piping longer than 15 meters, apply a piping size of $\varnothing 9.53$ mm (3/8 inches).
Fix the connecting pipe as shown in the following figure using the insulation attached to the Indoor Unit.



2


	Note
<ul style="list-style-type: none"> - A system with no moisture or oil contamination will give maximum performance and lifecycle compared to a poorly prepared system. Take particular care to ensure that all copper piping is clean and dry internally. - To ensure this, blow oxygen-free nitrogen through the pipes. 	

	caution
<ul style="list-style-type: none"> - When inserting a pipe through any hole protect the end with a cap. - Do not put pipes on the ground directly without a cap or vinyl tape at the end of the pipe - If the piping installation is not completed until the next day or even over a longer period of time, braze off the ends of the piping and charge the pipe with oxygen-free nitrogen through a Schrader-valve-type access-fitting, to prevent moisture and particle contamination entering. - Do not use insulation material that contents NH3. NH3 can damage the cooper pipe material and can be a source of future leakages 	



• **Insulation**

Attach the pipe insulation to each branch using vinyl tape. Attach also insulation to field supplied pipes in order to prevent the capacity decrease according to the ambient air conditions and dewing on the low pressure pipe surface.






	Note
	<ul style="list-style-type: none">- When polyethylene foam is applied, it is recommended the usage of a wall thickness of 10 mm for the liquid piping and 15 mm to 20 mm for the gas piping.


	caution
	<ul style="list-style-type: none">- Perform the insulation work after the pipe surface temperature decreases to the room temperature, if not the insulation material may melt.- If the ends of the piping system are open after ending the piping work, attach caps or vinyl bags securely to the ends of the piping, avoiding moisture and dust entering.

2.2. Outdoor units piping installation

2.2.1. Factory supplied accessories

Accessory		Q'ty	Purpose
Flange gasket		1	Connection for refrigerant gas piping with RAS-10FSN2 to 48FSN2
Pipe flange of refrigerant gas piping		1	
Pipe with flare nut of refrigerant gas piping (Ø19.05)		1	Connection for refrigerant gas piping with RAS-8FSN2
Pipe with flare nut of refrigerant liquid piping (Ø19.05)		1	Connection for refrigerant liquid piping with RAS-26FSN2 to 48FSN2
Rubber bush	–	2	For connection hole of operation wiring
	–	1	For connection hole of power source wiring
Screw	–	3	Spare

2.2.3. Flange piping connection



Model	Figure	Dimensions (mm)				
		A	B	C	ØD (ID)	ØE (ID)
RAS-10FSN2 Gas	1	95	27	97	22.2	–
RAS-12FSN2 Gas	1	95	27	85	25.4	–
RAS-14FSN2 Gas	2	100	29	87	25.4	–
RAS-16~24FSN2 Gas	1	100	29	87	28.6	–
RAS-26~34FSN2 Gas	2	135	34	116	31.75	34.92
RAS-36~48FSN2 Gas	4	135	34	116	38.10	41.30

i **NOTE**

- For connecting the lower piping diameter for the Outdoor Units having two piping dimensions, cut off the end part of pipe flange (factory supplied), which is for connecting the higher piping diameter.
- If it is necessary, use the reducer.


6.2. Test run procedure from the outdoor unit side

The test run procedure from the outdoor unit side is shown below. You can set this DIP switch while the power source is ON

Setting of Dip Switch (before shipment)

DSW4		
1	Test run	
2	COOL/HEAT setting (ON: Heating operation)	
3	OFF (mixed)	
4	Manual compressor OFF	
5	Number of indoor units is more than 16 OFF (Fixed)	
6	Compressor exchange operation	

Printed circuit board of the outdoor unit (PCB1)



Warning:

- Do not touch any other electrical components while you are setting the switches on the PCB.
- Do not attach or detach the service access panel when the power source for the outdoor unit is ON and the outdoor unit is operating.
- Set all the DIP switches of DSW4 to OFF after completing the test run.

	Dip switch setting	Operation	Remarks
Test run	<p>1. Setting operation mode</p> <p>Cooling: Set DSW4-2 OFF</p> <p>Heating: SET DSW4-2 ON</p> <p>Starting the test run: Set DSW4-1 at ON. The operation starts after 20 s. In case of heating process, leave DSW4-2 at ON</p>	<ul style="list-style-type: none"> - The indoor unit automatically starts to operate when the test run of the outdoor unit is set. - You can perform the ON/OFF operation from the remote control switch or the DSW4-1 of the outdoor unit. - Continuous operation during 2 hours is performed without the Thermo-OFF condition. 	<ul style="list-style-type: none"> - Make sure that the indoor units start to operate in accord with the test run of the outdoor unit. - If you start the test run from the outdoor unit and you stop the test run from the remote control switch, the test run function of the remote control switch is cancelled. However, the test run function of the outdoor unit is not cancelled. - Check to ensure that the DSW4-1 of the outdoor unit PCB is turned OFF. - If the more than one indoor unit is connected with one remote control switch, all the units start the test run at the same time. Therefore, turn OFF the power source so that the indoor units do not perform the test run. If this is the case, the TEST RUN indication of the remote control switch may flicker. This is not abnormal. <ul style="list-style-type: none"> - The setting of DSW4 is not required for the test run from the remote control switch.
Manual compressor OFF	<p>Setting the compressor manually OFF: Set DSW4-4 at ON</p> <p>ON: Set DSW4-4 at OFF</p>	<ul style="list-style-type: none"> - When DSW4-4 is ON during the compressor operation, the compressor stops operating immediately and the indoor unit is under the Thermo-OFF condition. - When DSW4-4 is OFF, the compressor starts to operate after the cancellation of the 3-minute guard. 	<ul style="list-style-type: none"> - Do not turn ON and OFF the compressor frequently
Manual defrost	<ul style="list-style-type: none"> - Manual defrost operation starts. Press the PSW1 for more than three seconds during the heating process. The defrost operation starts after two minutes. This function is available once the heating process has been running for five minutes. - Manual defrost operation finishes. The defrost operation automatically finishes and the heating process starts. 	<ul style="list-style-type: none"> - The defrost operation is available regardless of the frosting conditions and the total time of the heating process. - The defrost operation is not performed when the temperature of the outdoor heat exchanger is higher than 10°C, the high pressure is higher than 2.0MPa or under the Thermo-OFF condition. 	<ul style="list-style-type: none"> - Do not repeat the defrost operation frequently. - When the PSW1 accepts the manual defrost operation, the remaining time before starting the defrost operation is displayed at the 7-segment display on the PCB. <p>Remaining time (every 4 seconds)</p>

6.3. Check list

■ Check list on test run

Client:		Installer:			Date:		
Outdoor unit model:		Outdoor unit serial No.:			Checker:		
Indoor unit model:							
Indoor unit serial No.							

Piping length [m]	
Additional refrigerant charge [kg]	

1. General

No.	Check item	Result
1	Was the DIP switch DSW6 for the piping length in the outdoor unit set?	
2	Was the DIP switch DSW3 for the piping lift in the outdoor unit set?	
3	Are the power supply wires of the transmission cable making contacts on the piping?	
4	Was a ground wire connected?	
5	Is there any short circuit?	
6	Is there any voltage malfunction among the different phases (L1-L2, L2-L3, L3-L1, L1-N)?	

2. Refrigerant cycle

a. Cooling/heating process

No.	Check item	Result
1	Operate all the indoor units. (TEST RUN mode).	
2	Operate all the indoor units at the "HIGH" speed.	
3	If you turn ON and OFF the constant speed compressor repeatedly, stop one indoor unit (an indoor unit with a small capacity).	

b. Sampling data (cooling/heating process: if the indoor temperature is between 21°C and 30°C)

No.	Check item	Result
1	After operating for more than 20 minutes.	
2	Check Pd. and Td. Is TdSH 15 to 45 degrees?	
3	Is Ps 0.2 to 1.1?	
4	Is Pd 1.0 to 3.5? (If the outdoor temperature is high, the Pd. becomes high.)	

3. Check item after sampling data

a. Cooling process (if the outdoor temperature is higher than 15 °C)

No.	Check item	Standard	Causes	Result
1	Is $H1$ (compressor frequency) + $(CC$ (number of running compressors) - 1) \times (※) abnormally low or high? (It is applicable when the inlet air temperature is three degrees higher than the setting temperature).	Running horsepower of the indoor units \times 8Hz	<ul style="list-style-type: none"> - Low: excessive refrigerant; - High: insufficient refrigerant; - DSW for capacity of indoor units: Incorrect setting. 	
2	Is the fan actually running when Fo (airflow rate of fan) is other than "0" (5~32) or "16" (36~48)?	—	Failure of the fan motor; Failure of the PCB; Failure of the condenser.	
3	Is the $Td1$ higher than $Td2$ - $Td5$ when only the compressor No.1 is running (when CC (number of running compressors) is 「1」)?	—	Incorrect connection or incorrect mounting of the Td thermistor.	
4	Is the total of iE (indoor expansion valves opening) abnormally low or high?	Total % of iE : horsepower of the outdoor unit \times (0.7 to 1.5).	Low: excessive refrigerant; High: insufficient refrigerant, excessive pipe resistance.	
5	Is TL (liquid pipe temperature of the heat exchanger of the indoor unit) lower than Ti (air inlet temperature of the indoor unit)?	It is normal when $TL - Ti < -5$ deg.	Failure of the TL thermistor; Fully closed I.U. expansion valve; Short circuit.	
6	Is TG (gas pipe temperature of the heat exchanger of the indoor unit) lower than Ti (air inlet temperature of the indoor unit.)?	It is normal when $TG - Ti < -5$ deg.	Failure of the TG thermistor; Fully closed expansion valve or slightly open I.U. expansion valve; Short circuit.	
7	Is there any excessive difference among indoor units at $SH(TG - TL)$ of the heat exchanger of the indoor units? (It is applicable when the inlet air temperature is three degrees higher than the setting temperature.)	It is normal if the difference among units is within 3 - 7 deg. lower than other units.	Failure of the TL/TG thermistor; Fully open expansion valve, slightly open expansion valve or fully closed expansion valve.	
8	Is there any excessive different among indoor units at $SH(TG - TL)$ of the heat exchanger of the indoor units and is iE lower than 「7」? (It is applicable when intake air temp. is 3 deg. higher than setting temp.	It is normal if SH is within 3 deg. lower than other units.	Expansion valve locked in fully open position; The refrigerant cycle number does not match; Mismatched between wiring and piping.	
9	Is there any indoor unit with $SH(TG - TL)$ excessively lower than the value of other units, under the condition of IE (indoor unit expansion valve) 「100」?	It is normal if SH is within 3 deg. higher than other units.	Expansion valve locked in slightly open position or closed expansion valve; The refrigerant cycle number does not match; Mismatched between wiring and piping.	
10	Is the temperature difference between I.U.* more than 7 deg.? * The temperature difference between I.U. means the following; b3 (Discharge Air Temp.) - b2 (Intake Air Temp.) indicated on the remote control switch by check mode.	—	—	

b. Heating process (if the outdoor temperature is higher than 0 °C)

No.	Check item	Standard	Causes	Result
1	Is oE1, oE2 (outdoor unit expansion valves opening) abnormally low or high when TdSH is 15 to 45 degrees? (The higher the operating frequency, the higher the oE1).	Total of oE1, oE2: total frequency of compressor x 0.2 to 0.6	Low: excessive refrigerant; High: insufficient refrigerant.	
2	Is Pd <u>1.6</u> to <u>3.5</u> ? (Pd is high when the indoor temperature is high).		Low: leakage of the SVA (solenoid valve); High: excessive gas pipe resistance.	
3	Is H1 (compressor frequency) + (CC (number of running compressors) - 1) (※) abnormally low or high? (The lower the room temperature and the outdoor temperature, the higher the above value).		Low: excessive refrigerant; High: insufficient refrigerant, excessive pipe resistance.	
4	Is Ps <u>0.2</u> to <u>1.1</u> ? (Only under the condition that the solenoid valve (SVB) is OFF).		Low: short circuit of the outdoor unit; Low/High: failure of the following components: outdoor fan, motor, fan module, DC remote control or outdoor air sensor.	
5	Is the temperature difference among the indoor units* more than 15 degrees when iE (indoor unit expansion valve) is 100? *The temperature difference among the indoor units means the following: b3 (Discharge Gas Temperature) - b2 (air inlet temperature) that is displayed on the remote control switch by means of the check mode. However, this is applicable only when b2 (Air Inlet Temperature) - b1 (setting temperature) is higher than three degrees.		Failure of components such as the PCB, the wiring, the coil, the valve; Excessive pipe resistance; Failure of the thermistor for the discharge air temperature.	


NOTES:

1. The symbol with an underline indicates a check item. The mark indicates the checking data.
2. Regarding the mark (※) (converted frequency of constant compressor), you should apply the following values.

For FSN2

Outdoor Unit Model	Mark (※)			
	MC2	MC3	MC4	MC5
RAS-14 and 16FSN2	50	–	–	–
RAS-18 and 20FSN2	50	50	–	–
RAS-22 and 24FSN2	50	77	–	–
RAS-26 and 28FSN2	77	77	–	–
RAS-30 to 36FSN2	77	77	50	–
RAS-38 to 42FSN2	77	77	50	77
RAS-44 to 48FSN2	77	77	77	77


6.4. Judgement systems for refrigerant amount

6.4.1. Automatic judgement system for refrigerant amount

This function is available under the following conditions:

- Total piping length is 300 m or more.
- The indoor and outdoor air temperature is within the applicable range as shown in the figure:

Before performing this function, charge the additional refrigerant according to the total piping length. However, this function can not be utilized for judgement of excessive refrigerant and combined the indoor unit of 8HP or more.



◆ Procedure of judgement for refrigerant charge amount

1. Check to ensure that all of indoor units is turned OFF.
2. Turn ON No. 6 pin of DSW5 on the outdoor PCB (PWB1). When starting judgement, all of indoor units are operated at cooling mode.




i NOTES:

This function is automatically judged at the cooling mode. At heating mode, this function is not available. Check to ensure that the indoor and outdoor air temperature is within the applicable range.


◆ Contents of judgement for refrigerant charge amount

During the judgement operation, the 7-segment display is changed according to the operating condition.



Result	7-segment Indication	Remarks
Sufficient Refrigerant	End	The refrigerant amount is sufficient. However, check to ensure that it is possible to indicate the same judgement in case of the excessive refrigerant.
Insufficient Refrigerant	Ch. Lo	The refrigerant amount is insufficient. After charged measure of 3% or less of additional refrigerant, perform the refrigerant amount judgement again.

i NOTES:

1. This function is utilized in case of insufficient refrigerant only, not utilized in case of the excessive refrigerant and the total piping length 300m or more.
2. During the refrigerant amount judgement, the 7-segment display  is flickered and the judgement operation is forced termination. The causes of forced termination are following. After resolved the cause of forced termination, restart the refrigerant amount judgement again.
 - a) When turned ON the power supply, the automatic address setting operation is performed at the same time. During this time, No. 6 pin of DSW5 is turned ON.
 - b) Before turned ON No. 6 pin of DSW5, other indoor unit has been operated.
 - c) The indoor cooling load is decreased and the total of indoor units capacity is 30% or less of the outdoor unit capacity.

- d) No. 1 or No. 4 pin of DSW4 is ON.
 e) At starting the judgement system operation for the refrigerant amount, the indoor and outdoor air temperature is beyond the applicable range.
 f) The refrigerant cycle is varied widely.

In case except a) to e), it may be impossible to utilize the judgement because that the refrigerant cycle is varied widely. This is due to the installation condition by lower indoor heat load, etc. In this case, calculate the additional refrigerant according to the total piping length.

3. It takes about 20 to 120 minutes for the automatic refrigerant amount judgement operation.
4. The 7-segment indication during the refrigerant amount judgement is changed to the protection control code by the protection control, it is not abnormal. As for the protection control code, refer to the sheet attached to the inside of the outdoor unit service cover.

6.4.2. Simple judgement system for refrigerant amount

You can check the excess or the deficiency of the refrigerant by means of the data that is provided by the check mode of the 7-segment display. The following checking procedure is useful during the test run and the maintenance.

◆ Before the checking procedure:

1. Operate all the indoor units at the TEST RUN mode and operate all the indoor units at the HIGH speed.
2. Check the following items in order to make sure that the refrigerant cycle is stable.
 - 1) The continuous operation lasts more than 20 minutes.
 - 2) Td-SH is 25 to 45 °C in cooling or 15 to 45 °C in heating
 - 3) Ps is 0.4 to 1.1 MPa in cooling or 0.2 to 1.1 MPa in heating
 - 4) Pd is 2.0 to 3.5 MPa in cooling or 1.6 to 3.5 MPa in heating

Td-SH: Discharge gas temperature superheat

Ps: Suction pressure, Pd: Discharge pressure

3. Collect the checking data that is provided by the check mode of the 7-segment display.
4. Perform the checking according to the following procedure.

Judge according to the following target value:

Cooling	Refrigerant flow charge is controlled by indoor unit expansion valve
Heating	Refrigerant flow charge is controlled by outdoor unit expansion valve

Applicable air temperatures for the checking procedure:

Cooling	Room temperature: 20°C~30°C (DB) Outdoor temperature: 15°C (DB) or more
Heating	Room temperature: 20°C~30°C (DB) Outdoor temperature: 0°C~15°C (DB)

◆ Checking procedures for cooling

◆ Process

1. Convert iE (indoor unit expansion valve opening) with the following table:

Indoor Unit HP	Conversion
0.8 to 6 HP	iE
8 and 10 HP	iE × 2.0

2. Sum up the converted values of iE.

3. Calculate the total frequency (=H1(Inverter frequency)+Constant compressor reduced frequency) according to the following table:

Outdoor Unit Model	Converted frequency of constant speed compressor			
	MC2	MC3	MC4	MC5
RAS-14/16FSN2	50	–	–	–
RAS-18/20FSN2	50	50	–	–
RAS-22/24FSN2	50	77	–	–
RAS-26/28FSN2	77	77	–	–
RAS-30~36FSN2	77	77	50	–
RAS-38~42FSN2	77	77	50	77
RAS-44~48FSN2	77	77	77	77

◆ Judgement

- If total of converted \underline{iE} /Total frequency < 0.7 = Insufficient refrigerant
- If total of converted \underline{iE} /Total frequency > 1.6 = Excessive refrigerant

◆ Checking procedures for heating


◆ Process

1. Detect oE (total outdoor unit expansion valve opening) = oE1+oE2+oE3+oE4
2. Calculate the total frequency (=H1(Inverter frequency)+Constant compressor reduced frequency) according to the previous table:

◆ Judgement

- If total oE/Total frequency < 0.8 x Target value = Insufficient refrigerant
- If total oE/Total frequency > 1.2 x Target value = Excessive refrigerant

Refer to the following table to use the target value in heating.



◆ Examples

◆ Cooling process

	Indoor units				
	4HP	4HP	4HP	2HP	2HP
\underline{iE} (%) (from the checking data)	32	38	30	20	18
Calculate value of \underline{iE}	32 (Hold)	38 (Hold)	30 (Hold)	20 (Hold)	18 (Hold)
Total of \underline{iE} (a)	138 (32+38+30+20+18)				
Total frequency (b)	130 (80+50 (constant comp. frequency))				
Judgement	OK: $0.7 \leq (a) / (b) \leq 1.6$				

◆ Heating process

	Indoor units					Outdoor unit
	4HP	4HP	4HP	2HP	2HP	16HP
\underline{Ti} (indoor suction temperature)	26	27	23	23	25	–
\underline{To} (outdoor temperature) (°C)						7
Total of oE (a)	–					
Total of frequency (b)	130 (80+50 (constant comp. frequency))					
Judgement	OK: (a) / (b) $\approx \pm 20\%$ of target value					

7. Troubleshooting

Contents

7. Troubleshooting	93
7.1.2. Emergency operation	95
7.1.3. Failure of the power supply to the indoor unit and the remote control switch	101
7.1.4. Abnormal transmission between the remote control switch and the indoor unit	102
7.1.5. Abnormal operation of the devices	103
7.2. Troubleshooting procedure	111
7.2.1. Alarm code indication of remote control switch	111
7.2.2. Troubleshooting by alarm code	113
7.2.3. Troubleshooting in check mode	158
7.2.4. Troubleshooting by means of the 7 segment display	164
7.2.5. Running current of the compressor	170
7.2.6. Protection control code on the 7-segment display	172
7.2.7. Activating condition of the protection control code	173
7.3. Procedure for checking each main part	175
7.3.1. Self-checking procedure of PCB by means of the Remote Control Switch	175
7.3.2. Self-Checking procedure of the Remote Control Switch	177
7.3.3. Self-Checking procedure of the Indoor Unit PCB (only for RPK)	179
7.3.4. Procedure of checking other main parts	180

7.1. Initial troubleshooting

7.1.1. Checking by means of the 7-segment display

■ Simple checking procedure by means of the 7-segment display

1. Turn on all the indoor units which are connected to the outdoor unit.
2. Turn on the outdoor unit
3. Auto-addressing starts. (Outdoor unit printed circuit board PCB 1)

During the auto-addressing, you can check the following items by means of the 7-segment display of the outdoor unit.

- Disconnection of the power supply to the Indoor Unit.
- Duplication of the Indoor Unit number. See alarm code 35

Normal case:

The 7-segment display of the outdoor unit is not indicated.

Abnormal case:

If there is something wrong, the 7-segment display of the outdoor unit displays the following indications:

Cause	Indication	Remarks
a. The indoor units are not supplied with power.	03	continues to flash after 30 seconds.
b. Disconnection of the operating line between the outdoor units and the indoor units.	03	continues to flash after 30 seconds.
c. Duplicated settings of the indoor unit number on the rotary switch RSW (Refer to the section "Troubleshooting by means of the Alarm Code" for the description of the alarm code "35").		

7.1.2. Emergency operation


■ Emergency mode operation (RAS-14FSN2 to RAS-48FSN2 Only)

1. Emergency mode operation from Remote Control Switch

If compressor/fan motor is failed, emergency operation mode is available to change from the remote control switch. Even if the compressor is failed, the air conditioning operation is continuously available until the troubleshooting is performed.

Alarms corresponding to emergency operation (*)

- Inverter compressor failure
 - 06: Abnormality of inverter voltage
 - 23: Failure of discharge gas thermistor
 - 48: Inverter overcurrent protection activation
 - 51: Failure of inverter current sensor
 - 53: Transistor module protection activation
 - 54: Failure of inverter fin thermistor
- Constant speed compressor failure
 - 23: Failure of discharge gas thermistor
 - 39: Abnormality of running current at constant speed compressor
- Outdoor fan motor failure
 - 56 to 58: Abnormal outdoor fan operation



a. Procedure

By pressing “TEMP.” for 3 seconds simultaneously, emergency mode operation starts. “EMG” can be displayed on the LCD during this operation.

b. Operation Condition


- Inverter compressor failure
Emergency operation is performed by other compressors (except inverter compressor) when the inverter compressor is failed.

The compressor is forced to stop for compressor protection under the following condition:

- Total capacity of thermo ON I.U. < 50% of O.U. Capacity and
- Total capacity of thermo ON I.U. < 10HP

- Constant speed compressor failure
Emergency operation is performed by other compressors (except failure compressors).
- DC fan motor failure
Emergency operation is performed by other DC fan motor (except failure DC fan motor).

PC-ART



NOTES:

- Emergency operation is available only when all the indoor unit and remote control to be connected are for H-LINK II.
- Emergency operation is available only for when the alarm codes above (*) are indicated.
- The emergency operation does not correspond to the failures of inverter PCB or fan controller.
- This operation is an emergency but a temporary operation until the service people comes. If the alarm is indicated again during the emergency mode operation, the alarm cannot be canceled.

2. Emergency mode operation from PCB for inverter compressor failure

This operation is an emergency operation by the constant speed compressor when the inverter compressor is failed.

Alarms corresponding to inverter compressor failure


- 04: Abnormality of inverter transmitting
- 06: Abnormality of inverter voltage
- 23: Failure of discharge gas thermistor
- 48: Inverter overcurrent protection activation
- 51: Failure of inverter current sensor
- 53: Transistor module protection activation
- 54: Failure of inverter fin thermistor

a). Procedure

1. Turn OFF all the main switches of outdoor and indoor units.
2. Check the inverter PCB. If inverter PCB is faulty, disconnect the wiring (U, V, W) of diode module. (Insulate the disconnected terminals.)
3. Turn ON DSW5-#1 of outdoor unit PCB1.
4. Turn ON the power supply.
5. Start the operation by remote control switch.

b). Operation condition

- Indoor unit operation capacity
The compressor is forced to stop for compressor protection under the following condition:
 - Total capacity of thermo ON I.U. < 50% of O.U. Capacity, and
 - Total capacity of thermo ON I.U. < 10HP
 (Small capacity of thermo ON indoor unit may cause a constant speed compressor failure because the compressor is operated and stopped repeatedly.)



- i NOTES:**
- Measure the insulation resistance of inverter compressor.
Do not perform the emergency operation when the insulation resistance is 0 Ω
Other compressor may be damaged because there is a possibility that refrigerant oil may be oxidized.
 - Total operating capacity of indoor unit should be 10HP and over.
(Less than 10HP: Forced stoppage)
 - In this emergency operation, compressor frequency cannot be controlled at each 1 Hz.
Therefore, alarm code "07", "43", "44", "45", "45" or "47" may be indicated on LCD.
 - This emergency operation does not provide sufficient cooling and heating capacity.
 - This method is an emergency but a temporary operation when the inverter compressor is damaged. Therefore, change the new one as soon as possible.
 - Turn OFF DSW5 of outdoor PCB1 after replacing the compressor.
If this setting is not performed, the inverter compressor will be damaged.

3. Emergency mode operation from PCB for constant speed compressor failure

This operation is an emergency operation by the other compressor when the constant speed compressor is failed.


Alarms corresponding to constant speed compressor failure

- 23: Failure of discharge gas thermistor
- 39: Abnormality of running current at constant speed compressor

a Procedure

1. Turn OFF all the main switches of outdoor and indoor units.
2. Turn ON DSW5 of outdoor PCB1 as shown in the table below.
3. Turn ON the power supply.
4. Start the operation by remote control switch.

DSW5	Compressor	HP
1	Inverter Compressor	14-48HP
2	Constant Speed Compressor 1	14-48HP
3	Constant Speed Compressor 2	18-48HP
4	Constant Speed Compressor 3	30-48HP
5	Constant Speed Compressor 4	42-48HP



b. Operation Condition

- Td Thermistor

Td thermistor on the failure constant speed compressor is ignored by setting DSW5. If the thermistor is short-circuited, this operation is available.




NOTES:

- Measure the insulation resistance of constant speed compressor.
Do not perform the emergency operation when the insulation resistance is 0 Ω
Other compressor may be damaged because there is a possibility that refrigerant oil may be oxidized.
- In this emergency operation, compressor frequency cannot be controlled at each 1 Hz. Therefore, alarm code "07", "43", "44", "45", "45" or "47" may be indicated on LCD.
- This emergency operation does not provide sufficient cooling and heating capacity.
- This method is an emergency and temporary operation when the constant speed compressor is damaged. Therefore, change the new one as soon as possible.
- Turn OFF DSW5 on outdoor PCB1 after replacing the compressor.
If this setting is not performed, the constant speed compressor will be damaged.

■ **Method of collecting refrigerant**

1 In case that compressor operates

Perform only when collecting refrigerant is required.

Process No.	Procedure	Remarks
1	Turn OFF the main switch of O.U.	
2	Connect manifold to the check joint at low and high pressure sides in O.U.	
3	Turn ON the main switch of O.U.	
4	<In case of comp. failure> DSW5 ON (O.U. PCB1), so that the failure comp. will not run.	Refer to (2) and (3) of "Emergency Mode Operation from PCB" in "Emergency Mode Operation" (item 1.1.4) for more details.
5	Pre-refrigerant collection during cooling operation. <ul style="list-style-type: none"> - Start the test run by DSW4-#1 ON (O.U. PCB1). - The test run should run for approx. 20min. (until $P_s > 0.3\text{MPa}$, $T_d > 75^\circ\text{C}$) - P_s is indicated on 7-seg. (O.U. PCB1). - Close the gas valve immediately and perform the forced stoppage (DSW4-#4 ON) when $P_s < 0.2\text{MPa}$. - Cancel cooling operation (DSW4-#1 OFF). - Cancel the forced stoppage (DSW4-#4 OFF). 	After closing the gas stop valve, the decrease of P_s value is fast. To guarantee the reliability of the comp., make sure that the decrease does not reach $P_s < 0.1\text{MPa}$ when performing the forced stoppage.
6	Perform the operation for exchange comp. <ul style="list-style-type: none"> - Close all the gas stop valves. - Press PSW3 for 3 sec. after DSW4-#6 ON (O.U. PCB1) (cooling operation starts). 	This operation is performed up to a maximum of 10 min. If the inverter comp. is excluded, the operation starts after 3 min.
7	Finish the operation for exchange comp. (<u>one of the followings</u>): <ul style="list-style-type: none"> - 10 min. has passed. ("STP" (7-seg.) is indicated.) - "08" (7-seg.) is indicated. - When $P_s \leq 0.1\text{MPa}$ (1 min. continuously) within 10 min., "STP" (7-seg.) is indicated. 	
8	Close the liquid stop valve completely.	To avoid the spillage and leakage of refrigerant when the check valve is broken.
9	Check the leakage of the check valve on the discharge gas side. <ul style="list-style-type: none"> - DSW4-#4 ON (the comp. forced stoppage). The comp. will not run regardless of the remote control switch command. - Check the variation of P_s. Make sure that the P_s increase is within 0.03MPa for 2 min. after the P_s increase at the stoppage. (approx. 5 min.) Make sure that $P_d > P_s$ at this time.+  	<ul style="list-style-type: none"> - When performing by the comp. replacing mode, leakage of the check valve can be checked by P_s variation because SVA opens so that the discharge gas side of inverter comp. is connected to the lower pressure side. - Within $0.03\text{MPa}/2\text{ min.}$ is the permissible limits for the check valve on the discharge gas side. - The leakage of the check valve may cause an incorrect brazing due to the gas pressure at the brazing of the discharge piping. - If the comp. replacing mode is performed again, set DSW4-#4 to OFF side and start from Process No. 4 after 10 min.
10	Collect the refrigerant according to either A or B: (depending on the Process No.9.) A) If the leak rate at the Process No.9 is within the specification, collect the refrigerant only at the low pressure side. B) If the leak rate at the Process No. 9 is greater than the specification, collect all the refrigerant of the O.U. side by the collector.	<ul style="list-style-type: none"> - The discharge of the refrigerant in the atmosphere is strictly forbidden. Make sure that the refrigerant is collected by the collector. - Measure the quantity of the collected refrigerant. - In case of B, perform (2) of "In case that compressor does not operate" in "Method of Collecting Refrigerant".
11	After collecting the refrigerant, remove the low pressure side charge hose at the collector side, so that the low pressure side of the refrigerant cycle will be the atmosphere pressure.	<ul style="list-style-type: none"> - Make sure that there is no pressure increase of the low pressure sides after collecting the refrigerant. - Make sure that the refrigerant cycle is the atmosphere pressure. Otherwise, problems such as the blowing of gas and the suction of the cutting material may occur when removing the comp.
12	Turn OFF the main switch of the O.U.	

Process No.	Procedure	Remarks
13	In case collecting refrigerant oil in oil separator is required: - Connect the charge hose to the charge port of return oil circuit. - Take out the refrigerant oil from the charge hose at the release side to the oil pan. - If there is no refrigerant oil in the charge hose at the release side, it may remain in the oil separator. - Apply pressure gradually with nitrogen gas from the check joint at low pressure side, push the refrigerant oil in the oil separator with the pressure and take it out from charge hose at the release side.	- This work is necessary for replacing comp. and return oil circuit. - Measure the collected refrigerant oil quantity. - Check that no refrigerant oil remains in the oil separator when replacing the oil return circuit. The refrigerant oil may leak from the removing part of flare nut if the procedure on the left may not be followed. - If the refrigerant at the high pressure side remains, pressure from check joint at low pressure side should be applied lower than the one from check joint at high pressure side.
14	Perform replacing comp., return oil circuit and electrical parts.	Removing electrical box may be required.
15	With the electrical box mounted, check the wirings by contacting (except the power line for comp.) For the power line for comp., insulate the wiring terminal with vinyl tape.	
16	Turn ON the main switch of O.U.	This process is before removing or after mounting the electrical box.
17	Turn DSW4-#4 ON of O.U. PCB1	
18	Turn DSW4-#6 ON of O.U. PCB1	Power supply is ON, auto-address setting is completed and then "STP" is flashed on 7-seg. (O.U. PCB1). SVA is ON (open).
19	Charge the refrigerant oil. Perform the vacuuming from the check joint at low and high pressure sides. Connect the charge hose to the charge port of return oil circuit and charge the refrigerant oil.	- Calculation for recharge quantity of refrigerant is required if process No.12 is performed. (Refer to the item "Removing compressor" for calculating method.) - Use a clean charge hose. - Use a container with a small opening so that the refrigerant oil does not absorb the moisture in the atmosphere. - If the refrigerant oil is not clean, it should be changed as new one.
20	Disconnect the charge hose from the charge port of return oil circuit. Perform the vacuuming from the check joint at low pressure side.	In case of collecting refrigerant at only low pressure side in process No. 9: Vacuuming cannot be performed from high pressure side.
21	Turn OFF the main switch of O.U.	
22	Set DSW4-#4, 6 back to the original setting.	Refer to Process No. 17 and 18.
23	Check that the power line for comp. and wirings are connected correctly.	Check the main switch is OFF.
24	Recharge the collected refrigerant (process No.10) from the check joint at high pressure sides. For the remained refrigerant quantity: Open the liquid and gas stop valves completely and set DSW4-#1 to ON side (O.U. PCB1). Then recharge it from the liquid stop valve check joint during cooling operation.	
25	Check the liquid and gas stop valves are open completely.	

O.U.: Outdoor Unit
 I.U.: Indoor Unit
 7-Seg.: 7-Segment
 Comp.: Compressor

2 In case that compressor does not operate

Perform only when collecting refrigerant of outdoor unit is required.
(Perform the replacing compressor and oil return circuit if necessary.)

Process No.	Procedure	Remarks
1	Turn OFF the main switch of O.U.	
2	Connect manifold to the check joint* at low and high pressure sides of O.U.	* Not the check joint of liquid/gas stop valves.
3	Close the liquid and gas stop valve completely.	To improve the performance of vacuuming.
4	(Work 1: Collecting refrigerant in O.U.) – Collect the refrigerant from <u>check joint at high and low pressure sides</u> using the collector. (Work 2: Collecting refrigerant oil in oil separator) – Collecting refrigerant oil in oil separator: – Connect the charge hose to the charge port of return oil circuit. – Take out the refrigerant oil from the charge hose at the release side to the oil pan. – If there is no refrigerant oil in the charge hose at the release side, it may remain in the oil separator. – Apply pressure gradually with nitrogen gas from the check joint at low pressure side, push the refrigerant oil in the oil separator with the pressure and take it out from charge hose at the release side.	– The discharge of the refrigerant in the atmosphere is strictly forbidden. Make sure that the refrigerant is collected by the collector. – Measure the quantity of the collected refrigerant and refrigerant oil. – For the replacing comp. and return oil circuit: Perform Work 1 firstly and then Work 2. – Measure the collected refrigerant oil. – Check that no refrigerant oil remains in the oil separator when replacing the return oil circuit. The refrigerant oil may leak from the removing part of flare nut if the procedure may not be followed.
5	Remove charge hose at the low and high pressure sides check joint, so that the low pressure side of the refrigerant cycle will be the atmosphere pressure. Disconnect the charge hose at charge port of return oil circuit.	– Make sure that there is no pressure increase of the low pressure side after collecting the refrigerant. – Make sure that the refrigerant cycle is the atmosphere pressure. Otherwise, problems such as the blowing of gas and the suction of the cutting material may occur when removing the comp.
6	Perform replacing comp., return oil circuit and electrical parts.	Removing electrical box may be required.
7	With the electrical box mounted, check the wirings by contacting (except the power line for comp.) For the power line for comp., insulate the wiring terminal with vinyl tape.	
8	Turn ON the main switch of O.U.	This process is before removing and mounting electrical box.
9	Set DSW4-#4 to ON side (O.U. PCB1).	
10	Set DSW4-#6 to ON side (O.U. PCB1).	Power supply is ON, auto-address setting is completed and then "STP" is flashed on 7-seg. (O.U. PCB1). SVA is ON (open).
11	Charge the refrigerant oil. (For Process No. 4-Work 2) Perform the vacuuming from the check joint at low and high pressure sides. Connect the charge hose to the charge port of return oil circuit and charge the refrigerant oil.	– Calculation for recharge quantity of refrigerant is required if process No.4-Work 2 is performed. (Refer to the item "Removing Compressor" for calculating method.) – Use a clean charge hose. – Use a container with a small opening so that the refrigerant oil does not absorb the moisture in the atmosphere. – If the refrigerant oil is not clean, it should be changed as new one.
12	Disconnect the charge hose from the charge port of return oil circuit. Perform the vacuuming from the check joint at low pressure side.	
13	Turn OFF the main switch of O.U.	
14	Set DSW4-#4, #6 back to the original setting.	Refer to Process No. 9 and 10.
15	Check that the power line for comp. and wiring are connected correctly.	
16	Recharge the collected refrigerant (Process No.4) from the check joint at high pressure side. For the remained quantity: Open the liquid and gas stop valve completely and set DSW4-#1 to ON side (O.U. PCB1). Then recharge it from the liquid stop valve check joint during cooling operation.	
17	Check the liquid and gas stop valves are open completely.	

O.U.: Outdoor Unit
I.U.: Indoor Unit
7-Seg.: 7-Segment
Comp.: Compressor

7.1.3. Failure of the power supply to the indoor unit and the remote control switch

■ The LED and the LCD are not indicated.

■ Not operated

If the fuses are blown out or a breaker is activated, investigate the cause of the overcurrent and take the necessary action.

Phenomenon	Cause	Check item	Action (Turn OFF the main switch)
Power failure or power is not ON		Measure the voltage by means of the voltmeter	Supply the power
Blown out fuse or activation of the breaker at the power source	Short circuit supplied between the wires	Check for any uncovered part of the wires	Remove the cause of the short circuit and replace the fuse
	Short circuit of the wires to earth	Measure the insulation resistance	Remove the cause of the short circuit and replace the fuse
	Failure of indoor unit fan motor	Measure resistance between wires and insulation resistance	Replace AC chopper for indoor unit fan, fan motor and fuse
	Failure of AC chopper for indoor fan		Replace AC chopper for indoor unit fan and fuse
Blown out fuse at the control circuit	Short circuit supplied between the wires	Check for any uncovered part of the wires	Remove the cause of the short circuit and replace the fuse
	Short circuit of the control circuit to earth	Measure the insulation resistance	Remove the cause of the short circuit and replace the fuse
	Failure of indoor unit fan motor	Measure resistance between wires and insulation resistance	Replace AC chopper for indoor unit fan, fan motor and fuse
	Failure of AC chopper for indoor fan		Replace AC chopper for indoor unit fan and fuse
Failure of the transformer at the indoor unit side		Measure the voltage at the secondary side	Replace the transformer
Disconnected cable of the remote control switch		Connect the cable	Replace the cable or repair the cable
Insufficient contacting at the connectors of the remote control switch	Insufficient connection or incorrect connection of the indoor unit PCB	Check the connectors	Correctly connect the connector
	Insufficient connection or incorrect connection of the indoor unit PCB in the remote control switch		
Failure of the remote control switch		Check the remote control switch by means of the self-check mode *1)	Replace the remote control switch if it failed
Failure of PCB	Unconnected wires to PCB	Check the connectors	Correctly connect the wires
	Failure of PCB	Check PCB by means of the self-check mode *2)	Replace PCB if it failed
Incorrect wiring connection		Take action according to the procedure that is displayed in "TEST RUN"	

*1): Refer to section "Self-checking of remote control switch".

*2): Refer to section "Self-checking of PCB using remote control switch".

7.1.4. Abnormal transmission between the remote control switch and the indoor unit

- **RUN LED on the remote control switch:**
Flickering every 2 seconds.

Phenomenon	Cause	Check item	Action (Turn OFF the main switch)
	Disconnection or insufficient contacting of the remote control cable	Check the cable and the connections	Repair the cable or connect the cable
	Incorrect wiring connection (incorrect polarity)	Check the wiring and the connections	Repairing
	Failure of the remote control switch	Check the remote control switch by means of the self-check mode *1)	Replace the remote control switch if the remote control switch is faulty
Failure of PCB (in the indoor unit and the remote control switch)	Disconnected wire to PCB	Check the connectors	Correctly connect the wires
	Failure of PCB	Check PCB by means of the self-check mode *2)	Replace PCB if it failed

*1): Refer to section "Self-checking of remote control switch".

*2): Refer to section "Self-checking of PCB using remote control switch".

7.1.5. Abnormal operation of the devices

In the case that no abnormality (Alarm Code) is indicated on the remote control switch, and normal operation is not available, take necessary action according to the procedures mentioned below.

Phenomenon	Cause		Check item	Action (Turn OFF the main switch)	
RUN LED is ON and the LCD is indicated However, the system does not operate (For example, the indoor fan, the outdoor fan or the compressor does not operate)	Failure of the indoor unit fan motor	Disconnected coil	Measure the coil resistance by means of the tester	Replace the Indoor unit fan motor	
		Burnt-out coil	Measure the insulation resistance		
	Failure of the outdoor unit fan motor	Disconnected coil	Measure the coil resistance by means of the tester	Replace the outdoor unit fan motor	
		Burnt-out coil	Measure the insulation resistance		
	Failure of the magnetic switch for the outdoor unit fan motor	Insufficient contacting	Measure the voltage between the contacting parts	Replace PCB for the outdoor unit	
	Failure of the comp. motor		Measure the resistance between two wires	Replace the compressor	
	Failure of the comp.		Check for an abnormal sound from the Comp.		
	Failure of the magnetic switch for comp.	Insufficient contacting	Check that the magnetic switch activates correctly or not	Replace the magnetic switch	
	Failure of one of PCBs	Disconnected wiring to PCB		Check the connections	Correctly connect the wiring
		Failure of PCB		Check PCB by means of the self-check mode *1)	Replace PCB if it failed
The Comp. does not stop or start even if the setting temperature on the LCD changes to *3)	Failure of air inlet thermistor	Failure of thermistor	Check it by self-checking *2)	Replace or correctly connect the wires if Abnormal Operation exists	
		Disconnection of thermistor			
	Abnormal operation of the remote control switch cord				
	Failure of the indoor unit PCB				Check PCB by means of the self-check mode *1)

Abnormal operation of the devices (Cont.)

Phenomenon	Cause	Check item	Action (Turn OFF the main switch)
The Comp. does not stop or start even if the setting temperature on LCD changes to *3)	Incorrect optional setting	Check the setting condition of "thermistor of remote control switch." by means of the optional setting Setting and control: "00": Control by means of the indoor thermistor for the suction air "01": Control by means of the thermostat of the remote control switch "02": Control by means of the average value of the indoor thermistor for the suction air and the thermostat of the remote control switch	If the thermostat of the remote control switch is not used, set at "00"

*1): Refer to section "Self-checking of PCB using remote control switch".

*2): Refer to section "Troubleshooting in check mode by remote control switch".

*3): Even if the remote control switches are normal, the compressor does not operate under the following conditions:

- Indoor temp. is lower than 21°C or outdoor temp. is lower than -5°C during the cooling process (DB).
- Indoor temp. is higher than 27°C (DB) or outdoor temp. is higher than 15°C (WB) during the heating process.
- When a cooling (or heating) process signal is given to the outdoor unit and a different mode as heating (or cooling) process signal is given to the indoor units.
- When an emergency stop signal is given to outdoor unit.

Abnormal operation of the devices (Cont.)

Phenomenon	Cause		Check item	Action (Turn OFF the main switch)
Indoor fan speed does not change	Failure of the Discharge Air Temp. Thermistor	Failure of the Thermistor	Check the Thermistor by means of the self-check mode *2)	Replace or Correctly connect the wiring when it is abnormal
		Disconnected Wire of the Thermistor		
	Failure of the Remote Control Switch		Check it by means of the self-check mode *1)	Replace if it failed
	Failure of PCB for the indoor unit			Replace if PCB fails
Failure of AC chpper for indoor unit		Check the indoor unit stoppage when the remote control switch is swiched OFF	Replace if AC chpper is failed	
No defrost operation mode is available during the heating process or the defrost operation continues	Failure of thermistor for outdoor evaporating temp. during heating	Failure of thermistor	Replace or correctly connect when it is abnormal	
		Disconnected wire of thermistor		
	Failure of 4-way valve	Disconnected 4-way valve coil	Measure the resistance of coil	Replace the 4-way valve
		Incorrect activation of 4-way valve	Enforced power supply	
	Disconnected control wires between indoor unit, CH unit and outdoor unit		Check the connectors	Correctly connect the wiring
	Failure of the outdoor units of PCB	Disconnected wiring to PCB	Check the connectors	Correctly connect the wiring
		Failure of PCB	Check PCB by means of the self-check mode *1)	Replace PCB when the check mode is not available
	Failure of the Indoor Unit of PCB	Disconnected wiring to PCB	Check the connectors	Correctly connect the wiring
Failure of PCB		Check PCB by means of the self-check mode *1)	Replace if PCB fails	
Failure of PCB in the indoor unit or the remote control switch				
The LED and the LCD on the remote control switch remain ON			Check PCB by means of the self-check mode *1)	Replace if PCB fails

*1): Refer to section "Self checking of PCB using remote control switch".

*2): Refer to section "Troubleshooting in check mode by remote control switch".

Abnormal operation of the devices (Cont.)

Phenomenon	Cause		Check item	Action (Turn OFF the main switch)
Insufficient cooling process	Indoor heat load is greater than the cooling capacity		Calculate the heat load	Use a bigger unit
	Excessively low suction pressure	Gas leakage or shortage of refrigerant	Measure superheat	Correctly charge the refrigerant after repairing the gas leakage
		Excessively small diameter tube or long piping	Measure and check the field-supplied pipes	Use the correct pipes
		Incorrect activation of the check valve of the outdoor unit	Check whether or not the temp. difference exists before/after the check valve	Replace the check valve for the outdoor unit
		Failure or malfunction of the expansion valve	Check for clogging	Remove the clogging
			Check the connection cord and the connector	Replace the connector
			Is there an operation sound from the coil?	Replace the coil
			Is the thermistor on the compressor normal?	Replace the thermistor
		Is the thermistor installed correctly on compressor?	Correctly install the thermistor	
		Clogged strainer in the indoor unit; clogging at the low pressure piping	Check the temp. difference at the inlet and the outlet of the strainer	Replace the strainer in the indoor unit
		Clogging at the low pressure piping	Check the temp. difference	Remove the clogging
		Insufficient air flow to the indoor unit heat exchanger	Check for clogged air filter	Clean the air filter
			Check for an obstacle at the inlet or the outlet	Remove the obstacles
		Excessively low air temp. to the indoor unit heat exchanger	Insufficient speed of the indoor unit fan motor?	Replace the fan motor
			Short-circuited indoor unit air?	Remove the cause of the short-circuited air

Abnormal operation of the devices (Cont.)

Phenomenon	Cause		Check item	Action (Turn OFF the main switch)	
Insufficient cooling process	Insufficient air flow to the outdoor unit heat exchanger		Check clogging of the outdoor unit heat exchanger?	Remove the clogging	
			Obstacles at inlet or the outlet of outdoor unit heat exchanger?	Remove the obstacles	
			Is the service area for the outdoor unit sufficient?	Secure the service area	
			Correct fan speed?	Replace the fan motor	
	Excessively high air temp. to the outdoor unit heat exchanger		Short-circuited air to the outdoor unit?	Remove the cause of the short-circuited air	
			Any other heat load near the outdoor unit?	Remove the heat source	
	Excessively high discharge pressure	Excessively charged refrigerant	Check Expansion valve opening	Correctly charge the refrigerant	
		Non-condensate gas in cycle	Check each temp. and each pressure	Charge the refrigerant after the vacuum pumping	
		Clogging of the discharge piping	Check for clogging	Remove the clogging	
		Failure or malfunction of the expansion valve	Check for clogging	Remove the clogging	
			Check the connection cord and the connector	Replace the connector	
			Is there an operation sound from the coil?	Replace the coil	
			Is the thermistor on the compressor normal?	Replace the thermistor	
			Is the thermistor installed correctly on the compressor?	Correctly install the thermistor	
		Malfunction or internal leakage of the 4-way valve		Check the temp. difference at the inlet and the outlet of the 4-way valve	Replace the 4-way valve
	Excessively low suction pressure		Failure of bypass solenoid valve	Checking for leakage of solenoid valve	Replace solenoid valve
			Malfunction or internal leakage of the 4-way valve	Check the Temp. Difference between the Inlet and the Outlet of 4-Way Valve	Replace the 4-way valve
	Discharge temp. of the indoor unit is unstable		Check the expansion valve of the indoor unit in the same system	Replace the failed expansion valve of the indoor unit	

Abnormal operation of the devices (Cont.)

Phenomenon	Cause		Check item	Action (Turn OFF the main switch)
Insufficient heating process	Indoor heat load is greater than the heating capacity		Calculate the heat load	Replace the unit with a bigger unit
	Excessively low suction pressure	Gas leakage or insufficient refrigerant charge	Measure superheat	Correctly charge the refrigerant after the gas leakage check and repairing
		Excessively small diameter or long piping	Measure the field-supplied piping	Use the specified pipes
		Failure or malfunction of the expansion valve	Check for clogging	Remove the clogging
			Check the connection cord and the connector	Replace the connector
			Is there an operation sound from the coil?	Replace the coil
			Is the thermistor on the compressor normal?	Replace the thermistor
			Is the thermistor installed correctly on compressor?	Correctly install the thermistor
		Clogging of I.U./O.U./CH-Unit strainer	Check the temp. difference between the inlet and the outlet of strainer	Replace the strainer for the outdoor unit or the indoor unit
		Clogging of suction piping	Check the temp. difference of each part	Remove the clogging
		Insufficient air flow through the outdoor unit heat exchanger	Is the outdoor unit heat exchanger clogged?	Remove the clogging
			Are there any obstacles at the inlet or the outlet of outdoor unit?	Remove the obstacles
			Is the service area for the outdoor unit sufficient?	Secure a sufficient service area
			Check the speed of the outdoor unit fan	Replace the fan motor
		Excessively low air temp. through the outdoor unit heat exchanger	Check for any short-circuited air to the outdoor unit	Remove the cause of the short-circuited air
Defrosting is insufficiently completed	Check the thermistor for the defrost operation	Replace the thermistor for the defrost operation		

Abnormal operation of the devices (Cont.)

Phenomenon	Cause		Check item	Action (Turn OFF the main switch)
Insufficient heating process	Excessively high discharge pressure	Insufficient air flow to the indoor unit heat exchanger	Check the filter for a clogging	Remove the clogging
			Check for any obstacles at the inlet or the outlet of the indoor unit	Remove the obstacles
			Check the indoor fan speed	Replace the fan motor
		Excessively high air temp. to the indoor unit heat exchanger	Check whether or not the short-circuited air exists	Remove the cause of the short-circuited air
		Excessively charged refrigerant	Check the refrigerant quantity *1)	Correctly charge the refrigerant
		Non-condensate gas in ref. cycle	Check the refrigerant quantity *1)	Recharge the refrigerant after the vacuum pumping
		Clogging of the discharge pr. piping	Check for clogging	Remove the clogging
	Malfunction or internal leakage of the 4-way valve		Check the temp. difference at the inlet and the outlet of the 4-way valve	Replace the 4-way valve
	Malfunction of the check valve of the outdoor unit		Check the temp. difference at the inlet and the outlet of the check valve	Replace the check valve
	Excessively high suction pressure	Failure of the bypass solenoid valve	Check for leakage of the solenoid valve	Replace the solenoid valve
		Malfunction or internal leakage of 4-way valve	Check the temp. difference at the inlet and the outlet of the 4-way valve	Replace the 4-way valve
	Discharge temp. of the indoor unit is unstable		Check the expansion valve of the indoor unit in the same system	Replace the failed expansion valve of the indoor unit

*1): Refer to chapter 7 of TC.

Abnormal operation of the devices (Cont.)

Phenomenon	Cause		Check item	Action (Turn OFF the main switch)
Cooling or heating process with an abnormal sound	Foreign particles inside of the fan casing		Visually inspect it	Remove the foreign particles
	Indoor unit fan runner is hitting the casing		Visually inspect it	Adjust the position of the fan runner
	Outdoor unit propeller fan is hitting the shroud		Visually inspect it	Adjust the position of the propeller fan
	Abnormal sound from the compressor	Faulty Installation	Check that each part is tightly fixed	Tightly fix each part
		Liquid ref. compression	Check expansion valve opening	Ensure superheat
		Wear or breakage of the internal comp. parts	Abnormal Sound from the Inside of the Compressor	Replace the compressor
		No heating by the oil heater	Check the Resistance (Oil Heater, Fuse)	Replace the oil heater or the fuse
	Humming sound from the magnetic conductor		Check the surface of the contacts	Replace the magnetic switch
Abnormal vibration of the cabinets		Check each fixing screw	Tightly fix each screw	
Outdoor fan does not operate when the compressor operates	Obstacle at the outdoor fan		Check the obstacles	Remove the obstacles
	Watching condition for the heating process		Wait for the switching of the 4-Way Valve (1 ~ 3 minutes)	If the 4-Way Valve does not switch, check for insufficient refrigerant
Indoor fan does not operate when the compressor operates	Discharge pressure does not increase higher than 1.5 MPa due to the insufficient refrigerant		Check the operation pressure *1)	Add the refrigerant
	Disconnected Wiring for the Indoor Fan		Check the wiring	Connect the wiring correctly
	Failure of AC chopper		Check AC chopper	Replace AC chopper

*1): Refer to chapter 10 of TC.

7.2. Troubleshooting procedure

7.2.1. Alarm code indication of remote control switch


If the RUN LED flickers for 2 seconds, there is a failure in the transmission between the Indoor Unit and the Remote Control Switch.

Possible causes are:

- Broken remote cable
- Contact failure in the remote control cable
- Defective IC or defective microcomputer

In any case, ask your retailer for service

If the RUN LED flickers 5 times (5 seconds) with the unit number and the alarm code displayed, make a note of the alarm code (refer to the table below) and ask your retailer for service.




Alarm code table

Code No.	Category	Content of Abnormality	Leading Cause
01	Indoor Unit	Tripping of Protection Device	Failure of Fan Motor, Drain Discharge, PCB, Relay.
02	Outdoor Unit	Tripping of Protection Device	Activation of PSH
03	Transmission	Abnormality between Indoor (or Outdoor) and Outdoor (or Indoor)	Incorrect Wiring. Failure of PCB. Tripping of Fuse. Power Supply OFF
04		Abnormality between Inverter PCB and Outdoor PCB. Abnormality between Fan Controller and Outdoor PCB	Transmission Failure (Loose Connector), If only fan controller is failed, indications are as follows: Number 1 Fan Controller Failure - F1 04 Number 2 Fan Controller Failure - F2 04
05	Supply phase	Abnormality of Power Source Wiring	Reverse Phase Incorrect Wiring.
06	Voltage	Abnormal Inverter Voltage	Outdoor Voltage Drop, Insufficient Power Capacity, If voltage drop cause by fan controller is detected, indications are as follows: No. 1 Fan Controller Failure - F1 06 No. 2 Fan Controller Failure - F2 06
07	Cycle	Decrease in Discharge Gas Superheat	Excessive Refrigerant Charge. Expansion Valve Open Lock.
08		Increase in Discharge Gas Temperature	Insufficient Refrigerant. Ref. Leakage, Clogging or Expansion Valve Close Lock
09	Fan motor	Activation of Protection Device for Outdoor Fan	Fan Motor Overheat, Locking
11	Sensor on Indoor Unit	Inlet Air Thermistor	Incorrect Wiring, Disconnecting Wiring.
12		Outlet Air Thermistor	
13		Freeze Protection Thermistor	
14		Gas Piping Thermistor	
16	Thermistor	Remote thermistor	
17		Built-in thermistor at remote control switch	
19	Fan motor	Tripping of Protection Device for Fan Motor	Failure of Fan Motor
21	Sensor on Outdoor Unit	High Pressure Sensor	Incorrect Wiring, Disconnecting Wiring
22		Outdoor Air Thermistor	
23		Discharge Gas Thermistor on Comp.	
24		Evaporating Thermistor	
29		Low Pressure Sensor	
31	System	Incorrect Setting of Outdoor and Indoor Unit	Incorrect Setting of Capacity Code.
35		Incorrect Setting in Indoor Unit No.	Existence of the same Indoor Unit No. in the same Refrigerant Cycle
38		Abnormality of Protective Circuit in Outdoor Unit	Failure of Indoor Unit PCB. Incorrect wiring. Connection to PCB in Indoor Unit.


Code No.	Category	Content of Abnormality	Leading Cause
39	Compressor	Abnormality of Running Current at Constant Compressor	Overcurrent, Blown Fuse of Failure of Current Sensor.
43	Protection device	Pressure Ratio Decrease Protection Activating	Failure of Compressor, Inverter
44		Low Pressure Increase Protection Activating	Overload to Indoor in Cooling. High Temperature of Outdoor Air In Heating Expansion Valve Open Lock
45		High Pressure Increase Protection Activating	Overload Operation. Excessive Refrigerant. Clogging of Heat Exchanger
47		Low Pressure Decrease Protection Activating	Insufficient refrigerant .
48		Activation of inverter overcurrent protection device	Overload operation, compressor failure
51	Sensor	Abnormal Current Sensor	Current sensor failure
53	Inverter	Inverter Error Signal Detection	Driver IC Error Signal Detection (Protection for Overcurrent, Low Voltage, Short-Circuit)
54		Increase in Inverter Fin Temperature	Abnormal Inverter Fin Thermistor. Abnormal Outdoor Fan
55		Inverter failure	Inverter PCB failure
56	Outdoor fan	Abnormal detection of fan motor position	Abnormal of fan motor position detection circuit, disconnected wiring No. 1 Fan controller failure - F1 56 No. 2 Fan controller failure - F2 56
57	Fan controller	Activation of fan controller protection	Driver IC error signal detection, fin temp. increase No. 1 Fan controller failure - F1 57 No. 2 Fan controller failure - F2 57
58		Abnormal fan controller	Abnormal operating speed No. 1 Fan controller failure - F1 58 No. 2 Fan controller failure - F2 58
EE	Inverter	Compressor Protection	3 Time Occurrence of Alarm Giving Damage to Compressor within 6 hours
b1	Outdoor unit number setting	Incorrect outdoor unit number setting	Over 64 No. is set for address of refrigerant cycle
b5	Indoor unit number setting	Incorrect indoor unit number setting	More than 17 non-corresponding to H-LINKII units are connected to one system

7.2.2. Troubleshooting by alarm code

Alarm code	Description
01	Activation of the safety device in the indoor unit
<ul style="list-style-type: none"> ■ The RUN LED flickers and "ALARM" is displayed on the remote control switch. ■ The unit number, the alarm code and the unit code are alternately displayed on the set temperature section. The unit number and the alarm code are displayed on the display of the outdoor unit PCB. <ul style="list-style-type: none"> – This alarm code is displayed when the contact between #1 and #2 of CN14 is not closed over 120 seconds during the cooling process, the heating process or the fan operation. 	




Example of RCD, RPI and RPC Types




Phenomenon	Cause		Check item	Action (Turn OFF the main switch)
Activation of the float switch	High Drain Level	Clogging of the drainage	Check the drain pan	Remove the clogged foreign particles
	Faulty float switch	Fault	Check the continuity when the drain level is low	Replace the float switch if faulty
		Faulty contacting	Measure the resistance by means of the tester	Fix the looseness and Replace the connector
		Faulty connection	Check the connections	Repair the connection
Faulty indoor unit PCB			Check PCB by self checking	Replace PCB if faulty

Outdoor unit PCB display indication:



Alarm code	Description
02	Activation of the safety device in the outdoor unit
<ul style="list-style-type: none"> ■ The RUN LED flickers and “ALARM” is displayed on the remote control switch. ■ The unit number, the alarm code and the unit code are alternately displayed on the set temperature section. The unit number and the alarm code are indicated on the display of the outdoor unit PCB1. <ul style="list-style-type: none"> – This alarm is indicated when one of safety devices is activated during compressor running.. 	



Outdoor Unit PCB1 Display Indication

1 02	Abnormality of PSH1
2 02	Abnormality of PSH2
3 02	Abnormality of PSH3
4 02	Abnormality of PSH4
5 02	Abnormality of PSH5

Model	High Pressure Switch/(): Connector No.				
	PSH1 (PCN2)	PSH2 (PCN16)	PSH3 (PCN17)	PSH4 (PCN18)	PSH5 (PCN52)
RAS-8 to 12FSN2	○	-	-	-	-
RAS-14 and 16FSN2	○	○	-	-	-
RAS-18 to 28FSN2	○	○	○	-	-
RAS-30 to 36FSN2	○	○	○	○	-
RAS-38 to 48FSN2	○	○	○	○	○


Phenomenon	Cause		Check item	Action (Turn OFF the main switch)	
Activation of the high-pressure switch due to the excessively high discharge pressure	Insufficient air flow to the heat exchanger (Outdoor heat exchanger during the cooling process or indoor heat exchanger during the heating process)		Check the heat exchanger for dust or for clogging	Remove the dust or the clogging	
			Check the air filter for dust	Remove the dust	
			Check for any obstacles at the inlet or the outlet of the heat exchanger	Remove the obstacles	
			Check the service area	Secure service area	
			Check the speed (Outdoor Fan: Cooling / Indoor Fan: Heating)	Replace the fan motor if faulty	
	Malfunction of the expansion valve		Disconnected of the Connector	Fix the looseness or reconnect the connector	
			Fully closed and locked	Replace the expansion valve	
	Excessively high temp. air to the Indoor Unit		Calculate the heat load	Reduce the heat load or use a bigger unit	
			Check for hot air near the ceiling (Heating)	Provide good circulation	
			Check for short-circuited air (Heating)	Remove the short-circuited air	
			Check for other heat source	Remove the heat source	
	Faulty high-pressure switch		Faulty pressure switch	Measure the discharge pressure. Check the continuity after the decrease of the pressure	Replace the pressure switch if faulty
			Insufficient contacting	Measure the resistance by means of the tester	Fix the looseness. Replace the connector
			Incorrect connection	Check the connections	Repair the connections

Phenomenon	Cause	Check item	Action (Turn OFF the main switch)
Activation of the high-pressure switch due to the excessively high discharge pressure	Faulty or malfunction of the expansion valve	Check for clogging	Remove the clogging
		Check the connect wiring and the connectors	Replace the connector
		Check the operation sound from the coil	Replace the coil
		Check the discharge gas thermistor	Replace the thermistor
		Check the attaching state of the discharge gas thermistor	Reattach the thermistor
	Faulty gas bypass solenoid valve	Check for clogging	Replace the gas bypass solenoid valve
	Overcharged refrigerant	Check the cycle operation temp.	Charge the refrigerant correctly
	Mixture of the non-condensate gas in the refrigerant cycle	Check the air temp. and the pressure	Recharge the refrigerant after the vacuum pumping
	Clogging of the discharge piping	Check for clogging	Remove the clogging
	Liquid line stop valve or gas line stop valve is not in operation	Check the stop valves	Fully Open the stop valves
Clogging of the check valve	Check for clogging	Replace the check valve	


Alarm code	Description
03	Abnormal transmission between the indoor units and the outdoor unit

- The RUN LED flickers and "ALARM" is displayed on the remote control switch.
- The unit number, the alarm code and the unit code are alternately displayed on the set temperature section. The unit number and the alarm code are displayed on the display of the outdoor unit PCB1.
 - This alarm is displayed when an abnormal operation is maintained for three minutes after the normal transmission between the indoor units and the outdoor unit. Also, an abnormal operation is maintained for 30 seconds after the micro-computer is automatically reset.
 - The alarm is displayed when the abnormal transmission is maintained for 30 seconds from the starting of the outdoor unit.
 - Investigate the cause of the overcurrent and take the necessary action when the fuses are blown out or the breaker for the outdoor unit is activated.

PCB1: Outdoor unit printed circuit board
PCB: Indoor unit printed circuit board



To next page



*1): In case that terminal resistance (DSW10-1P) is OFF when H-Link Connection is performed.

Set the terminal resistance to ON when CN2 is removed.


Set the terminal resistance to OFF when CN2 is reconnected.

Phenomenon	Cause	Check item	Action (Turn OFF the main switch)
Power failure or no power supply		Measure the voltage by means of the tester	Supply the power
Blown out fuse for the power source or activation of the outdoor unit breaker	Short circuit between wires	Check the insulation material for breaks	Remove the short circuit and replace the fuse
	Short-circuited wire to ground	Measure the insulation resistance	Remove the short circuit to ground and replace the fuse
	Faulty comp. motor	Measure the resistance between the wires and the insulation resistance	Replace the comp. and the fuse
	Faulty outdoor unit fan motor	Measure the resistance between the wires and the insulation resistance	Replace the outdoor unit fan motor and the fuse
Blown out fuse for control circuit or activation of outdoor unit breaker	Short circuit between wires	Check the insulation material for breaks	Remove the short circuit and replace the fuse
	Short circuit of the control circuit (to ground)	Measure the insulation resistance	Remove the short circuit and replace the fuse
	Faulty solenoid coil for the magnetic switch for the comp. motor	Measure the resistance of coil	Replace the magnetic switch and the fuse
	Failure of the outdoor unit fan motor	Measure the resistance between the wires and the insulation resistance	Replace the outdoor unit fan motor and fuse
PCB1 power circuit failure		Measure PCB1 output voltage *2)	Replace PCB1
Disconnected wires insufficient contacting or incorrect connection	Between outdoor unit and indoor unit	Check the continuity of the wires. Check for looseness of the connection screws. Check the terminal Nos.	Replacing wires repairing and tightening the screws and the correct wiring
	Power source wiring for the outdoor unit		
Faulty PCB (outdoor unit, indoor unit)	Disconnected wires to PCB	Check the connections	Correctly connect the wires
	Faulty PCB	—	Replace PCB if faulty
Incorrect wiring	Disconnected wire; insufficient contacting	Check the continuity and the looseness of connection screws	Replacing wires, repairing and tightening the screws
	Incorrect wiring	Check the terminal Nos.	Correctly connect the wires

*2): VCC12~GND2: 12VDC
 VCC05~GND1: 5VDC
 VCC12~GND1: 12VDC
 VCC15~GND1: 15VDC
 VCC24~GND1: 24VDC
 VCC12T~GND1: 12VDC

7

Alarm code	Description
04	Abnormal transmission between Inverter and the Outdoor Unit PCB1, 2
<ul style="list-style-type: none"> ■ The RUN LED flickers and “ALARM” is displayed on the remote control switch. ■ The unit number, the alarm code and the unit code are alternately displayed on the set temperature section. The unit number and the alarm code are displayed on the display of the outdoor unit PCB1. <ul style="list-style-type: none"> – This alarm is displayed when the abnormal operation is maintained for 30 seconds after the normal transmission between the outdoor unit PCB1 and PCB2 and also abnormality is maintained for 30 seconds after the micro-computer is automatically reset. The alarm is displayed when the abnormal transmission is maintained for 30 seconds from the starting of the outdoor unit. – Alarm code “04.” is indicated when transmission between inverter and fan controller is abnormal. 	




Outdoor unit PCB1 display indication:

0	4	Abnormal transmitting of inverter		
F	1	0	4	Abnormal transmitting of fan controller 1
F	2	0	4	Abnormal transmitting of fan controller 2

Phenomenon	Cause	Check item	Action (Turn OFF the main switch)
Disconnected wires, insufficient contacting or incorrect connection	Between control PCB1, PCB2 and fan controller	Check the continuity of wires. Check for looseness of the connection screws. Check the connection No.	Replacing wires, repairing, tightening screws and incorrect wiring
	Power source wiring for the outdoor unit		
Faulty PCB (PCB1 and PCB2)	Disconnected wires to PCB	Check the connections	Repair the wiring connections
	Faulty PCB	—	Replace PCB if faulty
Incorrect wiring	Disconnected wires; insufficient contacting	Check the continuity. Check for looseness of connection screws	Replacing wires, repairing, tightening screws
	Incorrect wiring	Check the connection Nos.	Correctly connect the wires

Position of Surge Absorber (SA)



(380-415V)

When the unit is applied the excessive surge current due to lighting or other causes, it is indicated this alarm code “04” or the inverter stoppage code (ITC) “11” and the unit can not be operated. In this case, check to ensure the surge absorber (SA) on the noise filter (NF1). If the inside of the surge absorber is normal, turn OFF the power once and wait for PCB2’s LED OFF and turn ON again.

■ Position of the Thermistor

Thermistor ref.	Display	Drive	Number of compressors	Unit HP	Thermistor position (a)
THM8	<i>f d 1</i>	Inverter	1	8~12HP	
THM9	<i>f d 2</i>	Constant speed	2	14~16HP	
THM12	<i>f d 3</i>		3	18~28HP	
THM13	<i>f d 4</i>		4	30~36HP	
THM18	<i>f d 5</i>		5	38~48HP	

Phenomenon	Cause		Check item	Action (Turn OFF the main switch)
Decrease of the discharge gas superheat	Ref. cycle is different from the electrical system		Check the ref. cycle and the electrical system	Repair the wiring
	Overcharged refrigerant		Measure the pressure. (Refer to "Test Run of SM".)	Correctly charge the refrigerant
	Faulty Ex. valve		Check expansion valve (refer to procedure of checking other main parts)	Replace the ex. valve if faulty
	Faulty PCB	Fault	Replace PCB1 and check the operation	Replace PCB if faulty
		Disconnected wires for the Ex. valve control	Check the connections	Repair the wiring connection
	Faulty discharge gas thermistor	Fault	Check thermistor	Replace the thermistor if faulty
		Incorrect mounting	Check the mounting state (Refer to Alarm code 07)	Correctly mount the thermistor
Incorrect connection		Check the connections	Remove looseness. Replace the connector or repair the connections	

■ Position of the Thermistor

Thermistor ref.	Display	Drive	Number of compressors	Unit HP	Thermistor position (a)
THM8	<i>rd1</i>	Inverter	1	8~12HP	
THM9	<i>rd2</i>	Constant speed	2	14~16HP	
THM12	<i>rd3</i>		3	18~28HP	
THM13	<i>rd4</i>		4	30~36HP	
THM18	<i>rd5</i>		5	38~48HP	

Phenomenon	Cause		Check item	Action (Turn OFF the main switch)
Decrease of the discharge gas superheat	Ref. cycle is different from the electrical system		Check the ref. cycle and the electrical system	Repair the wiring
	Undercharged refrigerant		Check pressures	Correctly charge the refrigerant
	Faulty Ex. valve		Check expansion valve (refer to procedure of checking other main parts)	Replace the ex. valve if faulty
	Faulty PCB	Fault	Replace PCB and check the operation	Replace PCB if faulty
		Disconnected wires for the Ex. valve control	Check the connections	Repair the wiring connection
	Faulty discharge gas thermistor	Fault	Measure the resistance of thermistor	Replace the thermistor if faulty
		Incorrect mounting	Check the mounting state	Correctly mount the thermistor
		Incorrect connection	Check the connections	Remove looseness. Replace the connector or repair the connections

