

Haier

Horizontal and concealed type Fan Coil Service Manual

Models:

| | | |
|------------|------------|------------|
| FCE-034B** | FCE-051B** | FCE-068B** |
| FCE-085B** | FCE-102B** | FCE-136B** |
| FCE-170B** | FCE-204B** | FCE-238B** |



● Features

- Security and reliability, long life
- High efficiency , sufficient energy
- Large air volume and low noise level
- Universal application

Code: SYJS-014-05REV.2

Edition: 2007-10-10




Большая библиотека технической документации
<https://splitsystema48.ru/instrukcii-po-ekspluatacii-kondicionerov.html>
каталоги, инструкции, сервисные мануалы, схемы.

CONTENTS

| | |
|---|----|
| Contents..... | 2 |
| 1. Nomenclature..... | 3 |
| 2. Important cautions..... | 4 |
| 3. Features..... | 4 |
| 4. Specification..... | 5 |
| 5. Dimension and weight..... | 6 |
| 6. Installation instructions..... | 8 |
| 7. Installation inspection and startup..... | 9 |
| 8. Maintenance..... | 10 |
| 9. Troubleshooting..... | 11 |
| 10. Wiring diagram..... | 11 |

1. Nomenclature



| item | code | Definition |
|--------------------------|------|-----------------------------------|
| Fan coil | FC | Fan coil |
| Appearance code | B | Cassette type |
| | C | Convertible type |
| | D | Duct type |
| | E | Ceiling concealed horizontal type |
| | F | Ceiling concealed vertical type |
| External static pressure | A | 0 Pa |
| | B | 0 Pa or 30 Pa |
| | C | 50 Pa |
| | D | 60 Pa |
| | E | 80 Pa |
| | F | 100Pa |

| item | code | Definition |
|--------------------|------------------------|------------------------|
| Installation type | S | Shown |
| | C | Concealed |
| | X | Other types |
| Air return type | B | Back type |
| | D | Down type |
| | N | Without air return box |
| Applicable voltage | 1 | (100 ~ 115)V,(50/60)Hz |
| | 3 | (115 ~ 220)V,(50/60)Hz |
| | 2 | (220 ~ 240)V,50 Hz |
| | 4 | (220 ~ 240)V,60 Hz |
| | 6 | 220 V, (50/60)Hz |
| | 8 | 240 V, 50 Hz |
| | N | (380 ~ 400)V,50 Hz |
| | I | (380 ~ 400)V,60 Hz |
| | 9 | (100 ~ 220)V,(50/60)Hz |
| | M | 415V,50 Hz |
| | L | (380 ~ 400)V,60 Hz |
| I | (380 ~ 400)V,(50/60)Hz | |

2. Important cautions

2.1 Fan coil unit is the terminal device of the chiller system. It is professional very much and with perfect technology and requirement, so the installation, debugging, operation and management will be performed by the specified engineer.

2.2 The unit is applicable widely. But please do not use it at the wet place, or on the outside, dirty, or corrosive environment, and at the explosive place.

2.3 Applicable condition

Power source: 1PH, 220V~, 50Hz.

Max. operation pressure \leq 1.6MPa.

3. Features

3.1 Fan coil unit is mainly composed of centrifugal fan, motor and evaporator. which is used widely in the field such as the hotel, the restaurant, the hospital, the exhibition hall and the office building or industrial building and domestic building, etc. It will give you a comfortable environment.

3.2 Security and reliability, long life

Each set of fan coil evaporator will be tested leakage by pressure; water inlet/outlet connection pipe adopts brass forging structure, reliable and durable; the drain pan is made from mold and then treated with paint, stainless; motor is equipped with the rolling bearing, no need to add the oil, the life can be up to 60,000 hours; the motor long axis is stainless after the special treatment.

3.3 High efficiency, sufficient energy

The seamless pipe is cross the slit fin aluminum foil, then be enlarged by the mechanical device to make the copper pipe and the aluminum foil together, which will get the higher efficiency and sufficient heating/cooling capacity.

3.4 Large air volume and low noise level

The unit adopts the locked type scroll case, convenient to be taken down; multiple-blade fan. There will be multiple combinations by the fan and the motor to meet the different requirements.

3.5 Universal application

The unit adopts the drawable heat exchanger, convenient to maintain; optional left or right water inlet type, flexible installation; optional static external pressure 0Pa or 30Pa to meet the personalization requirement.

4. Specifications (without air return box, standard drainage pan)

| model | | | FCE-034B | FCE-051B | FCE-068B | FCE-085B | FCE-102B | FCE-136B | FCE-170B | FCE-204B | FCE-238B | |
|------------------------------------|-------|----|-------------------|----------|----------|-------------|----------|----------|--------------|----------|--------------|-------|
| data | | | | | | | | | | | | |
| air volume | m3/h | H | high | 340 | 510 | 680 | 850 | 1020 | 1360 | 1700 | 2040 | 2380 |
| | | M | med | 290 | 430 | 580 | 720 | 850 | 1120 | 1420 | 1700 | 1980 |
| | | L | low | 230 | 340 | 460 | 560 | 680 | 880 | 1110 | 1320 | 1580 |
| cooling capacity | | H | high | 2120 | 3040 | 3900 | 4820 | 5950 | 8300 | 9480 | 11720 | 13130 |
| | | M | med | 1781 | 2621 | 3354 | 4193 | 5296 | 7138 | 8437 | 10310 | 11686 |
| | | L | low | 1484 | 2215 | 2886 | 3519 | 4463 | 6059 | 7110 | 8790 | 9848 |
| heating capacity | | H | high | 3534 | 4750 | 6300 | 7940 | 9800 | 12755 | 15600 | 18700 | 21360 |
| | | M | med | 2969 | 3990 | 5418 | 7067 | 8624 | 11735 | 13416 | 16260 | 18583 |
| | | L | low | 2544 | 3420 | 4662 | 6034 | 7448 | 10076 | 11544 | 14020 | 16020 |
| power input | W | H | high | 24 | 32 | 50 | 61 | 81 | 120 | 148 | 178 | 198 |
| | | SH | super high | 42 | 50 | 65 | 95 | 110 | 135 | 183 | 210 | 260 |
| noise level | DB(A) | SH | super high | 37 | 38 | 41 | 44 | 45 | 46 | 48 | 48 | 49 |
| | | H | high | 35 | 36 | 37 | 41 | 43 | 43 | 46 | 48 | 48 |
| | | M | med | 28 | 29 | 31 | 32 | 35 | 35 | 36 | 36 | 37 |
| | | L | low | 22 | 22 | 24 | 25 | 26 | 27 | 28 | 28 | 29 |
| water flow | l/min | | 6 | 9.1 | 12.5 | 14 | 16.2 | 23 | 26 | 34 | 38 | |
| water pressure drop | kpa | | 10 | 16 | 18 | 23 | 35 | 35 | 38 | 39 | 46 | |
| net weight | kg | | 11.9 | 13 | 14.8 | 17.8 | 18.3 | 29 | 29.3 | 33.4 | 33.6 | |
| gross weight | kg | | 15.3 | 15.5 | 17.6 | 21.2 | 21.7 | 33.2 | 33.5 | 40.7 | 40.9 | |
| water inlet/outlet connection pipe | | | 3/4"inner grooved | | | | | | | | | |
| condensate water connection pipe | | | 3/4"outer grooved | | | | | | | | | |
| external dimension(L*W*H) | | | 624*466*220 | | | 944*466*220 | | | 1374*466*220 | | 1614*466*220 | |


Все каталоги и инструкции здесь: <https://>

- 1.Cooling conditions: DB temperature=27°C WB Temperature=19.5°C water IN=7°C water IN/OUT Diff=5°C
- 2.Heating conditions: DB temperature=21°C water IN=60°C
- 3.The left water outlet type or right water outlet type unit can be changed on site according to the actual requirement
- 4.The static pressure 0 Pa and 30 Pa can be selected freely according to the actual requirement
- 5.The data is subject to change without notice in order to update the design

5. Dimension and weight


Horizontal and concealed type, without air return box:

Все каталоги и инструкции здесь: <https://splitsystema48.ru/instrukcii-po-ekspluatacii-kondicionerov.html>



| standard drainage pan | | | | | extended drainage pan | | | | |
|-----------------------|------------------------|------|------|-------------|-----------------------|------------------------|------|------|-------------|
| model | external dimension(mm) | | | weight (kg) | model | external dimension(mm) | | | weight (kg) |
| | A | B | C | | | A | B | C | |
| FCE-034BCN2A | 624 | 508 | 478 | 11.9 | FCE-034BCN2B | 944 | 508 | 478 | 12.4 |
| FCE-051BCN2A | 624 | 508 | 478 | 13 | FCE-051BCN2B | 944 | 508 | 478 | 13.1 |
| FCE-068BCN2A | 944 | 808 | 778 | 14.8 | FCE-068BCN2B | 1084 | 808 | 778 | 15.1 |
| FCE-085BCN2A | 944 | 808 | 778 | 17.8 | FCE-085BCN2B | 1084 | 808 | 778 | 17.9 |
| FCE-102BCN2A | 944 | 808 | 778 | 18.3 | FCE-102BCN2B | 1084 | 808 | 778 | 18.4 |
| FCE-136BCN2A | 1374 | 1238 | 1208 | 29 | FCE-136BCN2B | 1634 | 1238 | 1208 | 29.1 |
| FCE-170BCN2A | 1374 | 1238 | 1208 | 29.3 | FCE-170BCN2B | 1634 | 1238 | 1208 | 29.4 |
| FCE-204BCN2A | 1634 | 1498 | 1468 | 33.4 | FCE-204BCN2B | 1754 | 1498 | 1468 | 33.5 |
| FCE-238BCN2A | 1634 | 1498 | 1468 | 33.6 | FCE-238BCN2B | 1754 | 1498 | 1468 | 33.7 |


Horizontal and concealed type with back type air return box:



| standard drainage pan | | | | | | extended drainage pan | | | | | | |
|-----------------------|------------------------|------|------|------|-------------|-----------------------|------------------------|------|------|------|-------------|------|
| model | external dimension(mm) | | | | weight (kg) | model | external dimension(mm) | | | | weight (kg) | |
| | A | B | C | D | | | A | B | C | D | | |
| | | | | | | | | | | | 451 | 15.4 |
| FCE-051BCB2A | 624 | 508 | 478 | 451 | 14.5 | FCE-051BCB2B | 944 | 508 | 478 | 451 | 15.5 | |
| FCE-068BCB2A | 944 | 808 | 778 | 751 | 18.3 | FCE-068BCB2B | 1084 | 808 | 778 | 751 | 18.8 | |
| FCE-085BCB2A | 944 | 808 | 778 | 751 | 18.5 | FCE-085BCB2B | 1084 | 808 | 778 | 751 | 19 | |
| FCE-102BCB2A | 944 | 808 | 778 | 751 | 18.6 | FCE-102BCB2B | 1084 | 808 | 778 | 751 | 19.1 | |
| FCE-136BCB2A | 1374 | 1238 | 1208 | 1183 | 28.5 | FCE-136BCB2B | 1634 | 1238 | 1208 | 1183 | 29.4 | |
| FCE-170BCB2A | 1374 | 1238 | 1208 | 1183 | 28.7 | FCE-170BCB2B | 1634 | 1238 | 1208 | 1183 | 29.6 | |
| FCE-204BCB2A | 1634 | 1498 | 1468 | 1443 | 34.5 | FCE-204BCB2B | 1754 | 1498 | 1468 | 1443 | 34.9 | |
| FCE-238BCB2A | 1634 | 1498 | 1468 | 1443 | 34.9 | FCE-238BCB2B | 1754 | 1498 | 1468 | 1443 | 35.3 | |

Все каталоги и инструкции здесь: <https://splitsystema48.ru/instrukcii-po-ekspluatácii-kondicionerov.html>

Horizontal and concealed type with down type air return box:



| standard drainage pan | | | | | | extended drainage pan | | | | | |
|-----------------------|------------------------|------|------|------|-------------|-----------------------|------------------------|------|------|------|-------------|
| model | external dimension(mm) | | | | weight (kg) | model | external dimension(mm) | | | | weight (kg) |
| | A | B | C | D | | | A | B | C | D | |
| FCE-034BCD2A | 624 | 508 | 478 | 451 | 14.4 | FCE-034BCD2B | 944 | 508 | 478 | 451 | 15.4 |
| FCE-051BCD2A | 624 | 508 | 478 | 451 | 14.5 | FCE-051BCD2B | 944 | 508 | 478 | 451 | 15.5 |
| FCE-068BCD2A | 944 | 808 | 778 | 751 | 18.3 | FCE-068BCD2B | 1084 | 808 | 778 | 751 | 18.8 |
| FCE-085BCD2A | 944 | 808 | 778 | 751 | 18.5 | FCE-085BCD2B | 1084 | 808 | 778 | 751 | 19 |
| FCE-102BCD2A | 944 | 808 | 778 | 751 | 18.6 | FCE-102BCD2B | 1084 | 808 | 778 | 751 | 19.1 |
| FCE-136BCD2A | 1374 | 1238 | 1208 | 1183 | 28.5 | FCE-136BCD2B | 1634 | 1238 | 1208 | 1183 | 29.4 |
| FCE-170BCD2A | 1374 | 1238 | 1208 | 1183 | 28.7 | FCE-170BCD2B | 1634 | 1238 | 1208 | 1183 | 29.6 |
| FCE-204BCD2A | 1634 | 1498 | 1468 | 1443 | 34.5 | FCE-204BCD2B | 1754 | 1498 | 1468 | 1443 | 34.9 |
| FCE-238BCD2A | 1634 | 1498 | 1468 | 1443 | 34.9 | FCE-238BCD2B | 1754 | 1498 | 1468 | 1443 | 35.3 |

6 . Installation instruction

Inspection when receipt

Each fan coil unit is packed with the carton to prevent being damaged in the transportation or installation.

Все каталоги и инструкции здесь: <https://splitsystema48.ru/instrukcii-po-ekspluatatsii-kondicionerov.html>

on, or if there

is obvious damage.

2.If the carton is damaged obviously, please unfold the carton to check the unit and its accessories.

3.Check the unit hidden damage.

4.If the hidden damage is found, please do not move the unit and the specialist will check if the damage occurs before or after the delivery.

5.If damage occurs, please inform the carrier. The carrier and the consignee must have an inspection together.

6.Please do not modify the unit before the responsibility is confirmed.

Safety precaution

To ensure the installation and the operation favorably, please check the below items before installation:

1.The unit should be enough space for installation and maintenance; please refer to the unit exterior dimension figure; there should be movable ceiling or check hole for daily maintenance.

2.Before installation, please confirm the pipe and electric wiring position.

3.Check if the suspension device is strong enough to support the unit.

4.All the units must be installed horizontally to ensure the water drainage smoothly and the normal operation.

5.The unit connecting the duct should be in the allowable external static pressure range.

6.The freezed water valve and the heat insulation will be supplied by the installer.

Installation

The installation can be performed according to the dimension figure and the installation figure. It can be mounted on the ceiling through the suspension pole, please perform as follows:

1.Install the suspension pole or other similar devices.

2.Tighten the upper screw and the washer, make the unit not move in operation.

3.Put the suspension pole into the suspension holder of the unit.

4.Tighten the lower screw and the washer to fix the unit, keep the unit horizontal to ensure the condensate water can flow out, and then tighten the upper screw.

Freezed water pipe connection

Connect the duct made of galvanized steel plate to the flange on the inlet/outlet frame. Please refer to the dimension figure, inset the duct into the flange and fix them with the screws. If the dimensions of both sides are different, connect them with the changing connector.

Connect the freezed water pipe to the coil with 3/4" outer grooved connector. Water inlet pipe is upper, and water outlet pipe is lower. The dimension is shown in the figure.

Condensate water pipe connection

The condensate water pipe can be PVC material or made of steel, connect the pipe to the drain pan with 3/4" inner grooved connector. At the connection, the adhesive tape against water leakage. The gradient of the drainage pipe should be at least 1:50 as suggestion.

Note: The freezed water pipe and the condensate pipe must be heat preserved, and please take especial notice of the end of heat preservation material against the dew in cooling mode.

Electric wiring

Electric wiring please refers to the wiring diagram.


The earthing point should be in the earthing system of the building.

All the wirina should comply with the local electric reulation.

Все каталоги и инструкции здесь: <https://splitsystema48.ru/instrukcii-po-ekspluatácii-kondicionerov.html>

d. The wire should be copper conductor, because other conductor will result in over heat and the unit being damaged.



If the unit is in ceiling concealed type, the air return box must be installed, as the figure:



The distance between the duct air outlet and the air conditioner air outlet will depend on the actual duct length and the actual static pressure terminal:

Installation of long/short duct is shown in below figure; when short duct is connected, the motor will use the low static pressure terminal, and the distance should be no more than 0.5m; when long duct is connected, the motor will use the high static pressure terminal, at this time, the distance should be no more than 5m.

Note: When in low static pressure, connect the high/med/low terminal to the 3-speed switch(or fan coil controller); when in high static pressure, connect the super high/high/med terminal to the 3-speed switch (or fan coil controller); one 3-speed switch(or fan coil controller) only can control one set of fan coil unit.



7. Installation inspection and startup

Installation inspection

Before startup, please cut off the power source to avoid injury.

- 1.The unit must be fixed firmly with the suspension pole and the ceiling or roof.
- 2.Air duct should be installed firmly.
- 3.Water pipe should be connected well and there is no leakage.
- 4.Drainage pipe should be connected well and there is no leakage.
- 5.Electric control system is connected completely, and there is no bad connection or leakage.
- 6.Finish reading the operation manual, and familiar with the unit.

Startup

The fan coil unit can be controlled by the fan speed switch or the thermostat.

The thermostat includes one fan speed switch, one ON/OFF switch and one temperature control element.

The element can control the frozen water switch and one temperature setting dialing switch. And the

Все каталоги и инструкции здесь: [EE/high/mod/low"](#), which can to control

the air volume.

Discharging operation

When the system is filled with water for the first time, there will be some remaining smell in the system, which will concentrate on the top of fan coil. The water outlet connector of fan coil is equipped with the manual discharging valve. When there is remaining smell in the fan coil, the unit will sound abnormal noise. Turning the discharging valve exhausts the air; if the valve is too fast, you can turn it with a plier at counter-clockwise until the steady water is exhausted from the valve, then tighten the valve.

8. Maintenance

Before maintenance, please cut off the power source to avoid injury.

Every month Check if the drainage pan is clean and if the condensate water can flow to the drainage pipe smoothly.

- Every year
1. Check if the outer case is dusty, please clean and maintain it.
 2. Check if the fan blade and the scroll case is damaged, turn the fan blade by hand to ensure there is no obstacle to stop it.
 3. Check if the coil fin is too dirty or damaged.
 4. Clean and tighten all the wires.
 5. Exhaust all the frozen water in the system, then move away the dirt.

Note:

1. The non-treated water will result in the dirt, the corrosion and poor performance; the system debugging and the maintenance should be executed by the specialist.
2. For the limited bracket weight and the dimension, the maintenance should be executed by two persons to ensure safety.
3. If the unit stops running, the water in system should be exhausted to avoid icing in the pipe, which will break the pipe.

Clean the coil

The blocked or dirty coil will lower the cooling capacity. Please perform as follow:

1. Cut off power source and motor wire, and make the fan stop running.
2. Loosen the screw between the side plate and the drainage pan.
3. Separate the shell and the drainage pan, and loosen the screw between the fixing plate and the side plate.
4. Draw out the evaporator.
5. Clean the coil.
6. Re-assemble the evaporator and the drainage pan, and fix them with the screws.
7. Supply the electricity and the water to the unit, and check the effect.


Drainage pan

The drainage pan must be cleaned in order to exhaust the condensate water.

9. Troubleshooting

| Failure description | Reason | Solution |
|--|------------------------------------|--------------------------|
| Too low air flow | Too dirty filter | Clean or replace |
| | Blocked air inlet/outlet | Smooth it |
| Large noise level | Motor bearing sounds | Modity or replace |
| Insufficient cooling /heating capacity | Dirty filter | Clean or replace |
| | Wrong water temperature | Adjust water temperature |
| | Low water flow | Increase water flow |
| | Low air flow | Increase air flow |
| | Blocked water pipe of drainage pan | Smooth it |
| Water leakage | Bad heat insulation of pipe | Heat preservation |
| | Unit not horizontal | Make it keep horizontal |
| | Cracked heat exchanger | Modity or replace |

10 Wiring diagram



Большая библиотека технической документации

<https://splitsystema48.ru/instrukcii-po-ekspluatacii-kondicionerov.html>

каталоги, инструкции, сервисные мануалы, схемы.