



Domestic Air conditioner

CAUTION

1. READ THIS MANUAL CAREFULLY TO
DIAGNOSE TROUBLE CORRECTLY
BEFORE OFFERING SERVICE.
2. THIS MANUAL IS USED BY QUALIFIED
APPLIANCE TECHNICIANS ONLY.
3. HAIER DOES NOT ASSUME ANY
RESPONSIBILITY FOR PROPERTY
DAMAGE OR PERSONAL INJURY FOR
IMPROPER
SERVICE PROCEDURES DONE BY ONE
UNQUALIFIED PERSON.




TECHNICAL DATA

ON/OFF

Wall mounted Type ARC-Series

HSU-07C03



Большая библиотека технической документации

<https://splitsystema48.ru/instrukcii-po-ekspluatacii-kondicionerov.html>

каталоги, инструкции, сервисные мануалы, схемы.

Table of Contents

1. Features	2
2. Specifications	3
3. Remote controller lists	6
4. Sensors lists	6
5. Dimensional drawings	7
6. Operation range	9
7. Piping diagrams	10
8. Wiring diagrams	11
9. Capacity diagrams and curves diagrams	13
10. Sound level	14
11. Accessories	15
12. Control systems	16
13. Center of gravity	18
14. Installations	19

1 Features



Anti-mold filter: Catches most small particles and remove unpleasant odors effectively .



Child lock: Avoid the child's wrong operation on the remote controller .



Auto mode: According to the fixed temperature "26C",the unit will adjust the operation mode automatically.



Auto restart: The function permits automatic return to previous peration conditions after asudden power blackout .



Sleep mode: The setting temperature and the indoor noise can be adjusted to a more comfortable level when you set the "sleep mode"during night sleep .



24Hour timer: Use the timer function to set on,or off,or from on to off,or from off to on .



4 Fan setting: Slect the fan speed LO,MED,HI,AUTO



Easy clean design: The panel is easy to wash and the airflow vents can be detached without any special tools for quick cleaning of the inside of the air conditioner .



2. Specifications

This information was not available at the time of publication .

NOMINAL CAPACITY and NOMINAL INPUT					
Model			HSU-07C03		
NOMINAL CAPACITY(3-4)	Cooling(1)	norm.	kw	2.10	
	Heating(2)	norm.	kw	-----	
NOMINAL INPUT	Cooling	norm	kw	0.72	
	Heating	norm.	kw	-----	
EER	Cooling			2.92	
COP	Heating			-----	
ENERGY LABEL(7-8)	Cooling			----	
	Heating			----	
ANNUAL ENERGY CONSUMPTION(9)	Cooling		kwh	307.5	

TECHNICAL SPECIFICATIONS						
INDOOR UNITS				HSU-07C03		
DIMENSIONS	Unit	H	mm	265		
		W	mm	795		
		D	mm	182		
WEIGHT	Unit	kg		7.2		
COLOR	Unit	white				
SOUND LEVEL	Sound pressure (cooling/heating)(5)	high	dB(A)	37		
		medium	dB(A)	35		
		low	dB(A)	30		
	Sound power(cooling/heating)(6)	high	dB(A)	37		
FAN	Air flow rate(cooling/heating)	high	m ³ /min	6.8		
		low	m ³ /min	6.0		
		super low	m ³ /min	5.2		
	Speed(cooling/heating)	steps		5steps,silent and auto		
		high	rpm	1150		
		medium	rpm	1100		
	low	rpm	920			
Type	Cross flow fan					
Motor output	W		16			
AIR FILTER					Removable/washable/mildew proof	
REMOTE CONTROLLER					YL-M05EN	
TEMPERATURE CONTROL					Microcomputer control	
PIPING CONNECTIONS(external diameter)	liquid	mm	Φ 6.35			
	gas	mm	Φ 9.52			
	drain	mm	Φ 16			
INSULATION MATERIAL	Heat insulation type				both liquid and gas pipes	
HEAT EXCHANGGER	TYPE			ML fin - Φ 9.52HI - XA tube		
	Row x stage x fin pinth		mm	2 x 8 x1.4		

TECHNICAL SPECIFICATIONS					
OUTDOOR UNITS				HSU-07C03	
NET DIMENSIONS (stop valve, and bottom support is not included)	Unit	H	mm	430	
		W	mm	695	
		D	mm	245	
WEIGHT	Unit		kg	22	
COLOR	Unit	white			
SOUND LEVEL	Sound pressure(cooling/heating)(5)	high	dB(A)	54	
	Sound power(cooling/heating)(6)	high	dB(A)	54	
FAN	Air flow rate(cooling/heating)	high	m ³ /min	21	
		low	m ³ /min	---	
	Speed(cooling/heating)	high	rpm	830	
		low	rpm	---	
	Type	Propeller fan			
	Motor output		W	60	
REFRIGERANT CIRCUIT	Refrigerant type	R22			
	Refrigerant charge		kg	0.54	
	Maximum allowable distance between indoor and outdoor		m	7	
	Maximum allowable level difference		m	5	
	Refrigerant control	-----			
COMPRESSOR	Type	rotary Compressor			
	Model	RECHI 44R193AE-FJS			
	Motor output		w	790	
	Oil type	SUNISO 4GSI			
	Oil charge volume		L	0.27	
PIPING CONNECTIONS	liquid		mm	Φ 6.35	
	gas		mm	Φ 9.52	
	drain		mm	Φ 18	
INSULATION MATERIAL	Heat insulation type			both liquid and gas pipes	
HEAT EXCHANGGER	TYPE			ML - Φ 9.52HI - XAbube	
	Row x stage x fin pinth		mm	2 x 8 x1.4	

ELECTRICAL SPECIFICATIONS					
For indoor units only:			HSU-07C03		
CURRENT	Nominal running current	cooling	A	0.15	
		heating	A	-----	
	Maximum running current	cooling	A	0.15	
		heating	A	-----	

For combination indoor units+ outdoor units:				HSU-07C03	
CURRENT	Nominal running current	cooling	A	3.4	
		heating	A	-----	
	Maximum running current	cooling	A	4.6	
		heating	A	-----	
	Starting current	cooling	A	18	
		heating	A	-----	

For indoor units only:				HSU-07C03	
POWER SUPPLY				VM	
NOMINAL DISTRIBUTION SYSTEM VOLTAGE	Phase		1PH		
	Frequency	Hz	50		
	Voltage	V	220V~		

NOTES

- 1 Nominal cooling capacities are based on: indoor temperature 27°CDB/19°CWB * outdoor temperature 35°CDB * refrigerant piping length: 5m * level difference: 0m.
- 2 Nominal heating capacities are based on: indoor temperature 20°CDB * outdoor temperature 7°CDB/6°CWB * refrigerant piping length 5m (horizontal) * level difference 0m.
- 3 Capacities are net, including a deduction for cooling (an addition for heating) for indoor fan motor heat.
- 4 Units should be selected on nominal capacity. Maximum capacity is limited to peak periods.
- 5 The sound pressure level is measured via a microphone at a certain distance from the unit. For measuring conditions: please refer to item 6 of this chapter.
- 6 The sound power level is an absolute value indicating the "power" which a sound source generates.
- 7 Energy label: scale from A (most efficient) to G (less efficient).
- 8 The energy label Directive 2002/31/EC will enter into force once the relevant measurement standard will be published in the European official Standard.
- 9 Annual energy consumption: based on average use of 500 running hours per year at full load (= nominal conditions)

3 Remote controller lists


Model	HSU-07C03	
YR-M05	Y	
YR-H10	Y	

4 Sensors lists


INDOOR UNIT		
type	Description	Qty
Room sensor	It's used for detecting room temperature	1
Pipe sensor	It's used for detecting temperature of evaporator	1

5 Dimensional drawings

Indoor unit




Outdoor unit



6 Operation range


The name of parts

Cooling




7 Piping diagrams

Cooling mode




8 Wiring diagrams

Indoor unit




Outdoor unit




9 Capacity tables and curves diagrams

HSU-07C03 performance curves								
cooling value-temperature talbe								
indoor temp	outdoor temp.(humidity 46%)							
DB/WB	18°C	20°C	25°C	32°C	35°C	40°C	43°C	46°C
18/12°C	1286	1297	1307	1086	1096	1139	989	773
18/14°C	1769	1780	1847	1595	1558	1428	1316	1130
20/15°C	2251	2264	2277	2182	2020	1859	1723	1487
22/16°C	2197	2213	2230	2162	1987	1781	1642	1477
25/18°C	2144	2163	2182	2141	1954	1768	1645	1449
27/19°C	2405	2315	2365	2202	2100	1949	1826	1602
30/22°C	2682	2534	2722	2428	2298	2168	1996	1849
32/23°C	2782	2518	2728	2399	2342	2233	2105	1877
32/24°C	2861	2592	2806	2471	2413	2301	2170	1940




10 Sound level

Model	Sound pressure level			Measuring location Location of microphone	sound power level
	220 ~ V,50Hz				
	Cooling				
	H	L	SL		
HSU-07C03	37	35	30		37

Sound level data

HSU-07C03	100Hz	125Hz	250Hz	500Hz	1000Hz	2000Hz	4000Hz	6000Hz	8000Hz
INDOOR	41.7	34.7	33.6	32.6	30.5	28.2	19.7	0.0	0.0
OUTDOOR	51.7	46.5	47.2	45.6	43.9	39.7	33.0	29.9	28.9

Sound pressure spectrum




11 Accessories

Standard name	HSU-07C03	
Drain hose	1	
Plastic bag	1	
screw assembly	1	
Air purifier	2	
Battery	2	
Mounting plate	1	
Remote controller	1	
Installation manual	1	
Operation manual	1	

12 Control systems

Operation

Buttons and display of the remote controller.



1. Mode display

AUTO

COOL

DRY

HEAT

FAN

2. SWING display



3. FAN SPEED display

4. SLEEP display

5. LOCK display

6. SIGNAL SENDING

7. TIMER OFF display

8. TIMER ON display

9. CLOCK display

10. TEMP display

11. POWER ON/OFF

Used for unit start and stop.

12. MODE

Used to select AUTO run, COOL, DRY, HEAT and FAN operation

13. FAN

Used to select fan speed LO, MED, HI, AUTO

14. HOUR

Used to set clock and timer setting.

15. SWING

Used to set auto fan direction.

16. SLEEP

Used to select sleep mode.

17. LOCK

Used to lock buttons and LCD display.

18. TEMP.

Used to select your desired temp.

19. SET

Used to confirm timer and clock settings.

20. TIMER

Used to select TIMER ON, TIMER OFF, TIMER ON-OFF

21. CLOCK

Used to set correct time

22. RESET

Used to reset the controller back to normal condition.

Clock set

When unit is started for the first time and after replacing batteries in remote controller, clock should be adjusted as follows:

Press CLOCK button, "AM" or "PM" flashes.

Press Δ or ∇ to set correct time. Each press will increase or decrease 1min. If the button is kept depressed, time will change quickly.

After time setting is confirmed, press SET, "AM" and "PM" stop flashing, while clock starts working.

NOTE: Cooling only unit do not have displays and functions related with heating


Hints


After replacing with new batteries, remote controller will conduct self-check, displaying all information on LCD. Then, it will become normal.

Operation

Buttons and display of the remote controller.

If the unit which you purchased has healthy function, Remote controller should like the following figure:



1. Mode display
 AUTO ▾
 COOL ❄️
 DRY 💧
 HEAT ☀️
 FAN 🌀
2. SWING display
3. FAN SPEED display 
4. SLEEP display
5. LOCK display
6. SIGNAL SENDING
7. TIMER OFF display
8. TIMER ON display
9. CLOCK display
10. TEMP display
11. POWER ON/OFF
Used for unit start and stop.
12. MODE
Used to select AUTO run, COOL, DRY, HEAT and FAN operation
13. FAN
Used to select fan speed LO, MED, HI, AUTO
14. HOUR
Used to set clock and timer setting.
15. SWING
Used to set auto fan direction.
16. SLEEP
Used to select sleep mode.
17. LOCK
Used to lock buttons and LCD display.
18. TEMP.
Used to select your desired temp.
19. SET
Used to confirm timer and clock settings.
20. TIMER
Used to select TIMER ON, TIMER OFF, TIMER ON-OFF
21. CLOCK
Used to set correct time
22. RESET
Used to reset the controller back to normal condition.
23. HEALTH
Used to set healthy operation

BRIEF INTRODUCTION TO HEALTH OPERATION



The anion generator in the air conditioner can generate a lot of anion to effectively balance the quantity of positive and negative ions in the air and also to kill bacteria and speed up the dust sediment in the room and finally clean the air in the room.

NOTE: Cooling only unit do not have displays and functions related with heating

Hints



After replacing with new batteries, remote controller will conduct self-check, displaying all information on LCD. Then, it will become normal.

13 Center of gravity






14 Installations

Indoor unit installation drawings



Cut thermal insulation pipe to an appropriate length and wrap it with tape, making sure that no gap is left in the insulation pipe's cut line .



How to remove the air filter.

Open the inlet grille by pulling it upward.

Push up the filter's center tab slightly until it is released from the stopper, and remove the filter downward.

How to Attach the air filter.

Attach the filter correctly so that the "FRONT" indication is facing to the front. Make sure that the filter is completely fixed behind the stopper. If the right and left filters are not attached correctly, that may cause defects.



Close the inlet grille.

Outdoor unit installation drawings


HSU-07C03

Model	26/28 class
Max.allowable length	Cooling only : 7 m Heat pump : 7 m
Max.allowable height	5 m
Additional refrigerant required for refrigerant pipe exceeding 5m in length	16g/m
Gas pipe	O.D. 9.52/12.7
Liquid pipe	O.D. 6.35/9.52

*Be sure to add the proper amount of additional refrigerant.
Failure to do so may result in reduced performance.



- Fix the unit to concrete or block with bolts ($\phi 10\text{mm}$) and nuts firmly and horizontally.
- When fitting the unit to wall surface, roof or rooftop, fix a supporter surely with nails or wires in consideration of earthquake and strong wind.
- If vibration may affect the house, fix the unit by attaching a vibration-proof mat.



Sincere Forever



Haier Group

Haier Industrial Park, No.1, Haier Road

266101, Qingdao, China

E-mail: hractech@haier.com

Tel: +86 532 87636957

[Http://www.haier.com](http://www.haier.com)

Edited by: Zhao Jicheng

Signed by: Yang Bifei

Approved by: Zhu Zhenxue