


SERVICE MANUAL

TECHNICAL INFORMATION


RAS-07G4/RAC-07G4
RAS-09G4/RAC-09G4
RAS-14G4/RAC-14G4

REFER TO THE FOUNDATION MANUAL


FOR SERVICE PERSONNEL ONLY



RAS-07G4
 RAS-09G4
 RAS-14G4



RAC-07G4
 RAC-09G4



RAC-14G4

CONTENTS

SPECIFICATIONS	5
HOW TO USE	8
CONSTRUCTION AND DIMENSIONAL DIAGRAM	30
MAIN PARTS COMPONENT	32
WIRING DIAGRAM	34
PRINTED WIRING BOARD LOCATION DIAGRAM	37
BLOCK DIAGRAM	39
BASIC MODE	41
REFRIGERATING CYCLE DIAGRAM	47
DESCRIPTION OF MAIN CIRCUIT OPERATION	49
AUTO SWING FUNCTION	57
SERVICE CALL Q & A	58
TROUBLE SHOOTING	63
PARTS LIST AND DIAGRAM	66

SPECIFICATIONS

TYPE		(WALL TYPE)					
		INDOOR UNIT	OUTDOOR UNIT	INDOOR UNIT	OUTDOOR UNIT	INDOOR UNIT	OUTDOOR UNIT
MODEL		RAS-07G4	RAC-07G4	RAS-09G4	RAC-09G4	RAS-14G4	RAC-14G4
POWER SOURCE		1 PHASE, 50 Hz, 220-230-240V		1 PHASE, 50 Hz, 220-230-240V		1 PHASE, 50 Hz, 220-230-240V	
COOLING	TOTAL INPUT (W)	590-610-630		890-900-950		1060-1090-1120	
	TOTAL AMPERES (A)	2.80-2.80-2.80		4.20-4.10-4.10		5.00-5.00-4.90	
	CAPACITY	(kW)	2.10		2.90		3.50
(B.T.U./h)		7,160		9,900		11,940	
DIMENSIONS (mm)	W	780	700	780	700	780	750
	H	280	570	280	570	280	570
	D	210	210	210	210	210	280
NET WEIGHT (kg)		9.0	32	9.0	32	9.0	38

※ After installation


SPECIFICATIONS AND PARTS ARE SUBJECT TO CHANGE FOR IMPROVEMENT

ROOM AIR CONDITIONER

INDOOR UNIT + OUTDOOR UNIT

SAFETY DURING REPAIR WORK

1. In order to disassemble and repair the unit in question, be sure to disconnect the power cord plug from the power outlet before starting the work.



2. If it is necessary to replace any parts, they should be replaced with respective genuine parts for the unit, and the replacement must be effected in correct manner according to the instructions in the Service Manual of the unit.

If the contacts of electrical parts are defective, replace the electrical parts without trying to repair them.



3. After completion of repairs, the initial state should be restored.
4. Lead wires should be connected and laid as in the initial state.
5. Modification of the unit by user himself should absolutely be prohibited.
6. Tools and measuring instruments for use in repairs or inspection should be accurately calibrated in advance.
7. In installing the unit having been repaired, be careful to prevent the occurrence of any accident such as electrical shock, leak of current, or bodily injury due to the drop of any part.
8. To check the insulation of the unit, measure the insulation resistance between the power cord plug and grounding terminal of the unit. The insulation resistance should be $1M\Omega$ or more as measured by a 500V DC megger.
9. The initial location of installation such as window, floor or the other should be checked for being and safe enough to support the repaired unit again. If it is found not so strong and safe, the unit should be installed at the initial location reinforced or at a new location.
10. Any inflammable thing should never be placed about the location of installation.
11. Check the grounding to see whether it is proper or not, and if it is found improper, connect the grounding terminal to the earth.



WORKING STANDARDS FOR PREVENTING BREAKAGE OF SEMICONDUCTORS

1. Scope

The standards provide for items to be generally observed in carrying and handling semiconductors in relative manufacturers during maintenance and handling thereof. (They apply the same to handling of abnormal goods such as rejected goods being returned).

2. Object parts

- (1) Micro computer
- (2) Integrated circuits (IC)
- (3) Field-effect transistors (FET)
- (4) P.C. boards or the like on which the parts mentioned in (1) and (2) of this paragraph are equipped.

3. Items to be observed in handling

- (1) Use a conductive container for carrying and storing of parts. (Even rejected goods should be handled in the same way).




Fig. 1. Conductive Container

- (2) When any part is handled uncovered (in counting, packing and the like), the handling person must always use himself as a body earth. (Make yourself a body earth by passing one M ohm earth resistance through a ring or bracelet).
- (3) Be careful not to touch the parts with your clothing when you hold a part even if a body earth is being taken.
- (4) Be sure to place a part on a metal plate with grounding.
- (5) Be careful not to fail to turn off power when you repair the printed circuit board. At the same time, try to repair the printed circuit board on a grounded metal plate.




Fig. 2. Body Earth

(6) Use a three wire type soldering iron including a grounding wire.




Fig. 3. Grounding of the working table




Fig. 4. Grounding a soldering iron

Use a high insulation mode (100V, 10MΩ or higher) when ordinary iron is to be used.

(7) In checking circuits for maintenance, inspection or some others, be careful not to have the test probes of the measuring instrument shortcircuit a load circuit or the like.

 **CAUTION**

1. In quiet or stopping operation, slight flowing noise of refrigerant in the refrigerating cycle is heard occasionally, but this noise is not abnormal for the operation.
2. When it thunders nearby, it is recommended to stop the operation and to disconnect the power cord plug from the power outlet for safety.
3. In the event of power failure, the airconditioner will restart automatically in the previously selected mode once the power is restored. In the event of power failure during TIMER operation, the timer will be reset and the unit will begin or stop operating under a new timer setting.
4. If the room air conditioner is stopped by adjusting thermostat, or missoperation, and re-start in a moment, there is occasion that the cooling and heating operation does not start for 3 minutes, it is not abnormal and this is the result of the operation of IC delay circuit. This IC delay circuit ensures that there is no danger of blowing fuse or damaging parts even if operation is restarted accidentally.
5. This room air conditioner should not be used at the cooling operation when the outside temperature is below 10°C (50°F).

SPECIFICATIONS

MODEL		RAS-07G4 RAS-09G4 RAS-14G4	RAC-07G4	RAC-09G4	RAC-14G4
FAN MOTOR		20 W	20 W	30 W	
FAN MOTOR CAPACITOR		NO	1.5 μ F, 450 VAC	2.5 μ F, 450VAC	
FAN MOTOR PROTECTOR		NO	NO		
COMPRESSOR		–	5RS080	5PS112	5PS132
COMPRESSOR MOTOR CAPACITOR		NO	20 μ F, 450 VAC	25 μ F, 450 VAC	
OVERLOAD PROTECTOR		NO	YES		
OVERHEAT PROTECTOR		NO	NO		
FUSE (for MICROPROCESSOR)		3.15A	NO		
POWER RELAY		G4A	NO		
POWER SWITCH		YES	NO		
TEMPORARY SWITCH		YES	NO		
SERVICE SWITCH		YES	NO		
TRANSFORMER		NO	NO		
VARISTOR		450NR	NO		
FUSE CAPACITY (TIME DELAY FUSE)		-----	10 A		15 A
THERMOSTAT		YES(IC)	NO		
REMOTE CONTROL SWITCH (LIQUID CRYSTAL)		YES	NO		
REFRIGERANT CHARGING VOLUME (Refrigerant 410A)	UNIT	-----	600g	650g	1050g
	MAX. PIPES	-----	10m		15m

WITHOUT REFRIGERANT BECAUSE COUPLING IS FLARE TYPE


MODEL RAS-07G4 / RAC-07G4 and RAS-09G4 / RAC-09G4

Figure showing the installation of Indoor and Outdoor unit



CAUTION

The installation height of indoor unit must be 2.3m or more from floor in a non public area




MODEL RAS-14G4 / RAC-14G4

Figure showing the installation of Indoor and Outdoor unit



CAUTION




The installation height of indoor unit must be 2.3m or more from floor in a non public area










SAFETY PRECAUTION

- Please read the “Safety Precaution” carefully before operating the unit to ensure correct usage of the unit.
- Pay special attention to signs of “**▲ Warning**” and “**▲ Caution**”. The “Warning” section contains matters which, if not observed strictly, may cause death or serious injury. The “Caution” section contains matters which may result in serious consequences if not observed properly. Please observe all instructions strictly to ensure safety.
- The sign indicate the following meanings.




 Make sure to connect earth line.	 The sign in the figure indicates prohibition.
 Indicates the instructions that must be followed.	

- Please keep this manual after reading.






PRECAUTIONS DURING INSTALLATION

 WARNING	<ul style="list-style-type: none"> ● Do not reconstruct the unit. Water leakage, fault, short circuit or fire may occur if you reconstruct the unit by yourself. 	
	<ul style="list-style-type: none"> ● Please ask your sales agent or qualified technician for the installation of your unit. Water leakage, short circuit or fire may occur if you install the unit by yourself. 	
 CAUTION	<ul style="list-style-type: none"> ● Please use earth line. Do not place the earth line near water or gas pipes, lightning-conductor, or the earth line of telephone. Improper installation of earth line may cause electric shock. 	
	<ul style="list-style-type: none"> ● A circuit breaker should be installed depending on the mounting site of the unit. Without a circuit breaker, the danger of electric shock exists. 	
	<ul style="list-style-type: none"> ● Do not install near location where there is flammable gas. The outdoor unit may catch fire if flammable gas leaks around it. ● Please ensure smooth flow of water when installing the drain hose. 	

PRECAUTIONS DURING SHIFTING OR MAINTENANCE

 WARNING	<ul style="list-style-type: none"> ● Should abnormal situation arises (like burning smell), please stop operating the unit and turn off the circuit breaker. Contact your agent. Fault, short circuit or fire may occur if you continue to operate the unit under abnormal situation. 	 
	<ul style="list-style-type: none"> ● Please contact your agent for maintenance. Improper self maintenance may cause electric shock and fire. 	
	<ul style="list-style-type: none"> ● Please contact your agent if you need to remove and reinstall the unit. Electric shock or fire may occur if you remove and reinstall the unit yourself improperly. 	

PRECAUTIONS DURING OPERATION

 WARNING	<ul style="list-style-type: none"> ● Avoid an extended period of direct air flow for your health. 	
	<ul style="list-style-type: none"> ● Do not insert a finger, a rod or other objects into the air outlet or inlet. As the fan is rotating at a high speed, it will cause injury. Before cleaning, be sure to stop the operation and turn the breaker OFF. 	
	<ul style="list-style-type: none"> ● Do not use any conductor as fuse wire, this could cause fatal accident. 	
	<ul style="list-style-type: none"> ● During thunder storm, disconnect and turn off the circuit breaker. 	


PRECAUTIONS DURING OPERATION

- The product shall be operated under the manufacturer specification and not for any other intended use.



- Do not attempt to operate the unit with wet hands, this could cause fatal accident.

- When operating the unit with burning equipments, regularly ventilate the room to avoid oxygen insufficiency.



- Do not direct the cool air coming out from the air-conditioner panel to face household heating apparatus as this may affect the working of apparatus such as the electric kettle, oven etc.

- Please ensure that outdoor mounting frame is always stable, firm and without defect. If not, the outdoor unit may collapse and cause danger.




- Do not splash or direct water to the body of the unit when cleaning it as this may cause short circuit.



C
A
U
T
I
O
N

- Do not use any aerosol or hair sprays near the indoor unit. This chemical can adhere on heat exchanger fin and blocked the evaporation water flow to drain pan. The water will drop on tangential fan and cause water splashing out from indoor unit.




- Please switch off the unit and turn off the circuit breaker during cleaning, the high-speed fan inside the unit may cause danger.

- Turn off the circuit breaker if the unit is not to be operated for a long period.



- Do not climb on the outdoor unit or put objects on it.

- Do not put water container (like vase) on the indoor unit to avoid water dripping into the unit. Dripping water will damage the insulator inside the unit and causes short-circuit.




- Do not place plants directly under the air flow as it is bad for the plants.

- When operating the unit with the door and windows opened, (the room humidity is always above 80%) and with the air deflector facing down or moving automatically for a long period of time, water will condense on the air deflector and drips down occasionally. This will wet your furniture. Therefore, do not operate under such condition for a long time.
- If the amount of heat in the room is above the cooling or heating capability of the unit (for example: more people entering the room, using heating equipments and etc.), the preset room temperature cannot be achieved.

NAMES AND FUNCTIONS OF EACH PART

INDOOR UNIT



Air filter

To prevent dust from coming into the indoor unit.
(Refer page 26)

Front panel

Indoor unit indicators

Light indicator showing the operating condition.
(Refer page 11)

Horizontal deflector • Vertical deflector (Air Outlet)

(Refer page 17)




Remote controller

Send out operation signal to the indoor unit. So as to operate the whole unit.
(Refer page 12)

OUTDOOR UNIT

RAC-07G4
RAC-09G4



Drain pipe


Condensed water drain to outside.

Connecting cord and insulation pipe for piping

Air inlet (Back, Left side)

Air outlet

RAC-14G4



Drain pipe

Condensed water drain to outside.

Connecting cord and insulation pipe for piping


Air inlet (Back and Left side)

Air outlet


MODEL NAME AND DIMENSIONS

MODEL	WIDTH (mm)	HEIGHT (mm)	DEPTH (mm)
RAS-07G4/09G4/14G4	780	280	210
RAC-07G4/09G4	700	570	210
RAC-14G4	750	570	280

INDOOR UNIT INDICATORS



FILTER LAMP

When the device is operated for a total of about 100 hours, the FILTER lamp lights indicates that it is time to clean the filter. The lamp goes out when the “ (AUTO SWING)” button is pressed while the device is on “STANBY MODE”.


OPERATION LAMP

This lamp lights during operation.

TIMER LAMP

This lamp lights when the timer is working.

OPERATION INDICATOR



TEMPORARY SWITCH


Use this switch to start and stop when the remote controller does not work. [Use non-conductor stick (example toothpick)]

- By pressing the temporary switch, the operation is done in previously set operation mode.
- When the operation is done using the temporary switch after the power source is turned off and turn on again, the operation is done in automatic mode.

NAMES AND FUNCTIONS OF REMOTE CONTROL UNIT

REMOTE CONTROLLER

- This controls the operation of the indoor unit. The range of control is about 7 meters. If indoor lighting is controlled electronically, the range of control may be shorter.
This unit can be fixed on a wall using the fixture provided. Before fixing it, make sure the indoor unit can be controlled from the remote controller.
- Handle the remote controller with care. Dropping it or getting it wet may compromise its signal transmission capability.
- After new batteries are inserted into the remote controller, the unit will initially require approximately 10 seconds to respond to commands and operate.




	AUTO
	COOL
	DEHUMIDIFY
	CIRCULATION
	FAN
	FAN SPEED LOW MED HI
	SLEEPING
	STOP (CANCEL)
	START (RESERVE)
	START/STOP
	TIME
	TIMER SET
	TIMER SELECTOR ON TIMER OFF TIMER
	AUTO SWING

Precautions for Use


- Do not put the remote controller in the following places.
 - Under direct sunlight.
 - In the vicinity of a heater.
- Handle the remote controller carefully. Do not drop it on the floor, and protect it from water.
- Once the outdoor unit stops, it will not restart for about 3 minutes (unless you turn the power switch off and on or unplug the power cord and plug it in again).
This is to protect the device and does not indicate a failure.
- If you press the FUNCTION selector button during operation, the device may stop for about 3 minutes for protection.

AUTOMATIC OPERATION

The device will automatically determine the mode of operation COOL, or Dehumidify, depending on the initial room temperature. The selected mode of operation will not change when the room temperature varies.





1


Press the FUNCTION selector so that the display indicates the  (AUTO) mode of operation.

- When AUTO has been selected, the device will automatically determine the mode of operation COOL or Dehumidify, depending on the initial room temperature and outdoor temperature.


START STOP

Press the  (START/STOP) button.
Operation starts with a beep.
Press the button again to stop operation.

- As the settings are stored in memory in the remote controller, you only have to press the  (START/STOP) button next time.



You can raise or lower the temperature setting as necessary by maximum of 3°C.



Press the temperature button and the temperature setting will change by 1°C each time.

- The preset temperature and the actual room temperature may vary somewhat depending on conditions.
- The display does not indicate the preset temperature in the AUTO mode. If you change the setting, the indoor unit will produce a beep.


■ CONDITION OF AUTOMATIC OPERATION

- The selected mode of operation will not change during the operation even though the room temperature change.

INITIAL ROOM TEMPERATURE (APPROX.)	FUNCTION	TEMPERATURE SETTING	FAN SPEED
Over 27°C	➔ COOL	27°C	HIGH at start, LOW after the preset temperature is reached.
16~27°C	➔ DEHUMIDIFY	Slightly lower than the room temperature	LOW

COOLING OPERATION

Use the device for cooling when the outdoor temperature is 22-42°C.
If indoor humidity is very high (80%), some dew may form on the air outlet grille of the indoor unit.



1


Press the FUNCTION selector so that the display indicates * (COOL).

Set the desired FAN SPEED with the ↻ (FAN SPEED) button (the display indicates the setting).

- ↻ (AUTO): The FAN SPEED is HI at first and varies to MED automatically when the preset temperature has been reached.
- ↓ (HI) : Economical as the room will become cool quickly.
- ↻ (MED) : Quiet.
- ↻ (LOW) : More quiet.

2

Set the desired room temperature with the TEMPERATURE button (the display indicates the setting).



The range of 25-28°C is recommended as the room temperature for cooling.

If the temperature setting is 27°C, the room temperature will be controlled at around 27°C.

The temperature setting and the actual room temperature may vary some how depending on conditions.

3


**START
STOP**

Press the ⏻ (START/STOP) button. Cooling operation starts with a beep. Press the button again to stop operation. The cooling function does not start if the temperature setting is higher than the current room temperature (even though the ⏻ (OPERATION) lamp lights). The cooling function will start as soon as you set the temperature below the current room temperature.

- As the settings are stored in memory in the remote controller, you only have to press the ⏻ (START/STOP) button next time.

DEHUMIDIFYING OPERATION

Use the device for dehumidifying when the room temperature is over 16°C.
When it is under 15°C, the dehumidifying function will not work.



1 Press the FUNCTION selector so that the display indicates ◊ (DEHUMIDIFY).
The FAN SPEED is set at LOW automatically.
The FAN SPEED button does not work.

2 Set the desired room temperature with the TEMPERATURE button (the display indicates the setting).

START STOP Press the Ⓜ (START/STOP) button. Dehumidifying operation starts with a beep. Press the button again to stop operation.

■ As the settings are stored in memory in the remote controller, you only have to press the Ⓜ (START/STOP) button next time.


■ Dehumidifying Function

When the room temperature is higher than the temperature setting: The device will dehumidify the room, reducing the room temperature to the preset level.

When the room temperature is lower than the temperature setting: Dehumidifying will be performed at the temperature setting slightly lower than the current room temperature, regardless of the temperature setting. The function will stop (the indoor unit will stop emitting air) as soon as the room temperature becomes lower than the setting temperature.

FAN OPERATION

You can use the device simply as an air circulator. Use this function to dry the interior of the indoor unit at the end of summer.




FAN SPEED (AUTO)

..... When the AUTO fan speed mode is set in the cooling operation:

For the cooling operation

- When the difference of room temperature and setting temperature is large, fan starts to run at HI speed.
- After room temperature reaches the preset temperature, the cooling operation, which changes the fan speed and room temperature to obtain optimum conditions for natural healthful cooling will be performed.


CIRCULATION OPERATION





ADJUSTING THE AIR DEFLECTOR

1

Adjustment of the conditioned air in the upward and downward directions.

The horizontal air deflector is automatically set to the proper angle suitable for each operation. The deflector can be swung up and down continuously and also set to the desired angle using the “ (AUTO SWING)” button.



- If the “ (AUTO SWING)” button is pressed once, the horizontal air deflector swings up and down. If the button is pressed again, the deflector stops in its current position. Several seconds (about 6 seconds) may be required before the deflector starts to move.
- Use the horizontal air deflector within the adjusting range shown on the right.
- When the operation is stopped, the horizontal air deflector moves and stops at the position where the air outlet closes.

CAUTION


- In “Cooling” operation, do not keep the horizontal air deflector swinging for a long time. Some dew may form on the horizontal air deflector and dew may drop.

When cooling, dehumidifying

Vertical

about 15°


about 60°



2

Adjustment of the conditioned air to the left and right.


Hold the vertical air deflector as shown in the figure and adjust the conditioned air to the left and right.



CAUTION


- When operating the unit in cooling operation with the air deflector facing down and moving automatically for a long period of time, water will condensed on the air deflector and drips down occasionally. This will wet your furniture.

HOW TO SET THE TIMER



Time, Day, Month



After you change the batteries;



1 Set the current month and day with the TIMER control button.

OFF-Timer


1 Press the (OFF-TIMER) button. The (OFF) mark blinks on the display.




You can set the device to turn off at the present time.

ON-Timer


- The device will turn on at the designated times.



1 Press the (ON-TIMER) button the (ON) mark blinks on the display.




ON/OFF-Timer




- The device will turn on (off) and off (on) at the designated times.
- The switching occurs first at the preset time that comes earlier.
- The arrow mark appearing on the display indicates the sequence of switching operations.


1 Press the (ON-OFF) button so that the (OFF) mark blinks.



2 Set the turn-off time with the TIMER control button. Press the (RESERVE) button.



3 Press the (ON-TIMER) button so that the (OFF) mark lights and the (ON) mark blinks.




How to Cancel Reservation

Point the signal window of the remote controller toward the indoor unit, and press the (CANCEL) button.

The (RESERVED) sign goes out with a beep and the (TIMER) lamp turns off on the indoor unit.


NOTE


You can set only one of the OFF-timer, ON-timer and ON/OFF-timer.


2 Press the  (TIME) button.




3 Set the current time with the TIMER control button.




4 Press the  (TIME) button again. The time indication starts lighting instead of flashing.







- The time indication will disappear automatically in 10 seconds.
- To check the current time setting, press the  (TIME) button twice. The setting of the current time is now complete.


Example: The current time is 1:30 p.m.

2 Set the turn-off time with the TIMER control button.



3 Point the signal window of the remote controller toward the indoor unit, and press the  (RESERVE) button.


The  (OFF) mark starts lighting instead of flashing and the sign  (RESERVED) lights. A beep occurs and the  (TIMER) lamp lights on the indoor unit.







Example: The device will turn off at 11:00p.m.


The setting of turn-off time is now complete.

2 Set the turn-on time with the TIMER control button.




3 Point the signal window of the remote controller toward the indoor unit, and press the  (RESERVE) button.


The  (ON) mark starts lighting instead of flashing and the  (RESERVED) sign lights. A beep occurs and the  (TIMER) lamp lights on the indoor unit.







Example:
The device will automatically turn on earlier so that the preset temperature can be reached at 7:00 a.m.
The setting of the turn-on time is now complete.

4 Set the turn-on time with the TIMER control button.




5 Point the signal window of the remote controller toward the indoor unit, and press the  (RESERVE) button.


The  (ON) mark starts lighting instead of flashing and the  (RESERVED) sign lights. A beep occurs and the  (TIMER) lamp lights on the indoor unit.




Example:
The device will turn off at 10:30 p.m. and then automatically turn on earlier so that the preset temperature can be reached at 7:00 a.m.
The settings of the turn-on/off times are now complete.


- The timer may be used in three ways: off-timer, on-timer, and ON/OFF (OFF/ON)-timer. Set the current time at first because it serves as a reference.
- As the time settings are stored in memory in the remote controller, you only have to press the  (RESERVE) button in order to use the same settings next time.

HOW TO SET THE SLEEP TIMER



Set the current time first if it is not set before (see the pages for setting the current time). Press the  (SLEEP) button, and the display changes as shown below.




• SLEEP

Mode	Indication
Sleep timer	

Sleep Timer: The device will continue working for the designated number of hours and then turn off. Point the signal window of the remote controller toward the indoor unit, and press the SLEEP button. The timer information will be displayed on the remote controller. The TIMER lamp lights with a beep from the indoor unit. When the sleep timer has been set, the display indicates the turn-off time.





Example: If you set 3 hours sleep time at 11:38 p.m., the turn-off time is 2:38 a.m.



The device will be turned off by the sleep timer and turned on by on-timer.

1 Set the ON-timer.


2 Press the  (SLEEP) button and set the sleep timer.




Example:

In this case, the device will turn off in 2 hours (at 1:38 a.m.) and turn on early so that the preset temperature will be almost reached at 6:00 next morning.

How to Cancel Reservation

Point the signal window of the remote controller toward the indoor unit, and press the  (CANCEL) button.

The  (RESERVED) sign goes out with a beep and the  (TIMER) lamp turns off on the indoor unit.

Explanation of the sleep timer

The device will control the FAN SPEED and room temperature automatically so as to be quiet and good for people's health.

You can set the sleep timer to turn off after 1, 2, 3 or 7 hours. The FAN SPEED and room temperature will be controlled as shown below.

Operation with the sleep timer

Function	Operation
Cooling “ ❄ ” and dehumidifying “ 💧 ”	<p>The room temperature will be controlled 2°C above the temperature and the FAN SPEED will be set to LOW setting 1 hour after the setting of the sleep timer.</p>
Fan “ ✂ ”	<p>The settings of room temperature and circulation are varied.</p>

NOTE

- If date or current time is not set, sleep timer can not be set.
- If you set the sleep timer after the off-, on/off- or off/on-timer has been set, the sleep timer becomes effective instead of the off-, on/off- or off/on-timer set.
- You can not set other timer during sleep timer operation.
- The angle of horizontal air deflector shifts up automatically after three hours on sleep timer operation.
- Fan will stop for a while if room temperature reaches setting temperature.

HOW TO EXCHANGE THE BATTERIES IN THE REMOTE CONTROLLER


1 Remove the cover as shown in the figure and take out the old batteries.



2 Install the new batteries.
The direction of the batteries should match the marks in the case.

⚠ CAUTION

1. Do not use new and old batteries, or different kinds of batteries together.
2. Take out the batteries when you do not use the remote controller for 2 or 3 months.




THE IDEAL WAYS OF OPERATION

Suitable Room Temperature



⚠ Warning
Freezing temperature is bad for health and a waste of electric power.

Install curtain or blinds



It is possible to reduce heat entering the room through windows.


Ventilation

⚠ Caution
Do not close the room for a long period of time. Occasionally open the door and windows to allow the entrance of fresh air.




Effective Usage Of Timer

At night, please use the "OFF or ON timer operation mode", together with your wake up time in the morning. This will enable you to enjoy a comfortable room temperature. Please use the timer effectively.




Do Not Forget To Clean The Air Filter

Dusty air filter will reduce the air volume and the cooling efficiency. To prevent from wasting electric energy, please clean the filter every 2 weeks.



Please Adjust Suitable Temperature For Baby And Children

Please pay attention to the room temperature and air flow direction when operating the unit for baby, children and old folks who have difficulty in movement.




FOR USER'S INFORMATION

The Air Conditioner And The Heat Source In The Room


⚠ Caution

If the amount of heat in the room is above the cooling capability of the air conditioner (for example: more people entering the room, using heating equipments and etc.), the preset room temperature cannot be achieved.



Not Operating For A Long Time


When the indoor unit is not to be used for a long period of time, please switch off the power from the mains. If the power from mains remains "ON", the indoor unit still consumes about 8W in the operation control circuit even if it is in "OFF" mode.



When Lightning Occurs

⚠ Warning


To protect the whole unit during lightning, please stop operating the unit and remove the plug from the socket.



Interference From Electrical Products

⚠ Caution

To avoid noise interference, please place the indoor unit and its remote controller at least 1m away from electrical products.



ATTACHING THE AIR CLEANSING AND DEODORIZING FILTERS


⚠ CAUTION

Cleaning and maintenance must be carried out only by qualified service personal. Before cleaning, stop operation and switch off the power supply.

1

Open the front panel.


- Pull up the front panel by holding it at both sides with both hands.



2

Remove the filter.


- Push upward to release the claws and pull out the filter.



3


Attaching the air cleansing and deodorizing filters to the filter.

- Attach the air cleansing and deodorizing filters to the frame by gently compress its both sides and release after insertion into filter frame.



⚠ CAUTION


Do not bend the air cleansing and deodorizing filter as it may cause damage to the structure.



4

Attach the filters.

- Attach the filters by ensuring that the surface written "FRONT" is facing front.
- After attaching the filters, push the front panel at three arrow portion as shown in figure and close it.



NOTE

- In case of removing the air cleansing and deodorizing filters, please follow the above procedures.
- The cooling capacity is slightly weakened and the cooling speed becomes slower when the air cleansing and deodorizing filters are used. So, set the fan speed to "HIGH" when using it in this condition.
- Air cleansing and deodorizing filters are washable and reusable up to 20 times by using vacuum cleaner or water rinse under running tap water. Type number for this air cleansing filter is <SPX-CFH11>. Please use this number for ordering when you want to renew it.
- Do not operate the air conditioner without filter. Dust may enter the air conditioner and fault may occur.

MAINTENANCE

⚠ CAUTION


Cleaning and maintenance must be carried out only by qualified service personal. Before cleaning, stop operation and switch off the power supply.

1. AIR FILTER


Clean the air filter, as it removes dust inside the room. In case the air filter is full of dust, the air flow will decrease and the cooling capacity will be reduced. Further, noise may occur. Be sure to clean the filter following the procedure below.

PROCEDURE


- 1 Open the front panel and remove the filter
 - Gently lift and remove the air cleansing and deodorizing filter from the air filter frame.



- 2 Vacuum dust from the air filter and air cleansing and deodorizing filter using vacuum cleaner. If there is too much dust, rinse under running tap water and gently brush it with soft bristle brush. Allow filters to dry in shade.



- 3
 - Re-insert the air cleansing and deodorizing filter to the filter frame. Set the filter with "FRONT" mark facing front, and slot them into the original state.
 - After attaching the filters, push the front panel at three arrow portions as shown in figure and close it.



NOTE:

- Air cleansing and deodorizing filter should be cleaned every month or sooner if noticeable loading occurs. When used overtime, it may loose its deodorizing function. For maximum performance, it is recommended to replace it every 3-6 months depending on application requirements.

⚠ CAUTION

- Do not wash with hot water at more than 40°C. The filter may shrink.
- When washing it, shake off moisture completely and dry it in the shade; do not expose it directly to the sun. The filter may shrink.
- Do not use detergent on the air cleansing and deodorizing filter as some detergent may deteriorate the filter electrostatic performance.

2. Washable Front Panel


- Remove the front panel and wash with clean water.
Wash it with a soft sponge.
After using neutral detergent, wash thoroughly with clean water.
- When front panel is not removed, wipe it with a soft dry cloth. Wipe the remote controller thoroughly with a soft dry cloth.
- Wipe the water thoroughly.
If water remains at indicators or signal receiver of indoor unit, it causes trouble.



Method of removing the front panel.


Be sure to hold the front panel with both hands to detach and attach it.

Removing the Front Panel



- When the front panel is fully opened with both hands, push the right arm to the inside to release it, and while closing the front panel slightly, put it out forward.

Attaching the Front Panel



- Move the projections of the left and right arms into the **Flanges** in the unit and securely insert them into the holes.


CAUTION

- Do not splash or direct water to the body of the unit when cleaning it as this may cause short circuit.
- Never use hot water (above 40°C), benzine, gasoline, acid, thinner or a brush, because they will damage the plastic surface and the coating.




3. MAINTENANCE AT BEGINNING OF LONG OFF PERIOD

- Run the unit by setting the operation mode to FAN (FAN) and the fan speed to HI for about half a day on a fine day, and dry the whole of the unit.
- Switch off the power plug.



CAUTION

- Please use earth line.
Do not place the earth line near water or gas pipes, lightning-conductor, or the earth line of telephone. Improper installation of earth line may cause electric shock.
- A circuit breaker should be installed depending on the mounting site of the unit. Without a circuit breaker, the danger of electric shock exists.



IMPORTANT

The wires in this mains lead are coloured in accordance with the following code:

- Green-and-yellow : Earth
- Blue : Neutral
- Brown : Live

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured green-and-yellow must be connected to the terminal in the plug which is marked with the letter E or by the earth symbol (⊕) or coloured green or green-and-yellow.

The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.

The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

NOTE

If the supply cord is damaged, it must be replaced by the special cord obtainable at authorized service/parts centers.

CAUTION

Cleaning and maintenance must be carried out only by qualified service personal. Before cleaning, stop operation and switch off the power supply.



REGULAR INSPECTION

PLEASE CHECK THE FOLLOWING POINTS BY QUALIFIED SERVICE PERSONAL EITHER EVERY HALF YEARLY OR YEARLY. CONTACT YOUR SALES AGENT OR SERVICE SHOP.

1		Is the earth line disconnected or broken?
2		Is the mounting frame seriously affected by rust and is the outdoor unit tilted or unstable?
3		Is the plug of power line firmly plugged into the socket? (Please ensure no loose contact between them).

AFTER SALE SERVICE AND WARRANTY

WHEN ASKING FOR SERVICE, CHECK THE FOLLOWING POINTS.

CONDITION	CHECK THE FOLLOWING POINTS
 <p>When it does not operate</p>	<ul style="list-style-type: none"> ● Is the fuse all right? ● Is the voltage extremely high or low? ● Is the circuit breaker "ON"?
 <p>When it does not cool well When it does not hot well</p>	<ul style="list-style-type: none"> ● Was the air filter cleaned? ● Does sunlight fall directly on the outdoor unit? ● Is the air flow of the outdoor unit obstructed? ● Are the doors or windows opened, or is there any source of heat in the room? ● Is the set temperature suitable?



Notes

- In quiet operation or stopping the operation, the following phenomena may occasionally occur, but they are not abnormal for the operation.
 - (1) Slight flowing noise of refrigerant in the refrigerating cycle.
 - (2) Slight rubbing noise from the fan casing which is cooled and then gradually warmed as operation stops.
- The odor will possibly be emitted from the room air conditioner because the various odor, emitted by smoke, foodstuffs, cosmetics and so on, sticks to it. So the air filter and the evaporator regularly must be cleaned to reduce the odor.

- Please contact your sales agent immediately if the air conditioner still fails to operate normally after the above inspections. Inform your agent of the model of your unit, production number, date of installation. Please also inform him regarding the fault.
- Power supply shall be connected at the rated voltage, otherwise the unit will be broken or could not reach the specified capacity.

Please note:

On switching on the equipment, particularly when the room light is dimmed, a slight brightness fluctuation may occur. This is of no consequence.

The conditions of the local Power Supply Companies are to be observed.


Note

- Avoid to use the room air conditioner for cooling operation when the outside temperature is below 21°C (70°F).
The recommended maximum and minimum operating temperatures of the hot and cold sides should be as below:

		Minimum	Maximum
Indoor	Dry bulb °C	21	32
	Wet bulb °C	15	23
Outdoor	Dry bulb °C	21	43
	Wet bulb °C	15	26


CONSTRUCTION AND DIMENSIONAL DIAGRAM

MODEL RAS-07G4/09G4/14G4




Note:


1. Servicing space of 100mm or more is required on the left and right sides of the indoor unit and also 50mm or more space is required above the unit
2. Insulated pipes should be used for both the narrow and wide dia. pipes.
3. Piping length is within 15m (RAS-14G4), 10m (RAS-07G4/RAS-09G4)
4. Height different of the piping between the indoor unit and the outdoor unit should be within 5m.
5. Power supply cord length is about 2m
6. Connecting cable 2.5mm² dia. x 3 is used for the connection.



MODEL RAC-07G4 / RAC-09G4



MODEL RAC-14G4



MAIN PARTS COMPONENT



THERMOSTAT

Thermostat Specifications

MODEL			RAS-07G4/09G4/14G4	
THERMOSTAT MODEL			IC	
OPERATION MODE			COOL	
TEMPERATURE °C (°F)	INDICATION 16	ON	16.6 (61.9)	
		OFF	16.0 (60.8)	
	INDICATION 24	ON	24.6 (76.3)	
		OFF	24.0 (75.2)	
	INDICATION 32	ON	32.6 (90.7)	
		OFF	32.0 (89.6)	

FAN MOTOR


Fan Motor Specifications

MODEL		RAS-07G4/09G4/14G4	RAC-07G4/09G4/14G4		
PHASE		-----	SINGLE		
RATED VOLTAGE		DC35V	220-240V		
RATED FREQUENCY		-----	50 Hz		
OUTPUT		20 W	20W	30W	30W
POLE NUMBER		-----	6		
CONNECTION					
RESISTANCE VALUE (Ω)	20°C	-----	RM = 355.1 RA = 252.6	RM = 253.0 RA = 173.4	RM = 250.3 RA = 171.1
	75°C	-----	RM = 431.9 RA = 307.1	RM = 307.7 RA = 210.9	RM = 304.4 RA = 208.1

COMPRESSOR MOTOR

Compressor Motor Specifications

MODEL	RAC-07G4/09G4/14G4			
COMPRESSOR MODEL	5RS080	5PS112	5PS132	
PHASE	SINGLE			
RATED VOLTAGE	220 – 240 V			
RATED FREQUENCY	50 Hz			
LOCKED ROTOR CURRENT	45 A			
POLE NUMBER	2			
CONNECTION				
RESISTANCE VALUE (Ω)	20°C (68°F)	RM = 5.233 RA = 5.621	RM = 3.192 RA = 4.621	RM = 2.826 RA = 5.413
	75°C (167°F)	RM = 6.364 RA = 6.836	RM = 3.882 RA = 5.620	RM = 3.437 RA = 6.583
EXTERNAL OVERLOAD RELAY	YES			
INTERNAL PROTECTOR	NO			




RAC-07G4 / RAC-09G4 / RAC-14G4

CAUTION

When the Air Conditioner has been operated for a long time with the capillary tubes clogged or crushed or with too little coolant, check the color of the refrigerant oil inside the compressor. If the color has been changed conspicuously, replace the compressor.


WIRING DIAGRAM

MODEL RAS-07G4/09G4/14G4//RAC-07G4/09G4/14G4



CIRCUIT DIAGRAM

Remote Control




Key matrix table

Input \ Output		Output			
		D0	D1	D2	D3
P10	Door open	Start/Stop	Operation selection	Fan speed selection	Automatic swing
	Door shut	Start/Stop	Super silent cooling	—	—
P11	Door open	On timer	Hour up	Hour down	Day • present time
	Door shut	—	Room temperature up	Room temperature down	Super cooling
P12	Door open	Off timer	—	Reservation	Cancel
	Door shut	Sleep	—	—	—

PRINTED WIRING BOARD LOCATION DIAGRAM

MODEL RAS-07G4/09G4/14G4



RESISTOR

SYMBOL	RESISTANCE	TOL.	POWER
R2	470K	±5%	1/16W
R3	56	±5%	1/16W
R4	56	±5%	1/16W
R5	680	±5%	1/16W
R7	330	±5%	1/16W
R8	100	±5%	1/16W
R9	15K	±5%	1/16W
R10	1.2K	±5%	1/16W
R11	3.9K	±1%	1/16W
R12	18K	±1%	1/16W
R13	470	±5%	1/16W
R14	2.2K	±5%	1/16W
R100	5.6K	±5%	1/16W
R101	120K	±5%	1/16W
R102	33K	±2%	1/16W
R103	3K	±2%	1/16W
R104	130K	±5%	1/16W
R105	470	±5%	1/16W
R106	330	±5%	1/16W
R107	330	±5%	1/16W
R108	2.2K	±5%	1/16W
R109	220K	±5%	1/16W
R110	2.2	±5%	5W
R111	560K	±5%	1/16W
R141	2.7K	±5%	1/16W

CAPACITOR

SYMBOL	RESISTANCE	TOL.	TYPE
C1	2200P	±50%	C
C2	1000P	±2%	F
C3	0.047µ	±50%	F
C4	0.047µ	±50%	F
C5	0.1µ	±50%	F
C6	0.1µ	±50%	F
C8	1000µ	±50%	D
C10	47µ	±50%	F
C100	0.22µ	±50%	F
C101	10µ	±5%	D
C102	68µ	±50%	D
C103	100µ	±10%	D
C104	0.1µ	±25%	C
C105	1000P	±50%	F
C106	0.1µ	±50%	F
C107	0.047µ	±25%	C
C108	1000P	±50%	F
C109	1µ	±50%	D
C110	0.15µ	±25%	F
C111	0.15µ	±25%	F
C112	10000P	±25%	D
C113	10000P	±25%	D
C114	0.15µ	±25%	F
C115	150µ	±50%	D
C116	10000P	±25%	D
C117	10000P	±25%	D
C118	10000P	±25%	D
C119	10000P	±25%	D
C120	0.0033µ	±25%	D
C121	0.0033µ	±25%	D
C201	100µ	±63%	D
C202	0.1µ	±25%	C
C203	0.1µ	±25%	C
C204	0.1µ	±25%	C
C205	0.1µ	±25%	C
C206	0.1µ	±25%	C
C207	0.1µ	±25%	C
C211	47µ	±6%	D
C212			
C301	0.1µ	±25%	C
C302	0.1µ	±25%	C
C303	0.1µ	±25%	C
C401	0.1µ	±25%	C
C601	0.1µ	±25%	C
C602	0.1µ	±25%	C
C610	0.1µ	±25%	C
C618	0.1µ	±25%	C
C628	0.1µ	±25%	C

WIRES

SYMBOL	MODEL
BLU1	SIN-41T-2.4S
BRN1	SIN-41T-2.4S
BRN2	SIN-41T-2.4S
GRN1	SIN-41T-1.8S
GRN2	SIN-41T-1.8S
GRN3	SIN-41T-1.8S
BLK1	SIN-41T-2.4S
WHT1	SIN-41T-2.4S

DIODE BRIDGE

SYMBOL	MODEL
DB110	D3S80

OTHERS

SYMBOL	MODEL	REMARK
T1	THA0481	TRANS
NF1	SS11V-13035	NOISE FILTER
NF2	SS11V-13035	NOISE FILTER
VS1	450NR12D	VARISTOR
VS2	450NR12D	VARISTOR
VS3	450NR12D	VARISTOR
SA101	DSA-102MA-05F25	SURGE ABSORBER
PQ1	PC817X7	PHOTO COUPLER
FUSE	250V 3.15A	FUSE

RESISTOR

SYMBOL	RESISTANCE	TOL.	POWER
R201	5.1K	±5%	1/16W
R202	5.1K	±5%	1/16W
R203	2K	±5%	1/16W
R204	5.1K	±5%	1/16W
R205	2.7K	±5%	1/16W
R206	10K	±5%	1/16W
R207	10K	±5%	1/16W
R208	10K	±5%	1/16W
R209	1K	±5%	1/16W
R210	1M	±5%	1/16W
R211	1K	±5%	1/16W
R212	47	±5%	1/16W
R302	1K	±5%	1/16W
R303	10K	±5%	1/16W
R304	2.4K	±2%	1/16W
R307	1K	±5%	1/16W
R308	18K	±1%	1/16W
R309	1K	±5%	1/16W
R310	12.7K	±1%	1/16W
R311	10K	±5%	1/16W
R312	10K	±5%	1/16W
R401	390	±5%	1/16W
R402	390	±5%	1/16W
R403	5.1K	±5%	1/16W
R404	5.1K	±5%	1/16W
R410	10K	±5%	1/16W

CAPACITOR

SYMBOL	RESISTANCE	TOL.	TYPE
C119	10000P	±25%	D
C120	0.0033µ	±25%	D
C121	0.0033µ	±25%	D
C201	100µ	±63%	D
C202	0.1µ	±25%	C
C203	0.1µ	±25%	C
C204	0.1µ	±25%	C
C205	0.1µ	±25%	C
C206	0.1µ	±25%	C
C207	0.1µ	±25%	C
C211	47µ	±6%	D
C212			
C301	0.1µ	±25%	C
C302	0.1µ	±25%	C
C303	0.1µ	±25%	C
C401	0.1µ	±25%	C
C601	0.1µ	±25%	C
C602	0.1µ	±25%	C
C610	0.1µ	±25%	C
C618	0.1µ	±25%	C
C628	0.1µ	±25%	C

DIODE

SYMBOL	MODEL
D1	D1N120U
D2	1SS120
D3	1SS120
D4	SF51C20U
D5	1SS120
D102	1W1G044
D401	HN1D03FU
D901	1SS355
D902	D1FL20U
D904	1SS133
D905	1SS133

OSCILLATOR

SYMBOL	MODEL	FREQ.
OSC1	FFOM3004	10MHz

ZENER DIODE


SYMBOL	MODEL
ZD1	HZ2B2
ZD2	MTZ16.2B
ZD100	RLZ 24B
ZD101	RLZ 16B
ZD102	PTZ20B
ZD103	RLZ 6.8B
ZD141	LDZS 5.6B
ZD201	IRLZ 27B

RESISTOR

SYMBOL	RESISTANCE	TOL.	POWER
R411	10K	±5%	1/16W
R412	10K	±5%	1/16W
R413	10K	±5%	1/16W
R601	10K	±5%	1/16W
R603	1K	±5%	1/16W
R604	10K	±5%	1/16W
R606	10K	±5%	1/16W
R607	10K	±5%	1/16W
R608	1K	±5%	1/16W
R609	1K	±5%	1/16W
R610	1K	±5%	1/16W
R611	10K	±5%	1/16W
R613	10K	±5%	1/16W
R614	1K	±5%	1/16W
R615	10K	±5%	1/16W
R616	10K	±5%	1/16W
R617	240	±5%	1/16W
R618	240	±5%	1/16W
R620	10K	±5%	1/16W
R621	10K	±5%	1/16W
R622	10K	±5%	1

BLOCK DIAGRAM

MODEL RAS-07G4/09G4/14G4//RAC-07G4/09G4/14G4



BASIC MODE

MODEL RAS-07G4/09G4/14G4//RAC-07G4/09G4/14G4

No.	Operation mode	Fan	Cooling	Sensor dehumidification	Circulation	Automatic					
1	ON / OFF switch, basic mode										
2	Timer operation	OFF timer				* Both operation lamp and Dry lamp light during Sensor dehumidification at operation mode.					
		ON timer									
		OFF ⇄ ON timer									
3	Fan speed mode	Automatic	<ul style="list-style-type: none"> • "HI", "MED", or "LO" operation is executed according to the thermostat signal. (Refer to "Thermostat operation".) 								
		HI	<ul style="list-style-type: none"> • Operation in "HI" mode 	<ul style="list-style-type: none"> • Same as on the left. 	<ul style="list-style-type: none"> • "LO" and "Stop" are repeated according to the thermostat signal, independent of the setting. 	<ul style="list-style-type: none"> • Repetition of "HI" and "Stop" by means of thermo signal and time. 	<ul style="list-style-type: none"> • The "Automatic" speed mode for each operation mode is used independent of the setting. ("LO" at the time of "Sensor dehumidification".) 				
		MED	<ul style="list-style-type: none"> • Operation in "MED" mode 	<ul style="list-style-type: none"> • Same as on the left. 		<ul style="list-style-type: none"> • Repetition of "MED" "Stop" by means of thermo signal and time. 					
		LO	<ul style="list-style-type: none"> • Operation in "LO" mode 	<ul style="list-style-type: none"> • Same as on the left. 		<ul style="list-style-type: none"> • Repetition of "LO" "Stop" by means of thermo signal and time. 					
4	Thermostat operation	<ul style="list-style-type: none"> • Only circulation with cut velocity is executed, independent of the thermostat signal. 	<p>(1) In case of "Automatic" mode</p> <p>Note:</p> <ul style="list-style-type: none"> • The min. ON time of the power relay is 3 minutes, and the min. OFF time also is 3 minutes. 	<p>(1) When the set temperature is lower than the room temperature.</p> <p>Notes:</p> <ul style="list-style-type: none"> • The min. ON time of the power relay is 3 minutes, and the min. OFF time also is 3 minutes. • The indoor fan is not delayed with operation start by ON / OFF button. 		<p>(2) In other modes than "Automatic" Same as above (but operation is made with the velocity set at the time of operation start).</p> <p>Notes:</p> <ul style="list-style-type: none"> • Forced operation by ON / OFF button ON is executed even with thermostat OFF. • The room temperature 30 sec after operation start, minus 0.66 deg, becomes the set temperature. • When the room temperature is 16°C or lower, 16°C becomes the set temperature. • The other operations are the same as for (1). 		<p>(1) Strong</p>	<p>Room temperature at the start of operation</p> <table border="1"> <tr> <td>Cooling</td> <td>The set temperature shall be 27°C.</td> </tr> <tr> <td>Sensor dehumidification</td> <td>The set temperature shall be 2 degrees below the room temperature at the start of operation.</td> </tr> </table> <p>Notes</p> <ul style="list-style-type: none"> • A shift is not accepted at the time of operation start. • There is no switching between modes after start of operation. • When the operation is started again within 20 hours after stop with the ON / OFF button, operation will be executed in the previous mode. • The operation details are the same as for each operation mode. • The set temperature is set with the room temperature adjustment button. Correction by V, ±3°C is possible with. At this time, the operation mode judgement temperature also is shifted at the same time. However, correction is possible only in cooling operation mode, but not in "Sensor dehumidification" mode. 	Cooling	The set temperature shall be 27°C.
Cooling	The set temperature shall be 27°C.										
Sensor dehumidification	The set temperature shall be 2 degrees below the room temperature at the start of operation.										

No.	Operation mode Control function	Fan	Cooling	Sensor dehumidification	Circulation	Automatic
5	<p>Sleep mode</p> <ul style="list-style-type: none"> The set temperature after sleep shift in sensor dehumidification operation is limited by 16°C. 	<ul style="list-style-type: none"> The operation is switched OFF at the set time. 	<p>Notes:</p> <ul style="list-style-type: none"> 60 minutes after the sleep key is switched on, sleep operation is started. When the sleep key is switched on during OFF timer operation, the OFF timer will be canceled. The sleep operation is started when the sleep key is "ON" after timer reservation. 		<ul style="list-style-type: none"> The operation is switched OFF at the set time. 	<ul style="list-style-type: none"> Sleep operation is executed for each operation mode.

6 "NICE TEMPERATURE" reservation

- Operation starts in advance so that the room temperature reaches the preset value at the set time.
- The operation time is obtained as follows depending on the room temperature when operation starts.

(1) Calculation method of the moved-up time.
 Moved-up time (MT) = Moved-up time depending on the temperature difference (OT) + compensation time (HT).
 MT is at least 5 minute if OT is not zero.

	Cooling
(MT)	00 ~ 60 min.
(OT)	00 ~ 60 min.
(HT)	-60 ~ 60 min.

Obtain OT (moved-up time depending on the temperature difference) from the table below.

Cooling			
Setting temp.	Room temp.	Time (min.)	
00.00	02.00	00	
02.25	05.00	15	
05.25	08.00	30	
08.25	11.00	45	
11.25	-	60	

* The preset temperature value shown above does not include any shift value.

(2) Compensation

- ① The "Attained" state is monitored and a "Not attained" check is done to revise the compensation time (HT).

"Attained" monitor
Continuously monitored during "NICE TEMPERATURE" operation.
(Cooling) _____ When the room temperature < Set value + compensation shift, it is regarded to be "attained" and 5 minutes are reduced from the cooling compensation time.
"Not attained" check
Performed once when the "NICE TEMPERATURE" timer is completed.
(Cooling) _____ When the room temperature > Set value + compensation shift +1°C, it is regarded to be "Not attained" and 5 minutes are added to the cooling compensation time.
* If the room temperature is within +1°C from the set value + compensation shift, compensation is not done.

8	Air blowing direction control	<ul style="list-style-type: none"> • The air deflector control operation shown below is done when the swing switch is pressed or when the operation mode is changed. • The air deflector control operation shown below is done when the operation switch is turned off after the filter sign lamp is lit. 	
		Item	Specification
			3-way AUTO (Swing)
		Cooling/dehumidifying	
Circulator	<p>The same as cooling • dehumidifying</p>		
(When the operation switch is turned off after the filter sign lamp lights.)			

Table 1 Specifications

Item	RAS-07G4/09G4/14G4	
Operation switching	Automatic	Yes
	Circulator	Yes
	Sensor dehumidification	Yes
	Cooling	Yes
	Fan	Yes
Temporary switch	Yes (automatic)	
Service switch	Cooling	Yes
Nice temperature reservation	Yes	
Defrosting	No	
Sleep circuit	Yes	
Heater operation at the time of sensor dehumidification	No	
Automatic blowing direction	Yes	
Filter sign	Yes	
Wireless mode	Cooling	

Table 2 Sensor operation values


Item	RAS-07G4/09G4/14G4			
Thermostat operation	ON temperature (Thermostat relay) power relay (°C)	Cooling, sensor dehumidification	16	17.6
			24	25.6
			32	33.6
	Differential (°C)			0.33
Low-temperature defrosting	(T1)	ON (°C)	4.0	
		Reset (°C)	12.0	

Other detailed specifications


1. When the room temperature starts to increase within 3 minutes after thermo OFF in "cooling" and fan speed "AUTO", the fan speed changes L → M → H as when thermo ON.
2. If "cooling" is selected during "sensor dehumidification" operation the operation continues as it is with the thermo ON. The 3 minutes delay is not started. The set temperature and fan speed depend on the remote control signal. It is same for "cooling" --- "sensor dehumidification". It is same for "AUTO" sensor dehumidification cooling "sensor dehumidification" "cooling".
3. The filter sign lights after 100 hours operation of the room fan. The time is cleared when power switch set to OFF and ON again.
4. After the failure mode is started (indicator lamp flickering), rapid mode changing cannot be done.
5. If the operation is made by the nice temperature reservation during the sleep operation, the normal operation continuously occurs, and for the advance time, the temperature difference between the set temperature without sleep shift and "room temperature" is used.

REFRIGERANT CYCLE DIAGRAM


MODEL RAS-07G4/RAC-07G4



MODEL RAS-09G4/RAC-09G4



MODEL RAS-14G4/RAC-14G4



DESCRIPTION OF MAIN CIRCUIT OPERATION

1. ON / OFF

The "ON / OFF" and "Timer reserve button" and "Sleeping" function independently. Their operations are shown in Fig. 1-1.






Fig. 1-1 Timer operation

2. Reset Circuit



- The reset circuit is used to reset the program to its initial settings when the power is turned on or when the power is recovered after a power failure.
- The micro computer is reset when the reset input is “Hi”, and operation is possible when the reset input is “Lo”.
- The waveforms at each point when the power is turned on and off are shown in the diagrams.
- When the power is turned on, the voltages of the DC 12V line and DC 5V lines are increased. When the voltage of DC 12V lines reaches about 7V, ZD201 is turned ON, the potential of Q201’s base rises and Q201 is turned ON. Since Q201’s collector is set to “LO” at this time, Q202 is turned OFF and the reset input of the micro computer is set to “Lo”. The DC 5V line voltage has already become 5V at this time and the micro computer starts operation.
- When the power is turned OFF, the voltage of the DC 12V line decreases. When it becomes about 7V, ZD201 is turned OFF, then Q201 is turned OFF, Q202 is turned ON the reset input of the micro computer is set to “Hi” and the micro computer is set to the reset mode.

3. Buzzer Circuit




Fig. 3-1 Buzzer Circuit

- When the buzzer sounds, an approx. 3.9kHz square signal is output from buzzer output pin ②① of the micro computer. After the amplitude of this signal has been set to 12Vp-p by a transistor, it is applied to the buzzer. The piezoelectric element in the buzzer oscillates to generate the buzzer's sound.






Fig. 3-2 Buzzer Operation

4. Initial setting (IC401)

The pre-heating operation start value, ratings of the compressor, maximum rotation speed, etc. are preset in the micro computer.




5. Receive circuit



Infrared signals from the wireless remote controller are received by the light receiving unit and output after being amplified and shaped.

6. Service Operation Circuit



- Use the service switch to select “Cooling” temporarily when the interior electric equipment has troubled.
- Setting the switch to “Cooling” causes continuous cooling room temperature control. To control the room temperature, turn on and off the disconnect switch. To protect the compressor, wait at least 3 minutes before turning on again.
- The fan speed is “MED”.
- Does not operate is 12V is not generated in the control circuit.
- When the service switch is used for operation, each change switch is overridden.
- Setting the service switch to “Cooling” turns on the “Power relay”.

7. Auto Sweep Motor Circuit




Fig. 7-1 Auto Sweep Motor Circuit (Horizontal air deflectors)

- Fig. 7-1 shows the Auto sweep motor drive circuit; the signals shown in Fig. 7-2 are output from pins ④⑧—⑤① of the micro computer.

Micro computer pins	Step width						Horizontal air deflectors: 10ms.	
Horizontal air deflectors	1	2	3	4	5	6	7	8
⑤①	[Active]							
⑤②	[Active]						[Active]	[Active]
④⑨					[Active]	[Active]	[Active]	
④⑧			[Active]	[Active]	[Active]			

Fig. 7-2 Micro computer Output Signals

- As the micro computer's outputs change as shown in Fig. 7-2, the core of the auto sweep motor is excited to turn the rotor. Table 7-1 shows the rotation angle of horizontal air deflectors.

Table 7-1 Auto sweep Motor Rotation

	Rotation angle per step (°)	Time per step (ms)
Horizontal air deflectors	0.0879	10

8. Room Temperature Thermistor Circuit

- Fig. 8-1 shows the room temperature thermistor circuit.




Fig. 8-1

- The voltage at (A) depends on the room temperature as shown in Fig. 8-2.




Fig. 8-2

9. Heat exchanger temperature thermistor circuit




Fig. 9-1

- The circuit detects the indoor heat exchanger temperature and controls the following.
 - (1) Low-temperature defrosting during cooling and dehumidifying operation.

The voltage at (A) depends on the heat exchanger temperature as shown in Fig. 9-2.




Fig. 9-2

10. Temporary Switch




Fig. 10-1

- The temporary switch is used to operate the air conditioner temporarily when the wireless remote control is lost or faulty.
- The air conditioner operates in the previous mode at the previously set temperature. However, when the power switch is set to OFF, it starts automatic operation.

11. DC Fan Motor Drive Circuit

- Fig. 11-1 shows the indoor DC fan motor drive circuit.




Fig. 11-1

- The circuit produces the fan motor drive voltages, 8-33V, from 35V DC supplied from the outdoor unit and controls the fan motor speed.
- Q901 is switched on and off according to the signal at fan PWM output pin ⑤⑦ to control the voltage which is smoothed by D902, L901 and C901 to drive the fan motor.
- The output voltage is divided by R919 and R920 and is input to divided voltage output pin ⑧; the micro computer controls the fan PWM output so the output voltage is set to the specified value. The chopper frequency of the fan PWM output is 15.7kHz.
- In the Fan current detection circuit, 35V line current is detected by R906 and input to fan current detection pin ⑨. Microcomputer detects overcurrent comparing it with the current judgment value corresponding to the fan rotation speed.




Fig. 11-2

AUTO SWING FUNCTION

INPUT SIGNAL	PRESENT CONDITION		OPERATING SPECIFICATION	REFERENCE
	OPERATION	OPERATION MODE		
KEY INPUT	STOP	EACH MODE	STOP	ONE SWING (CLOSING AIR DEFLECTOR) ① DOWNWARD ② UPWARD
	DURING OPERATION	AUTO COOL COOL FAN AUTO DRY DRY	DURING ONE SWING	STOP AT THE MOMENT. START SWINGING ① DOWNWARD ② UPWARD ③ DOWNWARD
INTERNAL FAN ON (THERMO. ON)	DURING OPERATION	CIRCULATOR	STOP	START SWINGING ① DOWNWARD ② UPWARD ③ DOWNWARD
			DURING SWINGING	STOP AT THE MOMENT.
INTERNAL FAN OFF (THERMO. OFF)	DURING OPERATION	AUTO DRY DRY CIRCULATOR	TEMPORARY STOP	START SWING AGAIN.
			DURING SWINGING	STOP SWINGING TEMPORARILY. (SWING MODE IS CLEARED IF SWING COMMAND IS TRANSMITTED DURING TEMPORARY STOP.)
MAIN SWITCH ON	STOP	COOL FAN DRY	STOP DURING ONE SWING	INITIALIZE ① DOWNWARD ② UPWARD
		CIRCULATOR	STOP DURING ONE SWING	INITIALIZE ① DOWNWARD
MAIN SWITCH OFF	DURING OPERATION	EACH MODE	STOP DURING SWINGING	ONE SWING (CLOSING AIR DEFLECTOR) ① DOWNWARD ② UPWARD
			DURING INITIALIZING	INITIALIZING CONDITION OF EACH MODE.
CHANGE OF OPERATION	DURING OPERATION	EACH MODE	STOP	INITIALIZE AT NEXT OPERATION.
			DURING SWINGING	STOP SWINGING AND MODE BECOMES INITIALIZING CONDITION.

SERVICE CALL Q & A

Cooling operation

Q1 While cooling, the compressor sometimes stops abruptly.

A1 Check whether frost sticks on the heat exchanger of indoor unit or not. Wait for 3 – 4 minutes until the frost melts.

If cooling is performance when the room temperature is low, frost may stick on the heat exchanger of indoor unit.

Dehumidifying operation

Q2 The fan speed does not change during a dehumidifying operation.

A2 The fan speed is always LO at a dehumidifying operation.

Q3 Cold air comes out during a dehumidifying operation.

A3 To improve the dehumidification efficiency, LO fan speed operation is performed. Therefore the air is cold. This is not a trouble.

Q4 The operation does not stop even by raising the room temperature setting of remote control at a dehumidifying operation.

A4 At a dehumidifying operation, the actual room temperature is compared with the room temperature setting when starting the operation and the operation is as follows.

- 1) When actual room temperature > room temperature setting.
The operation is according to the room temperature setting on the remote controller.
- 2) * When actual room temperature < room temperature setting
Regardless of the room temperature setting, the temperature is automatically set slightly lower than the room temperature.
In this case, the status is as 2) and, therefore, the operation by the room temperature control is impossible. Turn off the On / OFF switch, set the room temperature to a new value and turn on the operation by the On / Off switch.

Q5 In the dehumidifying mode, the temperature set by remote controller is set slightly higher than the room temperature but the operation starts.

A5 This is the status in 2) of (A4). The temperature is set a little lower than the room temperature to carry out a dehumidifying operation as far as possible.

Automatic operation

Q6

How is the automatic operation mode determined?

A6

According to the room temperature, cooling or dehumidifying operation is automatically selected.

Cooling:

When room temperature is approx. 27°C or higher

Dehumidifying:

When room temperature is between approx. 23°C and 27°C

Q7

At an automatic operation, changing the fan speed change switch does not vary the fan speed.

A7

The fan speed is automatically determined.

Q8

The room temperature cannot be controlled at an automatic operation.

A8

It is automatically set as follows.

At cooling: Set at 27°C

At dehumidifying:

Set slightly lower than room temperature

The room temperature setting can be raised 3°C by “Λ” or lowered 3°C by “V”.


When changing the room temperature setting in an automatic operation, the next automatic operation mode is determined by new room temperature setting. If, for example, the room temperature setting is 2°C lowered for example, the operation mode is as follows.

Cooling : When room temperature is approx. 25°C or higher

Dehumidifying : When room temperature is between approx. 21°C and 25°C


Common, etc.

Q9 There is a difference between the room temperature setting and actual room temperature.




A9 There may be a difference between the room temperature setting and actual room temperature on account of the room structure, air flow, etc. If there is a difference from the room temperature, adjust the set temperature to keep living space at a comfortable temperature.

Q10 What will happen if the time setting is changed while in a timer operation?



A10 A timer operation is performed until the time after changing the time setting.

Q11 In the "Automatic fan speed" mode, the indoor fan changes to MED and LO fan speed.




A11 It is not a trouble. The cold wind preventive function operates.

Set the temporary switch normal.


Nice temperature reservation

Q12 In case of "ON" timer, the operation does not start at a preprogrammed time but a little earlier.



A12 The "Nice temperature reservation" functions. The operation starts earlier so the room temperature will be as set at a programmed time. The operation starts at most 60 minutes before a preprogrammed time.


Q13 The time to start an operation is irregular while preprogramming at the same time.



A13 The "Nice temperature reservation" operates. The starting time depends on the room load.

Q14

- 1) When the "Automatic" operation mode is selected, "Automatic" does not change by pressing the fan speed select button.
- 2) The room temperature setting is not displayed.
- 3) Pressing the room temperature control button develops transmit mark "📶" and sounds a receive sound but does not display the room temperature setting.




A14

- 1) When the operation mode is "Automatic", the fan speed is automatically fixed to "Automatic".
- 2) At an "Automatic" operation, the room temperature setting is not displayed. The room temperature is automatically set as follows.
At cooling
Set at 27°C.
At dehumidifying
Set to a temperature slightly lower than the room temperature.
- 3) At an "Automatic" operation, the room temperature setting is not displayed. However, every pressing "Λ" or "V" button changes 1°C within the range of:
27±3°C when cooling.

The room temperature sensing thermistor in the indoor unit detects the room temperature and, according to the particular temperature, automatically performs "Cooling" or "Dehumidifying" operation. The value indicated not at an "Automatic" but manual operation is not the actual room temperature but the room temperature setting.

Q15

When the room temperature setting is "16", pressing the room temperature control button "V" causes no transmission. At "32", pressing "Λ" causes no transmission either.




A15

The room temperature is settable within the range of 16 - 32 and not beyond.

Q16

The timer cannot be set.




A16

Is the current time set?
The timer cannot be set unless the clock is adjusted correctly.

Q17

The current time disappears soon.




A17

The current time disappears soon and the timer setting indication takes a precedence.


When setting the current time, its indication blinks for approximately 3 minutes.

Q18 In spite of timer “Preprogram”, the time setting is extinguished.



A18 Isn't the time over the pre-programmed time?
As soon as the preprogrammed time is reached, the time setting disappears.

Q19 After selecting a “Dehumidifying” operation mode, the fan speed mode remains “LO” fan speed”.




A19 At a “Dehumidifying” operation, the “LO” fan speed” is forcibly selected.

TROUBLE-SHOOTING

No cooling

Operates by setting the service switch to forced cooling?



Return the service switch to "Normal".



Set the remote controller to an operation status and press the ON/OFF button.



Is the level LO (approx. 0.5V) between driver IC501 pin ⑩ power relay and 0V?



Is voltage normal between Blue wire and Red wire of Indoor DC Fan Motor *3



No operation at all.



NO

*1 Before using the service switch, disengage and engage the plug. Do not operate the remote controller.

Check the following parts and replace if faulty	
1) Current fuse	Remove and check the continuity across.
2) Varistor	Check whether the appearance is blackish or not. The resistance must be infinite. *2
3) Power switch	Check the continuity between contacts.
4) Thermal fuse for Terminal board	(102°C) Continuity across → If there is no continuity, check the electric parts and replace if abnormal.

*2 Before checking the varistor, detach a terminal.



Power relay abnormal




Replace Power relay


YES
Compressor does not turn at LO.



Indoor fan motor or Q903 abnormal



YES









*3

CN6 BLUE-RED (V)			
	RAS-07G4 RAC-07G4	RAS-09G4 RAC-09G4	RAS-14G4 RAC-14G4
Fan Speed	Cool	Cool	Cool
HI	20.8	21.3	27.0
MED	15.6	18.0	20.9
LO	12.5	13.7	15.8
SLEEP MODE	11.0	11.9	13.0

Timer-Lamp, break-down checking in blinking sign.

Check the break-down factor from the frequency of timer-lamp blinking.

No.	Mode of Timer-Lamp blinking	Indication Factor	Estimated Break-Down Part
1	 2 times	<u>Force cooling operation</u> Unit is under forcible operation or under balancing after forcible operation.	Check force cooling switch at indoor electrical.
2	 10 times	<u>DC Fan motor - over flow of electricity</u> Indoor - DC Fan motor has over flow of electricity.	(1) Indoor - Fan is locked. (2) Indoor - Fan motor damage. (3) Indoor - control circuit board.
3	 13 times	<u>IC 401 Data read wrongly</u> In case that data read from IC401 is wrong.	IC401 data is not in order.
4	 14 times	<u>Heat exchanger thermistor error</u> Heat exchanger thermistor open or short-circuit detected.	(1) Thermistor (2) Indoor - control circuit board.
5	 15 times	<u>Room thermistor error</u> Room thermistor error open or short-circuit detected.	(1) Thermistor (2) Indoor - control circuit board.

( -- 0.5 second on, 0.5 second off.)


CAUTION

Remote control is disabled while the Timer lamp is flashing.
To check operation, turn off the power switch and turn it on again.

PARTS LIST AND DIAGRAM

INDOOR UNIT

MODEL : RAS-07G4 / RAS-09G4 / RAS-14G4



MODEL RAS-07G4

NO.	PART NO. RAS-07G4	Q'TY / UNIT	PARTS NAME
1	HWRAS-25YH4 901	1	CABINET
2	HWRAS-25YH4 940	1	MOUNTING PLATE
3	PMRAS-07GH4 001	1	FAN MOTOR
4	HWRAS-25YH4 907	1	TANGENTIAL FAN
5	HWRAS-25YH4 908	1	P-BEARING ASSY
6	HWRAS-25YH4 910	1	FAN MOTOR BASE
7	PMRAS-07GH4 002	1	CYCLE ASSY
8	HWRAS-25YH4 909	1	FAN COVER
9	HWRAS-25YH4 914	1	PIPE SUPPORT
10	HWRAS-25YH4 926	1	DRAIN PAN ASSY
11	HWRAS-25YH4 929	1	AUTO SWEEP MOTOR
13	HWRAS-25YH4 933	1	FRONT COVER ASSY
14	HWRAS-25YH4 936	1	FRONT PANEL
15	HWRAS-25YH4 937	1	AIR FILTER (R)
16	HWRAS-25YH4 938	1	AIR FILTER (L)
17	PMRAS-51CHA1 011	1	REMOTE CONTROL ASSEMBLY
18	PMRAS-10C3M 003	1	REMOTE CONTROL SUPPORT
19	PMRAS-10C8M 003	1	THERMISTOR SUPPORT
20	PMRAS-07CH2 012	1	THERMISTOR
21	HWRAS-25YH4 920	1	POWER SWITCH
22	PMRAS-07G4 001	1	P.W.B (MAIN)
23	PMRAS-N09S 004	1	P.W.B (POWER SW SUPPLY)
24	HWRAS-25YH4 916	1	TERMINAL BOARD (THERM-FUSE)
26	HWRAS-25YH4 939	1	LOW COVER

MODEL RAS-09G4

NO.	PART NO. RAS-09G4	Q'TY / UNIT	PARTS NAME
1	HWRAS-25YH4 901	1	CABINET
2	HWRAS-25YH4 940	1	MOUNTING PLATE
3	PMRAS-07GH4 001	1	FAN MOTOR
4	HWRAS-25YH4 907	1	TANGENTIAL FAN
5	HWRAS-25YH4 908	1	P-BEARING ASSY
6	HWRAS-25YH4 910	1	FAN MOTOR BASE
7	PMRAS-07GH4 002	1	CYCLE ASSY
8	HWRAS-25YH4 909	1	FAN COVER
9	HWRAS-25YH4 914	1	PIPE SUPPORT
10	HWRAS-25YH4 926	1	DRAIN PAN ASSY
11	HWRAS-25YH4 929	1	AUTO SWEEP MOTOR
13	HWRAS-25YH4 933	1	FRONT COVER ASSY
14	HWRAS-25YH4 936	1	FRONT PANEL
15	HWRAS-25YH4 937	1	AIR FILTER (R)
16	HWRAS-25YH4 938	1	AIR FILTER (L)
17	PMRAS-51CHA1 011	1	REMOTE CONTROL ASSEMBLY
18	PMRAS-10C3M 003	1	REMOTE CONTROL SUPPORT
19	PMRAS-10C8M 003	1	THERMISTOR SUPPORT
20	PMRAS-07CH2 012	1	THERMISTOR
21	HWRAS-25YH4 920	1	POWER SWITCH
22	PMRAS-09G4 001	1	P.W.B (MAIN)
23	PMRAS-N09S 004	1	P.W.B (POWER SW SUPPLY)
24	HWRAS-25YH4 916	1	TERMINAL BOARD (FUSE)
26	HWRAS-25YH4 939	1	LOW COVER


MODEL RAS-14G4

NO.	PART NO. RAS-14G4	Q'TY / UNIT	PARTS NAME
1	HWRAS-25YH4 901	1	CABINET
2	HWRAS-25YH4 940	1	MOUNTING PLATE
3	PMRAS-07GH4 001	1	FAN MOTOR
4	HWRAS-25YH4 907	1	TANGENTIAL FAN
5	HWRAS-25YH4 908	1	P-BEARING ASSY
6	HWRAS-25YH4 910	1	FAN MOTOR BASE
7	PMRAS-07GH4 002	1	CYCLE ASSY
8	HWRAS-25YH4 909	1	FAN COVER
9	HWRAS-25YH4 914	1	PIPE SUPPORT
10	HWRAS-25YH4 926	1	DRAIN PAN ASSY
11	HWRAS-25YH4 929	1	AUTO SWEEP MOTOR
13	HWRAS-25YH4 933	1	FRONT COVER ASSY
14	HWRAS-25YH4 936	1	FRONT PANEL
15	HWRAS-25YH4 937	1	AIR FILTER (R)
16	HWRAS-25YH4 938	1	AIR FILTER (L)
17	PMRAS-51CHA1 011	1	REMOTE CONTROL ASSEMBLY
18	PMRAS-10C3M 003	1	REMOTE CONTROL SUPPORT
19	PMRAS-10C8M 003	1	THERMISTOR SUPPORT
20	PMRAS-07CH2 012	1	THERMISTOR
21	HWRAS-25YH4 920	1	POWER SWITCH
22	PMRAS-14G4 001	1	P.W.B (MAIN)
23	PMRAS-N09S 004	1	P.W.B (POWER SW SUPPLY)
24	HWRAS-25YH4 916	1	TERMINAL BOARD (FUSE)
26	HWRAS-25YH4 939	1	LOW COVER

PARTS LIST AND DIAGRAM

INDOOR UNIT

MODEL : RAC-07G4 / RAC-09G4



MODEL RAC-07G4


NO.	PART NO. RAC-07G4	Q'TY / UNIT	PARTS NAME
2	PMRAC-07GH4 907	1	STRAINER (CAPILLARY)
3	PMRAC-07GH4 908	1	STRAINER (CONDENSOR)
4	PMRAC-05CV 901	1	FAN MOTOR SUPPORT
5	PMRAC-10C8 908	1	FAN MOTOR
6	PMRAC-10CV6 903	1	PROPELLER FAN
7	PMRAC-07CH2 901	1	CABINET
9	PMRAC-05CV 906	1	SIDE PLATE (R)
10	PMRAC-05CV 907	1	SIDE PLATE (L)
11	PMRAC-05CV 908	1	HANDLE
12	PMRAC-09CHA1 903	1	D-GRILL
13	PMRAC-07GH4 901	1	COMPRESSOR
14	PMRA-08GF 904	3	COMPRESSOR RUBBER
15	PMRA-08GF 905	3	COMPRESSOR NUT
16	PMRAC-07GH4 902	1	CONDENSER
17	PMRAC-07GH4 904	1	2S-VALVE
18	PMRAC-07GH4 905	1	3S-VALVE
30	PMRAC-10C8 905	1	FAN MOTOR CAPACITOR
31	PMRAC-18CVP2 901	1	TERMINAL BOARD (2P)
50	PMRAC-07GH4 906	1	COMPRESSOR CAPACITOR
51	PMRAC-07GH4 903	1	REVERSING VALVE
52	PMRAC-07GH4 909	1	OVERLOAD PROTECTOR

MODEL RAC-09G4

NO.	PART NO. RAC-09G4	Q'TY / UNIT	PARTS NAME
1	PMRAC-09GH4 904	1	CHECK VALVE
2	PMRAC-07GH4 907	1	STRAINER (CAPILLARY)
3	PMRAC-09GH4 905	1	STRAINER (CONDENSOR)
4	PMRAC-05CV 901	1	FAN MOTOR SUPPORT
5	PMRAC-10C7 903	1	FAN MOTOR
6	PMRAC-10CV6 903	1	PROPELLER FAN
7	PMRAC-09GH4 907	1	CABINET
9	PMRAC-05CV 906	1	SIDE PLATE (R)
10	PMRAC-05CV 907	1	SIDE PLATE (L)
11	PMRAC-05CV 908	1	HANDLE
12	PMRAC-09CHA1 903	1	D-GRILL
13	PMRAC-09GH4 901	1	COMPRESSOR
14	PMRA-08GF 904	3	COMPRESSOR RUBBER
15	PMRA-08GF 905	3	COMPRESSOR NUT
16	PMRAC-09GH4 902	1	CONDENSER
17	PMRAC-07GH4 904	1	2S-VALVE
18	PMRAC-07GH4 905	1	3S-VALVE
30	PMRAC-10C7 904	1	FAN MOTOR CAPACITOR
31	PMRAC-18CVP2 901	1	TERMINAL BOARD
50	PMRAC-09GH4 903	1	COMPRESSOR CAPACITOR
51	PMRAC-07GH4 903	1	REVERSING VALVE
52	PMRAC-09GH4 906	1	OVERLOAD PROTECTOR

PARTS LIST AND DIAGRAM

OUTDOOR UNIT MODEL : RAC-14G4



MODEL RAC-14G4

NO.	PART NO. RAC-14G4	Q'TY / UNIT	PARTS NAME
1	KPNT1 001	3	PUSH NUT
2	PMRAC-14GH4 901	1	COMPRESSOR
3	RAC-2226HV 805	3	COMPRESSOR RUBBER
4	PMRAC-25NH4 904	1	VALVE (2S)
5	PMRAC-25NH4 905	1	VALVE (3S)
6	PMRAC-25NH4 901	1	CONDENSOR
7	PMRAC-51CA1 905	1	FAN MOTOR SUPPORT
8	PMRAC-18C7 901	1	FAN MOTOR
9	PMRAC-25CNH2 902	1	PROPELLER FAN
10	PMRAC-18CVP2 901	1	TERMINAL BOARD
11	PMRAC-09GH4 903	1	COMPRESSOR CAPACITOR
12	PMRAC-10C7 904	1	FAN MOTOR CAPACITOR
13	PMRAC-14GH4 902	1	HANDLE
14	PMRAC-51CA1 901	1	CABINET
15	PMRAC-09CHA1 903	1	D-GRILL
16	PMRAC-14GH4 905	1	SIDE PLATE (R)
17	PMRAC-51CA1 908	1	NET
18	PMRAC-51CA1 909	1	TOP COVER
21	PMRAC-07GH4 903	1	REVERSING VALVE
22	PMRAC-14GH4 903	1	STRAINER (CAPILLARY)
23	PMRAC-14GH4 904	1	STRAINER (CONDENSOR)
24	PMRAC-09GH4 904	1	CHECK VALVE
25	PMRAC-14GH4 906	1	OVERLOAD PROTECTOR

HITACHI

RAS-07G4 / RAC-07G4
RAS-09G4 / RAC-09G4
RAS-14G4 / RAC-14G4

PM NO. 0198E

Printed in Malaysia