

Air Conditioners

Technical Data







Air Conditioners

Technical Data





TABLE OF CONTENTS

BSVQ-P8

1	Specifications Technical Specifications Electrical Specifications
2	Safety device settings Safety Device Settings
3	Options Options
4	Dimensional drawings Dimensional Drawings
5	Centre of gravity Centre of Gravity
6	Piping diagrams Piping Diagrams
7	Wiring diagrams - Single Phase
8	Sound data

1 Specifications

1-1 Technical	Specifications				BSVQ100P8	BSVQ160P8	BSVQ250P8
Power input	Cooling	Nom.		kW		0.005	
	Heating	Nom.	Nom.		0.005		
Maximum number of	connectable indoor u	ınits			6		8
Maximum capacity in	dex of connectable in	ndoor units			15 <x≤100< td=""><td>100<x≤160< td=""><td>160<x≤250< td=""></x≤250<></td></x≤160<></td></x≤100<>	100 <x≤160< td=""><td>160<x≤250< td=""></x≤250<></td></x≤160<>	160 <x≤250< td=""></x≤250<>
Casing	Material				Galvanised	steel plate	Galvanised steel
Dimensions	Unit	HeightxV pth	VidthxDe	mm		207x388x326	
Weight	Unit			kg	1	2	15
Piping connections	1	Liquid	d Type		Brazing connection		
			OD	mm	9.5		
		Gas Dischar ge gas	Туре		Brazing connection		
			OD	mm	15.9	15.9 (1)	22.2
			Туре			Brazing connection	
			OD	mm	12.7	12.7 (1)	19.1
	Indoor unit	Liquid	Туре		Brazing connection		
			OD	mm	9.5 (1)	9	.5
		Gas Type		•		Brazing connection	
			OD	mm	15.9	15.9 (1) 22.2	
Sound absorbing the	rmal insulation	•	•	•	Foame	d polyurethane, frame resisting ne	edle felt

Standard Accessories : Clamps;

Standard Accessories : Insulation pipe cover; Standard Accessories : Attached piping; Standard Accessories : Installation manual;

1-2 Electrical Specifications			BSVQ100P8	BSVQ160P8	BSVQ250P8	
Power supply	Phase			1~		
	Voltage		220-240			
	Voltage range	Min.	%		-10	
		Max.	%		10	
Total circuit	Minimum circuit amps (MCA) A		0.1			
	Maximum fuse amps (MFA) A		15			
Notes		Instead of a fuse, use a circuit breaker		er		

Notes

- (1) In case of connection with a 20~50 type indoor unit, match to the size of the field pipe using the attached pipe. Connection between the attached pipe and the field pipe must be brazed.
- (2) Voltage range: units are suitable for use on electrical systems where voltage supplied to unit terminal is not below or above listed range limits.
- (3) Maximum allowable voltage range variation between phases is 2%.
- (4) MCA/MFA: MCA = 1.25 x FLA
- (5) MFA \leq 4 x FLA
- (6) Next lower standard fuse rating minimum 15A
- (7) Select wire size based on the value of MCA
- (8) Instead of a fuse, use a circuit breaker
- (9) In case of connecting with indoor unit capacity index between 150 and 160, match to the size of the field pipe using the attached pipe. Connection between the attached pipe and the field pipe must be brazed.
- (10) In case of connecting with a 200 type indoor unit or capacity index more than 160 and less than 200, match to the size of the field pipe using the attached pipe. Connection between the attached pipe and the field pipe must be brazed.

2 Safety device settings

2 - 1 Safety Device Settings

Model	Safety devices	
Wiodei	PC board fuse	
BSVQ100PV1	250V 3.15A	
BSVQ160PV1	250V 3.15A	
BSVQ250PV1	250V 3.15A	
BSVQ36PVJU	250V 3.15A	
BSVQ60PVJU	250V 3.15A	
BSVQ96PVJU	250V 3.15A	

3 Options

3 - 1 Options

BSVQ-P8

OPTION LIST

No	Item	BSVQ100P	BSVQ160P	BSVQ250P
1	PCB for multi tenant		DTA114A61	
2	Sound reduction for BSVQ box	El	KBSVQLNP (see note	2)


4TW31159-1A

NOTE


- 1 All options are kits.
- Only available for standard BSVQ boxes (not possible for central BSV4Q). Allows to reduce operating sound of BSVQ-box (requires 1 sound kit per BSVQ-box).

4 Dimensional drawings

4 - 1 Dimensional Drawings







350 or more	350 or more
(Servicing space)	(Servicing space)

(In case of use Attached pipe)

	Nr	Name	Description
	1	Suction gas pipe connection port	ø15.9mm brazing connection
	2	HP/LP gas pipe connection port	ø12.7mm brazing connection
	3	Liquid pipe connection port	ø9.5mm brazing connection
	4	Gas pipe connection port	ø15.9mm brazing connection
	5	Liquid pipe connection port	ø9.5mm brazing connection
	6	Electric box (note 1.)	
	7	Suspension brackets	M8 ~M10
	8	Grounding terminal	M4
	9	Attached pipe (1) (Note. 3)	ø19.1mm brazing connection
ī [10	Attached pipe (2) (Note. 3)	ø15.9mm brazing connection

Notes


- 1 Electric box can also be fixed on the other side of the unit.
- Be sure to install an inspection door at electric box side.
- 3 Attached pipe is only used in case of connecting with indoor unit capacity index 150 or more and 160 or less.
- 4 Small sound of refrigerant will be made, which may be disturbing.

Do not install it at the place such as bedroom under roof.

3D058004


4 Dimensional drawings

4 - 1 Dimensional Drawings




5 Centre of gravity

5 - 1 Centre of Gravity



In case of the electrical box on the standard side of the unit



In case of the electrical box on the other side of the unit

3D058132

6 Piping diagrams


6 - 1 Piping Diagrams

6

BSVQ-P8 Liquid pipe connection port Liquid pipe connection port Electric Expansion Valve (EVSC) Double pipe heat exchanger Filter Capillary tube Electric Expansion Valve (EVHS) Gas pipe connection port Electric Expansion Valve (EVH) HP/LP gas pipe connection port Electric Expansion Valve (EVLS) Suction gas pipe connection port Filter Electric Expansion Valve (EVL) 4D057985B

7 Wiring diagrams

7 - 1 Wiring Diagrams - Single Phase



A1P	Printed circuit board	X1M	Terminal strip (power)	Y5E	Electronical expansion valve (main suction)
DS1, DS2	Dip switch	X1M (A1P)	Terminal strip (control)	Z1C	Noise filter (ferrite core)
F1U	Fuse (T, 3.15A, 250V)	X2M	Terminal strip (C/H selector)		
F2U	Field fuse	Y1E	Electronical expansion valve (sub cool)		Connector for optional parts
HAP	Light emitting diode (service monitor green)	Y2E	Electronical expansion valve (sub discharge)	X2A	Connector (wiring external control adapter for outdoor)
PS	Switching power supply	Y3E	Electronical expansion valve (sub suction)	X38A	Connector (adapter for multi tenant)
Q1DI	Earth leak detector	Y4E	Electronical expansion valve (main discharge)		

: Terminal strip L : Live Colors: BLU Blue
: Connector N : Neutral RED Red

-── : Terminal
---- : Field wiring

⊕ : Protective earth (screw)

3TW31796-1

NOTES

- 1 This wiring diagram applies to the BS unit only.
- $2\qquad \hbox{When using the COOL/HEAT selector (optional accessory), connect it to terminals A, B and C on X2M.}$
- 3 As for wiring to the IN/D unit (F1) (F2) and OUT/D unit (F1)-(F2) on X1M (A1P), refer to the installation manual.
- 4 Use copper conductors only.
- 5 Dip switch (DS1-2) initial settings are as follows.




For using dip switch (DS1-2), refer to the installation manual or to the 'service label' on de el.compo.box cover.

BVSQ160P8B

8

8 Sound data

Sound Pressure Spectrum 8 - 1



4D058945

NOTE


- Over All (dB): (B, G, N is already rectified)
- Operating conditions:
 - Power source: 220-240V 50Hz
 - Standard condition (JIS)
- Measuring place: Anechoic chamber.
- Operation noise differs with operation and ambient conditions.
- In case of other unit operating in the same system, operating sound will be generated, ever if indoor unit connected to BS unit is stopped.
- Location of microphone.




Scale	Operation sound	Stoppage sound
A	42	32
С	49	40

Scale	Operation sound	Stoppage sound
Α	42	32
С	49	40

Location of microphone.





4D058946

Stoppage

Operation

NOTE

- Over All (dB):
 - (B, G, N is already rectified)
- Operating conditions:
 - Power source: 220-240V 50Hz
 - Standard condition (JIS)
- Measuring place: Anechoic chamber.
- Operation noise differs with operation and ambient conditions.
- In case of other unit operating in the same system, operating sound will be generated, ever if indoor unit connected to BS unit is stopped.
- Location of microphone.





Daikin's unique position as a manufacturer of air conditioning equipment, compressors and refrigerants has led to its close involvement in environmental issues. For several years Daikin has had the intention to become a leader in the provision of products that have limited impact on the environment. This challenge demands the eco design and development of a wide range of products and an energy management system, resulting in energy conservation and a reduction of waste.







The present publication is drawn up by way of information only and does not constitute an offer binding upon Dalkin Europe N.V. Dalkin Europe N.V. has compiled the content of this publication to the best of its knowledge. No express or implied warranty is given for the completeness, accuracy, reliability or fitness for particular purpose of its content and the products and services presented therein. Specifications are subject to change without prior notice. Dalkin Europe N.V. explicitly rejects any liability for any direct or indirect damage, in the broadest sense, arising from or related to the use and/or interpretation of this publication. All content is copyrighted by Dalkin Europe N.V.

Daikir	products	are	distributed	by:

 VRV^{\bullet} products are not within the scope of the Eurovent certification programme.